### **Dell Command | Configure**

Version 4.1.0 Release Notes



| Notes, cautions, and warnings  |
|--|
| <ul> <li>NOTE: A NOTE indicates important information that helps you make better use of your product.</li> <li>△   CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.</li> <li>▲   WARNING: A WARNING indicates a potential for property damage, personal injury, or death.</li> </ul> |
|  |
|  |
|  |
|  |
|  |
|  |
|  |
|  |
| © 2009 2018 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.  |
|  |

### Contents

| Release Type and Definition  | 4  |
|--|----|
| Version  | 4  |
| Release Date   | 4  |
| Previous Version   | 4  |
| Importance   | 5  |
| Platform(s) Affected   | 6  |
| Supported Operating Systems  | 7  |
| What's New In This Release   | 8  |
| Known Issues: Command Line Interface   | 9  |
| Issue: Unable to use Dell Command   Configure after reinstallation/upgrade                                     | 9  |
| Issue: Windows 7 does not recognize the digital signature validity   | 9  |
| Issue description: Do not use the infile or outfile options in the .ini file                                   | 9  |
| Issue description: Dell Command   Configure supports only single-byte characters for asset set operation       | 9  |
| Issue: TPM-related tokens can be modified independently  | 9  |
| Issue: Dependent options are not working as configured in UEFI mode for Legacy Option ROM and                  |    |
| Secure Boot  |    |
| Issue: Blinkpsu1led and Blinkpsu2led missing in the .ini file or SCE   | 10 |
| Issue: advsm option displays the status as Other   | 10 |
| Issue: Advance Battery Charge and Peak Shift Charge options display Disable                                    | 10 |
| Issue: Temperature probe in Advanced System Management option displays as Unknown                              | 10 |
| Issue: On some of the platforms that support Advanced System Management option, temperature probe              |    |
| of Memory sensor 2 displays the current status as Non-Critical instead of Normal                               | 10 |
| Issue: On some of the platforms that support Advanced System Management option, when you set non-              |    |
| critical upper threshold values for cooling device, the CLI indicates that the action failed; however, setting |    |
| the same is successful   |    |
| Issue: Unable to configure ASM (advsm) BIOS options in .ini file/SCE   | 11 |
| Known Issues: Graphical User Interface   | 12 |
| Issue: Unexpected Error at System.xml  |    |
| Issue: Unexpected Error  |    |
| Issue: Multiplatform displays X mark   |    |
| Issue: The GUI doesn't display the configuration when open it by double clicking the .cctk file                |    |
| Issue: The feedback link does not work with Internet Explorer version 7 and before                             | 12 |
| Fixes  | 13 |
| Fix: Dell Command   Configure sets an unknown password for the BIOS issue has been resolved                    |    |
| Fix: Local package takes few seconds to load for the first time issue has been resolved                        | 13 |
| Fix: GUI Application takes few seconds to exit if closed immediately after launch issue has been               |    |
| resolvedFix: Issue in validating the feature for non enum types has been resolved                              | 13 |
| Installation prerequisites   | 14 |
| Installation Prerequisites for Windows   |    |
| Installation Prerequisites for Linux   |    |
| Installation, Upgrade, and Uninstallation Instructions   |    |
| Contacting Dell  | 16 |

#### Release Type and Definition

Dell Command | Configure (formerly known as Client Configuration Toolkit or CCTK) is a packaged software that provides BIOS configuration capability to Dell client systems specific to IoT running the supported Microsoft Windows, Linux, and Ubuntu operating systems. You can configure the client systems using a Graphical User Interface (GUI) or a Command Line Interface (CLI) and is applicable to Dell Edge Gateway and Dell Embedded Box systems.

You can use Dell Command | Configure on systems running Linux operating systems such as Ubuntu Core OS 16. Also, Dell Command | Configure supports Microsoft Windows 10 operating systems, and Windows Preinstallation Environment (Windows PE).

#### Version

4.1.0

#### **Release Date**

May 2018

#### **Previous Version**

4.0

### **Importance**

RECOMMENDED: Dell recommends applying this update during your next scheduled update cycle. The update contains feature enhancements or changes that will help keep your system software current and compatible with other system modules (firmware, BIOS, drivers and software).

### Platform(s) Affected

- OptiPlex
- Latitude
- Internet of Things
- XPS Notebook
- Precision

#### (i) NOTE:

- Dell Command | Configure 4.0.0 or later requires platforms supporting WMI-ACPI BIOS. The complete functionalities of Dell Command | Configure is available for the supported platforms, refer the Supported Platforms list for more information.
- For the limited functionalities on non WMI-ACPI compliant platforms, see Windows SMM Security Mitigations Table (WSMT) Compliance section in Dell Command | Configure Version 4.1.0 User's Guide.

#### **Supported Operating Systems**

Dell Command | Configure supports the following operating systems:

- Windows 10 Redstone 1
- · Windows 10 Redstone 2
- Windows 10 Redstone 3
- Microsoft Windows 10 Core (32-bit and 64-bit)
- Microsoft Windows 10 Pro (64-bit)
- · Microsoft Windows 10 Enterprise (32-bit and 64-bit)
- · Microsoft Windows 8.1 Enterprise (32-bit and 64-bit)
- · Microsoft Windows 8.1 Professional (32-bit and 64-bit)
- Microsoft Windows 8 Enterprise (32-bit and 64-bit)
- Microsoft Windows 8 Professional (32-bit and 64-bit)
- · Microsoft Windows 7 Professional SP1 (32-bit and 64-bit)
- · Microsoft Windows 7 Ultimate SP1 (32-bit and 64-bit)
- · Windows 10 Pre-installation Environment (32-bit and 64-bit) (Windows PE 10.0)
- · Windows 8.1 Pre-installation Environment (32-bit and 64-bit) (Windows PE 5.0)
- · Windows 8 Pre-installation Environment (32-bit and 64-bit) (Windows PE 4.0)
- · Windows 7 SP1 Pre-installation Environment (32-bit and 64-bit) (Windows PE 3.1)
- · Windows 7 Pre-installation Environment (32-bit and 64-bit) (Windows PE 3.0)
- · Red Hat Enterprise Linux 7.0 Client version (64-bit) for Dell Precision workstations
- · Red Hat Enterprise Linux 6.8 Client Version (64-bit) for Dell Precision workstations
- · Red Hat Enterprise Linux 7.5
- · Ubuntu Desktop 16.04 (64-bit)

#### What's New In This Release

The new features for this release include:

- · Updated attribute names and possible values.
  - i NOTE: To view the complete list of the new and the older names:
  - Go to dell.com/techcenter and search for Dell Command | Configure page using the Search box at the top-right corner of the page.
- · Support for the following new BIOS attributes:
  - --BroadcomTruManage, --SecureBootMode, --DustFilter, -BIOSEnumMode, --FanSpdAutoLvlonCpuZone, --FanSpdAutoLvlonPsuZone, --PcieBusAllocation, --TbtPcieModeAutoSwitch and --WakeOnLan2.
- · Support for Thermal Configuration category.
- · Significant performance improvement:
  - GUI launch time has been improved
  - SCE execution time has been improved
  - Configuration read and write time using command line has been improved

(i) NOTE: For more details on CLI options, see *Dell Command | Configure Command Line Interface Reference Guide* available at dell.com/dellclientcommandsuitemanuals.

#### **Known Issues: Command Line Interface**

### Issue: Unable to use Dell Command | Configure after reinstallation/upgrade

**Description:** Dell command | Configure may not work after reinstallation/upgrade on Ubuntu Desktop 16.04 because **dcdbus** module may not be loaded during reinstallation.

**Resolution:** Load the module by running the following command:

insmod <filename>

### Issue: Windows 7 does not recognize the digital signature validity

**Description:** If the system is not connected to internet, Windows 7 does not recognize the digital signature validity of Dell Command | Configure installation file.

**Resolution:** Connect the system to internet and validate the digital signature.

## Issue description: Do not use the infile or outfile options in the .ini file.

# Issue description: Dell Command | Configure supports only single-byte characters for asset set operation.

Resolution: If the user has a different locale, change the keyboard layout to English before using the asset option.

### Issue: TPM-related tokens can be modified independently

**Description:** Dell Command | Configure does not control the dependencies among the various TPM PPI options. For example, it is possible to change the **TPM PPI ACPI** option through Dell Command | Configure even when TPM is not **On**.

(i) NOTE: There is no negative impact due to this on the BIOS.

# Issue: Dependent options are not working as configured in UEFI mode for Legacy Option ROM and Secure Boot

#### **Description:**

- · Dell Command | Configure allows enabling Legacy Option ROM when Secure Boot is On.
- Dell Command | Configure allows disabling Legacy Option ROM when Boot mode is Legacy.

- · Dell Command | Configure allows enabling Secure Boot when Legacy option ROM is enabled and boot mode is UEFI.
- · Dell Command | Configure does not allow enumerating Secure Boot when it is disabled.
- (i) NOTE: There is no negative impact due to this on the BIOS. This issue will be addressed in the upcoming BIOS versions.

### Issue: Blinkpsu1led and Blinkpsu2led missing in the .ini file or SCE

**Description:** Blinkpsu1led and Blinkpsu2led will not be present in the .ini file or SCE as they are enable-only tokens and they are active only for few seconds. These tokens cannot be modified using GUI.

#### Issue: advsm option displays the status as Other

Description: If any of the fans is not working, the advsm option displays the status as Other.

## Issue: Advance Battery Charge and Peak Shift Charge options display Disable

**Description:** Platforms that do not support Advance Battery Charge option, when advbatterychargecfg option is enumerated, the system displays the option as Disable.

Platforms that do not support **Peak Shift Charge** option, when **peakshiftcfg** option is enumerated, the system displays the option as **Disable**.

#### Issue: Temperature probe in Advanced System Management option displays as Unknown

**Description:** On some platforms that support **Advanced System Management** option, temperature probe of all the sensors displays as **Unknown**.

i NOTE: This issue will be addressed in the upcoming BIOS versions.

Issue: On some of the platforms that support Advanced System Management option, temperature probe of Memory sensor 2 displays the current status as Non-Critical instead of Normal.

i NOTE: This issue is addressed in the upcoming BIOS versions.

Issue: On some of the platforms that support Advanced System Management option, when you set non-critical upper threshold values for cooling device, the CLI indicates that the action failed; however, setting the same is successful.

Issue: Unable to configure ASM (advsm) BIOS options in .ini file/SCE

**Description:** While configuring ASM (advsm) option using .ini file, or SCE, Setup password or System password should not be set or modified.

#### **Known Issues: Graphical User Interface**

#### Issue: Unexpected Error at System.xml

**Description:** Dell Command | Configure GUI supports only printable characters for its text-entry fields. If the BIOS has non-printable characters, the GUI may fail to load and display the following error message: **Unexpected Error at System.xml.** 

Resolution: Make sure that BIOS options such as asset, and propowntag values do not contain non-printable characters.

#### **Issue: Unexpected Error**

**Description:** Rarely, when .NET libraries may not have loaded properly, while exporting the SCE the following error message is displayed: **Unexpected Error**.

i NOTE: This does not affect the Dell Command | Configure functionality

Resolution: Export the SCE again, and it will be successful.

#### Issue: Multiplatform displays X mark

**Description:** On systems that support features like **peak shift**, **irsttimer** and **advanced battery charge** options, the multiplatform displays **X** mark in multi-platform package after validation.

## Issue: The GUI doesn't display the configuration when open it by double clicking the .cctk file

**Description:** If Dell Command | Configure GUI is opened by double clicking the .cctk file, it does not display the settings of the file in the application. However, opening the .cctk or .ini file in **Open a Saved Package** tab displays the settings of the file.

### Issue: The feedback link does not work with Internet Explorer version 7 and before

**Description:** The feedback link in the GUI works only in Internet Explorer version 8 and later.

**Resolution:** Upgrade to Internet Explorer 8 or later.

#### **Fixes**

### Fix: Dell Command | Configure sets an unknown password for the BIOS issue has been resolved

**Description:** While running the following command cctk.exe --setuppwd --valsetuppwd=abcd1234, Dell Command | Configure displays **Only validation option. No actions will be performed. Password is set successfully** message issue has been resolved now.

### Fix: Local package takes few seconds to load for the first time issue has been resolved

**Description:** noe you launch the GUI Application for the first time, the local system package takes few seconds to load. As a result of that, the application takes few seconds to display the data grid. This delay is not observed during the next cycle onwards issue has been resolved now.

# Fix: GUI Application takes few seconds to exit if closed immediately after launch issue has been resolved

**Description:** Once you launch the GUI Application and close it immediately, the closure is delayed by few seconds. This happens for the first time and is not observed during the next cycle onwards issue has been resolved now.

### Fix: Issue in validating the feature for non enum types has been resolved

#### Installation prerequisites

The prerequisites for the systems running Microsoft Windows and Linux operating systems:

#### Topics:

- Installation Prerequisites for Windows
- · Installation Prerequisites for Linux

#### **Installation Prerequisites for Windows**

- The Dell Command | Configure installation file, Dell-Command-Configure\_<SWB>\_WIN\_4.1.0.
   build number>\_A00.EXE available at dell.com/support.
- Workstation running a supported Microsoft Windows operating system.
- · Administrator privileges on the system to install Dell Command | Configure .
- · Microsoft .NET 4.0 to install and run the GUI.
- NOTE: Select Microsoft .NET Framework 4.0 or later on the Turn Windows features on or off screen on systems running Windows 7 or later operating systems.
- (i) NOTE:
  - When the system does not have a WMI-ACPI compliant BIOS, the limited functionality is available. Update the BIOS with a
    compatible version, if available. For more information, see Windows SMM Security Mitigations Table (WSMT) Compliance section
    in Dell Command | Configure User's Guide.

#### **Installation Prerequisites for Linux**

The Dell Command | Configure installation package is available at: dell.com/support for RHEL and Ubuntu Desktop.

· Red Hat Package Managers (RPMs) / Debians provided in the Dell Command | Configure installation file.

#### ① NOTE:

- If you have downloaded the package for RHEL, then you have the RPMs available in the package.
- If you have downloaded the package for Ubuntu Desktop, then you have the Debians available in the package.
- Root login privileges.

The Dell Command | Configure installation file is available at: Canonical store for Ubuntu Core 16.

- · Snap package version 2.23 or later.
- Root login privileges.

# Installation, Upgrade, and Uninstallation Instructions

For information on installation, uninstallation, and upgrade of Dell Command | Configure, see the Dell Command | Configure Installation Guide at **dell.com/dellclientcommandsuitemanuals**.

#### **Contacting Dell**

(i) NOTE: Dell provides several online and telephone-based support and service options. If you do not have an active Internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog. Availability varies by country and product, and some services may not be available in your area.

To contact Dell for sales, technical support, or customer-service issues:

- 1 Go to dell.com/contactdell.
- 2 Select your country or region from the interactive world map. When you select a region, the countries for the selected regions are displayed.
- 3 Select the appropriate language under the country of your choice.
- 4 Select your business segment. The main support page for the selected business segment is displayed.
- 5 Select the appropriate option depending on your requirement.
- (i) NOTE: If you have purchased a Dell system, you may be asked for the Service Tag.