

Dell Precision Tower 3420

Owner's Manual

Notes, cautions, and warnings

 **NOTE:** A NOTE indicates important information that helps you make better use of your computer.

 **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

© 2019 -2020 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

1 Working on your computer	5
Safety instructions	5
Before working inside your computer	5
Turning off your computer	6
After working inside your computer	6
2 Removing and installing components	7
Recommended tools	7
Removing the cover	7
Installing the cover	7
Removing the front bezel	7
Installing the front bezel	8
Removing the hard drive assembly	8
Installing the hard drive assembly	9
Removing the optical drive	9
Installing the optical drive	10
Removing the intrusion switch	10
Installing the intrusion switch	11
Removing the memory module	11
Installing the memory module	12
Installing the optional PCIe SSD card	12
Removing the optional PCIe SSD card	13
Removing the expansion card	13
Installing the expansion card	14
Removing the power supply unit (PSU)	14
Installing the power supply unit (PSU)	15
Removing the power button	15
Installing the power button	16
Removing the Input/Output (I/O) panel	16
Installing the Input/Output (I/O) panel	17
Removing the system fan	17
Installing the system fan	17
Removing the heat sink fan cover	17
Installing the heat sink fan cover	18
Removing the heat sink assembly	18
Installing the heat sink assembly	19
Removing the processor	19
Installing the processor	20
Removing the system board	20
Installing the system board	21
System board components	22
3 System Setup	23
Boot Sequence	23

Navigation keys.....	23
System Setup options.....	24
Updating the BIOS	30
Jumper settings.....	31
System and setup password.....	31
Assigning a system password and setup password.....	31
Deleting or changing an existing system and/or setup password.....	32
Disabling a system password.....	32
4 Diagnostics.....	33
Enhanced Pre-Boot System Assessment (ePSA) diagnostics.....	33
Troubleshooting your computer.....	33
Power LED diagnostics.....	33
Beep code.....	34
Error messages.....	34
5 Specifications.....	38
6 Contacting Dell.....	42

Working on your computer

Safety instructions

Use the following safety guidelines to help protect your computer from potential damage and to help to ensure your personal safety. Unless otherwise noted, each procedure included in this document assumes that the following conditions exist:

- You have read the safety information that shipped with your computer.
- A component can be replaced or--if purchased separately--installed by performing the removal procedure in reverse order.

NOTE: Disconnect all power sources before opening the computer cover or panels. After you finish working inside the computer, replace all covers, panels, and screws before connecting to the power source.

NOTE: Before working inside your computer, read the safety information that shipped with your computer. For additional safety best practices information, see the Regulatory Compliance Homepage at www.dell.com/regulatory_compliance

CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

CAUTION: To avoid electrostatic discharge, ground yourself by using a wrist grounding strap or by periodically touching an unpainted metal surface, such as a connector on the back of the computer.

CAUTION: Handle components and cards with care. Do not touch the components or contacts on a card. Hold a card by its edges or by its metal mounting bracket. Hold a component such as a processor by its edges, not by its pins.

CAUTION: When you disconnect a cable, pull on its connector or on its pull-tab, not on the cable itself. Some cables have connectors with locking tabs; if you are disconnecting this type of cable, press in on the locking tabs before you disconnect the cable. As you pull connectors apart, keep them evenly aligned to avoid bending any connector pins. Also, before you connect a cable, ensure that both connectors are correctly oriented and aligned.

NOTE: The color of your computer and certain components may appear differently than shown in this document.

Before working inside your computer

To avoid damaging your computer, perform the following steps before you begin working inside the computer.

1. Ensure that you follow the [Safety instructions](#).
2. Ensure that your work surface is flat and clean to prevent the computer cover from being scratched.
3. Turn off your computer, see [Turning off your computer](#).

CAUTION: To disconnect a network cable, first unplug the cable from your computer and then unplug the cable from the network device.

4. Disconnect all the network cables from the computer.
5. Disconnect your computer and all attached devices from the electrical outlets.
6. Press and hold the power button while the computer is unplugged to ground the system board.
7. Remove the cover.

CAUTION: Before touching anything inside your computer, ground yourself by touching an unpainted metal surface, such as the metal at the back of the computer. While you work, periodically touch an unpainted metal surface to dissipate static electricity, which could harm internal components.

Turning off your computer

 **CAUTION:** To avoid losing data, save and close all open files and exit all open programs before you turn off your computer.

- Turning off your computer:
 - In Windows 10 (using a touch enabled device or mouse):
 - Click or tap .
 - Click or tap  and then click or touch **Shut down**.
 - In Windows 8 (using a touch enabled device):
 - Swipe in from the right edge of the screen, opening the **Charms** menu and select **Settings**.
 - Tap  and then tap **Shut down**.
 - In Windows 8 (using a mouse):
 - Point to upper-right corner of the screen and click **Settings**.
 - Click  and then click **Shut down**.
 - In Windows 7:
 - Click **Start**.
 - Click **Shut Down**.
 - or
 - Click **Start**.
 - Click the arrow in the lower-right corner of the **Start** menu and then click **Log off**.
- Ensure that the computer and all attached devices are turned off. If your computer and attached devices did not automatically turn off when you shut down your operating system, press and hold the power button for about 6 seconds to turn them off.

After working inside your computer

After you complete any replacement procedure, ensure that you connect any external devices, cards, and cables before turning on your computer.

- Replace the cover.
 -  **CAUTION:** To connect a network cable, first plug the cable into the network device and then plug it into the computer.
- Connect any telephone or network cables to your computer.
- Connect your computer and all attached devices to their electrical outlets.
- Turn on your computer.
- If required, verify that the computer works correctly by running **Dell Diagnostics**.

Removing and installing components


Recommended tools

The procedures in this document require the following tools:

- Small flat blade screwdriver
- Phillips screwdriver
- Small plastic scribe

Removing the cover

1. Follow the procedure in *Before Working Inside Your Computer*.
2. To remove the cover:
 - a) Slide the release latch to unlock the cover [1].
 - b) Slide the cover toward the back of the computer [2].
 - c) Lift the cover from the computer [3].




Installing the cover

1. Align the cover with the tabs on the chassis .
2. Slide the cover until it clicks into place.
3. Follow the procedure in *After Working Inside Your Computer*.

Removing the front bezel

1. Follow the procedure in *Before Working Inside Your Computer*.
2. Remove the [cover](#).
3. To remove the front bezel:
 - a) Lift the retention tabs and release the front bezel [1].
 - b) Lift the front bezel to remove it from the computer [2].



Installing the front bezel


1. Insert the tabs on the bezel into the slots on the computer.
2. Press the bezel until the tabs clicks into place.
3. Install the [cover](#).
4. Follow the procedure in [After Working Inside Your Computer](#).

Removing the hard drive assembly

1. Follow the procedure in [Before Working Inside Your Computer](#).
2. Remove the [cover](#).
3. To release the hard drive assembly:
 - a) Disconnect the data cables from the hard drives [1].
 - b) Lift the hard drive assembly away from the computer [2].



4. To remove the hard drive bracket:
 - a) Pull one side of the hard drive bracket to disengage the pins on the bracket from the slots on the hard drive [1].
 - b) Lift the hard drive out of the hard drive bracket [2].




5. Repeat steps 3 to remove the additional hard drive (if available).

Installing the hard drive assembly

1. Insert the hard drive into the hard drive bracket.
2. Press the securing brackets and slide the hard drive assembly into the bay.
3. Connect the data cable and the power cable to the hard drive.
4. Install the [cover](#).
5. Follow the procedure in [After Working Inside Your Computer](#).


Removing the optical drive

1. Follow the procedure in [Before Working Inside Your Computer](#).
2. Remove the:
 - a) [cover](#)
 - b) [front bezel](#)
3. To release the optical drive :
 - a) Remove the hard drive connector cables from the optical drive latch [1].
 - b) Slide the blue latch to the unlock position [2].



4. To remove the optical drive:
 - a) Hold the blue latch [1], lift the optical drive cage and disconnect the cables from the optical drive [2].

b) Lift the optical drive cage away from the computer [3].



5. To remove the optical drive from the optical drive cage:

- a) Press the optical drive release latch [1] and slide the optical drive forward [2].
- b) Remove the optical drive from the optical drive cage [3].




Installing the optical drive

- 1. Slide the optical drive into the optical drive cage.
- 2. Align the tabs on the optical cage with the slots on the computer.
- 3. Lower the optical drive cage into the computer and lock the latch.
- 4. Connect the data and power cables to the optical drive.
- 5. Install the:
 - a) front bezel
 - b) cover
- 6. Follow the procedure in *After Working Inside Your Computer*.

Removing the intrusion switch

- 1. Follow the procedure in *Before Working Inside Your Computer*.

2. Remove the:
 - a) [cover](#)
 - b) [heat sink fan cover](#)
3. To remove the intrusion switch:
 - a) Disconnect the intrusion switch cable from the connector on the system board [1, 2].
 - b) Slide the intrusion switch and lift it away from the computer [3].




Installing the intrusion switch

1. Insert the intrusion switch into the slot on the chassis.
2. Connect the intrusion switch cable to the system board.
3. Install the:
 - a) [heat sink fan cover](#)
 - b) [cover](#)
4. Follow the procedure in *After Working Inside Your Computer*.

Removing the memory module

1. Follow the procedure in *Before Working Inside Your Computer*.
2. Remove the:
 - a) [cover](#)
 - b) [hard drive](#)
 - c) [optical drive](#)
3. To remove the memory module:
 - a) Press the memory module retention tabs on both sides of the memory module.
 - b) Lift the memory module from the memory module connector on the system board.



Installing the memory module

1. Align the notch on the memory module with the tab on the memory module connector.
2. Insert the memory module into the memory module socket.
3. Press the memory module until the memory module retention tabs click into place.
4. Install the:
 - a) [optical drive](#)
 - b) [hard drive](#)
 - c) [cover](#)
5. Follow the procedure in *After Working Inside Your Computer*.


Installing the optional PCIe SSD card

NOTE: The PCIe SSD card is shipped with the following components:


1. PCIe SSD card
 2. Thermal pad
 3. Screw
1. Follow the procedure in *Before Working Inside Your Computer*
 2. Remove the:
 - a) [cover](#)
 - b) [hard drive](#)
 - c) [optical drive](#)
 3. Peel the adhesive tape (blue) from the rubber.



4. Place the rubber on the computer [1] and peel the adhesive tape (pink) from the rubber [2].



5. To install the SSD card:
 - a) Connect the SSD card to the connector on the system board [1].
 - b) Tighten the screw to secure the SSD card to the system board [2].




Removing the optional PCIe SSD card

1. Follow the procedure in *After Working Inside Your Computer*.
2. Install the:
 - a) [cover](#)
 - b) [hard drive](#)
 - c) [optical drive](#)
3. Remove the screw that secures the PCIe SSD card to the system board.
4. Disconnect the PCIe SSD card from the connector on the system board.
5. Remove the rubber from the system board.

Removing the expansion card

1. Follow the procedure in *Before Working Inside Your Computer*.
2. Remove the [cover](#).
3. To remove the expansion card:
 - a) Pull the metal tab to open the expansion card latch [1].
 - b) Pull the tab forward [2] and pull the expansion card from the connector on the computer [3].




Installing the expansion card

1. Insert the expansion card into the connector on the system board.
2. Press the expansion card until it clicks into place.
3. Close the expansion card latch and press it until it clicks into place.
4. Install the [cover](#).
5. Follow the procedure in *After Working Inside Your Computer*.


Removing the power supply unit (PSU)

1. Follow the procedure in *Before Working Inside Your Computer*.
2. Remove:
 - a) [cover](#)
 - b) [front bezel](#)
 - c) [hard drive](#)
 - d) [optical drive](#)
 - e) [heatsink fan cover](#)
3. To release the PSU:
 - a) Disconnect the power cable from the system board [1, 2].
 - b) Unroute the power cables from the retention clips on the chassis [3].



4. To remove the PSU:

- a) Remove the screws at the back of the computer that secure the PSU to the computer [1].
- b) Press the blue release tab [2] and lift the PSU away from the computer [3].




Installing the power supply unit (PSU)

1. Slide the PSU toward the back of the computer until it clicks into place.
2. Tighten the screws to secure the PSU to the computer.
3. Route the PSU cables through the retention clips.
4. Connect the PSU cables to their connectors on the system board.
5. Install the:
 - a) [heat sink fan cover](#)
 - b) [optical drive](#)
 - c) [hard drive](#)
 - d) [front bezel](#)
 - e) [cover](#)
6. Follow the procedure in [After Working Inside Your Computer](#).

Removing the power button

1. Follow the procedure in [Before Working Inside Your Computer](#).
2. Remove the:
 - a) [cover](#)
 - b) [front bezel](#)
 - c) [hard drive](#)
 - d) [optical drive](#)
3. To remove the power button:
 - a) Disconnect the power switch cable from the system board [1].
 - b) Press the power switch retention tabs and remove it from the chassis [2, 3].



Installing the power button

1. Slide the power switch module into the slot on the chassis until it clicks into place.
2. Connect the power switch cable to the connector on the system board.
3. Install the:
 - a) optical drive
 - b) hard drive
 - c) front bezel
 - d) cover
4. Follow the procedure in *After Working Inside Your Computer*.

Removing the Input/Output (I/O) panel

1. Follow the procedure in *Before Working Inside Your Computer*.
2. Remove the:
 - a) cover
 - b) front bezel
3. To remove the I/O panel:
 - a) Remove the screw that secures the I/O panel to the chassis [1].
 - b) Slide the I/O panel to the right and remove it from the computer [2].




Installing the Input/Output (I/O) panel

1. Insert the I/O panel on the chassis and slide it until it clicks into place.
2. Tighten the screws to secure the I/O panel to the chassis.
3. Install the:
 - a) front bezel
 - b) cover
4. Follow the procedure in *After Working Inside Your Computer*.

Removing the system fan

1. Follow the procedure in *Before Working Inside Your Computer*.
2. Remove the:
 - a) cover
 - b) front bezel
 - c) hard drive
 - d) optical drive
3. To remove the system fan:
 - a) Disconnect the system fan cable from the system board [1].
 - b) Slide the fan grommets toward the slot on the back wall [2].
 - c) Lift the fan away from the computer [3].




Installing the system fan

1. Place the system fan in the computer.
2. Pass the grommets through the chassis and slide outward along the groove to secure it in place.
3. Connect the system fan cable to the system board.
4. Install the:
 - a) optical drive
 - b) hard drive
 - c) front bezel
 - d) cover
5. Follow the procedure in *After Working Inside Your Computer*.

Removing the heat sink fan cover

1. Follow the procedure in *Before Working Inside Your Computer*.
2. Remove the cover.

3. To remove the fan duct:
 - a) Holding the touch points, pull the fan duct bracket to release the fan duct [1].
 - b) Lift the fan duct away from the computer [2].




Installing the heat sink fan cover

1. Align the slots on the fan duct, with the screws on the heat sink.
2. Insert the fan duct until it clicks into place.
3. Install the [cover](#).
4. Follow the procedure in [After Working Inside Your Computer](#).

Removing the heat sink assembly

1. Follow the procedure in [Before Working Inside Your Computer](#).
2. Remove the:
 - a) [cover](#)
 - b) [front bezel](#)
 - c) [hard drive](#)
 - d) [optical drive](#)
 - e) [heat sink fan cover](#)
3. To remove the heat sink assembly:
 - a) Disconnect the heat sink cable from the system board [1].
 - b) Loosen the captive screws that secure the heat sink assembly and lift it away from the computer [2, 3].



Installing the heat sink assembly

1. Place the heat sink assembly onto the processor.
2. Tighten the captive screws to secure the heat sink assembly to the system board.
3. Connect the heat sink cable to the system board.
4. Install the:
 - a) [heat sink fan cover](#)
 - b) [optical drive](#)
 - c) [hard drive](#)
 - d) [front bezel](#)
 - e) [cover](#)
5. Follow the procedure in *After Working Inside Your Computer*.

Removing the processor

1. Follow the procedure in *Before Working Inside Your Computer*.
2. Remove the:
 - a) [cover](#)
 - b) [front bezel](#)
 - c) [hard drive](#)
 - d) [heat sink](#)
3. To remove the processor:
 - a) Release the socket lever by pushing the lever down and out from under the tab on the processor shield [1].
 - b) Lift the lever upward and lift the processor shield [2].
 - c) Lift the processor out of the socket [3].




Installing the processor


1. Align the processor with the socket keys.
2. Align the pin-1 indicator of the processor with the triangle on the socket.
3. Place the processor on the socket such that the slots on the processor align with the socket keys.
4. Close the processor shield by sliding it under the retention screw.
5. Lower the socket lever and push it under the tab to lock it.
6. Install the:
 - a) heat sink
 - b) hard drive
 - c) front bezel
 - d) cover
7. Follow the procedure in *After Working Inside Your Computer*.

Removing the system board

1. Follow the procedure in *Before Working Inside Your Computer*.
2. Remove the:
 - a) cover
 - b) front bezel
 - c) hard drive
 - d) optical drive
 - e) heat sink fan cover
 - f) heat sink
 - g) system fan
 - h) memory module
 - i) PCIe SSD
3. Disconnect the cables from the system board.



4. To remove the system board:
 - a) Remove the screws that secure the system board to the computer [1].
 - b) Slide the system board toward the front of the computer and lift it from the computer [2].



Installing the system board

1. Hold the system board by its edges and angle it toward the back of the computer.
2. Lower the system board into the computer until the connectors at the back of the system board align with the slots on the back wall of the computer, and the screw holes on the system board align with the standoffs on the computer.
3. Tighten the screws that secure the system board to the computer
4. Connect the cables to the system board.
5. Install the:
 - a) [PCIe SSD](#)
 - b) [memory module](#)
 - c) [system fan](#)
 - d) [heat sink](#)
 - e) [heat sink fan cover](#)
 - f) [optical drive](#)
 - g) [hard drive](#)
 - h) [front bezel](#)
 - i) [cover](#)
6. Follow the procedure in [After Working Inside Your Computer](#).

System board components




Figure 1. Components of the system board

- | | |
|------------------------------------|---|
| 1. PCI Express x16 Gen 3 slot | 2. PCI Express x4 slot |
| 3. USB 2.0 with network connector | 4. USB 3.0 connector |
| 5. PS2 keyboard/mouse connectors | 6. serial port connector |
| 7. 2 x DisplayPort connector | 8. HDMI connector |
| 9. Line-Out connector | 10. P2 power connector |
| 11. intrusion switch connector | 12. VGA connector |
| 13. CPU socket | 14. CPU fan connector |
| 15. memory slot | 16. SATA or PCIe SSD Slot |
| 17. front power-switch connector | 18. debug connector |
| 19. SD Card Reader (optional) | 20. front panel power LED indicator |
| 21. system fan connector | 22. audio connector |
| 23. USB 2.0 connector | 24. USB 3.0 connector |
| 25. 8-pin power connector | 26. SATA 0 connector (Blue color) |
| 27. SATA 2 connector(Black color) | 28. password reset jumper |
| 29. service mode jumper connector | 30. speaker connector |
| 31. SATA power connector | 32. CLINK header for Intel WiFi add-in-card |
| 33. SATA 1 connector (White color) | 34. CMOS coin cell battery |
| 35. Debug connector | 36. Thunderbolt connector |
| 37. CMCLR jumper | |

System Setup

System Setup enables you to manage your computer hardware and specify BIOS level options. From the System Setup, you can:

- Change the NVRAM settings after you add or remove hardware
- View the system hardware configuration
- Enable or disable integrated devices
- Set performance and power management thresholds
- Manage your computer security

Topics:

- [Boot Sequence](#)
- [Navigation keys](#)
- [System Setup options](#)
- [Updating the BIOS](#)
- [Jumper settings](#)
- [System and setup password](#)

Boot Sequence

Boot Sequence allows you to bypass the System Setup-defined boot device order and boot directly to a specific device (for example: optical drive or hard drive). During the Power-on Self Test (POST), when the Dell logo appears, you can:

- Access System Setup by pressing F2 key
- Bring up the one-time boot menu by pressing F12 key

The one-time boot menu displays the devices that you can boot from including the diagnostic option. The boot-menu options are:

Table 1. Boot Sequence

Option	Description
Legacy Boot	<ul style="list-style-type: none"> • ST2000DM001-1ER164 • CD/DVD/CD-RW Drive • Onboard NIC
UEFI Boot	Windows Boot Manager
Other options	<ul style="list-style-type: none"> • BIOS Setup • BIOS Flash Update • Diagnostics • Intel (R) Management Engine BIOS Extension (MEBx) • Change Boot Mode Settings

The boot sequence screen also displays the option to access the System Setup screen.

Navigation keys

The following table displays the system setup navigation keys.

NOTE: For most of the System Setup options, changes that you make are recorded but do not take effect until you restart the system.

Table 2. Navigation keys

Keys	Navigation
Up arrow	Moves to the previous field.
Down arrow	Moves to the next field.
Enter	Allows you to select a value in the selected field (if applicable) or follow the link in the field.
Spacebar	Expands or collapses a drop-down list, if applicable.
Tab	Moves to the next focus area. NOTE: For the standard graphics browser only.
Esc	Moves to the previous page till you view the main screen. Pressing Esc in the main screen displays a message that prompts you to save any unsaved changes and restarts the system.
F1	Displays the System Setup help file.

System Setup options

NOTE: Depending on your computer and its installed devices, the items listed in this section may or may not appear.

Table 3. General

Option	Description
System Information	This section lists the primary hardware features of your computer. <ul style="list-style-type: none">System InformationMemory ConfigurationPCI InformationProcessor InformationDevice Information
Boot Sequence	Allows you to change the order in which the computer attempts to find an operating system. <ul style="list-style-type: none">Diskette DriveUSB Storage DeviceCD/DVD/CD-RW DriveOnboard NICInternal HDD
Boot List Options	Allows you to change the boot list option. <ul style="list-style-type: none">LegacyUEFI
Advanced Boot Options	Allows you to Enable Legacy Option ROMs <ul style="list-style-type: none">Enable Legacy Option ROMs (Default: not enabled)
Date/Time	Allows you to set the date and time. The changes to the system date and time takes effect immediately.

Table 4. System configuration

Option	Description
Integrated NIC	Allows you to configure the integrated network controller. The options are: <ul style="list-style-type: none">Enable UEFI Network StackDisabled NOTE: You can use the Disabled option, only if Active Management Technology (AMT) option is disabled.EnabledEnabled w/PXE (Default)

Option	Description
Serial Port	<ul style="list-style-type: none"> • Enabled w/Cloud Desktop <p>Identifies and defines the serial port settings. You can set the serial port to:</p> <ul style="list-style-type: none"> • Disabled • COM1 (Default) • COM2 • COM3 • COM4 <p> NOTE: The operating system may allocate resources even if the setting is disabled.</p>
SATA Operation	<p>Allows you to configure the internal SATA hard-drive controller. The options are:</p> <ul style="list-style-type: none"> • Disabled • AHCI • RAID On (Default)
Drives	<p>Allows you to configure the SATA drives on board. The options are:</p> <ul style="list-style-type: none"> • SATA-0 • SATA-1 • SATA-2 • M.2 PCIe SSD-0 <p>Default Setting: All drives are enabled.</p>
SMART Reporting	<p>This field controls if the hard drive errors for the integrated drives are reported during system startup. This technology is part of the SMART (Self Monitoring Analysis and Reporting Technology) specification.</p> <ul style="list-style-type: none"> • Enable SMART Reporting - This option is disabled by default.
USB Configuration	<p>Allows you to enable or disable the USB configuration. The options are:</p> <ul style="list-style-type: none"> • Enable Boot Support • Enable Front USB Ports • Enable rear USB Ports
Front USB Configuration	<p>Allows you to enable or disable the Front USB configuration. The options are:</p> <ul style="list-style-type: none"> • Front Port 1 • Front Port 2 • Front Port 3 • Front Port 4
Rear USB Configuration	<p>Allows you to enable or disable the rear USB configuration. The options are:</p> <ul style="list-style-type: none"> • Rear Port 1 • Rear Port 2 • Rear Port 3 • Rear Port 4 • Rear Port 5 • Rear Port 6
Thunderbolt	<p>Allows you to enable or disable Thunderbolt device support capability. The options are:</p> <ul style="list-style-type: none"> • Enabled (Default) • No Security • User Configuration • Secure Connect • Display Port Only
USB PowerShare	<p>Allows you to enable or disable USB PowerShare.</p> <p>Enable USB PowerShare -This option is disabled by default.</p>

Option	Description
Audio	Allows you enable or disable the audio feature. Enable Audio (Default) <ul style="list-style-type: none"> · Enable Microphone · Enable Internal Speaker
Miscellaneous devices	Allows you to enable or disable various on board devices. <ul style="list-style-type: none"> · Enable Media Card (Default) · Disable Media Card

Table 5. Video

Option	Description
Primary Display	Allows you to configure primary video controller when there are multiple controllers available. The options are: <ul style="list-style-type: none"> · Auto (Default) · Intel HD Graphics

Table 6. Security

Option	Description
Strong Password	Allows you to enforce the option to always set strong passwords. Default Setting: Enable Strong Password is not selected.
Password Configuration	Allows you to define the length of the Admin password. Min = 4 , Max = 32
Password Bypass	Allows you to enable or disable the permission to bypass the System password, when it is set. The options are: <ul style="list-style-type: none"> · Disabled (Default) · Reboot bypass
Password Change	Allows you to enable the disable permission to the System passwords when the administrator password is set. Default Setting: Allow Non-Admin Password Changes is selected
TPM 1.2 Security	Allows you to control whether the Trusted Platform Module (TPM) is visible to the operating system. The options are: <ul style="list-style-type: none"> · TPM On (Default) · PPI Bypass for Enable Commands · PPI Bypass for Disable Commands · Disabled · Enabled
Computrace (R)	Allows you to activate or disable the optional Computrace software. The options are: <ul style="list-style-type: none"> · Deactivate (Default) · Disable · Activate
Chassis Intrusion	Allows you to enable or disable the chassis intrusion feature. The options are: <ul style="list-style-type: none"> · Disabled (Default) · Enabled · On-Silent
CPU XD Support	Allows you to enable the Execute Disable mode of the processor. <ul style="list-style-type: none"> · Enable CPU XD Support (Default)

Option	Description
OROM Keyboard Access	Allows you to determine whether users are able to enter Option ROM Configuration screens via hotkeys during boot. The options are: <ul style="list-style-type: none"> • Enable (Default) • One Time Enable • Disable
Admin Setup Lockout	Allows you to prevent users from entering Setup when an administrator password is set. <ul style="list-style-type: none"> • Enable Admin Setup Lockout Default Setting: The option is disabled.

Table 7. Secure Boot

Option	Description
Secure Boot Enable	Allows you to enable or disable the Secure Boot Feature. The options are: <ul style="list-style-type: none"> • Disabled • Enabled (Default)
Expert Key Management	Allows you to enable or disable Custom Mode Key Management. <ul style="list-style-type: none"> • Enable Custom Mode (This option is not enabled by default) If Enabled, the options are: <ul style="list-style-type: none"> • PK • KEK • db • dbx

Table 8. Intel Software Guard Extensions

Option	Description
Intel SGX Enable	Allows you to enable or disable Intel Software Guard Extensions. The options are: <ul style="list-style-type: none"> • Disabled (Default) • Enabled
Enclave Memory Size	Allows you to change the Intel Software Guard Extensions Enclave Reserve Memory size. The options are: <ul style="list-style-type: none"> • 32 MB • 64 MB • 128 MB

Table 9. Performance

Option	Description
Multi Core Support	This field specifies whether the processor will have one or all cores enabled. The performance of some applications will improve with the additional cores. This option is enabled by default. Allows you to enable or disable multi-core support for the processor. The options are: <ul style="list-style-type: none"> • All (Default) • 1 • 2 • 3 <p>NOTE:</p> <ul style="list-style-type: none"> • The options displayed could be different depending on the installed processor. • The options depend on the number of cores supported by the installed processor (All, 1, 2, N-1 for N-Core Processors)

Option	Description
Intel SpeedStep	Allows you to enable or disable the Intel SpeedStep feature. Default Setting: Enable Intel SpeedStep
C-States Control	Allows you to enable or disable the additional processor sleep states. C states (This option is selected by default)
Limit CPUID Value	This field limits the maximum value the processor Standard CPUID Function will support. <ul style="list-style-type: none"> • Enable CPUID Limit Default Setting: The option is disabled.

Table 10. Power management

Option	Description
AC Recovery	Specifies how the computer will respond when AC power is applied after a AC power loss. You can set the AC Recovery to: <ul style="list-style-type: none"> • Power Off (Default) • Power On • Last Power State
Auto On Time	Allows you to set the time at which the computer must turn on automatically. The options are: <ul style="list-style-type: none"> • Disabled (Default) • Every Day • Weekdays • Select Days
Deep Sleep Control	Allows you to define the controls when Deep Sleep is enabled. <ul style="list-style-type: none"> • Disabled (Default) • Enabled in S5 only • Enabled in S4 and S5
Fan Control Override	Allows you to control the speed of the system fan. The options are: <ul style="list-style-type: none"> • Fan Control Override Default Setting: The option is disabled.
USB Wake Support	Allows you to enable USB devices to wake the system from standby. <ul style="list-style-type: none"> • Enable USB Wake Support Default Setting: The option is disabled.
Wake on LAN/WLAN	This option allows the computer to power up from the off state when triggered by a special LAN signal. Wake-up from the Standby state is unaffected by this setting and must be enabled in the operating system. This feature only works when the computer is connected to AC power supply. <ul style="list-style-type: none"> • Disabled (Default) • LAN Only • WLAN Only • LAN or WLAN • LAN with PXE Boot
Block Sleep	Allows you to block entering to sleep (S3 state) in OS Environment. Block Sleep (S3 State) This option is disabled by default.
Intel Ready Mode	This option allows you to enable the capability of Intel Ready Mode Technology. Enable Intel Ready Mode (this option is disabled by default)

Table 11. POST behavior

Option	Description
Numlock LED	Allows you to specify if the NumLock function is enabled when the system boots. This option is enabled by default.
MEBx Hotkey	Allows you to specify whether the MEBx Hotkey function should be enabled when the system boots. This option is enabled by default.
Keyboard Errors	Specifies whether keyboard related errors are reported when it boots. This option is enabled by default.

Table 12. Virtualization support

Option	Description
Virtualization	This option specifies whether a Virtual Machine Monitor (VMM) can utilize the additional hardware capabilities provided by Intel Virtualization technology. <ul style="list-style-type: none">· Enable Intel Virtualization Technology - This option is enabled by default.
VT for Direct I/O	Enables or disables the Virtual Machine Monitor (VMM) from utilizing the additional hardware capabilities provided by Intel Virtualization technology for direct I/O. <ul style="list-style-type: none">· Enable VT for Direct I/O - This option is enabled by default.
Trusted Execution	Allows you to specify whether a Measured Virtual Machine Monitor (MVMM) can utilize the additional hardware capabilities provided by Intel Trusted Execution Program. <ul style="list-style-type: none">· Trusted Execution - This option is disabled by default.

Table 13. Maintenance

Option	Description
Service Tag	Displays the service tag of your computer.
Asset Tag	Allows you to create a system asset tag if an asset tag is not already set. This option is not set by default.
SERR Messages	Allows you to control the SERR message mechanism. This option is not set by default. Some graphics cards require that the SERR message mechanism be disabled.
BIOS Downgrade	Allows you to control the flashing of the system firmware to previous revisions. This option is enabled by default.
Data Wipe	Allows you to securely erase data from all internal storage devices. The option is disabled by default.
BIOS Recovery	Allows you to recover from certain corrupted BIOS conditions using a recovery file. This option is enabled by default.

Table 14. Cloud desktop

Option	Description
Server Lookup Method	Allows you to specify how the Cloud Desktop software will lookup server addresses. The options are: <ul style="list-style-type: none">· Static IP· DNS (default)
Server Name	Allows you to specify the Server Name of the server.
Server IP Address	Specifies the primary static IP address of the Cloud Desktop Server with which the client software communicates. The default setting is 255.255.255.255
Server Port	Allows you to specify the primary IP port of the Cloud Desktop with which the client software communicates. The default setting is 06910.
Client Address Method	Allows you to specify how the client will obtain its IP address. The options are: <ul style="list-style-type: none">· Static IP

Option	Description
	<ul style="list-style-type: none"> · DHCP (default)
Client IP Address	Specifies the Static IP address of the client. The default setting is 255.255.255.255
Client Subnet Mask	Specifies the subnet mask of the client. The default setting is 255.255.255.255
Client Gateway	Specifies the gateway of the client. The default setting is 255.255.255.255
DNS IP Address	Specifies the DNS IP address of the client. The default setting is 255.255.255.255
Domain Name	Specifies the Domain name of the client.
Advanced	Allows you to enable Verbose Mode for advanced debugging. By default this option is disabled.

Table 15. System Logs

Option	Description
BIOS events	Displays the system event log and allows you to clear the log. <ul style="list-style-type: none"> · Clear Log

Table 16. Engineering configurations

Option	Description
ASPM	Allows you to set the Active State Power Management level: <ul style="list-style-type: none"> · Auto (Default) · Disabled · L1 Only

Updating the BIOS

It is recommended to update your BIOS (System Setup), on replacing the system board or if an update is available. For laptops, ensure that your computer battery is fully charged and connected to a power outlet

1. Restart the computer.
2. Go to **Dell.com/support**.
3. Enter the **Service Tag** or **Express Service Code** and click **Submit**.

 **NOTE: To locate the Service Tag, click Where is my Service Tag?**

 **NOTE: If you cannot find your Service Tag, click Detect My Product. Proceed with the instructions on screen.**

4. If you are unable to locate or find the Service Tag, click the Product Category of your computer.
5. Choose the **Product Type** from the list.
6. Select your computer model and the **Product Support** page of your computer appears.
7. Click **Get drivers** and click **View All Drivers**.
The Drivers and Downloads page opens.
8. On the Drivers and Downloads screen, under the **Operating System** drop-down list, select **BIOS**.
9. Identify the latest BIOS file and click **Download File**.
You can also analyze which drivers need an update. To do this for your product, click **Analyze System for Updates** and follow the instructions on the screen.
10. Select your preferred download method in the **Please select your download method below** window, click **Download File**.
The **File Download** window appears.
11. Click **Save** to save the file on your computer.
12. Click **Run** to install the updated BIOS settings on your computer.
Follow the instructions on the screen.

 **NOTE: It is recommended not to update the BIOS version for more than 3 revisions. For example: If you want to update the BIOS from 1.0 to 7.0, then install version 4.0 first and then install version 7.0.**

Jumper settings

To change a jumper setting, pull the plug off its pin(s) and carefully fit it down onto the pin(s) indicated on the system board.

Table 17. Jumper settings

Jumper	Setting	Description
PSWD	Default	Short: Default Open: Clear Password
RTCST	Default	Open: Default Short: Real-time clock reset. Can be used for troubleshooting
SERVICE_MODE	Default	Open: Default Short: ME disable

System and setup password

You can create a system password and a setup password to secure your computer.

Password type Description

System password Password that you must enter to log on to your system.

Setup password Password that you must enter to access and make changes to the BIOS settings of your computer.

 **CAUTION:** The password features provide a basic level of security for the data on your computer.

 **CAUTION:** Anyone can access the data stored on your computer if it is not locked and left unattended.

 **NOTE:** Your computer is shipped with the system and setup password feature disabled.

Assigning a system password and setup password

You can assign a new **System Password** and/or **Setup Password** or change an existing **System Password** and/or **Setup Password** only when **Password Status** is **Unlocked**. If the Password Status is **Locked**, you cannot change the System Password.

 **NOTE:** If the password jumper is disabled, the existing System Password and Setup Password are deleted and you need not provide the system password to log on to the computer.

To enter a system setup, press <F2> immediately after a power-on or re-boot.

- In the **System BIOS** or **System Setup** screen, select **System Security** and press Enter. The **System Security** screen appears.
- In the **System Security** screen, verify that **Password Status** is **Unlocked**.
- Select **System Password**, enter your system password, and press Enter or Tab. Use the following guidelines to assign the system password:
 - A password can have up to 32 characters.
 - The password can contain the numbers 0 through 9.
 - Only lower case letters are valid, upper case letters are not allowed.
 - Only the following special characters are allowed: space, ("), (+), (,), (-), (.), (/), (;), ([), (\), (]), (').Re-enter the system password when prompted.
- Type the system password that you entered earlier and click **OK**.
- Select **Setup Password**, type your system password and press Enter or Tab. A message prompts you to re-type the setup password.
- Type the setup password that you entered earlier and click **OK**.

7. Press Esc and a message prompts you to save the changes.
8. Press Y to save the changes.
The computer reboots.

Deleting or changing an existing system and/or setup password

Ensure that the **Password Status** is Unlocked (in the System Setup) before attempting to delete or change the existing System and/or Setup password. You cannot delete or change an existing System or Setup password, if the **Password Status** is Locked.

To enter the System Setup, press F2 immediately after a power-on or reboot.

1. In the **System BIOS** or **System Setup** screen, select **System Security** and press Enter.
The **System Security** screen is displayed.
2. In the **System Security** screen, verify that **Password Status** is **Unlocked**.
3. Select **System Password**, alter or delete the existing system password and press Enter or Tab.
4. Select **Setup Password**, alter or delete the existing setup password and press Enter or Tab.

NOTE: If you change the System and/or Setup password, re-enter the new password when promoted. If you delete the System and/or Setup password, confirm the deletion when promoted.

5. Press Esc and a message prompts you to save the changes.
6. Press Y to save the changes and exit from System Setup.
The computer reboots.

Disabling a system password

The system's software security features include a system password and a setup password. The password jumper disables any password(s) currently in use.

NOTE: You can also use the following steps to disable a forgotten password.

1. Follow the procedures in *Before Working on Your Computer*.
2. Remove the cover.
3. Identify the PSWD jumper on the system board.
4. Remove the PSWD jumper from the system board.

NOTE: The existing passwords are not disabled (erased) until the computer boots without the jumper.

5. Install the cover.

NOTE: If you assign a new system and/or setup password with the PSWD jumper installed, the system disables the new password(s) the next time it boots.

6. Connect the computer to the electrical outlet and power-on the computer.
7. Power-off the computer and disconnect the power cable from the electrical outlet.
8. Remove the cover.
9. Replace the PSWD jumper on the system board.
10. Install the cover.
11. Follow the procedures in *After Working on Your Computer*.
12. Power-on the computer.
13. Go to the system setup, and assign a new system or setup password. See *Setting up a System Password*.

Diagnostics

If you experience a problem with your computer, run the ePSA diagnostics before contacting Dell for technical assistance. The purpose of running diagnostics is to test your computer's hardware without requiring additional equipment or risking data loss. If you are unable to fix the problem yourself, service and support personnel can use the diagnostics results to help you solve the problem.

Topics:

- [Enhanced Pre-Boot System Assessment \(ePSA\) diagnostics](#)
- [Troubleshooting your computer](#)

Enhanced Pre-Boot System Assessment (ePSA) diagnostics

The ePSA diagnostics (also known as system diagnostics) performs a complete check of your hardware. The ePSA is embedded with the BIOS and is launched by the BIOS internally. The embedded system diagnostics provides a set of options for particular devices or device groups allowing you to:

- Run tests automatically or in an interactive mode
- Repeat tests
- Display or save test results
- Run thorough tests to introduce additional test options to provide extra information about the failed device(s)
- View status messages that inform you if tests are completed successfully
- View error messages that inform you of problems encountered during testing

 **CAUTION: Use the system diagnostics to test only your computer. Using this program with other computers may cause invalid results or error messages.**

 **NOTE: Some tests for specific devices require user interaction. Always ensure that you are present at the computer terminal when the diagnostic tests are performed.**

1. Power-on the computer.
2. As the computer boots, press the F12 key as the Dell logo appears.
3. On the boot menu screen, select the **Diagnostics** option.
The **Enhanced Pre-boot System Assessment** window is displayed, listing all devices detected in the computer. The diagnostics starts running the tests on all the detected devices.
4. To run a diagnostic test on a specific device, press Esc and click **Yes** to stop the diagnostic test.
5. Select the device from the left pane and click **Run Tests**.
6. If there are any issues, error codes are displayed.
Note the error code and contact Dell.

Troubleshooting your computer

You can troubleshoot your computer using indicators like diagnostic lights, beep codes, and error messages during the operation of the computer.

Power LED diagnostics

The power button LED located on the front of the chassis also functions as a bicolored diagnostic LED. The diagnostic LED is only active and visible during the POST process. Once the operating system starts to load, it is no longer visible.

Amber LED blinking scheme – The pattern is 2 or 3 blinks followed by a short pause then x number of blinks up to 7. The repeated pattern has a long pause inserted in the middle. For example 2,3 = 2 amber blinks, short pause, 3 amber blinks followed by long pause then repeats.

Table 18. Power LED diagnostics

Amber LED state	White LED state	Description
off	off	system is OFF
off	blinking	system is in sleep state
blinking	off	power supply unit (PSU) failure
steady	off	PSU is working but failed to fetch code
off	steady	system is ON

Amber LED state	Description
2,1	system board failure
2,2	system board, PSU or PSU cabling failure
2,3	system board, memory or CPU failure
2, 4	coin cell battery failure
2,5	corrupt BIOS
2,6	CPU configuration failure or CPU failure
2,7	memory modules are detected, but a memory failure
3,1	possible peripheral card or system board failure
3,2	possible USB failure
3,3	no memory modules are detected
3,4	possible system board error
3,5	memory modules are detected, but a memory configuration or compatibility error
3,6	possible system board resource and/or hardware failure
3,7	possible memory failure

Beep code

The computer can emit a series of beeps during start-up if the display does not show errors or problems. These series of beeps, called beep codes, identify various problems. The delay between each beep is 300 ms, the delay between each set of beeps is 3 sec, and the beep sound lasts 300 ms. After each beep and each set of beeps, the BIOS should detect if the user presses the power button. If so, BIOS will jump out from looping and execute the normal shutdown process and power system.

Code	1-3-2
Cause	Memory failure

Error messages

Error message	Description
Address mark not found	The BIOS found a faulty disk sector or could not find a particular disk sector.
Alert! Previous attempts at booting this system have failed at checkpoint [nnnn]. For help in resolving this problem, please	The computer failed to complete the boot routine three consecutive times for the same error. Contact Dell and report the checkpoint code (nnnn) to the support technician

Error message	Description
note this checkpoint and contact Dell Technical Support.	
Alert! Security override Jumper is installed.	The MFG_MODE jumper has been set and AMT Management features are disabled until it is removed.
Attachment failed to respond	The floppy or hard drive controller cannot send data to the associated drive.
Bad command or file name	Ensure that you have spelled the command correctly, put spaces in the proper place, and used the correct pathname.
Bad error-correction code (ECC) on disk read	The floppy or hard drive controller detected an uncorrectable read error.
Controller has failed	The hard drive or the associated controller is defective.
Data error	The floppy or hard drive cannot read the data. For the Windows operating system, run the chkdsk utility to check the file structure of the floppy or hard drive. For any other operating system, run the appropriate corresponding utility.
Decreasing available memory	One or more memory modules may be faulty or improperly seated. Re-install the memory modules and, if necessary, replace them.
Diskette drive 0 seek failure	A cable may be loose or the computer configuration information may not match the hardware configuration.
Diskette read failure	The floppy disk may be defective or a cable may be loose. If the drive access light turns on, try a different disk.
Diskette subsystem reset failed	The floppy drive controller may be faulty.
Gate A20 failure	One or more memory modules may be faulty or improperly seated. Reinstall the memory modules and, if necessary, replace them.
General failure	The operating system is unable to carry out the command. This message is usually followed by specific information—for example, Printer out of paper . Take the appropriate action to resolve the problem.
Hard-disk drive configuration error	The hard drive failed initialization.
Hard-disk drive controller failure	The hard drive failed initialization.
Hard-disk drive failure	The hard drive failed initialization.
Hard-disk drive read failure	The hard drive failed initialization.
Invalid configuration information—please run SETUP program	The computer configuration information does not match the hardware configuration.
Invalid Memory configuration, please populate DIMM1	DIMM1 slot does not recognize a memory module. The module should be re-seated or installed.

Error message	Description
Keyboard failure	A cable or connector may be loose, or the keyboard or keyboard/mouse controller may be faulty.
Memory address line failure at address, read value expecting value	A memory module may be faulty or improperly seated. Reinstall the memory modules and, if necessary, replace them.
Memory allocation error	The software you are attempting to run is conflicting with the operating system, another program, or a utility.
Memory data line failure at address, read value expecting value	A memory module may be faulty or improperly seated. Reinstall the memory modules and, if necessary, replace them.
Memory double word logic failure at address, read value expecting value	A memory module may be faulty or improperly seated. Reinstall the memory modules and, if necessary, replace them.
Memory odd/even logic failure at address, read value expecting value	A memory module may be faulty or improperly seated. Reinstall the memory modules and, if necessary, replace them.
Memory write/read failure at address, read value expecting value	A memory module may be faulty or improperly seated. Reinstall the memory modules and, if necessary, replace them.
Memory size in CMOS invalid	The amount of memory recorded in the computer configuration information does not match the memory installed in the computer.
Memory tests terminated by keystroke	A keystroke interrupted the memory test.
No boot device available	The computer cannot find the floppy disk or hard drive.
No boot sector on hard-disk drive	The computer configuration information in System Setup may be incorrect.
No timer tick interrupt	A chip on the system board might be malfunctioning.
Non-system disk or disk error	The floppy disk in drive A does not have a bootable operating system installed on it. Either replace the floppy disk with one that has a bootable operating system, or remove the floppy disk from drive A and restart the computer.
Not a boot diskette	The operating system is trying to boot to a floppy disk that does not have a bootable operating system installed on it. Insert a bootable floppy disk.
Plug and play configuration error	The computer encountered a problem while trying to configure one or more cards.
Read fault	The operating system cannot read from the floppy or hard drive, the computer could not find a particular sector on the disk, or the requested sector is defective.
Requested sector not found	The operating system cannot read from the floppy or hard drive, the computer could not find a particular sector on the disk, or the requested sector is defective.
Reset failed	The disk re-set operation failed.
Sector not found	The operating system cannot locate a sector on the floppy or hard drive.
Seek error	The operating system cannot find a specific track on the floppy disk or hard drive.

Error message	Description
Shutdown failure	A chip on the system board might be malfunctioning.
Time-of-day clock stopped	The battery might be dead.
Time-of-day not set-please run the System Setup program	The time or date stored in System Setup does not match the computer clock.
Timer chip counter 2 failed	A chip on the system board may be malfunctioning.
Unexpected interrupt in protected mode	The keyboard controller may be malfunctioning or a memory module may be loose.
WARNING: Dell's Disk Monitoring System has detected that drive [0/1] on the [primary/secondary] EIDE controller is operating outside of normal specifications. It is advisable to immediately back up your data and replace your hard drive by calling your support desk or Dell.	During initial startup, the drive detected possible error conditions. When your computer finishes booting, immediately back up your data and replace your hard drive (for installation procedures, see "Adding and Removing Parts" for your computer type). If no replacement drive is immediately available and the drive is not the only bootable drive, enter System Setup and change the appropriate drive setting to None . Then remove the drive from the computer.
Write fault	The operating system cannot write to the floppy or hard drive.
Write fault on selected drive	The operating system cannot write to the floppy or hard drive.

Specifications

NOTE: Offerings may vary by region. For more information regarding the configuration of your computer in:

- **Windows 10**, click Start  > Settings > System > About.
- **Windows 8.1 and Windows 8**, click Start  > PC Settings > PC and devices > PC Info.
- **Windows 7**, click Start , right-click My Computer, and then select Properties.

Table 19. Processor

Feature	Specification
Processor type	<ul style="list-style-type: none"> • Intel Core i3 series • Intel Core i5 series • Intel Core i7 series • Intel Xeon E3
Total cache	Up to 8 MB cache depending on processor type

NOTE: The Precision workstation 3420 has three processors that do not support onboard graphics.

Table 20. Memory

Feature	Specification
Type	DDR4, NECC, and ECC
Speed	2133 MHz
Connectors	Four DIMM slots
Capacity	4 GB, 8 GB, and 16 GB
Minimum memory	4 GB
Maximum memory	64 GB

Table 21. Video

Feature	Specification
Integrated	<ul style="list-style-type: none"> • Intel HD Graphics 530 (Core i3/i5/i7) • Intel HD Graphics P530 (Select Xeon)
Discrete	PCI Express x16 graphics adapter

Table 22. Audio

Feature	Specification
Integrated	Two Channel High Definition Audio

Table 23. Network

Feature	Specification
Integrated	Intel I219LM Ethernet capable of 10/100/1000 Mb/s communication

Table 29. Internal connectors

Feature	Specification
PCI 2.3 data width (maximum) - 32 bits	
Small Form Factor	None
PCI Express x4 data width (maximum) - four PCI Express lane	
Small Form Factor	One 64-pin connector
PCI Express x16 (wired as x4) data width (maximum) - four PCI Express lanes	
Small Form Factor	None
PCI Express x16 data width (maximum) - 16 PCI Express lanes	
Small Form Factor	One 164-pin connector
Serial ATA	
Small Form Factor	Three 7-pin connectors
Memory	Four 288-pin connectors
System fan	One 4-pin connector
Processor	One 1150-pin connector
Processor fan	One 4-pin connector
Service mode jumper	One 2-pin connector
Password clear jumper	One 2-pin connector
RTC reset jumper	One 2-pin connector
Internal speaker	One 4-pin connector
Intruder connector	One 3-pin connector
Power connector:	One 8-pin. one 4-pin,

Table 30. Controls and lights

Feature	Specification
Front of the computer	
Power button light	White light — Solid white light indicates power-on state; blinking white light indicates sleep state of the computer.
Drive activity light	White light — Blinking white light indicates that the computer is reading data from or writing data to the hard drive.
Back of the computer	
Link integrity light on integrated network adapter	Green — a 10 Mbps connection exists between the network and the computer. Green — a 100 Mbps connection exists between the network and the computer. Orange — a 1000 Mbps connection exists between the network and the computer. Off (no light) — the computer is not detecting a physical connection to the network.
Network activity light on integrated network adapter	Yellow light — A blinking yellow light indicates that network activity is present.
Power supply diagnostic light	Green light — The power supply is turned on and is functional. The power cable must be connected to the power connector (at the back of the computer) and the electrical outlet.

Table 31. Power

Power	Wattage	Maximum heat dissipation	Voltage
Small Form Factor	180 W/240 W EPA	614/819 BTU/hr	100 V AC to 240 V AC, 50 Hz to 60 Hz, 4.0 A

NOTE: Heat dissipation is calculated by using the power supply wattage rating.

Coin cell battery 3 V CR2032 lithium coin cell

Table 32. Physical dimension

Physical	Height	Width	Depth	Weight
Small Form Factor	290.00 mm (11.41 inches)	92.60 mm (3.64 inches)	292.00 mm (11.49 inches)	6.30 kg (13.88 lb)

NOTE: The weight of your computer is based on a typical configuration and may vary with different configurations.

Table 33. Environmental

Feature	Specification
Temperature range	
Operating	5°C to 35°C (41°F to 95°F)
Storage	-40°C to 65°C (-40°F to 149°F)
Relative humidity (maximum)	
Operating	20 percent to 80 percent (non-condensing)
Storage	5 percent to 95 percent (non-condensing)
Maximum vibration	
Operating	0.26 GRMS
Storage	2.20 GRMS
Maximum shock	
Operating	40 G
Storage	105 G
Altitude	
Operating	-15.2 m to 30482000 m (-50 to 10,0006560 ft)
Storage	-15.20 m to 10,668 m (-50 ft to 35,000 ft)
Airborne contaminant level	G1 or lower as defined by ANSI/ISA-S71.04-1985

Contacting Dell

 **NOTE:** If you do not have an active Internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.

Dell provides several online and telephone-based support and service options. Availability varies by country and product, and some services may not be available in your area. To contact Dell for sales, technical support, or customer service issues:

1. Go to **Dell.com/support**.
2. Select your support category.
3. Verify your country or region in the **Choose a Country/Region** drop-down list at the bottom of the page.
4. Select the appropriate service or support link based on your need.