

# **VMware vSphere 6.5.x on Dell EMC PowerEdge Servers**

Compatibility Matrix

## Notes, cautions, and warnings

 **NOTE:** A NOTE indicates important information that helps you make better use of your product.

 **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

**Copyright © 2017 Dell Inc. or its subsidiaries. All rights reserved.** Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

# Contents

<b>1 Overview.....</b>	<b>4</b>
<b>2 Dell EMC PowerEdge servers—Compatibility matrix.....</b>	<b>5</b>
<b>3 Dell EMC PowerEdge servers—SD card compatibility matrix.....</b>	<b>8</b>
<b>4 PowerEdge servers—RAID controller compatibility matrix.....</b>	<b>10</b>
<b>5 Dell EMC PowerEdge servers—VMware vCenter Server compatibility matrix.....</b>	<b>16</b>
<b>6 Devices supported for PCIe Pass-Through .....</b>	<b>17</b>
<b>7 Getting help.....</b>	<b>19</b>
Contacting Dell EMC.....	19
Related information for virtualization solutions.....	19
Technical support resources.....	20
Discussion forums.....	20
Knowledge base.....	20
Virtualization videos on Dell EMC PowerEdge servers.....	20
Documentation resources.....	21
Downloading the drivers and firmware.....	23
Documentation feedback.....	23

# Overview

This document provides information about Dell EMC-supported PowerEdge servers compatible with VMware ESXi 6.5.x.

# Dell EMC PowerEdge servers—Compatibility matrix

The following table lists the supported processors for Dell EMC PowerEdge servers:

**Table 1. Dell EMC 14<sup>th</sup> generation PowerEdge servers—compatibility matrix**

14 <sup>th</sup> generation PowerEdge servers	Processor series	Supported releases		Boot device		
		ESXi 6.5	ESXi 6.5 U1	Hard drive	Flash (SD) card	BOSS S1
R940	Intel Xeon SP (81xx,61xx,51xx) series	✓	✓	✓	✓	✓
R7425, R7415, R6415	AMD EPYC 7XX1 series	X	✓	✓	✓	✓
R740, R740xd, R640	Intel Xeon SP (81xx,61xx,51xx,41xx,31xx) series	✓	✓	✓	✓	✓
R540, R440	Intel Xeon SP (61xx,51xx,41xx,31xx) series	X	✓	✓	✓	✓
FC640, M640, M640 for VRTX	Intel Xeon SP (81xx,61xx,51xx,41xx,31xx) series	X	✓	✓	✓	✓
T640	Intel Xeon SP (81xx,61xx,51xx,41xx,31xx) series	X	✓	✓	✓	✓
T440	Intel Xeon SP (51xx,41xx,31xx) series	X	✓	✓	✓	✓

**Table 2. 13<sup>th</sup> generation PowerEdge servers—compatibility matrix**

13 <sup>th</sup> generation PowerEdge servers	Processor series	Supported releases		Boot device		
		ESXi 6.5	ESXi 6.5 U1	Hard drive	Flash (SD) card	BOSS S1
R930	Intel Xeon E7-88xx/48xx v3 series	✓	✓	✓	✓	X
	Intel Xeon E7-88xx/48xx v4 series	✓	✓	✓	✓	X
R830	Intel Xeon E5-46xx v4 series	✓	✓	✓	✓	X
R730, R730xd, R630	Intel Xeon E5-26xx v3 series	✓	✓	✓	✓	X
	Intel Xeon E5-26xx v4 series	✓	✓	✓	✓	X
R530, R430	Intel Xeon E5-26xx v3 series	✓	✓	✓	✓	X
	Intel Xeon E5-26xx v4 series	✓	✓	✓	✓	X

13 <sup>th</sup> generation PowerEdge servers	Processor series	Supported releases		Boot device		
		ESXi 6.5	ESXi 6.5 U1	Hard drive	Flash (SD) card	BOSS S1
R330	Intel Xeon E3-1200 v6 series	✓	✓	✓	✓	X
	Intel Xeon E3-1200 v5 series	✓	✓	✓	✓	X
R230	Intel Xeon E3-1200 v6 series	✓	✓	✓	X	X
	Intel Xeon E3-1200 v5 series	✓	✓	✓	X	X
FC830, M830, M830 for VRTX	Intel Xeon E5-46xx v3 series	✓	✓	✓	✓	X
	Intel Xeon E5-46xx v4 series	✓	✓	✓	✓	X
FC630, M630, M630 for VRTX	Intel Xeon E5-26xx v3 series	✓	✓	✓	✓	X
	Intel Xeon E5-26xx v4 series	✓	✓	✓	✓	X
FC430	Intel Xeon E5-26xx v3 series	✓	✓	✓	✓	X
	Intel Xeon E5-26xx v4 series	✓	✓	✓	✓	X
T630	Intel Xeon E5-26xx v3 series	✓	✓	✓	✓	X
	Intel Xeon E5-26xx v4 series	✓	✓	✓	✓	X
T430	Intel Xeon E5-26xx v3 series	✓	✓	✓	✓	X
	Intel Xeon E5-26xx v4 series	✓	✓	✓	✓	X
T330	Intel Xeon E3-1200 v6 series	✓	✓	✓	✓	X
	Intel Xeon E3-1200 v5 series	✓	✓	✓	✓	X
T130	Intel Xeon E3-1200 v6 series	✓	✓	✓	X	X
	Intel Xeon E3-1200 v5 series	✓	✓	✓	X	X

Table 3. 12<sup>th</sup> generation PowerEdge servers—compatibility matrix

12 <sup>th</sup> generation PowerEdge servers	Processor series	Supported releases		Boot device		
		ESXi 6.5	ESXi 6.5 U1	Hard drive	Flash (SD) card	BOSS S1
R920	Intel Xeon E7-88xx/48xx v2 series	✓	✓	✓	✓	X
R820	Intel Xeon E5-46xx v2 series	✓	✓	✓	✓	X

12 <sup>th</sup> generation PowerEdge servers	Processor series	Supported releases		Boot device		
		ESXi 6.5	ESXi 6.5 U1	Hard drive	Flash (SD) card	BOSS S1
	Intel Xeon E5-46xx series	✓	✓	✓	✓	X
R720, R720xd, R620	Intel Xeon E5-26xx v2 series	✓	✓	✓	✓	X
	Intel Xeon E5-26xx series	✓	✓	✓	✓	X
R520, R420	Intel Xeon E5-24xx v2 series	✓	✓	✓	✓	X
	Intel Xeon E5-24xx series	✓	✓	✓	✓	X
R320	Intel Xeon E5-24xx v2 series	✓	✓	✓	✓	X
	Intel Xeon E5-24xx series	✓	✓	✓	✓	X
	Intel Xeon E5-14xx v2 series	✓	✓	✓	✓	X
R220	Intel Xeon E3-1200-v3 series	✓	✓	✓	X	X
M820, M820 for VRTX	Intel Xeon E5-46xx v2 series	✓	✓	✓	✓	X
	Intel Xeon E5-46xx series	✓	✓	✓	✓	X
M620, M620 for VRTX	Intel Xeon E5-26xx v2 series	✓	✓	✓	✓	X
	Intel Xeon E5-26xx series	✓	✓	✓	✓	X
M520, M420, M520 for VRTX	Intel Xeon E5-24xx v2 series	✓	✓	✓	✓	X
	Intel Xeon E5-24xx series	✓	✓	✓	✓	X
T620	Intel Xeon E5-26xx v2 series	✓	✓	✓	✓	X
	Intel Xeon E5-26xx series	✓	✓	✓	✓	X
T420, T320	Intel Xeon E5-24xx v2 series	✓	✓	✓	✓	X
	Intel Xeon E5-24xx series	✓	✓	✓	✓	X

### Legend

✓ - Supported

X - Not supported

# Dell EMC PowerEdge servers—SD card compatibility matrix

**Table 4. Dell EMC 14<sup>th</sup> generation PowerEdge servers—compatibility matrix**

14 <sup>th</sup> generation PowerEdge servers	I/O Controller	Manufacturer	Specification	DPN *
R940, R740, R740xd, R640, R540, R440, FC640, M640, T640, T440, M640 for VRTX	Intel C621	Dell EMC	16 GB SD card	R7YTT
		Dell EMC	32 GB SD card	0PD22
		Dell EMC	64 GB SD card	7XDNW
R7425, R7415, R6415	USB 3.0 Controller	Dell EMC	16 GB SD card	R7YTT
		Dell EMC	32 GB SD card	0PD22
		Dell EMC	64 GB SD card	7XDNW

**Table 5. 13<sup>th</sup> generation PowerEdge servers—compatibility matrix**

13 <sup>th</sup> generation PowerEdge servers	I/O Controller	Manufacturer	Specification	DPN *
R930, R730, R630, R530, R430, M830, M630, FC830, FC630, FC430, T630, T430, M830 for VRTX, M630 for VRTX	Intel C610	Dell	8 GB SD card	W1T9G
		Dell	16 GB SD card	7GH0Y
		Dell	16 GB SD card	H1H8M
		Dell	32 GB SD card	XVP8P
		Dell	64 GB SD card	1X6VF
R330, T330	Intel C632	Dell	8 GB SD card	W1T9G
		Dell	16 GB SD card	7GH0Y
		Dell	16 GB SD card	H1H8M
		Dell	32 GB SD card	XVP8P
		Dell	64 GB SD card	1X6VF

**Table 6. 12<sup>th</sup> generation PowerEdge servers—compatibility matrix**

<b>12<sup>th</sup> generation PowerEdge servers</b>	<b>I/O Controller</b>	<b>Manufacturer</b>	<b>Specification</b>	<b>DPN *</b>
R920, R820, R720, R720xd, R620, R520, R420, R320, M820, M620, M520, M420, T620, T420, T320, M820 for VRTX, M520 for VRTX, M620 for VRTX	Intel C600	Dell	8 GB SD card	W1T9G
		Dell	16 GB SD card	7GH0Y
		Dell	16 GB SD card	H1H8M
		Dell	32 GB SD card	XVP8P
		Dell	64 GB SD card	1X6VF

\*Dell EMC Part Number (DPN) is an alphanumeric code on the barcode of your SD card.

# PowerEdge servers—RAID controller compatibility matrix

**Table 7. 14<sup>th</sup> generation PowerEdge servers—PERC 10 controllers compatibility matrix**

PowerEdge servers / PERC Controller	R940	R740	R740xd	R640	R540	R440	M640
PERC H840 adapter	Y	Y	Y	Y	Y	Y	N
PERC H740P adapter	Y	Y	Y	Y	Y	Y	N
PERC H740P mini monolithic	N	N	N	N	N	N	N

**Table 8. 14<sup>th</sup> generation PowerEdge servers—PERC 10 controllers compatibility matrix**

PowerEdge servers / PERC Controller	M640 for VRTX	FC640	T640	T440	R7425	R7415	R6415
PERC H840 adapter	N	N	Y	Y	Y	Y	Y
PERC H740P adapter	N	N	Y	Y	Y	N	N
PERC H740P mini monolithic	N	N	N	N	N	Y	Y

**Table 9. 14<sup>th</sup> generation PowerEdge servers—PERC 9 controllers compatibility matrix**

PowerEdge servers / PREC Controller	R940	R740	R740xd	R640	R540	R440	M640
PERC H730P adapter	N	Y	Y	Y	Y	Y	N
PERC H730P mini monolithic	N	Y	Y	Y	N	N	N
PERC H730P mini blades	N	N	N	N	N	N	Y
PERC H730 adapter	N	N	N	N	N	N	N
PERC H730 mini monolithic	N	N	N	N	N	N	N
PERC H730 mini blades	N	N	N	N	N	N	N
PERC H330 adapter	Y	Y	Y	Y	Y	Y	N
PERC H330 mini monolithic	N	Y	Y	Y	N	N	N
PERC H330 mini blades	N	N	N	N	N	N	Y
PERC H830 adapter	N	N	N	N	N	N	N
PERC HBA330 adapter	N	Y	Y	Y	Y	Y	N
PERC HBA330 Mini-Mono	N	Y	Y	Y	N	N	N

<b>PowerEdge servers / PREC Controller</b>	<b>R940</b>	<b>R740</b>	<b>R740xd</b>	<b>R640</b>	<b>R540</b>	<b>R440</b>	<b>M640</b>
12 Gbps SAS HBA adapter	Y	Y	Y	Y	Y	Y	N
FD33xS-PERC	N	Y	Y	Y	N	N	N
FD33xD-PERC	N	N	N	N	N	N	N
Shared PERC8	N	N	N	N	N	N	N
Shared PERC8 External	N	N	N	N	N	N	N

**Table 10. 14<sup>th</sup> generation PowerEdge servers—PERC 9 controllers compatibility matrix**

<b>PowerEdge servers / PREC Controller</b>	<b>M640 for VRTX</b>	<b>FC640</b>	<b>T640</b>	<b>T440</b>	<b>R7425</b>	<b>R7415</b>	<b>R6415</b>
PERC H730P adapter	N	N	Y	Y	Y	N	N
PERC H730P mini monolithic	N	N	N	N	N	Y	Y
PERC H730P mini blades	Y	Y	N	N	N	N	N
PERC H730 adapter	N	N	N	N	N	N	N
PERC H730 mini monolithic	N	N	N	N	N	N	N
PERC H730 mini blades	N	N	N	N	N	N	N
PERC H330 adapter	N	N	Y	Y	Y	N	N
PERC H330 mini monolithic	N	N	N	N	N	Y	Y
PERC H330 mini blades	Y	Y	N	N	N	N	N
PERC H830 adapter	N	N	N	N	N	N	N
PERC HBA330 adapter	N	N	Y	Y	Y	N	N
PERC HBA330 Mini-Mono	N	N	N	N	N	Y	Y
12 Gbps SAS HBA adapter	N	N	Y	Y	Y	Y	Y
FD33xS-PERC	N	Y	N	N	N	N	N
FD33xD-PERC	N	Y	N	N	N	N	N
Shared PERC8	Y	N	N	N	N	N	N
Shared PERC8 External	Y	N	N	N	N	N	N

**Table 11. 13<sup>th</sup> generation PowerEdge servers—PERC 9 controllers compatibility matrix**

<b>PowerEdge servers / PERC Controller</b>	<b>R930</b>	<b>R830</b>	<b>R920</b>	<b>R730</b>	<b>R730xd</b>	<b>R630</b>
PERC H730P adapter	Y	Y	Y	Y	N	Y
PERC H730P mini monolithic	N	N	N	Y	Y	Y
PERC H730P mini blades	N	N	N	N	N	N
PERC H730 adapter	N	Y	N	N	N	Y
PERC H730 mini monolithic	N	N	N	Y	Y	Y

<b>PowerEdge servers / PERC Controller</b>	<b>R930</b>	<b>R830</b>	<b>R920</b>	<b>R730</b>	<b>R730xd</b>	<b>R630</b>
PERC H730 mini blades	N	N	N	N	N	N
PERC H330 adapter	N	Y	N	N	N	Y
PERC H330 mini monolithic	N	N	N	Y	Y	Y
PERC H330 mini blades	N	N	N	N	N	N
PERC H830 adapter	Y	Y	N	Y	Y	Y
PERC HBA330 adapter	Y	Y	N	N	N	N
PERC HBA330 Mini-Mono	N	N	N	Y	Y	Y
12 Gbps SAS HBA adapter	Y	Y	N	Y	Y	Y
FD33xS-PERC	N	N	N	N	N	N
FD33xD-PERC	N	N	N	N	N	N
Shared PERC8	N	N	N	N	N	N
Shared PERC8 External	N	N	N	N	N	N

**Table 12. 13<sup>th</sup> generation PowerEdge servers—PERC 9 controllers compatibility matrix**

<b>PowerEdge servers / PERC Controller</b>	<b>R530</b>	<b>R430</b>	<b>R330</b>	<b>R230</b>	<b>M830</b>	<b>M830 for VRTX</b>	<b>M630</b>	<b>M630 for VRTX</b>
PERC H730P adapter	Y	Y	N	N	N	N	N	N
PERC H730P mini monolithic	Y	Y	N	N	N	N	N	N
PERC H730P mini blades	N	N	N	N	Y	Y	Y	Y
PERC H730 adapter	Y	Y	Y	Y	N	N	N	N
PERC H730 mini monolithic	Y	Y	N	N	N	N	N	N
PERC H730 mini blades	N	N	N	N	Y	Y	Y	Y
PERC H330 adapter	Y	Y	Y	Y	N	N	N	N
PERC H330 mini monolithic	Y	Y	N	N	N	N	N	N
PERC H330 mini blades	N	N	N	N	Y	Y	Y	Y
PERC H830 adapter	Y	Y	Y	Y	N	N	N	N
PERC HBA330 adapter	Y	N	Y	Y	N	N	N	N
PERC HBA330 Mini-Mono	Y	Y	N	N	N	N	N	N
12 Gbps SAS HBA adapter	Y	Y	Y	Y	N	N	N	N
FD33xS-PERC	N	N	N	N	N	N	N	N
FD33xD-PERC	N	N	N	N	N	N	N	N
Shared PERC8	N	N	N	N	N	Y	N	Y
Shared PERC8 External	N	N	N	N	N	Y	N	Y

**Table 13. 13<sup>th</sup> generation PowerEdge servers—PERC 9 controllers compatibility matrix**

<b>PowerEdge servers / PERC Controller</b>	<b>T630</b>	<b>T430</b>	<b>T330</b>	<b>T130</b>	<b>FC830</b>	<b>FC630</b>	<b>FC430</b>
PERC H730P adapter	Y	Y	N	N	N	N	N
PERC H730P mini monolithic	N	N	N	N	N	N	N
PERC H730P mini blades	N	N	N	N	Y	Y	N
PERC H730 adapter	Y	Y	Y	Y	N	N	N
PERC H730 mini monolithic	N	N	N	N	N	N	N
PERC H730 mini blades	N	N	N	N	Y	Y	N
PERC H330 adapter	Y	Y	Y	Y	N	N	N
PERC H330 mini monolithic	N	N	N	N	N	N	N
PERC H330 mini blades	N	N	N	N	Y	Y	N
PERC H830 adapter	Y	Y	Y	Y	N	N	N
PERC HBA330 adapter	Y	Y	Y	Y	N	N	N
PERC HBA330 Mini-Mono	N	N	N	N	N	N	N
12 Gbps SAS HBA adapter	Y	Y	Y	Y	N	N	N
FD33xS-PERC	N	N	N	N	Y	Y	Y
FD33xD-PERC	N	N	N	N	Y	Y	Y
Shared PERC8	N	N	N	N	N	N	N
Shared PERC8 External	N	N	N	N	N	N	N

**Table 14. 12<sup>th</sup> generation PowerEdge servers—PERC 8 controllers compatibility matrix**

<b>PowerEdge servers / PERC Controller</b>	<b>R920</b>	<b>R820</b>	<b>R720xd</b>	<b>R720</b>	<b>R620</b>	<b>R520</b>
PERC H710P adapter	N	Y	Y	Y	Y	N
PERC H710P mini monolithic	N	N	Y	Y	Y	Y
PERC H710P mini blades	N	N	N	N	N	N
PERC H710 adapter	N	Y	N	N	Y	N
PERC H710 mini monolithic	N	N	Y	Y	Y	Y
PERC H710 mini blades	N	N	N	N	N	N
PERC H310 adapter	N	Y	N	N	Y	Y
PERC H310 mini monolithic	N	N	Y	Y	Y	N
PERC H310 mini blades	N	N	N	N	N	N
PERC H810	Y	Y	Y	Y	Y	Y
6 Gbps SAS adapter	N	Y	Y	Y	Y	Y

<b>PowerEdge servers / PERC Controller</b>	<b>R920</b>	<b>R820</b>	<b>R720xd</b>	<b>R720</b>	<b>R620</b>	<b>R520</b>
Shared PERC8	N	N	N	N	N	N
Shared PERC8 External	N	N	N	N	N	N

**Table 15. 12<sup>th</sup> generation PowerEdge servers—PERC 8 controllers compatibility matrix**

<b>PowerEdge servers / PERC Controller</b>	<b>R420</b>	<b>R320</b>	<b>R220</b>	<b>M820</b>	<b>M820 for VRTX</b>	<b>M620</b>	<b>M620 for VRTX</b>
PERC H710P adapter	N	N	N	N	N	N	N
PERC H710P mini monolithic	N	N	N	N	N	N	N
PERC H710P mini blades	N	N	N	Y	Y	Y	Y
PERC H710 adapter	N	N	N	N	N	N	N
PERC H710 mini monolithic	Y	Y	N	N	N	N	N
PERC H710 mini blades	N	N	N	Y	Y	Y	Y
PERC H310 adapter	Y	Y	Y	N	N	N	N
PERC H310 mini monolithic	N	N	Y	N	N	N	N
PERC H310 mini blades	N	N	N	Y	Y	Y	Y
PERC H810	Y	Y	N	N	N	N	N
6 Gbps SAS adapter	Y	Y	N	N	N	N	N
Shared PERC8	N	N	N	N	Y	N	Y
Shared PERC8 External	N	N	N	N	Y	N	Y

**Table 16. 12<sup>th</sup> generation PowerEdge servers—PERC 8 controllers compatibility matrix**

<b>PowerEdge servers / PERC Controller</b>	<b>M520</b>	<b>M520 for VRTX</b>	<b>M420</b>	<b>T620</b>	<b>T420</b>	<b>T320</b>
PERC H710P adapter	N	N	N	Y	Y	Y
PERC H710P mini monolithic	N	N	N	N	N	N
PERC H710P mini blades	Y	Y	Y	N	N	N
PERC H710 adapter	N	N	N	Y	Y	Y
PERC H710 mini monolithic	N	N	N	N	N	N
PERC H710 mini blades	Y	Y	Y	N	N	N
PERC H310 adapter	N	N	N	Y	Y	Y
PERC H310 mini monolithic	N	N	N	N	N	N
PERC H310 mini blades	Y	Y	Y	N	N	N
PERC H810	N	N	N	Y	Y	Y
6 Gbps SAS adapter	N	N	N	Y	Y	Y
Shared PERC8	N	Y	N	N	N	N

<b>PowerEdge servers / PERC Controller</b>	<b>M520</b>	<b>M520 for VRTX</b>	<b>M420</b>	<b>T620</b>	<b>T420</b>	<b>T320</b>
Shared PERC8 External	N	Y	N	N	N	N

**Legend**

Y - Supported

N - Not supported

# Dell EMC PowerEdge servers—VMware vCenter Server compatibility matrix

VMware vCenter Server is supported on a limited set of the Microsoft Windows operating systems. For more information about supported operating systems, see [Vmware.com/support/pubs/](http://Vmware.com/support/pubs/).

VMware vCenter Server is also available as a Linux vCenter appliance.

For more information about the Dell EMC PowerEdge servers compatibility with supported operating systems, see [Dell.com/ossupport](http://Dell.com/ossupport).

# Devices supported for PCIe Pass-Through

**Table 17. Devices supported for Pass-Through**

Server model with BIOS version	Controller model	Firmware version	Guest operating system (OS)	Guest OS Driver name	Guest OS Driver version used
FC630 (2.3.5)	QLogic 57810S Dual 10GE PCIe Standup Base-T CNA	08.07.25	WS 2012 R2 DC	Bnxd60a	7.13.54.0
FC630 (2.3.5)	QLogic 57810S Dual 10GE PCIe Standup Base-T CNA	08.07.25	RHEL 7.2	Bnx2x	1.710.51-0
FC630 (2.3.5)	QLogic 57810S Dual 10GE PCIe Standup Base-T CNA	08.07.25	SLES 12 SP2	Bnx2x	1.710.51-0
T630 (2.3.4)	Intel X540 Adapter	17.5.10	WS 2012 R2 DC	ixi63x64	3.4.47.2
T630 (2.3.4)	Emulex OneConnect OCe14102-UX-D 2-port PCIe 10 GbE CNA	02.00.04	WS 2012 R2 DC	Ocnd64	11.0.243.18
T630 (2.3.4)	NVMe PM1725 800 GB PCIe SSD Controller	IPM0LD3Q	WS 2012 R2 DC	stornvme	6.3.9600.16421
T630 (2.3.4)	Emulex OneConnect OCe14102-UX-D 2-port PCIe 10 GbE CNA	02.00.04	RHEL 7.2	be2net	10.6.0.3r
T630 (2.3.4)	Intel X540 Adapter	17.5.10	RHEL 7.2	ixgbe	4.0.1-k
T630 (2.3.4)	NVMe PM1725 800 GB PCIe SSD Controller	IPM0LD3Q	RHEL 7.2	nvme	3.10.0-327
T630 (2.3.4)	NVMe PM1725 800 GB PCIe SSD Controller	IPM0LD3Q	SLES 12 SP2	nvme	4.4.21-69
T630 (2.3.4)	Intel X540 Adapter	17.5.10	SLES 12 SP2	ixgbe	4.0.1-k
T630 (2.3.4)	Emulex OneConnect OCe14102-UX-D 2-port PCIe 10 GbE CNA	02.00.04	SLES 12 SP2	be2net	11.0.0.0
M630P (2.3.5)	QLE2662 Dual Port FC16 HBA	08.00.15	WS 2012 R2 DC	ql2300i	9.1.11.3
M630P (2.3.5)	QLE2662 Dual Port FC16 HBA	08.00.15	RHEL 7.2	qla3xxx	v2.03.00-k5
M630P (2.3.5)	QLE2662 Dual Port FC16 HBA	08.00.15	SLES 12 SP2	qla3xxx	v2.03.00-k5
R930 (2.1.3)	Broadcom 57840 Adapter	08.07.25	WS 2012 R2 DC	bxnd60a	7.4.23.2
R930 (2.1.3)	Broadcom 57840 Adapter	08.07.25	RHEL 7.2	bnx2x	1.710.51-0
R930 (2.1.3)	Broadcom 57840 Adapter	08.07.25	SLES 12 SP2	bnx2x	1.710.51-0
R930 (2.1.3)	ConnectX-3 Dual Port 10 GbE DA/SFP+ Network Adapter	02.36.50	WS 2012 R2 DC	mlx4eth63	4.4.13905

<b>Server model with BIOS version</b>	<b>Controller model</b>	<b>Firmware version</b>	<b>Guest operating system (OS)</b>	<b>Guest OS Driver name</b>	<b>Guest OS Driver version used</b>
R930 (2.1.3)	ConnectX-3 Dual Port 10 GbE DA/SFP+ Network Adapter	02.36.50	RHEL 7.2	mlx4_core	2.2-1
R930 (2.1.3)	ConnectX-3 Dual Port 10 GbE DA/SFP+ Network Adapter	02.36.50	SLES 12 SP2	mlx4_core	2.2-1
M630P (2.3.5)	Dell Express Flash NVMe SM1715 3.2 TB PCIe SSD Adapter by Samsung	IPV45D3Q	WS 2012 R2 DC	stornvme	6.3.9600.16421
M630P (2.3.5)	Dell Express Flash NVMe SM1715 3.2 TB PCIe SSD Adapter by Samsung	IPV45D3Q	RHEL 7.2	nvme	1.0
M630P (2.3.5)	Dell Express Flash NVMe SM1715 3.2 TB PCIe SSD Adapter by Samsung	IPV45D3Q	SLES 12 SP2	nvme	1.0

Legends:

- WS - Windows Server
- SLES - SUSE Linux Enterprise Server
- SP - Service Pack
- RHEL - Red Hat Enterprise Linux

# Getting help

Topics:

- [Contacting Dell EMC](#)
- [Related information for virtualization solutions](#)
- [Documentation resources](#)
- [Downloading the drivers and firmware](#)
- [Documentation feedback](#)

## Contacting Dell EMC

Dell EMC provides several online and telephone based support and service options. If you do not have an active internet connection, you can find contact information about your purchase invoice, packing slip, bill, or Dell EMC product catalog. Availability varies by country and product, and some services may not be available in your area.

To contact Dell EMC for sales, technical assistance, or customer service issues:

- 1 Go to [Dell.com/support](#).
- 2 Select your country from the drop-down menu on the lower right corner of the page.
- 3 For customized support:
  - a Enter your system Service Tag in the **Enter your Service Tag** field.
  - b Click **Submit**.
 The support page that lists the various support categories is displayed.
- 4 For general support:
  - a Select your product category.
  - b Select your product segment.
  - c Select your product.
 The support page that lists the various support categories is displayed.
- 5 For contact details of Dell EMC Global Technical Support:
  - a Click [Global Technical Support](#).
  - b The **Contact Technical Support** page is displayed with details to call, chat, or email the Dell EMC Global Technical Support team.

## Related information for virtualization solutions

**Table 18. Related information for virtualization solutions**

If you need information about	See
Dell EMC VMware documentation	<a href="#">Dell.com/virtualizationsolutions</a>
OpenManage documentation	<a href="#">Dell.com/openmanagemanuals</a>
PowerEdge documentation	<a href="#">Dell.com/poweredge manuals</a>
Basic configuration information for running ESXi on a Dell EMC PowerEdge server.	<i>Getting Started Guide</i> at <a href="#">Dell.com/virtualizationsolutions</a>

If you need information about	See
<ul style="list-style-type: none"> <li>Information about downloading, installing, and configuring ESXi</li> <li>Supported hardware configurations for running ESXi on a Dell EMC PowerEdge server</li> </ul>	<i>Installation Instructions and Important Information Guide</i> at <a href="http://Dell.com/virtualizationsolutions">Dell.com/virtualizationsolutions</a>
PowerEdge servers and compatibility with vMotion	VMware vMotion and 64-bit Virtual Machine Support Compatibility Matrix at <a href="http://Dell.com/virtualizationsolutions">Dell.com/virtualizationsolutions</a>
PowerEdge and PowerVault compatibility information for running ESXi	VMware vSphere for Dell EMC PowerEdge servers Compatibility Matrix at <a href="http://Dell.com/virtualizationsolutions">Dell.com/virtualizationsolutions</a>
About known issues and resolutions	VMware vSphere 6 on Dell EMC PowerEdge server Release Notes at <a href="http://Dell.com/virtualizationsolutions">Dell.com/virtualizationsolutions</a>
ESXi ISO image customization information	ESXi Image Customization Information at <a href="http://Dell.com/virtualizationsolutions">Dell.com/virtualizationsolutions</a>

## Technical support resources

- [vmware.com/support](http://vmware.com/support)
- [Dell and VMware product page](http://Dell.com/VMware)
- [Dell.com/support/home](http://Dell.com/support/home)
- [Dell.com/services](http://Dell.com/services)

## Discussion forums

- [communities.vmware.com/community/vmtn](http://communities.vmware.com/community/vmtn)
- [en.community.dell.com/techcenter/virtualization/w/wiki/vmware.aspx](http://en.community.dell.com/techcenter/virtualization/w/wiki/vmware.aspx)
- Wikis, Forums, Blogs and Videos
- [Dellcommunity.com](http://Dellcommunity.com)

## Knowledge base

- [kb.vmware.com/kb](http://kb.vmware.com/kb)

 **NOTE:** For more information related to the VMware ESXi installation on Dell EMC PowerEdge servers, go to [Dell Virtualization](#).

## Virtualization videos on Dell EMC PowerEdge servers

All the supported virtualization videos for Dell EMC PowerEdge servers are available in the [Supported Operating Systems for Dell PowerEdge servers playlist](#).

**Table 19. Virtualization videos on Dell EMC PowerEdge servers**

Video title	Links
Downloading the Dell EMC customized ESXi image from support site	<a href="http://www.youtube.com/watch?v=YnVxtkAkYTI">www.youtube.com/watch?v=YnVxtkAkYTI</a>
OS Deployment (VMware ESXi) - Installing Using CD/DVD	<a href="http://www.youtube.com/watch?v=-EbufUS86zA">www.youtube.com/watch?v=-EbufUS86zA</a>
Enabling and Configuring Fault Resilient Memory on Dell EMC PowerEdge servers	<a href="http://www.youtube.com/watch?v=retSh-XlsK0">www.youtube.com/watch?v=retSh-XlsK0</a>
To enable UEFI Secure Boot on VMware ESXi 6.5.x for Dell's 13th generation of PowerEdge server	<a href="http://www.youtube.com/watch?v=Ll9qlF9qV9I">www.youtube.com/watch?v=Ll9qlF9qV9I</a>
OS Deployment (VMware ESXi) - Installing on BOSS S1 device	<a href="http://www.youtube.com/watch?v=TB1loXpFFME">www.youtube.com/watch?v=TB1loXpFFME</a>
OS Deployment (VMware ESXi) - Installing on IDSDM	<a href="http://www.youtube.com/watch?v=EC-Xntg5mgw">www.youtube.com/watch?v=EC-Xntg5mgw</a>
To enable UEFI Secure Boot on VMware ESXi 6.5.x for Dell EMC's 14th generation of PowerEdge server	<a href="http://www.youtube.com/watch?v=ZZB_XyV0enY">www.youtube.com/watch?v=ZZB_XyV0enY</a>

## Documentation resources

This section provides information about the documentation resources for your server.

**Table 20. Additional documentation resources for your server**

Task	Document	Location
Setting up your server	For information about installing the server into a rack, see the Rack documentation included with your rack solution Or the <i>Getting Started With Your System</i> document that is shipped with your server.  For information about turning on the server and the technical specifications of your server, see the <i>Getting Started With Your System</i> document that is shipped with your server.	<a href="http://Dell.com/poweredgemanuals">Dell.com/poweredgemanuals</a>
Configuring your server	For information about the iDRAC features, configuring and logging in to iDRAC, and managing your server remotely, see the Integrated Dell Remote Access Controller User's Guide.  For information about installing the operating system, see the operating system documentation.	<a href="http://Dell.com/idracmanuals">Dell.com/idracmanuals</a>  <a href="http://Dell.com/operatingsystemmanuals">Dell.com/operatingsystemmanuals</a>

Task	Document	Location
Managing your server	For information about understanding Remote Access Controller Admin (RACADM) subcommands and supported RACADM interfaces, see the RACADM Command Line Reference Guide for iDRAC.	<a href="http://Dell.com/idracmanuals">Dell.com/idracmanuals</a>
	For information about updating drivers and firmware, see the Methods to download firmware and drivers section in this document.	<a href="http://Dell.com/support/drivers">Dell.com/support/drivers</a>
	For information about servers management software offered by Dell EMC, see the Dell EMC OpenManage Systems Management Overview Guide.	<a href="http://Dell.com/openmanagemanuals">Dell.com/openmanagemanuals</a>
	For information about setting up, using, and troubleshooting OpenManage, see the Dell EMC OpenManage Server Administrator User's Guide.	<a href="http://Dell.com/openmanagemanuals">Dell.com/openmanagemanuals</a>
	For information about installing, using, and troubleshooting Dell EMC OpenManage Essentials, see the Dell EMC OpenManage Essentials User's Guide.	<a href="http://Dell.com/openmanagemanuals">Dell.com/openmanagemanuals</a>
	For information about installing and using Dell SupportAssist, see the Dell EMC SupportAssist Enterprise User's Guide.	<a href="http://Dell.com/serviceabilitytools">Dell.com/serviceabilitytools</a>
	For understanding the features of Dell EMC Lifecycle Controller (LC), see the Lifecycle Controller User's Guide.	<a href="http://Dell.com/idracmanuals">Dell.com/idracmanuals</a>
	For information about partner programs enterprise systems management, see the OpenManage Connections Enterprise Systems Management documents.	<a href="http://Dell.com/omconnectionsenterprisesystemsmanagement">Dell.com/omconnectionsenterprisesystemsmanagement</a>
	For information about viewing inventory, performing configuration, and monitoring tasks, remotely turning on or off servers, and enabling alerts for events on servers and components using the Dell EMC Chassis Management Controller (CMC), see the CMC User's Guide.	<a href="http://Dell.com/esmmanuals">Dell.com/esmmanuals</a>
	For information about understanding the features of the Dell EMC PowerEdge RAID controllers	<a href="http://Dell.com/storagecontrollermanuals">Dell.com/storagecontrollermanuals</a>

Task	Document	Location
	(PERC) and deploying the PERC cards, see the Storage controller documentation.	
Understanding event and error messages	For information about checking the event and error messages generated by the system firmware and agents that monitor server components, see the Dell EMC Event and Error Messages Reference Guide.	<a href="https://www.dell.com/openmanagemanuals">Dell.com/openmanagemanuals</a> > OpenManage software
Fan Control Board firmware update and Set Chassis Type procedure	For information about updating the Fan Control Board firmware and setting the chassis type to accommodate either PowerEdge C6320 or PowerEdge C6320p sleds in the PowerEdge C6300 enclosure, see the Fan Control Board firmware update and Set Chassis Type procedure section in this document.	
Troubleshooting your system	For information about identifying and troubleshooting the PowerEdge server issues, see the Server Troubleshooting Guide.	<a href="https://www.dell.com/poweredgemanuals">Dell.com/poweredgemanuals</a>

## Downloading the drivers and firmware

Dell EMC recommends that you download and install the latest BIOS, drivers, and systems management firmware on your system. Ensure that you clear the web browser cache before downloading the drivers and firmware.

- 1 Go to [Dell.com/support/drivers](https://www.dell.com/support/drivers).
- 2 Under the **Drivers & Downloads** section, type the Service Tag of your system in the **Service Tag or Express Service Code** box, and then click **Submit**.
 

**NOTE:** If you do not have the Service Tag, select **Detect My Product** to allow the system to automatically detect your Service Tag, or under **General support**, navigate to your product.
- 3 Click **Drivers & Downloads**.  
The drivers that are applicable to your selection are displayed.
- 4 Download the drivers to a USB drive, CD, or DVD.

## Documentation feedback

You can rate the documentation or write your feedback on any of our Dell EMC documentation pages and click **Send Feedback** to send your feedback.