




1. Disassembly Procedures:

Step	Figure	Remark
<p>S1.The FRONT VIEW</p>		<p>Turn off power, Unplug external cables from product</p>
<p>S2.Remove the STAND-BASE ASS'Y</p>		<p>To remove the stand:</p> <ol style="list-style-type: none"> 1. Press and hold the stand release button. 2. Lift the stand up and away from the monitor. <p>Note: To prevent scratches on the LCD screen while removing the stand, ensure that the monitor is placed on a soft, clean surface.</p>

S3.Remove the screws to remove the Rear Cover




Use a Philips-head screwdriver to remove 2 screws for unlocking mechanisms.

(No.1~2 screw size=M3x3;
Torque=6±1kgf.cm)

Use Penknife to separate the bezel and rear cover follow the arrows in sequence, then you can take out rear cover.

S4.Disconnect the pins and remove the tapes







Use a Philips-head screwdriver to remove 6 screws for remove speaker.

(No.1~6 screw size=M3x6;
Torque=6±1kgf.cm)

Only for S2419H model

S5.Remove the screws to remove the speaker



<p>S6.Remove the screws to remove the mainframe</p>		<p>Use a Philips-head screwdriver to remove 3 screws for remove mainframe (No.1~3 screw size=P3x4; Torque= 3±0.5kgf.cm)</p>
<p>S7.Remove the screws to remove the middle frame</p>		<p>Use a Philips-head screwdriver to remove 10 screws for remove middle frame (No.1~10 screw size=M3x3; Torque=3±0.5kgf.cm)</p>
<p>S8.Remove the panel FFC cable and the cable(converter board / panel)</p>		







S9.The panel




S10.Remove the Key Board



<p>S11.The Middle frame</p>		
<p>S12.Remove the screws to remove the main board and converter board</p>		<p>Use a Philips-head screwdriver to remove 5 screws for remove main board and converter board (No.1~5 screw size=D3x6; Torque=6±1kgf.cm)</p>
<p>S13.Remove the pin</p>		
<p>S14. The Converter Board</p>		<p>electrolyte capacitors (height < 25mm, diameter < 25mm)</p>

**S15.The Main
Frame**



2. Product material information

The following substances, preparations, or components should be disposed of or recovered separately from other WEEE in compliance with Article 4 of EU Council Directive 75/442/EEC.

Capacitors / condensers (containing PCB/PCT)	No used
Mercury containing components	No used
Batteries	No used
Printed circuit boards (with a surface greater than 10 square cm)	Product has printed circuit boards (with a surface greater than 10 square cm)
Component contain toner, ink and liquids	No used
Plastic containing BFR	The DC cable of power adapter contain BFR
Component and waste contain asbestos	No used
CRT	No used
Component contain CFC, HCFC, HFC and HC	No used
Gas discharge lamps	No used
LCD display > 100 cm ²	Product has an LCD greater than 100 cm ²
External electric cable	Product has external cables
Component contain refractory ceramic fibers	No used
Component contain radio-active substances	No used
Electrolyte capacitors (height > 25mm, diameter > 25mm)	The power adapter has electrolyte capacitors (height > 25mm, diameter > 25mm)

3. Tools Required

List the type and size of the tools that would typically can be used to disassemble the product to a point where components and materials requiring selective treatment can be removed.

Tool Description:

- Phillip head Screwdriver
- Penknife
- Soldering iron and absorber