

Dell DR4000 Systems

# Owner's Manual

**Regulatory Model E13S Series**  
**Regulatory Type E13S001**



# Notes, Cautions, and Warnings



**NOTE:** A NOTE indicates important information that helps you make better use of your computer.



**CAUTION:** A CAUTION indicates potential damage to hardware or loss of data if instructions are not followed.



**WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

---

**Information in this publication is subject to change without notice.**

**© 2012 Dell Inc. All rights reserved.**

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: Dell™, the DELL logo, and PowerVault™ are trademarks of Dell Inc.

Other trademarks and trade names may be used in this publication to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

**Regulatory Model E13S Series**  
**Regulatory Type E13S001**

# Contents

1	About Your System . . . . .	11
	<b>Accessing System Features During Startup . . . . .</b>	<b>11</b>
	<b>Front-Panel Features and Indicators . . . . .</b>	<b>12</b>
	<b>Hard-Drive Indicator Patterns . . . . .</b>	<b>14</b>
	<b>Back-Panel Features and Indicators . . . . .</b>	<b>15</b>
	<b>NIC Indicator Codes . . . . .</b>	<b>17</b>
	<b>NVRAM Card Indicator Codes . . . . .</b>	<b>17</b>
	<b>Power Indicator Codes . . . . .</b>	<b>18</b>
	<b>Diagnostic Lights . . . . .</b>	<b>19</b>
	<b>System Messages . . . . .</b>	<b>22</b>
	<b>Warning Messages . . . . .</b>	<b>37</b>
	<b>Diagnostics Messages . . . . .</b>	<b>37</b>
	<b>Alert Messages . . . . .</b>	<b>37</b>
	<b>Other Information You May Need . . . . .</b>	<b>38</b>
2	Using the System Setup Program and UEFI Boot Manager . . . . .	39
	<b>Entering the System Setup Program . . . . .</b>	<b>39</b>
	Responding to Error Messages. . . . .	39

Using the System Setup Program Navigation Keys . . . . .	40
<b>System Setup Options . . . . .</b>	<b>41</b>
Main Screen . . . . .	41
Memory Settings Screen . . . . .	43
Processor Settings Screen . . . . .	43
Boot Settings Screen . . . . .	45
Integrated Devices Screen . . . . .	45
PCI IRQ Assignments Screen . . . . .	46
Serial Communication Screen . . . . .	47
Power Management Screen . . . . .	48
System Security Screen . . . . .	48
Exit Screen . . . . .	50
<b>System and Setup Password Features. . . . .</b>	<b>51</b>
Using the System Password . . . . .	51
Using the Setup Password . . . . .	53
<b>Embedded System Management. . . . .</b>	<b>54</b>
<b>Baseboard Management Controller Configuration . . . . .</b>	<b>55</b>
Entering the BMC Setup Module . . . . .	55
<b>iDRAC Configuration Utility . . . . .</b>	<b>56</b>
Entering the iDRAC Configuration Utility . . . . .	56
<b>3 Installing System Components . . . . .</b>	<b>57</b>
<b>Recommended Tools . . . . .</b>	<b>57</b>
<b>Inside the System. . . . .</b>	<b>57</b>
<b>Front Bezel . . . . .</b>	<b>59</b>
Removing the Front Bezel. . . . .	59
Installing the Front Bezel . . . . .	60

<b>Opening and Closing the System</b> . . . . .	<b>60</b>
Opening the System . . . . .	60
Closing the System . . . . .	61
<b>Cooling Shroud</b> . . . . .	<b>62</b>
Removing the Cooling Shroud . . . . .	62
Installing the Cooling Shroud . . . . .	63
<b>Hard Drives</b> . . . . .	<b>63</b>
Removing a Hard-Drive Blank . . . . .	63
Installing a Hard-Drive Blank . . . . .	64
Removing a Hot-Swap Hard Drive . . . . .	64
Installing a Hot-Swap Hard Drive . . . . .	65
Removing a Hard Drive From a Hard-Drive Carrier . . . . .	66
Installing a Hard Drive Into a Hard-Drive Carrier . . . . .	67
<b>Internal Hard Drives</b> . . . . .	<b>67</b>
Removing an Internal Hard Drive Bay . . . . .	67
Installing an Internal Hard-Drive Bay . . . . .	69
Removing an Internal Hard Drive From the Internal Hard-Drive Bay . . . . .	69
Installing a Hard Drive Into a Hard-Drive Bay . . . . .	70
<b>Cooling Fans</b> . . . . .	<b>71</b>
Removing a Cooling Fan . . . . .	71
Installing a Cooling Fan . . . . .	73
<b>Power Supplies</b> . . . . .	<b>74</b>
Removing a Power Supply . . . . .	74
Installing a Power Supply . . . . .	75

<b>System Memory</b> . . . . .	<b>76</b>
General Memory Module Installation Guidelines . . . . .	76
Mode-Specific Guidelines . . . . .	77
Removing Memory Modules . . . . .	78
Installing Memory Modules . . . . .	79
<b>Expansion Cards and Expansion-Card Risers</b> . . . . .	<b>81</b>
Expansion Card Installation Guidelines . . . . .	81
Removing an Expansion Card . . . . .	82
Removing an Expansion-Card Riser . . . . .	83
Installing an Expansion Card . . . . .	84
Installing an Expansion-Card Riser . . . . .	86
<b>Integrated Storage Controller Card</b> . . . . .	<b>86</b>
Removing the Storage Controller Card . . . . .	87
Installing the Storage Controller Card . . . . .	89
<b>iDRAC6 Express Card</b> . . . . .	<b>90</b>
Removing an iDRAC6 Express Card . . . . .	90
Installing an iDRAC6 Express Card . . . . .	91
<b>iDRAC6 Enterprise Card</b> . . . . .	<b>93</b>
Removing an iDRAC6 Enterprise Card . . . . .	93
Installing an iDRAC6 Enterprise Card . . . . .	94
<b>Processors</b> . . . . .	<b>95</b>
Removing a Processor . . . . .	95
Installing a Processor . . . . .	99
<b>System Battery</b> . . . . .	<b>100</b>
Replacing the System Battery . . . . .	100
<b>RAID Battery</b> . . . . .	<b>103</b>
Removing the RAID Battery . . . . .	103
Installing the RAID Battery . . . . .	104

<b>Control Panel Assembly—LED</b> . . . . .	<b>104</b>
Removing the Control-Panel Module—LED . . . . .	104
Installing the Control-Panel Module—LED . . . . .	106
<b>Front-Panel I/O Module</b> . . . . .	<b>107</b>
Removing the Front-Panel I/O Module . . . . .	107
Installing the Front-Panel I/O Module . . . . .	109
<b>SAS Backplane</b> . . . . .	<b>109</b>
Removing the SAS Backplane . . . . .	109
Installing the SAS Backplane . . . . .	112
<b>Power Distribution Board</b> . . . . .	<b>113</b>
Removing the Power Distribution Board . . . . .	113
Installing the Power Distribution Board . . . . .	115
<b>System Board</b> . . . . .	<b>116</b>
Removing the System Board . . . . .	116
Installing the System Board . . . . .	118
<b>4 Troubleshooting Your System</b> . . . . .	<b>121</b>
<b>Safety First—For You and Your System</b> . . . . .	<b>121</b>
<b>Troubleshooting System Startup Failure</b> . . . . .	<b>121</b>
<b>Troubleshooting External Connections</b> . . . . .	<b>121</b>
<b>Troubleshooting the Video Subsystem</b> . . . . .	<b>122</b>
<b>Troubleshooting a USB Device</b> . . . . .	<b>122</b>
<b>Troubleshooting a Serial I/O Device</b> . . . . .	<b>123</b>
<b>Troubleshooting a NIC</b> . . . . .	<b>123</b>
<b>Troubleshooting an NVRAM card</b> . . . . .	<b>124</b>

<b>Troubleshooting a Wet System</b> . . . . .	124
<b>Troubleshooting a Damaged System</b> . . . . .	126
<b>Troubleshooting the System Battery</b> . . . . .	126
<b>Troubleshooting Power Supplies</b> . . . . .	127
<b>Troubleshooting System Cooling Problems</b> . . . . .	128
<b>Troubleshooting a Fan</b> . . . . .	128
<b>Troubleshooting System Memory</b> . . . . .	129
<b>Troubleshooting a Hard Drive</b> . . . . .	131
<b>Troubleshooting an Internal Hard Drive</b> . . . . .	132
<b>Troubleshooting a Storage Controller</b> . . . . .	133
<b>Troubleshooting Expansion Cards</b> . . . . .	134
<b>Troubleshooting Processors</b> . . . . .	136
<b>5 Running the System Diagnostics</b> . . . . .	139
<b>Embedded System Diagnostics Features</b> . . . . .	139
<b>When to Use the Embedded System Diagnostics</b> . . . . .	139
<b>Running the Embedded System Diagnostics</b> . . . . .	140
<b>Embedded System Diagnostics Testing Options</b> . . . . .	140
<b>Using the Custom Test Options</b> . . . . .	140
Selecting Devices for Testing . . . . .	141
Selecting Diagnostics Options . . . . .	141
Viewing Information and Results . . . . .	141



6	Jumpers and Connectors . . . . .	143
	<b>System Board Jumpers</b> . . . . .	<b>143</b>
	<b>System Board Connectors</b> . . . . .	<b>144</b>
	<b>Disabling a Forgotten Password</b> . . . . .	<b>146</b>
7	Getting Help . . . . .	149
	<b>Contacting Dell</b> . . . . .	<b>149</b>
	Index . . . . .	151



# About Your System


## Accessing System Features During Startup


The following keystrokes provide access to system features during startup.





<b>Keystroke</b>	<b>Description</b>
<F2>	Enters the System Setup program. See "Using the System Setup Program and UEFI Boot Manager" on page 39.
<F10>	Enters System Services, which opens the Lifecycle Controller. The controller allows you to access utilities such as embedded system diagnostics. For information on Lifecycle Controller or any of the Lifecycle Controller software components, see the Lifecycle Controller documentation at <a href="http://support.dell.com/manuals">support.dell.com/manuals</a> .
<F11>	Enters the BIOS Boot Manager, depending on the system's boot configuration. See "Using the System Setup Program and UEFI Boot Manager" on page 39.
<F12>	Starts Preboot eXecution Environment (PXE) boot.
<Ctrl><E>	Enters the Baseboard Management Controller (BMC) or Integrated Dell Remote Access Controller (iDRAC) Configuration Utility, which allows access to the system event log (SEL) and configuration of remote access to the system. For more information, see the BMC or iDRAC user documentation at <a href="http://support.dell.com/manual">support.dell.com/manual</a> .
<Ctrl><R>	Enters the RAID configuration utility. For more information, see the documentation for your SAS RAID card at <a href="http://support.dell.com/manual">support.dell.com/manual</a> .
<Ctrl><S>	Enters the utility to configure NIC settings for PXE boot. For more information, see the documentation for your integrated NIC at <a href="http://support.dell.com/manual">support.dell.com/manual</a> .

# Front-Panel Features and Indicators

Figure 1-1. Front-Panel Features and Indicators



Item	Indicator, Button, or Connector	Icon	Description
1	LED panel		The LED panel has four diagnostic indicator lights that display error codes during system startup. See "Diagnostic Lights" on page 19.
2	Power-on indicator/ power button		<p>The power-on indicator lights when the system power is on.</p> <p>The power button controls the DC power supply output to the system. When the system bezel is installed, the power button is not accessible.</p> <p><b>NOTE:</b> When powering on the system, the video monitor can take from several seconds to over 2 minutes to display an image, depending on the amount of memory installed in the system.</p> <p><b>NOTE:</b> On ACPI-compliant operating systems, turning off the system using the power button causes the system to perform a graceful shutdown before power to the system is turned off.</p> <p><b>NOTE:</b> To force an ungraceful shutdown, press and hold the power button for 5 seconds.</p>

Item	Indicator, Button, or Connector	Icon	Description
3	NMI button		Used to troubleshoot software and device driver errors when using certain operating systems. This button can be pressed using the end of a paper clip.  Use this button only if directed to do so by qualified support personnel or by the operating system's documentation.
4	System identification button		The identification buttons on the front and back panels can be used to locate a particular system within a rack. When one of these buttons is pushed, the blue system status indicator on the back blinks until one of the buttons is pushed again.
5	Hard drive		Twelve 3.5 inch hot-swappable SAS drives.
6	System identification panel		A slide-out panel for system information including the Express Service tag, embedded NIC MAC address, and iDRAC6 Enterprise card MAC address.
7	USB connector		Connects USB devices to the system. The port is USB 2.0-compliant.
8	Video connector		Connects a monitor to the system.

# Hard-Drive Indicator Patterns

Figure 1-2. Hard-Drive Indicators



- 1 hard-drive activity indicator (green)
- 2 hard-drive status indicator (green and amber)


Drive-Status Indicator Pattern	Condition
Blinks green two times per second	Identify drive/preparing for removal
Off	Drive ready for insertion or removal <b>NOTE:</b> The drive status indicator remains off until all hard drives are initialized after system power is applied. Drives are not ready for insertion or removal during this time.
Blinks green, amber, and off	Drive predicted failure
Blinks amber four times per second	Drive failed







Drive-Status Indicator Pattern	Condition
Blinks green slowly	Drive rebuilding
Steady green	Drive online
Blinks green three seconds, off three seconds, amber three seconds, and off three seconds	Rebuild aborted


## Back-Panel Features and Indicators

Figure 1-3 shows the controls, indicators, and connectors located on the back panel of the system.

**Figure 1-3. Back-Panel Features and Indicators**




Item	Indicator, Button, or Connector	Icon	Description
1	Serial connector		Connects a serial device to the system.
2	Video connector		Connects a VGA display to the system.
3	iDRAC6 Enterprise port		Dedicated management port for the iDRAC6 Enterprise card.
4	VFlash media slot (optional)		Connects an external SD memory card for the iDRAC6 Enterprise card.
5	USB connectors (2)		Connects USB devices to the system. The ports are USB 2.0-compliant.
6	Ethernet connectors (2)		Embedded 10/100/1000 NIC connectors.

Item	Indicator, Button, or Connector	Icon	Description
7	PCIe expansion card slots using riser card		<p>Connects one internal and three external PCI Express Generation 2 expansion cards.</p> <p>Slot 1: PCIe x4, half-length, full-height            Slot 2: PCIe x4, full-length, full-height            Slot 3: PCIe x8, half-length, full-height            Slot 4: PCIe x4, internal slot for integrated card</p> <p><b>NOTE:</b> All slots are x8 connectors.</p>
8	System identification connector		Connects the optional system status indicator assembly through the optional cable management arm.
9	System status indicator		<p>Lights blue during normal system operation.</p> <p>Both the systems management software and the identification buttons located on the front and back of the system can cause the indicator to blink blue to identify a particular system.</p> <p>Lights amber when the system needs attention due to a problem.</p>
10	System identification button		<p>The identification buttons on the front and back panels can be used to locate a particular system within a rack. When one of these buttons is pushed, the blue system status indicator on the chassis back blinks until one of the buttons is pushed again.</p>
11	Power supply 2 (PS2)		750 W redundant power supply
12	Power supply 1 (PS1)		750 W redundant power supply



# NIC Indicator Codes

**Figure 1-4. NIC Indicators**



1 link indicator

2 activity indicator

Indicator	Indicator Code
Link and activity indicators are off	The NIC is not connected to the network.
Link indicator is green	The NIC is connected to a valid network link at 1000 Mbps.
Link indicator is amber	The NIC is connected to a valid network link at 10/100 Mbps.
Activity indicator is green	Network data is being sent or received.

# NVRAM Card Indicator Codes

The NVRAM Card has a surface-mounted LED indicator as well as two LED indicators on the metal bracket to indicate the status.

**NOTE:** Ensure that all the LED indicators are off before you remove the NVRAM card.

Table 1-1 describes LED indicators behavior during normal powered operation of the NVRAM card and Table 1-2 describes LED indicators behavior in the event of power loss.

**Table 1-1. LED States during Normal Powered Operation of NVRAM Card**

Green Indicator	Amber Indicator	Description
Steady	Steady	Firmware is booting.
		<b>NOTE:</b> The LEDs remain in this state during the data restoration process
Steady	Blinking	Supercapacitors are charging.

**Table 1-1. LED States during Normal Powered Operation of NVRAM Card**

<b>Green Indicator</b>	<b>Amber Indicator</b>	<b>Description</b>
Steady	Off	Card is activated and operational.
Off	Steady	Error due to one or more of the following: <ul style="list-style-type: none"><li>• Supercapacitors are not connected.</li><li>• Flash module is either not connected or is not responding.</li><li>• POST memory test has failed.</li></ul>
Blinking	Off/Steady/Blinking	Data activity from host.

**Table 1-2. LED States during Power Loss**

<b>Green Indicator</b>	<b>Amber Indicator</b>	<b>Backup Progress</b>
Blinking	Off	0 to 25%
Blinking	Blinking	25 to 50%
Blinking	Steady	50 to 75%
Steady	Blinking	75 to 100%
Steady	Steady	Backup complete.


## Power Indicator Codes

The power supplies have an indicator that shows whether power is present or a power fault has occurred.

- Not lit — AC power is not connected.
- Green — In standby mode, indicates that a valid AC source is connected to the power supply, and that the power supply is operational. When the system is on, it also indicates that the power supply is providing DC power to the system.
- Amber — Indicates a problem with the power supply.

- Alternating green and amber — When hot-adding a power supply, this indicates that the power supply is mismatched with the other power supply. Replace the power supply that has the flashing indicator with a power supply that matches the capacity of the other installed power supply.

**Figure 1-5. Power Supply Status Indicator**



1 power supply status

## Diagnostic Lights

The four diagnostic indicator lights on the system front panel display error codes during system startup. Table 1-3 lists the causes and possible corrective actions associated with these codes. A highlighted circle indicates the light is on; a non-highlighted circle indicates the light is off.

**Table 1-3. Diagnostic Indicator Codes**


Code	Causes	Corrective Action
①②③④	<p>The system is in a normal off condition or a possible pre-BIOS failure has occurred.</p> <p>The diagnostic lights are not lit after the system successfully boots to the operating system.</p> <p>The system is in a normal operating condition after POST.</p>	<p>Plug the system into a working electrical outlet and press the power button.</p> <p>Information only.</p>
①②③④	<p>BIOS checksum failure detected; system is in recovery mode.</p>	<p>See "Getting Help" on page 149.</p>
①②③④	<p>Possible processor failure.</p>	<p>See "Troubleshooting Processors" on page 136.</p>
①②③④	<p>Memory failure.</p>	<p>See "Troubleshooting System Memory" on page 129.</p>
①②③④	<p>Possible expansion card failure.</p>	<p>See "Troubleshooting Expansion Cards" on page 134.</p>
①②③④	<p>Possible video failure.</p>	<p>See "Getting Help" on page 149.</p>
①②③④	<p>Hard drive failure.</p>	<p>Ensure that the hard drives are properly connected. See "Hard Drives" on page 63 for information on the drives installed in your system.</p>
①②③④	<p>Possible USB failure.</p>	<p>See "Troubleshooting a USB Device" on page 122.</p>

**Table 1-3. Diagnostic Indicator Codes (continued)**

<b>Code</b>	<b>Causes</b>	<b>Corrective Action</b>
① ② ③ ④	No memory modules detected.	See "Troubleshooting System Memory" on page 129.
① ② ③ ④	System board failure.	See "Getting Help" on page 149.
① ② ③ ④	Memory configuration error.	See "Troubleshooting System Memory" on page 129.
① ② ③ ④	Possible system board resource and/or system board hardware failure.	See "Getting Help" on page 149.
① ② ③ ④	Possible system resource configuration error.	See "Contacting Dell" on page 149.
① ② ③ ④	Other failure.	Ensure that the hard drives are properly connected. See "Troubleshooting a Hard Drive" on page 131 for the appropriate drive installed in your system. If the problem persists, see "Getting Help" on page 149.

# System Messages

System messages appear on the screen to notify you of a possible problem with the system.

 **NOTE:** If you receive a system message not listed in the table, check the documentation for the application that is running or the operating system's documentation for an explanation of the message and recommended action.

Message	Causes	Corrective Actions
128-bit Advanced ECC mode disabled. For 128-bit Advanced ECC, DIMMs must be installed in pairs. Pairs must be matched in size and geometry.	The Advanced ECC option was enabled in BIOS, but is no longer valid due to an unsupported memory configuration, possibly a faulty or removed memory module. The Advanced ECC setting has been disabled.	Check other messages for a faulty memory module. Reconfigure the memory modules for Advanced ECC mode. See "System Memory" on page 76.
Alert! Advanced ECC Memory Mode disabled! Memory configuration does not support Advanced ECC Memory Mode.	Advanced ECC Memory Mode was enabled in the system setup program, but the current configuration does not support Advanced ECC Memory Mode. A memory module may be faulty.	Ensure that the memory modules are installed in a configuration that supports Advanced ECC Memory Mode. Check other system messages for additional information for possible causes. For memory configuration information, see "General Memory Module Installation Guidelines" on page 76. If the problem persists, see "Troubleshooting System Memory" on page 129.

<b>Message</b>	<b>Causes</b>	<b>Corrective Actions</b>
Alert! iDRAC6 not responding. Rebooting.	The iDRAC6 is not responding to BIOS communication either because it is not functioning properly or has not completed initialization. The system reboots.	Wait for the system to reboot.
Alert! iDRAC6 not responding. Power required may exceed PSU wattage.  Alert! Continuing system boot accepts the risk that system may power down without warning.	The iDRAC6 stops responding.  The iDRAC6 was remotely reset while system was booting.  After AC recovery, the iDRAC6 takes longer than normal to boot.	Remove AC power to the system for 10 seconds and restart the system.
Alert! Node Interleaving disabled! Memory configuration does not support Node Interleaving.	The memory configuration does not support node interleaving, or the configuration has changed (for example, a memory module has failed) so that node interleaving cannot be supported. The system still runs, but without node interleaving.	Ensure that the memory modules are installed in a configuration that supports node interleaving. Check other system messages for additional information for possible causes. For memory configuration information, see "General Memory Module Installation Guidelines" on page 76. If the problem persists, see "Troubleshooting System Memory" on page 129.

<b>Message</b>	<b>Causes</b>	<b>Corrective Actions</b>
Alert! Power required exceeds PSU wattage. Check PSU and system configuration.  Alert! Continuing system boot accepts the risk that system may power down without warning.	The system configuration of processor(s), memory modules, and expansion cards may not be supported by the power supplies.	If any system components were just upgraded, return the system to the previous configuration. If the system boots without this warning, then the replaced component(s) are not supported with this power supply. If Energy Smart power supplies are installed, replace them with high output power supplies to use the components. See "Power Supplies" on page 74.
Alert! Redundant memory disabled! Memory configuration does not support redundant memory.	Memory sparing or memory mirroring was enabled in the system setup program, but the current configuration does not support redundant memory. A memory module may be faulty.	Check the memory modules for failure. See "Troubleshooting System Memory" on page 129. Reset the memory setting, if appropriate. See "Using the System Setup Program and UEFI Boot Manager" on page 39.
Alert! System fatal error during previous boot.	An error caused the system to reboot.	Check other system messages for additional information for possible causes.
BIOS MANUFACTURING MODE detected. MANUFACTURING MODE will be cleared before the next boot. System reboot required for normal operation.	System is in manufacturing mode.	Reboot to take the system out of manufacturing mode.



<b>Message</b>	<b>Causes</b>	<b>Corrective Actions</b>
BIOS Update Attempt Failed!	Remote BIOS update attempt failed.	Retry the BIOS update. If problem persists, see "Getting Help" on page 149.
Caution! NVRAM_CLR jumper is installed on system board. Please run SETUP.	NVRAM_CLR jumper is installed in the clear setting. CMOS has been cleared.	Move the NVRAM_CLR jumper to the default position (pins 3 and 5). See Figure 6-1 for jumper location. Restart the system and re-enter the BIOS settings. See "Using the System Setup Program and UEFI Boot Manager" on page 39.
CPU set to minimum frequency.	The processor speed may be intentionally set lower for power conservation.	If not an intentional setting, check any other system messages for possible causes.
CPU x installed with no memory.	Memory modules are required but not installed in the indicated processor's memory slots.	Install memory modules for the processor. See "System Memory" on page 76.

<b>Message</b>	<b>Causes</b>	<b>Corrective Actions</b>
CPUs with different cache sizes detected. CPUs with different core sizes detected! System halted.  CPUs with different logical processors detected! System halted.  CPUs with different power rating detected! System halted.	Mismatched processors have been installed in the system.	Ensure that all processors have the same cache size, number of cores and logical processors, and power rating. Ensure that the processors are properly installed. See "Processors" on page 95.
Current boot mode is set to UEFI. Please ensure compatible bootable media is available. Use the system setup program to change the boot mode as needed.	The system failed to boot because UEFI boot mode is enabled in BIOS and the boot operating system is non-UEFI.	Ensure that the boot mode is set correctly and that the proper bootable media is available. See "Using the System Setup Program and UEFI Boot Manager" on page 39.
Decreasing available memory.	Faulty or improperly installed memory modules.	Reseat the memory modules. See "Troubleshooting System Memory" on page 129.
DIMM configuration on each CPU should match.	Invalid memory configuration on a dual-processor system. The memory module configuration for each processor must be identical.	Ensure that the memory modules are installed in a valid configuration. See "General Memory Module Installation Guidelines" on page 76.

<b>Message</b>	<b>Causes</b>	<b>Corrective Actions</b>
Embedded NIC <sub>x</sub> and NIC <sub>y</sub> : OS NIC=<ENABLED /DISABLED>, Management Shared NIC=<ENABLED /DISABLED>.	The OS NIC interface is set in BIOS. The Management Shared NIC interface is set in management tools.	Check the system management software or the System Setup program for NIC settings. If a problem is indicated, see "Troubleshooting a NIC" on page 123.
Error 8602 - Auxiliary Device Failure. Verify that mouse and keyboard are securely attached to correct connectors.	Mouse or keyboard cable is loose or improperly connected.  Defective mouse or keyboard.	Reseat the mouse or keyboard cable.  Ensure that the mouse or keyboard is operational. See "Troubleshooting a USB Device" on page 122.
Gate A20 failure.	Faulty keyboard controller; faulty system board.	See "Getting Help" on page 149.
Invalid configuration information - please run SETUP program.	An invalid system configuration caused a system to stop responding.	Run the System Setup program and review the current settings. See "Using the System Setup Program and UEFI Boot Manager" on page 39.
Invalid PCIe card found in the Internal_Storage slot!	The system halted because an invalid PCIe expansion card is installed in the dedicated storage controller slot.	Remove the PCIe expansion card and install the integrated storage controller in the dedicated slot. See "RAID Battery" on page 103.
Keyboard fuse has failed.	Overcurrent detected at the keyboard connector.	See "Getting Help" on page 149.

<b>Message</b>	<b>Causes</b>	<b>Corrective Actions</b>
Local keyboard may not work because all user accessible USB ports are disabled. If operating locally, power cycle the system and enter system setup program to change settings.	The USB ports are disabled in the system BIOS.	Power down and restart the system from the power button, and then enter the System Setup program to enable the USB port(s). See "Entering the System Setup Program" on page 39.
Manufacturing mode detected.	System is in manufacturing mode.	Reboot to take the system out of manufacturing mode.
Maximum rank count exceeded. The following DIMM has been disabled: x	Invalid memory configuration. The system runs but with the specified memory module disabled.	Ensure that the memory modules are installed in a valid configuration. See "General Memory Module Installation Guidelines" on page 76.
Memory Initialization Warning: Memory size may be reduced.	Invalid memory configuration. The system runs but with less memory than is physically available.	Ensure that the memory modules are installed in a valid configuration. See "General Memory Module Installation Guidelines" on page 76.
Memory set to minimum frequency.	The memory frequency may be intentionally set lower for power conservation.  The current memory configuration may support only the minimum frequency.	If not an intentional setting, check any other system messages for possible causes.  Ensure that your memory configuration supports the higher frequency. See "General Memory Module Installation Guidelines" on page 76.

<b>Message</b>	<b>Causes</b>	<b>Corrective Actions</b>
Memory tests terminated by keystroke.	POST memory test was terminated by pressing the spacebar.	Information only.
MEMTEST lane failure detected on <i>x</i> .	Invalid memory configuration. Mismatched memory modules are installed.	Ensure that the memory modules are installed in a valid configuration. See "General Memory Module Installation Guidelines" on page 76.
Mirror mode disabled. For mirror mode, DIMMs must be installed in pairs. Pairs must be matched in size and geometry.	The memory configuration does not match the setting in BIOS. The BIOS setting has been disabled.	Reconfigure the memory modules for Memory Mirroring mode. See "System Memory" on page 76.
No boot device available.	Faulty or missing hard drive, or hard drive subsystem, or no bootable USB key installed.	Use a bootable USB key or hard drive. If the problem persists, see "Troubleshooting a USB Device" on page 122 and "Troubleshooting a Hard Drive" on page 131. See "Using the System Setup Program and UEFI Boot Manager" on page 39 for information on setting the order of boot devices.

<b>Message</b>	<b>Causes</b>	<b>Corrective Actions</b>
No boot sector on hard drive.	Incorrect configuration settings in System Setup program, or no operating system on hard drive.	Check the hard drive configuration settings in the System Setup program. See "Using the System Setup Program and UEFI Boot Manager" on page 39. If necessary, install the operating system on your hard drive. See your operating system documentation.
No timer tick interrupt.	Faulty system board.	See "Getting Help" on page 149.
PCIe Training Error: Expected Link Width is <i>x</i> , Actual Link Width is <i>y</i> .	Faulty or improperly installed PCIe card in the specified slot.	Reseat the PCIe card in the specified slot number. See "Troubleshooting Expansion Cards" on page 134. If the problem persists, see "Getting Help" on page 149.
Plug & Play Configuration Error.	Error encountered in initializing PCIe device; faulty system board.	Install the NVRAM_CLR jumper in the clear position (pins 1 and 3) and reboot the system. See Figure 6-1 for jumper location. If the problem persists, see "Troubleshooting Expansion Cards" on page 134.
Quad rank DIMM detected after single rank or dual rank DIMM in socket.	Invalid memory configuration.	Ensure that the memory modules are installed in a valid configuration. See "General Memory Module Installation Guidelines" on page 76.

<b>Message</b>	<b>Causes</b>	<b>Corrective Actions</b>
Read fault Requested sector not found.	The operating system cannot read from the hard drive or USB device, the system could not find a particular sector on the disk, or the requested sector is defective.	Replace the USB medium and device. Ensure that the USB cables and SAS backplane cables are properly connected. See "Troubleshooting a USB Device" on page 122 or "Troubleshooting a Hard Drive" on page 131 for the appropriate drive(s) installed in your system.
Sector not found. Seek error. Seek operation failed.	Faulty hard drive, USB device, or USB medium.	Replace the USB medium or device. Ensure that the USB or SAS backplane cables are properly connected. See "Troubleshooting a USB Device" on page 122 or "Troubleshooting a Hard Drive" on page 131 for the appropriate drive(s) installed in your system.
Shutdown failure.	General system error.	See "Getting Help" on page 149.
Sparing mode disabled. For sparing mode, matched sets of three must be populated across slots.	The memory configuration does not match the setting in BIOS. The BIOS setting has been disabled.	Reconfigure the memory modules for Memory Sparing mode. See "System Memory" on page 76.

<b>Message</b>	<b>Causes</b>	<b>Corrective Actions</b>
The amount of system memory has changed.	Memory has been added or removed or a memory module may be faulty.	If memory has been added or removed, this message is informative and can be ignored. If memory has not been added or removed, check the SEL to determine if single-bit or multi-bit errors were detected and replace the faulty memory module. See "Troubleshooting System Memory" on page 129.
The following DIMMs should match in geometry: <i>x, x, ...</i>  The following DIMMs should match in rank count: <i>x, x, ...</i>  The following DIMMs should match in size: <i>x, x, ...</i>  The following DIMMs should match in size and geometry: <i>x, x, ...</i>  The following DIMMs should match in size and rank count: <i>x, x, ...</i>	Invalid memory configuration. The specified memory modules do not match in size, number of ranks, or number of data lanes.	Ensure that the memory modules are installed in a valid configuration. See "General Memory Module Installation Guidelines" on page 76.




<b>Message</b>	<b>Causes</b>	<b>Corrective Actions</b>
Thermal sensor not detected on <i>x</i> .	A memory module without a thermal sensor is installed in the specified memory slot.	Replace the memory module. See "System Memory" on page 76.
Time-of-day clock stopped.	Faulty battery or faulty chip.	See "Troubleshooting the System Battery" on page 126.
Time-of-day not set - please run SETUP program.	Incorrect Time or Date settings; faulty system battery.	Check the Time and Date settings. See "Using the System Setup Program and UEFI Boot Manager" on page 39. If the problem persists, replace the system battery. See "System Battery" on page 100.
Timer chip counter 2 failed.	Faulty system board.	See "Getting Help" on page 149.
TPM configuration operation honored. System will now reset.	A TPM configuration command has been entered. The system reboots and executes the command.	Information only.
TPM configuration operation is pending. Press (I) to Ignore OR (M) to Modify to allow this change and reset the system.  WARNING: Modifying could prevent security.	This message displays during system restart after a TPM configuration command has been entered. User interaction is required to proceed.	Enter I or M to proceed.
TPM failure	A Trusted Platform Module (TPM) function has failed.	See "Getting Help" on page 149.

<b>Message</b>	<b>Causes</b>	<b>Corrective Actions</b>
Unable to launch System Services image. System halted!	System halted after F10 keystroke because System Services image is either corrupted in the system firmware or has been lost due to system board replacement. The iDRAC6 Enterprise card flash memory or BMC SPI flash may be corrupted.	Restart the system and update the Lifecycle Controller repository to the latest software to restore full functionality. See the <i>Lifecycle Controller User Guide</i> for more information.  Restore the flash memory using the latest version on <a href="http://support.dell.com">support.dell.com</a> . See the <i>Integrated Dell Remote Access Controller 6 (iDRAC6) User Guide</i> for instructions on performing a field replacement of the flash memory.
Unexpected interrupt in protected mode.	Improperly seated memory modules or faulty keyboard/mouse controller chip.	Reseat the memory modules. See "Troubleshooting System Memory" on page 129. If the problem persists, see "Getting Help" on page 149.
Unsupported CPU combination  Unsupported CPU stepping detected.	Processor(s) is not supported by the system.	Install a supported processor or processor combination. See "Processors" on page 95.
Unsupported DIMM detected. The following DIMM has been disabled: x	Invalid memory configuration. The system runs but with the specified memory module disabled.	Ensure that the memory modules are installed in a valid configuration. See "General Memory Module Installation Guidelines" on page 76.

<b>Message</b>	<b>Causes</b>	<b>Corrective Actions</b>
Unsupported memory configuration. DIMM mismatch across slots detected: <i>x, x, . . .</i>	Invalid memory configuration. Memory modules are mismatched in the specified slots.	Ensure that the memory modules are installed in a valid configuration. See "General Memory Module Installation Guidelines" on page 76.
Unused memory detected. DIMM's installed in the following slot are not available when in mirror mode: <i>x, x, x</i> .	The memory configuration is not optimal for mirroring mode. Modules in the specified slots are unused.	Reconfigure the memory for memory mirroring mode, or change the memory mode to <b>Optimized</b> or <b>Sparing</b> in the BIOS setup screen. See "System Memory" on page 76.
Unused memory detected. DIMM's installed in the following slot are not available when in 128-bit advanced ECC mode: <i>x, x, x</i> .	The memory configuration is not optimal for Advanced ECC Memory Mode. Modules in the specified slots are unused.	Reconfigure the memory for Advanced ECC Memory Mode, or change the memory mode to <b>Optimized</b> or <b>Sparing</b> in the BIOS setup screen. See "System Memory" on page 76.
Warning: A fatal error has caused system reset! Please check the system event log!	A fatal system error occurred and caused the system to reboot.	Check the SEL for information that was logged during the error. See the applicable troubleshooting section in "Troubleshooting Your System" on page 121 for any faulty components specified in the SEL.
Warning! No micro code update loaded for processor <i>n</i> .	Micro code update failed.	Update the BIOS firmware. See "Getting Help" on page 149.


<b>Message</b>	<b>Causes</b>	<b>Corrective Actions</b>
Warning! Power required exceeds PSU wattage. Check PSU and system configuration.  Warning! Performance degraded. CPU and memory set to minimum frequencies to meet PSU wattage. System will reboot.	The system configuration of processor(s), memory modules, and expansion cards may not be supported by the power supplies.	If any system components were just upgraded, return the system to the previous configuration. If the system boots without this warning, then the replaced component(s) are not supported with this power supply. If Energy Smart power supplies are installed, replace them with the High Output power supplies to use the components. See "Power Supplies" on page 74.
Warning! PSU mismatch. PSU redundancy lost. Check PSU.	A high output power supply and an Energy Smart power supply are installed in the system at the same time.	Install two high output or two Energy Smart power supplies in the system.  You can also run the system on one power supply until you can obtain two power supplies of the same type. See "Troubleshooting Power Supplies" on page 127.
Warning! Unsupported memory configuration detected. The memory configuration is not optimal. The recommended memory configuration is: <message>	Invalid memory configuration. The system runs but with reduced functionality.	Ensure that the memory modules are installed in a valid configuration. See "General Memory Module Installation Guidelines" on page 76. If the problem persists, see "Troubleshooting System Memory" on page 129.

Message	Causes	Corrective Actions
Write fault. Write fault on selected drive.	Faulty USB device, USB medium, hard drive, or hard drive subsystem.	Replace the USB medium or device. Ensure that the USB and SAS backplane cables are properly connected. See "Troubleshooting a USB Device" on page 122 and "Troubleshooting a Hard Drive" on page 131.

 **NOTE:** For the full name of an abbreviation or acronym used in this table, see the *Glossary* on [support.dell.com/manuals](http://support.dell.com/manuals).

## Warning Messages

A warning message alerts you to a possible problem and prompts you to respond before the system continues a task. For example, before you format a hard drive, a message warns you that you may lose all data on the hard drive. Warning messages usually interrupt the task and require you to respond by typing y (yes) or n (no).

 **NOTE:** Warning messages are generated by either the application or the operating system. For more information, see the documentation that accompanied the application or operating system.

## Diagnostics Messages

The system diagnostic utilities may issue messages if you run diagnostic tests on your system. See "Running the Embedded System Diagnostics" on page 140 for more information about system diagnostics.

## Alert Messages

Systems management software generates alert messages for your system. Alert messages include information, status, warning, and failure messages for drive, temperature, fan, and power conditions. For more information, see the systems management software documentation.

## Other Information You May Need



**WARNING:** See the safety and regulatory information that shipped with your system. Warranty information may be included within this document or as a separate document.

- The rack documentation included with your rack solution describes how to install your system into a rack.
- The *Getting Started Guide* provides an overview of system features, setting up your system, and technical specifications.
- Any media that ships with your system that provides documentation and tools for configuring and managing your system, including those pertaining to the operating system, system management software, system updates, and system components that you purchased with your system.



**NOTE:** Always check for updates on [support.dell.com/manuals](https://support.dell.com/manuals) and read the updates first because they often supersede information in other documents.

# Using the System Setup Program and UEFI Boot Manager


The System Setup program is the BIOS program that enables you to manage your system hardware and specify BIOS-level options. From the System Setup program, you can:

- View the system hardware configuration
- Enable or disable integrated devices
- Set performance and power management thresholds
- Manage system security

## Entering the System Setup Program

- 1 Turn on or restart your system.
- 2 Press <F2> after you see the following message:


<F2> = System Setup

 **NOTE:** The system does not respond until the USB keyboard is active.

If your operating system begins to load before you press <F2>, allow the system to finish booting, and then restart your system and try again.

## Responding to Error Messages

If an error message appears while the system is booting, make a note of the message. See "System Messages" on page 22 for an explanation of the message and suggestions for correcting errors.

 **NOTE:** After installing a memory upgrade, it is normal for your system to display a message that the system memory size has changed the first time you start your system.

## Using the System Setup Program Navigation Keys

Keys	Action
Up arrow or <Shift><Tab>	Moves to the previous field.
Down arrow or <Tab>	Moves to the next field.
<Enter>, <Spacebar>, <+>, <->, left and right arrows	Cycles through the settings in a field. In many fields, you can also type the appropriate value.
<Esc>	Exits the System Setup program and restarts the system if any changes were made.
<F1>	Displays the System Setup program's help file.




**NOTE:** For most of the options, any changes that you make are recorded but do not take effect until you restart the system.



# System Setup Options

## Main Screen

Figure 2-1. Main System Setup Program Screen




**NOTE:** The options for the System Setup program change based on the system configuration.



**NOTE:** The System Setup program defaults are listed under their respective options in the following sections, where applicable.

Option	Description
System Time	Sets the time on the system's internal clock.
System Date	Sets the date on the system's internal calendar.
Memory Settings	Displays information related to installed memory. See "Memory Settings Screen" on page 43.
Processor Settings	Displays information related to processors (speed, cache size, and so on). See "Processor Settings Screen" on page 43.

<b>Option</b>	<b>Description</b>
Boot Settings	See "Boot Settings Screen" on page 45.
Integrated Devices	See "Integrated Devices Screen" on page 45.
PCI IRQ Assignment	Displays a screen to change the IRQ assigned to each of the integrated devices on the PCI bus, and any installed expansion card that requires an IRQ.
Serial Communication (Off default)	See "Serial Communication Screen" on page 47.
Power Management	Enables you to manage power usage of the processor, fans, and memory modules with preconfigured or customized settings. See "Power Management Screen" on page 48.
System Security	Displays a screen to configure the system password and setup password features. See "System Security Screen" on page 48, "Using the System Password" on page 51, and "Using the Setup Password" on page 53 for more information.
Keyboard NumLock (On default)	Determines whether your system starts up with the NumLock mode activated on 101- or 102-key keyboards (does not apply to 84-key keyboards).
Report Keyboard Errors (Report default)	Enables or disables reporting of keyboard errors during the POST. Select <b>Report</b> for host systems that have keyboards attached. Select <b>Do Not Report</b> to suppress all error messages relating to the keyboard or keyboard controller during POST. This setting does not affect the operation of the keyboard itself if a keyboard is attached to the system.
F1/F2 Prompt on Error (Enabled default)	Enables the system to halt on errors during POST, which allows the user to observe events that may scroll by unnoticed during normal POST. Press F1 to continue or F2 to enter the System Setup program.

 **CAUTION: When setting this option to Disabled, the system does not halt if an error occurs during POST. Any critical errors is displayed and logged in the system event log.**

## Memory Settings Screen


Option	Description
System Memory Size	Displays the system memory size.
System Memory Type	Displays the system memory type.
System Memory Speed	Displays the system memory speed.
Video Memory	Displays the video memory size.
System Memory Testing ( <b>Enabled</b> default)	Specifies whether system memory tests are run at system boot. Options are <b>Enabled</b> and <b>Disabled</b> .
Memory Operating Mode	This field displays the type of memory operation if a valid memory configuration is installed. When set to <b>Optimizer Mode</b> , the memory controllers run independently of each other for improved memory performance. When set to <b>Mirror Mode</b> , memory mirroring is enabled. When set to <b>Advanced ECC Mode</b> , two controllers are joined in 128-bit mode running multi-bit advanced ECC. For information about the memory modes, see "System Memory" on page 76. <b>NOTE:</b> The <b>Spare Mode</b> option may not be present on all systems.
Node Interleaving ( <b>Disabled</b> default)	If this field is <b>Enabled</b> , memory interleaving is supported if a symmetric memory configuration is installed. If <b>Disabled</b> , the system supports Non-Uniform Memory Architecture (NUMA) (asymmetric) memory configurations. <b>NOTE:</b> The Node Interleaving field must be set to <b>Disabled</b> when using Mirror mode.

## Processor Settings Screen

Option	Description
64-bit	Specifies if the processor(s) support 64-bit extensions.
Core Speed	Displays the processor clock speed.
Bus Speed	Displays the processor bus speed.

<b>Option</b>	<b>Description</b>
Logical Processor ( <b>Enabled</b> default)	Each processor core supports up to two logical processors. If this field is set to <b>Enabled</b> , the BIOS reports both logical processors. If set to <b>Disabled</b> , only one logical processor is monitored by the BIOS.
Virtualization Technology ( <b>Disabled</b> default)	Enables or disables virtualization software to use the virtualization technology incorporated in the processor. <b>NOTE: Disable</b> this feature if your system will not be running virtualization software.
Adjacent Cache Line Prefetch ( <b>Enabled</b> default)	Enables or disables high utilization of sequential memory access. <b>NOTE: Disable</b> this option for applications that require high utilization of random memory access.
Hardware Prefetcher ( <b>Enabled</b> default)	Enables or disables the hardware prefetcher.
Execute Disable ( <b>Enabled</b> default)	Enables or disables <b>Execute Disable Memory Protection Technology</b> .
Number of Cores per Processor ( <b>All</b> default)	If set to <b>All</b> , the maximum number of cores in each processor is enabled.
Turbo Mode ( <b>Enabled</b> default)	Enables or disables <b>Turbo Mode</b> if Turbo Boost technology is supported by the processor(s).
C States ( <b>Enabled</b> default)	When set to <b>Enabled</b> , the processor(s) can operate in all available power states.
Processor 1 Family -Model-Stepping	Displays the family, model, and stepping of the selected processor.
Processor 2 Family -Model-Stepping	Displays the family, model, and stepping of the selected processor.

## Boot Settings Screen

Option	Description
Boot Mode (BIOS default)	 <b>CAUTION: Switching the boot mode could prevent the system from booting if the operating system was not installed in the same boot mode.</b>  Setting this field to <b>BIOS</b> allows compatibility with non-UEFI operating systems.
Boot Sequence	This field indicates to the system, the location of the operating system files needed for startup.
Hard-Disk Drive Sequence	Determines the order in which the BIOS attempts to boot from hard drives in the system during system startup.
USB Flash Drive Emulation Type (Auto default)	Determines the emulation type for a USB flash drive. <b>Hard disk</b> allows the USB flash drive to act as a hard drive. <b>Auto</b> automatically chooses an emulation type.
Boot Sequence Retry (Disabled default)	If this field is enabled and the system has failed to boot, the system reattempts to boot after 30 seconds.

## Integrated Devices Screen

Option	Description
Integrated SAS Controller (Enabled default)	Enables or disables the integrated storage controller.
User Accessible USB Ports (All Ports On default)	Enables or disables the user-accessible USB ports. Options are <b>All Ports On</b> , <b>Only Back Ports On</b> , and <b>All Ports Off</b> .
Internal USB Port 1 (On default)	Enables or disables the internal USB port.
Internal USB Port 2 (On default)	Enables or disables the internal USB port.
Embedded NIC1 and NIC2 (Enabled default)	Enables or disables the OS interface of the two embedded NICs. (The NICs may also be accessed through the system's management controller.)

<b>Option</b>	<b>Description</b>
Embedded Gb NICx (NIC1 default: <b>Enabled with PXE</b> ; Other NICs: <b>Enabled</b> )	Enables or disables the embedded NICs. Options are <b>Enabled</b> , <b>Enabled with PXE</b> , and <b>Enabled with iSCSI Boot</b> . PXE support allows the system to boot from the network.
MAC Address	Displays the MAC address for the NIC.
OS Watchdog Timer ( <b>Disabled</b> default)	Sets a timer to monitor the operating system for activity, and aids in recovery if the system stops responding. When <b>Enabled</b> , the operating system is allowed to initialize the timer. When <b>Disabled</b> , the timer is not initialized.  <b>NOTE:</b> This feature is usable only with operating systems that support WDAT implementations of the Advanced Configuration and Power Interface (ACPI) 3.0b specification.
I/OAT DMA Engine ( <b>Disabled</b> default)	Enables or disables the I/O acceleration technology (I/OAT). This feature should only be enabled if the hardware and software support I/OAT.
Embedded Video Controller ( <b>Enabled</b> default)	Displays the total amount of video memory available in the embedded video controller.

## **PCI IRQ Assignments Screen**

<b>Option</b>	<b>Description</b>
Embedded X-treme PCI Adapter	Use the <+> and <-> keys to manually select an <b>IRQ</b> for a given device, or select <b>Default</b> to allow the BIOS to select an <b>IRQ</b> value at system startup.

## Serial Communication Screen

Option	Description
Serial Communication (On without Console Redirection default)	<p>Selects whether the serial communication devices (Serial Device 1 and Serial Device 2) are enabled in BIOS. BIOS console redirection can also be enabled and the port address used can be specified.</p> <p>Options are <b>On without Console Redirection</b>, <b>On with Console Redirection via COM1</b>, <b>On with Console Redirection via COM2</b>, and <b>Off</b>.</p>
Serial Port Address (Serial Device 1=COM1, Serial Device 2=COM2 default)	<p>Sets the serial port addresses for the two serial devices.</p> <p><b>NOTE:</b> Only Serial Device 2 can be used for Serial Over LAN (SOL). To use console redirection by SOL, configure the same port address for console redirection and the serial device.</p>
External Serial Connector (Serial Device1 default)	<p>Specifies whether Serial Device 1, Serial Device 2, or Remote Access Device has access to the external serial connector.</p> <p><b>NOTE:</b> Only Serial Device 2 can be used for Serial Over LAN (SOL). To use console redirection by SOL, configure the same port address for console redirection and the serial device.</p>
Failsafe Baud Rate (115200 default)	<p>Displays the failsafe baud rate used for console redirection. BIOS attempts to determine the baud rate automatically. This failsafe baud rate is used only if the attempt fails. This rate should not be adjusted.</p>
Remote Terminal Type (VT100/VT220 default)	<p>Sets the remote console terminal type, either VT100/VT220 or ANSI.</p>
Redirection After Boot (Enabled default)	<p>Enables or disables BIOS console redirection when the operating system is loaded.</p>


## Power Management Screen


Option	Description
Power Management (Active Power Controller default)	<p>Options are OS Control, Active Power Controller, Custom, or Maximum Performance. For all but the Custom setting, the BIOS pre-configures the power settings on this screen as follows:</p> <ul style="list-style-type: none"><li>• OS Control sets the CPU power to OS DBPM, the fan power to Minimum Power, and the memory power to Maximum Performance. In this setting, all processor performance information is passed from the system BIOS to the operating system for control. The operating system sets the processor performance based on processor utilization.</li><li>• Active Power Controller sets the CPU power to System DBPM, the fan power to Minimum Power, and the memory power to Maximum Performance. The BIOS sets the processor performance based on processor utilization.</li><li>• Maximum Performance sets all fields to Maximum Performance.</li></ul>
CPU Power and Performance Management	Options are OS DBPM, System DBPM, Maximum Performance, or Minimum Power.
Fan Power and Performance Management	Options are Maximum Performance or Minimum Power.
Memory Power and Performance Management	Options are Maximum Performance, a specified frequency, or Minimum Power.

## System Security Screen

Option	Description
System Password	<p>Displays the current status of the password security feature and allows a new system password assignment and verification.</p> <p><b>NOTE:</b> For more information, see "Using the System Password" on page 51.</p>



Option	Description
Setup Password	<p>Restricts access to the System Setup program by using a setup password.</p> <p><b>NOTE:</b> For more information, see "Using the System Password" on page 51.</p>
Password Status (Unlocked default)	<p>When <b>Setup Password</b> is assigned and this field is <b>Locked</b>, the system password cannot be changed or disabled at system start-up.</p> <p>For more information, see "Using the System Password" on page 51.</p>
TPM Security (Off default)	<p>Sets the reporting of the Trusted Platform Module (TPM) in the system.</p> <p>If <b>Off</b>, the presence of the TPM is not reported to the operating system.</p> <p>If <b>On with Pre-boot Measurements</b>, the system reports the TPM to the operating system and stores the pre-boot measurements to the TPM during POST.</p> <p>If <b>On without Pre-boot Measurements</b>, the system reports the TPM to the operating system and bypasses pre-boot measurements.</p>
TPM Activation (No Change default)	<p>When set to <b>Activate</b>, the TPM is enabled to default settings. When set to <b>Deactivate</b>, the TPM is disabled. The <b>No Change</b> state initiates no action. The operational state of the TPM remains unchanged (all user settings for the TPM are preserved).</p> <p><b>NOTE:</b> This field is read-only when <b>TPM Security</b> is set to <b>Off</b>.</p>
TPM Clear (No default)	<p> <b>CAUTION: Clearing the TPM will lose all encryption keys in the TPM. This option prevents booting to the operating system and results in data loss if the encryption keys cannot be restored. Back up the TPM keys prior to enabling this option.</b></p> <p>When set to <b>Yes</b>, all TPM contents are cleared.</p> <p><b>NOTE:</b> This field is read-only when <b>TPM Security</b> is set to <b>Off</b>.</p>

Option	Description
Power Button (Enabled default)	<p>If <b>Enabled</b>, the power button can turn the system's power off and on. On an ACPI-compliant operating system, the system performs an orderly shutdown before power is turned off.</p> <p>When <b>Disabled</b>, the button can only turn on system power.</p>
NMI Button (Disabled default)	<p> <b>CAUTION: Use the NMI button only if directed to do so by qualified support personnel or by the operating system's documentation. Pressing this button halts the operating system and displays a diagnostic screen.</b></p> <p>Enables or disables the NMI feature.</p>
AC Power Recovery (Last default)	<p>Determines how the system reacts when power is restored. If set to <b>Last</b>, the system returns to the last power state. <b>On</b> turns on the system after power is restored. <b>Off</b> allows the system to remain off after power is restored.</p>
AC Power Recovery Delay (Immediate default)	<p>Determines when the system restarts after power is restored. Options are <b>Immediate</b> (no delay), <b>Random</b> (between 30 to 240 seconds for Integrated Dell Remote Access Controller (iDRAC), or 45 to 240 seconds for BMC), or <b>User Defined</b>.</p>
User Defined Delay	<p>Determines the user defined AC Recovery Delay.</p>

## Exit Screen

Press <Esc> to exit the System Setup program. The **Exit** screen appears:

- Save Changes and Exit
- Discard Changes and Exit
- Return to Setup

# System and Setup Password Features



**NOTE:** For a forgotten password, see "Disabling a Forgotten Password" on page 146.

Your system is shipped without the system password feature enabled in BIOS.



**CAUTION:** The password features provide a basic level of security for the data on your system. Anyone can access the data stored on your system if the system is running and unattended.

## Using the System Password

When a system password is assigned, the system prompts for the system password after the system starts and only those with the password have full use of the system.

### Assigning a System Password

Before assigning a system password, enter the System Setup program and check the **System Password** option.

When a system password is assigned, **System Password** is **Enabled**.

If **Password Status** is **Unlocked**, you can change the system password.

If **Locked**, you cannot change the system password. Disabling the password jumper on the system board sets **System Password** to **Disabled**, and you cannot change or enter a new system password.

When a system password is not assigned and the password jumper on the system board is in the enabled position, **System Password** is **Not Enabled** and **Password Status** is **Unlocked**. To assign a system password:

- 1 Verify that **Password Status** is **Unlocked**.
- 2 Highlight the **System Password** option and press <Enter>.
- 3 Type your new system password.

You can use up to 32 characters in your password.

As you type, placeholders appear in the field.

The password assignment is not case-sensitive. To erase a character, press <Backspace> or the left-arrow key.



**NOTE:** To escape from the field without assigning a system password, press <Enter> to move to another field, or press <Esc> before you complete step 5.

- 4 Press <Enter>.
- 5 To confirm your password, type it a second time and press <Enter>. **System Password** changes to **Enabled**. Exit the System Setup program and begin using your system.
- 6 Either reboot the system now for the password protection to take effect or continue working.



**NOTE:** Password protection does not take effect until the system reboots.

### Using Your System Password to Secure Your System



**NOTE:** If you have assigned a setup password (see "Using the Setup Password" on page 53), the system accepts your setup password as an alternate system password.

When **Password Status** is **Unlocked**, you have the option to leave the password security enabled or to disable password security.

To leave the password security enabled:

- 1 Turn on or reboot your system by pressing <Ctrl> <Alt> <Del>.
- 2 Type your password and press <Enter>.

To disable the password security:

- 1 Turn on or reboot your system by pressing <Ctrl> <Alt> <Del>.
- 2 Type your password and press <Ctrl> <Enter>.

When **Password Status** is **Locked**, you must type the password and press <Enter> when prompted at reboot.

If an incorrect system password is entered, the system displays a message and prompts you to re-enter your password. You have three attempts to enter the correct password. After the third unsuccessful attempt, the system displays an error message that the system has halted and must be shut down manually using the power button.

Even after you shut down and restart the system, the error message continues to be displayed until the correct password is entered.



**NOTE:** You can use the **Password Status** option in conjunction with the **System Password** and **Setup Password** options to protect your system from unauthorized changes.

## Disabling the System Password

If the system password is already set, you can disable it by typing the password during POST and pressing <Ctrl><Enter> or you can enter the system setup and press <Enter> twice when you are in the system password menu.

## Changing an Existing System Password

- 1 Enter the System Setup program by pressing <F2> during POST.
- 2 Select the System Security screen.
- 3 Verify that the **Password Status** is **Unlocked**.
- 4 Type the new system password in the two password fields.  
The **System Password** field changes to **Not Enabled** if the password was deleted.

## Using the Setup Password

### Assigning a Setup Password

You can assign a setup password only when the **Setup Password** is **Not Enabled**. To assign a setup password, highlight the **Setup Password** option and press the <+> or <-> key. The system prompts you to enter and verify the password.



**NOTE:** The setup password can be the same as the system password. If the two passwords are different, the setup password can be used as an alternate system password. The system password cannot be used in place of the setup password.

You can use up to 32 characters in your password.

As you type, placeholders appear in the field.

The password assignment is not case-sensitive. To erase a character, press <Backspace> or the left-arrow key.

When you verify the password, the **Setup Password** changes to **Enabled**.

The next time you enter the System Setup program, the system prompts you for the setup password.

A change to the **Setup Password** option becomes effective immediately (restarting the system is not required).

## Operating With a Setup Password Enabled

If **Setup Password** is **Enabled**, you must enter the correct setup password before modifying most of the System Setup options.

If you do not enter the correct password in three attempts, the system lets you view, but not modify, the System Setup screens. The following options are exceptions: If **System Password** is not **Enabled** and is not locked through the **Password Status** option, you can assign a system password. You cannot disable or change an existing system password.



**NOTE:** You can use the **Password Status** option in conjunction with the **Setup Password** option to protect the system password from unauthorized changes.

## Deleting or Changing an Existing Setup Password

- 1 Enter the System Setup program and select the **System Security**.
- 2 Highlight **Setup Password**, press <Enter> to access the setup password window. Press <Enter> twice to clear the existing setup password.  
The setting changes to **Not Enabled**.
- 3 If you want to assign a new setup password, perform the steps in "Assigning a Setup Password" on page 53.

## Embedded System Management

The Lifecycle Controller is an embedded utility that enables systems management tasks from an embedded environment throughout the server's lifecycle.

The controller can be started during the boot sequence and can function independently of the operating system.



**NOTE:** Certain platform configurations may not support the full set of features provided by the controller.

On systems with Baseboard Management Controller (BMC), the Lifecycle Controller supports running diagnostics to validate the memory, I/O devices, processors, physical disks, and other peripherals.\



**NOTE:** The Baseboard Management Controller (BMC) utility is replaced by the iDRAC6 utility.

The iDRAC6 Express provides the following additional features in a remote environment:

- Downloading and applying firmware updates
- Configuring hardware and firmware

For more information about setting up the controller and configuring hardware and firmware, see the *Lifecycle Controller User Guide* at [support.dell.com/manuals](http://support.dell.com/manuals).



**NOTE:** To reinstall and deploy the operating system, use the Recovery Manager solution available for download at [support.dell.com](http://support.dell.com).

## Baseboard Management Controller Configuration



**NOTE:** The Baseboard Management Controller (BMC) utility is replaced by the iDRAC6 utility.

The BMC enables configuring, monitoring, and recovery of systems remotely. BMC provides the following features:

- Uses the system's integrated NIC
- Enables fault logging and SNMP alerting
- Provides access to system event log and sensor status
- Allows control of system functions including power on and off
- Functions independently of the system's power state or the system's operating system
- Provides text console redirection for system setup, text-based utilities, and operating system consoles



**NOTE:** To remotely access the BMC through the integrated NIC, you must connect the network connection to integrated NIC1.

For additional information on using BMC, see the documentation for the BMC and systems management applications.

## Entering the BMC Setup Module

- 1 Turn on or restart your system.
- 2 Press <Ctrl><E> when prompted after POST.  
If your operating system begins to load before you press <Ctrl><E>, allow the system to finish booting, and then restart your system and try again.

## iDRAC Configuration Utility

The iDRAC Configuration Utility is a pre-boot configuration environment that allows you to view and set parameters for the iDRAC6 and for the managed server. The iDRAC Configuration Utility enables you to:

- Configure, enable, or disable the iDRAC6 local area network (LAN) through the dedicated iDRAC6 Enterprise card port or the embedded NICs.
- Enable or disable IPMI over LAN.
- Enable a LAN Platform Event Trap (PET) destination.
- Attach or detach the Virtual Media devices.
- Change the administrative username and password and manage user privileges.
- View System Event Log (SEL) messages or clear messages from the log.

For additional information on using iDRAC6, see the documentation for iDRAC6 and systems management applications.

## Entering the iDRAC Configuration Utility

- 1 Turn on or restart your system.
- 2 Press <Ctrl><E> when prompted during POST.  
If your operating system begins to load before you press <Ctrl><E>, allow the system to finish booting, restart your system and try again.



# Installing System Components

## Recommended Tools


- Key to the system keylock
- #1 and #2 Phillips screwdrivers
- T10 Torx screwdriver
- Wrist grounding strap

## Inside the System



**CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

**Figure 3-1. Inside the System**




- |   |                      |    |                          |
|---|----------------------|----|--------------------------|
| 1 | cooling fan          | 2  | internal hard drives (2) |
| 3 | expansion-card riser | 4  | power supply bays (2)    |
| 5 | cooling shroud       | 6  | heat sink/processor (2)  |
| 7 | memory modules (8)   | 8  | system cooling fans (4)  |
| 9 | SAS backplane        | 10 | hard drives (12)         |

# Front Bezel

## Removing the Front Bezel

- 1 Using the system key, unlock the bezel.
- 2 Lift the release latch next to the key lock.
- 3 Rotate the left end of the bezel away from the front panel.
- 4 Unhook the right end of the bezel and pull the bezel away from the system.

**Figure 3-2. Removing and Installing the Front Bezel**



- 1 release latch
- 3 bezel

- 2 keylock
- 4 hinge tab

## Installing the Front Bezel

- 1 Hook the right end of the bezel onto the chassis.
- 2 Fit the free end of the bezel onto the system.
- 3 Secure the bezel with the keylock. See Figure 3-2.

## Opening and Closing the System



**WARNING:** Whenever you need to lift the system, get others to assist you. To avoid injury, do not attempt to lift the system by yourself.




**CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

### Opening the System

- 1 Turn off the system and attached peripherals, and disconnect the system from the electrical outlet and peripherals.
- 2 Rotate the latch release lock on the system cover counter clockwise to the unlocked position. See Figure 3-3.
- 3 Lift the latch on top of the system and slide the cover back.
- 4 Grasp the cover on both sides and lift the cover away from the system. See Figure 3-3.

**Figure 3-3. Opening and Closing the System**



1 system cover latch

2 latch release lock

### **Closing the System**

- 1 Lift the latch on the system cover.
- 2 Place the cover onto the chassis and offset it slightly back so that the two hooks on the back edge of the cover fit the corresponding tabs on the back edge of the chassis. See Figure 3-3.
- 3 Slide the cover towards the front of the chassis and press down the latch.
- 4 Rotate the latch release lock in the clockwise direction to secure the cover.
- 5 Reconnect the system and peripherals to their electrical outlets, and turn on the system.

# Cooling Shroud


A cooling shroud directs airflow from the cooling fans over the system processor(s) and memory module(s).

## Removing the Cooling Shroud


**△ CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

- 1 Open the system. See "Opening the System" on page 60.
- 2 Grasp and gently lift the shroud up and away from the system board. See Figure 3-4.

**Figure 3-4. Removing and Installing the Cooling Shroud**



## Installing the Cooling Shroud


 **CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

- 1 Align the shroud using the center of the numbered fan bays as a guide.
- 2 Press the cooling shroud down into the chassis.
- 3 Close the system. See "Closing the System" on page 61.
- 4 Reconnect the system to its electrical outlet and turn the system on, including any attached peripherals.

## Hard Drives


Your system supports up to twelve 3.5" SAS hard drives in 3.5" hot-swap hard drive carriers. The hard drives are front-mounted and connected to a SAS backplane through hard-drive carriers. See Figure 3-1.

### Removing a Hard-Drive Blank

 **CAUTION:** To maintain proper system cooling, all empty hard-drive bays must have drive blanks installed.

- 1 If applicable, remove the front bezel. See "Removing the Front Bezel" on page 59.
- 2 Grasp the front of the hard-drive blank, press the release lever on the right side, and slide the blank out until it is free of the drive bay. See Figure 3-5.

**Figure 3-5. Removing or Installing a Hard-Drive Blank**



1 hard-drive blank

2 release lever

### **Installing a Hard-Drive Blank**

Align the hard-drive blank with the drive bay and insert the blank into the drive bay until the release lever clicks into place. See Figure 3-5.

### **Removing a Hot-Swap Hard Drive**

- 1 If applicable, remove the front bezel. See "Removing the Front Bezel" on page 59.
- 2 Using the RAID management software, prepare the drive for removal. Wait until the hard-drive indicators on the drive carrier signal that the drive can be removed safely. See "Hard-Drive Indicator Patterns" on page 14.

If the drive has been online, the green activity/fault indicator flashes as the drive is powered down. When the drive indicators are off, the drive is ready for removal.


- 3 Press the release button and open the drive carrier release handle to release the drive. See Figure 3-6.
- 4 Slide the hard drive out of the drive bay.

**CAUTION:** To maintain proper system cooling, all empty hard-drive bays must have hard-drive blanks installed.

- 5 Insert a drive blank in the vacated drive bay. See "Installing a Hard-Drive Blank" on page 64.



**Figure 3-6. Removing and Installing a Hot-Swap Hard Drive**



1 release button

2 hard-drive carrier handle

## Installing a Hot-Swap Hard Drive

**CAUTION:** Use only hard drives that have been tested and approved for use with the SAS backplane.

**CAUTION:** When installing a hard drive, ensure that the adjacent drives are fully installed. Inserting a hard-drive carrier and attempting to lock its handle next to a partially installed carrier can damage the partially installed carrier's shield spring and make it unusable.

**CAUTION:** To prevent data loss, ensure that your operating system supports hot-swap drive installation. See the documentation supplied with the operating system.


- 1 If applicable, remove the front bezel. See "Removing the Front Bezel" on page 59.
- 2 If present, remove the drive blank. See "Removing a Hard-Drive Blank" on page 63.
- 3 Press the button on the front of the drive carrier.

- 4 With the lever on the hard drive carrier open, slide the hard drive into the drive bay until the carrier contacts the backplane. See Figure 3-6.
- 5 Close the handle to lock the drive in place.

### Removing a Hard Drive From a Hard-Drive Carrier

Remove the screws from the slide rails on the hard-drive carrier and separate the hard drive from the carrier. See Figure 3-7.

**Figure 3-7. Installing a Hot-Swap Hard Drive Into a Hard-Drive Carrier**



- |   |               |   |               |
|---|---------------|---|---------------|
| 1 | hard drive    | 2 | SAS indicator |
| 3 | drive carrier | 4 | screws (4)    |

## Installing a Hard Drive Into a Hard-Drive Carrier

- 1 Insert the hard drive into the hard-drive carrier with the connector end of the drive at the back. See Figure 3-7.
- 2 Align the holes on the hard drive with the holes on the hard-drive carrier. When aligned correctly, the back of the hard drive will be flush with the back of the hard-drive carrier.
- 3 Attach the four screws to secure the hard drive to the hard-drive carrier.

## Internal Hard Drives

Your system supports two cabled 2.5" SAS internal hard drives. Internal hard drives are connected to the SAS backplane. The operating system is installed on the internal hard drives in a RAID 1 configuration. For information on RAID configuration, see the RAID documentation at [support.dell.com/manuals](http://support.dell.com/manuals).


## Removing an Internal Hard Drive Bay



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Turn off the system and attached peripherals, and disconnect the system from the electrical outlet and from the peripherals.
- 2 Open the system. See "Opening the System" on page 60.
- 3 Lift the latch on your internal hard-drive bay and lift it out of the system. See Figure 3-8.

**Figure 3-8. Removing and Installing an Internal Hard-Drive Bay**



- 1 internal hard drives (2)
- 3 internal hard-drive bay

- 2 release latch
- 4 support bracket

## Installing an Internal Hard-Drive Bay




**CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

- 1 Turn off the system and attached peripherals, and disconnect the system from the electrical outlet and from the peripherals.
- 2 Open the system. See "Opening the System" on page 60.
- 3 Lift the latch on your internal hard-drive bay and align the bay on the support bracket.
- 4 Rotate the latch to lock.

## Removing an Internal Hard Drive From the Internal Hard-Drive Bay

Remove the screws on the sides of the internal hard-drive bay and slide out the hard drive. See Figure 3-9.

**Figure 3-9. Removing and Installing an Internal Hard Drive From the Internal Hard-Drive Bay**



- |   |                         |   |                     |
|---|-------------------------|---|---------------------|
| 1 | internal hard drive bay | 2 | release latch       |
| 3 | screws (4) *            | 4 | internal hard drive |

\*Screws are supplied along with the hard drives ordered from Dell.

### **Installing a Hard Drive Into a Hard-Drive Bay**

- 1 Insert the hard drive into the internal hard-drive bay with the connector end of the drive at the back, until it is flush with the back of the hard-drive bay. See Figure 3-9.
- 2 Attach the four screws to secure the hard drive to the hard-drive bracket.

## Cooling Fans

Your system contains four dual-motor cooling fans. These provide cooling for the processor, PCI cards, and memory modules. Your system also contains one single-motor fan to provide cooling for the power supplies.



**NOTE:** Hot-swap removal or installation of the cooling fans is not supported.



**NOTE:** In the event of a problem with a particular fan, the fan number is referenced by the system's management software, allowing you to easily identify and replace the proper fan by noting the fan numbers on the fan assembly.

### Removing a Cooling Fan



**WARNING:** The cooling fan can continue to spin for some time after the system has been powered down. Allow time for the fan to stop spinning before removing it from the system.



**WARNING:** Do not attempt to operate the system without the cooling fans.



**CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

- 1 Turn off the system, including any attached peripherals, and disconnect the system from its electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 If applicable, remove the cooling shroud. See "Removing the Cooling Shroud" on page 62.
- 4 Disconnect the fan's power cable from the system board. See Figure 3-10.




**NOTE:** To remove fans 3 and 4, remove the storage controller card first. See "Removing the Storage Controller Card" on page 87.



**NOTE:** To remove fan 5, remove the internal hard drive bay and carrier. See "Removing an Internal Hard Drive Bay" on page 67.

- 5 Press the release tab while grasping the ends of the fan and lift the fan straight up from the fan bracket. See Figure 3-10.

**Figure 3-10. Removing and Installing a Fan**



1 fans (5)

2 release tab

3 fan power cable



## Installing a Cooling Fan



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1** Align the fan module so that the side with the power cable faces toward the back of the system.
- 2** Slide the fan module into the fan assembly until the fan is fully seated. See Figure 3-10.
- 3** Connect the fan's power cable to the power connector on the system board.
- 4** Replace the internal hard-drive carrier and bay. See "Installing an Internal Hard-Drive Bay" on page 69.
- 5** Route the power cable through the guides on the chassis.
- 6** Replace the cooling shroud. See "Installing the Cooling Shroud" on page 63.
- 7** Close the system. See "Closing the System" on page 61.
- 8** Reconnect the system to its electrical outlet and turn the system on, including any attached peripherals.

# Power Supplies

Your system supports two 750 W redundant power supply modules.



**NOTE:** The maximum output power (shown in Watts) is listed on the power supply label.

Two power supplies are installed and the second power supply provides hot-swappable, power redundancy. In redundant mode, the system distributes the power load across both power supplies to maximize efficiency. When a power supply is removed with the system powered on, the full power load is picked up by the remaining power supply.



**NOTE:** The system needs to run on both power supplies always, except when you replace a power supply module.

## Removing a Power Supply



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**



**CAUTION: The system requires one power supply to operate the system normally. Remove and replace only one power supply at a time in a system that is powered on.**


- 1 Disconnect the power cable from the power source.
- 2 Disconnect the power cable from the power supply and remove the system cables from the Velcro straps.



**NOTE:** You may have to unlatch and lift the optional cable management arm if it interferes with power-supply removal. For information about the cable management arm, see the system's rack documentation.

- 3 Press the lever release latch and slide the power supply out of the chassis. See Figure 3-11.


**Figure 3-11. Removing and Installing a Power Supply**



- |   |              |   |                     |
|---|--------------|---|---------------------|
| 1 | power supply | 2 | power supply handle |
| 3 | velcro strap | 4 | release latch       |


### Installing a Power Supply

- 1 Verify that both power supplies are of the same type and have the same maximum output power.
- 2 Slide the new power supply into the chassis until the power supply is fully seated and the release latch snaps into place. See Figure 3-11.

 **NOTE:** If you unlatched the cable management arm in step 2 of the previous procedure, relatch it. For information about the cable management arm, see the system's rack documentation.

- 3 Connect the power cable to the power supply and plug the cable into a power outlet.

 **CAUTION:** When connecting the power cable, secure the cable with the Velcro strap.

 **NOTE:** When installing, hot-swapping, or hot-adding a new power supply in a system with two power supplies, allow several seconds for the system to recognize the power supply and determine its status. The power-supply status indicator turns green to signify that the power supply is functioning properly (see Figure 1-5).

## System Memory

Your system supports up to eight dual-rank registered DIMMs (RDIMMs) of 1067 MHz or 1333 MHz.

The system contains eight memory sockets split into two sets of four sockets, one set per processor. Each four-socket set is organized into three channels. Two DIMMs for channel 0 and a single DIMM for channel 1 and 2. The first socket of each channel is marked with white release levers.

Dual-rank RDIMMs of size 4 GB are supported for a total of 32 GB.

### General Memory Module Installation Guidelines

To ensure optimal performance of your system, observe the following general guidelines when configuring your system memory.



**NOTE:** Memory configurations that fail to observe these guidelines can prevent your system from starting and producing any video output.

- RDIMMs and UDIMMs cannot be mixed.
- Except for memory channels that are unused, all populated memory channels must have identical configurations.
- The memory configuration for each processor must be identical.
- Memory modules of different sizes can be mixed in A1-A4 or B1-B4 (for example, 2 GB and 4 GB), but all populated channels must have identical configurations.
- For Optimizer Mode, memory modules are installed in the numeric order of the sockets beginning with A1 or B1.
- For Memory Mirroring or Advanced ECC Mode, the channel furthest from the processor is unused and memory modules are installed beginning with channel A1 or B1 and proceeding with channel A2 or B2.
- Advanced ECC Mode requires memory modules that use x4 or x8 DRAM device widths.

- The memory speed of each channel depends on the memory configuration:
  - For single or dual-rank memory modules:
    - One memory module per channel supports up to 1333 MHz.
    - Two memory modules per channel supports up to 1067 MHz.
  - For quad-rank memory modules:
    - One memory module per channel supports up to 1067 MHz.
    - Two memory modules per channel are limited to 800 MHz, regardless of memory module speed.
- If quad-rank memory modules are mixed with single- or dual-rank modules, the quad-rank modules must be installed in the sockets with the white release levers.
- If memory modules with different speeds are installed, they operate at the speed of the slowest installed memory module(s).

## Mode-Specific Guidelines

Three memory channels are allocated to each processor. The number of channels used and the allowable configurations depend on the memory mode selected.

### Advanced ECC (Lockstep) Mode Support

In this configuration, the two channels closest to the processor are combined to form one 128-bit channel. This mode supports Single Device Data Correction (SDDC) for both x4- and x8-based memory modules. Memory modules must be identical in size, speed, and technology in corresponding slots.

### Memory Mirroring Support

The system supports memory mirroring if identical memory modules are installed in the two channels closest to the processor (memory should not be installed in the farthest channel). Mirroring must be enabled in the System Setup program. In a mirrored configuration, the total available system memory is one-half of the total installed physical memory.

### Optimizer (Independent Channel) Mode

In this mode, all three channels are populated with identical memory modules. This mode permits a larger total memory capacity but does not support SDDC with x8-based memory modules.


A minimal single-channel configuration of one 1 GB memory module per processor is also supported in this mode.


Table 3-1 shows a sample memory configuration that follows the appropriate memory guidelines stated in this section.

**Table 3-1. RDIMM Dual-Rank Memory Configuration (Per Processor)**

Memory Mode	Memory Module Size	Memory Sockets				Single Processor		Dual Processor	
		4	1	2	3	Physical Memory (GB)	Available Memory (GB)	Physical Memory (GB)	Available Memory (GB)
Optimizer	4 GB	X	X	X	X	16	all	32	all

### Removing Memory Modules

 **WARNING:** The memory modules are hot to the touch for some time after the system has been powered down. Allow time for the memory modules to cool before handling them. Handle the memory modules by the card edges and avoid touching the components on the memory module.

 **CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

- 1 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 Remove the cooling shroud. See "Removing the Cooling Shroud" on page 62.
- 4 Locate the memory module sockets. See Figure 6-1.

- 5 Press down and out on the ejectors on each end of the socket until the memory module pops out of the socket. See Figure 3-12.  
Handle each memory module only on either card edge, making sure not to touch the middle of the memory module.
- 6 Replace the cooling shroud. See "Installing the Cooling Shroud" on page 63.
- 7 Close the system. See "Closing the System" on page 61.
- 8 Reconnect the system and peripherals to their power sources, and turn them on.

## Installing Memory Modules




**WARNING:** The memory modules are hot to the touch for some time after the system has been powered down. Allow time for the memory modules to cool before handling them. Handle the memory modules by the card edges and avoid touching the components on the memory module.



**CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

- 1 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 Remove the cooling shroud. See "Removing the Cooling Shroud" on page 62.
- 4 Locate the memory module sockets. See Figure 6-1.
- 5 Press the ejectors on the memory module socket down and out to allow the memory module to be inserted into the socket. See Figure 3-12.
- 6 Handle each memory module only on either card edge, making sure not to touch the middle of the memory module.

**Figure 3-12. Removing and Installing a Memory Module**



- 1 memory module
- 2 memory module socket ejectors (2)
- 3 alignment key

**7** Align the memory module's edge connector with the alignment key of the memory module socket, and insert the memory module in the socket.

**NOTE:** The memory module socket has an alignment key that allows you to install the memory module in the socket in only one way.

**8** Press down on the memory module with your thumbs to lock the memory module into the socket.

When the memory module is properly seated in the socket, the ejectors on the memory module socket snap in place.

**9** Repeat step 5 through step 8 of this procedure to install the remaining memory modules.

**10** Replace the cooling shroud. See "Installing the Cooling Shroud" on page 63.

**11** Close the system. See "Closing the System" on page 61.

**12** Start up the system, press <F2> to enter the System Setup program, and check the **System Memory** settings on the main System Setup screen.




The system should have already changed the value to reflect the newly installed memory.

- 13 If the value is incorrect, one or more of the memory modules may not be installed properly. Repeat step 2 through step 12 of this procedure, to ensure that the memory modules are firmly seated in their sockets.
- 14 Run the system memory test in the system diagnostics. See "Running the Embedded System Diagnostics" on page 140.

## Expansion Cards and Expansion-Card Risers


Your system supports up to four PCI Express (PCIe) expansion cards installed in connectors on an expansion-card riser.

Your system has an expansion-card riser 1 that provides three x4 Gen2 PCIe expansion-card slots and one x8 Gen2 PCIe expansion-card slot.

 **CAUTION: Expansion cards can only be installed in the slots on the expansion-card riser. Do not attempt to install expansion cards directly into the riser connector on the system board.**

### Expansion Card Installation Guidelines

- The expansion-card slots support full-height, half-length cards.
- The expansion-card slots are hot-swappable.
- PCI Express Generation 2 expansion cards are supported in all the slots.
- All the slots are x8 connectors.

 **CAUTION: To ensure proper cooling, only one of the two expansion cards can have a power consumption of greater than 15 W (up to 25 W maximum), not including the integrated storage controller.**

- Table 3-2 provides a guide for installing expansion cards to ensure proper cooling and mechanical fit. The expansion cards with the highest priority should be installed first using the slot priority indicated. All other expansion cards should be installed in card priority and slot priority order.


**Table 3-2. Expansion-Card Installation Priority for Riser 1**

<b>Card Priority</b>	<b>Card Type</b>	<b>Slot Priority</b>	<b>Max Allowed</b>	<b>25 W Card</b>
1	PERC H800	3	1	Y
2	8 GB NVRAM card	2	1	Y
3	10 GB NIC	1	1	Y
4	All other NICs	1	1	N

### Removing an Expansion Card



**CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

- 1 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 Remove the cooling shroud. See "Removing the Cooling Shroud" on page 62.
- 4 Disconnect all cables from the card.
- 5 Open the expansion-card latch. See Figure 3-14.
- 6 Grasp the expansion card by its edges, and carefully remove it from the expansion-card connector.
- 7 If you are removing the card permanently, install a metal filler bracket over the empty expansion slot opening and close the expansion-card latch.
  -  **NOTE:** You must install a filler bracket over an empty expansion slot to maintain Federal Communications Commission (FCC) certification of the system. The brackets also keep dust and dirt out of the system and aid in proper cooling and airflow inside the system.
- 8 Close the system. See "Closing the System" on page 61.
- 9 Reconnect the system to its electrical outlet and turn the system on, including any attached peripherals.


## Removing an Expansion-Card Riser



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 Remove the cooling shroud. See "Removing the Cooling Shroud" on page 62.
- 4 If installed, remove the expansion card from the expansion-card slot. See "Removing an Expansion Card" on page 82.
- 5 If installed, remove the storage controller card. See "Removing the Storage Controller Card" on page 87.
- 6 Disconnect the cables connected to the riser card.
- 7 To remove the expansion-card riser, simultaneously press both the blue tabs on the expansion-card riser and lift it from the chassis. See Figure 3-13.

**Figure 3-13. Removing and Installing an Expansion-Card Riser**



- |   |                                    |   |                                |
|---|------------------------------------|---|--------------------------------|
| 1 | integrated storage controller slot | 2 | riser guides (2)               |
| 3 | expansion-card riser               | 4 | expansion card slot            |
| 5 | riser guide posts (2)              | 6 | expansion-card riser slots (2) |

## Installing an Expansion Card

**CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

- 1 Unpack the expansion card and prepare it for installation.  
For instructions, see the documentation accompanying the card.
- 2 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.


- 3 Open the system. See "Opening the System" on page 60.
- 4 Remove the cooling shroud. See "Removing the Cooling Shroud" on page 62.
- 5 Open the expansion-card latch and remove the filler bracket. See Figure 3-14.



**NOTE:** Keep this bracket in case you need to remove the expansion card. Filler brackets must be installed over empty expansion-card slots to maintain FCC certification of the system. The brackets also keep dust and dirt out of the system and aid in proper cooling and airflow inside the system.

- 6 Holding the card by its edges, position the card so that the card-edge connector aligns with the expansion-card connector on the expansion-card riser.
- 7 Insert the card-edge connector firmly into the expansion-card connector until the card is fully seated.
- 8 Close the expansion-card latch. See Figure 3-14.

**Figure 3-14. Removing and Installing an Expansion Card**



- 1 expansion-card riser
- 3 expansion card

- 2 expansion-card latch

- 9 Connect any cables to the expansion card.
- 10 Close the system. See "Closing the System" on page 61.
- 11 Reconnect the system to its electrical outlet and turn the system on, including any attached peripherals.

## Installing an Expansion-Card Riser



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 To install an expansion-card riser, align the riser guides with the riser guide posts on the system board. See Figure 3-13.
- 2 Lower the expansion-card riser into place until the expansion-card riser connector is fully seated.
- 3 If applicable, reinstall the expansion card. See "Installing an Expansion Card" on page 84.
- 4 Reinstall the storage controller card. See "Installing the Storage Controller Card" on page 89.
- 5 Reconnect all cables.
- 6 Close the system. See "Closing the System" on page 61.
- 7 Reconnect the system and peripherals to their power sources.

## Integrated Storage Controller Card

Your system includes a dedicated expansion-card slot on the riser for an integrated RAID controller card that provides the integrated storage subsystem for your system's hard drives. The controller supports SAS hard drives and also enables you to set up the hard drives in RAID configurations as supported by the version of the storage controller included with your system.


## Removing the Storage Controller Card



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 If installed, remove the expansion card. See "Removing an Expansion Card" on page 82.
- 4 Disconnect the SAS cables connected to the card.
- 5 Disconnect the cable connecting the card to the expansion-card riser.
- 6 For a battery-cached RAID controller, disconnect the cable connecting the card to the RAID battery.
- 7 Bend both the card-edge guides outward and pull the storage controller card out of the connector.

**Figure 3-15. Installing and Removing the Storage Controller Card**



- 1 storage connector
- 3 storage controller card
- 5 SAS data cable connector

- 2 expansion-card riser
- 4 storage controller card cable
- 6 release lever (blue)



## Installing the Storage Controller Card



**CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

- 1 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 If installed, remove the expansion card. See "Removing an Expansion Card" on page 82.
- 4 Route the cables in the cable path under the storage controller card slot on the expansion card riser.
- 5 With the storage controller card edge facing the riser, insert one side of the card into the black card-edge guide.



**NOTE:** For expansion-card riser 1, the installation sequence must be slot 3, 2, 1, and 4. The storage controller card must be installed in Slot 4 after the other expansion cards have been installed.

- 6 Bend outward on the blue card-edge guide, lower the card onto the blue card-edge guide, and release the guide. See Figure 3-15.
- 7 Slide the storage controller's card edge connector into the card slot on the riser until the card is fully seated.
- 8 Connect the two SAS data cable connectors, CNTRL 0 and CNTRL 1, to the storage controller card. See Figure 3-15.



**NOTE:** Ensure to connect the cables according to the connector labels on the cable. The cable does not function properly if reversed.

- 9 For a battery-cached RAID controller, connect the RAID battery cable to the controller card.

- 10 Replace the expansion card. See "Installing an Expansion Card" on page 84.
- 11 Close the system. See "Closing the System" on page 61.
- 12 Reconnect the system to its electrical outlet and turn the system on, including any attached peripherals.

## iDRAC6 Express Card

### Removing an iDRAC6 Express Card



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 Pull back slightly on the retention standoff tab at the front edge of the card and gently lift the card off the retention standoff. See Figure 3-16.

As the holder releases from the standoff, the connector under the card disengages from the system board connector.

- 4 Angle the card so that the notch on the card slips through the clip on the system board.
- 5 Replace the expansion cards. See "Installing an Expansion Card" on page 84.
- 6 Close the system. See "Closing the System" on page 61.
- 7 Reconnect the system and peripherals to their power sources, and turn them on.


## Installing an iDRAC6 Express Card



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 If installed, remove all expansion cards from expansion-card riser. "Removing an Expansion Card" on page 82.
- 4 Insert the notch on the Integrated Dell Remote Access Controller 6 (iDRAC6) Express card into the clip on the system board.
- 5 Align the front edge of the card with the connector on the system board. See Figure 6-1 for the location of the connector.
- 6 Press the card down until it is fully seated. See Figure 3-16.  
When the front of the card is fully seated, the plastic standoff tab snaps over the edge of the holder.

**Figure 3-16. Removing and Installing an iDRAC6 Express Card**



- |   |                     |   |                      |
|---|---------------------|---|----------------------|
| 1 | iDRAC6 Express card | 2 | plastic standoff tab |
| 3 | notch               | 4 | clip                 |

- 7** Reinstall all expansion cards in the expansion-card riser. See "Installing an Expansion Card" on page 84.
- 8** Close the system. See "Closing the System" on page 61.
- 9** Reconnect the system and peripherals to their power sources, and turn them on.

# iDRAC6 Enterprise Card

## Removing an iDRAC6 Enterprise Card



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 2 If present, disconnect the Ethernet cable from the iDRAC6 enterprise card connector on the system back panel. See Figure 1-3.
- 3 Open the system. See "Opening the System" on page 60.
- 4 Remove the cooling shroud. See "Removing the Cooling Shroud" on page 62.
- 5 Pull back slightly on the two tabs at the front edge of the card and gently lift the front edge of the card off of the retention standoffs.  
As the card releases from the standoffs, the connector under the card disengages from the system board connector.
- 6 Slide the card away from the back of the system until the RJ-45 connector is clear of the back panel, then lift the card out of the system.
- 7 Replace the plastic filler plug over the port at the system back panel. See "Back-Panel Features and Indicators" on page 15 for the location of the port.
- 8 Replace the cooling shroud. See "Installing the Cooling Shroud" on page 63.
- 9 Close the system. See "Closing the System" on page 61.
- 10 Reconnect the system and peripherals to their power sources, and turn them on.

## Installing an iDRAC6 Enterprise Card




**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 Remove the cooling shroud. See "Removing the Cooling Shroud" on page 62.
- 4 Remove the plastic filler plug of the iDRAC6 Enterprise port from the system back panel.
- 5 Angle the card so that the RJ-45 connector fits through the back-panel opening. See Figure 3-17.
- 6 Align the front edge of the card with the two front plastic retention standoffs next to the iDRAC6 connector on the system board, and lower the card into place. See Figure 3-17.

When the front of the card is fully seated, the plastic standoffs snap over the edge of the card.

**Figure 3-17. Removing and Installing an iDRAC6 Enterprise Card**



- |   |                             |   |                                  |
|---|-----------------------------|---|----------------------------------|
| 1 | VFlash SD card              | 2 | VFlash media slot                |
| 3 | iDRAC6 Enterprise card      | 4 | retention standoff posts (2)     |
| 5 | retention standoff tabs (2) | 6 | iDRAC6 Enterprise card connector |

- 7 Close the system. See "Closing the System" on page 61.
- 8 Reconnect the system and peripherals to their power sources, and turn them on.

## Processors

### Removing a Processor



**CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service

**and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Prior to upgrading your system, download the latest system BIOS version from [support.dell.com](http://support.dell.com).
- 2 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 3 Open the system. See "Opening the System" on page 60.
- 4 Remove the cooling shroud. See "Removing the Cooling Shroud" on page 62.



**WARNING: The heat sink and processor are hot to touch for some time after the system has been powered down. Allow the heat sink and processor to cool before handling them.**



**CAUTION: Never remove the heat sink from a processor unless you intend to remove the processor. The heat sink is necessary to maintain proper thermal conditions.**

- 5 Using a #2 Phillips screwdriver, loosen one of the heat-sink retention screws. See Figure 3-18.
- 6 Wait 30 seconds for the heat sink to loosen from the processor.
- 7 Loosen the other three heat-sink retention screws.
- 8 Gently lift the heat sink off of the processor and set the heat sink aside with thermal grease side facing up.




**CAUTION: The processor is held in its socket under strong pressure. Be aware that the release lever can spring up suddenly if not firmly grasped.**

- 9 Position your thumb firmly over the processor socket-release lever and release the lever from the locked position. Rotate the lever 90 degrees upward until the processor is released from the socket. See Figure 3-19.



**Figure 3-18. Installing and Removing the Heat Sink**



1 heat sink

2 retention screws (4)


**10** Rotate the processor shield upward and out of the way. See Figure 3-19.

**11** Lift the processor out of the socket and leave the release lever so that the socket is ready for the new processor.

**⚠ CAUTION:** Be careful not to bend any of the pins on the ZIF socket when removing the processor. Bending the pins can permanently damage the system board.


**🔧 NOTE:** In single-processor configurations, the processor must be installed in socket CPU1. Install the blank in socket CPU2 only.

**Figure 3-19. Installing and Removing a Processor**




- |   |                    |   |                      |
|---|--------------------|---|----------------------|
| 1 | processor          | 2 | processor shield     |
| 3 | notch in processor | 4 | socket key           |
| 5 | ZIF socket         | 6 | socket-release lever |

## Installing a Processor

 **CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

- 1 If you are upgrading your processors, prior to upgrading your system, download and install the latest system BIOS version from [support.dell.com](http://support.dell.com). Follow the instructions included in the file download to install the update on your system.

 **NOTE:** In single-processor configurations, socket CPU1 must be used.

- 2 Unpack the processor if it has not been used previously.

If the processor has already been used, remove any thermal grease from the top of the processor using a lint-free cloth.


- 3 Align the processor with the socket keys on the ZIF socket.  
See Figure 3-19.

 **CAUTION:** Positioning the processor incorrectly can permanently damage the system board or the processor. Be careful not to bend the pins in the ZIF socket.

- 4 With the release lever on the processor socket in the open position, align the processor with the socket keys and set the processor lightly in the socket.

 **CAUTION:** Do not use force to seat the processor. When the processor is positioned correctly, it engages easily into the socket.

- 5 Close the processor shield.
- 6 Rotate the socket release lever down until it snaps into place.
- 7 Using a clean lint-free cloth, remove the thermal grease from the heat sink.
- 8 Open the grease packet included with your processor kit and apply thermal grease evenly to the center of the top of the new processor.

 **CAUTION:** Using excess thermal grease can cause grease to contact the processor shield, which can cause contamination of the processor socket.

- 9 Place the heat sink on the processor. See Figure 3-18.

- 10 Using a #2 Phillips screwdriver, tighten the heat-sink retention screws. See Figure 3-18.
- 11 Replace the cooling shroud. See "Installing the Cooling Shroud" on page 63.
- 12 Close the system. See "Closing the System" on page 61.
- 13 Reconnect the system to its electrical outlet and turn the system on, including any attached peripherals.
- 14 Press <F2> to enter the System Setup program, and check that the processor information matches the new system configuration. See "Entering the System Setup Program" on page 39.
- 15 Run the system diagnostics to verify that the new processor operates correctly.  
See "Running the Embedded System Diagnostics" on page 140 for information about running the diagnostics.

## System Battery

### Replacing the System Battery




**WARNING:** There is a danger of a new battery exploding if it is incorrectly installed. Replace the battery only with the same or equivalent type recommended by the manufacturer. See your safety information for additional info.



**CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

- 1 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 Remove the cooling shroud. See "Removing the Cooling Shroud" on page 62.

**Figure 3-20. Replacing the System Battery**



- 1 system battery
- 2 negative side of battery connector
- 3 positive side of battery connector

- 4 If installed, remove the expansion card from the expansion-card slot. See "Removing an Expansion Card" on page 82.
- 5 If installed, remove the storage controller card. See "Removing the Storage Controller Card" on page 87.
- 6 To remove the expansion-card riser, press the blue tabs on the expansion-card riser and lift it from the chassis. See "Removing an Expansion-Card Riser" on page 83.
- 7 Locate the battery socket. See "System Board Connectors" on page 144.

**⚠ CAUTION: To avoid damage to the battery connector, you must firmly support the connector while installing or removing a battery.**

- 8 Support the battery connector by firmly holding the positive side of the connector.

- 9 Press the battery toward the negative side of the connector and lift it up out of the securing tab at the negative side of the connector.
- 10 Support the battery connector by pressing down firmly on the positive side of the connector.
- 11 Hold the new battery with the "+" facing the plastic connector on the system board and slide it under the securing tabs.
- 12 Press the battery straight down into the connector until it snaps into place.
- 13 Replace the expansion-card riser. See "Installing an Expansion-Card Riser" on page 86.
- 14 Replace the storage controller card. See "Installing the Storage Controller Card" on page 89.
- 15 Replace the expansion card from the expansion-card slot, now. See "Installing an Expansion Card" on page 84.
- 16 Replace the cooling shroud. See "Installing the Cooling Shroud" on page 63.
- 17 Close the system. See "Closing the System" on page 61.
- 18 Reconnect the system to the electrical outlet and turn the system on, including any attached peripherals.
- 19 Enter the System Setup program to confirm that the battery is operating properly. See "Entering the System Setup Program" on page 39.
- 20 Enter the correct time and date in the System Setup program's **Time** and **Date** fields.
- 21 Exit the System Setup program.


# RAID Battery

## Removing the RAID Battery

**⚠ CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 To disconnect the RAID battery cable by gently pulling the cable connector out of the connector. See Figure 3-21.
- 4 Pull back gently on the two tabs holding the RAID battery and lift the RAID battery from the battery carrier. See Figure 3-21.

**Figure 3-21. Removing and Installing the RAID Battery**



- 1 battery carrier
- 3 RAID battery

- 2 battery cable connector
- 4 battery carrier tabs (2)

## Installing the RAID Battery



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Insert the RAID battery into the battery carrier until it locks into place. See Figure 3-21.
- 2 Connect the cable to the battery. See Figure 6-1.
- 3 Close the system. See "Closing the System" on page 61.
- 4 Turn on the system and attached peripherals.

## Control Panel Assembly—LED

### Removing the Control-Panel Module—LED



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 If installed, remove the front bezel. See "Removing the Front Bezel" on page 59.
- 2 Turn off the system and attached peripherals, and disconnect the system from the electrical outlet and peripherals.
- 3 Remove the single screw securing the bracket to the module and remove the bracket.
- 4 Disconnect the control-panel cable at back of the module by using the pull tab. See Figure 3-22.




**CAUTION: Do not pull on the cable to unseat the connector. Doing so can damage the cable.**

- 5 Remove the screw securing the power button board to the control-panel module. See Figure 3-22.
- 6 Remove the power button board and power button from the control-panel module.



**Figure 3-22. Removing and Installing the Control Panel—LED**



- 1 bracket
- 3 power button board
- 5 control-panel module

- 2 control-panel cable
- 4 power button

## Installing the Control-Panel Module–LED



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Assemble the power button and power button board in the control-panel module.
- 2 Tighten the screw to secure the power button board to the control-panel module. See Figure 3-22.
- 3 Connect the control-panel cable to the control-panel module.
- 4 Replace the bracket and tighten the single screw to secure the bracket to the back of the control-panel module.
- 5 Close the system. See "Closing the System" on page 61.
- 6 Reconnect the system to the power source and turn on the system and attached peripherals.
- 7 If applicable, replace the front bezel. See "Installing the Front Bezel" on page 60.

# Front-Panel I/O Module

## Removing the Front-Panel I/O Module




**CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

- 1 If installed, remove the front bezel. See "Removing the Front Bezel" on page 59.
- 2 Turn off the system and attached peripherals, and disconnect the system from the electrical outlet and peripherals.
- 3 Using a Torx screwdriver, remove the three screws that secure the front panel I/O module to the system chassis and remove the module.
- 4 Remove the single screw securing the bracket to the module and remove the bracket.
- 5 Unlatch and disconnect the front-panel I/O cable at back of the module. See Figure 3-23.



**CAUTION:** Do not pull on the cable to unseat the connector. Doing so can damage the cable.

**Figure 3-23. Removing and Installing the Front-Panel I/O Module**



- 1 front-panel I/O cable
- 3 front-panel I/O module


- 2 bracket
- 4 mounting screws (3)

## Installing the Front-Panel I/O Module

- 1 Connect and latch the front-panel I/O cable at the back of the module.
- 2 Tighten the single screw to secure the bracket to the back of the module.
- 3 Align the module with the holes on the right side of the system chassis and secure with the three Torx screws. See Figure 3-23.
- 4 Connect the front-panel I/O cable to the connector on the back of the SAS backplane.
- 5 Close the system. See "Closing the System" on page 61.
- 6 Reconnect the system to its electrical outlet and turn the system on, including any attached peripherals.
- 7 If applicable, replace the front bezel. See "Installing the Front Bezel" on page 60.

## SAS Backplane

### Removing the SAS Backplane

 **CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 If applicable, remove the bezel. See "Removing the Front Bezel" on page 59.
- 2 Turn off the system and attached peripherals, and disconnect the system from the electrical outlet.
- 3 Open the system. See "Opening the System" on page 60.

 **CAUTION: To prevent damage to the drives and backplane, you must remove the hard drives from the system before removing the backplane.**

 **CAUTION: You must note the number of each hard drive and temporarily label them before removal so that you can replace them in the same locations.**

- 4 Remove all hard drives. See "Removing a Hot-Swap Hard Drive" on page 64.


- 5 Disconnect the power cable from the end of the SAS backplane.
- 6 Disconnect the SAS data cables from the backplane.
- 7 Disconnect the USB cable and the control-panel cable.



**CAUTION: Handle the cables gently to prevent damage.**

- 8 Disconnect the internal hard-drive cables.
- 9 While pressing the two blue latches toward each other, lift the backplane upward. See Figure 3-24.
- 10 When the backplane cannot slide upward any further, pull the backplane toward the back of the system to remove it from the retention hooks.
- 11 Lift the board out of the system, being careful to avoid damaging components on the face of the board.
- 12 Place the SAS backplane face down on a work surface.

**Figure 3-24. Removing and Installing a SAS Backplane**



- |   |                          |    |                                 |
|---|--------------------------|----|---------------------------------|
| 1 | SAS backplane            | 2  | backplane retention latches (2) |
| 3 | SAS cables               | 4  | control panel module cable      |
| 5 | USB memory key connector | 6  | SAS backplane power cable       |
| 7 | control panel cable      | 8  | internal hard drive cables (2)  |
| 9 | USB cable                | 10 | SAS backplane cable             |

## Installing the SAS Backplane



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Lower the backplane into the system, being careful to avoid damaging components on the face of the board.
- 2 Align the slots in the backplane with the retention hooks on the back of the drive bays, then move the backplane forward until the retention hooks fit through the slots in the backplane. See Figure 3-24.
- 3 Slide the backplane downward until the two blue retention latches snap into place.
- 4 Connect the SAS data and power cables to the SAS backplane.
- 5 Install the hard drives in their original locations.
- 6 Connect the USB cable and the control panel cable to the system board.



**CAUTION: Handle the cables gently to prevent damage.**

- 7 Connect the internal hard-drive cables.
- 8 Close the system. See "Closing the System" on page 61.
- 9 Reconnect the system to its electrical outlet and turn the system on, including any attached peripherals.



# Power Distribution Board

The power distribution board is located on your system directly behind the power supply fan module. See Figure 3-25.


## Removing the Power Distribution Board



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Remove the internal hard drive bay and support carrier. See "Removing an Internal Hard Drive Bay" on page 67.
- 2 If applicable, remove the thumb screw on the support bracket and lift it up and out of the system.
- 3 Remove the power supplies from the system. See "Removing a Power Supply" on page 74.
- 4 Remove the expansion cards. See "Removing an Expansion Card" on page 82.
- 5 Remove the expansion card riser. See "Removing an Expansion-Card Riser" on page 83.
- 6 Disconnect power distribution cables from the system board (see "System Board" on page 116).
- 7 Disconnect the fan cable.
- 8 Remove the three screws securing the power distribution board to the chassis using the #2 Phillips screw driver. See Figure 3-25.
- 9 Pull the blue tab, lift the power distribution board, and move it toward the front of the system to disengage from the tabs on the power supply bay. See Figure 3-25.

**Figure 3-25. Removing and Installing the Power Distribution Board**



- |   |                          |   |                            |
|---|--------------------------|---|----------------------------|
| 1 | screws (3)               | 2 | power supply connector     |
| 3 | power-interposer board   | 4 | blue tab                   |
| 5 | power-distribution board | 6 | fan module cable connector |

## Installing the Power Distribution Board





**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1** Unpack the new power distribution board assembly.
- 2** Align the power distribution board with the tabs on the chassis and slide it in place until the blue tab snaps over the edge of the board. See Figure 3-25.
- 3** Install the three screws that secure the power distribution board to the chassis. See Figure 3-25.
- 4** Connect the power distribution cables to the system board (see "System Board" on page 116) and fan cable to the power distribution board as shown in Figure 3-25.
- 5** Align the support bracket over the Power Distribution board and secure in place with the screw.
- 6** Install the internal hard-drive bay. See "Installing an Internal Hard-Drive Bay" on page 69.
- 7** Install the power supplies in the system. See "Installing a Power Supply" on page 75.
- 8** Replace the expansion-card riser. See "Installing an Expansion-Card Riser" on page 86.
- 9** Replace the expansion cards. See "Installing an Expansion Card" on page 84.
- 10** Close the system. See "Closing the System" on page 61.
- 11** Reconnect the system to its electrical outlet and turn the system on, including any attached peripherals.

# System Board

## Removing the System Board

 **CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.


 **CAUTION:** If you are using the Trusted Program Module (TPM) with an encryption key, you may be prompted to create a recovery key during program or system setup. Be sure to create and safely store this recovery key. If you replace this system board, you must supply the recovery key when you restart your system or program before you can access the encrypted data on your hard drives.

- 1 Turn off the system and attached peripherals, and disconnect the system from the electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 Remove the cooling shroud. See "Removing the Cooling Shroud" on page 62.
- 4 Remove the power supplies. See "Removing a Power Supply" on page 74.
- 5 Remove all expansion cards and, if applicable, the storage controller card. See "Removing an Expansion Card" on page 82 and "Removing the Storage Controller Card" on page 87.
- 6 Remove the expansion-card riser. See "Removing an Expansion-Card Riser" on page 83.
- 7 Remove the heat sinks, processors and heat-sink blanks. See "Removing a Processor" on page 95.
- 8 If installed, remove the iDRAC6 Enterprise card. See "Removing an iDRAC6 Enterprise Card" on page 93.
- 9 If installed, remove the iDRAC6 Express card. See "Removing an iDRAC6 Express Card" on page 90.
- 10 Disconnect all cables from the system board.
- 11 Remove the nine screws securing the system board to the chassis and then slide the system board assembly toward the front end of the chassis.

**CAUTION:** Do not lift the system board assembly by grasping a memory module, processor, or other components.

**12** Grasp the system board assembly by the edges and lift the system board assembly away from the chassis. See Figure 3-26.

**Figure 3-26. Removing and Installing the System Board**



## Installing the System Board



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Unpack the new system board.
- 2 Remove the labels from the processor shield and affix them to the system identification panel on the front of the system. See Figure 1-1.
- 3 Holding the system board by the edges, lower it into the chassis.



**CAUTION: Do not lift the system board assembly by grasping a memory module, processor, or other components.**

- 4 Slightly lift up the front of the system board and maneuver the system board to the bottom of the chassis until it lays completely flat.
- 5 Push the system board toward the back of the chassis until the board is in place.
- 6 Tighten the nine screws that secure the system board to the chassis. See Figure 3-26.
- 7 Transfer the processors to the new system board. See "Removing a Processor" on page 95 and "Installing a Processor" on page 99.
- 8 Remove the memory modules and transfer them to the same locations on the new board. See "Removing Memory Modules" on page 78 and "Installing Memory Modules" on page 79.
- 9 Connect the cables to the system board. See Figure 6-1 for the locations of the connectors on the system board.
- 10 Replace the expansion-card riser. See "Installing an Expansion-Card Riser" on page 86.
- 11 Install all expansion cards. See "Installing an Expansion Card" on page 84.
- 12 If applicable, reinstall the storage controller card. See "Installing the Storage Controller Card" on page 89.

After connecting the SAS cables to the controller, make sure to place the cables under the guide on the end of riser 1.


- 13** If applicable, install the iDRAC6 Enterprise card. See "Installing an iDRAC6 Enterprise Card" on page 94.
- 14** If applicable, install the iDRAC6 Express card. See "Installing an iDRAC6 Express Card" on page 91.
- 15** Replace the cooling shroud. See "Installing the Cooling Shroud" on page 63.
- 16** Close the system. See "Closing the System" on page 61.
- 17** Reconnect the system to its electrical outlet and turn the system on, including any attached peripherals.
- 18** If applicable, replace the front bezel. See "Removing the Front Bezel" on page 59.





# Troubleshooting Your System

## Safety First—For You and Your System

 **CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

## Troubleshooting System Startup Failure

If your system halts during startup prior to video imaging messaging, especially after installing an operating system or reconfiguring your system's hardware, check for the following conditions.

- If you boot the system to the BIOS boot mode after installing an operating system from the UEFI Boot Manager, the system will hang. The reverse is also true. You must boot to the same boot mode in which you installed the operating system. See "Using the System Setup Program and UEFI Boot Manager" on page 39.
- Invalid memory configurations could cause the system to halt at startup without any video output. See "Expansion Cards and Expansion-Card Risers" on page 81.

For all other startup issues, note the system messages that appear onscreen. See "System Messages" on page 22 for more information.

## Troubleshooting External Connections

Ensure that all external cables are securely attached to the external connectors on your system before troubleshooting any external devices. See Figure 1-1 and Figure 1-3 for the front- and back-panel connectors on your system.

## Troubleshooting the Video Subsystem

- 1 Check the system and power connections to the monitor.
- 2 Check the video interface cabling from the system to the monitor.
- 3 Run the appropriate Embedded System diagnostic test. See "Running the Embedded System Diagnostics" on page 140.

If the tests run successfully, the problem is not related to video hardware.

If the tests fail, see "Getting Help" on page 149.

## Troubleshooting a USB Device

Use the following steps to troubleshoot a USB keyboard and/or mouse.

For other USB devices, go to step 5.

- 1 Disconnect the keyboard and mouse cables from the system briefly and reconnect them.
- 2 Connect the keyboard/mouse to the USB port(s) on the opposite side of the system.
- 3 If the problem is resolved, restart the system, enter the System Setup program, and check if the nonfunctioning USB ports are enabled.
- 4 Replace the keyboard/mouse with another working keyboard/mouse.

If the problem is resolved, replace the faulty keyboard/mouse.

If the problem is not resolved, proceed to the next step to begin troubleshooting the other USB devices attached to the system.

- 5 Turn off all attached USB devices and disconnect them from the system.
- 6 Restart the system and, if your keyboard is functioning, enter the system setup program. Verify that all USB ports are enabled. See "Integrated Devices Screen" on page 45.

If your keyboard is not functioning, you can also use remote access. If the system is not accessible, see "System Board Jumpers" on page 143 for instructions on setting the NVRAM\_CLR jumper inside your system and restoring the BIOS to the default settings.

- 7 Reconnect and power on each USB device one at a time.
- 8 If a device causes the same problem, power down the device, replace the USB cable, and power up the device.

If the problem persists, replace the device.

If all troubleshooting fails, see "Getting Help" on page 149.

## Troubleshooting a Serial I/O Device

- 1 Turn off the system and any peripheral devices connected to the serial port.
- 2 Swap the serial interface cable with another working cable, and turn on the system and the serial device.

If the problem is resolved, replace the interface cable.

- 3 Turn off the system and the serial device, and swap the device with a comparable device.

- 4 Turn on the system and the serial device.

If the problem is resolved, replace the serial device.

If the problem persists, see "Getting Help" on page 149.

## Troubleshooting a NIC

- 1 Run the appropriate Embedded System diagnostic test. See "Running the Embedded System Diagnostics" on page 140.
- 2 Restart the system and check for any system messages pertaining to the NIC controller.
- 3 Check the appropriate indicator on the NIC connector. See "NIC Indicator Codes" on page 17.

- If the link indicator does not light, check all cable connections.
- If the activity indicator does not light, the network driver files might be damaged or missing.

Remove and reinstall the drivers, if applicable. See the NIC's documentation.

- Change the auto-negotiation setting, if possible.
- Use another connector on the switch or hub.

If you are using a NIC card instead of an integrated NIC, see the documentation for the NIC card.

- 4 Ensure that the appropriate drivers are installed and the protocols are bound. See the NIC's documentation.
- 5 Enter the System Setup program and confirm that the NIC ports are enabled. See "Integrated Devices Screen" on page 45.
- 6 Ensure that the NICs, hubs, and switches on the network are all set to the same data transmission speed. See the documentation for each network device.
- 7 Ensure that all network cables are of the proper type and do not exceed the maximum length.

If all troubleshooting fails, see "Getting Help" on page 149.

## Troubleshooting an NVRAM card



**CAUTION: Installing the NVRAM card in a legacy PCI slot reduces performance and might cause irreparable damage to the PCIe host interface.**

Ensure that the NVRAM card is installed in a PCIe x4 or x8 slot.

## Troubleshooting a Wet System



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Turn off the system and attached peripherals, and disconnect the system from the electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 Disassemble components from the system. See "Installing System Components" on page 57.
  - Cooling shroud

- Hard drives
- SAS backplane
- USB memory keys
- NIC hardware key
- Expansion-card riser
- Integrated storage controller card
- iDRAC6 Express card
- iDRAC6 Enterprise card
- Power supplies
- Fans
- Processors and heat sinks
- Memory modules

**4** Let the system dry thoroughly for at least 24 hours.

**5** Reinstall the components you removed in step 3.

**6** Close the system. See "Closing the System" on page 61.

**7** Reconnect the system to the electrical outlet, and turn on the system and attached peripherals.

If the system does not start properly, see "Getting Help" on page 149.

**8** If the system starts properly, shut down the system and reinstall all of the expansion cards that you removed. See "Installing an Expansion Card" on page 84.

**9** Run the appropriate Embedded System diagnostic test. See "Running the Embedded System Diagnostics" on page 140.

If the tests fail, see "Getting Help" on page 149.

# Troubleshooting a Damaged System



**CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

- 1 Turn off the system and attached peripherals, and disconnect the system from the electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 Ensure that the following components are properly installed:
  - Expansion-card riser
  - Power supplies
  - Fans
  - Processors and heat sinks
  - Memory modules
  - Hard-drive carriers
  - Cooling shroud
- 4 Ensure that all cables are properly connected.
- 5 Close the system. See "Closing the System" on page 61.
- 6 Run the system board tests in the system diagnostics. See "Running the System Diagnostics" on page 139.  
If the tests fail, see "Getting Help" on page 149.

# Troubleshooting the System Battery




**NOTE:** If the system is turned off for long periods of time (for weeks or months), the NVRAM may lose its system configuration information. This situation is caused by a defective battery.


- 1 Re-enter the time and date through the System Setup program. See "System Setup Options" on page 41.
- 2 Turn off the system and disconnect it from the electrical outlet for at least one hour.

- 3 Reconnect the system to the electrical outlet and turn on the system.
- 4 Enter the System Setup program.

If the date and time are not correct in the System Setup program, replace the battery. See "Replacing the System Battery" on page 100.


 **CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

If the problem is not resolved by replacing the battery, see "Getting Help" on page 149.


 **NOTE:** Some software may cause the system time to speed up or slow down. If the system seems to operate normally except for the time kept in the System Setup program, the problem may be caused by software rather than by a defective battery.

## Troubleshooting Power Supplies

- 1 Identify the faulty power supply by the power supply's fault indicator. See "Power Indicator Codes" on page 18.

 **CAUTION: At least one power supply must be installed for the system to operate. Operating the system with only one power supply installed for extended periods of time can cause the system to overheat.**


- 2 Reseat the power supply by removing and reinstalling it. See "Power Supplies" on page 74.

 **NOTE:** After installing a power supply, allow several seconds for the system to recognize the power supply and to determine if it is working properly. The power indicator turns green to signify that the power supply is functioning properly.

If the problem persists, replace the faulty power supply.

- 3 If all troubleshooting fails, see "Getting Help" on page 149.


# Troubleshooting System Cooling Problems

 **CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

Ensure that none of the following conditions exist:

- System cover, cooling shroud, drive blank, power supply blank, or front or back filler panel is removed.
- Ambient temperature is too high.
- External airflow is obstructed.
- Cables inside the system obstruct airflow.
- An individual cooling fan is removed or has failed. See "Troubleshooting a Fan" on page 128.
- The expansion card installation guidelines have not been followed. See "Expansion Card Installation Guidelines" on page 81.

## Troubleshooting a Fan

 **CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Turn off the system and all attached peripherals.
- 2 Open the system. See "Opening the System" on page 60.
- 3 Reseat the fan's power cable.
- 4 Restart the system.

If the fan functions properly, close the system. See "Closing the System" on page 61.

- 5 If the fan does not function, turn off the system and install a new fan. See "Installing a Cooling Fan" on page 73.



- 6 Restart the system.

If the problem is resolved, close the system. See "Closing the System" on page 61.

If the replacement fan does not operate, see "Getting Help" on page 149.

## Troubleshooting System Memory



**CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.



**NOTE:** Invalid memory configurations can cause your system to halt at startup without video output. See "General Memory Module Installation Guidelines" on page 76 and verify that your memory configuration complies with all applicable guidelines.

- 1 If the system is operational, run the appropriate Embedded System diagnostic test. See "Running the Embedded System Diagnostics" on page 140.

If diagnostics indicates a fault, follow the corrective actions provided by the diagnostic program.

- 2 If the system is not operational, turn off the system and attached peripherals, and unplug the system from the power source. Wait at least 10 seconds and then reconnect the system to power.

- 3 Turn on the system and attached peripherals and note the messages on the screen.

Go to step 14 if an error message appears indicating a fault with a specific memory module.


- 4 Enter the System Setup program and check the system memory setting. See "Memory Settings Screen" on page 43. Make changes to the memory settings, if needed.

If the memory settings match the installed memory but a problem is still indicated, go to step 14.

- 5** Turn off the system and attached peripherals, and disconnect the system from the electrical outlet.
- 6** Open the system. See "Opening the System" on page 60.
- 7** Remove the cooling shroud. See "Removing the Cooling Shroud" on page 62.
- 8** Check the memory channels and ensure that they are populated correctly. See "General Memory Module Installation Guidelines" on page 76.
- 9** Reseat the memory modules in their sockets. See "Installing Memory Modules" on page 79.
- 10** Replace the cooling shroud. See "Installing the Cooling Shroud" on page 63.
- 11** Close the system. See "Closing the System" on page 61.
- 12** Reconnect the system to its electrical outlet, and turn on the system and attached peripherals.
- 13** Enter the System Setup program and check the system memory setting. See "Memory Settings Screen" on page 43.  
If the problem is not resolved, proceed with the next step.
- 14** Turn off the system and attached peripherals, and disconnect the system from the power source.
- 15** Open the system. See "Opening the System" on page 60.
- 16** If a diagnostic test or error message indicates a specific memory module as faulty, swap or replace the module.
- 17** To troubleshoot an unspecified faulty memory module, replace the memory module in the first DIMM socket with a module of the same type and capacity. See "Installing Memory Modules" on page 79.
- 18** Close the system. See "Closing the System" on page 61.
- 19** Reconnect the system to its electrical outlet, and turn on the system and attached peripherals.
- 20** As the system boots, observe any error message that appears and the diagnostic indicators on the front of the system.
- 21** If the memory problem is still indicated, repeat step 14 through step 20 for each memory module installed.

If the problem persists after all memory modules have been checked, see "Getting Help" on page 149.

## Troubleshooting a Hard Drive

 **CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

 **CAUTION: This troubleshooting procedure can destroy data stored on the hard drive. Before you proceed, back up all files on the hard drive.**

- 1 Run the appropriate Embedded System diagnostics test. See "Running the Embedded System Diagnostics" on page 140.

Depending on the results of the diagnostics test, proceed as needed through the following steps.

- 2 If installed, remove the front bezel. See "Removing the Front Bezel" on page 59.
- 3 If your system has a RAID controller and your hard drives are configured in a RAID array, perform the following steps:
  - a Restart the system and enter the host adapter configuration utility program by pressing <Ctrl><R> for a PERC controller or <Ctrl><C> for a SAS controller.  
See the documentation supplied with the host adapter for information about the configuration utility.
  - b Ensure that the hard drive(s) have been configured correctly for the RAID array.
  - c Take the hard drive offline and reseal the drive. See "Removing a Hot-Swap Hard Drive" on page 64
  - d Exit the configuration utility and allow the system to boot to the operating system.
- 4 Ensure that the required device drivers for your controller card are installed and are configured correctly. See the operating system documentation for more information.

- 5 Restart the system, enter the System Setup program, and verify that the controller is enabled and the drives appear in the System Setup program. See "Entering the System Setup Program" on page 39.  
If the problem persists, see "Getting Help" on page 149.
- 6 Replace the front bezel. See "Installing the Front Bezel" on page 60.

## Troubleshooting an Internal Hard Drive



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**



**CAUTION: This troubleshooting procedure can destroy data stored on the hard drive. Before you proceed, back up all files on the hard drive.**

- 1 Run the appropriate Embedded System diagnostics test. See "Running the Embedded System Diagnostics" on page 140.

Depending on the results of the diagnostics test, proceed as needed through the following steps.

- 2 If your system has a RAID controller and your hard drives are configured in a RAID array, perform the following steps:
  - a Restart the system and enter the host adapter configuration utility program by pressing <Ctrl><R> for a PERC controller or <Ctrl><C> for a SAS controller.  
See the documentation supplied with the host adapter for information about the configuration utility.
  - b Ensure that the hard drive(s) have been configured correctly for the RAID array.
  - c Take the hard drive offline and reseal the drive. See "Removing an Internal Hard Drive Bay" on page 67
  - d Exit the configuration utility and allow the system to boot to the operating system.

- 3 Ensure that the required device drivers for your controller card are installed and are configured correctly. See the operating system documentation for more information.
- 4 Restart the system, enter the System Setup program, and verify that the controller is enabled and the drives appear in the System Setup program. See "Entering the System Setup Program" on page 39.  
If the problem persists, see "Getting Help" on page 149.

## Troubleshooting a Storage Controller



**CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.



**NOTE:** When troubleshooting a SAS or SAS RAID controller, also see the documentation for your operating system and the controller.

- 1 Run the appropriate Embedded System diagnostic test. See "Running the Embedded System Diagnostics" on page 140.
- 2 Enter the System Setup program and ensure that the SAS or PERC controller is enabled. See "Entering the System Setup Program" on page 39.
- 3 Restart the system and press the applicable key sequence to enter the configuration utility program.
  - <Ctrl><C> for a SAS controller
  - <Ctrl><R> for a PERC controllerSee the controller's documentation for information about configuration settings.
- 4 Check the configuration settings, make any necessary corrections, and restart the system.
- 5 If installed, remove the front bezel. See "Removing the Front Bezel" on page 59.
- 6 Turn off the system and attached peripherals, and disconnect the system from its electrical outlet.

- 7 Open the system. See "Opening the System" on page 60.
- 8 Ensure that the controller card is firmly seated into the system board connector. See "Installing an Expansion Card" on page 84.
- 9 If you have a battery-cached PERC controller, ensure that the RAID battery is properly connected and, if applicable, the memory module on the PERC card is properly seated.
- 10 Verify that the cable connections between the SAS backplane(s) and the integrated storage controller are correct. See "Installing the Storage Controller Card" on page 89 and Figure 3-15.  
  
Ensure that the cables are firmly connected to the storage controller and the SAS backplane board.
- 11 Close the system. See "Closing the System" on page 61.
- 12 Reconnect the system to its electrical outlet, and turn on the system and attached peripherals.  
  
If the problem persists, see "Getting Help" on page 149.
- 13 Replace the front bezel. See "Installing the Front Bezel" on page 60.

## Troubleshooting Expansion Cards



**CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.



**NOTE:** When troubleshooting an expansion card, see the documentation for your operating system and the expansion card.

- 1 Run the appropriate Embedded System diagnostic test. See "Running the Embedded System Diagnostics" on page 140.
- 2 If installed, remove the front bezel. See "Removing the Front Bezel" on page 59.
- 3 Turn off the system and attached peripherals, and disconnect the system from the electrical outlet.
- 4 Open the system. See "Opening the System" on page 60.

- 5** Ensure that each expansion card is firmly seated in its connector. See "Installing an Expansion Card" on page 84.
- 6** Ensure that each expansion-card riser is firmly seated in its connector. See "Installing an Expansion-Card Riser" on page 86.
- 7** Close the system. See "Closing the System" on page 61.
- 8** Reconnect the system to the electrical outlet, and turn on the system and attached peripherals.
- 9** If problem is not resolved, turn off the system and attached peripherals, and disconnect the system from the electrical outlet.
- 10** Open the system. See "Opening the System" on page 60.
- 11** Remove all expansion cards installed in the system. See "Removing an Expansion Card" on page 82.
- 12** Close the system. See "Closing the System" on page 61.
- 13** Reconnect the system to the electrical outlet, and turn on the system and attached peripherals.
- 14** Run the appropriate Embedded System diagnostic test. See "Running the System Diagnostics" on page 139.  
If the tests fail, see "Getting Help" on page 149.
- 15** For each expansion card you removed in step 11, perform the following steps:
  - a** Turn off the system and attached peripherals, and disconnect the system from the electrical outlet.
  - b** Open the system. See "Opening the System" on page 60.
  - c** Reinstall one of the expansion cards.
  - d** Close the system. See "Closing the System" on page 61.
  - e** Run the appropriate diagnostic test.  
If the tests fail, see "Getting Help" on page 149.

# Troubleshooting Processors



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Run the appropriate Embedded System diagnostics test. See "Running the Embedded System Diagnostics" on page 140.
- 2 Turn off the system and attached peripherals, and disconnect the system from the electrical outlet.
- 3 Open the system. See "Opening the System" on page 60.
- 4 Ensure that each processor and heat sink are properly installed. See "Installing a Processor" on page 99.
- 5 Close the system. See "Closing the System" on page 61.
- 6 Reconnect the system to the electrical outlet, and turn on the system and attached peripherals.
- 7 Run the appropriate Embedded System diagnostic test. See "Running the System Diagnostics" on page 139.
- 8 Turn off the system and attached peripherals, and disconnect the system from the electrical outlet.
- 9 Open the system. See "Opening the System" on page 60.
- 10 Remove processor 2. See "Removing a Processor" on page 95.
- 11 Close the system. See "Closing the System" on page 61.
- 12 Reconnect the system to the electrical outlet, and turn on the system and attached peripherals.



**13** Run the appropriate Embedded System diagnostic test. See "Running the System Diagnostics" on page 139.

If the test fails, the processor is faulty. See "Getting Help" on page 149.

**14** Turn off the system and attached peripherals, and disconnect the system from the electrical outlet.

**15** Open the system. See "Opening the System" on page 60.

**16** Replace processor 1 with processor 2. See "Installing a Processor" on page 99.

**17** Repeat step 11 through step 13.

If you have tested both the processors and the problem persists, the system board is faulty. See "Getting Help" on page 149.



# Running the System Diagnostics

If you experience a problem with your system, run the diagnostics through the system GUI before calling for technical assistance. The purpose of the Dell diagnostics suite is to test your system's hardware without requiring additional equipment or risking data loss. If you are unable to fix the problem yourself, service and support personnel can use diagnostics test results to help you solve the problem.

## Embedded System Diagnostics Features

The embedded system diagnostics provides a series of menus and options for particular device groups or devices. The system diagnostics menus and options allow you to:


- Run tests individually or collectively
- Control the sequence of tests
- Repeat tests
- Display, print, or save test results
- Temporarily suspend testing if an error is detected or terminate testing when a user-defined error limit is reached
- View help messages that briefly describe each test and its parameters
- View status messages that inform you if tests are completed successfully
- View error messages that inform you of problems encountered during testing

## When to Use the Embedded System Diagnostics

If a major component or device in the system does not operate properly, component failure may be indicated. As long as the processor and the system's input/output devices are functioning, you can use the system diagnostics to help identify the problem.

# Running the Embedded System Diagnostics

You can run the embedded system diagnostics program from the USC main screen.

 **CAUTION: Use the system diagnostics to test only your system. Using this program with other systems may cause invalid results or error messages.**

- 1 As the system boots, press <F10> to start the controller.
- 2 Click **Diagnostics** in the left pane and click **Launch Diagnostics** in the right pane.

The **Diagnostics** menu allows you to run all or specific diagnostics tests or to exit.

## Embedded System Diagnostics Testing Options

Click the testing option in the **Main Menu** window.

Testing Option	Function
Express Test	Performs a quick check of the system. This option runs device tests that do not require user interaction.
Extended Test	Performs a more thorough check of the system. This test can take an hour or longer.
Custom Test	Tests a particular device.
Information	Displays test results.

## Using the Custom Test Options

When you select **Custom Test** in the **Main Menu** window, the **Customize** window allows you to select the device(s) to be tested, select specific options for testing, and view the test results.

## Selecting Devices for Testing

The left side of the **Customize** window lists devices that can be tested. Click the (+) next to a device or module to view its components. Click (+) on any component to view the tests that are available. Clicking a device, rather than its components, selects all of the components of the device for testing.



**NOTE:** After you select all the devices and components that you want to test, highlight **All Devices** and then click **Run Tests**.

## Selecting Diagnostics Options

From the **Diagnostics Options** area, select the test(s) you want to run on a device:

- **Non-Interactive Tests Only**—Runs only tests that require no user intervention.
- **Quick Tests Only**—Runs only the quick tests on the device.
- **Show Ending Timestamp**—Time stamps the test log.
- **Test Iterations**—Selects the number of times the test is run.
- **Log output file pathname**—Enables you to specify the USB memory key where the test log file is saved. You cannot save the file to a hard drive.

## Viewing Information and Results

The following tabs in the **Customize** window provide information about the test and the test results:

- **Results** — Displays the test that ran and the result.
- **Errors** — Displays any errors that occurred during the test.
- **Help** — Displays information about the currently selected device, component, or test.
- **Configuration** — Displays basic configuration information about the currently selected device.
- **Parameters** — Displays parameters that you can set for the test.







# Jumpers and Connectors

This section provides specific information about the system jumpers. It also provides some basic information on jumpers and switches and describes the connectors on the various boards in the system.

## System Board Jumpers

Figure 6-1 shows the location of the configuration jumpers on the system board. Table 6-1 lists the jumper settings.


**Table 6-1. System Board Jumper Settings**

Jumper	Setting	Description
PWRD_EN	 (default)	The password feature is enabled (pins 2-4)
		The password feature is disabled, and iDRAC6 local access is unlocked at the next AC power cycle (pins 4-6)
NVRAM_CLR	 (default)	The configuration settings are retained at system boot (pins 3-5)
		The configuration settings are cleared at the next system boot (pins 1-3)

# System Board Connectors

See Figure 6-1 and Table 6-2 for the location and description of the system board connectors.

**Figure 6-1. System Board Connectors**





**Table 6-2. System Board Connectors**

<b>Item</b>	<b>Connector</b>	<b>Description</b>
1	CPU2	Processor 2
2	iDRAC6 Enterprise	iDRAC6 Enterprise card connector
3	B4	Memory module slot B4
	B1	Memory module slot B1 (white release lever)
	B2	Memory module slot B2 (white release lever)
	B3	Memory module slot B3 (white release lever)
4	CPU1	Processor 1
5	FAN1	Cooling fan 1 connector
6	FAN2	Cooling fan 2 connector
7	A3	Memory module slot A3 (white release lever)
	A2	Memory module slot A2 (white release lever)
	A1	Memory module slot A1 (white release lever)
	A4	Memory module slot A4
8	FAN3	Cooling fan 3 connector
9	BATTERY	System battery
10	FAN4	Cooling fan 4 connector
11	12V	8-pin power connector
12	FP_CONN	control panel connector
13	BP_CONN	Backplane power connector
14	PWR_CONN	24-pin power connector
15	PDB_I2C	Power distribution board connector
16	FP_USB_CONN	Backplane USB connector
17	SATA_A	SATA connector A
	SATA_B	SATA connector B
	SATA_C	SATA connector C
	SATA_D	SATA connector D
	SATA_E	SATA connector E

**Table 6-2. System Board Connectors (continued)**

Item	Connector	Description
18	RISER	Expansion-card riser connector
19	RISER	Expansion-card riser connector
20	iDRAC6 Express	iDRAC6 Express card connector
21	PSWD_EN	Password enable jumper
	NVRM_CLR	NVRAM clear jumper

## Disabling a Forgotten Password

The system's software security features include a system password and a setup password, which are discussed in detail in "Using the System Setup Program and UEFI Boot Manager" on page 39. The password jumper enables these password features or disables them and clears any password(s) currently in use.



**CAUTION: Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.**

- 1 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 2 Open the system. See "Opening the System" on page 60.
- 3 Move the password jumper to the "disabled" position to clear the password. See Table 6-1.  
See Figure 6-1 to locate the password jumper on the system board.
- 4 Close the system. See "Closing the System" on page 61.
- 5 Reconnect your system and peripherals to their electrical outlets, and turn on the system.

The existing passwords are not disabled (erased) until the system boots with the password jumper plug in the "disabled" position. However, before you assign a new system and/or setup password, you must return the jumper plug to the enabled position.



**NOTE:** If you assign a new system and/or setup password with the jumper plug still in the "disabled" position, the system disables the new password(s) the next time it boots.

- 6** Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 7** Open the system. See "Opening the System" on page 60.
- 8** Move the password jumper back to the enabled position to restore the password function. See Table 6-1.
- 9** Close the system. See "Closing the System" on page 61.
- 10** Reconnect your system and peripherals to their electrical outlets, and turn on the system.
- 11** Assign a new system and/or setup password.  
To assign a new password using the System Setup program, see "System and Setup Password Features" on page 51.



# Getting Help

## Contacting Dell

For customers in the United States, call 800-WWW-DELL (800-999-3355).



**NOTE:** If you do not have an active Internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.

Dell provides several online and telephone-based support and service options. Availability varies by country and product, and some services may not be available in your area. To contact Dell for sales, technical support, or customer service issues:

- 1 Visit [support.dell.com](https://support.dell.com).
- 2 Verify your country or region in the **Choose A Country/Region** drop-down menu at the bottom of the page.
- 3 Click **Contact Us** on the left side of the page.
- 4 Select the appropriate service or support link based on your need.
- 5 Choose the method of contacting Dell that is convenient for you.



# Index

## A

Advanced ECC memory mode, 77

## B

back-panel features, 15

batteries  
troubleshooting, 126

battery  
troubleshooting the RAID card battery, 133

battery (system)  
replacing, 100

bezel, 59

blank  
hard drive, 63

BMC  
configuring, 55

## C

connectors  
system board, 144  
USB, 12  
video, 12

contacting Dell, 149

control panel assembly

features, 12  
installing, 106  
removing, 104

cooling fan  
replacing, 73

cooling fans  
troubleshooting, 128

cooling shroud  
installing, 63  
removing, 62

cover  
closing, 61  
opening, 60

## D

damaged systems  
troubleshooting, 126

Dell  
contacting, 149

diagnostics  
advanced testing options, 140  
testing options, 140  
when to use, 139

DIMMs  
*See* memory modules (DIMMs).

drive blank  
installing, 64  
removing, 63

## E

- Embedded System Management, 54
- error messages, 39
- expansion card
  - troubleshooting, 134
- expansion cards
  - installing, 84
  - removing, 82
  - SAS controller, 87
- expansion slots, 81

## F

- front-panel features, 12
- front-panel IO module, 107
  - installing, 109
  - removing, 107

## G

- guidelines
  - expansion card installation, 81
  - memory installation, 76

## H

- hard drive
  - troubleshooting, 131-132
- hard drives (hot-swappable)
  - installing, 65
- heat sink, 97

## I

- iDRAC card
  - installing, 90, 93
  - system port, 15
- iDRAC Configuration Utility, 56
- indicators
  - back-panel, 15
  - front-panel, 12
  - NIC, 17
  - power, 12, 18
- installing
  - control panel assembly, 106
  - cooling shroud, 63
  - expansion card, 84
  - front-panel IO module, 109
  - hard drive (hot-swappable), 65
  - hard drive blank, 64
  - iDRAC card, 90, 93
  - memory modules, 79
  - processor, 99
  - SAS backplane board, 112
  - SAS controller, 89

## J

- jumpers (system board), 143

## K

- keyboards
  - troubleshooting, 122



## M

- memory
  - troubleshooting, 129
- Memory Mirroring memory mode, 77
- memory mode
  - Advanced ECC, 77
  - memory mirroring, 77
  - Optimizer, 78
- memory modules (DIMMs)
  - configuring, 76
  - installing, 79
  - removing, 78
  - UDIMM configurations, 82
- messages
  - error messages, 39
  - system, 22
  - warning, 37

## N

- NIC
  - indicators, 17
- NICs
  - back-panel connectors, 15
  - troubleshooting, 123

## O

- Optimizer memory mode, 78

## P

- password
  - setup, 53
  - system, 51
- passwords
  - disabling, 146
- phone numbers, 149
- POST
  - accessing system features, 11
- power indicators, 12, 18
- power supplies
  - indicators, 18
  - removing, 74
  - replacing, 75
- processor
  - installing, 99
  - removing, 95
  - See* processor.
  - upgrades, 95
- processors
  - troubleshooting, 136

## R

- remote access controller
  - See* iDRAC.
- removing
  - bezel, 59
  - control panel assembly, 104
  - cooling shroud, 62
  - cover, 60
  - expansion card, 82

- front-panel IO module, 107
- hard drive blank, 63
- memory modules, 78
- power supply, 74
- processor, 95
- SAS backplane board, 109
- SAS controller, 87
- system board, 116

replacing

- cooling fan, 73
- power supply, 75
- system battery, 100

## S

- safety, 121
- SAS backplane board
  - installing, 112
  - removing, 109
- SAS controller card
  - installing, 89
  - removing, 87
- SAS controller daughter card
  - troubleshooting, 133
- SAS hard drive. *See* hard drive.
- SAS RAID controller daughter card
  - troubleshooting, 133
- securing your system, 48, 52
- setup password, 53
- slots
  - See* expansion slots.
- startup
  - accessing system features, 11
- support
  - contacting Dell, 149
- system
  - closing, 61
  - opening, 60
- system board
  - connectors, 144
  - installing, 118
  - jumpers, 143
  - removing, 116
- system cooling
  - troubleshooting, 128
- system features
  - accessing, 11
- system messages, 22
- system password, 51
- system setup program
  - boot settings, 45
  - integrated devices options, 45
  - keystroke to enter, 39
  - memory settings, 43
  - PCI IRQ assignments, 46
  - power management options, 48
  - processor settings, 43
  - serial communications
    - options, 47
  - system security options, 48
- system setup screens
  - main, 41

## **T**

- telephone numbers, 149
- TPM security, 48
- troubleshooting
  - battery, 126
  - cooling fans, 128
  - damaged system, 126
  - expansion card, 134
  - external connections, 121
  - hard drive, 131-132
  - internal hard drive, 132
  - keyboard, 122
  - memory, 129
  - NIC, 123
  - processors, 136
  - SAS RAID controller daughter card, 133
  - system cooling, 128
  - video, 122
  - wet system, 124

## **U**

- Unified Server Configurator Lifecycle Controller, 54
- upgrades
  - processor, 95
- USB
  - front-panel connectors, 12
- USB device
  - back-panel connectors, 15

## **V**

- video
  - back-panel connector, 15
  - front-panel connectors, 12
  - troubleshooting, 122

## **W**

- warning messages, 37
- warranty, 38
- wet system
  - troubleshooting, 124

