

Dell PowerVault TL2000 Tape Library and TL4000 Tape
Library

User's Guide

Information in this document is subject to change without notice.

Copyright © 2017 Dell Inc. or its subsidiaries. All rights reserved.

Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

Printed December 2017

Read this first

Minimum firmware levels for common library features

Table 1. Minimum firmware levels for common library features

Feature	Minimum Firmware Level(s) Required
LTO HH V2 Tape Drives	Library firmware level must be at A.00, or greater, to support HH V2 Tape Drives.
LTO 8 Tape Drive	Library firmware must be at E.70 or greater to support the Ultrium 8 drives. Ensure the minimum version required to support Ultrium 8 tape drives are installed on the host. Ensure that any host applications and software using their own device drivers are at the minimum level required to support Ultrium 8 tape drives.
LTO 7 Tape Drive	Library firmware must be at D.10 or greater to support the Ultrium 7 drives. Ensure the minimum version required to support Ultrium 7 tape drives are installed on the host. Ensure that any host applications and software using their own device drivers are at the minimum level required to support Ultrium 7 tape drives.
LTO 6 Tape Drive	Library firmware must be at B.50 or greater to support the Ultrium 6 drives. Ensure the minimum version required to support Ultrium 6 tape drives are installed on the host. Ensure that any host applications and software using their own device drivers are at the minimum level required to support Ultrium 6 tape drives.
LTO 5 Tape Drive	Library firmware must be at 9.00, or greater, to support the Ultrium 5 drives. Ensure the minimum version required to support Ultrium 5 tape drives are installed on the host. Ensure that any host applications and software using their own device drivers are at the minimum level required to support Ultrium 5 tape drives.
Library BCR (Bar Code Reader)	Libraries manufactured after May 2010 may have a BCR that requires a minimum level of library firmware. The minimum level of firmware for these libraries is 9.00. Attempts to downlevel these libraries below 9.00 will be blocked by the library.
Dedicated Cleaning Slot removal	Library firmware level must be greater than 3.90.
Encryption	Library firmware level must be 5.80 or greater. LTO4 Drive firmware level must be 77BE or greater.
Key Path Diagnostics	Library firmware level must be greater than 6.3, if feature is available.
Path Failover	LTO 4 Tape Drives: No minimum level of firmware is required.
IPv6 Support	Library firmware level: 4.50

Contacting Dell

For customers in the United States, call 800-WWW-DELL (800-999-3355).

Note: If you do not have an active Internet connection, you can find contact information about your purchase invoice, packing slip, bill, or Dell product catalog.

Dell provides online and telephone-based support and service options. Service availability varies by country and product, and some services might not be available in your area. To contact Dell for sales, technical support, or customer service issues, follow the steps that are listed:

1. Go to Dell.com/support.
2. Select your country from the drop-down menu on the lower right corner of the page.
3. For customized support:
 - a. Enter your system Service Tag in the **Enter your Service Tag** field.
 - b. Click **Submit**. The support page that lists the various support categories is displayed.
4. For general support:
 - a. Select your product category.
 - b. Select your product segment.
 - c. Select your product. The support page that lists the various support categories is displayed.
5. For contact details of Dell Global Technical Support:
 - a. Click Global Technical Support.
 - b. The **Contact Technical Support** page is displayed with details to call, chat, or e-mail the Dell Global Technical Support team.

Contents

	iii		
Read this first	v	Installation Planning	25
Minimum firmware levels for common library features	v	Determining the Number of Logical Libraries	25
Contacting Dell	vi	Basic Guidelines	25
		Library Sharing	25
Figures	xi	Using Multiple Logical Libraries for Library Sharing	25
		Using Multiple Control Paths	26
Tables	xv	Using Multiple Control Paths for Path Failover	26
		Library Partitioning and Element Addressing	26
Safety and environmental notices	xvii	Logical Unit Number (LUN) Scanning	30
Danger and caution notices	xvii	Host Interfaces	30
Laser Safety and Compliance	xviii	SCSI Interface	30
Performing the safety inspection procedure	xviii	Physical Characteristics of the SCSI Interface	31
Rack safety	xviii	Using Multiple SCSI Buses	32
		Terminating the Bus	32
Preface	xxi	SCSI Differential - LVD	32
		SAS Interface	32
Product Description	1	Fibre Channel Interface	33
Front Panel	1	Cables and Speeds	33
Rear Panel	3	Using Zoning to Isolate Devices and Enhance Security	33
Bar Code Reader	5	Sharing on a Storage Area Network	34
Encryption	6		
Supported Internet Protocols	7	Installation and Configuration	35
SNMP Messaging	7	Using the Library Configuration Form	35
SNMP Traps	7	Installing Your Library	35
Maximum Library Storage Capacity and Data Transfer Rate	8	Choosing a Location	35
Ultrium Tape Drives	9	Unpacking the Library	36
Speed Matching	10	Verifying the shipment	36
Channel Calibration	10	Installing the Library Foot Pads (for Desktop Installation ONLY)	37
Power Management	11	Removing and Storing the Shipping Lock	38
Media	11	Rackmounting the Library (for Rack Installation ONLY)	40
Library Specifications	12	Attaching the Library to a Server	50
Product Environment	15	Connecting the Host Interface Cable	50
Supported Device Drivers	15	Connecting a Power Cord	52
		Configuring Your Library	53
		Choosing Your Configuration Method	53
User Interfaces	17	Using Factory Defaults as Your Configuration	53
Operator Control Panel	17	Configuring Your Library using the Web User Interface	53
Operator Control Panel Philosophy	17	Establishing Remote Access to Your Library	54
Power-ON Display	18	Logging on to the Web User Interface	55
Note about the Front Panel LEDs	18	Verifying/Updating Firmware	56
Input Modes	19	Choosing General Library Settings	57
Selecting Predefined Values	19	Choosing the Number of Logical Libraries for Your Library	58
Toggling Values	19	Entering Path Failover Feature Activation Key	59
Entering Numerical Values	19	Setting Up Encryption	60
Power ON/OFF	20	Choosing Drive(s) Interface Identification/Settings	61
Web User Interface	20	Entering Library Network Settings	62
Login	20	Entering User Access Information using the Web User Interface	64
System Status	21		
Web User Interface Help Pages	23		
Logging out of the Web User Interface	23		

Entering Date and Time using the Web User Interface	65	Configure Library: General	116
Configuring Logs and Traces using the Web User Interface	65	Configure Library: Logical Libraries	117
Entering Email Notification Information using the Web User Interface	66	Configure Library: Path Failover	118
Configuring SNMP settings	66	Configure Library: Encryption	118
Testing encryption configuration for Library Managed encryption	68	Configure Library: Drives	120
Restoring Factory Default Settings using the Web User Interface	68	Configure Library: Network	122
Logging out of the Web User Interface	68	Configure Library: User Access	123
Configuring Your Library using the Operator Control Panel.	68	Configure Library: Date & Time	125
Preparing the Host	69	Configure Library: Logs & Traces.	125
Verifying the Connection	69	Configure Library: Event Notification	126
Cartridge magazines	69	Configure Library: SNMP	127
Populating the Library with Data Cartridges	73	Configure Library: Save/Restore Configuration	128
Inserting the Cleaning Cartridge	74	Service Library Menu	129
Operations	75	Service Library: Clean Drive	129
Operator Control Panel Navigation	81	Service Library: Advanced Diagnostics (for Service Personnel Only)	130
Operator Control Panel Menu Tree	83	Service Library: View Logs	130
Monitor Menu	84	Service Library: View Drive Logs.	131
Monitor: Library.	84	Service Library: Save Drive Dump	131
Monitor: Drive	86	Service Library: Perform Diagnostics	132
Monitor: Inventory	88	Service Library: Key Path Diagnostics	133
Control Menu	90	Service Library: Upgrade Firmware	134
Control: Open I/O Station	90	Service Library: Reboot	135
Control: Move Cartridges.	91	Import and Export Media during Normal Library Operation	135
Control: Magazine	91	Configuring I/O Stations and Reserving Slots	136
Control: Re-Inventory	92	Using Ultrium Media	139
Configure Menu.	92	Data Cartridges	139
Configure: Logical Libraries	92	Cartridge Compatibility	141
Configure: Library	94	WORM (Write Once, Read Many) Cartridges	141
Configure: Drive.	96	WORM Media	141
Configure: Network	97	Data Security on WORM Media	142
Configure: Set Access PIN	98	WORM Media Errors.	142
Setting the Operator Control Panel Access PIN using the Operator Control Panel	98	Cleaning Cartridge	142
Configure: Save/Restore	99	Bar Code Label.	142
Configure: Set Date and Time	101	Guidelines for Using Bar Code Labels	144
Configure: Path Failover.	102	Write-Protect Switch	144
Service Menu	102	Handling the Cartridges.	145
Service: Library Verify	102	Provide Training	145
Service: Run Tests	103	Ensure Proper Packaging	145
Service: Service (Drives)	104	Provide Proper Acclimation and Environmental Conditions	146
Service: Display Contrast	104	Perform a Thorough Inspection	146
Service: Telnet Service Port	105	Handle the Cartridge Carefully	147
Web User Interface Menus	105	Environmental and Shipping Specifications for Tape Cartridges	147
Monitor Library Menu	106	Troubleshooting	149
Monitor Library: Library Identity.	106	Installation Problems	154
Monitor Library: Drive Identity	107	Library Recovery Problem Determination	155
Monitor Library: Library Status	109	Procedures for Isolating CRU Problems.	155
Monitor Library: Drive Status	110	Isolating a Power Supply Problem	155
Monitor Library: Inventory	112	Isolating Drive Sled Problems	157
Manage Library Menu	114	Isolating a Library Controller Card vs. Accessor Enclosure Problem	158
Manage Library: Move Media	114	Isolating Web User Interface Problems	159
Manage Library: Perform Inventory	115	Isolating Accessor Scanner Problems.	159
Manage Library: Release Magazine	115	Isolating Host Attachment Interface Problems	159
Configure Library Menu.	116		

Identifying a Suspect Cartridge 160

Error codes 161

Service Procedures. 175

Removing Cartridges from Magazine Slots 175

Releasing the Magazines Manually 175

Using the ITDT Firmware Update, Dump Retrieval
and Drive Test Tool 177

Check, Adjust, Remove, and Replace 179

Tools Required 179

Electrostatic Discharge 179

Relocating Your Library 179

Removing/Installing/Adding a Tape Drive Sled 181

 Removing a Tape Drive Sled 182

 Installing a Tape Drive Sled 183

 Adding a Tape Drive Sled 185

 Configuring the Tape Drive 186

Replacing a Power Supply 186

Replacing a Library Controller Card. 187

Replacing Cartridge Magazines 188

Replacing the Library Enclosure 189

 Preparing the Defective Library for Replacement 189

 Unpacking and Preparing the Replacement

 Library Enclosure 190

 Installing your drive in the replacement library
 enclosure 192

 Swapping Power Supplies 194

 Swapping Library Controller Cards 196

 Swapping Cartridge Magazines 198

 Installing the Replacement Library Enclosure 200

 Completing the Installation of the Replacement

 Library Enclosure 202

 Returning the Defective Library Enclosure. 202

**Appendix A. SCSI Element Types,
SCSI Addresses, and Physical
Configurations 203**

2U Library I/O Slot, Storage Slots and Drive Slot
Element Addresses and Physical Locations 203

4U Library I/O Slots, Storage Slots, and Drive Slots
Element Addresses and Physical Locations 204
Library Partitioning and Element Addressing. 205

Appendix B. TapeAlert Flags 209

TapeAlert Flags Supported by the Library 209

TapeAlert Flags Supported by the Drive 211

Appendix C. Sense Data. 215

Library sense data. 215

Drive Sense Data 221

**Appendix D. Enabling LUN Support in
Linux 231**

Red Hat Enterprise Linux 231

Enabling LUN Support in Netware 232

**Appendix E. Notes on IPv6
Compatibility with Windows 2003/XP
and 2008/Vista 235**

Notes on IPv6 Compatibility with Linux 236

**Appendix F. SNMP Status MIB
Variables and Traps 237**

**Appendix G. Library Configuration
Form 239**

Appendix H. Accessibility 241

Glossary 243

Index 261

Figures

1. Front panel of a 2U library	1	38. Attaching host interface cables to the 4U library	51
2. Front panel of a 4U library	2	39. Attaching a SAS interface cable to the 2U library	51
3. Rear panel (drive sled only) of a half height Fibre Channel drive	3	40. Removing the protective label from the power receptacle	52
4. Rear panel of a 4U library with full height Fibre Channel drive and half height SAS drives.	3	41. Log in screen on the Web User Interface	56
5. Rear panel of a 2U library with a full height dual port SAS drive	4	42. The 2U library Configure Library: General screen	58
6. Library drive sled without ESD springs (SCSI sled shown)	10	43. Example: The 4U library Configure Library: General screen	58
7. Library drive sled with ESD springs [1] (SAS sled shown)	10	44. The 4U library Configure Library: Logical Libraries page.	59
8. Power-ON screens	18	45. The Configure Library: Path Failover Feature Activation screen.	59
9. Web User Interface login page	21	46. Feature Key verification screen	60
10. 2U library System Status screen	21	47. Feature Activation Key screen	60
11. 4U library System Status screen	22	48. Configure Library: Encryption Activation screen	60
12. 4U library System Status screen showing media attention status	22	49. The Configure Library: Drive screen	62
13. 4U library System Status screen showing a power supply failure	23	50. Configure Library: Network Page	62
14. Configuration of a one - partition system	27	51. Warning Screen	63
15. Configuration of a two - partition system	28	52. The Configure Library: User Access screen	64
16. Configuration of a three - partition system	28	53. The Configure Library: Date and Time screen	65
17. Configuration of a four - partition system	29	54. The Configure Library: Logs and Traces screen	65
18. Examples of SCSI element addressing.	29	55. The Configure Library: Email Notification screen	66
19. Removing the plastic protective sheets from the library	36	56. Configure Library: SNMP page	67
20. Installing foot pads on the bottom of the library enclosure	38	57. 2U library left magazine	70
21. Shipping lock and label	39	58. 2U library right magazine.	70
22. Removing the Shipping lock and label	39	59. 2U library I/O station in the left magazine	71
23. Library shipping lock and label storage location on rear panel of library.	40	60. 4U library left magazines	71
24. Rack Kit A mounting hardware	41	61. 4U library right magazines	71
25. Rack Kit B mounting hardware	42	62. 4U library I/O station in the lower left magazine	72
26. Examples of EIA units for round hole and square hole installations	43	63. Finger Holes on back side of 4U library I/O station	73
27. Rear view of Rack Kit A which shows the narrow part of the rail located at the rear of the rack.	43	64. 2U Library Control Keys	82
28. Rear view of Rack Kit B shows a different mounting method	44	65. 4U Library Control Keys	82
29. Kit A (top picture with circles) showing rails installed. Rack Kit B is below showing the front view of this kit installed.	45	66. Operator Control Panel Menu Tree.	83
30. 2U library rack anchors and mounting brackets	46	67. Monitor: Library menu.	85
31. Close-up view of mounting of the anchors on both sides of the library	46	68. Monitor: Drive menu	87
32. 2U library side screws to remove	47	69. Example of a 4U Monitor: Inventory menu	89
33. Sliding the 2U library into the rack	48	70. Overview of inventoried cartridges: Left magazines of a 4U Library	89
34. Sliding the 4U library into the rack	48	71. Detailed information on cartridges residing in a magazine.	90
35. Securing the 2U library to the rack.	49	72. Control: I/O station menu	90
36. Securing the 4U library to the rack.	50	73. Control: Move Cartridges menu.	91
37. Attaching a SCSI host interface cable to the 2U library	51	74. Control: Magazine menu	91
		75. Control: Re-Inventory menu	92
		76. Configure: Logical Libraries menu	93
		77. Configure: Library menu	94
		78. Configure: Drive menu.	96
		79. Configure: Network menu	97
		80. Configure: Set Access PIN menu	98

81. Pound sign (#) shows accessible menus when access PIN is enabled but before it is entered	99	123. Service Library: Reboot page	135
82. Configure: Save/Restore menu.	100	124. The LTO Ultrium Data Cartridge	139
83. Configure: Set Date and Time menu	102	125. Ultrium Data and WORM Tape Cartridges	142
84. Configure: Path Failover	102	126. Sample bar code label on the LTO Ultrium 8 Tape Cartridge	144
85. Service: Library Verify menu	103	127. Setting the write-protect switch	145
86. Service: Run Tests menu	103	128. Double-boxing tape cartridges for shipping	146
87. Service: Service menu	104	129. Checking for gaps in the seams of a cartridge	147
88. Service: Display Contrast menu	105	130. A 250w power supply with LEDs	156
89. The 4U library Monitor Library: Library Identity page	107	131. A 80w power supply without LEDs	156
90. The 4U library Monitor Library: Drive Identity page showing one Ultrium 3 SAS half height V2 drive (#1) and one Ultrium 4 SAS half height drive (#2)	109	132. Access holes for the left magazine	175
91. The 4U library Monitor Library: Library Status page	110	133. Access holes for the right magazine	176
92. The 4U library Monitor Library: Drive Status page	112	134. Left magazine pulled out of the 2U library	176
93. The 2U library Monitor Library: Inventory page	113	135. Left Magazines pulled out of the 4U Library	177
94. The 4U library Monitor Library: Inventory page (Right Magazines)	114	136. ESD label	179
95. Manage Library: Move Media page	115	137. Shipping Lock and Label Storage Location	180
96. Manage Library: Perform Inventory page	115	138. Shipping Lock and Label	180
97. Manage Library: Release Magazine page	115	139. Library drive sled without ElectroStatic Discharge (ESD) springs (SCSI sled shown)	181
98. The 4U library Configure Library: General and Extended page	117	140. Library drive sled with ESD springs [1] (SAS sled shown)	181
99. The 4U library Configure Library: Logical Libraries page	118	141. Drive sled components (full height fibre drive in top position, half height SCSI drive in middle position, half height SAS drive in bottom position) on back panel of a 4U library	182
100. The 4U library Configure Library: Path Failover page	118	142. Pulling the drive sled out of the library (drive sled without ESD springs shown)	183
101. Path Failover license verification page	118	143. Pushing the drive sled into the library (drive sled without ESD springs shown)	184
102. Feature Activation Key screen	119	144. Diagrams for applying conductive tape for ESD protection to the back of a drive sled installed in a 2U or 4U library	184
103. Configure Library: Encryption Feature configuration screen	119	145. A power supply being removed from a 2U library	187
104. The Configure Library: Drives page for a 2U library	121	146. A Library Controller Card being removed from the library	188
105. The Configure Library: Drives page for a 4U library	121	147. Removing the two mounting bracket screws anchoring the library to the rack (one screw on each side of the library)	190
106. Configure Library: Network Page.	122	148. Foot pads installed on the bottom of the library enclosure	191
107. Warning Screen	123	149. Removing the shipping label and lock from the top of the library and storing on the rear panel	192
108. Configure Library: User Access page	124	150. Library shipping lock and label storage location on the rear panel of the library	192
109. The Configure Library: Date & Time page	125	151. Removing a drive sled from the library (drive sled without ESD springs shown)	193
110. Configure Library: Logs & Traces page	126	152. Drive sled taping diagrams	194
111. Configure Library: Event Notification page	126	153. A power supply being removed from a library	195
112. Configure Library: SNMP page	127	154. Removing a Library Controller Card from the library	196
113. Configure Library: Save/Restore page	129	155. Library front panel LEDs	197
114. No Cleaning Required	129	156. Access hole for the left magazine (facing rear of library)	198
115. No cleaning cartridge in library	129	157. Access hole for the right magazine (facing rear of library)	199
116. Service Library: Clean Drive page.	130	158. Left magazines pulled out of a 4U library (facing front of library)	200
117. Service Library: View Logs page	131		
118. Service Library: View Drive Logs screen	131		
119. Service: Save Drive Dump	132		
120. Service Library: Perform Diagnostics page	132		
121. Service Library: Perform Key Path Diagnostics page	133		
122. The Service Library: Upgrade Firmware page, showing one Ultrium 3 SAS Half Height V2 drive and one Ultrium 4 SAS Half Height drive.	135		

159. Mounting brackets and anchors for securing the library in a rack (one bracket and anchor on each side of the library)	201	162. Configuration of a two - partition system	206
160. Front view of rack showing screw placement	201	163. Configuration of a three - partition system	207
161. Configuration of a one - partition system	206	164. Configuration of a four - partition system	207
		165. Examples of SCSI element addressing	208

Tables

1. Minimum firmware levels for common library features	v	31. Cartridge Types and Colors	139
2. 2U library and 4U library front panel descriptions	2	32. Cartridge Data Capacity and Recording Formats	140
3. 2U library and 4U library rear panel descriptions	5	33. Nominal Cartridge Life: Load/Unload Cycles	140
4. Tape drive model and host interface type	8	34. Ultrium data cartridge compatibility with Ultrium tape drive	141
5. Library storage capacity and data transfer rate	8	35. Bar code label requirements for Ultrium tape drives and libraries	143
6. Physical Specifications	12	36. Cartridges and VOLSERS compatible with the Ultrium Tape Drives	143
7. Power Specifications	12	37. Location of the write-protect switch	145
8. Operation Specifications: Ultrium 8	12	38. Environment for operating, storing, and shipping the LTO Ultrium Tape Cartridge	148
9. Operation Specifications: Ultrium 7	12	39. Troubleshooting table	149
10. Operation Specifications: Ultrium 6	13	40. Power Supply LED Meanings	156
11. Operation Specifications: Ultrium 5	13	41. Main Error Codes	162
12. Operation Specifications: Ultrium 4	13	42. Sub error codes	167
13. Operation Specifications: Ultrium 3	14	43. Warning events	171
14. Environmental Specifications.	14	44. Shipping Lock/Shipping Label.	180
15. Host Drive Interface Support.	30	45. 2U library SCSI Element Types and Element Addresses.	203
16. Maximum bus length between terminators	31	46. 4U library SCSI Element Types and Element Addresses.	203
17. Recommended maximum quantity of drives per SCSI bus	32	47. 2U library SCSI element addresses for storage slots and drive slot (one logical partition with one drive).	204
18. Location criteria	35	48. 4U library SCSI element addresses for storage slots and drive slot (one logical partition with drives in slot 1 and slot 2)	204
19. Menu navigation shortcuts	75	49. TapeAlert Flags Supported by the Ultrium Tape Drive	211
20. Library Control Keys	82	50. Library Sense Keys, ASC and ASCQ	215
21. Detailed information on cartridges residing in a magazine.	90	51. LTO Tape Drive Sense Data	221
22. Factory Default Settings	100	52. SNMP Status Events	237
23. Web User Interface Menus	105		
24. Library Identity page elements.	106		
25. Drive Identity page elements	107		
26. Library Status page elements	109		
27. Drive Status page elements	110		
28. Configure Library: General page elements	116		
29. Configure Library: Specific page elements	116		
30. Drive Identity page elements	120		

Safety and environmental notices

When this product is used, observe the danger, caution, and attention notices that are contained in this guide. The notices are accompanied by symbols that represent the severity of the safety condition.

The sections that follow define each type of safety notice and give examples.

Danger and caution notices







Danger Notice



A danger notice calls attention to a situation that is potentially lethal or extremely hazardous to people. A lightning bolt symbol always accompanies a danger notice to represent a dangerous electrical condition.

Caution Notice

A caution notice calls attention to a situation that is potentially hazardous to people because of some existing condition. A caution notice can be accompanied by one of several symbols:

If the symbol is...	It means...
	A hazardous electrical condition with less severity than electrical danger.
	A hazardous condition that is not represented by other safety symbols.
	A hazardous condition due to the use of a laser in the product. Laser symbols are always accompanied by the classification of the laser as defined by the U. S. Department of Health and Human Services (for example, Class I, Class II).
	A hazardous condition due to mechanical movement in or around the product.
	A hazardous condition due to the weight of the unit. Weight symbols are accompanied by an approximation of the product's weight.
	A hazardous condition due to the unit's susceptibility to electrostatic discharge.

Laser Safety and Compliance

Before the library is used, review the following laser safety information.

Class I Laser Product

The product might contain a laser assembly that complies with the performance standards set by the US Food and Drug Administration for a Class I laser product. Class I laser products do not emit hazardous laser radiation. The library has the necessary protective housing and scanning safeguards to ensure that laser radiation is inaccessible during operation or is within Class I limits. External safety agencies reviewed the product and obtained approvals to the latest standards as they apply.

Performing the safety inspection procedure

Before you service the unit, complete the following safety inspection procedure.

1. Stop all activities between the host and the library's tape drives.
2. Turn off the power to the library by pushing in the **Power** button on the rear of the tape library for 4 seconds.
3. If the drives are SCSI attached, disconnect the SCSI cable and check the SCSI bus terminator for damage.
4. Unplug the library's power cord from the electrical outlet and the library's power supply unit.
5. Check the library's power cords for damage, such as a pinched, cut, or frayed cord.
6. If drives are SCSI attached, check the tape drive's SCSI bus (signal) cable for damage.
7. If drives are FC/SAS attached, check the tape drive's FC/SAS cable for damage.
8. Check the cover of the library for sharp edges, damage, or alterations that expose its internal parts.
9. Check the cover of the library for proper fit. It should be in place and secure.
10. Check the product label at the rear of the library to make sure that it matches the voltage at your outlet.

Rack safety

The following general safety information must be used for all rack-mounted devices.

DANGER



- Always lower the leveling pads on the rack cabinet.
- Always install stabilizer brackets on the rack cabinet.
- To avoid hazardous conditions because of uneven mechanical loading, always install the heaviest devices in the bottom of the rack cabinet. Always install servers and optional devices, starting from the bottom of the rack cabinet.
- Rack-mounted devices are not to be used as a shelf or workspace. Do not place any object on top of rack-mounted devices.
- Each rack cabinet might have more than one power cord. Be sure to disconnect all power cords in the rack cabinet before you service any device in the rack cabinet.
- Connect all devices that are installed in a rack cabinet to power devices installed in the same rack cabinet. Do not plug a power cord from a device that is installed in one rack cabinet into a power device that is installed in a different rack cabinet.
- An electrical outlet that is not correctly wired might place hazardous voltage on the metal parts of the system or the devices that attach to the system. It is the responsibility of the customer to ensure that the outlet is correctly wired and grounded to prevent an electrical shock.

CAUTION:



- Do not install a unit in a rack where the internal rack ambient temperatures might exceed the manufacturer's recommended ambient temperature for all your rack mounted devices.
- Do not install a unit in a rack where the air flow is compromised. Ensure that air flow is not blocked or reduced on any side, front, or back of a unit that is used for air flow through the unit.
- Consideration must be given to the connection of the equipment to the supply circuit so that overloading of the circuits does not compromise the supply wiring or overcurrent protection. To provide the correct power connection to a rack, refer to the rating labels on the equipment in the rack to determine the total power requirement of the supply circuit.
- (For sliding drawers) Do not pull out or install any drawer or feature if the rack stabilizer brackets are not attached to the rack. Do not pull out more than one drawer at a time. The rack might become unstable if you pull out more than one drawer at a time.
- (For fixed drawers) This drawer is a fixed drawer and must not be moved for servicing unless specified by the manufacturer. Attempting to move the drawer partially or out of the rack might cause the rack to become unstable or cause the drawer to fall out of the rack.

(R001)

CAUTION:



Removing components from the upper positions in the rack cabinet improves rack stability during relocation. Follow these general guidelines whenever you relocate a populated rack cabinet within a room or building:

- Reduce the weight of the rack cabinet by removing equipment, starting at the top of the rack cabinet. When possible, restore the rack cabinet to the configuration of the rack cabinet as you received it. If this configuration is not known, you must do the following:
 - Remove all devices in the 32U position and above.
 - Ensure that the heaviest devices are installed in the bottom of the rack cabinet.
 - Ensure that there are no empty U-levels between devices that are installed in the rack cabinet below the 32U level.
- If the rack cabinet you are relocating is part of a suite of rack cabinets, detach the rack cabinet from the suite.
- Inspect the route that you plan to take to eliminate potential hazards.
- Verify that the route that you choose can support the weight of the loaded rack cabinet. Refer to the documentation that comes with your rack cabinet for the weight of a loaded rack cabinet.
- Verify that all door openings are at least 760 x 2032 mm (30 x 80 in.).
- Ensure that all devices, shelves, drawers, doors, and cables are secure.
- Ensure that the four leveling pads are raised to their highest position.
- Ensure that there is no stabilizer bracket that is installed on the rack cabinet during movement.
- Do not use a ramp that is inclined at more than 10 degrees.
- When the rack cabinet is in the new location:
 - Lower the four leveling pads.
 - Install stabilizer brackets on the rack cabinet.
 - If you removed any devices from the rack cabinet, repopulate the rack cabinet from the lowest position to the highest position.
- If a long-distance relocation is required, restore the rack cabinet to the configuration of the rack cabinet as you received it. Pack the rack cabinet in the original packaging material, or equivalent. Also, lower the leveling pads to raise the casters off the pallet and bolt the rack cabinet to the pallet.

(R002)

Preface

This manual contains information and instructions necessary for the installation, operation, and service of the Dell™ PowerVault™ TL2000 Tape Library and TL4000 Tape Library.

Related Publications

Refer to the following publications for additional information.

- *Dell™ PowerVault™ TL2000 Tape Library and TL4000 Tape Library Getting Started Guide* provides installation information.
- *Dell™ PowerVault™ TL2000 Tape Library and TL4000 Tape Library SCSI Reference* provides supported SCSI commands and protocol governing the behavior of SCSI interface.
- *IBM Security Key Lifecycle Manager Knowledge Center*, located at <http://www-01.ibm.com/support/knowledgecenter/SSWPVP/welcome?lang=en>, contains information to help you install, configure, and use the IBM® Security Key Lifecycle Manager.

Product Description

The Dell™ PowerVault™ TL2000 Tape Library (2U library) and the Dell PowerVault TL4000 Tape Library (4U library) provide compact, high-capacity, low-cost solutions for simple, unattended data backup. The 4U library houses up to 48 tape cartridges (or 45 and an elective 3-slot I/O Station) in a compact 4U form factor with easy access to cartridges via four removable magazines. The 2U library houses up to 24 tape cartridges (or 23 and an elective 1-slot I/O Station) in a compact 2U form factor with easy access to cartridges via two removable magazines.

The TL2000/TL4000 Library supports LTO 3 tape drives with these interfaces: Small Computer Systems Interface (SCSI), SAS, Fibre Channel interface (FC). LTO 4 to LTO 7 Full Height and Half Height drives are Serial Attached SCSI interface (SAS), and Fibre Channel (FC). LTO 8 Half Height drives are Serial Attached SCSI interface (SAS), or Fibre Channel (FC).

Front Panel




Figure 1. Front panel of a 2U library




Figure 2. Front panel of a 4U library

Table 2 below contains front panel descriptions for both the 2U library in Figure 1 on page 1 and the 4U library in Figure 2.

Table 2. 2U library and 4U library front panel descriptions

Number	Item	Description
1	Power button	Pressing this button powers ON the library. Pressing and holding this button for 4 seconds will power OFF the unit (soft power down). No power switch or button can be found on the back panel of the library.
2	Front panel LEDs (left to right)	<ul style="list-style-type: none"> • Ready/Activity (Green LED) - It is illuminated any time the unit is powered ON and able to function. It should blink whenever there is library or drive activity, or when the library is in the process of powering up. • Clean Drive (Amber LED) - It is illuminated when the drive needs to be cleaned. The LED will be turned OFF after the drive is cleaned successfully. • Attention (Amber LED) - It is illuminated when there has been a failure that indicates a piece of media is incompatible with the drive, damaged, marginal, or invalid. It will be cleared when all invalid cartridges have been exported from the library. The amber LED may also be lit because a power supply or a power supply fan is failing, or a drive sled is defective, missing, or has been replaced by a different drive type. • Error (Amber LED) - It is illuminated when there is an unrecoverable library or drive failure. A message is displayed at the same time on the Operator Control Panel display.
3	Cartridge magazines	<ul style="list-style-type: none"> • The 2U library contains two cartridge magazines. <ul style="list-style-type: none"> – The left magazine can hold up to 12 cartridges (or 11 data cartridges and the elective 1-slot I/O Station.) – The right magazine can hold up to 12 cartridges. • The 4U library contains four cartridge magazines. <ul style="list-style-type: none"> – The upper left magazine can hold up to 12 cartridges. – The lower left magazine can hold up to 12 cartridges (or 9 data cartridges and the elective 3-slot I/O Station.) – The upper right magazine can hold up to 12 cartridges. – The lower right magazine can hold up to 12 cartridges.
4	Air vents	These vents draw cooler air into the library enclosure and allow warm air to escape, which helps keep the library at a normal operating temperature.

Table 2. 2U library and 4U library front panel descriptions (continued)

Number	Item	Description
5	Control keys	<ul style="list-style-type: none"> • UP (Λ) - The upper left button is used to scroll upward through menu items. • DOWN (v) - The lower left button is used to scroll downward through menu items. • CANCEL (X) - The upper right button is used to cancel a user action and return to the previous menu screen. • SELECT (v) - The lower right button is used to display a sub-menu or force an accessor action.
7	Operator Control Panel display	This component is a 128 X 64 monochrome graphic display.
8	I/O Station	<p>The Input/Output (I/O) Station is used to import and export cartridges into and out of the library.</p> <ul style="list-style-type: none"> • The 2U library has an elective 1-slot I/O Station. • The 4U library has an elective 3-slot I/O Station.

Rear Panel



Figure 3. Rear panel (drive sled only) of a half height Fibre Channel drive




Figure 4. Rear panel of a 4U library with full height Fibre Channel drive and half height SAS drives.




Figure 5. Rear panel of a 2U library with a full height dual port SAS drive

Table 3. 2U library and 4U library rear panel descriptions

Number	Item	Description
1	Power connector(s)	Both libraries require a 110/220 volt AC power connection. <ul style="list-style-type: none"> The 2U library has one power supply. The 4U library has a minimum of one power supply, but has the capability of adding a redundant power supply.
2	Host interface connectors	The library has one or more of the following host interface connectors on the drive sled: <ul style="list-style-type: none"> Fibre Channel connector SFF-8088 mini-SAS connector
3	Tape drive sled	This library supports the Ultrium 3 to Ultrium 7 full height tape drives and the Ultrium 8 half height tape drive. The tape drive in the library is packaged in a container called a drive sled. The drive sled is a customer replaceable unit (CRU), and is hot-pluggable, which is designed for easy removal and replacement.
4	Shipping lock and label storage location	The shipping lock, which secures the accessor during shipping, and associated label are stored on the rear panel of the library for future use. See “Removing and Storing the Shipping Lock” on page 38. Note: The shipping lock must be removed before powering ON the library to allow the accessor to function properly.
5	USB port	Used to save/restore library configuration information on a USB device.
6	Library Control Board (LCC) LED	An LED showing the status of the Library Control Board. LED flashing (1 flash per second) - normal operation
7	Serial port	This port is used to communicate serially with the library using an RJ-11 connector. For use by Service Personnel.
8	Ethernet port	This port is used to connect the library to a network. LED <ul style="list-style-type: none"> <i>10/100 Link</i> <ul style="list-style-type: none"> Description: Green: Link Integrity Flashing: Network synchronization/negotiation Steady (On): Good connection Off: No connection between NIC and hub <i>Activity</i> <ul style="list-style-type: none"> Description: Amber: Port traffic indicator Flashing: Network traffic present Steady (On): Heavy network traffic Off: No traffic
9	Tape drive LED	This LED indicates the current status of the drive. When the LED is green, it indicates normal drive activity.
10	Service Tag/Serial Number	The service tag and serial number on the pull-out label links the library to your warranty.
11	Fan vents	These vents allow air to escape from the power supply and tape drive sled.

Bar Code Reader

The bar code reader is an integral part of the library accessor. The bar code reader provides inventory feedback to the host application, Operator Control Panel display, and Web User Interface by reading cartridge bar code labels. The library stores the customized inventory data in memory.

Library firmware supports a 6 or 8 character volume serial number (VOLSER) on the bar code label on the tape cartridge. Bar code selection is available for libraries with library code 4.50 or greater.

Encryption

The LTO Ultrium 4 and later Tape Drives support Application Managed Encryption (AME), and Library Managed Encryption (LME), using T10 encryption methods, for SAS and Fibre Channel drives only. Data encryption is supported with LTO Ultrium 4 and later Data Cartridges only. Encryption is also supported with library firmware version 5.80 and higher and drive firmware version 77BE for LTO 4 and higher drive code level.

The encryption enabled drive contains the necessary hardware and firmware to encrypt and decrypt host tape application data. Encryption policy and encryption keys are provided by the host application or host server. A drive digital certificate is installed at manufacturing time. Each drive receives a unique serial number and certificate. The T10 application may validate each drive instance by checking the drive's digital certificate.



CAUTION:

The library must be offline from any user and all media must be removed from the drives before license keys are installed or any configuration modifications are made. Please refer to “Power ON/OFF” on page 20 and “Removing Cartridges from Magazine Slots” on page 175 for instructions to take the library offline and to eject media from the drives.

To prevent possible data loss due to a key management server failure, Dell recommends the use of a primary and secondary key management server. This configuration provides redundancy in the event the primary key management server is down or unavailable. Please refer to *IBM SKLM Knowledge Center* online at <http://www-01.ibm.com/support/knowledgecenter/SSWPVP/welcome?lang=en> for information on configuring a primary and secondary key management server for your library.

If the backup job fails due to a key management server failure, the job recovers if connectivity is restored to the key management server prior to expiration of the timeout set in the tape backup software application.

Enabling library-managed encryption on a PowerVault TL2000 or TL4000 is a 6 step process.

1. Upgrade the library and drive firmware to the latest versions. The firmware can be found at www.Dell.com/support.
2. Enable library-managed encryption on the library via the license key if not already licensed. Please refer to “Configure Library: Encryption” on page 118 for activation instructions.

If you purchased library-managed encryption at the time you purchased your library, a hard copy of the license key is provided with your library as a backup. If there are any issues with the license key for library-managed encryption purchased with the library, please visit <http://www.dell.com/tapeautomation> to obtain your license key. You will need the library serial number and worldwide node name to obtain the license key. Please refer to the following tables in this document for instructions on locating this information:

- Table 1.2 for library serial number
- Table 5.6 for library worldwide node name

If this does not resolve your issue, please contact Dell technical support.

3. Configure library-managed encryption on your library. Please refer to “Configure Library: Encryption” on page 118 for instructions.
4. Install the IBM SKLM application on the server designated as the key manager. Refer to the *IBM SKLM Knowledge Center* online for information.
5. Configure the IBM SKLM application. Refer to the *IBM SKLM Knowledge Center* online for information.

6. Start the IBM SKLM application. Refer to the *IBM SKLM Knowledge Center* online for information.

Note: All encryption settings should be configured or re-verified in the drive after any library or drive reset. This is because a new drive may have been added or an existing drive may have been swapped with another drive.

Supported Internet Protocols

The library supports the following Internet protocols:

- IPv4
- IPv6

To learn more about Internet protocols, visit <http://www.iana.org/>.

SNMP Messaging

Occasionally, the library may encounter a situation that you want to know about, such as an open magazine or a fault that causes the library to stop. The library provides a standard TCP/IP protocol called Simple Network Management Protocol (SNMP) to send alerts about conditions (such as need for operator intervention) over a TCP/IP LAN network to an SNMP monitoring station. These alerts are called SNMP traps. Using the information supplied in each SNMP trap, the monitoring station (together with customer-supplied software) can alert operations personnel of possible problems or operator interventions that occur.

SNMP Traps

SNMP traps are alerts or status messages that can be collected, monitored and used to proactively manage attached libraries using SNMP protocol with the host server(s). In summary, each trap provides the following information:

- **Product Identification** such as product name, description, manufacturer, model number, firmware level, and the URL that the trap is designated for.
- **Product Status** such as the severity of the trap, status (current and previous) and the time the trap occurred.
- **Library State** (physical device status) such as identification and status of devices that are monitored. In the case of the library, it would include enclosure, power supply, controller, magazine status, drive count, cartridge slot count, and I/O station count. Also included would be certain library statistics, and where appropriate, the fault FSC (fault symptom code) including the severity and description of that fault.
- **Drive Status** such as the identification of each drive in the library, firmware level, serial number and other address and status information.
- **Trap Definitions** such as library status change, open magazine, I/O accessed, hard fault information, drive cleaning requests, excessive retries and library returning to normal operations. For additional information, refer to Appendix G. "SNMP Status MIB Variables and Traps" on page G-1.
- **SNMP MIBs:** The library's Management Information Base (MIB) contains units of information that specifically describe an aspect of the system, such as the system name, hardware number or communications configuration. Status and error data is also gathered by MIBs and sent to one or more IP addresses defined during the SNMP configuration operation. Download the SNMP MIB file for this library from www.Dell.com/support.

Maximum Library Storage Capacity and Data Transfer Rate

Maximum library storage capacity and maximum data transfer rates are as follows:

Table 4. Tape drive model and host interface type

Tape Drive Model	Host Interface
Ultrium 8 Half Height drives	<ul style="list-style-type: none"> 8 Gb/s Fibre Channel - single port 6 Gb/s Serial Attached SCSI (SAS) - dual port
Ultrium 7 Full Height and Half Height drives	<ul style="list-style-type: none"> 8 Gb/s Fibre Channel - single port 6 Gb/s Serial Attached SCSI (SAS) - dual port
Ultrium 6 Full Height and Half Height drives	<ul style="list-style-type: none"> 8 Gb/s Fibre Channel - single port 6 Gb/s Serial Attached SCSI (SAS) - dual port
Ultrium 5 Full Height and Half Height drives	<ul style="list-style-type: none"> 8 Gb/s Fibre Channel - single port 6 Gb/s Serial Attached SCSI (SAS) - dual port
Ultrium 4 Full Height drives	<ul style="list-style-type: none"> 4 Gb/s Fibre Channel - single port 3 Gb/s Serial Attached SCSI (SAS) - dual port
Ultrium 4 Half Height V2 drives	<ul style="list-style-type: none"> 8Gb/s Fibre Channel - single port 6GB/s Serial Attached SCSI (SAS) - dual port
Ultrium 4 Half Height drives	<ul style="list-style-type: none"> 3 Gb/s SAS - single port
Ultrium 3 Full Height drives	<ul style="list-style-type: none"> Ultra160 SCSI LVD (depending on drive; single-ended (SE) is not recommended as it will severely degrade performance) 4 Gb/s Fibre Channel - single port
Ultrium 3 Half Height V2 drives	<ul style="list-style-type: none"> 6GB/s Serial Attached SCSI (SAS) - dual port
Ultrium 3 Half Height drives	<ul style="list-style-type: none"> 3 Gb/s SAS - single port

Table 5. Library storage capacity and data transfer rate

Characteristic	2U Library Specification	4U Library Specification
Maximum storage capacity - Ultrium 8 Data Cartridges	<ul style="list-style-type: none"> 24 data cartridges Native: 288 TB Compressed: 720 TB (2.5:1 compression) 	<ul style="list-style-type: none"> 48 data cartridges Native: 576 TB Compressed: 1440 TB (2.5:1 compression)
Maximum storage capacity - Ultrium 7 Data Cartridges	<ul style="list-style-type: none"> 24 data cartridges Native: 144 TB Compressed: 360 TB (2.5:1 compression) 	<ul style="list-style-type: none"> 48 data cartridges Native: 288 TB Compressed: 720 TB (2.5:1 compression)
Maximum storage capacity - Ultrium 6 Data Cartridges	<ul style="list-style-type: none"> 24 data cartridges Native: 60 TB Compressed: 150 TB (2.5:1 compression) 	<ul style="list-style-type: none"> 48 data cartridges Native: 120 TB Compressed: 300 TB (2.5:1 compression)
Maximum storage capacity - Ultrium 5 Data Cartridges	<ul style="list-style-type: none"> 24 data cartridges Native: 36 TB Compressed: 72 TB (2:1 compression) 	<ul style="list-style-type: none"> 48 data cartridges Native: 72 TB Compressed: 144 TB (2:1 compression)

Table 5. Library storage capacity and data transfer rate (continued)

Characteristic	2U Library Specification	4U Library Specification
Maximum storage capacity - Ultrium 4 Data Cartridges	<ul style="list-style-type: none"> • 24 data cartridges • Native: 19.2 TB • Compressed: 38.4 TB (2:1 compression) 	<ul style="list-style-type: none"> • 48 data cartridges • Native: 38.4 TB • Compressed: 75.2 TB (2:1 compression)
Maximum storage capacity - Ultrium 3 Data Cartridges	<ul style="list-style-type: none"> • 24 data cartridges • Native: 9.6 TB • Compressed: 19.2 TB (2:1 compression) 	<ul style="list-style-type: none"> • 48 data cartridges • Native: 19.2 TB • Compressed: 38.4 TB (2:1 compression)
Sustained native data transfer rate	<p>LTO 3 HH: 60 MBs, LTO 3 HH V2: 80 MBs LTO 3 FH: 80 MBs LTO 4 HH and FH: 120 MBs LTO 5 : 140 MBs LTO 6: 160 MBs LTO 7: 300 MBs LTO 8 HH: 300 MBs</p>	

Ultrium Tape Drives

This library supports the Ultrium 3 to Ultrium 8 Tape Drives. Each tape drive in the library is packaged in a container called a drive sled. The drive sled is a customer replaceable unit (CRU), and is designed for quick removal and replacement in the library.

The Ultrium 8 Half Height Tape Drive supports two SAS SFF-8088 connectors, or one LC Fibre Channel connector. The SFF-8088 SAS connectors on the Ultrium 8 tape drives are compatible with SAS-1 or SAS-2 cables.

The Ultrium 7 Tape Drive supports two SAS SFF-8088 connectors, or one LC Fibre Channel connector. The SFF-8088 SAS connectors on the Ultrium 7 tape drives are compatible with SAS-1 or SAS-2 cables.

The Ultrium 6 Tape Drive supports two SAS SFF-8088 connectors, or one LC Fibre Channel connector. The SFF-8088 SAS connectors on the Ultrium 6 tape drives are compatible with SAS-1 or SAS-2 cables.

The Ultrium 5 Tape Drive supports two SAS SFF-8088 connectors, or one LC Fibre Channel connector. The SFF-8088 SAS connectors on the Ultrium 5 tape drives are compatible with SAS-1 or SAS-2 cables.

The Ultrium 4 Full Height Tape Drives support SAS, or Fibre Channel interfaces. It features two SFF-8088 SAS connectors, or one LC Fibre Channel connector. The Ultrium 4 Half Height Tape Drive supports one SAS SFF-8088 connector. The Ultrium 4 Half High V2 Tape Drives support two SFF-8088 SAS connectors, or one LC Fibre Channel connector. The SFF-8088 SAS connectors on the Ultrium 4 tape drives are compatible with SAS-1 cables.

The Ultrium 3 Full Height Tape Drive supports LVD Ultra160, or Fibre Channel interfaces. It features two HD68 connectors or one LC Fibre Channel connector. The Ultrium 3 Half Height Drive supports one SAS SFF-8088 connector. The Ultrium 3 Half High V2 Tape Drive supports two SFF-8088 SAS connectors. The

SFF-8088 SAS connectors on the Ultrium 3 tape drives are compatible with SAS-1 cables.



Figure 6. Library drive sled without ESD springs (SCSI sled shown)




Figure 7. Library drive sled with ESD springs [1] (SAS sled shown)

Speed Matching

To improve system performance, the Ultrium 3 and later Tape Drives use a technique called *speed matching* to dynamically adjust its native (uncompressed) data rate to the slower data rate of the attached server.

Channel Calibration

The channel calibration feature of the Ultrium 3 and later Tape Drives customizes each read/write data channel for optimum performance. The customization enables compensation for variations in the recording channel transfer function, media characteristics, and read/write head characteristics.

Power Management

The Ultrium 3 and later Tape Drive's power management function controls the drive's electronics so that part of the electronics completely turn OFF when circuit functions are not needed for the drive's operation.

Media

The library uses Ultrium Tape Cartridges that provide up to 6000 GB native capacity (up to 15000 GB with 2.5:1 hardware data compression) for LTO 7 Tape Drives, up to 2500 GB native capacity (up to 6250 GB with 2.5:1 hardware data compression) for LTO 6 Tape Drives, up to 1500 GB native capacity (up to 3000 GB with 2:1 hardware data compression) for LTO 5 tape drives, up to 800 GB native capacity (up to 1600 GB with 2:1 hardware data compression) for LTO 4 tape drives, and up to 400 GB native capacity (up to 800 GB with 2:1 hardware data compression) for LTO 3 tape drives.

Ultrium 8 Tape Drives can read and write LTO Ultrium 8 and Ultrium 7 Data Cartridges. Ultrium 7 Tape Drives can read and write LTO Ultrium 7 Data Cartridges. Ultrium 7 tape drives can read and write LTO Ultrium 6 Data Cartridges at original Ultrium 6 capacities, and can also read LTO Ultrium 5 Data Cartridges with improved data rates. Ultrium 6 Tape Drives can read and write LTO Ultrium 6 Data Cartridges. Ultrium 6 tape drives can read and write LTO Ultrium 5 Data Cartridges at original Ultrium 5 capacities, and can also read LTO Ultrium 4 Data Cartridges with improved data rates. Ultrium 5 tape drives can read and write LTO Ultrium 5 Data Cartridges. Ultrium 5 tape drives can read and write LTO Ultrium 4 Data Cartridges at original Ultrium 4 capacities, and can also read LTO Ultrium 3 Data Cartridges with improved data rates. Ultrium 4 tape drives can read and write LTO Ultrium 4 Data Cartridges. Ultrium 4 tape drives can read and write LTO Ultrium 3 Data Cartridges at original Ultrium 3 capacities, and can also read LTO Ultrium 2 Data Cartridges with improved data rates. Ultrium 3 Tape Drives can read and write LTO Ultrium 3 Data Cartridges. Ultrium 3 Tape Drives can read and write LTO Ultrium 2 Data Cartridges at original Ultrium 2 capacities, and can also read LTO Ultrium 1 Data Cartridges with improved data rates of up to 20 MB/second native data transfer rate (40 MB/second with 2:1 compression).

Note: Ultrium 4 tape drives cannot read or write to Ultrium 1 tapes. Ultrium 5 tape drives cannot read or write to Ultrium 1 or Ultrium 2 tapes. Ultrium 6 tape drives cannot read or write to Ultrium 3, Ultrium 2 and Ultrium 1 tapes. Ultrium 7 tape drives cannot read or write to Ultrium 4, Ultrium 3, Ultrium 2 and Ultrium 1 tapes. Ultrium 8 tape drives cannot read or write Ultrium 6, Ultrium 5, Ultrium 4, Ultrium 3, Ultrium 2 and Ultrium 1 tapes.

Supported cartridges include:

- LTO Ultrium 12000 GB Data Cartridge (Ultrium 8)
- LTO Ultrium 6000 GB Data Cartridge (Ultrium 7)
- LTO Ultrium 2500 GB Data Cartridge (Ultrium 6)
- LTO Ultrium 1500 GB Data Cartridge (Ultrium 5)
- LTO Ultrium 800 GB Data Cartridge (Ultrium 4)
- LTO Ultrium 400 GB Data Cartridge (Ultrium 3)
- Write-Once-Read-Many WORM Data Cartridge (Ultrium 3, Ultrium 4, Ultrium 5, Ultrium 6, Ultrium 7, Ultrium 8)
- LTO Ultrium 200 GB Data Cartridge (Ultrium 2)
- 100 GB Data Cartridge (Ultrium 1; read only)
- LTO Ultrium Cleaning Cartridge

Important: Cartridges placed in the library must be labeled with the correct bar code labels. For additional information, see "Using Ultrium Media" on page 139.

Library Specifications

Physical Specifications

Table 6. Physical Specifications

Specification	2U library	4U library
Height	Rack mount 87.6 mm (3.44 in), stand-alone 97.6 mm (3.84 in)	Rack mount 175.2 mm (6.9 in), stand-alone 185.2 mm (7.3 in)
Width	447.5 mm (17.6 in.)	447.5 mm (17.6 in.)
Depth	Rack mount 740 mm (29.13 in), stand-alone 810 mm (31.9 in)	Rack mount 740 mm (29.13 in), stand-alone 810 mm (31.9 in)
Weight with 1 drive and without media	15.59 kg (34.37 lbs.)	21.32 kg (47 lbs.)
Weight with media	20.67 kg (45.57 lbs.)	31.71 kg (69.9 lbs.)

Power Specifications

Table 7. Power Specifications

AC power voltage	100-127 VAC; 200-240 VAC (4 - 2 A)
Line frequency	50-60 Hz

Operation Specifications

Table 8. Operation Specifications: Ultrium 8

Library with Ultrium 8 drive(s)	2U Library	4U Library
Maximum storage capacity	Maximum number of data cartridges: 24 Native: 288 TB Compressed: 720 TB (2.5:1 compression)	Maximum number of data cartridges: 48 Native: 576 TB Compressed: 1440 TB (2.5:1 compression)
Number of slots	24 (including I/O Station)	48 (Including 3 I/O Station slots)
Sustained native data transfer rate	Ultrium 8 Half Height Drive: 300 MB/s	
Drive types	Ultrium 8 Half Height Drive: Fibre Channel, SAS	
Interfaces	8 Gb/s Fibre Channel 6 Gb/s SAS	
*Host Interface Drive Transfer Rates may vary depending on host usage and interface utilization.		

Table 9. Operation Specifications: Ultrium 7

Library with Ultrium 7 drive(s)	2U Library	4U Library
Maximum storage capacity	Maximum number of data cartridges: 24 Native: 144 TB Compressed: 360 TB (2.5:1 compression)	Maximum number of data cartridges: 48 Native: 288 TB Compressed: 720 TB (2.5:1 compression)
Number of slots	24 (including I/O Station)	48 (Including 3 I/O Station slots)
Sustained native data transfer rate	Ultrium 7 Drive: 300 MB/s	
Drive types	Ultrium 7 Half Height Drive: Fibre Channel, SAS	

Table 9. Operation Specifications: Ultrium 7 (continued)

Library with Ultrium 7 drive(s)	2U Library	4U Library
Interfaces	8 Gb/s Fibre Channel 6 Gb/s SAS	
*Host Interface Drive Transfer Rates may vary depending on host usage and interface utilization.		

Table 10. Operation Specifications: Ultrium 6

Library with Ultrium 6 drive(s)	2U Library	4U Library
Maximum storage capacity	Maximum number of data cartridges: 24 Native: 60 TB Compressed: 150 TB (2.5:1 compression)	Maximum number of data cartridges: 48 Native: 120 TB Compressed: 300 TB (2.5:1 compression)
Number of slots	24 (including I/O Station)	48 (Including 3 I/O Station slots)
Sustained native data transfer rate	Ultrium 6 Drive: 160 MB/s	
Drive types	Ultrium 6 Half Height Drive: Fibre Channel, SAS	
Interfaces	8 Gb/s Fibre Channel 6 Gb/s SAS	
*Host Interface Drive Transfer Rates may vary depending on host usage and interface utilization.		

Table 11. Operation Specifications: Ultrium 5

Library with Ultrium 5 drive(s)	2U Library	4U Library
Maximum storage capacity	Maximum number of data cartridges: 24 Native: 36 TB Compressed: 72 TB (2:1 compression)	Maximum number of data cartridges: 48 Native: 72 TB Compressed: 144 TB (2:1 compression)
Number of slots	24 (including I/O Station)	48 (Including 3 I/O Station slots)
Sustained native data transfer rate	Ultrium 5 Full Height Drive: 140 MB/s Ultrium 5 Half Height Drive: 140 MB/s	
Drive types	Ultrium 5 Full Height Drive: Fibre Channel, SAS Ultrium 5 Half Height Drive: Fibre Channel, SAS	
Interfaces	8 Gb/s Fibre Channel 6 Gb/s SAS	
*Host Interface Drive Transfer Rates may vary depending on host usage and interface utilization.		

Table 12. Operation Specifications: Ultrium 4

Library with Ultrium 4 drive(s)	2U Library	4U Library
Maximum storage capacity	Maximum number of data cartridges: 24 Native: 19.2 TB Compressed: 38.4 TB (2:1 compression)	Maximum number of data cartridges: 48 Native: 38.4 TB Compressed: 75.2 TB (2:1 compression)
Number of slots	24 (including I/O Station)	48 (Including 3 I/O station slots)
Sustained native data transfer rate	Ultrium 4 Full Height Drive: 120 MB/s Ultrium 4 Half Height Drive: 120 MB/s	

Table 12. Operation Specifications: Ultrium 4 (continued)

Library with Ultrium 4 drive(s)	2U Library	4U Library
Drive types	Ultrium 4 Full Height Drive: Fibre Channel, SAS Ultrium 4 Half Height Drive: SAS, Fibre Channel	
Interfaces	Ultrium 4 HH Fibre Drive V2 (8Gb/s) Ultrium 4 HH SAS Drive V2 (6Gb/s) 4 Gb/s Fibre Channel 3 Gb/s SAS	
*Host Interface Drive Transfer Rates may vary depending on host usage and interface utilization.		

Table 13. Operation Specifications: Ultrium 3

Library with Ultrium 3 drive(s)	2U library	4U library
Maximum storage capacity	Maximum number of data cartridges: 24 Native: 9.6 TB Compressed: 19.2 TB (2:1 compression)	Maximum number of data cartridges: 48 Native: 19.2 TB Compressed: 38.4 TB (2:1 compression)
Number of slots	24 (including I/O Station)	48 (Including 3 I/O station slots.)
Sustained native data transfer rate	Ultrium 3 Full Height Drive: 80 MB/s Ultrium 3 Half Height V2 Drive: 80 MB/s Ultrium 3 Half Height Drive: 60 MB/s	
Drive types	Ultrium 3 Full Height Drive: SCSI, Fibre Channel Ultrium 3 Half Height Drive: Serial Attached SCSI (SAS)	
Interfaces	Ultra160 SCSI LVD 4 Gb/s Fibre Channel Ultrium 3 HH SAS Drive V2 (6Gb/s) 3 Gb/s SAS	

Environmental Specifications

Table 14. Environmental Specifications

Temperature	
Operating	10° to 35° C (50° to 95° F)
Storage, without cartridges	-30° to 60° C (-22° to 140° F)
Wet bulb, operating	26° C (79.0° F) maximum
Temperature shock immunity - maximum rate of change	10° C (18° F) per hour
Miscellaneous	
Dust concentration	less than 200 microgram/cubic meter
Maximum acoustical noise sound power levels LwAd in bels	6.6/6.8
Humidity	
Operating	15% to 80% RH non-condensing
Storage, without cartridges	10% to 90% RH non-condensing

Product Environment

The library is designed to operate in a general business environment.

The library meets the acoustical requirements for general business area category 2D. Category 2D states that the library should be installed a minimum of 4 m (13 ft.) from a permanent work station.

To allow for service access, install the library a minimum of 0.9 m (3 ft.) from all obstacles.

The library is a precision computer peripheral. To ensure maximum longevity of your library, locate the library away from dust, dirt, and airborne particulates:

- Keep the library away from high-traffic areas, especially if the floor is carpeted. Carpeting harbors dust and people walking on the carpet can cause the carpet fibers and the dust to become airborne.
- Keep the library out of printer/copier rooms because of toner and paper dust. Additionally, do not store paper supplies next to the library.
- Keep the library away from moving air caused by doorways, open windows, fans, and air conditioners.

Ensure that the machine covers are always kept closed to minimize any contamination from airborne particles.

Supported Device Drivers

The latest levels of device drivers can be downloaded by visiting www.Dell.com/support.

Note: The TL2000 and TL4000 libraries utilize the generic SCSI drivers in RHEL 4 and 5. Depending on the ISV you are using, you will use either the sg or st driver. Please refer to your ISV documentation for more information on which driver to use.

User Interfaces

This library has two user interfaces.

- Operator Control Panel - located on the front panel of the library
- “Web User Interface” on page 20 - accessed via a web browser

Operator Control Panel

The Operator Control Panel operates in two basic modes.

- **User Interaction mode** - This mode is employed when a user is pushing buttons on the Operator Control Panel.
- **System Driven mode** - This is the normal mode of operation. In this mode, the Operator Control Panel displays status associated with the actions that were caused from commands issued via the drive's internal (drive to library) serial interface.

When an Operator Control Panel button is pressed and released, the Operator Control Panel automatically transitions to User Interaction mode. User Interaction mode will continue until 3 minutes after a user stops pushing buttons, or the requested accessor action stops - whichever is longer. At which time, the Operator Control Panel will return to System Driven mode.

If necessary, the Operator Control Panel automatically transitions to the System Driven mode. When this occurs, the library must remember the previous function before the display mode changed. Therefore the next button pressed only transitions the Operator Control Panel to the User Interaction mode from the System Driven mode.

In case of the activated user security feature, the User Interaction mode is restricted to **Login** and **Monitor** menu items, until a user logs in with a correct password.

Operator Control Panel Philosophy

Operator Control Panel operation must obey some basic rules. These rules of operation constitute a philosophy.

- Any operational conflict between commands received over the host interface or the Web User Interface and those entered via the Operator Control Panel will be avoided with a reservation mechanism on a first-come, first-served basis. Any reservation by the Operator Control Panel is canceled by an Operator Control Panel logout or a timeout, which cancels the User Interaction Mode.
- Library firmware will not allow a user to select an impossible request. Those situations will include, but are not limited to:
 - Moving a cartridge from any source to a full slot
 - Moving a cartridge from an empty slot
 - Loading a cartridge from any source to a full drive
 - Unloading a cartridge from an empty drive
- Any error detected by the library or drive controller and not recoverable through predetermined firmware algorithms will be considered as fatal. An error code will be displayed on the Operator Control Panel display and the error LED will become illuminated. The error code remains on the Operator Control Panel until a push button is pressed, which causes the Operator Control Panel to return to the Home Screen.
- Numeric error codes are only used for unrecoverable, fatal errors, otherwise text status messages are displayed.

Power-ON Display

When the library powers ON or resets, it goes through several internally controlled processes that allow it to get initialized and running. These processes are called Power-On-Self-Test (POST). During the POST the Operator Control Panel displays information that may be meaningless until POST is complete. When the POST is finished, the library displays the Startup screen, then the Home screen.

The Startup screen is the first screen that appears after powering ON the library. It contains the following information:

- Firmware Rev: the current level of library firmware
- Drives: the total number of drives that the library can support
- Magazines: the total number of magazines in the library
- I/O Station: the current status of the I/O Station

While the library is going through its power up cycle you can monitor the state of the library via the OCP; however, you may not be able to make any configuration changes until the unit has completed its initialization routine. Attempts to make changes will be ignored.




Figure 8. Power-ON screens

Note about the Front Panel LEDs

All LEDs are updated during power ON and reset sequences. Upon power ON or software reset, the library illuminates all LEDs as soon as POST allows. When initialization starts, all LEDs are extinguished and the Ready/Activity LED flashes at a rate of approximately one second per cycle. When the mechanical initialization is complete, the Ready/Activity LED will stop flashing and be constantly illuminated.

If a library failure occurs, the Ready/Activity LED will turn OFF and the Error LED illuminates. The Operator Control Panel will also display an appropriate error code to help identify the failure.

The following are additional operational details of LEDs:

- The **Ready/Activity** LED is illuminated any time the unit is powered ON and functional. The Ready/Activity LED blinks whenever there is library or drive activity. This LED will also blink when the unit is OFFLINE.
- The **Clean** LED is illuminated when either a cleaning requested or a cleaning required flag has been issued by the drive. The LED is turned off after a successful drive cleaning operation.
- The **Attention** LED indicates one of the following conditions.

Problem	Action Required
Bad media	<ol style="list-style-type: none"> 1. Go to Monitor > Inventory to locate the defective cartridge. 2. Move the defective cartridge to the I/O Station. (Operator Control Panel: Control > Move Cartridges). 3. Open the I/O Station to remove the defective cartridge. (Operator Control Panel: Control > Open I/O).
Drive sled issues	Do one of the following: <ul style="list-style-type: none"> - Install a drive sled (see “Removing/Installing/Adding a Tape Drive Sled” on page 181). - Modify or resubmit Logical Library setting (Operator Control Panel: Configure > Logical Libraries or Web User Interface: Configure Library > Logical Libraries). - Restore defaults (Operator Control Panel: Configure > Restore Defaults or Web User Interface: Configure Library > Restore Defaults).
Redundant power supply failed	Complete the following steps: <ol style="list-style-type: none"> 1. Replace the failed power supply (see “Replacing a Power Supply” on page 186). 2. Cycle library power.
Power supply fan failure	Replace the power supply.

- The **Error** LED is illuminated when there is an unrecoverable (i.e. hard) drive or library failure. This will happen at the same time the hard error message is displayed on the screen and the LED will remain lit until the error state is resolved.

Note: From the Operator Control Panel, run **Service > Library Verify**. If Library Verify runs without error, the Error LED turns off. If the error persists, recycle power.

Input Modes

There are several ways to enter values in the different menu items. These values are selectable predefined values, toggle values (for example, ON/OFF) and numerical values like network addresses.

Selecting Predefined Values

1. To set the predefined values, press the SELECT button to select the menu item.
2. Using the UP and DOWN buttons, select one of the various predefined values for that item.
3. As soon as the Operator Control Panel display shows the correct value, press the SELECT button to apply the value.

Toggling Values

Toggle values are used to switch between two different states like *ON* and *OFF*.

1. After navigating to the menu item, press the SELECT button to select the menu item.
2. Using the UP and DOWN buttons, select one of the various predefined states for that item.
3. Press the SELECT button to apply the new state.

Entering Numerical Values

Numerical values are needed for network addresses, password entries and other configuration entries.

1. After navigating to the menu item, the current value is displayed and the cursor highlights the first digit of the value that can be changed.
2. For each digit to be changed in the value:
 - a. Use the UP and DOWN buttons to increment / decrement the digit.
 - b. Press the SELECT button to highlight the next editable digit.
3. Press the SELECT button at the last digit to apply the complete entry, or press the CANCEL button to cancel the whole edit process and maintain the original value.

Power ON/OFF

Part of the Operator Control Panel is the Power ON/OFF button. If the library is powered ON, pressing this button for 4 seconds will initiate a controlled power down of the library (soft landing). The following operations will take place before the library shuts down completely:

- The display indicates with an appropriate message that the shutdown is in progress.
- The library controller finishes all ongoing library and drive activities.
- The accessor is moved to its home position.
- The library controller switches OFF the power supply's secondary side.

Note: The shutdown process may be aborted by releasing the button before 4 seconds has passed.

Web User Interface

Many of the same operations performed from the Operator Control Panel can also be performed remotely using the Web User Interface.

The Web User Interface lets you monitor and control your library from any terminal connected to your network or through the World Wide Web (WWW). The Web User Interface hosts a dedicated, protected Internet site that displays a graphical representation of your library.

For static IP Addresses only: After establishing a connection to the library, open any HTML browser and enter the IP address of the library. To configure the Web User Interface, you must first set the IP address using the Operator Control Panel. Refer to "Configure: Network" on page 5-23 or "Configure Library: Network" on page 5-45.

Login

Important: Some options of the Web User Interface take the library OFFLINE. This inactive mode can interfere with host-based application software, causing data loss. Make sure the library is idle before attempting to perform any remote operations that will take the library OFFLINE.

To login, select the Role type and enter the correct password. The TL4000/TL2000 RMU screen shows Welcome : User, superuser, admin, or service after a successful login. The user can log out at any time by clicking on the "logout" text located in to top right corner of the RMU page.

- The User only has access to Monitor Library menus. The User account has only viewing privileges to the unit, not able to make any configuration changes.
- Superuser - The Superuser has access to the Monitor Library and Manage Library sections.
- The Admin user has access to all menus except those restricted to Service only. The Admin account has access to monitor, configure and run unit diagnostics (only exception is the advanced diagnostics reserved for service personnel only).
- Service personnel have access to all menus. The Service account has all the same privileges as the Admin account with the addition of advanced unit diagnostics.

Note: User and Superuser accounts must be enabled by the library administrator. These accounts are disabled by default.

Note: Passwords are case-sensitive.

Use the following password for logging in as an Admin user: **secure**

Each level affects which areas you have access to and what actions you can initiate from those areas.

For DHCP, use the Operator Control Panel to determine the IP Address assigned to your library. Navigate to **Monitor > Library > Identity**. Scroll down to **IP Address** and make note of the address. Enter the IP Address in your internet browser address field to access your library with the Web User Interface.

For IPv4 or Dual Stack IPv4 + IPv6, enter your library's static IP Address using the 0.0.0.0 format (four octets).

For IPv6, enter your library's static IP Address or Router Assigned IP Address using the following format: `http://[0:0:0:0:0:0:0:0]`. To determine your Router Assigned IP Address, navigate to **Monitor > Library > Network** on the Operator Control Panel.

If the dual IP stack is enabled (IPv4 + IPv6), IPv6 addresses cannot be configured in the OCP (Operator Control Panel) and must be configured through the Web User Interface. IPv6 addresses can only be configured in the OCP if the IPv6-only stack is enabled. In the case where the dual stack is enabled, the IPv6 address must be configured through the web interface (either using the IPv4 address or a known other IPv6 address).




Figure 9. Web User Interface login page

System Status

The **System Status** screen is always present after login giving current status of the library.



System Status	
View Legend	
03/28/2007 15:59:24	
Library Name	BOSTON141
Status	Ready
Drive 1 Status	Ready
Slots (Empty/Total)	22/23
I/O Station	Disabled
Library Time	15:59:24

Figure 10. 2U library System Status screen



Figure 11. 4U library System Status screen

Status icons indicate the following conditions.

- The green check mark indicates that the library is fully operational and that no user intervention is required.
- The yellow exclamation point indicates that user intervention is necessary, but that the library is still capable of performing operations. This condition can be caused by a media, library, redundant power supply, power supply fan, or a drive sled problem. To determine which, view the System Status screen.
- The red X indicates that user intervention is required and that the library is not capable of performing operations.
- If Auto Clean is enabled and a cleaning cartridge is **not** present, or if a cleaning cartridge is present, but not in a reserved slot, Auto Clean status will show **Chk Media/Rsvd Slot?** and **Status** will show a green check mark and the words **Media Attention**. The Auto Clean status disappears from the system status screen once Auto Clean has been properly configured. You will get messages if the cleaning media expires.




Figure 12. 4U library System Status screen showing media attention status

- The Power Supply Status will only appear if redundant power is being utilized with a 4U library, and the library was manufactured after March 14, 2008. If a redundant power supply fails, the System Status screen will appear as shown in Figure 13 on page 23.




Figure 13. 4U library System Status screen showing a power supply failure

Note: If your library has -04 level redundant power supplies (see label on top of power supply), it is normal for the one in “Standby” mode to turn its “Green” LED off. You can test this power supply by pulling the power connector from the other “Active” power supply. The power supply that was in “Standby” mode will now become “Active”, and its “Green” LED should light. If it doesn’t, replace it (refer to “Replacing a Power Supply” on page 186).

If your library has -05 level redundant power supplies, the “Green” LED will be ON on both power supplies. If both “Green” LEDs are not ON, replace the failed power supply (refer to “Replacing a Power Supply” on page 186).

Web User Interface Help Pages

Each screen on the Web User Interface has an associated Help page. To access a Help page, click on **Help** in the upper right corner of the screen. A new web page will open. Using the left navigation pane, select the desired Help page. To close the Help page, click the red **X** in the upper right corner of the screen.

Logging out of the Web User Interface

To log out of the Web User Interface, click **Logout** in the upper right corner of the current screen.

Important: If you click the **X** in the upper right corner of your internet browser window, you will not log out of the Web User Interface.

Installation Planning

Before installing your library, take time to review the following information.

Determining the Number of Logical Libraries

You can partition the library into as many logical libraries as there are drives in the library.

Basic Guidelines

- Each logical library must contain at least one drive.
- A library configuration of exactly one logical library equals the entire physical library.
- The library issues a warning to the user if media is moved across logical libraries.

Library Sharing

The library's default configuration allows a single application to operate the library through a single control path. Often, it is advantageous to be able to share a single library between heterogeneous (dissimilar) or homogeneous (similar) applications. Some applications (and some servers) do not allow for sharing a library between systems. Configurations can be created that enable the library to process commands from multiple heterogeneous applications and multiple homogeneous applications.

From the library's Web User Interface or Operator Control Panel, the following actions can be performed:

- Configure the library so that it is partitioned into separate logical libraries that independently communicate with separate applications through separate control paths. This configuration requires no special capabilities from the server or application. (For more information, see "Using Multiple Logical Libraries for Library Sharing.")
- Configure any single logical library (including the entire physical library) so that it is shared by two or more servers that are running the same application. Depending on the capabilities of the server and application, there are several ways to set up this type of configuration. Three typical ways include:
 - Configuring one server (host) to communicate with the library through a single control path; all other servers send requests to that server through a network.
 - Configuring all of the servers to communicate with the library through a single, common control path. This configuration is used in high-availability environments. Multi-initiator configurations are only supported by certain adapters and independent software vendors (ISVs). Check with your ISV.
 - Configuring a single logical library to communicate with multiple servers through multiple control paths. This configuration requires that control paths be added (see "Using Multiple Control Paths" on page 26).

Library configuration is not limited to the examples given above. Many configurations are possible, and can be designed according to your business needs. For additional information, refer to your host application documentation.

Using Multiple Logical Libraries for Library Sharing

Multiple logical libraries are an effective way for the library to simultaneously back up and restore data from heterogeneous applications. For example, the library can be partitioned so that it processes:

- Commands from Application A (about Department X) in Logical Library 1
- Commands from Application B (about Department Y) in Logical Library 2

In this configuration, the storage slots and drives in each logical library are dedicated to that library and are not shared among other libraries. Commands issued by the applications travel to the library through two unique control paths. Thus, the data processing for:

- Department X is confined to the storage slots and drives in Logical Library 1
- Department Y is confined to the storage slots and drives in Logical Library 2

Using Multiple Control Paths

In addition to creating multiple logical libraries, any logical library can be configured to have more than one control path. When configuring additional control paths, additional library sharing configurations and availability options are made possible. Access to the logical library is on a first-come, first-served basis and each control path for a logical library can accept commands while the library is in use by another control path. By default, only the first drive in a logical library will be LUN-1 enabled.

For a particular logical library, you can enable as many control paths as there are drives in that logical library.

Using Multiple Control Paths for Path Failover

Command failures and timeouts are costly. You want your library to run smoothly and efficiently. To ensure continued processing, the library offers an optional path failover feature that enables the host device driver to resend the command to an alternate control path for the same logical library. With control path failover installed, the alternate control path can include another HBA, SAN, or library control path drive. The device driver initiates error recovery and continues the operation on the alternate control path without interrupting the application.

Path Failover is a combination of two previous features: Control Path Failover (key entered at the library user interface) and Data Path Failover (key entered at the device driver interface). Go to “Minimum firmware levels for common library features” on page v to find the minimum firmware levels for path failover on your library.

The Path Failover feature can be installed by the customer.

For more information about using the path failover feature, see the *Dell PowerVault TL4000 Failover Configuration Guide*, included with the library documentation if purchased at point of sale and with the customer kit if purchased later.

Library Partitioning and Element Addressing

Library 4U systems with firmware versions of .80 and higher, and containing at least 2 drives, have the ability to configure two logical libraries (create two partitions). This partitioning has been expanded with the new library firmware and half-high drive integration. Now it is possible to configure 1, 2, 3 or 4 partitions in the 4U library. Additionally the 2U library can now be configured into one or two partitions. Each library must contain at least one drive per logical library (partition). In a partitioned library, the Operator Control Panel (OCP) only reports the status of logical library 1 in the main menu due to space limitations. The user must navigate to the logical libraries status in the OCP to get the information on the additional library partitions.

Partitioning of 2U Libraries

When two half height drives are installed in a 2U library, the library firmware will support partitioning in the same way that the 4U supports partitioning with two full height drives today. The first partition will contain the first magazine and the first drive. The second partition will contain the second magazine and the second drive. The I/O station (if configured as I/O) will be shared, as is done with the partitioned 4U library.

One full height drive is "Drive 1". When using half height drives, the first half height drive position will be called "Drive 1", The second half height drive position will be called "Drive 2."

Partitioning of 4U Libraries

When one or more half height drives are added to a 4U library, the drive naming will change. Currently, the first full height drive is "Drive 1" and the second full height drive is "Drive 2". When you consider that each full height drive slot may contain one or two half height drives, there are four potential drives in the space that used to occupy two. As a result, the first half height drive position, or the first full-high drive position, will be called "Drive 1". The second half height drive position will be called "Drive 2". The third half height drive position, or the second full height drive position, will be called "Drive 3". The fourth half height drive position will be called "Drive 4".

Important: In a 4U library a full height drive sled may be installed in drive slot 1 (drive will occupy slot 1 and slot 2) or drive slot 3 (drive will occupy slot 3 and slot 4). A full height drive sled should never be installed in drive slot 2 (drive will occupy slot 2 and slot 3).

Mixing of Drives

The library supports a mix of full height and half height drives in the same physical library and the same logical library. They support a mix of drives in the same physical library and the same logical library. They will also support a mix of SCSI, SAS, and Fibre Channel in the same physical library and the same logical library; however, mixing drive interface types in the same logical library is not recommended.

Important: Drives that do not share a common media type cannot be mixed in the same logical library. For instance, Gen 4 and Gen 7 drives cannot use the same media and so they cannot be mixed. LTO 4 media **cannot** be read on an LTO 7 drive.

Configuration of a 1 - Partition System

A one partition system configured for a 4U library contains any and all drives present in any drive positions, and it will contain all four magazines.

When configured with one logical partition, the Element Address assignments will be as follows: DTE assignments will be as shown in Figure 14.

STE assignments:

- Logical Library 1: Slot1 through 23 4096 (0x1000) through 4118 (0x1016) as shown in Figure 17 on page 29




Figure 14. Configuration of a one - partition system

Configuration of a 2 - Partition System

A two partition system must have at least two drives installed. One drive must be installed in either drive position 1 or drive position 2, and another drive must be installed in either drive position 3 or

drive position 4. Partition 1 contains any drives in drive position 1 and drive position 2. Partition 1 will also contain magazine 1 and magazine 2. Partition 2 contains any drives in drive position 3 and drive position 4. Partition 2 will also contain magazine 3 and magazine 4.

When configured with two logical partitions, the Element Address assignments will be as follows: DTE assignments will be as shown in Figure 15.

STE assignments

- Logical Library 1: Slot 1 through slot 21 4096 (x1000) through 4116 (0x1014)
- Logical Library 2: Slot 22 through slot 45 4096 (x1000) through 4019 (0x1017)




Figure 15. Configuration of a two - partition system

Configuration of a 3 - Partition System

A three partition system must have at least three drives installed. A drive must be installed in drive position 1, another drive must be installed in drive position 2, and another drive must be installed in either drive position 3 or drive position 4. Partition 1 will contain the first drive and the first magazine. Partition 2 will contain the second drive and the second magazine. Partition 3 will contain any drives in drive position 3 and drive position 4. Partition 3 will also contain magazine 3 and magazine 4.

STE assignments

- Logical Library 1: Slot 1 through slot 9 4096 (x1000) through 4104 (0x1008)
- Logical Library 2: Slot 10 through slot 21 4096 (x1000) through 4107 (0x100B)
- Logical Library 3: Slot 22 through slot 45 4096 (x1000) through 4119 (0x1017)




Figure 16. Configuration of a three - partition system

Configuration of a 4 - Partition System

A four partition system must have four drives. Each partition contains one drive and one magazine.

When configured with four logical partitions, the Element Address assignments will be as follows: DTE assignments will be as shown in Figure 17 on page 29.

STE assignments

- Logical Library 1: Slot 1 through slot 9 4096 (x1000) through 4104 (0x1008)
- Logical Library 2: Slot 10 through slot 21 4096 (x1000) through 4107 (0x100B)
- Logical Library 3: Slot 22 through slot 33 4096 (x1000) through 4107 (0x100B)
- Logical Library 4: Slot 34 through slot 45 4096 (x1000) through 4107 (0x100B)




Figure 17. Configuration of a four - partition system

SCSI Element Addressing

Every logical library starts at the first drive slot with the current assigned element start address (default value 256). It will be incremented from the bottom to the top slots for every drive slot. There is one exception to this addressing scheme to accommodate libraries currently in the field. A 4U library containing only full height drives will continue to have the addresses assignments 256 and 257, thus causing no interruptions to their operation. Drive slots will still be incremented by 1 for each drive slot position.

Note: Exchanging drives with different form factors will result in the library needing to be reconfigured.

4U Unit with only FH drives
(1 logical library)

SCSI Element	Slot
257	4
	3
256	2
	1

4U Unit with FH and HH drives
(1 logical library)

SCSI Element	Slot
258	4
	3
257	2
256	1

a77ug165

Figure 18. Examples of SCSI element addressing

The SCSI specification does not allow gaps in the SCSI element addressing. Special handling is needed for empty drive slots to fulfill the specification. Also temporarily removed drives need to have their addresses preserved to not confuse the attached host and host application. Generally only drives which are currently physically available or temporarily removed are reported. Empty (unused) slots located at the bottom or the top should not be reported, with an exception in case of a “removed” condition. A

drive slot which does not contain a drive, and has a position between used slots, needs to be reported as a SCSI element. To signal the host application that this slot is not usable, its ACCESS bit will be disabled.

Note: When reducing the number of drives in your library, update the Logical Library configuration. This will remove the Attention LED on the front panel and the exclamation mark on the Home screen indicating that a drive is missing.

Updating the Logical Library configuration will also update the drive element addressing and drive numbering. Replacing LTO half height drives with full height drives may require you to execute Restore Factory Defaults to correctly update the drive element addressing and drive numbering. See “Configure Library: Save/Restore Configuration” on page 128.

Logical Unit Number (LUN) Scanning

The library uses a single SCSI or Loop ID per drive and dual LUNs to control the tape drive (LUN 0) and library accessor (LUN 1). The library requires a Host Bus Adapter (HBA) that supports LUN scanning. If it is not enabled, your host system will not scan beyond LUN 0 and will fail to discover the library. It will only see the tape drive.

Important: Some HBAs, such as RAID controllers, do not support LUN scanning.

Host Interfaces

The 2U library and the 4U library can be attached to servers using the following interfaces:

- SCSI (LVD Ultrium 160)
- Serial Attached SCSI (SAS)
- Fibre Channel

Table 15. Host Drive Interface Support

Drive	SCSI (LVD Ultra 160)	SAS	FC
Ultrium 3 FH	X		X
Ultrium 3 HH		X*	
Ultrium 3 HH v2		X*	
Ultrium 4 FH		X*	X
Ultrium 4 HH		X*	X
Ultrium 4 HH v2		X*	X
Ultrium 5 HH		X*	X
Ultrium 6 HH		X*	X
Ultrium 7 HH		X*	X
Ultrium 8 HH		X*	X
Note: * = Dual Port SAS			

SCSI Interface

Note: Although the LVD hardware in the library is capable of operating in single-ended (SE) mode, SE operation is not recommended.

The library supports SCSI LVD attachments by using SCSI cables with 68-pin, HD-connectors. SCSI adapters must be properly terminated.

Before installing the SCSI cables, inspect all cables for damage. Do not install a cable if it is damaged. Report the damage immediately by contacting Dell customer care.

The maximum allowable length of your bus cabling depends on the type of SCSI bus that you use (LVD).

- For a server with an LVD SCSI bus:
 - Use a maximum system-to-device cable length of 10 m (33 ft) when attaching to the host interface board (SCSI) and one or two daisy-chained drives.
 - Use a maximum system-to-device cable length of 5 m (17 ft) when attaching to the host interface board (SCSI) and three to six daisy-chained drives.

Note: For maximum performance, it is recommended to have a maximum of one drive per SCSI bus.

- Only use the maximum system-to-device cable length of 25 m (82 ft) when attaching directly to one device (a point to point interconnection).

Note: Daisy-chaining is NOT recommended due to potential issues with SCSI bus performance, SCSI cables/connectors, and host bus adapters.

Physical Characteristics of the SCSI Interface

The library operates as a set of SCSI-3 devices. The Ultrium Tape Drives attach to servers using an LVD Ultra160 SCSI interface. Each SCSI drive sled uses shielded, HD68-pin connectors, and can attach directly to a 2-byte-wide SCSI cable.

Any combination of up to two initiators (servers) and up to four targets (devices) is allowed on a single SCSI bus if the following conditions are met:

- The SCSI bus is terminated properly at each end
- Cable restrictions are followed according to the SCSI-3 specification

Under the SCSI-3 protocol, this type of attachment allows cable lengths of up to 25 m (81 ft) with the appropriate cable and terminator. The table below gives the maximum bus length between terminators for the LVD interface.

Table 16. Maximum bus length between terminators

Type of Interconnection	Maximum Bus Length Between Terminators (in meters)
Point-to-point (1 server and 1 drive)	25
Multi-drop/daisy-chain (1 server and multiple drives)	12 (LVD)

Note: The maximum bus lengths stated in this table include the internal length of the bus.

For maximum performance, multiple SCSI buses may be required (see “Using Multiple SCSI Buses” on page 32), and Ultrium Tape Drives must be the only target devices that are active on the bus.

Note: Daisy-chaining is NOT recommended due to potential issues with SCSI bus performance, SCSI cables/connectors, and host bus adapters.

Note: For maximum performance, the quantity of tape drives that you can attach to one SCSI bus is limited, and is based on the type of bus that you have and the amount of data compression achieved. Ultra160 SCSI buses have a bandwidth of 160 MB per second. The table below lists the types of SCSI buses and gives the recommended maximum quantity of drives that you can attach.

Table 17. Recommended maximum quantity of drives per SCSI bus

Type of Drive	Ultra 160 SCSI Bus
LVD Ultrium 3	1 drive at 2:1 compression

Using Multiple SCSI Buses

The library has two SCSI connectors for each tape drive in the library. Each drive can be daisy-chained using a SCSI bus jumper.

Note: Daisy-chaining is NOT recommended due to potential issues with SCSI bus performance, SCSI cables/connectors, and host bus adapters.

Removal of any jumpers will create a SCSI bus for each drive installed in your library for attachment to multiple servers or to multiple SCSI adapter cards on one server. Remember that each SCSI bus must be terminated. Multiple SCSI buses may be required for maximum performance, depending on the application and data compression ratio. Note, however, that library (Medium Changer) control is required on at least one SCSI bus.

The Medium Changer device is required to be addressed via LUN 1 of the lowest-numbered drive position of each logical library. The Medium Changer device may additionally be addressed via LUN 1 of other drives in any logical library.

Any bus containing a Medium Changer device via LUN 1 of a drive is referred to as a control and data path. Any other bus is referred to as a data path. For information about control paths, see "Using Multiple Control Paths" on page 26.

Terminating the Bus

The SCSI bus and all of the wires in the SCSI cable must be properly terminated according to the SCSI standard.

You can plug an external terminator into one of the SCSI connectors. A terminator must be installed on the last device on each end of a string of multiple devices. A terminator is included with each SCSI Ultrium Tape Drive.

SCSI Differential - LVD

LVD tape devices support a bus length of 25 meters (82 ft.) point-to-point, and 12 meters (39 ft.) using multi-drop interconnection (daisy-chaining). For each daisy-chained device, the maximum cable length must be reduced by 0.5 meters (1.6 ft).

Important: A faster bus does not imply that an attached device will support that data rate, but that multiple devices can operate on the bus at that maximum speed. For a detailed table of SCSI terms and related specifications, refer to the SCSI Trade Association Web site at <http://www.scsita.org/terms/scsiterms.html>. To ensure best performance, if possible, avoid daisy-chaining.

SAS Interface

A drive sled with a SAS (Serial Attached SCSI) interface can be linked directly to controllers. SAS is a performance improvement over traditional SCSI because SAS enables multiple devices (up to 128) of different sizes and types to be connected simultaneously with thinner and longer cables; its full-duplex signal transmission supports up to 6.0 Gb/s. The SFF-8088 SAS connectors on the Ultrium 5 and later tape drives are compatible with SAS-1 or SAS-2 cables. The SFF-8088 SAS connectors on the Ultrium 3 and Ultrium 4 tape drives are compatible with SAS-1 cables. In addition, SAS drives can be hot-plugged.

SAS drives will auto-negotiate speed. There are no configurable topologies thus no feature switches associated with SAS. The SAS Ultrium 3 and Ultrium 4 half height drive sleds are single ported and can only be attached to one host. The Ultrium 4 and 5 full height, and the Ultrium 6, 7, and 8 half height

drives are dual ported, and are attached to a maximum of two hosts. Sharing between these two hosts is limited to active/passive cluster failover. LAN-free drive sharing is not supported. Ultrium 3 and Ultrium 4 SAS drive sleds use the SFF-8088 connection at the drive sled end and SFF-8088 or SFF-8470 at the host adapter end.

Fibre Channel Interface

Fibre Channel allows for an active intelligent interconnection scheme, called a Fabric, to connect devices. Everything between the ports on Fibre Channel is called the Fabric. The Fabric is most often a switch or series of switches that takes the responsibility for routing.

The library allows the selection of the following Fibre channel port behaviors:

- LN Port: (default setting) - an automatic configuration that tries arbitrated loop first, then switched fabric
- L Port - arbitrated loop
- N Port - point to point protocol in a switched fabric topology

Cables and Speeds

Ultrium 3 and later Fibre Channel tape drives use LC duplex fiber optics cables.

The maximum distances that the library supports on a Fibre Channel link is determined by the link speed, the type of fiber (50-micron or 62.5-micron), and the device to which the library is attached.

If the library attaches to an HBA (Host Bus Adapter), refer to the distances that are supported by the HBA. If the library attaches to a switch, the supported distances are:

- For a multi-mode 50-micron cable:
 - 1-Gbit link speed = up to 500 m (1640 ft)
 - 2-Gbit link speed = up to 300 m (984 ft)
 - 4-Gbit link speed = up to 175 m (574 ft)
 - 8-Gbit link speed = up to 150 m (492 ft)
- For a multi-mode 62.5-micron cable:
 - 1-Gbit link speed = up to 300 m (984 ft)
 - 2-Gbit link speed = up to 90 m (295 ft)
 - 4-Gbit link speed = up to 50 m (164 ft)
 - 8-Gbit link speed = up to 21 m (68 ft)

Note: Minimum distance for both 50 micron and 62.5 micron is 2 m (6 ft).

The library uses 50-micron cables internally. Therefore, you must use a 50-micron cable to attach to the library's port. To attach to a 62.5-micron SAN, you must attach the 50-micron cable to an active port, such as a port on a switch.

Using Zoning to Isolate Devices and Enhance Security

For security reasons, it is important to limit the devices that a server or servers can recognize or access. Also, some performance configurations and SAN configurations can result in a device being seen multiple times from the same server. For example, if you have two HBAs from the same server connected to an Ultrium Tape Drive in the library, the drive will be detected and appear as two logical devices. That is, there will be two special files for one physical device. Zoning can address these issues.

Zoning allows you to partition your SAN into logical groupings of devices so that each group is isolated from the other and can only access the devices in its own group. Two types of zoning exist: hardware zoning and software zoning. Hardware zoning is based on physical fabric port number. Software zoning is defined with a World Wide Node Name (WWNN) or World Wide Port Name (WWPN). While zoning

can be reconfigured without causing an outage, some zoning configurations can become complicated. The advantage of the library's WWNN implementation is that you can avoid the exposure of introducing zoning errors because you do not have to change the zoning configuration if a drive needs service or replacement.

Sharing on a Storage Area Network

With Storage Area Network (SAN) components, the possibilities for connecting multiple systems and multiple drives have increased. Not all software and systems are designed to share drives. Before you install a drive that would allow two systems to share it, check that the systems and their software support sharing. If your software does not support sharing, note that Fibre Channel switches have a zoning capability to form a SAN partition. For systems that do not cooperate, use zoning to prevent the systems from sharing the same drive. You can remove zoned partitions as you upgrade software and system levels.

Installation and Configuration

Note: Review the information in "Installation Planning" before installing your library.

To install a desktop or rack mounted 2U library or 4U library, perform the procedures in this chapter in the order they are presented.

Using the Library Configuration Form

Before beginning the installation and configuration of your library, make a copy of the Appendix G, "Library Configuration Form," on page 239. Enter library information (such as serial numbers, types of drives, etc.) and configuration settings on the Library Configuration Form and store in a safe location for future reference. Be sure to update this form any time changes are made to your library hardware or configuration.

Installing Your Library

Complete these procedures to install your library hardware.

1. "Choosing a Location."
2. "Unpacking the Library" on page 36.
3. "Verifying the shipment" on page 36.
4. "Installing the Library Foot Pads (for Desktop Installation ONLY)" on page 37.
5. "Removing and Storing the Shipping Lock" on page 38.
6. "Rackmounting the Library (for Rack Installation ONLY)" on page 40.
7. "Connecting the Host Interface Cable" on page 50.
8. "Connecting a Power Cord" on page 52.

Choosing a Location

Choose a location that meets the following criteria:

Table 18. Location criteria

Criteria	Definition
Room temperature	10° - 35° C (50° - 95° F) Note: If the temperature in the room where the library will be installed varies by 15° C (30° F) from the room where the library was stored, allow the library to acclimate to the surrounding environment for at least 12 hours before unpacking it from the shipping container.
Power source	<ul style="list-style-type: none">• AC power voltage: 100-127 VAC; 200-240 VAC (4 - 2 A)• Line frequency: 50-60 Hz Note: The 4U library requires two separate power sources to implement redundant power. Place the library near an AC outlet. The AC power cord is the product's main AC disconnect device and must be easily accessible at all times. Two separate power sources must be available for redundant power.
Air quality	The library should be placed in an area with minimal sources of particulate contamination. Avoid areas near frequently used doors and walkways, stacks of supplies that collect dust, printers, and smoke-filled rooms. Excessive dust and debris can damage tapes and tape drives.
Humidity	15-80 % RH non-condensing

Table 18. Location criteria (continued)

Criteria	Definition
Clearance	<ul style="list-style-type: none"> • Back: Minimum of 15.4 cm (6 inches) • Front: Minimum of 30.8 cm (12 inches) • Sides: Minimum of 5.08 cm (2 inches)
Rack requirements	Standard 19-inch rack with: <ul style="list-style-type: none"> • 2U (88.90 mm/3.5 in.) of clearance for a 2U library • 4U (177.8 mm/7 in.) of clearance for a 4U library Rackmounting the library is optional.

Unpacking the Library

1. Clear a work surface to unpack the library.
2. Open the shipping container and carefully remove the shipping materials from the top of the library. Remove the accessory package and set it aside.

Note: Once the drive is unpacked, **save and store** the packaging materials for future moves or shipping.

3. Lift the library out of the carton and remove the bag from the library. Remove the foam cushion from the back of the library. Save the packaging materials for future use.

Important: Do not place the library on the front panel or the rear panel as this may damage the library. The display should NOT be touched during the removal of the unit from the packaging.

4. Remove all clear plastic protective sheets from the library.



Figure 19. Removing the plastic protective sheets from the library

Verifying the shipment

Verify that the following items are included in your library shipment:

- With every library:
 - Power cord
 - Bar code labels
 - Foot pads (for desktop installation)
- With every library that contains a SCSI drive:
 - SCSI terminator (one per SCSI drive)
 - SCSI library-to-host cable (if ordered by customer)
- With every library that contains a Fibre Channel drive:
 - Fibre Channel library-to-host/switch cable (if ordered by customer)

- With every library that contains a SAS drive:
 - SAS library-to-host cable (if ordered by customer)
- Rack Mount Kit

Important: If your library did not contain preinstalled drives, then install them now. Refer to “Removing/Installing/Adding a Tape Drive Sled” on page 181 for instructions on installing your tape drives.

Installing the Library Foot Pads (for Desktop Installation ONLY)

If you intend to install your library in a rack, skip this step and proceed to “Removing and Storing the Shipping Lock” on page 38.

Important: Operating your library on a flat surface without foot pads may damage your library or cause it not to function properly.

Six foot pads must be installed on the bottom of the library before the library can be used as a desktop unit.

To install the library foot pads:

1. Being very careful, lay the library on its side.
2. Peel the adhesive from the back of each foot pad.
3. Install the foot pads on the bottom of the library enclosure by pressing each foot into one of the six areas (**1**) as shown in the figure below.




Figure 20. Installing foot pads on the bottom of the library enclosure

4. Carefully return the library to an upright position.

Important: Do not place any objects on top of the library.

Removing and Storing the Shipping Lock

Important: The shipping lock, which prevents the library accessor from moving during shipment, **must be removed before the library is powered ON.**

The shipping lock is held in place with a label and is located in the top center of the library. After the shipping lock is removed, it should be stored on the right side of the back panel of the library for future use.

To remove and store the shipping lock:

1. Remove the blue label (**2**) that is securing the lock (**1**) to the top of the library, then remove the lock (see Figure 21 on page 39).



Figure 21. Shipping lock and label




Figure 22. Removing the Shipping lock and label

2. Store the lock (**1**) and label (**2**) on the rear panel of the library as shown in Figure 23 on page 40.



Figure 23. Library shipping lock and label storage location on rear panel of library

Rackmounting the Library (for Rack Installation ONLY)

The 2U library and the 4U library are easily installed into a standard 19-inch rack system. The 2U library requires 2U (3.5 in.) of space. The 4U library requires 4U (7 in.) of space.

If you are not rackmounting your library, skip this procedure and go to “Attaching the Library to a Server” on page 50.

Important: A 2U library weighs 15.59 kg (34.37 lbs.) with one drive and without media. A 4U library weighs 21.32 kg (47 lbs.) with one drive and without media.

To reduce the risk of personal injury or damage to the library:

1. observe local health and safety requirements and guidelines for manual material handling,
2. obtain adequate assistance to lift and stabilize the library during installation or removal, and
3. always remove all cartridges to reduce the overall weight of the library.

To install your library in a rack, perform the following steps.

1. Verify which rack kit was included in your shipment. Although there are two different rack kits, the steps to install them are the same. After verifying which Rack Kit you received, see Figure 24 on page 41 for the installation steps.




Figure 24. Rack Kit A mounting hardware

a77ug275

a. Rack Kit A: The following parts make up Rack Kit A.

- Packaged in cardboard material:
 - 2 rails (not shown) See Figure 27 on page 43 for a graphic of the rails.
 - 2 mounting brackets (**1** in Figure 24)
- Packaged in the small bag with no label:
 - 1 Torx wrench (**5** in Figure 24)
 - 2 anchors (**4**)
 - 2 countersunk screws for securing the anchors (**6**)
 - 2 small countersunk screws for securing the tops of the mounting brackets (**7**)
 - 2 large screws to secure the mounting brackets to the rack (**8**)
- Packaged in the small bag with "Round Hole" on the label: 9 screws to be used on racks with round holes. (**2**)
- Packaged in the small bag with "Square Hole" on the label: 9 screws to be used on racks with square holes. (**3**)

Note: Eight (8) screws are needed for the installation. One additional screw is provided for security.




Figure 25. Rack Kit B mounting hardware

a77ug292

b. Rack Kit B: The following parts make up Rack Kit B.

- Packaged in plastic material:
 - 2 rails (not shown) See Figure 28 on page 44 for a graphic of the rails.
 - 2 mounting brackets with captive thumb screws (**1** in Figure 25)
 - Packaged in small bags and labeled with part numbers:
 - 1 Torx wrench (**5** in Figure 25)
 - 2 anchors (**4**)
 - 2 countersunk screws for securing the anchors (**6**)
 - 2 small countersunk screws for securing the tops of the mounting brackets (**7**)
 - Packaged in the small bag 4 rail mounting screws to be used on racks with round or square holes (**8**) .
 - 12 black plastic square plugs for covering rack holes for the 4U library application (**2**)
 - 12 black plastic round plugs for covering rack holes for the 4U library application (**3**)
2. Determine the location in your rack for your library to be installed and, using a pencil, mark the location on each vertical rail in your rack.

Note: A 2U library requires 2U (3.5 in.) of rack space. A 4U library requires 4U (7 in.) of rack space.




Figure 26. Examples of EIA units for round hole and square hole installations

1	Two EIA units for round hole and square hole installation	3	Wide Gaps within the EIA unit
2		4	Narrow Gaps between EIA units

- Using the screws for your rack type (round holes or square holes) and a #2 Phillips screwdriver and ensuring that the flange on each rail points toward the other to form a shelf, secure one rail to each side of the rack in your chosen rack location. Secure both the front and back of each rail to the rack. The narrow end of each rail goes to the rear of the rack. The rails extend to fit a variety of rack depths. Each rail requires 2U of rack space (**1** in Figure 27).





Figure 27. Rear view of Rack Kit A which shows the narrow part of the rail located at the rear of the rack.



at7ug274

Figure 28. Rear view of Rack Kit B shows a different mounting method



a77ug196



a77ug271

Figure 29. Kit A (top picture with circles) showing rails installed. Rack Kit B is below showing the front view of this kit installed.

Note: The rail must be fastened with the bottom of the rail parallel to floor and at the same level.

4. Using the Torx wrench included in your shipment, remove the screws (**1**) as shown in Figure 30 on page 46. Screw locations on the 4U library are similar.




Figure 30. 2U library rack anchors and mounting brackets

5. Install the library rack anchors (**2**) as shown in Figure 30 on each side of your library using the longest counter-sunk screws included in the rack kit.



Figure 31. Close-up view of mounting of the anchors on both sides of the library






Figure 32. 2U library side screws to remove

6. Install the library mounting brackets (**1**) as shown on the 2U library on each side of the library using the screw that was removed from your library and an additional short, counter-sunk screw included in the rack kit. (The 4U rack anchors and mounting brackets are similar.)
7. With library rack anchors and mounting brackets installed, slide the library onto the rails (as shown in Figure 33 on page 48 and Figure 34 on page 48). Gently push the library into the rack to lock the REAR anchors installed on each side of the library. When the library stops, the front mounting brackets will be flush with the vertical rack rails.



a77ug267


Figure 33. Sliding the 2U library into the rack



a77ug266

Figure 34. Sliding the 4U library into the rack

- Using a #2 Phillips screwdriver, secure the library to the rack (see Figure 35 on page 49 or Figure 36 on page 50) by placing a screw in the center hole of each mounting bracket and tightening them (**1**).



a77up268

Figure 35. Securing the 2U library to the rack




Figure 36. Securing the 4U library to the rack

9. Install either the round or the square rack hole covers for the 4U library as shown in Figure 36. There are 6 covers for each side for a total of 12.

Attaching the Library to a Server

The 2U library and the 4U library can be attached to servers using the following interfaces:

- SCSI (LVD Ultra 160)
- Fibre Channel
- Serial Attached SCSI (SAS)

Connecting the Host Interface Cable

To connect the host interface cables to the library:

1. It is recommended that you shut down and turn OFF the associated server. Turn OFF all attached devices. Remove the power cables from the server and all attached accessories.

Important: Failure to remove the power cords from these devices before connecting the host interface cable could result in damage to the library.

2. For a SCSI library, attach one end of the host interface cable to one of the connectors on the back panel of the library (see **1** in Figure 37 on page 51). For a Fibre Channel library, attach one end of the host interface cable to the connector on the back panel of the library (see **4** in Figure 38 on page 51). For a Serial Attached SCSI (SAS) connected library, attach the host end of the SAS cable to the SAS HBA (see **2** in Figure 39 on page 51). Full high drives will have dual SAS connectors. Half high drives will have one SAS connector. Unused SAS connectors do not need to be terminated.




Figure 37. Attaching a SCSI host interface cable to the 2U library




Figure 38. Attaching host interface cables to the 4U library. THE CONFIGURATION SHOWN IN THIS FIGURE IS USED FOR EXAMPLE ONLY. THIS CONFIGURATION IS NOT SUPPORTED.




Figure 39. Attaching a SAS interface cable to the 2U library

3. Attach the other end of the host interface cable as follows:
 - For a SCSI library, connect the host interface cable to the connector on the SCSI host bus adapter or to the connector on the previous device on the SCSI bus. Attach the terminator (**3** in Figure 37) to the remaining SCSI connector on the back panel of the library, if the library is the last or only

device on the SCSI bus. Otherwise, attach one end of a SCSI cable to the remaining port and the other end to the next device on the SCSI bus. Make sure that the last device on the SCSI bus is properly terminated.

Note: Only cables and terminators specified for Ultra160 or Ultra320 use or labeled as Multi Mode should be used.

Note: The host bus adapter should be LVD SCSI. A single-ended (SE) SCSI host bus adapter will work, but will severely degrade performance, and limit cable length. If there are any SE devices on the same SCSI bus, the entire SCSI bus will negotiate down to SE speed and severely degrade performance.

- For a Fibre Channel library, connect the host interface cable to the host or to a switch.
 - For a SAS library, connect the Host Interface Cable to the host HBA, using a direct SFF-8088 connection, or an interposer as required. Unused SAS connectors do not need termination.
4. Plug the network ethernet cable (**2** in Figure 37 on page 51, **5** in Figure 38 on page 51, or **3** in Figure 39 on page 51) into the ethernet port on the back panel of the library. If the ethernet connection is directly attached to a server or laptop, a crossover ethernet cable may be required.

Note: It is the customer's responsibility to supply the crossover cable if one is required.

Connecting a Power Cord

Attention: This product can ONLY be used with an approved power cord for your specific geographic region. Use of an unapproved power cord may result in:

- not meeting individual country specific safety requirements;
- overheating with potential personal injury and/or property damage; and
- a fracture resulting in the internal contacts being exposed, which potentially could subject the user to a shock hazard.

For every power supply in the library, complete the following steps.

1. Remove the protective label from the power receptacle on your library.




Figure 40. Removing the protective label from the power receptacle

2. Plug one end of the power cord (**6** in “Connecting the Host Interface Cable” on page 50) into each power supply connector on the back panel of the library.
3. Plug the other end of each power cord into the nearest properly grounded power outlet. Use separate power sources for each power supply for redundant power.

Attention: To disconnect all power from the library, remove the power cord from each outlet. The power button removes power from portions of the library and the drives, but the power supplies still have AC power at their inputs.

4. Remove the protective plastic on the exterior surfaces of the library.

- Turn ON the library using the power button. Check the Operator Control Panel display to make sure the library is receiving power. If it is not, check the power connections and your power source. During the Power-On Self Test (POST), all four LEDs are illuminated briefly, followed by a flashing Ready LED. When the initialization sequence is complete, the Home screen (see “Power-ON Display” on page 18) will be displayed.

Configuring Your Library

Note: Review the information in "Installation Planning" before configuring your library.

The library can be configured using the Operator Control Panel and/or the Web User Interface. The recommended method for configuring your library is using the Web User Interface.

For complete detailed configuration information on all of the functions available on your library using both the Operator Control Panel and the Web User Interface, see “Operations” on page 75. For default library settings, see “Configure: Save/Restore” on page 99

Choosing Your Configuration Method

If you choose to use the factory defaults for your library configuration, go to “Using Factory Defaults as Your Configuration.”

If you choose to use the Web User Interface for configuring your library, go to “Configuring Your Library using the Web User Interface.”

If you choose to use the Operator Control Panel for configuring your library, go to “Configuring Your Library using the Operator Control Panel” on page 68.

Write down all library configuration settings on the Appendix G, “Library Configuration Form,” on page 239 for future reference.

Using Factory Defaults as Your Configuration

The table below shows the main default library settings. If you wish to use the defaults, no other changes need to be made before using your library

Item	Default Setting
Logical Libraries	1
Active Slots	Maximum
I/O Slots	Enabled
DHCP	Enabled
Internet Protocol	IPv4 Only
Bar Code Label Length	8
Library Mode	Random
AutoClean	Disabled
Encryption	Application Managed Encryption (AME)

For a full list of factory defaults, see “Configure: Save/Restore” on page 99.

Configuring Your Library using the Web User Interface

To configure your library using the Web User Interface, complete the following procedures:

- “Establishing Remote Access to Your Library” on page 54

2. "Logging on to the Web User Interface" on page 55
3. "Verifying/Updating Firmware" on page 56
4. "Choosing General Library Settings" on page 57
5. "Choosing the Number of Logical Libraries for Your Library" on page 58
6. "Entering Path Failover Feature Activation Key" on page 59
7. "Setting Up Encryption" on page 60
8. "Choosing Drive(s) Interface Identification/Settings" on page 61
9. "Entering Library Network Settings" on page 62
10. "Entering User Access Information using the Web User Interface" on page 64
11. "Entering Date and Time using the Web User Interface" on page 65
12. "Configuring Logs and Traces using the Web User Interface" on page 65
13. "Entering Email Notification Information using the Web User Interface" on page 66
14. "Configuring SNMP settings" on page 66
15. "Testing encryption configuration for Library Managed encryption" on page 68
16. "Restoring Factory Default Settings using the Web User Interface" on page 68
17. "Logging out of the Web User Interface" on page 23
18. "Setting the Operator Control Panel Access PIN using the Operator Control Panel" on page 98

Establishing Remote Access to Your Library

Static library network settings must be entered using the Operator Control Panel before the library can be accessed remotely using the Web User Interface. If your system is serviced by DHCP (Dynamic Host Configuration Protocol) server, the network parameters will be automatically set. Once remote access has been established, you can complete the configuration of your library using the Web User Interface.

1. Access the **Configure** menu using the Operator Control Panel.
 - a. From the screen that shows the library logo (Home screen), press either the UP or DOWN button to get to the Main Menu.
 - b. Press the DOWN button to select **Configure**.
 - c. Press the SELECT button to display the **Configure** menu.
2. Press the DOWN button to highlight the **Network** menu.
3. Press the SELECT button to display the **Network** screen.
4. Select IP STACK, and press the SELECT button to highlight the Internet Protocol field.
 - a. Press the DOWN or UP button to scroll through the Internet Protocol options.
 - b. Press the SELECT button on the desired Internet Protocol.

If you select IPv6 protocol, the Configure Network menu will include options for Stateless Autoconfig and Prefix length.

- Stateless Autoconfig:
 - Press the DOWN button to highlight Stateless Autoconfig.
 - Press the SELECT button to highlight the Stateless Autoconfig option field.
 - Press the DOWN button to scroll through the Stateless Autoconfig options.
 - Press the SELECT button to apply the option.
 - Prefix Length:
 - Press the DOWN button to highlight Prefix Length.
 - Press the SELECT button to highlight the Prefix Length option field.
 - Press the UP or DOWN buttons to scroll through the Prefix Length digits.
 - Press the SELECT button to apply the Prefix Length digits.
5. If you do **not** want to select DHCP as your library network setting, skip this step and proceed to the next step. If you want to select DHCP as your library network setting, complete the following steps:

- a. Press the DOWN button to highlight DHCP.
 - b. Press the SELECT button to highlight the **DHCP** field.
 - c. Press the DOWN button to select **ON**.
 - d. Press the SELECT button to apply your selection.
 - e. Skip to Step 7.
6. Press the DOWN button to select **IP Address**. For IPv4 only, enter only an IPv4 address. For IPv6 only, enter only an IPv6 address. For IPv4 & IPv6, enter an IPv4 address and an IPv6 address.
 - a. Press the SELECT button to highlight the **IP Address** field.
 - b. Press the UP or DOWN button to select the digit(s) in the first octet of your library's IP Address.
 - c. Press the SELECT button to highlight the digit(s) in the next octet of your IP Address.
 - d. After entering the digits for the last octet, press the SELECT button to apply your entries.
 7. Press the DOWN button to select **Netmask**. For IPv4, enter only an IPv4 Netmask address. For IPv6, enter only an IPv6 Netmask address. For IPv4 & IPv6, enter both IPv4 and IPv6 Netmask addresses.
 - a. Press the SELECT button to highlight the **Netmask** field.
 - b. Press the UP or DOWN button to select the digit(s) in the first octet of your library's Netmask address.
 - c. Press the SELECT button to highlight the digit(s) in the next octet of your library's Netmask address.
 - d. After entering the digits for the last octet of your Netmask address, press the SELECT button to apply your entries.
 8. Press the DOWN button to select **Gateway**. For IPv4, enter only an IPv4 Gateway address. For IPv6, enter only an IPv6 Gateway address. For IPv4 & IPv6, enter a Gateway address for both IPv4 and IPv6.
 - a. Press the SELECT button to highlight the **Gateway** field.
 - b. Press the UP or DOWN button to select the digit(s) in the first octet of your library's Gateway address.
 - c. Press the SELECT button to highlight the digit(s) in the next octet of your library's Gateway address.
 - d. After entering the digits for the last octet in your Gateway address, press the SELECT button to apply your entries.
 9. Press the DOWN button to select **Ethernet**.
 - a. Press the DOWN button to highlight the **Ethernet** field.
 - b. Press the SELECT button to highlight the Ethernet setting.
 - c. Press the DOWN button to select a new setting.
 - d. Press the SELECT button to apply the new setting.
 10. Press the DOWN button to highlight SAVE. Press the DOWN again to highlight CANCEL. Continue to press the DOWN button to switch between SAVE and CANCEL.
 - If SAVE is highlighted, press the SELECT button to apply your new configuration. If changes were made to the Network settings, a pop-up menu will display the option to reboot the library or cancel the reboot. If you select CANCEL in the pop-up menu, you will need to power cycle the library for the network changes to be applied.
 - If CANCEL is highlighted, press the SELECT button to cancel all of your entries and return to the Configure menu.

Logging on to the Web User Interface

To complete the configuration of your library using the Web User Interface, follow the steps below.

1. On your host computer, open an Internet browser.
2. In the browser address field, enter your library's IP Address.

- a. For DHCP and/or Stateless Autoconfig, use the Operator Control Panel to determine the IP Address assigned to your library. Navigate to **Monitor > Library > Network**. Scroll down to the library address information and make note of the address. Enter the IP Address in your internet browser address field to access your library with the Web User Interface. The library address information may include one or more of the following address types:
 - IP Address (IPv4 static or DHCP)
 - Static IPv6 Address
 - Link Local IPv6 Address
 - Assigned IPv6 address (DHCP or Stateless Autoconfig)
 - b. For IPv4, enter your library's IP Address using the 0.0.0.0 format (four octets).
 - c. For IPv6, enter your library's IP Address using the following format: http://[0:0:0:0:0:0:0:0].
 - d. For Dual Stack IPv4 + IPv6, enter your library's IP Address for either IPv4 or IPv6.
3. When the login screen appears,
 - a. Select **admin** for a User ID.
 - b. Enter **secure** for a Password.




Figure 41. Log in screen on the Web User Interface

Verifying/Updating Firmware

It is important to run the latest level of firmware. To ensure that you are running the latest levels of library firmware, drive firmware, and SNMP MIB (Management Information Base) file, complete this procedure.

1. Verify the SNMP MIB file currently installed on your SNMP server. Verify the levels of library and drive firmware currently installed on your library by completing the following steps:
 - a. Expand **Monitor Library** in the left navigation pane of the Web User Interface.
 - b. Click **Library Identity** and make note of the Firmware revision.
 - c. Click **Drive Identity** and make note of the Firmware revision.
 - d. Log out of the Web User Interface.

Note: The SNMP MIB file is an optional feature.

2. Download the latest library firmware, drive firmware, and SNMP MIB (Management Information Base) file from **www.Dell.com/support**.

Note: The SNMP MIB file is an optional feature.

- a. Enter in your internet browser address field and press **Enter** on your keyboard.
 - b. Compare the firmware level available on the web to those that you made note of in step 1. If you are running the latest levels of library and drive firmware, proceed to the next step. If you are not running the latest levels of library and drive firmware, download the firmware that needs to be updated to your library host.
3. Update library and drive firmware on your library, if necessary.
 - a. Enter the IP Address of your library in your internet browser address field and press **Enter** on your keyboard.

- b. Log in to your library's Web User Interface.
 - c. Expand **Service Library** in the left navigation pane of the Web User Interface.
 - d. Click **Upgrade Firmware**.
 - e. Browse to the new firmware level on your host, then click **Update**. Do this for both library and drive firmware, if necessary.
4. Install the MIB file on your SNMP server. Refer to your server application documentation for instructions.

Choosing General Library Settings

If your library contains only one drive or logical library, both general and specific settings will be combined into one table (see Figure 42 on page 58).

1. Expand **Configure Library** in the left navigation pane of the Web User Interface.
2. Click **General** and enter the following:
 - **Library Name** - Enter a name for your library.
 - **Library Mode** (select one of the following per logical library):
 - **Random**: In random mode, the library allows the server's (host's) application software to select any data cartridge in any order.
 - **Sequential**: In sequential mode, the library's firmware predefines the selection of the cartridges. After initialization, the firmware causes the library to select the first available cartridge found (counting from the I/O Station through the last slot in your library) for loading into the drive.

Important: A Logical Library in Sequential Mode supports only one tape drive. If it contains more than one drive, only the first drive in the Logical Library is used and the other drives are not supported.

- **Autoload**: Sequential mode with autoload mode ON loads the first available cartridge (slot with the lowest numerical value that contains a cartridge) automatically if the library powers ON with an empty drive.
- **Loop**: Sequential mode with loop mode ON loads the cartridge in the lowest numerical slot after the cartridge in the highest numerical slot has been filled and sent back to its home slot. This allows endless backup operations without user interaction.
- **Active Slots** - Select the number of active slots you would like to assign in your library. This item will affect the number of **Res. (Reserved) Slots** in your library. For more information refer to "Configuring I/O Stations and Reserving Slots" on page 136.

Note: Slots can be reserved so that they are invisible to the host. It may be necessary to reserve slots in order to match the number of available slots to the ISV software licensing. Slots will be reserved starting with the highest element address. If your library does not have a dedicated cleaning cartridge slot, and you desire to enable Auto Clean, you must designate a reserved slot which can be used to hold the cleaning cartridge.

- **I/O Station Enabled** - If checked, the I/O Station is enabled. If not, the first 3 slots (in a 4U library or the 1st slot in a 2U library) are configured as storage. See "Configure Library: General" on page 116.
- **Auto Clean Enabled** - Automatically cleans drive when drive requests cleaning **and** cleaning cartridge is present in a reserved slot or a dedicated cleaning slot. All cleaning cartridges must have **CLN** as part of the bar code. The Universal Cleaning Cartridge has the bar code label CLNUxxLx.

Note: It is recommended that the Auto Clean function is enabled on the library. With the Auto Clean function enabled, drive cleaning occurs automatically. The only time Auto Cleaning must be disabled is when your Backup Application requires that it has control.

- **Bar Code Label Length Reported to Host** - Choose between 6 and 8. With 6, the first six characters of the cartridge VOLSER (Volume Serial Numbers) will be reported to the host. With 8, All characters in the VOLSER (first six characters plus the two character media type identifier) will be reported to the host.
- Click one of the following:
 - **Refresh** - Click this button to update the current screen.
 - **Apply Selections** - Click this button to submit the changes made to the screen.

General	
Library Name	<input type="text"/>
Library Mode	<input checked="" type="radio"/> Random <input type="radio"/> Sequential <input type="checkbox"/> Autoload <input type="checkbox"/> Loop
Active Slots	23 ▼
I/O Station Enabled	<input checked="" type="checkbox"/>
Auto Clean Enabled	<input type="checkbox"/>
Barcode Label Length Reported To Host	8 ▼

a77ug066

Figure 42. The 2U library Configure Library: General screen

General	
Library Name	<input type="text"/>
I/O Station Enabled	<input checked="" type="checkbox"/>
Auto Clean Enabled	<input checked="" type="checkbox"/>
Barcode Label Length Reported To Host	8 ▼

Extended Configuration for Logical Libraries	
Logical Library 1	
Library Mode	<input checked="" type="radio"/> Random <input type="radio"/> Sequential <input type="checkbox"/> Autoload <input type="checkbox"/> Loop
Active Slots	21 ▼
Logical Library 2	
Library Mode	<input checked="" type="radio"/> Random <input type="radio"/> Sequential <input type="checkbox"/> Autoload <input type="checkbox"/> Loop
Active Slots	23 ▼

a77ug094

Figure 43. Example: The 4U library Configure Library: General screen

3. If your library has more than one drive, proceed to “Choosing the Number of Logical Libraries for Your Library.” If your library has one drive, proceed to “Entering Path Failover Feature Activation Key” on page 59.

Choosing the Number of Logical Libraries for Your Library

Note: Review the information in “Determining the Number of Logical Libraries” on page 25 before completing the procedure in this section.

If you have a 2U or 4U library with only one drive, or do not wish to partition your library, proceed to the next section, “Entering Path Failover Feature Activation Key.”

One cartridge magazine cannot be assigned to two logical libraries. If you partition a multi-drive library, each of the magazines must be assigned to a logical library on a magazine boundary. The entire magazine must be part of one logical library only.

Note: If you have a 2U library with two drives, you have the capability to have two logical libraries.

In a fully populated 4U library with four half height drives and four logical libraries, resource assignments will be as follows:

- Logical Library 1 will contain Drive 1 and the lower left cartridge magazine.
- Logical Library 2 will contain Drive 2 and the upper left cartridge magazine.
- Logical Library 3 will contain Drive 3 and the lower right cartridge magazine.
- Logical Library 4 will contain Drive 4 and the upper right cartridge magazine.

The I/O Station and slots reserved for cleaning cartridges, if any, are shared among all logical libraries.

1. Click **Configure Library** > **Logical Libraries** in the left navigation pane.




Figure 44. The 4U library Configure Library: Logical Libraries page

2. Select the number of logical libraries you would like to create in your library.
3. Click **Submit** to create the logical libraries.

Entering Path Failover Feature Activation Key

For more information, refer to the *Dell PowerVault TL4000 Failover Configuration Guide*, included with the library documentation.

1. Click **Configure Library** > **Path Failover** in the left navigation pane.



Figure 45. The Configure Library: Path Failover Feature Activation screen

2. Enter the Control Path Failover 12-digit feature key in the spaces provided.
3. Click **Activate** to save the feature key. The following screen will display if you have correctly entered the feature key.




Figure 46. Feature Key verification screen

Note: Follow the instructions in the *Dell PowerVault TL4000 Failover Configuration Guide* to configure your environment for failover.

Setting Up Encryption

Note: Application Managed Encryption (AME) does not require a key. Library Managed Encryption requires a license key. The customer should contact their TSR (technical sales representative) to purchase this feature.

For information on minimum firmware levels for Application Managed and Library Managed Encryption, see “Minimum firmware levels for common library features” on page v.

Setting a Drive's Method of Encryption

1. Click **Configure Library** > **Encryption** in the left navigation panel.




Figure 47. Feature Activation Key screen

2. On the **Encryption** screen, enter the **Feature Activation Key** to make available the library managed encryption options.
3. Click **Activate** to save the key and expand the screen for additional encryption settings.




Figure 48. Configure Library: Encryption Activation screen

4. Select **Enable SSL for EKM** to enable Secure Sockets Layer for the IBM SKLM application.
5. Select an **Encryption method** for each logical library.
 - Without an encryption license key, select **None** or **Application Managed Encryption**.
 - With an encryption license key, select **Library Managed Encryption**.
6. Select an **Encryption policy** for each logical library.

- **Encrypt All:** This is the default policy. It encrypts all cartridges using the default data keys specified in the key manager. This setting applies to all drives in a TL2000/TL4000 logical library.
 - **Internal Label - Selective Encryption:** Check your tape backup software application documentation to see if this feature is supported.
 - **Internal Label - Encrypt All:** Check your tape backup software application documentation to see if this feature is supported.
7. A primary and secondary key management server can be set for each logical library. Each partition has its own Encryption and key management settings. Maintaining primary and secondary key management servers is desired for maximum availability of encrypted backup and recovery. These settings are required for Library Managed Encryption only. Enter the **EKM Server Setting** information.

Note: The IP address of the key management host must be consistent with the library Network settings. This means if the library is set to **IPv4 only** network support, the key management host must be an IPv4 address. If the Dell PowerVault library is required to function in a mixed network environment the library must be set to **IPv4 + IPv6**.

- **Primary IP address (IPv4 or IPv6):** Enter the IP address of the primary key management server.
- **Primary TCP port:** After entering the Primary IP address, the library will automatically set the value of the Primary TCP port.
- **Secondary IP address (IPv4 or IPv6):** Enter the IP address of the secondary key management server.
- **Secondary TCP port:** After entering the **Secondary IP address**, the library will automatically set the value of the **Secondary TCP port**.

Note: The Default Port for TCP (SSL disabled) is **3801**. The Default Port for SSL is **443**. These values are the default values set by the library. They can be changed depending on the user configuration but the user has to make sure they match the EKM properties file.

Note: If SSL is enabled the encryption host configuration will request a SSL port instead of a TCP port. Review your *IBM SKLM Knowledge Center* online at <http://www-01.ibm.com/support/knowledgecenter/SSWPVP/welcome?lang=en> for instructions to locate the appropriate port settings.

8. Click **Submit** to apply the changes.
9. Install the IBM SKLM application on your host. Refer to the *IBM SKLM Knowledge Center* online for information on locating the appropriate IP address and port.

Choosing Drive(s) Interface Identification/Settings

1. Click **Configure Library > Drives** in the left navigation pane.

Drives	
Drive 1 (Logical Library 1)	<input checked="" type="checkbox"/> Power On <input checked="" type="checkbox"/> Control Path Note: SAS drives do not require user configuration
Drive 2 (Logical Library 2)	<input checked="" type="checkbox"/> Power On <input checked="" type="checkbox"/> Control Path
SCSI ID	6
Drive 3 (Logical Library 3)	<input checked="" type="checkbox"/> Power On <input checked="" type="checkbox"/> Control Path
Port A Configuration	
Speed	Automatic
Topology	LN-Port
FC-AL Loop ID	6
Port B Configuration	
Port not available	

Refresh Submit

a77ug095

Figure 49. The Configure Library: Drive screen

2. Select the desired settings for each drive listed (either SCSI, SAS, or Fibre Channel). See Figure 49.
3. Click one of the following:
 - **Refresh** - to update the current screen
 - **Submit** - to apply the changes made to the screen

Entering Library Network Settings

This page shows the current network configuration of the library and allows modification to the configuration. When a change is requested, a pop-up box confirms the request.

1. Click **Configure Library > Network** in the left navigation pane, to display the **Network** page.

Network	
Protocol Stack	IPv6 only
Host Name	ATL008
Domain Name	storage.tucson.ibm.com
Enable SSL for Web	<input type="checkbox"/>
Ethernet Settings	Auto
IPv4	
Enable DHCP	<input type="checkbox"/>
Static Address	9.11.198.225
Subnet Mask	255.255.254.0
Gateway address	9.11.198.1
DNS Primary	0.0.0.0
DNS Secondary	0.0.0.0
IPv6	
DNS Primary	2002:90B:E006:646:9:11:224:119
DNS Secondary	2002:90B:E006:646:9:11:224:121
Enable Stateless Auto Config	<input checked="" type="checkbox"/>
Enable DHCP	<input type="checkbox"/>
Static Address	2002:90B:E006:198:9:11:198:225
Prefix length	64
Gateway address	2002:90B:E006:198::1

a77ug074

Figure 50. Configure Library: Network Page

Important: Do not click the Submit button until all changes have been made to the Network page. Once the Submit button has been clicked, no other changes can be made until after the library has applied the current changes.

After the Submit button has been clicked, depending on the changes made, you will either be disconnected and need to login again or reboot the library.

Clicking the Refresh button will refresh the page and any changes made will not be retained.

2. Select a **Protocol Stack** - Choose **IPv4 only**, **IPv6 only**, or **Dual Stack IPv4 & IPv6**.

If you choose **Dual Stack IPv4 & IPv6**, you must be prepared to enter both IPv4 and IPv6 IP addresses. The sections below will gray out depending on the choices made here.

3. Enter the **Host Name**.

Note: The underscore (_) is not allowed as part of a host name.

4. Enter the **Domain Name**.

5. **DNS Primary** - Enter the IP address of your primary DNS server.

6. **DNS Secondary** - Enter the IP address of your secondary DNS server.

7. **Enable SSL for Web** - If you desire to have SSL (Secure Sockets Layer) enabled, place a check in this box.

Note: If you get a security certificate alert when logging in to the Web User Interface, you can install the certificate or allow an exception (depending on the internet browser you are using). SSL is enabled when the URL begins with **https://** and some browsers will show a lock.

8. **Ethernet Settings** - Ethernet Settings choices are: **Auto** (the default), **10 Mbit/Half**, **10 Mbit/Full**, **100 Mbit/Half**, **100 Mbit/Full**. Please refer to www.Dell.com/support to determine the availability of manual Ethernet settings in your library's firmware.

9. **Enter IPv4 settings (if applicable)**.

a. **Enable DHCP** - Click this item ON to have the IP Address of your library automatically set by the DHCP server.

b. **Static Address** - Enter the assigned IPv4 address. The format of an IPv4 IP address is a 32-bit numeric address written as four numbers separated by periods.

c. **Network Mask** - Enter the assigned IPv4 Network Mask.

d. **Gateway address** - Enter the assigned IPv4 Gateway address. This address allows access outside the local network.

10. **Enter IPv6 settings (if applicable)**.

a. **Enable DHCP** - Click this item ON to have the IP Address of your library automatically set by the DHCP server.

b. **Enable Stateless Auto Config** - Stateless Auto config is ALWAYS on (not defeatable).

c. **Static Address** - Enter the assigned IPv6 address. The format of an IPv6 IP address is a 128-bit numeric address written as 8 groups of four numbers separated by colons.

d. **Prefix length** - The default prefix length is set to 64, but can be set to any length, depending upon the address used.

e. **Gateway address** - Enter the assigned IPv6 Gateway address. This address allows access outside the local network.

11. Click one of the following:

• **Refresh** - to cancel the changes made to the screen.

• **Submit** - to apply the changes made to the screen.

Note: Depending on the changes made, you will either be disconnected and need to login again, or reboot the library. If a reboot is required, the following Warning message will appear after the Submit button is clicked.



Warning: Changes Will Take Effect After A Reboot!

a77ug171

Figure 51. Warning Screen

The library must be rebooted or the changes will not take place.

Entering User Access Information using the Web User Interface

The **Configure Library > User Access** page is only accessible to the Admin and Service login. Access is denied to User and Superuser logins.

The Admin login has access to all library functions except **Service Library > Advance Diagnostics**.

The Service login has access to all library functions including **Service Library > Advance Diagnostics**.

1. Click **Configure Library > User Access** in the left navigation pane.

Roles	
<input type="checkbox"/> Disable Superuser	
<input type="checkbox"/> Disable User	

Passwords	
Role	User
New Password (Enter Up To Twenty Characters)	••••••
Repeat Password	••••••

Support Contact	
Support Name	
Support Phone	
Support Email	

Password Rules	
Minimum Number Of Characters	8
Minimum Number Of Upper Case Alphabetic Characters (A-Z)	0
Minimum Number Of Lower Case Alphabetic Characters (a-z)	0
Minimum Number Of Numeric Characters (0-9)	0
Minimum Number Of Special Characters (!@#\$%^&*()_+-={} []\;:'<>?,./)	0
Maximum Number Of Identical Consecutive Characters	0
Maximum Number Of Failed Logins Before Password Is Locked	0
Maximum Number Of Days Before Password Must Be Changed	0

Refresh Submit

a77uq082

Figure 52. The Configure Library: User Access screen

2. Check the **Disable Superuser** checkbox to disable the Superuser role for this library. Check the **Disable User** checkbox to disable the User role for this library. Uncheck these boxes to allow these roles access to your library.
3. Choose a Role.

Note: Admin can select User, Superuser, and Admin roles. Service can select User, Superuser, Admin, and Service roles.

- User (if enabled)
- Superuser (if enabled)
- Admin
- Service

Note: Only one password can be set for each Role.

4. Enter the **New Password** . The password has a maximum of 10 characters (A-Z, a-z, 0-9, @, <hyphen>, <space>, <period>).
5. In **Repeat Password**, enter the new password again.
6. In **Support Name**, enter the name of the person that will be able to offer the user help with the library.

Note: Only one support person can be configured for the entire tape library. The support person may or may not be one of the user, superuser, or admin account holders.

7. In **Support Phone**, enter the phone number of the person that will be able to offer the user help with the library.

8. In **Support Email**, enter the email address of the person that will be able to offer the user help with the library.
9. Click one of the following:
 - **Refresh** - to update the current screen.
 - **Submit** - to apply the changes made to the screen.

Entering Date and Time using the Web User Interface

1. Click **Configure Library > Date & Time** in the left navigation pane.

Date & Time	
Time (24H)	17 : 41 : 11
Date	Month : 04 Day : 11 Year : 2006

Refresh Submit

Figure 53. The Configure Library: Date and Time screen

2. Enter the current **Time** using the HH:MM:SS 24-hour format.
3. Enter the current **Date** using the MMDDYYYY format.
4. Click one of the following:
 - **Refresh** - to cancel all of your entries and leave the settings as they were.
 - **Submit** - to apply the changes made to the screen.

Configuring Logs and Traces using the Web User Interface

This function is not available on the Operator Control Panel.

1. Click **Configure Library > Logs & Traces** in the left navigation pane.

Logs & Traces	
Error Log Mode	<input checked="" type="radio"/> Continuous <input type="radio"/> Stop Trace At First Error <input type="radio"/> Stopped
Trace Level	<input checked="" type="checkbox"/> Cmd <input checked="" type="checkbox"/> Response <input checked="" type="checkbox"/> Event <input checked="" type="checkbox"/> Trace Data <input checked="" type="checkbox"/> Low Level Trace <input checked="" type="checkbox"/> Recovered Error <input checked="" type="checkbox"/> Hard Error
Trace Filter	<input checked="" type="checkbox"/> Main <input checked="" type="checkbox"/> Drive <input checked="" type="checkbox"/> CDB Interpreter <input checked="" type="checkbox"/> Robotic <input checked="" type="checkbox"/> Trace <input checked="" type="checkbox"/> OCP Input <input checked="" type="checkbox"/> OCP Output <input checked="" type="checkbox"/> SCSI Module <input checked="" type="checkbox"/> SDCI Module

Refresh Submit

Figure 54. The Configure Library: Logs and Traces screen

2. For Error Log Mode, select **Continuous** so all information for logs and traces will be captured.
3. Trace Level and Trace Filter options can be changed by Service personnel only.
4. Click one of the following:
 - **Refresh** - to cancel all of your entries and leave the settings as they were.
 - **Submit** - to apply the changes made to the screen.

Entering Email Notification Information using the Web User Interface

This function is not available on the Operator Control Panel.

Use this menu item to set up email notification of library errors and warnings.

1. Click **Configure Library > Email Notification** in the left navigation pane.

Event Notification	
Notify Errors	<input type="checkbox"/> On
Notify Warnings	<input type="checkbox"/> On
To Email Address	<input type="text"/>
SMTP Server Address (IPv4)	<input type="text" value="0.0.0.0"/> IPv4 address or Host name and domain *
Domain Name	<input type="text"/>

Refresh Submit a77ug065

Figure 55. The Configure Library: Email Notification screen

2. If you would like to be notified when an error occurs, select **Notify Errors**.
3. If you would like to be notified when a warning occurs, select **Notify Warnings**.
4. In **To Email Address**, enter the email address to which the information will be sent.
5. In **SMTP Server Address (IPv4 or IPv6)**, enter the IP Address of the SMTP server associated with the email address.
6. Enter the **Domain Name** for your library. This field cannot be blank when using event notification.

Note: If you attempt to enter a blank value for the Domain Name, a warning message will appear. It will say **If you are using Event Notification then a value is required for the Domain Name.**

7. Click one of the following:
 - **Refresh** - to cancel all of your entries and leave the settings as they were.
 - **Submit** - to apply the changes made to the screen.

Configuring SNMP settings

This page shows the current SNMP configuration of the library and allows modification to the configuration. When a change is requested, a box checks to confirm the changes.

Click **SNMP** in the left navigation pane to display the **SNMP** page.

SNMP	
Enabled	<input checked="" type="checkbox"/>
Community Name	<input type="text" value="public"/>
SNMP DESTINATIONS	
Target 1 - IP Address	<input type="text" value="isv3.storage.tucson.ibm.com"/> Version <input type="text" value="SNMPv1"/>
	<small>IPv4 address or Host name and domain *</small>
Target 2 - IP Address	<input type="text" value="0.0.0.0"/> Version <input type="text" value="SNMPv1"/>
	<small>IPv4 address or Host name and domain *</small>
Target 3 - IP Address	<input type="text" value="0.0.0.0"/> Version <input type="text" value="SNMPv1"/>
	<small>IPv4 address or Host name and domain *</small>
Audit Logging	<input checked="" type="checkbox"/>
SNMP V3 SECURITY	
User Name	<input type="text" value="initial"/>
Authentication	<input type="text" value="MD5"/>
Authentication Password	<input type="text" value="*****"/>
Privacy	<input type="text" value="DES"/>
Privacy Password	<input type="text" value="*****"/>
<input type="button" value="Refresh"/> <input type="button" value="Submit"/>	

a77ug278

Figure 56. Configure Library: SNMP page

Note: For information about SNMP, see “SNMP Messaging” on page 7 and Appendix F, “SNMP Status MIB Variables and Traps,” on page 237.

Note: If SNMP is not enabled (cleared), all SNMP fields are disabled.

SNMP

- **Enabled** - Check this box to have SNMP traps sent to an SNMP Management console.
- **Community Name** - An SNMP community name is a text string that acts as a password to authenticate messages that are sent between the SNMP remote management application and the library. Enter your preferred name, or leave as "public".

SNMP DESTINATIONS

- **Target 1 - IP Address** - If SNMP traps are enabled, enter an IP address where SNMP traps are sent.
- **Target 2 - IP Address** - Enter an optional second IP address where SNMP traps are sent, or leave as 0.0.0.0.
- **Target 3 - IP Address** - Enter an optional third IP address where SNMP traps are sent, or leave as 0.0.0.0.
- **Version** - The library offers three versions of the SNMP protocol; v1, v2, and v3. Select a version for each Target IP address.
- **Audit Logging** - If SNMP is enabled and Audit Logging is enabled, the library sends SNMP traps to an SNMP Management console when the library or tape drive configuration changes.

Note: This option is available only if the library firmware is 9.00 or higher, and the latest library MIB file is added to the SNMP Management console.

SNMP V3 SECURITY

- **User Name** - Enter your preferred name, or leave as "initial".
- **Authentication** - The options for Authentication are **none**, **MD5**, or **SHA**.
- **Authentication Password** - The Authentication Password must be at least 8 characters in length. If Authentication is set to **none**, this field and the **Privacy** and **Privacy Password** fields are disabled.
- **Privacy** - The options for Privacy are **none**, or **DES**. If Privacy is set to **none**, then the **Privacy Password** field is disabled.

- **Privacy Password** - The Privacy Password must be at least 8 characters in length.

Note: The factory default settings for SNMP V3 Security are

- User Name - **initial**
- Authentication - **none**
- Privacy - **none**

Testing encryption configuration for Library Managed encryption

Refer to www.Dell.com/support to determine the availability of this feature.

If you purchased an encryption activation key and any LTO 4 or higher Fibre Channel or SAS drive for your library, and the library is configured for library managed encryption, run the Key Path Diagnostic to ensure that your encryption configuration is correct.

Important: Ensure that library firmware and drive firmware are up to date before the Key Path Diagnostic procedure is run. Library firmware level must be greater than 6.xx. See “Verifying/Updating Firmware” on page 56.

For information about running the diagnostic procedure, refer to “Service Library: Key Path Diagnostics” on page 133.

Restoring Factory Default Settings using the Web User Interface

If you would like to erase your current configuration and restore factory default settings, do so by selecting **Restore Factory Defaults** in the **Configure Library > Save/Restore** menu. See “Configure Library: Save/Restore Configuration” on page 128.

The factory default settings are listed in Table 22 on page 100.

Logging out of the Web User Interface

To log out of the Web User Interface, click **Logout** in the upper right corner of the current screen.

Important: If you click the **X** in the upper right corner of your internet browser window, you will not log out of the Web User Interface.

Configuring Your Library using the Operator Control Panel

If you choose to use the Operator Control Panel for configuring your library, go to “Configure Menu” on page 92 for information on configuring the following items:

- Logical Libraries
- Library Settings
- Drive(s)
- Network
- Set Access PIN
- Set Date and Time
- Path Failover

To complete the configuration of your library, the following items will have to be accessed from the Web User Interface:

- Encryption (if purchased) (see “Configure Library: Encryption” on page 118)
- User Access Information (see “Configure Library: User Access” on page 123)
- Logs and Traces (see “Configure Library: Logs & Traces” on page 125)
- Event Notification Information (see “Configure Library: Event Notification” on page 126)

- Key Path Diagnostic (if Encryption was purchased) (see “Service Library: Key Path Diagnostics” on page 133)
 - Updating Firmware (see “Service Library: Upgrade Firmware” on page 134)
-

Preparing the Host

Follow these general guidelines:

1. Ensure that your backup application supports the SCSI, SAS, or Fibre Channel host bus adapter (HBA).
 2. Ensure that all the required or latest available Operating System files and/or updates (dll's, PTF's, etc.) have been installed and applied.
 3. If the host server is connected to a network, check with the system administrator before turning host power OFF.
 4. Install a suitably rated HBA. Remember that if there are any single-ended (SE) devices on the same SCSI bus, the entire SCSI bus will negotiate down to SE speed and severely degrade performance and limit cable length.
 5. Ensure that LUN scanning is enabled on the SCSI host adapter.
 6. Ensure that Fibre Channel Tape Support is enabled on the Fibre Channel HBA if installing a library with a Fibre Channel drive.
 7. Ensure that SAS support is enabled on the SAS HBA if installing a library with a SAS drive.
 8. For library managed encryption, install the IBM SKLM application on your host. Refer to the *IBM SKLM Knowledge Center* online at <http://www-01.ibm.com/support/knowledgecenter/SSWPVP/welcome?lang=en> for information.
-

Verifying the Connection

1. Depending on the server configuration, you may need to change the SCSI ID or Fibre Channel Loop ID of the library, if the current ID is the same as another device on the bus.
2. When the host server is powered ON, install the software and/or driver(s) that are compatible with the library. Backup software packages may require additional software or licensing to communicate with the library accessor.
3. If this is a SCSI attachment, ensure the library is properly terminated. If the library is the only SCSI device, other than the SCSI host adapter on the selected SCSI bus, it must be terminated. Likewise, if the library is physically the last SCSI device on the SCSI bus, it must be terminated. Only the devices physically located at the beginning and end of the SCSI bus should be terminated.
4. Confirm that the host server operating system recognized the library. In Microsoft Windows Server 2003, you can verify this by going to: **Settings > Control Panel > System > Hardware > Device Manager > Tape Drive and/or Medium Changer** .

For more information on verifying the connection of SCSI devices, see the operating system documentation.

Cartridge magazines

The library has removable magazines. Magazine access is password protected. For safety reasons, the accessor motion is stopped when a magazine is removed.

The magazines are released with the Operator Control Panel or the Web User Interface. In case the Operator Control Panel or Web User Interface initiated process failed or the library no longer has power, a manual emergency release is available.

Important: To manually release a magazine, see “Releasing the Magazines Manually” on page 175. This manual process is used only if the magazine cannot be released with the Operator Control Panel or the Web User Interface.

2U library cartridge magazines

The 2U library has two cartridge magazines. The left cartridge magazine (see Figure 57) has 11 storage slots and houses the elective 1-slot I/O station. The right magazine (see Figure 58) has 12 storage slots. For information about Element Addressing, see “2U Library I/O Slot, Storage Slots and Drive Slot Element Addresses and Physical Locations” on page 203.



Figure 57. 2U library left magazine



Figure 58. 2U library right magazine

2U Library I/O station

The I/O (input/output) station (see Figure 59 on page 71) in a 2U library is part of the left magazine. To open the I/O station, select **Control > Open I/O Station**. The I/O station slot opens, and the "Unlocking I/O station" message displays. Wait for the "Insert/remove cartridge and close I/O station" message to insert or remove the cartridge, then close the I/O station by gently pushing the slot back into the left magazine.

Note: It is recommended to wait for the messages before you insert or remove cartridges to ensure that the library is ready to handle the cartridges.



a77ug248

Figure 59. 2U library I/O station in the left magazine

4U library cartridge magazines

The 4U library has four cartridge magazines, two on each side (see Figure 60 and Figure 61). The upper left magazine has 12 storage slots. The lower left magazine has 9 storage slots and houses the elective 3-slot I/O station (**1** in Figure 60). The upper right magazine has 12 storage slots. The lower right magazine has 12 storage slots. For information about Element Addressing, see “4U Library I/O Slots, Storage Slots, and Drive Slots Element Addresses and Physical Locations” on page 204.



a77ug245

Figure 60. 4U library left magazines



a77ug249

Figure 61. 4U library right magazines

4U library I/O station

The I/O station in a 4U library (see Figure 62) is part of the lower left magazine. To open the I/O station, select **Control > Open I/O Station**. The I/O station slot opens, and the "Unlocking I/O station" message displays. Wait for the "Insert/remove cartridge and close I/O station" message to insert or remove the cartridge, then close the I/O station by gently pushing the slot back into the left magazine.

Note: It is recommended to wait for the messages before you insert or remove cartridges to ensure that the library is ready to handle the cartridges.



Figure 62. 4U library I/O station in the lower left magazine

There are finger holes on the back side of the I/O station (see **1** in Figure 63 on page 73) that allow the user to push the cartridges out of the I/O station.



Figure 63. Finger Holes on back side of 4U library I/O station

Populating the Library with Data Cartridges

Important: Cartridges placed in the library must be labeled with the correct bar code labels. For additional information, see “Using Ultrium Media” on page 139.

For information on working with the cartridge magazines, see “Cartridge magazines” on page 69.

1. Properly label the data cartridges. Refer to “Using Ultrium Media” on page 139.
2. Unlock the cartridge magazines.
 - Using the Operator Control Panel: **Control** > **Magazines** select Left or Right.
 - Using the Web User Interface: **Manage Library** > **Release Magazine** select Left or Right.

Note: The magazines will relock after 15 seconds if they have not been removed.

3. Remove the selected magazines from the library.
4. Insert cartridges in the magazine(s). Do not store cartridges in the I/O Station or in the dedicated cleaning cartridge slot. See “2U Library I/O Slot, Storage Slots and Drive Slot Element Addresses and Physical Locations” on page 203 or “4U Library I/O Slots, Storage Slots, and Drive Slots Element Addresses and Physical Locations” on page 204 for determining slot location.
5. Put magazines back into the library. The library will automatically start up and perform an inventory check.

Inserting the Cleaning Cartridge

Important: Cleaning cartridges placed in the library must be labeled with the correct bar code labels. For additional information, see “Using Ultrium Media” on page 139.

Note: Earlier versions of the 4U library contained a **Dedicated Cleaning Slot (DCS)**. This DCS can be retained and is supported by future library firmware updates. However, library firmware later than 3.90 will allow removal of the DCS, thus enabling this slot to be used as a storage slot. Once the DCS is removed, the Auto Clean cleaning cartridge slot must be configured as described below. If the DCS has been removed, it can only be reinstated by restoring factory default settings. To remove the DCS, perform the following procedure using the Operator Control Panel (OCP): **OCP->Configure->Library Settings->General->Remove DCS->No/Yes->Save**.

The following criteria must be followed for **Auto Clean** to function:

1. A storage slot must be reserved (Res or RSVD).
 - Reserving a slot is accomplished by reducing the **Active Slot** count in any particular logical library. A reserved slot (or slots) is always the last slot in the last magazine of any particular logical library. A cleaning cartridge that is in a reserved slot is available to any logical library drive even if the reserved slot is not in that particular logical library. If the library contains multiple logical libraries, typically, the last logical library is chosen to be the reserved slot containing the cleaning cartridge. As with a library with a single logical library, this slot is the last physical slot in the library (top right magazine, uppermost rear slot).
2. The **Auto Clean** function must be **Enabled**.
 - Operator Control Panel: **Configure->Library Settings->Auto Clean: Enabled**
 - Web User Interface: **Configure Library->General->Auto Clean Enabled->check box**

Note: Enabling Auto Clean without first reserving a slot for the cleaning cartridge will result in the library System Status screen (web UI) reporting the following attention conditions:

- Media Attention
 - Chk Media/Rsvd Slot
3. To install a cleaning cartridge in the 2U or 4U library:
 - a. Properly label the cleaning cartridge (CLNxxxLx). Refer to “Using Ultrium Media” on page 139.
 - b. Place the cleaning cartridge in the library using the same procedure described in “Populating the Library with Data Cartridges” on page 73. Ensure the cleaning cartridge is placed in a reserved slot or the DCS (if one exists, 4U only).
 - c. If the cleaning cartridge is not in a reserved slot, use the Operator Control Panel: **Control > Move Cartridge** or the Web User Interface: **Manage Library > Move Media** to move the cleaning cartridge into the reserved slot or the DCS (if one exists, 4U only).

Note: A user has the option to perform manual cleaning by navigating in the RMU to **Service > Clean Drive**. In units with more than one drive to be cleaned, the user must manually refresh the screen after the clean has completed in order to be able to select an additional drive to be cleaned.

4. Replace the cleaning cartridge, if needed.
 - A cleaning cartridge must be replaced after 50 uses. To determine the number of cleaning uses remaining, click on the Web User Interface, **Monitor Library->Inventory** .
 - Click on the **(+)** located under that magazine presentation to expand the detail of resident cartridges.
 - Cleaning cartridges are labeled as CLNxxxLx. Observe the information displayed for the slots containing a cleaning cartridge. The number of Media Loads represent how many times the cleaning cartridge has been used. The number 50, minus that Media Load number represents the number of uses remaining.

Operations

The following table lists menu navigation shortcuts to activities that can be performed via the Operator Control Panel and/or the Web User Interface.

Before using the Operator Control Panel or the Web user Interface, please review the information in Chapter 3: **User Interfaces**.

Table 19. Menu navigation shortcuts

Information/ Activity	Menu Navigation Shortcuts			
	Operator Control Panel	For More Info	Web User Interface	For More Info
Accessor, number of cartridge moves	Monitor > Library > Status > Cycles	"Monitor: Library" on page 84	Monitor Library > Library Status	"Monitor Library: Library Status" on page 109
Auto Clean, enable	Configure > Library Settings > Auto Clean	"Configure: Library" on page 94	Configure Library > General	"Configure Library: General" on page 116
Cartridge, currently active/moving	Monitor > Library > Status > Act. Cart	"Monitor: Library" on page 84	Monitor Library > Library Status	"Monitor Library: Library Status" on page 109
Cartridge, determine encryption	Not available with this interface		Monitor Library > Inventory	"Monitor Library: Inventory" on page 112
Cartridge, Inventory	Monitor > Inventory > Magazines	"Monitor: Inventory" on page 88	Manage Library > Perform Inventory	"Manage Library: Perform Inventory" on page 115
Cartridge, Move	Control > Move Cartridges	"Control: Move Cartridges" on page 91	Manage Library > Move Media	"Manage Library: Move Media" on page 114
Cartridge currently in drive (n), Cartridge label and slot source	Monitor > Inventory > Drive (n)	"Monitor: Inventory" on page 88	Monitor Library > Drive Status	"Monitor Library: Drive Status" on page 110
Cartridge in drive (n), cartridge slot source	Monitor > Drive > Status > Drive (n)	"Monitor: Drive" on page 86	Monitor Library > Drive Status	"Monitor Library: Drive Status" on page 110
Configuration, save and restore*	Configure > Save/Restore	"Configure: Save/Restore" on page 99	Configure Library > Save/Restore	"Configure Library: Save/Restore Configuration" on page 128
	* Note: From this location, you can not only save and restore your library configuration, but you can also restore factory defaults.			
Control path, enable	Configure > Drive > Control Path	"Configure: Drive" on page 96	Configure Library > Drives	"Configure Library: Drives" on page 120

Table 19. Menu navigation shortcuts (continued)

Information/ Activity	Menu Navigation Shortcuts			
	Operator Control Panel	For More Info	Web User Interface	For More Info
Date and time, current setting	Monitor > Library > Status > Date/Time	“Monitor: Library” on page 84	Current date and time displayed in System Status screen.	“System Status” on page 21
Date and time, set	Configure > Set Date and Time	“Configure: Set Date and Time” on page 101	Configure Library > Date & Time	“Configure Library: Date & Time” on page 125
Dedicated Cleaning slot, removing, reinstating	Configure > Library Settings	“Configure: Library” on page 94	Not available with this interface	
	Note: Dedicated Cleaning Slot (DCS) only available on earlier versions of the 4U library. Refer to “Inserting the Cleaning Cartridge” on page 74.			
DHCP, current status	Monitor > Library > Network > DHCP	“Configure: Network” on page 97	Configure Library > Network	“Configure Library: Network” on page 122
DHCP, modify	Configure > Network > DHCP	“Configure: Network” on page 97	Configure Library > Network	“Configure Library: Network” on page 122
Diagnostics, run drive Head test	Service > Service > Drive Tests	“Service: Run Tests” on page 103	Not available with this interface	
Diagnostics, run drive Media test	Service > Service > Drive Tests	“Service: Run Tests” on page 103	Not available with this interface	
Diagnostics, run drive Normal Read/Write test	Service > Service > Drive Tests	“Service: Run Tests” on page 103	Not available with this interface	
Diagnostics, run drive POST	Service > Service > Drive Tests	“Service: Run Tests” on page 103	Not available with this interface	
Diagnostics, run Key Path diagnostics (if feature is available)	Not available with this interface		Service Library > Key Path Diagnostics	“Service Library: Key Path Diagnostics” on page 133
Diagnostics, run Library Verify test	Service > Library Verify	“Service: Library Verify” on page 102	Not available with this interface.	
Diagnostics, run Slot to Slot test	Service > Run Tests	“Service: Run Tests” on page 103	Service Library > Perform Diagnostics	“Service Library: Perform Diagnostics” on page 132
Diagnostics, run System Test	Service > Run Tests	“Service: Run Tests” on page 103	Service Library > Perform Diagnostics	“Service Library: Perform Diagnostics” on page 132

Table 19. Menu navigation shortcuts (continued)

Information/ Activity	Menu Navigation Shortcuts			
	Operator Control Panel	For More Info	Web User Interface	For More Info
Display Contrast	Service > Display Contrast	“Service: Display Contrast” on page 104	Not available with this interface.	
DNS, modify settings	Not available with this interface.		Configure Library > Network	“Configure Library: Network” on page 122
Drive, change interface configuration	Configure > Drive > Drive Interface	“Configure: Drive” on page 96	Configure Library > Drives	“Configure Library: Drives” on page 120
Drive, change SCSI/Loop ID	Configure > Drive > Drive Interface	“Configure: Drive” on page 96	Configure Library > Drives	“Configure Library: Drives” on page 120
Drive, clean	Service > Service > Clean Drive	“Service: Service (Drives)” on page 104	Service Library > Clean Drive	“Service Library: Clean Drive” on page 129
Drive, current SCSI/Loop ID	Monitor > Drive > Identity	“Monitor: Drive” on page 86	Monitor Library > Drive Identity	“Monitor Library: Drive Identity” on page 107
Drive, current status	Monitor > Drive > Status	“Monitor: Drive” on page 86	Monitor Library > Drive Status	“Monitor Library: Drive Status” on page 110
Drive, data compression status	Not available with this interface.		Monitor Library > Drive Identity > Data Compression	“Monitor Library: Drive Identity” on page 107
Drive, Fibre, Worldwide Node Name	Monitor > Drive > Identity > Drive (n)/WWNN	“Monitor: Drive” on page 86	Monitor Library > Drive Identity	“Monitor Library: Drive Status” on page 110
Drive, Hashed SAS Address	Not available with this interface.		Monitor Library > Drive Status	“Monitor Library: Drive Status” on page 110
Drive, Interface type	Configure > Drive > Drive Interface	“Configure: Drive” on page 96	Monitor Library > Drive Identity	“Monitor Library: Drive Identity” on page 107
Drive, SCSI Inquiry string	Monitor > Drive > Identity	“Monitor: Drive” on page 86	Monitor Library > Drive Identity	“Monitor Library: Drive Identity” on page 107
Drive, turn power ON/OFF	Service > Service > Drive Power	“Service: Service (Drives)” on page 104	Configure Library > Drive	“Configure Library: Drives” on page 120
Drive activity, current	Monitor > Drive > Status > Drive (n)/Activity	“Monitor: Drive” on page 86	Monitor Library > Drive Status	“Monitor Library: Drive Status” on page 110
Drive fan, status	Not available with this interface		Monitor Library > Drive Status	“Monitor Library: Drive Status” on page 110

Table 19. Menu navigation shortcuts (continued)

Information/ Activity	Menu Navigation Shortcuts			
	Operator Control Panel	For More Info	Web User Interface	For More Info
Drive Dump, save	Not available with this interface.		Service Library > Save Drive Dump	"Service Library: Save Drive Dump" on page 131
Encryption, activate	Not available with this interface.		Configure Library > Encryption	"Configure Library: Encryption" on page 118
Encryption, configure	Not available with this interface.		Configure Library > Encryption	"Configure Library: Encryption" on page 118
Encryption, testing configuration (if feature is available)	Not available with this interface.		Service Library > Key Path Diagnostics	"Service Library: Key Path Diagnostics" on page 133
Encryption, determine method, current method	Not available with this interface.		Monitor Library > Drive Status	"Monitor Library: Drive Status" on page 110
Ethernet settings	Monitor > Library > Network	"Monitor: Library" on page 84	Configure Library > Network	"Configure Library: Network" on page 122
Email notifications: add, modify, and delete	Not available with this interface.		Configure Library > Email Notification	"Configure Library: Event Notification" on page 126
Error log, view	Monitor > Library > Error log	"Monitor: Library" on page 84	Service Library > View logs	"Service Library: View Logs" on page 130
Error logs and traces, set mode	Not available with this interface		Configure Library > Logs & Traces	"Configure Library: Logs & Traces" on page 125
Factory Default settings, restore	Configure > Save/Restore	"Configure: Save/Restore" on page 99	Configure Library > Save/Restore	"Configure Library: Save/Restore Configuration" on page 128
Fibre Channel, speed	Monitor > Drive > Status > Drive (n)	"Monitor: Drive" on page 86	Monitor Library > Drive Status	"Monitor Library: Drive Status" on page 110
Fibre Channel speed, change	Configure > Drives > Drive Interface	"Configure: Drive" on page 96	Configure Library > Drives	"Configure Library: Drives" on page 120
Fibre Channel, topology	Monitor > Drive > Status > Drive (n)	"Monitor: Drive" on page 86	Monitor Library > Drive Status	"Monitor Library: Drive Status" on page 110

Table 19. Menu navigation shortcuts (continued)

Information/ Activity	Menu Navigation Shortcuts			
	Operator Control Panel	For More Info	Web User Interface	For More Info
Fibre Channel topology, change	Configure > Drives > Drive Interface	“Configure: Drive” on page 96	Configure Library > Drives	“Configure Library: Drives” on page 120
Fibre Channel link, status	Monitor > Drive > Status > Drive (n)/Link	“Monitor: Drive” on page 86	Monitor Library > Drive Status	“Monitor Library: Drive Status” on page 110
Firmware, drive, current level	Monitor > Drive > Identity	“Monitor: Drive” on page 86	Monitor Library > Drive Identity	“Monitor Library: Drive Identity” on page 107
Firmware, library, identify current level	Monitor > Library > Identity	“Monitor: Library” on page 84	Monitor Library > Library Identity	“Monitor Library: Library Identity” on page 106
Firmware, library or drive update	Not available with this interface.		Service Library > Upgrade Firmware	“Service Library: Upgrade Firmware” on page 134
Gateway, current address	Monitor > Library > Network > Gateway	“Monitor: Library” on page 84	Configure Library > Network	“Configure Library: Network” on page 122
Gateway Address, modify	Configure > Network > Gateway	“Configure: Network” on page 97	Configure Library > Network	“Configure Library: Network” on page 122
Inventory, perform	Control > Re-Inventory	“Control: Re-Inventory” on page 92	Manage Library > Perform Inventory	“Manage Library: Perform Inventory” on page 115
I/O Station, configuring	Configure > Library Settings > I/O Station	“Configure: Library” on page 94	Configure Library > General	“Configure Library: General” on page 116
I/O Station, current status	Monitor > Library > Status	“Monitor: Library” on page 84	System Status screen	
I/O Station, open	Control > Open I/O Station	“Control: Open I/O Station” on page 90	Not available with this interface	
IP Address, current	Monitor > Library > Network	“Monitor: Library” on page 84	Monitor Library > Library Identity	“Monitor Library: Library Identity” on page 106
IP Address, modify	Configure > Network > IP Address	“Configure: Network” on page 97	Configure Library > Network	“Configure Library: Network” on page 122
Library, current status	Monitor > Library > Status	“Monitor: Library” on page 84	Monitor Library > Library Status	“Monitor Library: Library Status” on page 109
Logical libraries, configure	Configure > Logical Libraries	“Configure: Logical Libraries” on page 92	Configure Library > Logical Libraries	“Configure Library: Logical Libraries” on page 117

Table 19. Menu navigation shortcuts (continued)

Information/ Activity	Menu Navigation Shortcuts			
	Operator Control Panel	For More Info	Web User Interface	For More Info
Logs, library, view	Monitor > Library > Error Log	“Monitor: Library” on page 84	Service Library > View Logs	“Service Library: View Logs” on page 130
Magazines, graphical representation	Monitor > Inventory > Magazines	“Monitor: Inventory” on page 88	Monitor Library > Inventory	“Monitor Library: Inventory” on page 112
Magazines, Unlock	Control > Magazines	“Control: Magazine” on page 91	Manage Library > Release Magazine	“Manage Library: Release Magazine” on page 115
Mode, library, change	Configure > Library Settings > Mode	“Configure: Library” on page 94	Configure Library > General	“Configure Library: General” on page 116
Mode, library, current	Monitor > Library > Identity	“Monitor: Library” on page 84	Monitor Library > Library Identity	“Monitor Library: Library Identity” on page 106
Netmask, current address	Monitor > Library > Network	“Monitor: Library” on page 84	Configure Library > Network	“Configure Library: Network” on page 122
Netmask Address, modify	Configure > Network > Netmask	“Configure: Network” on page 97	Configure Library > Network	“Configure Library: Network” on page 122
Network configuration, change	Configure > Network	“Configure: Network” on page 97	Configure Library > Network	“Configure Library: Network” on page 122
Network configuration, view	Monitor > Library > Network	“Monitor: Library” on page 84	Configure Library > Network	“Configure Library: Network” on page 122
Path Failover, enter activation key	Configure > Control Path Failover	“Configure: Path Failover” on page 102	Configure Library > Path Failover	“Configure Library: Path Failover” on page 118
Restart, library,	Not available with this interface.		Service Library > Reboot	“Service Library: Reboot” on page 135
SCSI Inquiry string, drive	Monitor > Drive > Identity	“Monitor: Drive” on page 86	Monitor Library > Drive Identity	“Monitor Library: Drive Identity” on page 107
Serial Number, drive	Monitor > Drive > Identity	“Monitor: Drive” on page 86	Monitor Library > Drive Identity	“Monitor Library: Drive Identity” on page 107
Serial Number, library	Monitor > Library > Identity	“Monitor: Library” on page 84	Monitor Library > Library Identity	“Monitor Library: Library Identity” on page 106
Slots, number active	Monitor > Library > Identity	“Monitor: Library” on page 84	System Status screen	

Table 19. Menu navigation shortcuts (continued)

Information/ Activity	Menu Navigation Shortcuts			
	Operator Control Panel	For More Info	Web User Interface	For More Info
Slots, number empty	Monitor > Library > Status	“Monitor: Library” on page 84	System Status screen	
Slots, reassign number of active, reserving	Note: Varies according to the number logical libraries. Single partition: Configure > Logical Library Settings Multiple partitions: Configure > Logical Library Settings > Logical Library (n)	“Configure: Library” on page 94	Configure Library > General	“Configure Library: General” on page 116
SNMP, modify settings	Not available with this interface.		Configure Library > SNMP	“Configure Library: SNMP” on page 127
Telnet Service Port, activate	Service > Telnet Service Port	“Service: Telnet Service Port” on page 105	Not available with this interface.	
Time elapsed since power ON	Monitor > Library > Status	“Monitor: Library” on page 84	Monitor Library > Library Status	“Monitor Library: Library Status” on page 109
Operator Control Panel, access PIN, enable/disable	Configure > Set Access PIN	“Configure: Set Access PIN” on page 98	Not available with this interface.	
Web User Interface, user access, create or modify	Not available with this interface.		Configure Library > User Access	“Configure Library: User Access” on page 123

Operator Control Panel Navigation

The four control keys on the front of a 2U or 4U library enable the user to navigate through the library settings and make changes as needed to configure the library.




Figure 64. 2U Library Control Keys




Figure 65. 4U Library Control Keys

Table 20. Library Control Keys

Control Keys	Description
1	UP (∧) - Upper-left button Used to scroll upward through menu items.
2	CANCEL (X) - Upper-right button Used to cancel a user action and return to the previous menu screen.
3	SELECT (v) - Lower-right button Used to display a sub-menu or force an accessor action.
4	DOWN (v) - Lower-left button Used to scroll downward through menu items.

1. Press the UP (**1**) or DOWN(**4**) keys to enter Interaction Mode. The Main Selection Menu will appear. The Main Selection screen shows Monitor, Control, Configure, and Service.

2. Scroll to your selection, then press the SELECT (**3**) key. The sub-menu for the selected menu item will appear.
3. Use the UP (**1**) or DOWN(**4**) and SELECT (**3**) keys to scroll until you get to the area/screen you wish to configure.
4. Use the CANCEL (**2**) key if you wish to move backwards through the menu selections.

Operator Control Panel Menu Tree

The Operator Control Panel Main menu is made up of the following items:

- Monitor
- Control
- Configure
- Service

The table below shows each Main menu item and the associated sub menu items.




Figure 66. Operator Control Panel Menu Tree

Note: Depending on the version of library firmware, there may be differences between the Menu Tree description in this document and the OCP Menu Tree on your library.

a77ug050

Monitor Menu

The Monitor menu contains information about the following sub menu items:

- Library
- Drive
- Inventory

Monitor: Library

This menu item displays current library information and settings.




Figure 67. Monitor: Library menu

Under **Monitor** > **Library** are the following items:

- **Status**

- **Identity**
- **Error Log**
- **Network**

Under **Monitor > Library > Status** are the following items:

- Status - Status of the library
- Act. Cart - The serial number of the cartridge currently active in the library
- On Time - The amount of time the library is powered ON
- Slots Empty - The number of empty slots in the library/total number of active slots in the library
- Moves - The total number of cartridge moves that are carried out by the library accessor
- I/O Station - Indicates whether the I/O station is open or closed
- Date/Time - Gives the current date and time that is set in the library

Under **Monitor > Library > Identity** are the following items.

- Service Tag - the service tag of the library
- Version - the current level of library firmware installed
- Vendor ID - Dell
- Product ID - TL2000/TL4000
- Active Slots - Number of active slots in each logical library
- WWNN - Worldwide Node Name of the library
- Lib.x Mode - Current library mode (Random or Sequential)

Note: X = the number of logical libraries (1 - 4 partitions).


Under **Monitor > Library > Error Log**, a list of errors is logged by the library. The errors are displayed beginning with the most recent error.

Under **Monitor > Library > Network** are the following items:

- IP Stack - Internet Protocol used by the library
- DHCP - (Dynamic Host Configuration Protocol) - records whether DHCP is ON or OFF
- IP Addresses - IP (Internet Protocol) addresses of the library
- Stateless auto configuration - Indicates whether stateless auto configuration is enabled
- Prefix Length - The length of the IP address prefix
- Netmask - The Network Mask address of the library
- Static IPv6 Address - The static IPv6 address of the library
- Link Local IPv6 Address - Local link-only IPv6 address of the library
- Assigned IPv6 Address - IPv6 address or addresses that are discovered by the network router. The addresses display only when DHCP is OFF and Stateless auto configuration is ON.
- Gateway - The Gateway address of the library
- Ethernet - The speed of the ethernet interface

Monitor: Drive

This menu item displays drive information and settings.



a77ug035

Figure 68. Monitor: Drive menu

Important: Encryption is not supported on Gen3 drives or SCSI drives. With Gen3 or SCSI drives, Encryption will not appear in the OCP menu.

Under **Status** and **Drive (n)** are the following items:


- Status - the current status of the drive
- Activity - the current action being performed by the drive
- Source - the serial number of the cartridge currently in the drive
- Encryption - indicates the type of data encryption currently set for the selected drive (will not appear on Gen3 or SCSI drives)
- Topology - the topology chosen for a fibre library (see "Fibre Channel Interface" on page 33)
- Speed - indicates the speed of the fibre channel (fibre library)
- Link - indicates the status of the fibre channel (fibre library)
- Hashed Address - an address calculated from the WWID

Under **Identity** and **Drive (n)** are the following items:

- Firmware Rev - the current level of drive firmware
- Vendor ID - Dell
- Product ID - drive inquiry string
- Serial Number - the drive serial number
- Version - Ultrium 3 and 4 half high SAS drives and Ultrium 4 Fibre Channel drives may be listed as Version 2.
- SCSI ID - the unique identifier assigned to a SCSI drive
- WWNN - the fibre channel drive's World Wide Node Name
- Topology - the topology chosen for the fibre channel drive
- Speed - indicates the speed of the fibre channel tape drive
- Loop ID - unique identifier assigned to a fibre channel tape drive
- PID - port identification (SAS only)

Monitor: Inventory

This menu item displays the current library inventory of a 4U library.



a77ug036

Figure 69. Example of a 4U Monitor: Inventory menu

Note: 2U has a single right-side magazine.

Under **Magazine** choose one of the following to see a graphical representation of the cartridge magazine(s). Slots containing cartridges will be highlighted.

Magazines > Lower Left			
I/O 3	7	8	9
I/O 2	4	5	6
I/O 1	1	2	3
Idle Rand			

Magazines > Upper Left			
18	19	20	21
14	15	16	17
10	11	12	13
Idle Rand			

a77ug166

Figure 70. Overview of inventoried cartridges: Left magazines of a 4U Library

Note: Left magazine of a 2U Library has a 1-slot I/O Station.

The black boxes are inventoried cartridges. Press the up and down keys to scroll. Note that this magazine has a 3-slot I/O Station. These slots can be changed to storage slots if needed. See “Configuring I/O Stations and Reserving Slots” on page 136.

Press **SELECT** to display all empty slots and cartridge serial numbers in the associated magazine.

Magazines > Lower Left	
2	DT0632L4 LTO4 EC
3	3FB114L4 LTO4 ED
4	Empty
5	Empty
Idle Rand	

Figure 71. Detailed information on cartridges residing in a magazine

Table 21. Detailed information on cartridges residing in a magazine

1	Magazine slot number	3	Media type (generation of cartridge)
2	Cartridge volume serial number or “Empty” (meaning no cartridge currently residing in slot)	4	Encryption abbreviation for LTO4 cartridges: <ul style="list-style-type: none"> • EC - encryption capable (The LTO 4 cartridge does not contain encrypted data). • ED- encrypted data (The LTO 4 cartridge does contain encrypted data).

Control Menu

The Control Menu contains the following items:

- Open I/O Station
- Move Cartridges
- Magazine
- Re-Inventory

Control: Open I/O Station

Use this menu item to open the I/O station.




Figure 72. Control: I/O station menu

Important: Wait for the messages before you insert or remove cartridges to ensure that the library is ready to handle the cartridges. After the I/O station is closed, you must wait for the library to complete its inventory before normal library operations commence.

Control: Move Cartridges

Use this menu item to move cartridges in the library.




Figure 73. Control: Move Cartridges menu

To move a cartridge from point A to point B, you must make the following choices:

- Source Type - Drive, I/O station, magazine. Only the source type(s) that contain cartridges will be listed.
- Source - the choices start with the choice made in the preceding item and then advances through all available choices.

Note: If the Attention LED is ON due to a suspect cartridge, that cartridge will be identified by an exclamation point (!) when scrolling through the source cartridges.

- Volume Serial - the serial number of the cartridge
- Dest Type - the destination Drive, I/O station, magazine
- Dest - the choices start with the choice made in the preceding item and then advances through all available choices.

Control: Magazine

Use this menu item to unlock the cartridge magazines.




Figure 74. Control: Magazine menu

Choose "Left" or "Right" to unlock the corresponding cartridge magazine(s). The magazines can now be removed from the library by gently pulling each magazine out of the library. To replace a magazine,

insert the back of the magazine into the front of the library and gently push the magazine into the library. The magazine will lock when inserted into the library.

Attention: After inserting the magazines into the library, you must wait for the library to complete its inventory before proceeding with normal library operations.

If the magazines are not pulled out of the library within 15 seconds after they are unlocked, the command will cancel and you will have to repeat the process to unlock the magazines.

Control: Re-Inventory

Use this menu item to initiate a scan of the cartridges currently in the library.




Figure 75. Control: Re-Inventory menu

Note: It may take up to five minutes to complete the library inventory.

Configure Menu

The Configure Menu is used during the initial setup of your library and when changes need to be made to your library's configuration. This menu contains the following items:

- Logical Libraries
- Library Settings
- Drive
- Network
- Set Access PIN
- Save/Restore
- Set Date and Time

Configure: Logical Libraries

Use this menu item to select the number of logical libraries. The **Currently Configured - x** section shows the number of logical libraries currently configured.




Figure 76. Configure: Logical Libraries menu

Note: The maximum number of Logical Libraries in a 2U is two.

Note: This menu is only available on libraries with multiple drives.

Note: Whenever there is a hardware configuration change such as drives being swapped with different form factors (i.e. HH to FH or FH to HH), a library configuration change is needed. Reconfiguring the library by reassigning the amount of logical libraries will clear this issue.

Configure: Library




Figure 77. Configure: Library menu

Note: The Remove DCS No is only available on libraries with the DCS feature.

The following library configuration items are in this menu:

- **Mode:**

- **Random:** In random mode, the library allows the server's (host's) application software to select any data cartridge in any order.
- **Sequential:** In sequential mode, the library's firmware predefines the selection of the cartridges. After initialization, the firmware causes the library to select the first available cartridge found (counting from the I/O Station through slot 23) for loading into the drive.

Important: A Logical Library in Sequential Mode supports only one tape drive. If it contains more than one drive, only the first drive in the Logical Library is used and the other drives are not supported.

- **Autoload:** Sequential mode with autoload mode ON loads the first available cartridge (slot with the lowest numerical value that contains a cartridge) automatically if the library powers ON with an empty drive.
- **Loop:** Sequential mode with loop mode ON loads the cartridge in the lowest numerical slot after the cartridge in the highest numerical slot has been filled and sent back to its home slot. This allows endless backup operations without user interaction.
- **Starting Sequential Mode**
 - Autoload Option:
 - If the Autoload option is set to **ON (Configure > Library Settings > Autoload)**, the accessor will load the first cartridge (cartridge located in the slot with the lowest numeric value) found in the storage inventory area into the drive upon power ON of the library. If the library powers on with a cartridge already in the drive, sequential mode will start with that cartridge unless the host issues a rewind and unload command to the drive. In that case, the next cartridge in sequence will be loaded into the drive.
 - If the Autoload Option is **OFF**, sequential mode must be started by selecting the Move Cartridges option (**Control > Move Cartridges**) to load the first cartridge (or any cartridge) into the drive. Whatever cartridge is loaded into the drive, that is where the sequence starts from. For example, if a cartridge from the fifth lowest numeric storage slot containing a cartridge is loaded using the Move Cartridges option, after the host issues a rewind/unload command, the next cartridge loaded will be the cartridge from the next higher numeric slot. Cartridges need not be in contiguous slots.
 - Loop Option:

If the Loop option is set to **ON (Configure > Library Settings > Loop)**, when the last cartridge (cartridge in the highest numeric slot) is unloaded and placed back into storage, the accessor will immediately start over again loading the first cartridge into the drive.
 - **Stopping Sequential Mode:** To stop sequential mode, use the Move Cartridges option from the Control menu (**Control > Move Cartridges**) to unload the drive. The next sequential cartridge will NOT be loaded. To restart sequential mode, use the same Control menu command to load a cartridge. The loading sequence will resume from that numeric slot in the cartridge inventory.
- **Active Slots** - the number of active slots in each logical library.

Note: Slots can be reserved so that they are invisible to the host. It may be necessary to set the number of **Active Slots** to match the number of slots that are available to the ISV software. Reserved slots are created by reducing the number of active slots.

- **Auto Clean** - Use this menu item to enable the Auto Clean function. All cleaning cartridges must have "CLNxxxLx" as part of the bar code.

With Auto Clean disabled, the cleaning tape can be stored in any data slot if you wish to manually clean the drives. This is not recommended.

With Auto Clean disabled, the cleaning tape can be stored in any data slot if it was put there under Backup Application control. In other words, the Backup Application is controlling the cleaning of the tape drives and the cleaning tape would be imported into this library under its control.

Note: The universal cleaning cartridge has a bar code CLNUxxLx. This cleaning cartridge is used to clean all LTO generation tape drives.


For Auto Clean to function, the following criteria must be met:

- On 4U libraries with library firmware of .80 or lower that still contain a Dedicated Cleaning Slot (DCS), or 4U libraries with library firmware higher than 1.95 that chose to retain the DCS in their library, a CLN cartridge must be present in that slot.
- On libraries that don't have a DCS, a storage slot must be reserved (RSVD) by reducing the active slot count by one.
- A cleaning cartridge (CLNxxxLx) must be placed or moved to the reserved slot.
- Auto Clean must be enabled.

Note: Cleaning cartridges must be replaced after 50 cleanings. The Web User Interface inventory screen will show the number of times the media has been loaded, not the number of cleaning sessions remaining. Subtract this number from 50 to determine the number of cleanings remaining.

- **I/O Station(s) enabled** - The I/O Station(s) can be enabled (the default), or disabled so the stations can be utilized as storage slots.
- **Remove DCS** - If the DCS has been removed, it cannot be reinstated. This option will no longer appear in the Operator Control Panel.
- **Host Label Length** - The Host Label Length is related to the Bar Code Labels appearing on the media being used. The default value is 8, but 6 can also be chosen.

Configure: Drive



a77ug299

Figure 78. Configure: Drive menu

The following items are in this menu:

- **Drive Interface** - use this to assign a SCSI ID to a SCSI drive or to assign a Port Speed, Port Type, and Loop ID to a Fibre Channel drive. SAS drives do not require user configuration. For more information on drive interfaces, refer to “Host Interfaces” on page 30.
- **Control Paths** - use this to enable the drive as a control path drive. Each logical library must have a control path drive; however, all drives in a logical library can be designated as control path drives.

Configure: Network




Figure 79. Configure: Network menu

Use these menu items to change the current network settings which allow you to access the library remotely via a web browser.

- **IP Stack** - Choose **IPv4 only**, **IPv6 only**, or **IPv4 & IPv6**.
- **IPv6 Only** and **Dual Stack IPv4 & IPv6** - Choose **Enable** Stateless Auto Config Address (Web User Interface) or Stateless Autoconfig (Operator Control Panel) if assigned IPv6 IP addresses are desired. To view the assigned IPv6 addresses after enabling Stateless Auto Config Address, do the following:
 - **Operator Control Panel (IPv6 Only): Monitor > Library > Network**
 If you choose **Dual Stack IPv4 & IPv6**, you must be prepared to enter both IPv4 and IPv6 IP addresses.
- **DHCP** - (Dynamic Host Configuration Protocol) If this is enabled, your library host will negotiate the connection with the library. If DHCP is disabled, the following information is necessary to establish the remote access.
- **IP Address** - the IP address of the library
- **Netmask** - the Network Mask address of the library

- **IP Stack** - the IP Stack manages static IP addresses
- **Stateless autoconfig** - allows IPv6 hosts to be configured automatically when connected to a routed IPv6 network
- **Prefix length** - the length of the IP address prefix
- **Static IPv6 address** - a static IPv6 address that has been assigned to the library
- **Gateway** - the Gateway address of the library
- **Ethernet** - the current speed setting of the ethernet interface
- **DNS Server 1** - the first DNS server address
- **DNS Server 2** - the second DNS server address

Note: If a host and domain name are entered instead of an address, the IPv4 or IPv6 address will be resolved from the DNS using that name. That address will be stored in the library rather than the name. Therefore, if the address changes, the name or a new address will have to be entered.

Configure: Set Access PIN

Use this menu item to enable/disable, set or change the Access PIN (personal identification number) which is used to restrict access to the Control, Configure, and Service menus.

Note: Record the Access PIN and store this in a secure location for future reference. Library configuration files, saved with the Save Library Config menu, do not include the Access PIN.

The Operator Control Panel (OCP) pin is turned off by default, but it is strongly recommended to be enabled if your environment requires unit security. Enabling the OCP pin feature prevents the unit settings from being tampered with. Users will be allowed to review the library status and manipulate media without entering the OCP pin.

If a unit administrator needs to make a configuration change in the unit, the OCP will ask for the 4-digit code in order to allow access to make changes. Once all the changes are completed the pin access will expire after 5 minutes of inactivity in the OCP (there is no log-out function in the library for this feature). A library reboot is recommended after making configuration changes to the library.





Figure 80. Configure: Set Access PIN menu

Setting the Operator Control Panel Access PIN using the Operator Control Panel:

1. Navigate to **Configure** > **Set Access PIN**.
2. Press the SELECT button to highlight the first digit of the 4-digit Access PIN.
3. Use the UP and DOWN buttons to select each digit.
4. Press the SELECT button to move to the next digit.
5. Repeat these steps for repeating the Access PIN.
6. After entering the final digit, press the DOWN button and select one of the following:
 - **Save** - to apply your settings.

- **Cancel** - to delete your settings.

Note: In Figure 81, menus with the pound sign (#) are the only menus accessible when the Access PIN is enabled, but entered incorrectly or before it is entered. To gain access to all menus, disable the Access PIN or enter the correct PIN number when requested.



a77ug231

Figure 81. Pound sign (#) shows accessible menus when access PIN is enabled but before it is entered

Configure: Save/Restore

Use this menu item to restore the factory default settings.




Figure 82. Configure: Save/Restore menu

- **Restore Passwords** - This menu item restores the factory default for both the RMU Admin user access password and the service password.
- **Restore all** - This menu item restores all factory default settings (refer to Table 22).
- **Restore Library Config** - This menu item restores your saved library configuration from a USB device. If you have more than one saved configuration file (.dbb) on your USB device, press **Select**, then use the up and down keys to move between the different files. When the correct configuration file is displayed, press **Select** again.
- **Save Library Config** - This menu item saves your library configuration to a USB device.

Note: Ensure the USB device is formatted for FAT12, FAT16, or FAT32 and does not use autorun files.

Note: Configuration files saved with one version of library firmware may not be compatible with other versions of firmware. It is recommended to save a configuration file each time the library firmware is upgraded. Restore the library using a configuration file that was saved with the same version of firmware currently installed in the library.

Important: Restoring factory defaults will wipe out all the previous configuration data. Factory defaults must be restored when the library drive is changed from a LTO half height to full height configuration, in order for the library to correct the element addressing and drive numbering. If a new drive is added to the library configuration, a restore factory default is not required.

Table 22. Factory Default Settings

Restored Item	Default Setting*	Comments
Autoclean	Disabled	
Logical Libraries	1	
Active Slots	Maximum number of slots in library minus I/O Station	
I/O Station	Enabled	2U library has 1-slot I/O Station.4U library has 3-slot I/O Station.
Encryption	None	License Key is protected, if previously entered.
Ethernet Setting	Auto	
DHCP	Enabled	Note: DNS server addresses, if available, will be automatically assigned. If the DHCP server does not find any DNS server, the DNS fields will be set to "0.0.0.0".
Network IP Mode	IPv4 Only	

Table 22. Factory Default Settings (continued)

Restored Item	Default Setting*	Comments
Bar Code Label Length Reported to Host	8	
SNMP	Disabled	
Email Notifications	None	
User Access		Restore from Operator Control Panel or Web User Interface
Admin	secure	(default)
Library Mode	Random	
Library Name	(Blank)	
Host Name		(Depends on MAC Address)
Logs & Traces Error Log Mode	Continuous	
Path Failover Key	No change	License Key is protected, if previously entered.
OCP Access PIN	Disabled Note: The initial Factory Default setting is disabled. If the OCP Access PIN setting is changed, executing "Restore Defaults" will not change the setting.	If OCP Access PIN has been enabled the default PIN is "1234".
SSL for Web	Disabled	
Drives		
Power	Power On	(All drives)
Drive 1 SCSI-ID	4	SCSI Drives
Drive 2 SCSI-ID	5	SCSI Drives
Drive 3 SCSI-ID	6	SCSI Drives
Drive 4 SCSI-ID	8	SCSI Drives
Drive 1 Loop-ID	4	FC Drives Arbitrated Loop
Drive 2 Loop-ID	5	FC Drives Arbitrated Loop
Control Path Drive	Drive 1 only	
Partitions	None	
Reserved Slots	2U:24, 4U:48	
IPv6 Stateless Autoconfig	Enabled	
Note: * = all settings at library firmware level 4.xx and greater		

In some cases, (such as Library Mode), the entry of one option precludes any other options from being selected. In such cases, the details of the non-applicable options are not shown.

Configure: Set Date and Time

Use this menu item to set the current date and time in your library.




Figure 83. Configure: Set Date and Time menu

Configure: Path Failover

Use this menu item to enter the Path Failover Feature Activation key (Supported on 4U library only for library firmware levels at or below 8.xx. Supported on both the 2U and 4U libraries with library firmware levels above 8.xx).




Figure 84. Configure: Path Failover

For information on minimum firmware levels for path failover, see “Minimum firmware levels for common library features” on page v. For more information, refer to the *Dell PowerVault TL2000/TL4000 Failover Configuration Guide*, included with the library documentation.

Service Menu

The 2U/4U library is always online, except for when the user enters the Service Library area. A warning message appears stating that the library should be taken offline from the host before performing any Service functions. It is up to the operator to ensure that it is taken offline by phoning the host operator or other means of communication. Before performing any service functions, ensure the host is not performing any data writing or retrieval.

The **Service Menu** contains the following items:

- Library Verify - an overall library diagnostic
- Run Tests - other library diagnostics
- Service - diagnostics and procedures for servicing the drive
- Display Contrast - setting the display from light to dark
- Telnet Service Port

Service: Library Verify

This is an overall diagnostic that exercises all library components. To run the Library Verify test, complete the following procedure.




Figure 85. Service: Library Verify menu

1. On the Operator Control Panel, navigate to **Service > Library Verify** and start diagnostic.
 - Push the **Select** key to highlight the drive field. Use the **Up/Down** keys to select the drive. Push the **Select** key to complete the selection.
 - Push the **Down** key to highlight <Run>.
 - Push the **Select** key to execute Library Verify.
2. When prompted by the Operator Control Panel display and the I/O Station opens, insert a blank or scratch data cartridge.
3. Close the I/O Station by pushing it back into the library.
4. While the test is running, the Operator Control Panel will display library status.
 - If the test **PASSES**, resume normal library operations.
 - If the test **FAILS**, an error code will be displayed. Make note of the error, then refer to “Troubleshooting” on page 149.

Note: Library Verify requires a piece of scratch media to perform the test. Once the test has been initiated, the user must complete the test.

5. When prompted by the Operator Control Panel display and the I/O Station opens, remove the cartridge used in the test.
6. Close the I/O Station by pushing it back into the library.
7. Use the **Up/Down** keys to highlight <Cancel>. Press the **Select** key to exit the Library Verify screen.

Service: Run Tests




Figure 86. Service: Run Tests menu

The following library diagnostics are available in this menu:

- **System Test** - this test exercises library components by moving customer data cartridges from slots to drives and back to slots. No data is written or read from the customer tapes. To run this test successfully, the library must contain at least one data cartridge for every drive present in the library.
- **Slot to Slot Test** - The Slot To Slot test will move each resident data cartridge from one slot to another, for each test cycle requested. When completing the Slot To Slot test, you will need to **Inventory** your library before placing it back online, since this test scrambles the cartridge slot locations.

Note: After running the System Test or the Slot to Slot Test, the library will need to be re-inventoried. It might be required to reboot the library after library diagnostics completes to ensure proper library re-detection on some backup applications.

Service: Service (Drives)




Figure 87. Service: Service menu

The following drive diagnostics and service procedures are available in this menu:

- **Clean Drive** - The accessor takes the cleaning cartridge from the dedicated cleaning cartridge slot (DCS), or previously reserved slot if no DCS is available, and inserts it into the drive. After the cleaning is complete, the accessor removes the cleaning cartridge from the drive and returns it to the dedicated cleaning cartridge slot or reserved slot.
- **Drive Tests** - Power On Self Test (POST), Normal Read/Write Test, Head Test, Media Test
 1. Navigate to the desired test (**Service > Service > Drive Tests**).
 - a. Select the drive if more than one is installed.
 - b. Press the Enter button.
 - c. Press either + or - to toggle drive test options.
 - d. Move the cursor to the <Run> option.
 - e. Press the Enter button to apply the test.
 2. Follow the instructions displayed on the Operator Control Panel, and, if required, insert a blank or scratch cartridge into the I/O Station when requested.
 3. The test will execute.
 - If the test PASSES, resume normal library operations.
 - If the test FAILS, an error will be displayed. Make note of the error, then refer to “Isolating Drive Sled Problems” on page 157.
 4. Remove the cartridge from the I/O Station, if needed, then close the I/O Station.
 5. Press **Cancel** to exit the screen.
- **Drive Power** - use this item to turn drive power ON and OFF

Note: When configuration changes of a disabled drive are made from the Operator Control Panel (OCP), the drive powers ON after committing changes. When configuration changes of a disabled drive are made from the Web Interface (RMU), the drive does not power ON after committing changes.

Service: Display Contrast




Figure 88. Service: Display Contrast menu

The following display contrast settings are available in this menu:

- The numbers 1 through 10 will display, with 10 being the lightest shade and 1 being the brightest.

Service: Telnet Service Port

The Telnet Service Port menu item is to be used under the direction of Dell Technical Support.

Web User Interface Menus

Note: Depending on the version of library firmware, there may be differences between the Menu description in this document and the web user interface menus on your library.

The following menus are available on the Web User Interface.

Table 23. Web User Interface Menus

[-] Monitor Library

- Library Identity
- Drive Identity
- Library Status
- Drive Status
- Inventory

[-] Manage Library

- Move Media
- Perform Inventory
- Release Magazine

[-] Configure Library

- General
- Logical Libraries
- Path Failover
- Encryption
- Drives
- Network
- User Access
- Date & Time
- Logs & Traces
- Email Notification
- SNMP
- Save/Restore

[-] Service Library

Table 23. Web User Interface Menus (continued)

- Clean Drive
- Advance Diagnostic (for Service Personnel only)
- View Logs
- View Drive Logs
- Save Drive Dump
- Perform Diagnostics
- Key Path Diagnostics (if feature is available)
- Upgrade Firmware
- Reboot

Monitor Library Menu

The **Monitor Library** menu contains the following sub-menu items.

- “Monitor Library: Library Identity”
- “Monitor Library: Drive Identity” on page 107
- “Monitor Library: Library Status” on page 109
- “Monitor Library: Drive Status” on page 110
- “Monitor Library: Inventory” on page 112

Monitor Library: Library Identity

This page provides access to the static information about the library. No changes can be made from this page. Table 24 lists all available elements on the Library Identity page. An "X" indicates that the element displays for the specified library type.

Table 24. Library Identity page elements

Menu Item	Description	2U	4U
Service Tag	This is the unique identification number assigned by the manufacturer.	X	X
Product ID	Machine Type and Model (this is the SCSI inquiry string of the Library)	X	X
Currently Installed Library Firmware	This is the current level of firmware installed on the library. For information on updating your firmware, refer to “Service Library: Upgrade Firmware” on page 134.	X	X
Bootcode Firmware Revision	This is the level of bootcode firmware currently installed on the library. Bootcode is the firmware that allows the library to begin initialization when it is powered ON.	X	X
Barcode Reader	This is the version of barcode reader in the library.	X	X
IPv4 Address	This is the Internet Protocol v4 Address assigned to your library.	X	X
Link local IPv6 address	This is the local IPv6 address assigned to your library. Note: It can verified with library firmware of A.40 or higher.	X	X
IPv6 static assigned address	This is your library's IPv6 static assigned address.	X	X
Router discovery IPv6 address	This is the IPv6 router discovery address assigned to your library. Note: There may be more than one IPv6 discovery address if there is more than one IPv6 router available in your network environment.	X	X
MAC Address	This is the machine's access code assigned to your library.	X	X
WWide Node Name	This is the Worldwide Node Name assigned to your library.	X	X

Table 24. Library Identity page elements (continued)

Menu Item	Description	2U	4U
Logical Library x Library Mode	The Extended Logical Libraries Information table displays information about the logical libraries currently assigned in your library. For each logical library in your library, either Random or Sequential Loop Autoload will be displayed.	X	X

Library Identity	
Serial Number	78P6824
Product ID	3573-TL
Currently Installed Library Firmware	A.60 / 3.10e
Bootcode Firmware Revision	0.80
Barcode Reader	SE625
IPv4 Address	9.11.221.201
Link local IPv6 address	FE80::20E:11FF:FE14:4740
IPv6 static assigned address	2002:90B:E002:653:9:11:221:201
Router discovery IPv6 address 1	2002:90B:E002:653:20E:11FF:FE14:4740
Router discovery IPv6 address 2	2002:90B:E002:653:20E:11FF:FE14:4740
MAC Address	000E1144740
Library Mode	Random
WWide Node Name	2000000E1144740

Extended Logical Library Informations	
Logical Library 1	
Library Mode	Random
Logical Library 2	
Library Mode	Sequential Loop Autoload
Logical Library 3	
Library Mode	Random
Logical Library 4	
Library Mode	Sequential Loop Autoload

a77uq090

Figure 89. The 4U library Monitor Library: Library Identity page

This view is correct for a library with multiple logical partitions. The Library Identify screen will be different for a library with a single logical partition.

Monitor Library: Drive Identity

This page provides the following detailed information about the drive. No changes can be made from this page. The displayed information will vary depending on the library model and drive type (SCSI, SAS, or Fibre Channel). Table 25 lists all available elements on the Drive Identity page. An "X" indicates that the element displays for the specified drive type.

Table 25. Drive Identity page elements

Menu Item	Description	2U Library			4U Library		
		SCSI	Fibre	SAS	SCSI	Fibre	SAS
Vendor ID	This identifies the manufacturer of the tape drive.	X	X	X	X	X	X
Product ID	This is the Type and Model of the Library. Note: HH means Half-High drive, and TD means Full-High drive.	X	X	X	X	X	X
Serial Number	This is the unique identification number of the tape drive that was assigned by the manufacturer.	X	X	X	X	X	X
Version	Only Version 2 (V2) half-high drives will have a separate version line with the number 2.		X	X		X	X
Firmware Revision	This is the current level of firmware installed on the drive. For information on updating your firmware, refer to "Service Library: Upgrade Firmware" on page 134.	X	X	X	X	X	X
SCSI ID	This is the unique identifier assigned to the SCSI drive to enable it to receive communications from the host computer.	X			X		

Table 25. Drive Identity page elements (continued)

Menu Item	Description	2U Library			4U Library		
		SCSI	Fibre	SAS	SCSI	Fibre	SAS
Element Address	This is the unique identifier assigned to the drive that allows the host to recognize and communicate with the drive.	X	X	X	X	X	X
Control Path Drive	If the drive communicates all messages from the host to the library, then it is considered the control path drive. If the drive is the control path drive, this element displays "Yes." If not, this element displays "No." All drives in a logical library may be a control path drive.	X	X	X	X	X	X
Data Compression	If the drive is compressing data, this element displays "Yes." If not, this element displays "No."	X	X	X	X	X	X
Interface Type	This identifies the drive host interface.	X	X	X	X	X	X
Node Name	This is the Worldwide node Name assigned to a Fibre drive.		X			X	
Worldwide ID	This is the Worldwide ID assigned to a SAS drive. (Ports A and B)			X			X
Port A	This provides information about Port A.		X			X	
Port Name	This is the name assigned to a Fibre channel port that is "enabled".		X			X	
Topology	This is the type of connection to the host.		X			X	
FC-AL Loop ID	This is the Fibre Channel - Arbitrated Loop ID of the drive. Options are: LN, L or N.		X			X	
Speed	This is the current speed setting of the drive. Choices are Auto (where the drive will automatically negotiate the speed of the drive to match that of the server), 1Gb/s, 2Gb/s, 4Gb/s, or 8 Gb/s for Fibre Channel; 3 Gb/s or 6 Gb/s for SAS..		X			X	
Port B	This provides information about Port B. For Fibre Channel drives, Port B is Disabled.		X			X	

Drive Identity	1 (LUN)
Vendor ID	
Product ID	ULT3580-HH3
Serial Number	1068000539
Version	2
Firmware Revision	ACF1
World Wide ID - Port A	5000E11800245002
World Wide ID - Port B	5000E11800245003
Element Address	256
Control Path Drive	Yes
Data Compression	Yes
Interface Type	SAS

Drive Identity	2
Vendor ID	
Product ID	ULT3580-HH4
Serial Number	1K10000896
Firmware Revision	A23E
World Wide ID - Port A	5000E11800245005
World Wide ID - Port B	5000E11800245006
Element Address	257
Control Path Drive	No
Data Compression	Yes
Interface Type	SAS

a77u9288

Figure 90. The 4U library Monitor Library: Drive Identity page showing one Ultrium 3 SAS half height V2 drive (#1) and one Ultrium 4 SAS half height drive (#2)

Monitor Library: Library Status

This page displays the dynamic information about the library, such as the current status of the components. No changes can be made from this page. Table 26 lists all available elements on the Library Identity page. An "X" indicates that the element displays for the specified library type.

Table 26. Library Status page elements

Menu Item	Description	2U	4U
Status	Library status is displayed using icons with text. A checkmark with the word "Ready" indicates the library is functioning properly. An exclamation point with the word "Caution" indicates the library can function, but is experiencing a problems. An X with the word "Error" indicates the library is not functioning because of a serious problem.	X	X
Cartridge in Transport	This identifies a cartridge that is currently being moved by the accessor. "None" is displayed if no cartridge is being moved.	X	X
Number of Moves	This is the number of times the accessor has moved a cartridge from Point A to Point B (for example, from a storage slot to a drive).	X	X
Total Power On Time	This is the total amount of time that the library has been powered ON.	X	X
Accessor Status	This is the current status of the accessor.	X	X
Left Magazine	This displays whether the left magazine is "Present" or "Not Present".	X	
Right Magazine	This displays whether the right magazine is "Present" or "Not Present".	X	
1. Left Magazine	This displays whether the lower left magazine is "Present" or "Not Present".		X
1. Right Magazine	This displays whether the lower right magazine is "Present" or "Not Present".		X

Table 26. Library Status page elements (continued)

Menu Item	Description	2U	4U
2. Left Magazine	This displays whether the upper left magazine is "Present" or "Not Present".		X
2. Right Magazine	This displays whether the upper right magazine is "Present" or "Not Present".		X




Figure 91. The 4U library Monitor Library: Library Status page

Monitor Library: Drive Status

This page provides the following detailed dynamic information about the drive in the library. No changes can be made from here. The displayed information varies depending on the library model and drive type (SCSI, SAS, or Fibre Channel). Table 27 lists all available elements on the Drive Status page. An "X" indicates that the element displays for the specified drive type.

Table 27. Drive Status page elements

Menu Item	Description	2U Library			4U Library		
		SCSI	Fibre	SAS	SCSI	Fibre	SAS
Status	The status of the drive. A check mark indicates that the drive is operating properly. An exclamation point indicates that the drive is operating but has a problem. An X indicates that the drive is not operational because of a serious problem.	X	X	X	X	X	X
Cartridge in Drive	The serial number of the cartridge currently in the drive. If the drive does not contain a cartridge, "None" is displayed.	X	X	X	X	X	X
Drive Error Code	If the drive generated an error code, it is displayed here. If the drive did not generate an error, "No Error" is displayed.	X	X	X	X	X	X
Cooling Fan Active	Displays whether the drive 's cooling fan is ON (checked) or OFF.	X	X	X	X	X	X
Drive Activity	Indicates whether the drive is operating.	X	X	X	X	X	X
Port A Status	Indicates whether Port A is logged on or out.		X	X		X	X
Port B Status	Indicates whether Port B is logged on or out.			X			X
Port Name	The name that is assigned to the Port on the drive.		X			X	

Table 27. Drive Status page elements (continued)

Menu Item	Description	2U Library			4U Library		
		SCSI	Fibre	SAS	SCSI	Fibre	SAS
Speed	The speed setting of the drive. Choices are Auto (where the drive automatically negotiates the speed of the drive to match that of the server), 1 Gb/s, 2 Gb/s, 4 Gb/s, or 8 Gb/s for Fibre Channel; 3 Gb/s or 6 Gb/s for SAS.		X	X		X	X
Topology	The type of connection to the host. The choices are LN-port, N-port, and L port.		X			X	
Hashed SAS address	The Hashed SAS address is a value that is calculated from the WWID for use on the SAS interface			X			X
FC-AL Loop ID	The loop position number; it shows the numeric ID.		X			X	
Encryption Status*	The following entries show the current encryption status for this drive (method, key path, BOP, density report).		X	X		X	X
Encryption method*	The type of encryption that is enabled on the drive.		X	X		X	X
Key path*	The path that is used for transferring an encryption key. This setting is dependent upon the encryption method selected.		X	X		X	X
BOP policy*	Indicates whether the Beginning of Partition (BOP) policy is enabled or disabled. If encryption is enabled, the policy type might display depending on the encryption method used. Policy types include Internal label select, Internal label always, Enabled, or Disabled. Other type designations might display if Advanced Encryption Settings are set (Engineering Support use only).		X	X		X	X
Density reporting*	LTO drives do not support settings changes to report various densities, thus LTO drives always report (Other).		X	X		X	X

*These features are not supported on Gen3 SAS drive types or any SCSI drive types.

Drive 2 Status At 13:32:22 Library Time	
Status	✓ Idle
Cartridge In Drive	N.A.
Drive Error Code	No Error
Cooling Fan Active	✓
Drive Activity	Ready
Port A Status	Not ready, not connected
Speed	-
Hashed SAS address	000000
Encryption Status	
Encryption method	Disabled
Key path	Default by method
BOP policy	Disabled
Density reporting	Other

Drive 3 Status At 13:32:22 Library Time	
Status	✓ Idle
Cartridge In Drive	N.A.
Drive Error Code	No Error
Cooling Fan Active	✓
Drive Activity	Idle
Port A Status	No light detected

Refresh

a77ug093

Figure 92. The 4U library Monitor Library: Drive Status page

Term Definitions:

- **BOP (Beginning of Partition):** BOP (Beginning of Partition) is a SCSI term, which in a single partition format is the same as beginning of tape. It means that policy is determined on writes at LB zero. Appending to a tape [or overwriting at a non-zero LB] does not change the policy already in use for that tape.
- **Key Path:** The avenue where key resolution is completed. This avenue is left to be determined by method (and is the same), but can be set differently for some hybrid modes.
- **Density Reporting:** Affects host reporting of density and is included to support legacy needs for transparency. The default of not masking encrypted densities means that the host can see a different density code for encrypted vs non-encrypted tapes (x72 [enc] as opposed to x52 [non-enc]). This feature masks this code so the drive reports the primary density only. Normally this feature is set to the drive default (which is to show encr density).

Note: LTO drives do not support setting or reporting various densities, thus LTO drives always report 0xFE (**Other**).

Monitor Library: Inventory

This page provides detailed information about the tape inventory in the library. A summary of each magazine is shown. To get detailed information about the cartridges that reside in a magazine, click on the + button. This will expand the display for the magazine. To determine whether a cartridge is encrypted, refer to the Comments column in the Cartridge Details screen. See Figure 94 on page 114.

Inventory As Of 14:02:04 Library Time

Drive Inventory

Drive	Status	Label	Source
1	Empty	-----	

Magazine Inventory

8	9	10	11	+
4	5	6	7	
IO-Station	1	2	3	

23	22	21	20	+
19	18	17	16	
15	14	13	12	

Refresh

a77ug067

Figure 93. The 2U library Monitor Library: Inventory page




Figure 94. The 4U library Monitor Library: Inventory page (Right Magazines)

Note: The 4U graphic shows the Slot Inventory for the right magazines of this library as an example. The left magazines are similar.

Manage Library Menu

The **Manage Library** menu contains the following sub-menu items.

- “Manage Library: Move Media”
- “Manage Library: Perform Inventory” on page 115
- “Manage Library: Release Magazine” on page 115

Manage Library: Move Media

This page allows the user to move tape cartridges within the library. The source and destination are selected and then the MOVE button in the center of the screen is clicked to activate the move.




Figure 95. Manage Library: Move Media page

The following elements appear in the **Source** and **Destination** screens.

Element

In the **Source** screen, this identifies the library element that contains a cartridge. In the **Destination** screen, this identifies the library element that is empty and can receive a cartridge.

Volume Serial

In the **Source** screen, this element displays the serial number of the cartridge. In the **Destination** screen, this element contains no information.

Manage Library: Perform Inventory

This page allows the library to be re-scanned to determine the current media inventory.




Figure 96. Manage Library: Perform Inventory page

Manage Library: Release Magazine

This page allows the user to release the right or left magazine from the library.




Figure 97. Manage Library: Release Magazine page

Note: To manually release a magazine, see “Releasing the Magazines Manually” on page 175. However, this manual process should only be used if the magazine cannot be released using the Operator Control Panel or the Web User Interface.

Configure Library Menu

The **Configure Library** menu contains the following submenu items:

- “Configure Library: General”
- “Configure Library: Logical Libraries” on page 117
- “Configure Library: Path Failover” on page 118
- “Configure Library: Encryption” on page 118
- “Configure Library: Drives” on page 120
- “Configure Library: Network” on page 122
- “Configure Library: User Access” on page 123
- “Configure Library: Date & Time” on page 125
- “Configure Library: Logs & Traces” on page 125
- “Configure Library: Event Notification” on page 126
- “Configure Library: SNMP” on page 127
- “Configure Library: Save/Restore Configuration” on page 128

Configure Library: General

This page allows you to make changes to general library configuration elements. As changes are made, they will only be applied after the **Apply Selections** or the **Submit** button is selected. After making the selection, a warning page will inform you of the impact of the proposed change. In some cases a pop-up screen will ask for confirmation. Many changes will also require a library reboot.

Table 28. Configure Library: General page elements

Menu Item	Description	2U	4U
Library Name	Enter the name of the library.	X	X
I/O Station Enabled	The I/O Station defaults to I/O Station Enabled . Choosing Disabled (no checkmark) adds one more storage slot to the 2U library, and 3 more storage slots to the 4U library. When the I/O Station is disabled, removing or adding media to the library must be performed by releasing the left and/or right magazine(s).	X	X
Auto Clean Enabled	Auto Clean defaults to Disabled . For Auto Clean to function, a cleaning cartridge (CLNxxxLx) must be resident in a reserved library slot and Auto Clean must be enabled (turned on). Note: If Auto Clean is enabled, and a cleaning cartridge is not resident in a reserved slot, the Auto Clean Status field in the web System Status screen will post a "Chk Media/Rsvd Slot" message.	X	X
Bar Code Label Length Reported To Host	The default bar code label length is 8, but can be set to 6. The bar code label length is a "reported" length. This setting will cause the host computer to only see the first 6 characters of the label or all 8 characters. This setting does not affect the bar code label that is shown on any of the library user interfaces (always shows all 8 characters).	X	X

Table 29. Configure Library: Specific page elements

Menu Item	Description	2U	4U
Library Mode	Choices are Random and Sequential. If you choose Sequential, you may also activate Autoload and/or Loop. If there is more than one logical library, there is a Library Mode entry for each logical library. Important: If a Logical Library in Sequential Mode contains more than one drive, only the first drive in the Logical Library will be utilized.	X	X

Table 29. Configure Library: Specific page elements (continued)

Menu Item	Description	2U	4U
Active Slots	It may be necessary to modify the number of active slots to agree with the number of slots allowed by your host software. To modify the number of active slots in your library, click on the drop down list and select the number of slots you want active in your library. Also, the Auto Clean function requires the cleaning cartridge to be in a DCS or reserved slot. Reserved slots are created by reducing the number of active slots.	X	X

The screenshot shows a web-based configuration interface for a library. It is divided into two main sections:

- General:**
 - Library Name:** An empty text input field.
 - I/O Station Enabled:** A checked checkbox.
 - Auto Clean Enabled:** A checked checkbox.
 - Barcode Label Length Reported To Host:** A dropdown menu currently set to '8'.
- Extended Configuration for Logical Libraries:**
 - Logical Library 1:**
 - Library Mode:** Radio buttons for 'Random' (selected), 'Sequential', 'Autoload', and 'Loop'.
 - Active Slots:** A dropdown menu set to '21'.
 - Logical Library 2:**
 - Library Mode:** Radio buttons for 'Random' (selected), 'Sequential', 'Autoload', and 'Loop'.
 - Active Slots:** A dropdown menu set to '23'.

At the bottom right of the form are two buttons: 'Refresh' and 'Apply Selections'. A small vertical text 'a77ug094' is located to the right of the 'Apply Selections' button.

Figure 98. The 4U library Configure Library: General and Extended page

Configure Library: Logical Libraries

To partition your multi-drive library, select the number of logical libraries you would like to create in your library, then click **Submit**.

One cartridge magazine cannot be assigned to two logical libraries. If you partition a multi-drive library, each of the magazines must be assigned to a logical library on a magazine boundary. The entire magazine must be part of one logical library only. In a fully populated 4U library with four logical libraries, resource assignments will be as follows:

- Logical Library 1 will contain Drive 1 and the lower left cartridge magazines.
- Logical Library 2 will contain Drive 2 and the upper left cartridge magazines.
- Logical Library 3 will contain Drive 3 and the lower right cartridge magazine.
- Logical Library 4 will contain Drive 4 and the upper right cartridge magazine.

The I/O Station and the reserved slot (or dedicated cleaning slot (DCS) if one is assigned) are shared among all logical libraries.

Note: When reducing the number of drives in your library, update the Logical Library configuration. This will remove the Attention LED on the front panel and the exclamation mark on the Home screen indicating that a drive is missing.

Updating the Logical Library configuration will also update the drive element addressing and drive numbering. Replacing LTO half height drives with full height drives may require you to execute **Restore Factory Defaults** to correctly update the drive element addressing and drive numbering. See “Configure Library: Save/Restore Configuration” on page 128.




Figure 99. The 4U library Configure Library: Logical Libraries page

Configure Library: Path Failover

This page allows the user to enter the Path Failover feature activation key (Supported on 4U library only for library firmware levels at or below 8.xx. Supported on both the 2U and 4U libraries with library firmware levels above 8.xx) For information on minimum firmware levels for path failover, see “Minimum firmware levels for common library features” on page v. For more information, refer to the *Dell PowerVault TL4000 Failover Configuration Guide*, included with the library documentation.



Figure 100. The 4U library Configure Library: Path Failover page

Enter the Feature Activation key and click **Activate**. This page will display if you have entered the feature key correctly.



Figure 101. Path Failover license verification page

Note: Follow the instructions in the *Dell PowerVault TL4000 Failover Configuration Guide* to configure your environment for failover.

Configure Library: Encryption

Note: Application Managed Encryption (AME) does not require a license key. Library Managed Encryption requires a license key. Contact your TSR (technical sales representative) to purchase this feature.

Important: The Advanced Encryption Settings are for Engineering Support use only. These fields should always be set to "No Advanced Setting".

For information on minimum firmware levels for Application-Managed and Library -Managed Encryption, see “Minimum firmware levels for common library features” on page v.

Setting or Changing a Drive's Method of Encryption

1. Enter your library's IP Address in an internet browser address field and press ENTER.
2. Log in to the Web User Interface. Refer to “Login” on page 20.
3. Expand **Configure Library** in the left navigation panel.
4. Click **Encryption**.




Figure 102. Feature Activation Key screen

5. On the **Encryption** screen, enter the **Feature Activation Key** to enable the library managed encryption options.
6. Click **Activate** to save the key and expand the screen for additional encryption settings.




Figure 103. Configure Library: Encryption Feature configuration screen

7. Select **Enable SSL for EKM** to enable Secure Sockets Layer for the IBM SKLM application.
8. Select an **Encryption method**, from the pull down menu, for each logical library.
 - Without an encryption license key, select **None** or **Application Managed Encryption**.
 - With an encryption license key, select **Library Managed Encryption**.
9. Select an **Encryption policy**, from the pull down menu, for each logical library.

- **Encrypt All:** This is the default policy. It encrypts all cartridges using the default data keys specified in the key manager. This setting applies to all drives in the TL2000/TL4000 logical library.
 - **Internal Label - Selective Encryption:** Check your tape backup software application documentation to see if this feature is supported.
 - **Internal Label - Encrypt All:** Check your tape backup software application documentation to see if this feature is supported.
10. A primary and secondary key management server can be set for each logical library. Each partition has its own Encryption and key management settings. Maintaining primary and secondary key management servers are desired for maximum availability of encrypted backup and recovery. These settings are required for Library Managed Encryption only. Enter the **EKM Server Setting** information.
- **Primary IP address (IPv4 or IPv6):** Enter the IP address of the primary key management server.
 - **Primary TCP port:** After entering the Primary IP address, the library will automatically set the value of the Primary TCP port.
 - **Secondary IP address (IPv4 or IPv6):** Enter the IP address of the secondary key management server.
 - **Secondary TCP port:** After entering the **Secondary IP address**, the library will automatically set the value of the **Secondary TCP port**.

Note: The Default Port for TCP (SSL disabled) is **3801**. The Default Port for SSL is **443**. These values are the default values set by the library. They can be changed depending on the user configuration but the user has to make sure they match the IBM SKLM properties file.

Note: If SSL is enabled the encryption host configuration will request a SSL port instead of a TCP port. Review the *IBM SKLM Knowledge Center* online at <http://www-01.ibm.com/support/knowledgecenter/SSWPVP/welcome?lang=en> for instructions to locate the appropriate port settings.

11. Click **Submit** to apply the changes.
12. Install the IBM SKLM application on your host. Refer to the *IBM SKLM Knowledge Center* online for information on locating the appropriate IP address and port.

Configure Library: Drives

This page allows you to modify the current ID assigned to a SCSI or Fibre Channel drive. This page allows any drive in the library to be powered off by de-selecting the check mark in the Power On box. The displayed information will vary depending on the library model and drive type (SCSI, SAS, or Fibre Channel). Table 30 lists all available elements on this page. An "X" indicates that the element displays for the specified drive type.

Table 30. Drive Identity page elements

Menu Item	Description	2U Library			4U Library		
		SCSI	Fibre	SAS	SCSI	Fibre	SAS
SCSI ID	For each SCSI drive, click on the drop down list and select the number of the slot in which the drive is located.	X			X		
Power On	For each drive, click in the box to power ON the selected drive.	X	X	X	X	X	X
Control Path	The control path drive communicates messages from the host to the library. Select this option for each drive that you want to be a control path drive. At least one drive in each logical library must be designated as a control path drive.	X	X	X	X	X	X

Table 30. Drive Identity page elements (continued)

Menu Item	Description	2U Library			4U Library		
		SCSI	Fibre	SAS	SCSI	Fibre	SAS
Port A Configuration:							
Speed	This is the current speed setting of the drive. For each Fibre Channel drive, click on the drop down list and select Automatic, 1Gb/s, 2Gb/s, 4 Gb/s, or 8 Gb/s. For each SAS drive, select Automatic, 3 Gb/s, or 6 Gb/s. Selecting Automatic will allow library speed to automatically negotiate to the current server speed.		X			X	
Topology	For each Fibre Channel drive, click LN-Port, L-Port, or N-Port.		X			X	
FC-AL Loop ID	This is the loop position number. The options are: "Manual" or "Automatic".		X			X	
Port B Configuration:							
	Port B is supported for SAS full height drives only. Note: Port B is only supported for failover.			X			X

Drives

Drive 1 (Logical Library 1) Power On Control Path

Port A Configuration

Speed: Automatic

Topology: LN-Port

FC-AL Loop ID: 5

Port B Configuration: Port not available

Refresh Submit

a77ug064

Figure 104. The Configure Library: Drives page for a 2U library

Drives

Drive 1 (Logical Library 1) Power On Control Path

Drive 2 (Logical Library 2) Power On Control Path
Note: SAS drives do not require user configuration

SCSI ID: 6

Drive 3 (Logical Library 3) Power On Control Path

Port A Configuration

Speed: Automatic

Topology: LN-Port

FC-AL Loop ID: 6

Port B Configuration: Port not available

Refresh Submit

a77ug095

Figure 105. The Configure Library: Drives page for a 4U library

Click one of the following:

- **Refresh** - to cancel the changes made to the screen.
- **Submit** - to apply the changes made to the screen.

Note: When configuration changes of a disabled drive are made from the Operator Control Panel (OCP), the drive powers ON after committing changes. When configuration changes of a disabled drive are made from the Web Interface (RMU), the drive does not power ON after committing changes.

Configure Library: Network

This page shows the current network configuration of the library and allows modification to the configuration. When a change is requested, a pop-up box checks confirms the request.

1. Click **Network** in the left navigation pane, to display the **Network** page.

Network	
Protocol Stack	IPv6 only
Host Name	ATL008
Domain Name	storage.tucson.ibm.com
Enable SSL for Web	<input type="checkbox"/>
Ethernet Settings	Auto
IPv4	
Enable DHCP	<input type="checkbox"/>
Static Address	9.11.198.225
Subnet Mask	255.255.254.0
Gateway address	9.11.198.1
DNS Primary	0.0.0.0
DNS Secondary	0.0.0.0
IPv6	
DNS Primary	2002:90B:E006:646:9:11:224:119
DNS Secondary	2002:90B:E006:646:9:11:224:121
Enable Stateless Auto Config	<input checked="" type="checkbox"/>
Enable DHCP	<input type="checkbox"/>
Static Address	2002:90B:E006:198:9:11:198:225
Prefix length	64
Gateway address	2002:90B:E006:198::1

Figure 106. Configure Library: Network Page

Important: Do not click the Submit button until all changes have been made to the Network page. Once the Submit button has been clicked, no other changes can be made until after the library has applied the current changes.

After the Submit button has been clicked, depending on the changes made, you will either be disconnected and need to login again or reboot the library.

Clicking the Refresh button will refresh the page and any changes made will not be retained.

2. Select a **Protocol Stack** - Choose **IPv4 only**, **IPv6 only**, or **Dual Stack IPv4 & IPv6**.
If you choose **Dual Stack IPv4 & IPv6**, you must be prepared to enter both IPv4 and IPv6 IP addresses. The sections below will gray out depending on the choices made here.
3. Enter the **Host Name**.


Note: The underscore (_) is not allowed as part of a host name.

4. Enter the **Domain Name**.
5. **DNS Primary** - Enter the IP address of your primary DNS server.
6. **DNS Secondary** - Enter the IP address of your secondary DNS server.
7. **Enable SSL for Web** - If you desire to have SSL (Secure Sockets Layer) enabled, place a check in this box.

Note: If you get a security certificate alert when logging in to the Web User Interface, you can install the certificate or allow an exception (depending on the internet browser you are using). SSL is enabled when the URL begins with **https://** and some browsers will show a lock.

8. **Ethernet Settings** - Ethernet Settings choices are: **Auto** (the default), **10 Mbit/Half**, **10 Mbit/Full**, **100 Mbit/Half**, **100 Mbit/Full**. Please refer to www.Dell.com/support to determine the availability of manual Ethernet settings in your library's firmware.
9. **Enter IPv4 settings (if applicable).**
 - a. **Enable DHCP** - Click this item ON to have the IP Address of your library automatically set by the DHCP server.
 - b. **Static Address** - Enter the assigned IPv4 address. The format of an IPv4 IP address is a 32-bit numeric address written as four numbers separated by periods.
 - c. **Network Mask** - Enter the assigned IPv4 Network Mask.
 - d. **Gateway address** - Enter the assigned IPv4 Gateway address. This address allows access outside the local network.
10. **Enter IPv6 settings (if applicable).**
 - a. **Enable DHCP** - Click this item ON to have the IP Address of your library automatically set by the DHCP server.
 - b. **Enable Stateless Auto Config** - Stateless Auto config is ALWAYS on (not defeatable).
 - c. **Static Address** - Enter the assigned IPv6 address. The format of an IPv6 IP address is a 128-bit numeric address written as 8 groups of four numbers separated by colons.
 - d. **Prefix length** - The default prefix length is set to 64, but can be set to any length, depending upon the address used.
 - e. **Gateway address** - Enter the assigned IPv6 Gateway address. This address allows access outside the local network.
11. Click one of the following:
 - **Refresh** - to cancel the changes made to the screen.
 - **Submit** - to apply the changes made to the screen.

Note: Depending on the changes made, you will either be disconnected and need to login again, or reboot the library. If a reboot is required, the following Warning message will appear after the Submit button is clicked.



Warning: Changes Will Take Effect After A Reboot!

a77ug171

Figure 107. Warning Screen

The library must be rebooted or the changes will not take place.

Configure Library: User Access

This page allows the user to add and modify user accounts. See "Login" on page 20 for information about user types.

The **Configure Library > User Access** page is accessible only to the Admin and Service login. Access is denied to User and Superuser logins.

The Admin login has access to all library functions except **Service Library > Advance Diagnostics**.

The Service login has access to all library functions including **Service Library > Advance Diagnostics**.

Figure 108. Configure Library: User Access page

The following elements are displayed on the **User Access** page.

Roles

- Check the **Disable Superuser** check box if you do not want **Superuser** to be listed on the **Role** listbox (that is, prohibits Superuser login).

Check the **Disable User** check box if you do not want **User** to be listed on the **Role** listbox (that is, prohibits User login). Clear the check box to allow **Superuser** or **User** login.

Passwords

- **Role** - The name that is associated with the chosen Access Level. Choose from **User**, **Superuser**, **Admin**, or **Service**.

Note: Admin can select User, Superuser, and Admin roles. Service can select User, Superuser, Admin, and Service roles.

- **New Password (Enter Up To Twenty Characters)** - Enter a new password to be associated with the Access Level Name.
- **Repeat Password** - Reenter the new password for verification purposes.

Support Contact

- **Support Name** - The name of the individual within your company to contact for Web User Interface or library support.

Note: Only one support person is configured for the entire tape library. The support person might or might not be one of the user, superuser, or admin account holders.

- **Support Phone** - The phone number of the individual within your company to contact for Web User Interface or library support.
- **Support Email** - The email address of the individual within your company to contact for Web User Interface or library support.

Password Rules

- **Minimum Number Of Characters** - Choose the minimum password length. The factory default value is 8. Possible range for this configuration option is 8 - 20. The maximum password length is 20.

- **Minimum Number Of Upper Case Alphabetic Characters (A-Z)** - Choose the minimum number of uppercase alphabetic characters. The factory default value is 1. Possible range for this configuration option is 0 - 3.
- **Minimum Number Of Lower Case Alphabetic Characters (a-z)** - Choose the minimum number of lowercase alphabetic characters. The factory default value is 1. Possible range for this configuration option is 0 - 3.
- **Minimum Number Of Numeric Characters (0-9)** - Choose the minimum number of numeric characters. The factory default value is 1. Possible range for this configuration option is 0 - 3.
- **Minimum Number Of Special Characters (!@#\$%^&*()_+={}|[]\;:'"<>?,./)** - Choose the minimum number of special characters. The factory default value is 0. Possible range for this configuration option is 0 - 3.
- **Maximum Number Of Identical Consecutive Characters** - Choose the maximum number of identical consecutive characters. The factory default value is 2. Possible range for this configuration option is 0 - 3. There is no limitation if 0 is selected.
- **Maximum Number Of Failed Logins Before Password Is Locked** - Choose the maximum number of failed logins before the password is locked. The factory default value is 5. Possible range for this configuration option is 0 - 10. There is no limitation if 0 is selected.

Note: When a password is locked, the login cannot continue. First, you must complete a valid login with an admin account where the admin can change a password, or a restore factory default password from the operator panel (if the admin account is the one that is locked out).

- **Maximum Number Of Days Before Password Must Be Changed** - Choose the maximum number of days before the password must be changed. The factory default value is 90. Possible range for this configuration option is 0 - 365. There is no limitation if 0 is selected.

Click one:

- **Refresh** - Cancels the changes that are made to the screen.
- **Submit** - Applies the changes that are made to the screen.

Configure Library: Date & Time

This page allows the user to set the time and date, and how it will be displayed.

Figure 109. The Configure Library: Date & Time page

Time (24H)

Using a 24-hour format, enter the current hour, minutes, and seconds.

Date Enter the current month, day, and year.

Click one of the following:

- **Refresh** - to cancel the changes made to the screen.
- **Submit** - to apply the changes made to the screen.

Configure Library: Logs & Traces

This page allows service personnel to set the error log mode to **Continuous** or to **Stop trace at first error**.

Logs & Traces	
Error Log Mode	<input checked="" type="radio"/> Continuous <input type="radio"/> Stop Trace At First Error <input type="radio"/> Stopped
Trace Level	<input checked="" type="checkbox"/> Cmd <input checked="" type="checkbox"/> Response <input checked="" type="checkbox"/> Event <input checked="" type="checkbox"/> Trace Data Trace <input checked="" type="checkbox"/> Low Level Trace <input checked="" type="checkbox"/> Recovered Error <input checked="" type="checkbox"/> Hard Error
Trace Filter	<input checked="" type="checkbox"/> Main <input checked="" type="checkbox"/> Drive <input checked="" type="checkbox"/> CDB Interpreter <input checked="" type="checkbox"/> Robotic <input checked="" type="checkbox"/> Trace <input checked="" type="checkbox"/> OCP Input <input checked="" type="checkbox"/> OCP Output <input checked="" type="checkbox"/> SCSI Module <input checked="" type="checkbox"/> SDCI Module

Refresh Submit

a77ug071

Figure 110. Configure Library: Logs & Traces page

It is recommended that you select **Continuous** for the **Error Log Mode** so that all information for logs and traces will be captured.

Click one of the following:

- **Refresh** - to cancel the changes made to the screen.
- **Submit** - to apply the changes made to the screen.

Note: The trace level and trace filter selection options are only changeable by Service personnel.

Configure Library: Event Notification

This page allows the user to enter information for event notification. When set up correctly, **Event Notification** allows the library to send an email to a designated individual when the library is experiencing a problem.

Event Notification	
Notify Errors	<input type="checkbox"/> On
Notify Warnings	<input type="checkbox"/> On
To Email Address	<input type="text"/>
SMTP Server Address (IPv4)	<input type="text" value="0.0.0.0"/> <small>IPv4 address or Host name and domain *</small>
Domain Name	<input type="text"/>

Refresh Submit

a77ug065

Figure 111. Configure Library: Event Notification page

The following elements are displayed on the **Event Notification** page.

Notify Errors

Select this item to be notified of library errors via email.

Notify Warnings

Select this item to be notified of library warnings via email.

To Email Address

Enter the email address of the individual you would like to receive the errors and/or warnings.

Note: The TL2000/TL400 email address field cannot be empty (clear). The email notification setup allows the user to turn off the feature by deselecting the **notify error** and **notify warnings** boxes. The user can add an invalid email as long as the email address format is correct (i.e. a@xxx.xxx).

SMTP Server Address (IPv4 or IPv6)

Enter the address of the email server of the individual you would like to receive the errors and/or warnings. This can be an IPv4 or IPv6 address, or a host name and domain. If a host name and domain is listed, the IPv4 or IPv6 address will be resolved from the DNS using that name, and the address will be stored rather than the name. If the address changes, a new name or a new address will need to be entered.

Domain Name

Enter the Domain Name for your library. This field cannot be blank when using email notification.

Note: If you attempt to enter a blank value for the Domain Name, a warning message will appear. It will say **If you are using Email Notification then a value is required for the Domain Name.**

Click one of the following:

- **Refresh** - to cancel the changes made to the screen.
- **Submit** - to apply the changes made to the screen.

Configure Library: SNMP

This page shows the current SNMP configuration of the library and allows modification to the configuration. When a change is requested, a box checks to confirm the changes.

Click **SNMP** in the left navigation pane to display the **SNMP** page.

The screenshot displays the SNMP configuration interface, organized into three main sections:

- SNMP:** Includes a checked "Enabled" checkbox and a "Community Name" text field containing "public".
- SNMP DESTINATIONS:** Contains three rows for "Target 1 - IP Address", "Target 2 - IP Address", and "Target 3 - IP Address". Each row has a text input field (with "isv3.storage.tucson.ibm.com", "0.0.0.0", and "0.0.0.0" respectively) and a "Version" dropdown menu set to "SNMPv1". An "Audit Logging" checkbox is also checked.
- SNMP V3 SECURITY:** Includes fields for "User Name" (initial), "Authentication" (MD5), "Authentication Password" (masked with asterisks), "Privacy" (DES), and "Privacy Password" (masked with asterisks).

At the bottom right, there are "Refresh" and "Submit" buttons, and a vertical label "a77ug278".

Figure 112. Configure Library: SNMP page

Note: For information about SNMP, see “SNMP Messaging” on page 7 and Appendix F, “SNMP Status MIB Variables and Traps,” on page 237.

Note: If SNMP is not enabled (cleared), all SNMP fields are disabled.

SNMP

- **Enabled** - Check this box to have SNMP traps sent to an SNMP Management console.
- **Community Name** - An SNMP community name is a text string that acts as a password to authenticate messages that are sent between the SNMP remote management application and the library. Enter your preferred name, or leave as "public".

SNMP DESTINATIONS

- **Target 1 - IP Address** - If SNMP traps are enabled, enter an IP address where SNMP traps are sent.
- **Target 2 - IP Address** - Enter an optional second IP address where SNMP traps are sent, or leave as 0.0.0.0.
- **Target 3 - IP Address** - Enter an optional third IP address where SNMP traps are sent, or leave as 0.0.0.0.
- **Version** - The library offers three versions of the SNMP protocol; v1, v2, and v3. Select a version for each Target IP address.
- **Audit Logging** - If SNMP is enabled and Audit Logging is enabled, the library sends SNMP traps to an SNMP Management console when the library or tape drive configuration changes.

Note: This option is available only if the library firmware is 9.00 or higher, and the latest library MIB file is added to the SNMP Management console.

SNMP V3 SECURITY

- **User Name** - Enter your preferred name, or leave as "initial".
- **Authentication** - The options for Authentication are **none**, **MD5**, or **SHA**.
- **Authentication Password** - The Authentication Password must be at least 8 characters in length. If Authentication is set to **none**, this field and the **Privacy** and **Privacy Password** fields are disabled.
- **Privacy** - The options for Privacy are **none**, or **DES**. If Privacy is set to **none**, then the **Privacy Password** field is disabled.
- **Privacy Password** - The Privacy Password must be at least 8 characters in length.

Note: The factory default settings for SNMP V3 Security are

- User Name - **initial**
- Authentication - **none**
- Privacy - **none**

Configure Library: Save/Restore Configuration

This page allows the library configuration to be reset to the factory defaults.

Saving and restoring configuration data can be done using the Remote Management Unit (RMU) and/or the Operator Control Panel (OCP). The feature has been implemented on the RMU and on the OCP, but with slightly different functionality.

Note: Configuration files saved with one version of library firmware may not be compatible with other versions of firmware. It is recommended to save a configuration file each time the library firmware is upgraded. Restore the library using a configuration file that was saved with the same version of firmware currently installed in the library.

Since the RMU can be accessed remotely, its implementation will save/restore the configuration data to/from a file on the host site. When entering commands on the OCP, the unit is accessed directly. For this reason the OCP implementation will save/restore the configuration data to/from a USB memory stick that is inserted into the USB connector on the library controller.

Note: Factory defaults must be restored when the library drive is changed from a LTO half height to full height configuration, in order for the library to correct the element addressing and drive numbering. If a new drive is added to the library configuration, a restore factory default is not required.




Figure 113. Configure Library: Save/Restore page

Service Library Menu

Some Service Library functions will post a warning message stating that the library should be taken offline from the host before performing any Service functions. It is up to the operator to ensure that it is taken offline at the host. Before performing any service functions, ensure the host is not performing any data writing or retrieval.

Service Library: Clean Drive

If the library is not configured for Auto Clean, this page allows the user to manually clean the tape drive.

A drive cleaning is initiated only after the library or drive posted a status message that indicates Cleaning Required

To manually complete a drive cleaning, complete the following steps:

1. Select a cleaning cartridge that is listed in the **Slot #** field.
2. Select a drive that is listed in the **Drive** field.
3. Click **Clean**. See Figure 116 on page 130.

Note: Enabling the Auto Clean function is recommended on the library. With the Auto Clean function enabled, drive cleaning occurs automatically. The only time Auto Cleaning is disabled is when your Backup Application requires that it has control.

Drives that do not require a cleaning are labeled with **No Cleaning Required**. See Figure 114.




Figure 114. No Cleaning Required

If there is no cleaning cartridge in the library, **Clean** cannot be selected and the Slot # displays N.A.. See Figure 115




Figure 115. No cleaning cartridge in library

Note: If the library is configured for Auto Clean, and a cleaning cartridge is resident in a reserved slot, the library automatically loads the drive with a cleaning cartridge. The drive completes a cleaning and the library returns the cleaning cartridge to the reserved slot. If Auto Clean is enabled and a cleaning

cartridge is **not** present in a reserved slot, Auto Clean status on the Web User Interface Status screen shows **Chk Media/Rsvd Slot**.

Clean Drive	
Slot #	45
Drive	3
Clean	

Figure 116. Service Library: Clean Drive page

Service Library: Advanced Diagnostics (for Service Personnel Only)

This menu is for use by Service Personnel only.

Service Library: View Logs

This page allows the library logs to be viewed after entering the following:

- Log Type
 - **Error Trace:** Logs all the error messages
 - **Informational Trace:** Logs all the informational messages created as the library operates
 - **Warning Trace:** Logs all warning messages created by the library. Warning messages will not stop a library's operation but does remind the user of issues that may become a problem. Example: Invalid Media.
 - **Configuration Change Trace:** Logs any configuration changes made, such as changing/adding partitions, changing SCSI addresses, removing a DCS, etc.
 - **Standard Trace:** Logs all library operations

Note: Ensure that all the pop-up facilities on the web browser are set to enable pop-up boxes to appear. For example, on Microsoft Internet Explorer, under **Tools**, ensure that the Pop-up Blocker is turned OFF and **Internet Options > Security > Custom Level > Downloads > Automatic Prompting** for file Downloads and **File Downloads** are both Enabled.

- Total Number of Entries
- Start Entry
- Number of Entries per Page
- View
- Clear Log - Clears the log you are viewing
- Dump Log - Dumps the log you are viewing
- Save Service Dump - Creates a DPA (Dump All) log output that can be viewed or saved to a file

<Prev | Next> buttons appear if the number of logs entries exceeds the number of entries per page. Click <Prev | Next> to index through the log entries. The 'Next' button will not be displayed if the log has more fewer entries than the '# of entries per page' setting. After clicking the 'Next' button, the 'Prev' button will be displayed. If the log entries fit on a single page the <Prev | Next> buttons do not appear.




Figure 117. Service Library: View Logs page

Service Library: View Drive Logs

This page allows the drive logs to be viewed after selecting the following:

- Log Type
 - **Error:** Logs drive error code information.
 - **SCSI:** Logs ASC/ASCQ and FSC information.
- Additional Sense Code (ASC)
- Additional Sense Code Qualifier (ASCQ)
- Fault Symptom Code (FSC)



Figure 118. Service Library: View Drive Logs screen

Service Library: Save Drive Dump

This menu item allows a drive memory dump to be saved to the host computer.

1. Select the drive.
2. Choose the regular drive memory dump option (data that is stored in flash), or the forced drive memory dump option (data that is stored in memory and moved to flash).
3. Click **Save Drive Dump**.

When **Save Drive Dump** is clicked, the user has the option of saving the drive memory dump to their hard disk drive. The progress status for the drive memory dump is shown on the System Status screen to the right of the main Web User Interface screen.

Note: It is recommended that both a regular and forced drive memory dumps be created and saved.

Note: Ensure that all the pop-up facilities on the web browser are set to allow pop-up boxes to display. With Microsoft Internet Explorer, under **Tools**, ensure that the pop-up blocker is turned OFF and **Internet Options > Security > Custom Level > Downloads > Automatic Prompting** for file **Downloads and File Downloads** are both Enabled.

When the memory dumps are saved on the hard disk, they can be e-mailed to Tech Support for analysis, if needed.

Note: The memory dump might take up to 20 minutes to complete. The System Status portion of the screen shows "Drive Dump in Progress" with the number of KBs transferred.




Figure 119. Service: Save Drive Dump

Service Library: Perform Diagnostics

Note: When running the "System Test", the library must contain at least the same number of data cartridges as there are drives in that library. For example, if your library has 4 drives installed, you must have 4 or more data cartridges in the library prior to the start of the test. If there are fewer data cartridges than drives in the library, an error message "Slot Empty" will occur, and the test will not complete successfully. The media type must be compatible with the drive type. Otherwise, an error message "Incompatible Media" will occur and the test will fail.

This page provides the system administrator with general tests to verify the usability and reliability of the library. The "System Test" will use resident data cartridges to test the load and unload capability of the drives, and ensure that the library mechanics are working satisfactorily. No data will be written to the cartridges and the cartridges will be returned to their normal slot location. The "Slot To Slot" test will move each resident data cartridge from one slot to another, for each test cycle requested. When completing the "Slot To Slot" test, you will need to Inventory your library before placing it back online, since this test scrambles the cartridge slot locations.

The user selects the number of test cycles before starting the test from the EXECUTE button. To cancel the test before it completes the cycles, select the STOP button.

Note: The Web User Interface System Status screen will indicate progress and completion of the activity.




Figure 120. Service Library: Perform Diagnostics page

The first field can be modified to set the number of cycles. The second field displays the cycles completed.

Service Library: Key Path Diagnostics

Please refer to www.Dell.com/support to determine the availability of this feature.

Important: Ensure that library firmware and drive firmware are up to date before running the Key Path Diagnostic. Library firmware level must be greater than 6.xx. See “Verifying/Updating Firmware” on page 56.

The key path diagnostics test provides the ability to perform diagnostics on the encryption key path. Only drives that are set up for library managed encryption will be tested. Only encryption capable drives in logical libraries that are configured for Library Managed Encryption will be tested. To configure the library for encryption, refer to “Configure Library: Encryption” on page 118.

The test consists of four parts:

- **Drive Test:** The library performs a drive communication test to confirm communication with the drive.
- **Ethernet Test:** For each key management IP address, the library performs a ping test and records the results.
- **EKM Path Test:** For each key management IP address that passed the ping test, the library performs a communication test.
- **EKM Config Test:** This test confirms that a drive is correctly configured in the key manager to service key requests.

To run the Key Path Diagnostic, complete the following procedure.

1. Log on to the Web User Interface. Refer to “Login” on page 20.
2. Quiesce all drives, then unload all drives.
3. Click **Service Library**, then **Key Path Diagnostics**.

Drive	IP Address	Drive Test	Ethernet Test	EKM Path Test	EKM Config Test
1	9.11.221.224	Passed	Passed	Failed	N/A
	9.11.221.242	Passed	Passed	In Progress	
2	N/A				
	N/A				
3	9.11.221.204	Passed	Passed	Failed	N/A
	9.11.221.224	Passed	Passed	In Progress	

01/02/2008 15:25:40

a77ug193

Figure 121. Service Library: Perform Key Path Diagnostics page

4. Click **Start Tests**.

Note: If you have just enabled encryption on your library, wait for all LME drives to be displayed in the table and the **Start Tests** button to become active.

Each test will show a result of "Passed" or "Failed". If a test fails the remaining tests will not be executed, and the test will show a result of "N/A". The IP Address may show "N/A" for the following reasons:

1. Drive is not encryption capable.
2. EKM Server Settings, on the **Configure Library > Encryption** page, are not configured correctly.

Test results will clear:

- When the test is rerun
- When the library is rebooted

The time and date of the last test will appear below the Key Path Diagnostics screen. If any of the tests fail, refer to “Troubleshooting” on page 149 for additional information.

Service Library: Upgrade Firmware

Consider these recommendations to provide maximum performance and reliability:

1. The latest version of microcode must be installed on your Dell tape libraries and devices.
2. The library code must be updated first, unless noted otherwise. This action supports any changes that are introduced in the library code for that drive, or any changes that are made to the drive for that release.
3. These firmware updates are intended to increase overall reliability, improve tape handling, reduce the possibility of data errors, and enhance diagnostic capabilities.

Note: Library firmware and tape drive firmware are verified and released together. When you are updating to the latest firmware, verify that all installed components such as tape drive, and library are at the latest levels noted on the Support website. Mixing different levels of library and tape drive firmware is not supported and might cause unpredictable results.

This page displays the current library and drive firmware versions. Firmware is downloaded to the host, then uploaded to the drive or library.

Click **Browse...** to choose the firmware file you downloaded from the website for the library or drive you want to update. (You can update only one device at a time). Be sure that you choose the correct firmware for the library or drive type. Click **Update** to initiate the file transfer and firmware update.

Note: During the update, no host drive action is possible. The drive update takes approximately 5 minutes. The system status panel (in the right of the browser window) changes from "update" to "ready".

If incompatible firmware is transferred to the library or drive the **Update** function terminates with a message that indicates incompatible firmware. If the library has a BCR (barcode reader) that requires 9.00 or greater firmware, the **Update** function terminates with a message that indicates the library requires firmware 9.00 or higher.

To ensure that the drive is updated with the correct firmware, refer to the drive identification information provided in the Upgrade Library Firmware banner. Ensure that the drive firmware is for the correct drive type (Full Height, Half Height), correct protocol (SCSI, SAS, Fibre Channel), and correct version (V2). Drive code for V2 drives is not compatible with drives that are not V2.

V2 drive firmware compatibility

- ULT3580-HH3 drives
 - Firmware for the LTO3 HH drive is not compatible with the LTO3 HH V2 drive
 - Firmware for the LTO3 HH V2 drive is not compatible with the LTO3 HH drive
- ULT3580-HH4 drives
 - Firmware for the LTO4 HH drive is not compatible with the LTO4 HH V2 drive
 - Firmware for the LTO4 HH V2 drive is not compatible with the LTO4 HH drive
- ULT3580-HH5 drives
 - The latest firmware for the LTO5 HH drive is compatible with all LTO5 HH drives. Upgrade the drive with the latest firmware if the drive **Update** function terminates with a message that indicates incompatible firmware.

Upgrade Library Firmware	
Currently Installed Library Firmware	10gA
Library Firmware File	<input type="text"/> <input type="button" value="Browse..."/>
<input type="button" value="Update"/>	

Upgrade Drive 1 (LTO3 HH SAS V2) Firmware	
Drive Firmware Revision	ACF1
Drive Firmware File	<input type="text"/> <input type="button" value="Browse..."/>
<input type="button" value="Update"/>	

Upgrade Drive 2 (LTO4 HH SAS) Firmware	
Drive Firmware Revision	A23E
Drive Firmware File	<input type="text"/> <input type="button" value="Browse..."/>
<input type="button" value="Update"/>	

a77ug289

Figure 122. The Service Library: Upgrade Firmware page, showing one Ultrium 3 SAS Half Height V2 drive and one Ultrium 4 SAS Half Height drive.

Service Library: Reboot

Important: Some options of the Web User Interface take the library OFFLINE. This inactive mode can interfere with host-based application software, causing data loss. Ensure that the library is idle before attempting to perform any remote operations that will take the library OFFLINE.

This page is used to perform a library reboot. There is a default time delay when the Web User Interface page refreshes itself. This time should be sufficient to reload the page. However, during a reboot, the connection to the library may be lost. If the connection is lost, the user will have to reload the page manually.

Click the **Reboot** button to initiate the reboot.

Reboot
<input type="button" value="Reboot"/>

a77ug077

Figure 123. Service Library: Reboot page

Import and Export Media during Normal Library Operation

Import Media

Data cartridges can be inserted and taken out of a magazine while the library is in operation. If the library contains an I/O Station, and you wish to import media, follow these steps:

1. From the OCP Main Menu, select **Control > Open I/O Station**. The I/O Station will unlock itself. The I/O station slot opens, and the "Unlocking I/O station" message displays. Wait for the "Insert/remove cartridge and close I/O station" message to insert or remove the cartridge, then close the I/O station by gently pushing the slot back into the left magazine.

Note: It is recommended to wait for the messages before you insert or remove cartridges to ensure that the library is ready to handle the cartridges.

2. Pull out the I/O Station and insert a data cartridge(s). On a 2U library, only 1 cartridge can be inserted at a time. On the 4U library, 3 cartridges can be inserted at one time.
3. Close the I/O Station. The library will automatically start an inventory. The cartridges in the I/O Station will be counted but unassigned until they are moved into storage slots.

4. From the OCP Main Menu, select **Control > Move Cartridges** and move the data cartridges into the desired data slots. See “Control: Move Cartridges” on page 91 or “Manage Library: Move Media” on page 114 for more information.

If the library does not have an I/O Station (all slots are assigned to storage), and you wish to import media, you will need to release a magazine and insert the cartridges manually following these steps:

1. From the OCP Main Menu, select **Control > Magazine**. Choose the desired magazine to unlock/remove.
2. Pull out the magazine and insert a data cartridge(s) into the empty slots.
3. Push the magazine back into the library. The library will automatically start an inventory.
4. To move cartridges in the magazine once they are inserted, from the OCP Main Menu, select **Control > Move Cartridges** and move the data cartridges into the desired slots. See “Control: Move Cartridges” on page 91 or “Manage Library: Move Media” on page 114 for more information.

Note: If you run a library configuration backup program on your host computer, use the program to run an audit of the library after new cartridges have been added to update the backup program.

Export Media

To remove cartridges from your library using your I/O Station, follow these steps:

1. From the OCP Main Menu, select **Control > Move Cartridges** and move the data cartridges into the I/O Station. See “Control: Move Cartridges” on page 91 or “Manage Library: Move Media” on page 114 for more information.
2. From the OCP Main Menu, select **Control > Open I/O Station**. The I/O Station will unlock itself. The I/O station slot opens, and the "Unlocking I/O station" message displays. Wait for the "Insert/remove cartridge and close I/O station" message to insert or remove the cartridge, then close the I/O station by gently pushing the slot back into the left magazine.

Note: It is recommended to wait for the messages before you insert or remove cartridges to ensure that the library is ready to handle the cartridges.

3. Pull out the I/O Station and take out the data cartridge(s).
4. Push the I/O Station back into the library. The library will automatically start an inventory of the I/O Station.

If you do not have an I/O Station (all slots are assigned to storage), and wish to export media, you will need to release a magazine and take out the cartridges manually following these steps:

1. From the OCP Main Menu, select **Control > Magazine**. Choose the magazine you wish to unlock/remove.
2. Pull out the magazine and remove the desired data cartridge(s).
3. Push the magazine back into the library. The library will automatically start an inventory.

Note: If you run a library configuration backup program on your host computer, use the program to run an audit of the library after cartridges have been removed to update the backup program.

Configuring I/O Stations and Reserving Slots

2U libraries usually have 1 slot for an I/O Station, while 4U libraries have 3 slots assigned as an I/O Station. These slots can be configured as storage if needed.

To configure the I/O Station using the Web User Interface, follow these steps.

- Go to **Configure Library->General**.

- To enable the I/O Station, place a check mark in the **I/O Station Enabled** box. If it is checked as enabled, the first 3 physical slots in the lower left magazine in a 4U or the first physical slot in the left magazine in a 2U is configured as an I/O station. If the I/O Station Enabled box is not checked, the slots are configured as storage.

Note: The number of I/O Station slots and storage are automatically assigned when the **I/O Station Enabled** box is checked or unchecked.

Dedicated Cleaning Slot

Earlier versions of the 4U library contained a Dedicated Cleaning Slot (DCS). This DCS can be retained and is supported by future library firmware updates. Library firmware after 1.95 will allow removal of the DCS, thus enabling this slot to be used as a storage slot.

To remove the DCS, perform the following procedures using the Operator Control Panel (OCP).

1. Navigate to the Library Settings (Logical Library Settings) screen **Configure > Library Settings (or Logical Library Settings)**.
2. Select **General**.
3. Scroll down to **Remove DCS**.
4. Select **No** or **Yes**.
5. Select **Save** then press the **Enter** button.

Attention: If your library originally contained a Dedicated Cleaning Slot and was removed, it can only be reinstated by restoring factory default settings.

To enable automatic cleaning of the drives when needed, a slot must be reserved, a cleaning cartridge must be present in the reserved slot, and Auto Clean must be enabled.

Reserving Slots

Reserving a slot is accomplished by reducing the **Active Slot** count in any particular logical library. Slots are reserved beginning with the last available slot in the last magazine of the library. A cleaning cartridge in a reserved slot is available to any logical library drive even if the reserved slot is not in that logical library. Typically, if the library contains multiple logical libraries, the last logical library is chosen for the reserved slot containing the cleaning cartridge. As with a library with a single logical library, this slot is the last physical slot in the library (top right magazine, uppermost rear slot).

Note: Configure the required number of reserved slots prior to enabling Auto Clean.

To reserve a cleaning slot, follow these steps.

- To reserve slots in your library, go to the Web User Interface at “Choosing General Library Settings” on page 57 or the Operator Control Panel at “Configure: Library” on page 94 to get directions on reducing the Active slot count.

Using Ultrium Media

Figure 124 shows the LTO Ultrium Data Cartridge and its components.

- | | | | |
|----------|----------------------|----------|----------------------|
| 1 | LTO cartridge memory | 4 | Write-protect Switch |
| 2 | Cartridge door | 5 | Label area |
| 3 | Leader Pin | 6 | Insertion guide |




Figure 124. The LTO Ultrium Data Cartridge

Note: The same components are on all the LTO Ultrium Data Cartridges.

Data Cartridges

The different generations of Ultrium data cartridges can be identified by color:

Table 31. Cartridge Types and Colors

Type	Color
Ultrium 8	Burgundy
Ultrium 8 WORM	Burgundy and Silvery gray
Ultrium 7	Purple
Ultrium 7 WORM	Purple and Silvery gray
Ultrium 6	Black
Ultrium 6 WORM	Black and Silvery gray
Ultrium 5	Burgundy
Ultrium 5 WORM	Burgundy and Silvery gray
Ultrium 4	Green
Ultrium 4 WORM	Green and Silvery gray
Ultrium 3	Slate Blue
Ultrium 3 WORM	Slate Blue and Silvery gray
Ultrium 2	Purple

Table 31. Cartridge Types and Colors (continued)

Type	Color
Ultrium 1	Black

All generations contain 1/2-inch, dual-coat, magnetic tape.

When processing tape in the cartridges, Ultrium Tape Drives use a linear, serpentine recording format. The native data capacity and recording format of Ultrium data cartridges is as follows:

Table 32. Cartridge Data Capacity and Recording Formats

Type	Native Data Capacity	Recording Format
Ultrium 8	12000 GB (30000 GB at 2.5:1 compression)	Reads and writes data on 6656 tracks, 32 tracks at a time
Ultrium 7	6000 GB (15000 GB at 2.5:1 compression)	Reads and writes data on 3584 tracks, 32 tracks at a time
Ultrium 6	2500 GB (6250 GB at 2.5:1 compression)	Reads and writes data on 2176 tracks, sixteen tracks at a time
Ultrium 5	1500 GB (3000 GB at 2:1 compression)	Reads and writes data on 1280 tracks, sixteen tracks at a time
Ultrium 4	800 GB (1600 GB at 2:1 compression)	Reads and writes data on 896 tracks, sixteen tracks at a time.
Ultrium 3	400 GB (800 GB at 2:1 compression)	Reads and writes data on 704 tracks, sixteen tracks at a time
Ultrium 2	200 GB (400 GB at 2:1 compression)	Reads and writes data on 512 tracks, eight tracks at a time
Ultrium 1	100 GB (200 GB at 2:1 compression)	Reads and writes data on 384 tracks, eight tracks at a time

The first set of tracks is written from near the beginning of the tape to near the end of the tape. The head then repositions to the next set of tracks for the return pass. This process continues until all tracks are written and the cartridge is full, or until all data is written.

The cartridge door (**2** Figure 124 on page 139) protects the tape from contamination when the cartridge is out of the drive. The tape is attached to a leader pin (**3** in in Figure 124 on page 139) behind the door. When the cartridge is inserted into the drive, a threading mechanism pulls the pin (and tape) out of the cartridge, across the drive head, and onto a non-removable take-up reel. The head can then read or write data from or to the tape.

The write-protect switch (**4** in Figure 124 on page 139) prevents data from being written to the tape cartridge. For more information, see “Write-Protect Switch” on page 144.

The label area (**5** in Figure 124 on page 139) provides a location to place a label. .

The insertion guide (**6** in Figure 124 on page 139) is a large, notched area that prevents the cartridge from being inserted incorrectly.

Table 33. Nominal Cartridge Life: Load/Unload Cycles

Type	Load/Unload Cycles
Ultrium 8	20,000 (20k)
Ultrium 7	20,000 (20k)
Ultrium 6	20,000 (20k)

Table 33. Nominal Cartridge Life: Load/Unload Cycles (continued)

Type	Load/Unload Cycles
Ultrium 5	20,000 (20k)
Ultrium 4	20,000 (20k)
Ultrium 3	20,000 (20k)
Ultrium 2	10,000 (10k)
Ultrium 1	5000 (5k)

Cartridge Compatibility

Table 34. Ultrium data cartridge compatibility with Ultrium tape drive

Tape Drive	LTO Ultrium Data Cartridges							
	12000 GB Ultrium 8	6000 GB Ultrium 7	2500 GB Ultrium 6	1500 GB Ultrium 5	800 GB Ultrium 4	400 GB Ultrium 3	200 GB Ultrium 2	100 GB Ultrium 1
Ultrium 8	Read/Write	Read/Write						
Ultrium 7		Read/Write	Read/Write	Read only				
Ultrium 6			Read/Write	Read/Write	Read only			
Ultrium 5				Read/Write	Read/Write	Read only		
Ultrium 4					Read/Write	Read/Write	Read only	
Ultrium 3						Read/Write	Read/Write	Read only
Ultrium 2							Read/Write	Read/Write
Ultrium 1								Read/Write

WORM (Write Once, Read Many) Cartridges

Certain records retention and data security applications require a Write Once, Read Many (WORM) method for storing data on tape. The LTO Ultrium 4 and later drives enable WORM support when a WORM tape cartridge is loaded into the drive.

WORM Media

Because standard read/write media are incompatible with the WORM feature, a specially formatted WORM tape cartridge (see Figure 125 on page 142) is required. Each WORM cartridge has a unique, worldwide cartridge identifier (WWCID), which comprises the unique CM chip serial number and the unique tape media serial number. Ultrium WORM cartridges are two-tone. The top half is the color of the data cartridge and the bottom half is silvery gray.




Figure 125. Ultrium Data and WORM Tape Cartridges

Data Security on WORM Media

Certain built-in security measures help ensure that the data written on a WORM cartridge does not become compromised, for example:

- The format of a WORM Tape Cartridge is unlike that of standard read/write media. This unique format prevents a drive that lacks WORM-capable firmware from writing on a WORM tape cartridge. For LTO 8, native data capacity is 12000 GB and compressed data capacity is 30000 GB.
- When the drive senses a WORM cartridge, the firmware prohibits the changing or altering of user data already written on the tape. The firmware keeps track of the last appendable point on the tape.

WORM Media Errors

The following conditions cause WORM media errors to occur:

- Information in the servo manufacturer's word (SMW) on the tape must match information from the cartridge memory (CM) module in the cartridge. If it does not match, a media Error Code 7 will post on the drive's single-character display (SCD).
- Inserting a WORM tape cartridge into a drive that is not compatible with WORM causes the cartridge to be treated as an unsupported medium. The drive will report a media Error Code 7. Upgrading the drive firmware to the correct code level will resolve the problem.

Cleaning Cartridge

With each library, a specially labeled LTO Ultrium Cleaning Cartridge is supplied to clean the drive head. The drive itself determines when a head needs to be cleaned. It alerts you by lighting the "Clean Drive" (amber LED) above the library Operator Control Panel. To clean the head manually, insert a cleaning cartridge into the tape load compartment (see "Inserting the Cleaning Cartridge" on page 74). The drive performs the cleaning automatically. When the cleaning is finished, the drive ejects the cartridge, and the library turns the "Clean Drive" LED off. Some libraries have an Auto Clean function which, when enabled, will prompt the library to retrieve the cleaning cartridge that resides in the library, insert it in the drive that needs cleaning, clean the drive, then return the cleaning cartridge to its home slot.

Note: The drive will automatically eject an expired cleaning cartridge.

The Cleaning Cartridges are valid for 50 uses.

Bar Code Label

A bar code label contains:

- A volume serial number (VOLSER) that is human-readable
- A bar code that the library can read

Note: The LTO Ultrium Tape Drives do not require bar code labels, but you may choose to use labels for tape cartridge identification purposes.

Table 35. Bar code label requirements for Ultrium tape drives and libraries

Ultrium Tape Drive/Library	Bar Code Label Requirements
3555	Required
3573	Required
3576	Required
3580	Not required
3581	Required with optional Bar Code Reader
3582	Required
3583	Required
3584	Required

When read by a library's bar code reader, the bar code identifies the cartridge's VOLSER to the library. The bar code also tells the library whether the cartridge is a data cartridge or cleaning cartridge. In addition, the bar code includes the two-character media-type identifier Lx, where x equals 1, 2, 3, 4, 5, 6, 7, or 8. L identifies the cartridge as an LTO cartridge and the number represents the generation of cartridge for that cartridge type. Figure 126 on page 144 shows a sample bar code label for the LTO Ultrium Tape Cartridge.

Tape cartridges can be ordered with the labels included or with custom labels.

Table 36. Cartridges and VOLSERs compatible with the Ultrium Tape Drives

Cartridges	VOLSER
Ultrium 8 Data Cartridge	xxxxxxL8
Ultrium 8 WORM Cartridge	xxxxxxLY
Ultrium 7 Data Cartridge	xxxxxxL7
Ultrium 7 WORM Cartridge	xxxxxxLX
Ultrium 6 Data Cartridge	xxxxxxL6
Ultrium 6 WORM Cartridge	xxxxxxLW
Ultrium 5 Data Cartridge	xxxxxxL5
Ultrium 5 WORM Cartridge	xxxxxxLV
Ultrium 4 Data Cartridge	xxxxxxL4
Ultrium 4 WORM Cartridge	xxxxxxLU
Ultrium 3 Data Cartridge	xxxxxxL3
Ultrium 3 WORM Cartridge	xxxxxxLT
Ultrium 2 Data Cartridge	xxxxxxL2
Ultrium 1 Data Cartridge (READ ONLY)	xxxxxxL1
LTO Ultrium Cleaning Cartridge	CLNxxxxLx
*An Ultrium 3 Tape Drive must have a minimum firmware level of 54xx for it to be compatible with the WORM cartridge.	

To determine the complete specifications of the bar code and the bar code label, contact your sales representative.

When attaching a bar code label to a tape cartridge, place the label only in the recessed label area (see **5** in Figure 124 on page 139). A label that extends outside of the recessed area can cause loading problems in the drive.

Attention: Do not place any type of mark on the white space at either end of the bar code. A mark in this area may prevent the library from reading the label.




Figure 126. Sample bar code label on the LTO Ultrium 8 Tape Cartridge. The volume serial number (LTO123) and bar code are printed on the label.


Guidelines for Using Bar Code Labels

Apply the following guidelines whenever using bar code labels:

- Do not reuse a label or reapply a used label over an existing label.
- Before you apply a new label, remove the old label by slowly pulling it at a right angle to the cartridge case.
- Use peel-clean labels that do not leave a residue after being removed. If there is glue residue on the cartridge, remove it by gently rubbing it with your finger. Do not use a sharp object, water, or a chemical to clean the label area.
- Examine the label before applying it to the cartridge. Do not use the label if it has voids or smears in the printed characters or bar code (a library's inventory operation will take much longer if the bar code label is not readable).
- Remove the label from the label sheet carefully. Do not stretch the label or cause the edges to curl.
- Position the label within the recessed label area (see **5** in Figure 124 on page 139).
- With light finger pressure, smooth the label so that no wrinkles or bubbles exist on its surface.
- Verify that the label is smooth and parallel, and has no roll-up or roll-over. The label must be flat to within 0.5 mm (0.02 in.) over the length of the label and have no folds, missing pieces, or smudges.
- Do not place other machine-readable labels on other surfaces of the cartridge. They may interfere with the ability of the drive to load the cartridge.

Write-Protect Switch

The position of the write-protect switch on the tape cartridge (see **1**) determines whether you can write to the tape. If the switch is set to:

- The locked position  (solid red), data cannot be written to the tape.
- The unlocked position (black void), data can be written to the tape.

If possible, use your server's application software to write-protect your cartridges (rather than manually setting the write-protect switch). This allows the server's software to identify a cartridge that no longer

contains current data and is eligible to become a scratch (blank) data cartridge. Do not write-protect scratch (blank) cartridges; the tape drive will not be able to write new data to them.

If you must manually set the write-protect switch, slide it left or right to the desired position.




Figure 127. Setting the write-protect switch

Table 37. Location of the write-protect switch

1	Write-Protect Switch
----------	----------------------

Handling the Cartridges

Attention: Do not insert a damaged tape cartridge into the drive. A damaged cartridge can interfere with the reliability of a drive and may void the warranties of the drive and the cartridge. Before inserting a tape cartridge, inspect the cartridge case, cartridge door, and write-protect switch for breaks.

Incorrect handling or an incorrect environment can damage cartridges or their magnetic tape. To avoid damage to your tape cartridges and to ensure the continued high reliability of your LTO Ultrium Tape Drives, use the following guidelines:

Provide Training

- Post procedures that describe proper media handling in places where people gather.
- Ensure that anyone who handles tape has been properly trained in handling and shipping procedures. This includes operators, users, programmers, archival services, and shipping personnel.
- Ensure that any service or contract personnel who perform archiving are properly trained in media-handling procedures.
- Include media-handling procedures as part of any services contract.
- Define and make personnel aware of data recovery procedures.

Ensure Proper Packaging

- When shipping a cartridge, use the original or better packaging.
- Always ship or store a cartridge in a jewel case.
- Use only a recommended shipping container that securely holds the cartridge in its jewel case during transportation.
- Never ship a cartridge in a commercial shipping envelope. Always place it in a box or package.

- If you ship the cartridge in a cardboard box or a box of a sturdy material, ensure the following:
 - Place the cartridge in polyethylene plastic wrap or bags to protect it from dust, moisture, and other contaminants.
 - Pack the cartridge snugly; do not allow it to move around.
 - Double-box the cartridge (place it inside a box, then place that box inside the shipping box) and add padding between the two boxes (see Figure 128).



Figure 128. Double-boxing tape cartridges for shipping

Provide Proper Acclimation and Environmental Conditions

- Before you use a tape cartridge, acclimate it to the operating environment for 24 hours or the time necessary to prevent condensation in the drive (the time will vary, depending on the environmental extremes to which the cartridge was exposed).
- Ensure that all surfaces of a cartridge are dry before inserting it.
- Do not expose the cartridge to moisture or direct sunlight.
- Do not expose recorded or blank cartridges to stray magnetic fields of greater than 100 oersteds (for example, terminals, motors, video equipment, X-ray equipment, or fields that exist near high-current cables or power supplies). Such exposure can cause the loss of recorded data or make the blank cartridge unusable.
- Maintain the conditions that are described in “Environmental and Shipping Specifications for Tape Cartridges” on page 147.

Perform a Thorough Inspection

After purchasing a cartridge and before using it, perform the following steps:

- Inspect the cartridge's packaging to determine potential rough handling.
- When inspecting a cartridge, open only the cartridge door. Do not open any other part of the cartridge case. The upper and lower parts of the case are held together with screws; separating them destroys the usefulness of the cartridge.
- Inspect the cartridge for damage before using or storing it.
- Inspect the rear of the cartridge (the part that loads first into the tape load compartment) and ensure that there are no gaps in the seam of the cartridge case. If there are gaps in the seam (see Figure 129 on page 147), the leader pin may be dislodged.




Figure 129. Checking for gaps in the seams of a cartridge

- Check that the leader pin is properly seated.
- If you suspect that the cartridge has been mishandled but it appears usable, copy any data onto a good cartridge immediately for possible data recovery. Discard the mishandled cartridge.
- Review handling and shipping procedures.

Handle the Cartridge Carefully

- Do not drop the cartridge. If the cartridge drops, slide the cartridge door back and ensure that the leader pin is properly seated in the pin-retaining spring clips.
- Do not handle tape that is outside the cartridge. Handling the tape can damage the tape's surface or edges, which may interfere with read or write reliability. Pulling on tape that is outside the cartridge can damage the tape and the brake mechanism in the cartridge.
- Do not stack more than six cartridges.
- Do not degauss a cartridge that you intend to reuse. Degaussing makes the tape unusable.

Environmental and Shipping Specifications for Tape Cartridges

Before you use a tape cartridge, acclimate it to the operating environment for 24 hours or the time necessary to prevent condensation in the drive (the time will vary, depending on the environmental extremes to which the cartridge was exposed).

The best storage container for the cartridges (until they are opened) is the original shipping container. The plastic wrapping prevents dirt from accumulating on the cartridges and partially protects them from humidity changes.

When you ship a cartridge, place it in its jewel case or in a sealed, moisture-proof bag to protect it from moisture, contaminants, and physical damage. Ship the cartridge in a shipping container that has enough packing material to cushion the cartridge and prevent it from moving within the container.

Table 38 on page 148 gives the environment for operating, storing, and shipping LTO Ultrium Tape Cartridges.

Table 38. Environment for operating, storing, and shipping the LTO Ultrium Tape Cartridge

Environmental Factor	Environmental Specifications			
	Operating	Operational Storage ¹	Archival Storage ²	Shipping
Temperature	10 to 45°C(50 to 113°F)	16 to 32°C(61 to 90°F)	16 to 25°C(61 to 77°F)	-23 to 49°C(-9 to 120°F)
Relative humidity (non-condensing)	10 to 80%	20 to 80%	20 to 50%	5 to 80%
Maximum wet bulb temperature	26°C(79°F)	26°C(79°F)	26°C(79°F)	26°C(79°F)
Note:				
1. The short term or operational storage environment is for storage durations of up to six months.				
2. The long term or archival storage environment is for durations of six months up to ten years.				

Troubleshooting

- The library consists of the following CRUs (Customer Replaceable Units):
 - Control Card (electronics, processor, memory, etc.)
 - Power Supply
 - Drive Sled (drive plus drive-to-library connectivity)
 - Cartridge Magazines
- **Service Spare:**
 - Library Enclosure (accessor, Operator control panel display, etc.)
- **Other possible Replacement Parts are:**
 - Data Cartridges
 - Cables/Terminator

Important: Before replacing any CRU and after finding the problem and performing any listed actions listed in the Troubleshooting Table below, be sure to review the “Procedures for Isolating CRU Problems” on page 155 to help confirm the failing CRU.

The following table is the starting point for all service issues. Find the reason which closest resembles the problem you are experiencing and perform the listed action. If you are unable to correct the problem, create a prioritized list of replacement parts required. Select only one CRU at a time starting with the most likely based on the “Procedures for Isolating CRU Problems” on page 155 and/or the error code listing.

After correcting the problem, run Library Verify (Operator Control Panel: **Service > Library Verify**) to ensure that all library components are functioning properly before resuming normal library operations.

Table 39. Troubleshooting table

Problem	Solution
INSTALLATION/CONFIGURATION	
Unable to configure 3 logical libraries with 3 drives (2 half height drives and 1 full height drive) installed.	The 2 half height drives must be in drive positions 1 and 2 (the lowest drive positions in the library) and the full height drive must be in the remaining drive position. For additional information, refer to Appendix A, “SCSI Element Types, SCSI Addresses, and Physical Configurations,” on page 203.
Installation and Configuration	1. Refer to “Installation Problems” on page 154.
POWER	
Library does not power ON	1. Perform “Isolating a Power Supply Problem” on page 155.
The Operator Control Panel is blank or frozen	<ol style="list-style-type: none"> 1. Power cycle the library. 2. If possible, log on to the Web User Interface and check the error log (Service Library > View Logs). Look up the error code and try to resolve (see “Error codes” on page 161). 3. Upgrade/reinstall the latest library firmware. To download the latest library firmware, visit www.Dell.com/support. <ul style="list-style-type: none"> • If the problem is corrected, run Library Verify before resuming normal library operations. Refer to “Service: Library Verify” on page 102. • If the problem persists, refer to Dell technical support.
ENCRYPTION	

Table 39. Troubleshooting table (continued)

Problem	Solution
<p>Encryption Error: Displayed when the drive detects an error associated with an encryption operation - if the problem occurred while the tape drive was writing data to, or reading data from, tape</p>	<ol style="list-style-type: none"> 1. Check the host application to ensure the key management application is providing the correct encryption key. <ul style="list-style-type: none"> • Refer to the “Drive Sense Data” on page 221 returned for an encryption operation. • Retry the encryption operation after the key management application problems have been resolved. 2. Check the operation of the tape drive by resetting the drive (Operator Control Panel: Service > Service > Drive Power) and running POST. <ul style="list-style-type: none"> • Refer to the error code displayed on the Operator Control Panel if the drive resets and POST fails. • Retry the encryption operation if the drive reset and POST complete without errors. 3. Check the media. <ul style="list-style-type: none"> • Ensure the correct media is being used. Data encryption is supported with LTO Ultrium 4, 5, 6, and 7 Data and WORM Cartridges only. • Retry the encryption operation with the tape cartridge in another encryption enabled drive. Replace the media if the problem repeats with the same tape cartridge in multiple drives. If the problem occurred while the tape drive was running POST or diagnostics, replace the drive. The error code clears with the first attempted write/read after the encryption key is changed, or when the drive is placed in maintenance mode.
<p>Encryption-related error is posted</p>	<p>Check the IBM SKLM application's error logs, device driver logs, tape library error logs, and tape drive error logs for entries that are related to encryption. See “Service Library: View Logs” on page 130, “Service Library: View Drive Logs” on page 131, “Error codes” on page 161, and “Drive Sense Data” on page 221.</p>
<p>Connection problem with the IBM SKLM application</p>	<p>If you are using library-managed encryption, perform the Key Path Diagnostic (see “Service Library: Key Path Diagnostics” on page 133) if this feature is available. If the test fails, a problem could exist with the IP address, the Ethernet cable, or the key management server. Perform the following:</p> <ol style="list-style-type: none"> 1. Check the Ethernet connection between the library and the key management server. 2. Check the TCP/IP configuration of the library and the server. 3. Check that the key manager is correctly installed and configured, and that the application is properly started (refer to your key management documentation). 4. Ensure that the tape drive is registered in the key manager (refer to the <i>IBM SKLM Knowledge Center</i> online). 5. Ensure that a default key label is defined in the key manager (refer to the <i>IBM SKLM Knowledge Center</i> online). <p>If you are using application-managed encryption, check your tape backup application documentation for a similar test.</p>
<p>ERROR CODES</p>	
<p>There is an error code in the error log.</p>	<p>Most library or drive errors will result in an error code or error message on the Operator Control Panel display. An error code history is maintained in the library or drive error log. See “Service Library: View Drive Logs” on page 131 for how to get the error log over the Operator Control Panel and “Service Library: View Logs” on page 130 to view logs using the Web User Interface.</p> <p>Look up the error code and try to resolve (see “Error codes” on page 161 and/or Appendix C, “Sense Data,” on page 215).</p>
<p>FRONT PANEL LEDs</p>	

Table 39. Troubleshooting table (continued)

Problem	Solution
Attention LED	<p>To determine why the Attention LED is turned ON, log in to the Web User Interface and select Service Library > View Logs > Warning Trace.</p> <p>Drive Sled Issues:</p> <ul style="list-style-type: none"> • Refer to “Isolating Drive Sled Problems” on page 157. • Whenever there is a hardware configuration change such as drives being swapped with different form factors (i.e. HH to FH or FH to HH), a library configuration change is needed. Reconfiguring the library by reassigning the amount of logical libraries will clear this issue. Navigate to the Web User Interface Configure Library > Logical Libraries or to the Operator Control Panel's Configure > Logical Libraries section and reassign the logical libraries. If you do not want to change your logical library configuration, resubmit your current settings. • Restore factory defaults (Operator Control Panel: Configure > Save/Restore and select Restore All, or Web User Interface: Configure Library > Save/Restore and select Restore). <p>Media Issues:</p> <ul style="list-style-type: none"> • Avoid contamination by ensuring that the library is installed in a clean, contamination-free environment. Continue cleaning the tape drive as needed. Refer to “Choosing a Location” on page 35. • A cartridge should be acclimated for at least 24 hours before being used, particularly if it has been stored at a substantially different temperature or level of humidity than the library. Refer to “Provide Proper Acclimation and Environmental Conditions” on page 146. • Any cartridge that is suspected of being defective or contaminated should NOT be reused, in any drive. <p>Power Supply or Fan Issues:</p> <p>Check the power supply (or redundant power supply) for failure, and also check any power supply fans. Replace any defective units. Refer to “System Status” on page 21 for a redundant power supply failure on a 4U library and “Isolating a Power Supply Problem” on page 155.</p>
Clean Drive LED	<ul style="list-style-type: none"> • Ensure that you are using an Ultrium universal cleaning cartridge (see “Cleaning Cartridge” on page 142). • Ensure that the cleaning cartridge has not expired. A drive will automatically eject an expired cleaning cartridge. A cleaning cartridge is good for 50 cleans. If your cleaning cartridge has expired, order a new cleaning cartridge. • If the problem still exists, contact technical support.
Error LED	<p>If the Error LED remains ON after completing any user action listed for the error code in “Error codes” on page 161, run Library verify (Operator Control Panel: Service > Library Verify).</p> <ul style="list-style-type: none"> • If the test passes, the Error LED will turn OFF. • If the test fails, cycle library power to turn the Error LED OFF. <p>To check the library error log, log on to the Web User Interface and click Service Library, then View Logs. If the Operator Control Panel displays WARNING: Unit Busy, click OK to turn the error LED OFF.</p>
FIRMWARE	

Table 39. Troubleshooting table (continued)

Problem	Solution
Determining current firmware levels	<p>Many problems can be resolved by a firmware upgrade. Ensure that both the library and drive firmware are at the latest levels available.</p> <ul style="list-style-type: none"> • Library firmware: Monitor > Library > Identity > Version • Drive firmware: Monitor > Drives > Identity (select a drive) > Firmware Rev
Update library firmware	Refer to “Service Library: Upgrade Firmware” on page 134.
Update drive firmware	Refer to “Service: Service (Drives)” on page 104 or “Service Library: Upgrade Firmware” on page 134.
CARTRIDGE MOVEMENT PROBLEMS	
Cartridge placement problems	<p>Magazine slot prism fiducials NOT seated properly can result in gripper or slider error codes due to the fiducial interfering with the back edge of the cartridge. Release and pull magazines out of the library for inspection. To release the magazines using the Operator Control Panel, navigate to Control > Magazine and select Left or Right. To release the magazines using the Web User Interface, navigate to Manage Library > Release Magazines.</p> <p>Inspect the light pipe fiducials on each slot of the magazine for proper seating.</p>
Cartridge will not eject from drive	<ol style="list-style-type: none"> 1. Allow the drive to complete all operations. This may take as long as 1 hour if you reset or cycle power on the library while the cartridge is positioned at the physical end of the media. 2. Ensure that the backup software is not reserving the slot or preventing the drive from ejecting the cartridge. The backup software needs to cancel the reservation and any hold it has on the drive. Temporarily disconnecting the library from the host server and power cycling eliminates the host and its software as a problem source. 3. If the problem still exists, contact technical support.
Cartridge can not be removed from storage slot	See “Removing Cartridges from Magazine Slots” on page 175.
MEDIA	
Cleaning or data cartridge incompatible with drive.	Ensure that you are using data and cleaning cartridges that are compatible with the drive and model of your library. The library automatically unloads incompatible cartridges and the Media Attention LED flashes. Export the media in order to clear the state. Refer to “Cartridge Compatibility” on page 141.
Cannot write to or read from tape.	<ol style="list-style-type: none"> 1. Ensure that the cartridge write-protect switch is in the write enabled position (see “Write-Protect Switch” on page 144). 2. Ensure that you have the appropriate data cartridge for your library model (see “Cartridge Compatibility” on page 141). 3. Ensure that you are using an Ultrium cartridge that has <u>not</u> been degaussed. Do not degauss Ultrium cartridges. 4. Ensure that the cartridge has not been exposed to harsh environmental or electrical conditions and is not physically damaged in any way. Refer to “Provide Proper Acclimation and Environmental Conditions” on page 146 and “Perform a Thorough Inspection” on page 146. 5. Many backup applications do not read or write to cartridges that were created using a different backup application. In this case, you may have to perform an erase, reformat, or label replacement operation on the cartridge. 6. Ensure that you understand any data protection or overwrite protection schemes that your backup application may be using, which could prevent you from writing to a given cartridge. 7. Retry the operation with a different, known good cartridge. 8. Clean the drive. See “Service Library: Clean Drive” on page 129.

Table 39. Troubleshooting table (continued)

Problem	Solution
Cartridge VOLSER is reported as "unknown"	Probable cause: cartridge with no label or damaged label. Ensure that cartridge is properly labelled. If cartridge is properly labelled, unload the cartridge from drive and perform an inventory (OCP: Control > Re-Inventory ; Web: Manage Library > Perform Inventory). If VOLSER is again reported as "Unknown", run Library Verify (Service > Library Verify).
DRIVE ID (SCSI, SAS, OR FIBRE CHANNEL LOOP)	
Changed drive ID, but the host server does not recognize the new ID	<ol style="list-style-type: none"> 1. Ensure that all devices on the same bus/network have unique ID numbers. 2. Ensure that you cycle power on the library after changing the ID. 3. Reboot the host server.
Tape library performance: The library is not efficiently backing up data	<ol style="list-style-type: none"> 1. Check the network bandwidth from the host computer. If you are backing up data over a network, consider comparing to a local-only backup. 2. Ensure that the library and tape drive are on their own SCSI and not daisy-chained to another tape drive or to the hard drive being backed up. 3. Ensure that the library is connected to a LVDS SCSI bus and there are no single-ended (SE) devices on the same bus, because this will cause the entire bus to negotiate down to SE speed. 4. Use an Ultra160 SCSI bus and high-quality cabling with the library.
CUSTOMER REPLACEABLE UNITS (CRU) AND SERVICE SPARES	
Drive Sled	See "Isolating Drive Sled Problems" on page 157.
Power Supply	See "System Status" on page 21 and "Isolating a Power Supply Problem" on page 155.
Library Controller Card	See "Isolating a Library Controller Card vs. Accessor Enclosure Problem" on page 158.
Library Enclosure (Service Spare)	See "Isolating a Library Controller Card vs. Accessor Enclosure Problem" on page 158.
ITDT	
Performance Test duration varies	Items affecting the duration of the test are: <ul style="list-style-type: none"> • The level of adapter device driver • Your adapter model and type
OTHER PROBLEMS	
Web User Interface problems	See "Isolating Web User Interface Problems" on page 159.
Bar code scanner problems	See "Isolating Accessor Scanner Problems" on page 159.
Host Attachment Interface problems	See "Isolating Host Attachment Interface Problems" on page 159
Need help with a library password	Contact technical support.
Key path diagnostic not working	This diagnostic is available with library firmware level greater than 6.xx. Refer to "Verifying/Updating Firmware" on page 56 to determine the level of firmware on your library. If necessary, visit www.Dell.com/support to download the latest levels of firmware for your library.
Auto Clean status displayed as "Chk Media/Rsvd Slot?" on the Web User Interface System Status screen.	If Auto Clean is enabled and a cleaning cartridge is not present, or if a cleaning cartridge is present but not in the reserved slot, Auto Clean status will show "Chk Media/Rsvd Slot?" and Status will show a green check mark and the words "Media Attention."

Installation Problems

Problems encountered during the installation of the library are usually caused by improper SCSI bus configuration, application software configuration errors, or an incorrectly configured operating system. If the application software that you are using is not communicating with the library after installation, check the following:

- **Accessor Ship Lock Key:**

Ensure that the Accessor Ship Lock Key on the top cover has been removed **before** powering on the library. Refer to “Removing and Storing the Shipping Lock” on page 38.

- **Drive SCSI or Loop ID:**

Ensure that the SCSI ID of the Drive (or Fibre Channel Loop ID) is correct and not the same as other devices that may be on the same bus or loop. To determine the SCSI or Loop ID for each SCSI or Fibre Channel drive in your library, navigate to:

- Operator Control Panel: **Monitor > Drive > Identity**
- Web User Interface: **Monitor Library > Drive Identity**

To change a drive's ID, navigate to:

- Operator Control Panel: **Configure > Drive > Drive Interface**
- Web User Interface: **Configure Library > Drives**

- **Host Bus Adapter (HBA) Compatibility:**

Ensure that the library is compatible with the HBA. For best performance, the HBA used for this library should be SCSI-3 LVDS. Pay particular attention to any steps describing settings of various jumpers and/or switches.

- **HBA LUN 0/1 Support:**

A single ID will address both drive and library since the drive is LUN 0 and the library is LUN 1. These models require an HBA that supports LUN scanning which must be enabled at the HBA. Refer to “Logical Unit Number (LUN) Scanning” on page 30.

- **Cable Connections:**

Ensure that there are no bent pins on cables and that all connections are securely fastened.

- **Fibre Channel Tape Support:**

Ensure that Fibre Channel Tape Support is enabled on the HBA if you are installing a library with a Fibre Channel drive.

- **SCSI Cable Length:**

Ensure that the maximum cable length is not over 25 meters (82 ft.) for a single device on the bus or 12 meters (40 ft.) for multiple devices. Internal SCSI length within the library accounts for 2 ft.

- **SCSI Termination:**

Verify proper termination on both ends of the SCSI bus. Refer to “Connecting the Host Interface Cable” on page 50.

- **SAS Cables**

Ensure that SAS Cables are properly attached. Refer to “Connecting the Host Interface Cable” on page 50.

- **Backup Application Installation:**

Refer to the documentation included with your backup application software for instructions on how to verify proper installation.

- **Device Driver Installation:**

Ensure that the proper device driver, if applicable, is installed for the library.

Note: Many backup applications use their own drivers for the library and drive. Before installing a driver, make sure it will not be in conflict with the software. Contact your Backup Application vendor for this information.

Library Recovery Problem Determination

The 2U and 4U library firmware will generally retry failed operations up to three times before posting a failure to complete the operation, or, in some situations, proceeding with an operation that can be completed in an alternative manner. Of course, if the operation is successful within the allotted retry count, the appropriate retry counter is updated and recorded in the retry log and the next library operation will commence.

For example, failure to pick or place a cartridge from or to a designated cell or drive location after exhausting the retry count will result in a failed operation with the appropriate error code. However, failure to detect a particular cell location by sensing the prism fiducial located on the cell shelf because it is missing or damaged will eventually result in the cell location being located by the gripper, bar code reader and positional emitter pulse count after the prism detection retry count is exhausted. If several prisms are missing or damaged or if the accessor prism sensor/emitter is inoperable, initialization and/or inventory functions can take a prolonged amount of time to complete due to the lengthy retry recovery procedure.

If the library is taking an extended amount of time to initialize, to perform an inventory or even move a cartridge within the library, the magazines prism integrity should be verified prior to exchanging a library component. This situation can be noted by the ACTIVITY line on the Operator Panel posting Recovery. Prism integrity verification can be done by releasing the magazines and inspecting the cell prisms. Normal initialization or inventory time for a 2U library once the picker mechanism starts its operation should be approximately 1 to 2 minutes. For a 4U library, 2 to 3 minutes. A single missing or damaged prism can add 1 to 2 minutes. If the accessor tray sensor/emitter is inoperable, or several prisms are missing or damaged, initialization or inventory could exceed 30 minutes or longer. Refer to Troubleshooting table "Cartridge Movement Problems".

Procedures for Isolating CRU Problems

Isolating a Power Supply Problem

Note: Not all power supplies have LEDs. The original power supply for the 2U library did not have LEDs though any power supplies replaced will likely have LEDs. The 4U library has power supplies with LEDs.




Figure 130. A 250w power supply with LEDs




Figure 131. A 80w power supply without LEDs

Table 40. Power Supply LED Meanings

1	If the blue LED is lit, AC voltage is available.
2	If the amber LED is lit, there is a possible fan problem or other power supply issue. The power supply will need replacement.
3	If the green LED is lit, DC power is OK and active.
4	Cooling Fan Grill
5	Thumb Screws
6	Power Receptacle

If the Library does not power on:

1. With library power OFF and the power cord unplugged, loosen the three thumb screws (**5**), grasp two of the thumb screws, pull the power supply out half way, reseal the power supply, and tighten the three thumb screws.
2. Ensure the power cord is plugged in at the power supply (**6**) and at the electrical outlet, then turn library power ON.
 - a. For power supplies with LED's, the "Blue" LED will be lit if AC power is good.
 - b. If your power supply does not have LED's, feel for air flowing out of the cooling fan grill on the rear of the library (**4**). AC is good if air is flowing from the cooling fan grill.
3. If power appears to be missing
 - a. Plug the power cord into another electrical outlet.
 - b. If power is still missing, plug another device into the outlet to test.
 - c. If the outlet tests OK, try another power cord with the library.
4. For power supplies with LED's, if the "Amber" LED is lit, replace the power supply (refer to "Replacing a Power Supply" on page 186).
5. If your power supply has no LED's, and you have verified that the electrical outlet works properly, but the power supply is still failing, replace it (refer to "Replacing a Power Supply" on page 186).
6. If the power supply seems to be delivering power to the library (Operator Control Panel and front panel LED's may be functioning); however, air does not flow from the power supply cooling fan grill on the rear of the library, replace the power supply (refer to "Replacing a Power Supply" on page 186).
7. If the power supply seems to be delivering power to the library (Operator Control Panel and front panel LED's may be functioning), and air is flowing from the power supply cooling fan grill on the rear of the library, observe the "Green" LED (lowest of the three). If it is lit, the power supply is OK.

Note: If your library has -04 level redundant power supplies (see label on top of power supply), it is normal for the one in "Standby" mode to turn its "Green" LED off. You can test this power supply by pulling the power connector from the other "Active" power supply. The power supply that was in "Standby" mode will now become "Active", and its "Green" LED should light. If it doesn't, replace it (refer to "Replacing a Power Supply" on page 186).

If your library has -05 level redundant power supplies, the "Green" LED will be ON on both power supplies. If both "Green" LEDs are not ON, replace the failed power supply (refer to "Replacing a Power Supply" on page 186).

8. If the "Green" LED is not lit, and it is the only one in the Library, replace it (refer to "Replacing a Power Supply" on page 186).

Isolating Drive Sled Problems

Prior to replacing a drive sled CRU, verify that the following activities have been performed:

1. BEFORE POWERING OFF THE LIBRARY, write the drive dump to flash. It is important to preserve the drive dump on the drive for analysis by Technical Support.

Note: If you are instructed by Dell Technical Support to copy the drive dump to your host computer, use one of the following methods:

- Web User Interface: Refer to "Service Library: Save Drive Dump" on page 131.
 - ITDT: Refer to "Using the ITDT Firmware Update, Dump Retrieval and Drive Test Tool " on page 177.
2. Ensure that the drive firmware is at the latest level. To determine current library and drive firmware version using the Operator Control Panel:
 - Library firmware: **Monitor > Library > Identity**
 - Drive firmware: **Monitor > Drives > Identity (select a drive)** Drive firmware is identified in the **FW Rev** field.

3. Try reseating the drive sled.

Note: The drive sled is hot-pluggable so it is not necessary to power off the library. See “Removing/Installing/Adding a Tape Drive Sled” on page 181.

4. Cycle power to the library.
5. If air does not flow from the drive sled cooling fan grill on the rear of the library, replace the drive sled CRU. Several library error codes also point to cooling problems. See “Removing/Installing/Adding a Tape Drive Sled” on page 181.
6. If the drive is experiencing permanent or temporary errors or if the amber Clean LED is lit on the front panel of the library, select Clean Drive from the Operator Control Panel Service Menu (**Service > Service > Clean Drive**) and clean the drive. Use only an approved cleaning cartridge (see “Cleaning Cartridge” on page 142).
7. Run the **Library Verify Diagnostic** which includes a drive performance Read/Write test. Be sure to use a known good scratch or blank data cartridge.
 - If the drive test fails, replace the drive sled CRU (refer to “Removing/Installing/Adding a Tape Drive Sled” on page 181).
8. If the drive passes all the tests, inspect the media to ensure the media is compatible with the drive and not causing drive errors. Refer to “Using Ultrium Media” on page 139.

Isolating a Library Controller Card vs. Accessor Enclosure Problem

1. If possible, ensure that the library firmware is at the latest level, check the current library firmware level using the Operator Control Panel (**Monitor > Library > Identity > Version**) or the Web User Interface (**Monitor Library > Library Identity**), then.
2. Observe the LED on the Library Controller Card.
 - LED On solid - LCC failed or in a hang condition.
 - LED Off - LCC not fully inserted, or LCC failed, or library not connected to power source, or Power Supply defect.
 - LED flashing (1 flash per second) - normal operation
 - LED flashing (slower than once per second) - normal operation
 - LED flashing (faster than once per second) - LCC failed
3. With library power OFF, loosen the two thumb screws which secure the controller card to the library enclosure and slide it out.
 - Inspect the card for any broken components or other anomalies.
 - If the card appears to have no abnormalities, reseal the card back in the library, tighten the thumb screws, and turn library power ON.
4. If both the Operator Control Panel and Web User interfaces are inoperable or frozen and the latest firmware has been installed, the controller card CRU electronics is the most likely failure. If only the Web User Interface has failed, please see “Isolating Web User Interface Problems” on page 159 before replacing any CRUs.
5. If a control card error code has been obtained and reseating, power cycling, and updating the library firmware did not fix the problem, the controller card CRU is the most likely failing CRU (refer to “Replacing a Library Controller Card” on page 187).
6. If the error code indicates an accessor type error (slider, elevator, sled, etc.), release and remove both magazines (see “Control: Magazine” on page 91, “Manage Library: Release Magazine” on page 115, or “Releasing the Magazines Manually” on page 175) and observe the accessor path for any obvious obstruction or problems. Resolve any observed problem if possible. Execute a Library System Test. See “Service Library: Perform Diagnostics” on page 132 for the web or “Service: Run Tests” on page 103 for the OCP. If the problem is persistent, contact Dell technical support.
7. If the library is taking an extended amount of time in recovery to complete initialization, perform an inventory, or executing a cartridge movement within the library, and, after finding the magazine cell fiducials to be present with no visible damage and correctly installed, suspect the sensor/emitter on

the accessor mechanism to be inoperable. Execute a Library System Test. See "Service Library: Perform Diagnostics" on page 132 for the web or "Service: Run Tests" on page 103 for the OCP. If the problem is persistent, contact Dell technical support.

Isolating Web User Interface Problems

If the Web User Interface is not functioning at all or if it is intermittently functioning, review the following steps to ensure that it is properly configured, or, to help determine which CRU or part needs to be replaced. The complete Web User Interface electronics reside on the library controller card CRU.

1. Ensure that the ethernet cable is securely plugged in the rear of the library at the ethernet port. See **7** on the "Rear Panel" on page 3.
2. Ensure that the correct IP, Netmask, and Gateway addresses are keyed into the network parameters. From the Operator Control Panel, navigate to **Configure > Network**.
3. Ensure that the correct IP address is being used on the web browser. If you get a security certificate alert when logging in to the Web User Interface, you can install the certificate or allow an exception (depending on the internet browser you are using). Even though with some browsers you will still receive a security certificate warning/error each time you log in to the Web User Interface, your transmission is secure. SSL is enabled when the URL to your library begins with **https://** and some browsers will show a lock.
4. If the ethernet connection is a direct connection between the PC and the library, a special "crossover" ethernet cable needs to be used.

Note: On newer PCs, either straight through or crossover ethernet cables may be used since the crossover requirement is provided internally.

5. Check the ethernet cable carefully (or try another cable) and, if the cable is connected to a network hub or switch, try a different port.
6. If the Web User Interface is still malfunctioning, replace the Library Controller Card CRU (refer to "Replacing a Library Controller Card" on page 187).

Isolating Accessor Scanner Problems

If the server has reported inventory problems relating to inability to read bar code labels, or, if some or all of the cartridge labels are not being displayed on the Web User Interface, use the following procedure to determine if the scanner (library enclosure CRU) needs to be replaced.

1. Ensure that a supported bar code label (or labels) are being used.
2. With library power OFF, reseal the library controller card CRU (refer to "Replacing a Library Controller Card" on page 187), and then switch library power ON.
3. Perform a re-inventory via the Operator Control Panel (**Control > Re-Inventory**) and view the inventory via the Web User Interface (**Monitor Library > Inventory**) to determine if the labels are now being read.
4. If the labels are still not being read properly, please contact Dell technical support.

Isolating Host Attachment Interface Problems

After successfully exercising "Isolating Drive Sled Problems", and more specifically the "Library Verify" diagnostic on the Operator Control Panel (**Service > Library Verify**) which includes a drive (or drives) read/write diagnostic, the following procedures are suggested to help isolate the failure to properly establish connectivity to the Host Bus Adapter (HBA).

1. Use the utility, ITDT, to evaluate connectivity from the HBA through the cabling to the drive (or drives). ITDT does not require separate device drivers, thus the Operating System has the ability to scan and find all the LTO devices that are attached. If ITDT cannot successfully locate the LTO drive, suspect cabling or HBA problems, and skip step 2. If ITDT successfully located the LTO drive, proceed to step 2. See "Using the ITDT Firmware Update, Dump Retrieval and Drive Test Tool " on page 177 for a brief description of ITDT and instructions on how to download the tool from the web.

2. If ITDT successfully locates the LTO device(s), verify that the correct application device drivers and backup application software is properly installed.
3. Ensure that all the required or latest available Operating System files and/or updates (dll's, PTF's, etc.) have been installed and applied.

Identifying a Suspect Cartridge

The amber **Attention** LED will be lit on the front panel of the library when there has been a failure that indicates a piece of media is bad, marginal, or invalid. It will be cleared when all invalid cartridges have been exported from the library.

Note: The amber LED may also be lit because a power supply, or a power supply fan is failing. Refer to "Isolating a Power Supply Problem" on page 155.

1. Identify the media using the Web User Interface (**Monitor Library > Inventory**). Expand the cartridge details for each magazine and look for media status in the **Attn** column of the inventory table.
2. Make note of the cartridge location (Slot #) and VOLSER (Label) in the inventory table.
3. To remove the cartridge from the library:
 - a. Using the web, select **Manage Library > Move Media**. If the cartridge is not in an I/O Station slot, move the cartridge to an I/O Station slot.
 - b. Using the OCP, select **Control > Open I/O Station**.
4. Remove cartridge. If cartridge was reported as **Bad**, properly dispose the cartridge.
5. Close the I/O Station. If the amber LED was lit because of bad media, the **Attention** LED will turn OFF. If the amber LED is still on, check the power supply or the power supply fans. See "Isolating a Power Supply Problem" on page 155.

Error codes

If an error occurs during operation of the library, the library stops the current operation and displays an error code on the LCD screen. Unless otherwise noted in “Error codes,” try to resolve the error by cycling power to the library and retrying the last operation. If the error persists, contact technical support.

Example error code

EVENT -6

8D 07

Where:

- -6 indicates the position in sequence list, 0 being the most recent.
- 8D 07 indicates the error. (code 8D = sled blocked,).

The event log with the library also includes a date stamp for each event. Press SELECT to display the associated time stamp in the following format:

yy.mm.dd hh:mm:ss:HH

Where:

- yy is the year
- mm is the month
- dd is the current day
- hh is hours
- mm is minutes
- ss is seconds
- HH is 1/100 second

The time stamp is set to zero at system start.

A description of each error code and possible solution is provided in “Error codes”.

Preparing to resolve an error code

1. Record the error information that is displayed on the Operator Control Panel display or Web User Interface screen.
2. If possible, cycle library power and retry the operation.
 - If the error recurs, refer to “Error codes” for information about resolving the error.
 - If the error does not recur, run Library Verify before normal library operation is continued.

Complete the steps in “Preparing to resolve an error code” before you complete the User Action listed in “Error codes.”

Error codes

Errors that are described are hard errors. If such an error occurs the library stops all operations and the Error LED starts flashing. An appropriate message is posted on the Operator Control Panel and the Web

User Interface. These errors are also reported by way of email notification, if enabled. To enable email notifications, refer to “Configure Library: Event Notification” on page 126.

Table 41. Main Error Codes

Error Code	Description	User Action
80	Bar code reader error, cannot initialize BCR	<p>Error Code 80 01 might be posted if the library has a BCR (bar code reader) that requires a minimum level of library firmware. Update the library firmware to 9.00 or higher. If the problem still exists, follow the procedure. See “Isolating a Library Controller Card vs. Accessor Enclosure Problem” on page 158. Possible replacement CRUs:</p> <ul style="list-style-type: none"> • Primary: Library Enclosure • Secondary: Library Controller Card
81	Bar code reader error, no response from BCR	
82	EEPROM (Electrically Erasable Programmable Read-Only Memory) error, no response from EEPROM (located on accessor controller)	
83	Accessor controller generic problem	
84	Setting of gripper motor parameters failed	
85	Setting of slider motor parameters failed	
86	Setting of elevator motor parameters failed	
87	Setting of rotation motor parameters failed	
88	Setting of sled motor parameters failed	
89	Gripper blocked	<ol style="list-style-type: none"> 1. If this is the first time that the library was powered ON or if it was moved to a new location, ensure that the shipping lock was removed. The lock is on the top of the library (see “Removing and Storing the Shipping Lock” on page 38). 2. Refer to “Isolating a Library Controller Card vs. Accessor Enclosure Problem” on page 158. Possible Replacement CRUs: <ul style="list-style-type: none"> • Primary: Library Enclosure • Secondary: Library Controller Card
8A	Slider blocked	
8B	Elevator blocked	
8C	Rotation blocked	
8D	Sled blocked	

Table 41. Main Error Codes (continued)

Error Code	Description	User Action
8E	Cannot find gripper block within the expected range	<p>Refer to “Isolating a Library Controller Card vs. Accessor Enclosure Problem” on page 158. Possible Replacement CRUs:</p> <ul style="list-style-type: none"> • Primary: Library Enclosure • Secondary: Library Controller Card
8F	Cannot find slider block within the expected range	
90	Cannot find elevator block within the expected range	
91	Cannot find rotation block within the expected range	
92	Cannot find sled block within the expected range	
93	Gripper outside range, Gripper reached a position beyond the expected range	
94	Slider outside range, Slider reached a position beyond the expected range	
95	Elevator outside range, Elevator reached a position beyond the expected range	
96	Rotation outside range, Rotation reached a position beyond the expected range	
97	Sled outside range, Sled reached a position beyond the expected range	
98	Cartridge present sensor not found	
99	Slider home sensor not found	
9A	Rotation home sensor not found	
9B	Sled position sensor (fiducial sensor) not found	
9C	Gripper ranges out of specification	
9D	Slider range out of specification	
9E	Elevator range out of specification	
9F	Rotation range out of specification	
A0	Sled range out of specification	
A1	Open I/O Station (Import/Export Element) failed	
A2	Error during elevator locking	
A6	No elevator home sensor found	
B0	Robotic controller response timeout. A command did not complete in the required amount of time.	
B1	NACK (not acknowledged) received from robotic controller	
B2	Accessor controller communication failed	
B3	Accessor controller urgent stop because of a released magazine	<ol style="list-style-type: none"> 1. Verify that the left and right magazines are inserted, then retry operation. 2. Refer to “Isolating a Library Controller Card vs. Accessor Enclosure Problem” on page 158. Possible Replacement CRUs: <ul style="list-style-type: none"> • Primary: Library Enclosure • Secondary: Library Controller Card
B4	Cartridge did not transport completely	
B5	Accessor controller does not respond on command	

Table 41. Main Error Codes (continued)

Error Code	Description	User Action
C0	Network initialization failed	<ol style="list-style-type: none"> 1. Refer to “Isolating Web User Interface Problems” on page 159. 2. If the error recurs, contact technical support.
C1	Telnet Interface initialization failed	
C2	Webserver initialization failed	
C6	Ping command did not reach target	
C7	Cannot Upgrade from USB	Not supported
C8	Cannot Upgrade from FTP	<ol style="list-style-type: none"> 1. Retry the Firmware upgrade. 2. If the error recurs, contact technical support.
C9	Cannot Upgrade Robotic from Flash	
D0	ROM error. ROM checksum incorrect	<p>Refer to “Isolating a Library Controller Card vs. Accessor Enclosure Problem” on page 158. Possible replacement CRUs:</p> <ul style="list-style-type: none"> • Primary: Library Controller Card • Secondary: Library Enclosure <p>*D7 - Fatal System error can occur because of an over-temperature condition. Ensure that the environment meets the Environmental Specifications (refer to “Environmental Specifications” on page 14).</p> <p>**If you receive a D8 error while your library configuration is restored from the OCP or Web UI, verify that your file extension is .dbb. If the extension is correct, your file was corrupted during the save. Reconfigure, then save your library configuration.</p> <p>Note: Configuration files that are saved with one version of library firmware might not be compatible with other versions of firmware. It is recommended to save a configuration file each time the library firmware is upgraded. Restore the library using a configuration file that was saved with the same version of firmware that is currently installed in the library.</p>
D1	RAM error. Power on Self Test (POST) failed	
D2	NVRAM (Non-Volatile Random Access Memory) error. Read/Write operation to NVRAM failed	
D3	CTC (Channel to Channel) Error. Timer unit failed during POST.	
D4	UART (Universal Asynchronous Receiver Transmitter) Error. Frame overrun or Parity Error on serial Interface.	
D5	Display Error Communication to display failed	
D6	Memory Error, Stack and heap overflow.	
D7	Fatal system error*	
D8	Database error**	
D9	No SCSI IC detected	
DA	While the Library Verify Test is running, the bar code reader reads different bar code data for the same customer-supplied scratch cartridge label.	<ol style="list-style-type: none"> 1. Check the barcode label on the scratch cartridge and run the Library Verify test again. 2. If the error recurs, contact technical support.
DB	Warning Event! See Table 43 on page 171	
DC	I ² C Bus Failure	<ol style="list-style-type: none"> 1. Retry the operation. 2. After several occurrences, contact technical support.
DD	Warning Event! See Table 43 on page 171	

Table 41. Main Error Codes (continued)

Error Code	Description	User Action
DE	Warning Event! See Table 43 on page 171	
DF	Warning Event! See Table 43 on page 171	
E0	Incompatible magazine that is detected	<ol style="list-style-type: none"> 1. Remove magazine from library. 2. Insert magazine in library. If error recurs, contact technical support.
E2	New hardware found. Library firmware upgrades required.	Upgrade library firmware to the latest version.
EB	Power supply health check failed because of a power supply failure.	Refer to “Isolating a Power Supply Problem” on page 155
F0	<p>Drive Over temperature Condition</p> <p>The subcode indicates which drive is affected.</p> <p><u>Example:</u></p> <p>Subcode 02: drive #2</p>	<ol style="list-style-type: none"> 1. Check the ambient temperature conditions, and check all fans. 2. Refer to “Isolating Drive Sled Problems” on page 157.

Table 41. Main Error Codes (continued)

Error Code	Description	User Action	
F1	<p>Drive Communication Error</p> <p>Library controller lost communication to drive</p> <p>The subcode indicates which drive is affected.</p> <p><u>Example:</u></p> <p>Subcode 02: drive #2</p>		
F2	<p>Drive Sled not present</p> <p>The subcode indicates which drive sled is affected.</p> <p><u>Example:</u></p> <p>Subcode 02: drive sled #2</p>		
F3	<p>Drive Hardware Error</p> <p>The subcode indicates which drive is affected.</p> <p><u>Example:</u></p> <p>F3 xy</p> <p>Where x refers to the hardware drive error code (single character display) and Y refers to the drive position in the library. x values:</p> <ul style="list-style-type: none"> • 4: firmware or hardware error • 5: hardware error • 6: hardware or media error • A: recoverable hardware error 	<p>Refer to “Isolating Drive Sled Problems” on page 157.</p>	
F4	<p>Drive Load Timeout</p> <p>Drive run in a timeout while a tape is loading.</p> <p>The subcode indicates which drive is affected.</p> <p><u>Example:</u></p> <p>Subcode 02: drive #2</p>		
F5	<p>Drive Unload Timeout</p> <p>Drive run in a timeout while a tape is unloading</p> <p>The subcode indicates which drive is affected.</p> <p><u>Example:</u></p> <p>subcode 02: drive #2</p>		

Table 41. Main Error Codes (continued)

Error Code	Description	User Action
F6	No drive installed. A drive was never installed	Refer to “Isolating Drive Sled Problems” on page 157.
F7	Support ticket download from drive not possible	
F8	Invalid drive command	
F9	Invalid drive parameter	
FA	SDCI microcode error	
FB	Drive logged out	
FC	Internal SCSI command failed with check condition	
FD	Internal SCSI command timeout	

Sub Error Codes

Table 42. Sub error codes

Error Code	Description
ROBOTICS	
00	No sub error code
01	Mechanical initialization failure
02	Connection to slave robotic failed
03	Error motor initialization
04	Error during gripper close
05	Error slider home positioning
06	Error elevator home movement
07	Error during sled movement to rotation position
08	Error during rotation initialization, get range failed
09	Error elevator init
0A	Error during rotation to far position
0B	Error first sled init, move to sensor failed
0C	Error during sled movement to rotation position
0D	Error during rotation to drive position
0E	Error slider init, get range failed
0F	Error during slider forward movement
10	Error gripper init, get range failed

Table 42. Sub error codes (continued)

11	Error during slider home movement
12	Error during rotation to FAR position
13	Error sled init, move to sensor failed
14	Error during sled movement; check shipping lock
15	Error move to a certain position failed
16	Error positioning of the rotation motor failed
20	Error Inventory scan
21	Error during gripper close
22	Error slider home movement
23	Error during move gripper to scan pos
24	Error reading barcode label
25	Error during move sled to scan position
26	Error during move elevator to scan position
27	Error during sled preposition movement
28	Error Extra inventory scan
29	Error during closing gripper
2A	Error slider preposition movement
2B	Error during opening gripper
2C	Error during sled movement up to sensor
2D	Error slider preposition backwards movement
30	Error slot preposition
31	Error during sled movement in FLMoveRotation function
32	Command sending to robotic failed
33	Error during elevator movement in FLMoveRotation function
34	Error during rotation in FLMoveRotation function
35	Error during elevator movement in FLMoveSled function
36	Error during sled movement in FLMoveSled function
37	Error during sled positioning to sensor in FLMoveSled function

Table 42. Sub error codes (continued)

38	Error during sled positioning to mail slot in FLMoveSled function
39	Error during sled positioning without sensor
3A	Error during elevator movement without sensor
3B	Error slot position sensor not found
40	Movement to/from slot failed
41	Error during first slider movement
42	Error during first gripper movement
43	Error during second slider movement
44	Error during second gripper movement, get range failed
45	Error during third slider movement, move home failed
46	Error during set hold current to avoid torsion
47	Negative direction blocked
48	Positive direction blocked
49	Possible motor defect, because both directions blocked
4A	Cartridge present sensor defect
4B	Inventory lost, because destination possibly full
4C	Inventory lost, because source might be empty
4D	Could not pull tape out of slot from magazine
4E	Unexpected tape on elevator, possible inventory lost
50	Preposition to drive failed
51	Elevator movement to home sensor failed.
52	Sled movement to home sensor failed.
53	Error during sled movement to drive position.
54	Error during rotation to drive position.
55	Error during elevator movement in drive position.
56	Error during sled movement to rotation position.
57	Error during rotation to end position.
60	Move from/to drive failed.
61	Error during first slider movement.
62	Error during first gripper movement.
63	Error during second slider movement.
64	Error during second gripper movement, get range failed.
65	Error during third slider movement, move home failed.
70	Release magazine failed.
71	Error during sled movement to rotation position.
72	Error during rotation to unlock position.

Table 42. Sub error codes (continued)

73	Error during move sled to block.
80	Opening I/O slot failed.
81	Error during movement to I/O slot open position.
82	Error during moving back - sensor was found.
90	Movement to home position failed.
91	Elevator movement to home position failed.
92	Error during sled movement to rotation position.
93	Error during rotation to home or far position.
94	Sled movement to home sensor position failed.
95	Sled movement to transport position failed.
99	Error during rotation movement to rotation min position
A0	Movement of I/O slot failed.
A1	Sled movement to sensor failed.
A2	Sled movement to rotation position failed.
A3	Elevator movement to home position failed.
A4	Error during rotation to far position.
A5	Sled movement to I/O slot position failed.
A6	Error during elevator movement to position
A7	Error during mailslot detection
B0	EEPROM on robotics controller not accessible or error during Read/Write operation
B1	Save/restore configuration settings: not enough internal memory available for creating the file and restoring the file respectively
B2	Save/restore configuration settings: restore buffer corrupted, checksum calculation failed
B3	Save/restore configuration settings: data base field corrupted
B4	Save/restore configuration settings: invalid personality
B5	Save/restore configuration settings: invalid file
LIBRARY	
81	Drive wake up failed
88	Error accessing slot status
90	Accessor load not reached Cartridge Present sensor
91	No activity after Load command
92	Timeout while loading tape
93	No activity after load command
94	Timeout drive Unload
95	Drive terminated unsuccessfully
96	Tape not ejected at robot unload

Table 42. Sub error codes (continued)

97	Slot not free at robot unload
98	Cartridge not seated in load phase

Warning events

Warning events that are described are reported by way of email notification. The Attention LED flashes when warning events for the following occur:

- Media
- Fan
- Redundant power supply

An appropriate message is posted on the Operator Control Panel and the Web User Interface.

Table 43. Warning events

30	SCSI: transport element full	Refer to your host application documentation for problem determination information.
31	SCSI: all slots empty	
32	SCSI: invalid opcode	
33	SCSI: invalid element address	
34	SCSI: invalid field in CDB	
35	SCSI: Invalid drive specified	
36	SCSI: SEND DIAGNOSTIC command: invalid test number	
37	SCSI: invalid LUN	
38	SCSI: parameter list length error	
39	SCSI: parameter list error: invalid field	
3A	SCSI: parameter list error: parameter not supported	
3B	SCSI: parameter value invalid	
3C	SCSI: saving parameters not supported	
3D	SCSI: invalid ID message	
3E	SCSI: destination element full	
3F	SCSI: source slot or drive empty	
40	SCSI: wrong checksum	
41	SCSI: command sequence error	
42	SCSI: drive disabled	Refer to your host application documentation for problem determination information.
43	SCSI: I/O Station disabled	
44	SCSI: flash image does not fit bootcode	Check the version of firmware that is used for the upgrade.
45	SCSI: media removal prevented by drive	
46	SCSI: media removal prevented by library	Check whether a version of firmware is available that supports this drive type. For a list of supported drives, refer to "Ultrium Tape Drives" on page 9.
47	SCSI: flash image does not fit personality	
48	SCSI: drive type not supported in this library	

Table 43. Warning events (continued)

49	SCSI: incompatible magazine, magazine not accessible	Check your configuration settings.
4A	SCSI: source not ready	Complete move process and retry operation.
4B	SCSI: destination source not ready	
4C	SCSI: library controller busy	Complete process and retry operation.
4D	SCSI: Cannot make reservation	Refer to your host application documentation for problem determination information.
4E	SCSI: invalid slave robotic controller request	
4F	SCSI: robotic axes/motors aren't initialized	Check robotics status. Refer to "Isolating a Library Controller Card vs. Accessor Enclosure Problem" on page 158.
50	SCSI: cartridge belongs to another partition	Check application software.
51	Incompatible medium	Check the compatibility of media and drive generation.
52	All slots full, no movement possible	Remove a cartridge to make a move possible.
53	All slots empty required for wellness test	Fill up required slots before the wellness test is started.
54	SCSI: failure in LME interface	<ol style="list-style-type: none"> 1. Check your Encryption configuration. 2. Run Key Path Diagnostics. 3. Refer to the <i>IBM SKLM Knowledge Center</i> online for information.
55	SCSI: invalid license key entered	Reenter license key. If problem persists, refer to technical support.
58	Recovered Error: SCSI parity error	No user action is required.
59	Recovered Error: Error log overflow	
5A	Illegal request, downgrade prohibited	Disable encryption for firmware downgrade.
5B	Incompatible medium generation	Replace incorrect cartridges.
5C	Illegal request, downgrade that is prohibited because of incompatible network stack	Change network settings to IPv4 only before downgrading firmware.
5D	Illegal request, wrong drive FW for drive	Obtain correct drive firmware image.
5E	Full height drive in illegal position	Check correct Drive position.
60	Cleaning cartridge installed	Complete the cleaning process and retry the operation.
61	Cleaning failure. Cleaning process could not be performed	<ol style="list-style-type: none"> 1. Verify that autoclean is enabled. 2. Check for an expired cleaning cartridge and replace if necessary. 3. Refer to "Configuring I/O Stations and Reserving Slots" on page 136.
62	Cleaning cartridge expired	Replace cleaning cartridge.
63	Invalid cartridge. Drive rejected the data cartridge as invalid	<ol style="list-style-type: none"> 1. Verify that the correct cartridge is being used. Refer to "Cartridge Compatibility" on page 141. 2. Refer to "Identifying a Suspect Cartridge" on page 160.
64	Invalid cleaning cartridge. Drive rejected the cleaning cartridge as invalid	
65	Invalid upgrade cartridge. Drive rejected the upgrade cartridge as invalid	Not supported
66	Medium error; diagnostic tape write protected	Ensure that diagnostic tape is not write protected.

Table 43. Warning events (continued)

67	Medium error, incompatible medium for write operation	Replace incorrect cartridges.
6A	Medium error, no OBDR tape	Insert OBDR tape.
70	Currently not used	
71	Currently not used	
72	Currently not used	
73	SCSI: overlapped command attempt	Refer to your host application documentation for problem determination information.
74	SCSI: echo buffer overwritten	
75	Download prevented due to incompatible bar code reader hardware	Older firmware image doesn't support current bar code reader hardware. No downgrade possible.
77	Download prevented due to incompatible LCM	Older firmware image doesn't support current library controller hardware. No downgrade possible.
78	Download prevented due to incompatible Rob Code	Older firmware image doesn't support current robotics controller hardware. No downgrade possible.
79	Download prevented due to incompatible drive version	Use correct drive firmware image.
80	Movement Retry.	
81	Fan Alert.	
82	Clean request from drive.	
83	Media Attention.	
84	Drive reported warning or critical tape alert flag.	
85	Network problem.	Check network connections, configuration, and settings.
86	Not enough cleaning cartridges present to autoclean.	Insert more cleaning cartridges to the empty reserved slots.
87	Drive disabled because it is not supported for use in this library.	Check drive type and install only supported drives.
88	Drive firmware unchanged after upgrade.	This is normal if the old and new drive firmware is the same version.
89	Power Supply Fan operation warning.	Check the power supply status.
8A	Power Supply failed.	Check the power supply status and replace the failed power supply.
8B	Power supply failed.	Check the power supply status and replace the failed power supply.
8C	Invalid Robotic Code.	Install the latest version of library firmware.
8E	Cleaning tape nearly expired.	Continue with cleaning cartridge until it is expired, then replace the expired cleaning cartridge with a new cleaning cartridge.
8F	I2C bus recovery.	Run library System Test.
92	VPD data have been restored from EEPROM.	This is normal when the VPD is restored EEPROM.

Table 43. Warning events (continued)

DB	<p>External cooling fan error (fan motion stopped).</p> <p>The subcode indicates which drive sled fan is affected</p> <p>Subcode 01: drive sled #1(bottom)</p> <p>Subcode 02: drive sled #2</p>	Refer to “Isolating Drive Sled Problems” on page 157.
DC	I ² C Bus Failure	Refer to “Isolating a Power Supply Problem” on page 155.
DD	<p>Power Supply x fan failed,</p> <p>Redundancy might be at risk</p> <p>The subcode indicates which power supply fan is affected</p> <p>Subcode 01: 1st PS fan from bottom</p> <p>Subcode 02: 2nd PS fan from bottom</p>	
DF	Power Good signal that is changed from 2 to 1 Power Supplies	
F6	No drive installed. A drive was never installed.	Install at least one drive.

Service Procedures

Removing Cartridges from Magazine Slots

In the event of a severe mechanical problem with the library or if circumstances require you to remove tape cartridges, do the following. If the Operator Control Panel or the Web User Interface is still operational:

1. Move the tapes from the drive(s) to the magazines using the **Manage Library > Move Media** command (Web User Interface) or **Control > Move Cartridges** command (Operator Control Panel). See “Manage Library: Move Media” on page 114 or “Control: Move Cartridges” on page 91.

Note: Contact technical support if a cartridge will not eject from the drive.

2. Use the magazine removal process to release the magazine and remove it from the library. To use the Operator Control Panel, see “Control: Magazine” on page 91. To use the Web User Interface, see “Manage Library: Release Magazine” on page 115. If neither one of these processes works, see “Releasing the Magazines Manually.”


Releasing the Magazines Manually

If the directions in Steps 1 and 2 above do not allow you to remove the tapes, do the following:

1. Unplug the power cord from the library.
2. Find the access holes for the right and left magazines.



Figure 132. Access holes for the left magazine



a77ug024

Figure 133. Access holes for the right magazine

3. To manually release the magazines, push the end of a straightened paper clip into the access hole for each magazine at the back of the library. While holding the paper clip, have a second person pull the magazine out of the front of the unit. **DO NOT** push the paper clip in more than 1/2 inch.



a77ug248

Figure 134. Left magazine pulled out of the 2U library



Figure 135. Left Magazines pulled out of the 4U Library

4. If there are additional tapes still in the library, or if you were unable to manually remove the magazines and drive, contact technical support for further instructions.

Using the ITDT Firmware Update, Dump Retrieval and Drive Test Tool

ITDT has multiple functional capability and is a very quick, convenient and efficient method for drive firmware updates. As a note, drive dump retrievals can be performed by the tool as well.

The ITDT Tool:

- Runs quick or extended diagnostics on tape drives. If the library is online to the server/host where the tool resides, ITDT will communicate with the drive through the library to load and unload a test cartridge thereby exercising some library functions.
- Retrieves firmware dumps from tape drives and libraries.
- Performs a firmware update on tape drives or libraries. See note below regarding library firmware update.
- Tests the performance of the environment by completely writing a cartridge and measuring performance.
- Retrieves and displays cartridge information.
- Verifies the encryption environment.
- Does not require special device drivers.
- Is available for most major platforms.

Note: ITDT Version 7 or higher is required for Ultrium 5, Ultrium 6, and Ultrium 7 tape drives. Before using ITDT, verify that your library host operating system is at the latest released level. This will ensure optimum read/write operations for diagnostics.

Note: If the library has a BCR (Barcode Reader) that requires 9.00 or greater firmware, the Update function will terminate with an error code of "Unexpected Data" if you attempt to downlevel the library firmware.

To download the ITDT tool and instructions for using the tool, visit www.Dell.com/support.

Check, Adjust, Remove, and Replace

Tools Required

To service a library you may need one or more of the following tools:

- #2 Phillips screwdriver
- Ground strap (recommended, if available)

Electrostatic Discharge

Important: A discharge of static electricity can damage static-sensitive devices or microcircuitry. Proper packaging and grounding techniques are necessary precautions to prevent damage.



Figure 136. ESD label

To prevent electrostatic damage, observe the following precautions:

- Transport products in static-safe containers such as conductive tubes, bags, or boxes.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free stations.
- Cover the unit with approved static-dissipating material. If available, provide a ground strap connected to the work surface and properly grounded tools and equipment. If a ground strap is not available, touch a metal surface to discharge any static electricity in your body.
- Keep the work area free of no conducting materials, such as ordinary plastic assembly aids and foam packing.
- Make sure you are always properly grounded when touching a static-sensitive component or assembly.
- Avoid touching pins, leads, or circuitry.
- Use conductive field service tools.

Relocating Your Library

When moving or shipping your library, it is important that the shipping lock be in place to prevent the accessor from moving and to protect the library from possible damage. Before relocating your library, complete the following procedure.

1. Remove all cartridges from inside the library.
2. Power OFF the library. This will align the robot with the shipping lock slot.
3. Remove any cables and terminators connected to the library.
4. Remove the library from the rack, if necessary.
5. Remove the shipping label (**2**) and lock (**1**) from the rear panel of the library.



Figure 137. Shipping Lock and Label Storage Location

6. Insert the shipping lock (**1**) into the slot located on the center of the top of the library and secure with the shipping label (**2**).



Figure 138. Shipping Lock and Label

7. Pack the library in its original packaging materials (or equivalent packaging) for moving or shipping.

Table 44. Shipping Lock/Shipping Label

1	Shipping Lock
2	Shipping Label

Removing/Installing/Adding a Tape Drive Sled


There are two types of drive sleds in a TL2000 library (2U library) and a TL4000 library (4U library). The contents of the ship groups are specific to the type of drive sled.

- Drive sled without ElectroStatic Discharge (ESD) springs (see Figure 139) ship group:
 - Drive sled without ESD springs
 - Packet of conductive tape to be applied to the drive sled for ESD protection
- Drive sled with ESD springs (see Figure 140) ship group:
 - Drive sled with ESD springs



a77ug008

Figure 139. Library drive sled without ElectroStatic Discharge (ESD) springs (SCSI sled shown)



a77ug202

Figure 140. Library drive sled with ESD springs [1] (SAS sled shown)

Removing a Tape Drive Sled

1. IT IS IMPORTANT TO PRESERVE A DRIVE DUMP FOR ANALYSIS IF ALL OF THE FOLLOWING CONDITIONS EXIST:

- Library Error LED is ON.
- Operator Control Panel is displaying a drive error message.
- Web User Interface System Status screen is indicating that a drive has failed.

IF NONE OF THE CONDITIONS LISTED ABOVE EXIST, PROCEED TO THE NEXT STEP.

2. Power OFF the library before removing and/or installing a SCSI drive sled. Fibre Channel and SAS drive sleds are hot pluggable and may be removed and installed while the library is powered ON.
3. If necessary, unload the tape cartridge from the drive to be removed.
 - Using the Operator Control Panel: **Control > Move Cartridges**
 - Using the Web User Interface: **Manage Library > Move Media**
4. Remove the host interface cable (**1**, **2**, or **4** in Figure 141) and terminator (**3** for SCSI drive sled only).




Figure 141. Drive sled components (full height fibre drive in top position, half height SCSI drive in middle position, half height SAS drive in bottom position) on back panel of a 4U library

1	SCSI cable
2	SAS cable
3	SCSI terminator
4	Fibre Channel cable
5	Ethernet cable
6	Power cords
7	Drive sled blue captive thumbscrews
8	Black pull-out tab
9	Drive sled
10	Drive sled handle

5. If present, remove the conductive tape from the drive sled (refer to Figure 144 on page 184).
6. Loosen the blue captive thumbscrews (**7** in Figure 141) on the drive sled.

7. Pull straight back on the drive sled handle (**10**) to remove it from the library (see Figure 142).
8. If you are replacing the tape drive sled, proceed to Installing a Tape Drive Sled for instructions. If you are not replacing the tape drive sled immediately, you will need to perform the following procedures:
 - a. Install a drive cover plate to protect your library from dust and debris.
 - b. To remove the "Missing drive" indicators on the Operator Control Panel (Attention LED) and the Web User Interface (System Status screen), modify or resubmit logical library setting (Operator Control Panel: **Configure > Logical Libraries** or Web User Interface: **Configure Library > Logical Libraries**).



Figure 142. Pulling the drive sled out of the library (drive sled without ESD springs shown)

Installing a Tape Drive Sled

Note: Power OFF the library before installing a SCSI drive sled. Fibre Channel and SAS drive sleds are hot pluggable and may be removed and installed while the library is powered ON.

Important: In a 4U library a full height drive sled may be installed in drive slot 1 (drive will occupy slot 1 and slot 2) or drive slot 3 (drive will occupy slot 3 and slot 4). A full height drive sled should never be installed in drive slot 2 (drive will occupy slot 2 and slot 3).

1. Before installing the new drive sled, inspect all connectors on the drive sled. Ensure that the connectors are intact, free of any foreign objects, and have no cracks, deformed, or bent contacts.
2. Extend the black pull-out tab (**8** in Figure 141 on page 182) located underneath the library near the lower right corner of the drive sled.
3. Slowly insert the new drive sled into the drive slot while supporting the bottom of the drive sled (see Figure 143 on page 184). Ensure that the black tab remains extended (**8** in Figure 141 on page 182).

Important: Push in on the drive sled handle (**10** in Figure 141 on page 182) while supporting the bottom of the drive sled until it is properly seated. Damage to the connector pins may occur if this procedure is not followed.


4. Push the drive sled slowly into the drive slot until the sled seats itself against the back of the library.



Figure 143. Pushing the drive sled into the library (drive sled without ESD springs shown)

5. Tighten the captive thumbscrews (7 in Figure 141 on page 182) until the drive sled is secure.
6. If you are installing a drive sled without ESD springs (see Figure 139 on page 181), apply conductive tape to the sled as shown in Figure 144.

2U Library



4U Library




Figure 144. Diagrams for applying conductive tape for ESD protection to the back of a drive sled installed in a 2U or 4U library

Note: The small gray markers show where conductive tape should be placed to provide ESD protection.

7. Push the black tab (**8** in Figure 141 on page 182) back underneath the library. When inserted properly, only the handle of the tab will be visible.
8. Upgrade library firmware and drive firmware to the latest version.
Refer to “Configure Library: Drives” on page 120 to configure the drive if it is a SCSI or FC drive. Connect the drive host interface cable to the host or FC switch.

Note: Go to www.Dell.com/support to download the latest firmware for your library and tape drive(s).

9. Run the Library Verify test. (Operator Control Panel: **Service > Library Verify**). This test requires the use of a scratch (blank) cartridge.
 - If the test passes:
 - When prompted by the Operator Control Panel display and the I/O Station opens, remove the cartridge used in the test.
 - Close the I/O Station by pushing it back into the library.
 - Press **Cancel** to exit the Library Verify screen.
 - Resume normal library operations.
 - If the test fails, an error code will be displayed. Make note of the error, then refer to the Troubleshooting chapter in this document for additional instructions.
10. Package the failed drive sled in the same packaging in which the new sled was shipped to you and return to Dell.

Important: If the failed drive was configured for encryption, to ensure the replacement drive receives the proper encryption parameters, resubmit the encryption choices listed on **Configure Library > Encryption** for that particular drive or logical library even if the encryption settings did not change.

Adding a Tape Drive Sled

Use these instructions to add a new tape drive to your 2U or 4U Tape Library. Refer to Appendix A, “SCSI Element Types, SCSI Addresses, and Physical Configurations,” on page 203 for more information.

Note: Power OFF the library before installing a SCSI drive sled. Fibre Channel and SAS drive sleds are hot pluggable and may be removed and installed while the library is powered ON.

Important: In a 4U library a full height drive sled may be installed in drive slot 1 (drive will occupy slot 1 and slot 2) or drive slot 3 (drive will occupy slot 3 and slot 4). A full height drive sled should never be installed in drive slot 2 (drive will occupy slot 2 and slot 3).

Complete the following procedure to add a new tape drive to your library.

1. Before installing the new drive sled, inspect all connectors on the drive sled. Ensure that the connectors are intact, free of any foreign objects, and have no cracks, deformed, or bent contacts.
2. Slowly insert the new drive sled into the drive slot while supporting the bottom of the drive sled (see Figure 143 on page 184). If necessary, ensure that the black tab remains extended (**8** in Figure 141 on page 182). Push in on the drive sled handle (**10** in Figure 141 on page 182) while supporting the bottom of the drive sled until it is properly seated.

Important: Damage to the connector pins may occur if this procedure is not followed.

3. Tighten the captive thumbscrews (**7** in Figure 141 on page 182) until the drive sled is secure.
4. If you are installing a drive sled without ESD springs (see Figure 139 on page 181), apply conductive tape to the sled as shown in Figure 144 on page 184.

Note: The small gray markers show where conductive tape should be placed to provide ESD protection.

5. Install cover plates on any open drive slots in the library.
6. Power ON the library.
7. Run the Library Verify test. (Operator Control Panel: **Service > Library Verify**). This test requires the use of a scratch (blank) cartridge.
 - If the test passes:
 - When prompted by the Operator Control Panel display and the I/O Station opens, remove the cartridge used in the test.
 - Press **Cancel** to exit the Library Verify screen.
 - Proceed to “Configuring the Tape Drive.”
 - If the test fails, an error code will be displayed. Make note of the error, then refer to the Troubleshooting chapter in the *Dell PowerVault TL2000 Tape Library and TL4000 Tape Library User’s Guide* for additional instructions.

Configuring the Tape Drive

1. Log on to the Web User Interface.
2. Verify that you are running the latest versions of Library and Drive firmware. Upgrade the firmware at **Service Library > Upgrade Firmware**.
3. Use the Web UI to update the Logical Library (**Configure Library > Logical Libraries**) and Drive (**Configure Library > Drives**) configurations. Refer to “Operations” on page 75. Select **Submit** on the **Configure Library > Logical Libraries** web page even if there are no required changes. This action will refresh the Data Transfer Element (DTE) for the drives. Refer to Appendix A, “SCSI Element Types, SCSI Addresses, and Physical Configurations,” on page 203 for information regarding DTE addressing. If **Configure Library > Logical Libraries** does not correctly refresh/update the DTE addresses, execute step 3 and step 4. Otherwise, proceed to Step 5.
4. Reconfigure your library using the OCP to configure your network settings, then using the Web UI to complete your library configuration.
5. Save your library configuration to your host computer or to a USB device.
6. Update your Library Configuration Form with the new drive and configuration information.
7. Resume normal library operations.

Replacing a Power Supply

1. Power OFF the library by pressing and holding down the power button for 4 seconds.
2. Disconnect the power cord from the electrical source, then from the library.
3. Loosen the three blue captive thumbscrews on the power supply located on the back panel of the library.
4. Pull on two of the thumbscrews to pull the unit away from the rear panel of the library, then grasp the top and bottom edge of the power supply and pull it out of the library.



Figure 145. A power supply being removed from a 2U library

5. Remove the packaging from the replacement power supply.
6. Grasp the top and bottom edge of the power supply and push it into the library.
7. Tighten the three blue captive thumbscrews on the power supply located on the back panel of the library.
8. Connect the power cord to the library, then to the electrical source.
9. Power ON the library using the power button on the front panel.
10. Run the Library Verify test (refer to "Service: Library Verify" on page 102).
11. Package the failed power supply in the same packaging in which the new power supply was shipped to you and return to Dell.

Replacing a Library Controller Card

Read Me before Continuing

The Library Controller Card contains a copy of the vital product data (VPD) for your library. The VPD contains your current library configuration. A backup copy of this VPD is contained within the electronics of the Library Enclosure. When the Library Controller Card is replaced, the new replacement card should contain zeros (0's) in key VPD locations. Upon detection of these zeros, the library will automatically attempt to write VPD data to the new Library Controller Card from the backup copy of the VPD contained in the Library Enclosure. In rare occurrences, the new Library Controller Card may contain valid (non-zero) VPD data left over from having been installed previously in another library. If this occurs, the library, which is expecting to see zeros in the VPD area, will instead detect valid VPD data, and will not know which copy of the VPD is the correct one. It will detect a "VPD Mismatch" and display on the Operator Control Panel a screen entitled "VPD Selection", where it is asking you to determine which copy of VPD should be written to the new Library Controller Card.

If the message "VPD Selection" is displayed at the Operator Control Panel, carefully highlight the "VPD from Enclosure" option to copy that version of the VPD to the new Library Controller Card. Then continue with the procedure.

Removal and Replacement

1. Power OFF the library by pressing and holding the power button at the front of the library for 4 seconds.
2. Disconnect the power cord from the electrical source, then from the power supply or supplies at the back of the library.
3. Loosen the two blue captive thumbscrews on the Library Controller Card.
4. Grasp the two thumbscrews and pull the defective Library Controller Card out of the library.



Figure 146. A Library Controller Card being removed from the library

5. Remove the packaging from the replacement Library Controller Card.
6. Grasp the two thumbscrews and push the replacement Library Controller Card into the library.
7. Tighten the two blue captive thumbscrews on the Library Controller Card.
8. Connect the power cord to the power supply or supplies at the back of the library, then to the electrical source.
9. Power ON the library using the power button on the front panel.
10. After power is restored to the Library Controller Card, the library will automatically restore the VPD on the new Library Controller Card from the Library Enclosure. If a "VPD Selection" message is displayed in the Operator Control Panel, see the "Read Me before Continuing" section earlier in this procedure to determine how to respond to the message.
11. Upgrade library firmware and drive firmware to the latest version. See "Service Library: Upgrade Firmware" on page 134.
12. Run the Library Verify test (refer to "Service: Library Verify" on page 102).

Note: Use care when selecting the appropriate VPD to restore from/to. An error in selection here could cause a long downtime.

13. Package the failed Library Controller Card in the same packaging in which the new control board was shipped to you and return to Dell.

Replacing Cartridge Magazines

To replace a cartridge magazine, refer to one of the following procedures:

- Using the Web User Interface, refer to "Manage Library: Release Magazine" on page 115.
- Using the Operator Control Panel, refer to "Control: Magazine" on page 91.
- If your library can not be powered ON, refer to "Releasing the Magazines Manually" on page 175.

Replacing the Library Enclosure

This procedure is necessary when the library enclosure, accessor, or display fails. These components are contained within the replacement library enclosure.

Important: Refer to the Installation Instructions that are included with the new replacement library enclosure. Follow the procedures included in this document for replacing the Library Enclosure, only if Installation Instructions are not included with the new replacement library enclosure.

The replacement library enclosure includes cartridge magazines, a power supply, a Library Controller Card, and a packet of library foot pads. These items are included with the replacement library enclosure due to safety agency requirements. These unused parts will be removed from the replacement library enclosure and returned to Dell in the defective library. The old parts currently in your defective library will be removed, and installed into the replacement library enclosure.

Note: To reduce the risk of personal injury or damage to equipment:

- observe local health and safety requirements and guidelines for manual material handling
- obtain adequate assistance to lift and stabilize the library during installation or removal

Minimum Installation Time: 1 hr.

Minimum Number of Persons Required: 2

Recommended Tools: #2 Phillips screw driver, paper clip, blank (or scratch) data cartridge

Preparing the Defective Library for Replacement

1. If possible, use the Operator Control Panel to unload any drives that contain a cartridge (**Control > Move Cartridges**).
2. Power OFF the defective library.
3. Disconnect all cables from the rear panel of the defective library.
4. If the defective library is rack mounted, remove the two screws (**1** in Figure 147 on page 190) from the front of the defective library anchoring the mounting brackets on the library to the rack. With assistance, remove the defective library from the rack.



a77ug244

1
Figure 147. Removing the two mounting bracket screws anchoring the library to the rack (one screw on each side of the library)

5. Place the defective library on a clean and sturdy work surface.
6. Proceed to “Unpacking and Preparing the Replacement Library Enclosure.”

Unpacking and Preparing the Replacement Library Enclosure

Before installing the replacement library enclosure, it is important to verify that the enclosure is functioning properly.

1. Unpack the replacement library enclosure and place it on a sturdy and clean work surface near the defective library. Save all packaging materials for returning the failing part(s) to Dell.
2. Choose one of the options below for installing the foot pads.

Important: Operating your library on a flat surface without foot pads may damage your library or cause it not to function properly.

- Rack Mount - temporary placement of the foot pads
 - Desktop - permanent placement of the foot pads
- a. For a rack mounted library:
 - 1) Lift the replacement library enclosure slightly above the work surface, have another person place a foot pad under each corner of the library and on each side of the library halfway between the front and back.
 - 2) Gently set the replacement library enclosure on top of the feet. Adjust foot pad placement as necessary to stabilize the library. Do not permanently attach the foot pads to the library.
 - b. For a desktop library:
 - 1) Carefully, lay the library on its side.
 - 2) Peel the adhesive from the back of each of the six foot pads.

- 3) Install the foot pads on the bottom of the library enclosure by pressing each foot into one of the six areas (**1**) as shown in Figure 148.




Figure 148. Foot pads installed on the bottom of the library enclosure

3. Carefully return the library to an upright position.
4. Remove the shipping lock from the top of the replacement library enclosure (see Figure 149 on page 192).




Figure 149. Removing the shipping label and lock from the top of the library and storing on the rear panel

5. Store the lock and label on the back panel of the replacement library enclosure (see Figure 150).



Figure 150. Library shipping lock and label storage location on the rear panel of the library

6. Proceed to “Installing your drive in the replacement library enclosure.”

Installing your drive in the replacement library enclosure

Important: It is important to install the drives from the defective library into the same positions in the replacement library enclosure to maintain your current library configuration.

1. Remove all drives from the defective library (see Figure 151 on page 193) and install them in the same positions in the replacement library enclosure.




Figure 151. Removing a drive sled from the library (drive sled without ESD springs shown)

- a. Ensure that the power cord is unplugged from the power source for each power supply in the defective library enclosure.
- b. On the rear of the defective library, loosen the blue captive thumbscrews on the drive sled.
- c. If necessary, remove the conductive tape from the drive sled.
- d. Pull back on the tape drive handle to remove it from the library.
- e. On the rear of the replacement library enclosure, extend the black pull-out tab that is located underneath the lower right corner of the lowest drive sled position. Ensure that the black pull-out tab remains extended when a drive sled is inserted in the lowest drive position in the library.

Important: If this procedure is not followed, damage to the connector pins can occur.

- f. Place each tape drive into the replacement library enclosure in the same drive slot as it was positioned in the defective library.
 - While the drive assembly is supported, align the drive sled with the groove in the drive slot rails.
 - Slowly push the drive sled forward until it is properly seated.
- g. Tighten the captive thumbscrews until the drive is secure.
- h. If a drive sled without ESD springs is installed (see Figure 151), apply conductive tape as shown in Figure 152 on page 194.

2U Library



4U Library




Figure 152. Drive sled taping diagrams

Note: The gray markers show where conductive tape is placed.

- i. Push the black tab back underneath the drive sled. When inserted properly, only the handle of the tab is visible.
2. Power ON the replacement library enclosure.
 - a. If power ON is successful,
 - 1) After power up, the Ready/Activity LED (**1** in Figure 155 on page 197) turns ON.
 - a) If this message is displayed after the library powers ON, follow the instructions.

```
[New library detected.]  
[Please remove power and insert LCC from old library]  
[ok]
```
 - 2) Power OFF the replacement library enclosure.
 - 3) You must power down, and remove the CRU LCC. Then, replace it with the original LCC to have VPD transferred from the original LCC to the new chassis.
 - 4) Proceed to "Swapping Power Supplies."
 - b. If power ON is not successful,
 - 1) The Error LED (**4** in Figure 155 on page 197) turns ON.
 - 2) Power OFF the replacement library enclosure.
 - 3) Contact technical support for instructions.

Swapping Power Supplies

1. Unplug the power cord from the power source then from the replacement library enclosure if this was not done previously (see "Installing your drive in the replacement library enclosure" on page 192).
2. Swap the Power Supply in the defective library with the Power Supply in the replacement library enclosure.
 - a. Remove the power supply from the defective library and from the replacement library enclosure. To remove a power supply from a library:
 - 1) Loosen the three blue captive thumbscrews on the power supply.

- 2) Pull on two of the thumbscrews, on opposite sides of the power supply, and pull the unit away from the rear panel of the library.
- 3) Grasp the top and bottom edges of the power supply and remove it from the library.
- b. Install the power supply removed from the replacement library enclosure in the defective library to return to Dell. To install a power supply:
 - 1) While supporting the power supply, align the power supply with the groove in the enclosure rails.
 - 2) Push the power supply forward until it is properly seated.
 - 3) Tighten the thumbscrews.



Figure 153. A power supply being removed from a library

3. Plug the power cord into the replacement library enclosure then into a power source.
4. Power ON the replacement library enclosure.
 - a. If power ON is successful:
 - 1) The replacement library enclosure will power up with the Ready/Activity LED (**1** in Figure 155 on page 197) ON.
 - 2) Power OFF the replacement library enclosure.
 - 3) Unplug the power cord from the power source then from the library.
 - 4) Proceed to “Swapping Library Controller Cards” on page 196.
 - b. If power ON is not successful, contact Technical Support for further instructions.

Swapping Library Controller Cards

IMPORTANT - READ ME BEFORE CONTINUING

The Library Enclosure contains a copy of the vital product data (VPD) for your library. The VPD contains your current library configuration. A primary copy of this VPD is contained within the Library Controller Card. A backup copy of this VPD is maintained on the accessor in the enclosure (or chassis). When the Library Enclosure is replaced, the new enclosure electronics should contain zeros (0's) in key VPD locations. Upon detection of these zeros, the library will automatically write VPD data to the replacement library enclosure from the primary copy of the VPD contained in the Library Controller Card. In rare occurrences, the replacement library enclosure may contain valid (non-zero) VPD data left over from having been installed previously in another library. If this occurs, the library firmware, which is expecting to see zeros in the VPD area, will instead detect valid VPD data, and will not know which copy of the VPD is the correct one. It will detect this VPD mismatch and display a message entitled "VPD Selection" on the Operator Control Panel. The library will need your input to determine which copy of VPD to write to the replacement library enclosure. If you are replacing both the Library enclosure and the Library Controller Card, transfer VPD after installing one part before installing the other.

If the message "VPD Selection" is displayed at the Operator Control Panel, carefully highlight the "VPD from Controller" option before selecting OK. This will copy VPD from the controller to the replacement library enclosure.

1. Swap the Library Controller Card in the defective library with the Library Controller Card in the replacement library enclosure.
 - a. Remove the Library Controller Card (see Figure 154) in the defective library and in the replacement library enclosure. To remove a Library Controller Card:
 - 1) Loosen the two blue captive thumbscrews on the Library Controller Card.
 - 2) Grasp the thumbscrews and pull the card out of the library.
 - b. Install the Library Controller Card from the defective library in the replacement library enclosure. Install the Library Controller Card from the replacement library enclosure in the defective library to return to Dell. To install a Library Controller Card:
 - 1) Grasp the Library Controller Card faceplate and align the Library Controller Card with the groove in the enclosure rails.
 - 2) Push the Library Controller Card forward until it is properly seated.

Note: You will hear a snap when the Library Controller Card is fully engaged and installed properly.

 - 3) Tighten the thumbscrews.



Figure 154. Removing a Library Controller Card from the library

Note: If you power on the replacement library without first swapping the Library Controller Card from the original (defective) library enclosure, the following message will appear on the Operator Control Panel shortly after applying power: **"New library detected. Please remove library power and insert Library Controller Card from old Library"**. The library requires the library serial number and other library attributes from the original library which is located in the VPD on the original Library Controller Card in order to continue library initialization. See **Important - Read Me Before Continuing** message listed above.

As a further Note, if the replacement library does **not** complete library initialization successfully after swapping in the original Library Controller Card, be sure to retain the original Library Controller Card so it can be swapped into the "new" replacement library enclosure which will have to be ordered.

2. Plug one end of the power cord (removed earlier from the defective library) into the rear panel of the replacement library enclosure and plug the other end into a power source.
3. Power ON the replacement library enclosure.
 - a. If power ON is successful:
 - 1) The Ready/Activity LED (**1**) will turn ON indicating that all components are functioning properly.
 - 2) After power is restored to the replacement library enclosure, the library will automatically restore the VPD on the replacement library enclosure from the Library Controller Card. If a "VPD Selection" message is displayed in the Operator Control Panel, see the "Read Me before Continuing" section earlier in this procedure to determine how to respond to the message.
 - 3) Power OFF the replacement library enclosure.
 - 4) Proceed to "Swapping Cartridge Magazines" on page 198.
 - b. If power ON is not successful:
 - 1) The Error LED (**4** in Figure 155) will turn ON. This indicates that the Library Controller Card from the defective library is not functioning properly.
 - 2) Power OFF the replacement library enclosure.
 - 3) Refer to Dell technical support for further instructions.




Figure 155. Library front panel LEDs

1	Ready/Activity LED (green)	3	Attention LED (amber)
2	Clean Drive LED (amber)	4	Error LED (amber)

Swapping Cartridge Magazines

1. Manually release and remove all magazines from the defective library and from the replacement library enclosure. To release and remove a cartridge magazine:
 - a. Find the access holes for the right and left magazines (see Figure 156 and Figure 157 on page 199).



Figure 156. Access hole for the left magazine (facing rear of library)




Figure 157. Access hole for the right magazine (facing rear of library)

- b. Push the end of a straightened paper clip into the access hole for each magazine at the back of the library. **DO NOT push the paper clip in more than ½ inch.** While holding the paper clip, have a second person pull the magazine out from the front of the unit.

Note: To prevent dropping the magazine, support both ends of the magazine before it clears the front edge of the library.



Figure 158. Left magazines pulled out of a 4U library (facing front of library)

2. Insert the cartridge magazines removed from the defective library into the same positions in the replacement library enclosure.
3. Insert the cartridge magazines removed from the replacement library enclosure into the same positions in the defective library to return to Dell.
4. Wait for inventory of the magazines to complete.
 - a. If inventory is successful:
 - 1) The replacement library enclosure will complete with the Ready/Activity LED (**1** in Figure 155 on page 197) ON.
 - 2) Power OFF the replacement library enclosure.
 - 3) Proceed to “Swapping Power Supplies” on page 194.
 - b. If inventory is not successful:
 - 1) The Error LED (**4** in Figure 155 on page 197) will turn ON.
 - 2) Power OFF the enclosure.
 - 3) Contact Technical Support for further instructions.

Installing the Replacement Library Enclosure

Refer to the appropriate procedure in this section (rack or desktop) for installing the replacement library enclosure.

Note: If you are shipping the replacement library enclosure to a remote location, install the shipping lock and label before shipment.

Rack Installation:

1. Remove the mounting brackets (**1** in Figure 159 on page 201) and anchors (**2**) from each side of the defective library and install them on the replacement library enclosure.



Figure 159. Mounting brackets and anchors for securing the library in a rack (one bracket and anchor on each side of the library)

2. With assistance, slide the replacement library enclosure onto the metal rails that are already in position in the rack (see Figure 160).




Figure 160. Front view of rack showing screw placement

3. Tighten the mounting bracket screws (**1** in Figure 147 on page 190) to anchor the replacement library enclosure to the rack.
4. Proceed to “Completing the Installation of the Replacement Library Enclosure” on page 202.

Desktop Installation:

1. Place the library in its permanent location.
2. Proceed to “Completing the Installation of the Replacement Library Enclosure” on page 202.

Completing the Installation of the Replacement Library Enclosure

1. Connect all cables to the replacement library enclosure.
2. Power ON the replacement library enclosure.
3. Upgrade library firmware and drive firmware to the latest version.
 - a. Visit www.Dell.com/support to download the latest levels of library and drive firmware.
 - b. Using the Web User Interface (**Service Library > Upgrade Firmware**), upgrade library and drive firmware.
4. Run the Library Verify test (Operator Control Panel: **Service > Library Verify**). This diagnostic requires a blank or scratch data cartridge.
5. Proceed to "Returning the Defective Library Enclosure."

Returning the Defective Library Enclosure

1. Remove the shipping label (**2** in Figure 150 on page 192) and lock (**1**) from the rear panel of the defective library, place the lock in the slot located in the top center of the library, and secure with the shipping lock label. This will secure the library accessor for shipping.
2. Using the replacement library enclosure packaging materials, securely package the defective library (including the left and right magazines, Library Controller Card, and power supply removed from the replacement library enclosure) and return it, to Dell.

Important: Failure to return all of these components to Dell will result in you being charged for any missing components.

Appendix A. SCSI Element Types, SCSI Addresses, and Physical Configurations

For an overview of library partitioning and element addressing, see “Library Partitioning and Element Addressing” on page 205.

The following tables contain element addresses for the 2U library and the 4U library.

Table 45. 2U library SCSI Element Types and Element Addresses

Element Type	Element Address Range
Media Transport (Accessor) Element (MTE)	1 (0x01)
I/O Station Element (IEE)	16 (0x10)
Data Transfer (Drive) Element (DTE)	256 (0x100), 257 (0x101)
Storage Elements (STE)	4096 (0x1000) - 4118 (0x1016)

Table 46. 4U library SCSI Element Types and Element Addresses

Element Type	Element Address Range
Media Transport (Accessor) Element (MTE)	1 (0x01)
I/O Station Elements (IEE)	16 (0x10), 17 (0x11), 18 (0x12)
Data Transfer (Drives) Elements (DTE)	256 (0x100), 257 (0x101), 258 (0x102), 259 (0x103)
Storage Elements (STE)	4096 (0x1000) - 4140 (0x102C)

2U Library I/O Slot, Storage Slots and Drive Slot Element Addresses and Physical Locations

For an overview of library partitioning and element addressing, see “Library Partitioning and Element Addressing” on page 205.

The following table contains the physical location and SCSI element address (decimal and hexadecimal) of the I/O slot, storage slots, and drive slot in the 2U library configured with one drive and one logical partition. If a second drive were installed, it would be located at address 257 (0x101).

With two drives installed, the library can be configured as one partition (with two drives) or as two partitions (with one drive per partition).

When configured with two drives and one logical partition, the Element Address assignments will be as follows: DTE assignments

- Drive 1: 256 (0x100)
- Drive 2: 257 (0x101)

The STE assignments will be as shown in Table 47 on page 204.

When configured with two drives and one logical partition, the Element Address assignments will be as follows:

DTE assignments

- Logical Library 1: Drive 1: 256 (0x100)
- Logical Library 2: Drive 2: 256 (0x100)

STE assignments

- Logical Library 1: Slot 1 through slot 11 4096 (x1000) through 4106 (0x100A)
- Logical Library 2: Slot 12 through slot 23 4096 (x1000) through 4107 (0x100B)

Table 47. 2U library SCSI element addresses for storage slots and drive slot (one logical partition with one drive)

Left Magazine ⇐ Front of 2U library				Library Rear Panel	Right Magazine Front of 2U library ⇒			
Slot 8 4103 (0x1007)	Slot 9 4104 (0x1008)	Slot 10 4105 (0x1009)	Slot 11 4106 (0x100A)	Drive 1 256 (0x100)	Slot 23 4118 (0x1016)	Slot 22 4117 (0x1015)	Slot 21 4116 (0x1014)	Slot 20 4115 (0x1013)
Slot 4 4099 (0x1003)	Slot 5 4100 (0x1004)	Slot 6 4101 (0x1005)	Slot 7 4102 (0x1006)		Slot 19 4114 (0x1012)	Slot 18 4113 (0x1011)	Slot 17 4112 (0x1010)	Slot 16 4111 (0x100F)
I/O slot 16 (0x10)	Slot 1 4096 (0x1000)	Slot 2 4097 (0x1001)	Slot 3 4098 (0x1002)		Slot 15 4110 (0x100E)	Slot 14 4109 (0x100D)	Slot 13 4108 (0x100C)	Slot 12 4107 (0x100B)

4U Library I/O Slots, Storage Slots, and Drive Slots Element Addresses and Physical Locations

For an overview of library partitioning and element addressing, see “Library Partitioning and Element Addressing” on page 205.

The following table contains the physical location (Slot x) and SCSI element address in decimal (4xxx) and in hexadecimal (0x10xx) of the I/O slots, storage slots, and drive slots in the 4U library containing only two drive sleds.

In older 4U libraries where the Dedicated Cleaning Slot (DCS) is in a fixed location (slot 9) and elected to be retained as a DCS (option to delete DCS is available in library firmware greater than 1.95), the above slot numbering and element address changes starting with slot 10. In 4U libraries with a DCS, the information shown in slot 9 below moves to slot 10 and so forth through the remaining magazine slots. The final slot is slot 44 instead of slot 45 for libraries without a DCS. See “Configuring I/O Stations and Reserving Slots” on page 136 for information on how to delete the dedicated cleaning slot. Once the DCS is deleted, you cannot get it back. You will have to create a reserved slot if you want to clean the drive(s).

Table 48. 4U library SCSI element addresses for storage slots and drive slot (one logical partition with drives in slot 1 and slot 2)

Upper Left Magazine ⇐Front of 4U library				Library Rear Panel	Upper Right Magazine Front of 4U library⇒			
Slot 18 4113 (0x1011)	Slot 19 4114 (0x1012)	Slot 20 4115 (0x1013)	Slot 21 4116 (0x1014)	Drive 2 257 (0x101)	Slot 45 4140 (0x102C)	Slot 44 4139 (0x102B)	Slot 43 4138 (0x102A)	Slot 42 4137 (0x1029)
Slot 14 4109 (0x100D)	Slot 15 4110 (0x100E)	Slot 16 4111 (0x100F)	Slot 17 4112 (0x1010)		Slot 41 4136 (0x1028)	Slot 40 4135 (0x1027)	Slot 39 4134 (0x1026)	Slot 38 4133 (0x1025)
Slot 10 4105 (0x1009)	Slot 11 4106 (0x100A)	Slot 12 4107 (0x100B)	Slot 13 4108 (0x100C)		Slot 37 4132 (0x1024)	Slot 36 4131 (0x1023)	Slot 35 4130 (0x1022)	Slot 34 4129 (0x1021)

Table 48. 4U library SCSI element addresses for storage slots and drive slot (one logical partition with drives in slot 1 and slot 2) (continued)

Lower Left Magazine				Drive 1 256 (0x100)	Lower Right Magazine			
I/O Slot 3 18 (0x12)	Slot 7 4102 (0x1006)	Slot 8 4103 (0x1007)	Slot 9 4104 (0x1008)		Slot 33 4128 (0x1020)	Slot 32 4127 (0x101F)	Slot 31 4126 (0x101E)	Slot 30 4125 (0x101D)
I/O Slot 2 17 (0x11)	Slot 4 4099 (0x1003)	Slot 5 4100 (0x1004)	Slot 6 4101 (0x1005)		Slot 29 4124 (0x101C)	Slot 28 4123 (0x101B)	Slot 27 4122 (0x101A)	Slot 26 4121 (0x1019)
I/O Slot 1 16 (0x10)	Slot 1 4096 (0x1000)	Slot 2 4097 (0x1001)	Slot 3 4098 (0x1002)		Slot 25 4120 (0x1018)	Slot 24 4119 (0x1017)	Slot 23 4118 (0x1016)	Slot 22 4117 (0x1015)

Library Partitioning and Element Addressing

Library 4U systems with firmware versions of .80 and higher, and containing at least 2 drives, have the ability to configure two logical libraries (create two partitions). This partitioning has been expanded with the new library firmware and half-high drive integration. Now it is possible to configure 1, 2, 3 or 4 partitions in the 4U library. Additionally the 2U library can now be configured into one or two partitions. Each library must contain at least one drive per logical library (partition). In a partitioned library, the Operator Control Panel (OCP) only reports the status of logical library 1 in the main menu due to space limitations. You must navigate to the logical libraries status in the OCP to get the information on the additional library partitions.

Partitioning of 2U Libraries

When two half height drives are installed in a 2U library, the library firmware will support partitioning in the same way that the 4U supports partitioning with two full height drives today. The first partition will contain the first magazine and the first drive. The second partition will contain the second magazine and the second drive. The I/O station (if configured as I/O) will be shared, as is done with the partitioned 4U library.

One full height drive is "Drive 1". When using half height drives, the first half height drive position will be called "Drive 1", The second half height drive position will be called "Drive 2."

Partitioning of 4U Libraries

When one or more half height drives are added to a 4U library, the drive naming will change. Currently, the first full height drive is "Drive 1" and the second full height drive is "Drive 2". When you consider that each full height drive slot may contain one or two half height drives, there are four potential drives in the space that used to occupy two. As a result, the first half height drive position, or the first full-high drive position, will be called "Drive 1". The second half height drive position will be called "Drive 2". The third half height drive position, or the second full height drive position, will be called "Drive 3". The fourth half height drive position will be called "Drive 4".

Important: In a 4U library a full height drive sled may be installed in drive slot 1 (drive will occupy slot 1 and slot 2) or drive slot 3 (drive will occupy slot 3 and slot 4). A full height drive sled should never be installed in drive slot 2 (drive will occupy slot 2 and slot 3).

Mixing of Drives

The library will support a mix of full height and half height drives in the same physical library and the same logical library. They will support a mix of drives in the same physical library and the same logical

library. They will also support a mix of SCSI, SAS, and Fibre Channel in the same physical library and the same logical library; however, mixing drive interface types in the same logical library is not recommended.

Important: Drives that do not share a common media type cannot be mixed in the same logical library. For instance, Gen 4 and Gen 7 drives cannot use the same media and so they cannot be mixed. LTO 4 media **cannot** be read on an LTO 7 drive.

Configuration of a 1 - Partition System

A one partition system configured for a 4U library contains any and all drives present in any drive positions, and it will contain all four magazines. When configured with one logical partition, the Element Address assignments will be as follows: DTE assignments will be as shown in Figure 161

STE assignments

- Logical Library 1: Slot1 through 23 4096 (0x1000) through 4118 (0x1016) as shown in Figure 164 on page 207




Figure 161. Configuration of a one - partition system

Configuration of a 2 - Partition System

A two partition system must have a minimum of two drives, but may have three or four drives. Partition 1 will contain any drives in drive position 1 and drive position 2. Partition 1 will also contain magazine 1 and magazine 2. Partition 2 will contain any drives in drive position 3 and drive position 4. Partition 2 will also contain magazine 3 and magazine 4.

When configured with two logical partitions, the Element Address assignments will be as follows: DTE assignments will be as shown in Figure 162.

STE assignments

- Logical Library 1: Slot 1 through slot 21 4096 (x1000) through 4116 (0x1014)
- Logical Library 2: Slot 22 through slot 45 4096 (x1000) through 4019 (0x1017)




Figure 162. Configuration of a two - partition system

Configuration of a 3 - Partition System

A three partition system must have at least three drives installed. A drive must be installed in drive position 1, another drive must be installed in drive position 2, and another drive must be installed in either drive position 3 or drive position 4. Partition 1 will contain the first drive and the first magazine. Partition 2 will contain the second drive and the second magazine. Partition 3 will contain any drives in drive position 3 and drive position 4. Partition 3 will also contain magazine 3 and magazine 4.

STE assignments

- Logical Library 1: Slot 1 through slot 9 4096 (x1000) through 4104 (0x1008)
- Logical Library 2: Slot 10 through slot 21 4096 (x1000) through 4107 (0x100B)
- Logical Library 3: Slot 22 through slot 45 4096 (x1000) through 4119 (0x1017)




Figure 163. Configuration of a three - partition system

Configuration of a 4 - Partition System

A four partition system must have four drives. Each partition will contain one drive and one magazine.

When configured with four logical partitions, the Element Address assignments will be as follows: DTE assignments will be as shown in Figure 164.

STE assignments

- Logical Library 1: Slot 1 through slot 9 4096 (x1000) through 4104 (0x1008)
- Logical Library 2: Slot 10 through slot 21 4096 (x1000) through 4107 (0x100B)
- Logical Library 3: Slot 22 through slot 33 4096 (x1000) through 4107 (0x100B)
- Logical Library 4: Slot 34 through slot 45 4096 (x1000) through 4107 (0x100B)




Figure 164. Configuration of a four - partition system

SCSI Element Addressing

Every logical library starts at the first drive slot with the current assigned element start address (default value 256). It will be incremented from the bottom to the top slots for every drive slot. There is one exception to this addressing scheme to accommodate libraries currently in the field. A 4U library which contains only full height drives will continue to have the addresses assignments 256 and 257, thus causing no interruptions to their operation. Drive slots will still be incremented by 1 for each drive slot position.

Note: Exchanging drives with different form factors will result in the library needing to be reconfigured.

4U Unit with only FH drives
(1 logical library)

SCSI Element	Slot
257	4
	3
256	2
	1

4U Unit with FH and HH drives
(1 logical library)

SCSI Element	Slot
258	4
	3
257	2
256	1

a77ug165

Figure 165. Examples of SCSI element addressing

The SCSI specification does not allow gaps in the SCSI element addressing. Special handling is needed for empty drive slots to fulfill the specification. Also temporarily removed drives need to have their addresses preserved to not confuse the attached host and host application. Generally only drives which are currently physically available or temporarily removed are reported. Empty (unused) slots located at the bottom or the top should not be reported, with an exception in case of a “removed” condition. A drive slot which does not contain a drive, and has a position between used slots, needs to be reported as a SCSI element. To signal the host application that this slot is not usable, its ACCESS bit will be disabled.

Note: When reducing the number of drives in your library, update the Logical Library configuration. This will remove the Attention LED on the front panel and the exclamation mark on the Home screen indicating that a drive is missing.

Updating the Logical Library configuration will also update the drive element addressing and drive numbering. Replacing LTO half height drives with full height drives may require you to execute Restore Factory Defaults to correctly update the drive element addressing and drive numbering. See “Configure Library: Save/Restore Configuration” on page 128.

Appendix B. TapeAlert Flags

This appendix is intended to provide additional information to the reader about the tape drive. All error code and diagnostic information contained in this chapter can be accessed from the Operator Control Panel of the Library. The drive portion of the Operator Control Panel Display will contain any drive error codes. Therefore there is no need to open the Library to access the buttons on the drive as described in this chapter.

TapeAlert is a standard that defines status conditions and problems experienced by devices such as tape drives, autoloaders, and libraries. The standard enables a server to read TapeAlert messages (called *flags*) from a tape drive via the SCSI bus. The server reads the flags from Log Sense Page 0x2E.

This library is compatible with TapeAlert technology, which provides error and diagnostic information about the drives and the library to the server. Because library and drive firmware may change periodically, the SNMP interface in the library does not require code changes if devices add additional TapeAlerts that are not supported today. However, should this occur the Management Information Block (MIB) is written to minimize impact to the SNMP monitoring station. At the time of this writing, the TapeAlert flags in this appendix correctly represent TapeAlerts that will be sent. The MIB file should not be taken to mean that all traps that are defined in the MIB (refer to Appendix F, “SNMP Status MIB Variables and Traps,” on page 237) will be sent by the library or that they will be sent in the future.

This appendix lists TapeAlert flags that are supported by the Ultrium 3 and later Tape Drives.

TapeAlert Flags Supported by the Library

Parameter Code (d=decimal)	Flag name	Type	Action Required
01d	Library Hardware A	C	The media changer mechanism is having difficulty communicating with the drive. Power cycle the library and try the operation again. <ul style="list-style-type: none">• If the problem is corrected, run Library Verify before resuming normal library operations. Refer to “Service: Library Verify” on page 102.• If the problem persists, contact technical support.
02d	Library Hardware B	W	There is a problem with the media changer mechanism. Power cycle the library and try the operation again. <ul style="list-style-type: none">• If the problem is corrected, run Library Verify before resuming normal library operations. Refer to “Service: Library Verify” on page 102.• If the problem persists, contact technical support.
03d	Library Hardware C	C	The media changer has a hardware fault: <ul style="list-style-type: none">• Ensure that the media changer and drives are not being used by any host, then reset the library from the front panel.• If the problem persists, contact technical support.
04d	Library Hardware D	C	<ul style="list-style-type: none">• Ensure that the media changer and drives are not being used by any host, then reset the library from the front panel.• If the problem persists, contact technical support.

13d	Library Pick Retry	W	<p>There is a potential problem with the cartridge loader picking a cartridge from a drive or slot.</p> <ul style="list-style-type: none"> • No action needs to be taken at this time. • If the problem persists, contact technical support. <p>This flag is cleared when the next move command is received.</p>
14d	Library Place Retry	W	<p>There is a potential problem with the cartridge loader placing a cartridge into a slot.</p> <ul style="list-style-type: none"> • No action needs to be taken at this time. • If the problem persists, contact technical support. <p>This flag is cleared when the next move command is received.</p>
15d	Drive Load Retry	W	<p>There is a potential problem with the cartridge loader or drive when placing a cartridge into a drive.</p> <ul style="list-style-type: none"> • No action needs to be taken at this time. • If the problem persists, contact technical support. <p>This flag is cleared when the next move command is received.</p>
17d	Library I/O Station	C	There is a mechanical problem with the library media I/O Station.
18d	Media Changer	C	It is set when a magazine is removed from the changer.
19d	Library Security	W	Library security has been compromised. The door was opened then closed during operation.
21d	Media Changer	I	It is set when the changer is set offline.
24d	Library Inventory	C	<p>The library has detected an inconsistency in its inventory.</p> <ul style="list-style-type: none"> • Redo the library inventory to correct inconsistency. • Restart the operation. <p>Check the applications users manual or the hardware users manual for specific instructions on redoing the library inventory.</p>
25d	Media Changer	W	It is set when it receives unsupported SCSI opcodes.
27d	Cooling FAN Failure	W	One or more fans inside the library have failed. This flag is cleared when all fans are working again.
32d	Unreadable Bar Code Labels	I	The library was unable to read the barcode on a cartridge.
<ul style="list-style-type: none"> • D = Decimal • I = Informational suggestion to user • W = Warning. Remedial action is advised. Performance of data may be at risk. • C = Critical immediate remedial action is required. 			

TapeAlert Flags Supported by the Drive

Table 49. TapeAlert Flags Supported by the Ultrium Tape Drive

Flag Number	Flag	Description	Action Required
3	Hard error	Set for any unrecoverable read, write, or positioning error. (This flag is set in conjunction with flags 4, 5, or 6.)	See the Action Required column for Flag Number 4, 5, or 6 in this table.
4	Media	Set for any unrecoverable read, write, or positioning error that is due to a faulty tape cartridge.	Replace the tape cartridge.
5	Read failure	Set for any unrecoverable read error where isolation is uncertain and failure could be due to a faulty tape cartridge or to faulty drive hardware.	If Flag 4 is also set, the cartridge is defective. Replace the tape cartridge.
6	Write failure	Set for any unrecoverable write or positioning error where isolation is uncertain and failure could be due to a faulty tape cartridge or to faulty drive hardware.	If Flag Number 9 is also set, make sure that the write-protect switch is set so that data can be written to the tape (see "Write-Protect Switch" on page 144). If Flag Number 4 is also set, the cartridge is defective. Replace the tape cartridge.
7	Media life	Set when the tape cartridge reaches its end of life (EOL).	<ol style="list-style-type: none"> 1. Copy the data to another tape cartridge. 2. Discard the old (EOL) tape.
8	Not data grade	Set when the cartridge is not data-grade. Any data that you write to the tape is at risk.	Replace the tape with a data-grade tape.
9	Write protect	Set when the tape drive detects that the tape cartridge is write-protected.	Ensure that the cartridge's write-protect switch is set so that the tape drive can write data to the tape (see "Write-Protect Switch" on page 144).
10	No removal	Set when the tape drive receives an UNLOAD command after the server prevented the tape cartridge from being removed.	Refer to the documentation for your server's operating system.
11	Cleaning media	Set when you load a cleaning cartridge into the drive.	No action required.
12	Unsupported format	Set when you load an unsupported cartridge type into the drive or when the cartridge format has been corrupted.	Use a supported tape cartridge.
15	Cartridge memory chip failure	Set when a cartridge memory (CM) failure is detected on the loaded tape cartridge.	Replace the tape cartridge.
16	Forced eject	Set when you manually unload the tape cartridge while the drive was reading or writing.	No action required.
17	Media loaded is Read-only format	Set when a cartridge marked as read only is loaded into the drive. The flag is cleared when the cartridge is ejected.	No action required.

Table 49. TapeAlert Flags Supported by the Ultrium Tape Drive (continued)

Flag Number	Flag	Description	Action Required
18	Tape directory corrupted in the cartridge memory	Set when the drive detects that the tape directory in the cartridge memory has been corrupted.	Re-read all data from the tape to rebuild the tape directory.
19	Nearing media life	Set when the tape cartridge is nearing its specified end of life. The flag is cleared when the cartridge is removed from the drive.	<ol style="list-style-type: none"> 1. Copy the data to another tape cartridge. 2. Replace the tape cartridge.
20	Clean now	Set when the tape drive detects that it needs cleaning.	Clean the tape drive.
21	Clean periodic	Set when the drive detects that it needs routine cleaning.	Clean the tape drive as soon as possible. The drive can continue to operate, but you should clean the drive soon.
22	Expired clean	Set when the tape drive detects a cleaning cartridge that has expired.	Replace the cleaning cartridge.
23	Invalid cleaning tape	Set when the drive expects a cleaning cartridge and the loaded cartridge is not a cleaning cartridge.	Use a valid cleaning cartridge.
30	Hardware A	Set when a hardware failure occurs that requires that you reset the tape drive to recover.	
31	Hardware B	Set when the tape drive fails its internal Power-On Self Tests.	Note the error code on the single-character display, then
32	Interface	Set when the tape drive detects a problem with the host interface.	
33	Eject media	Set when a failure occurs that requires you to unload the cartridge from the drive.	Unload the tape cartridge, then reinsert it and restart the operation.
34	Download fail	Set when an FMR image is unsuccessfully downloaded to the tape drive through the host interface.	Ensure that it is the correct FMR image. Download the FMR image again.
37	Drive voltage	Set when the drive detects that the externally supplied voltages are either approaching the specified voltage limits or are outside the voltage limits.	
38	Predictive failure of drive hardware	Set when a hardware failure of the tape drive is predicted.	
39	Diagnostics required	Set when the drive detects a failure that requires diagnostics for isolation.	
51	Tape directory invalid at unload	Set when the tape directory on the tape cartridge that was previously unloaded is corrupted. The file-search performance is degraded.	Use your backup software to rebuild the tape directory by reading all the data.
52	Tape system area write failure	Set when the tape cartridge that was previously unloaded could not write its system area successfully.	Copy the data to another tape cartridge, then discard the old cartridge.

Table 49. TapeAlert Flags Supported by the Ultrium Tape Drive (continued)

Flag Number	Flag	Description	Action Required
53	Tape system area read failure	Set when the tape system area could not be read successfully at load time.	Copy the data to another tape cartridge, then discard the old cartridge.
55	Loading Failure	When loading a tape into a drive, a hardware malfunction can prevent the tape from being loaded into the drive, or the tape may actually get stuck in the drive.	<p>Take this action if the tape cartridge will not load in the drive:</p> <ol style="list-style-type: none"> 1. Remove the tape cartridge from the library and inspect it for damage. If damaged, discard it. 2. Try another cartridge in that tape drive. If it still fails, replace the drive sled. See “Removing/Installing/Adding a Tape Drive Sled” on page 181. <p>Take this action if the tape is stuck in the drive:</p> <ol style="list-style-type: none"> 1. Attempt to unload the tape from the drive using the host backup application that is currently using the drive, or using the remote or local UI. 2. If the cartridge will not unload, contact technical support.
56	Unload Failure	When attempting to unload a tape cartridge, a drive hardware malfunction can prevent the tape from being ejected. The tape may actually be stuck in the drive.	<ol style="list-style-type: none"> 1. Unload the cartridge from the drive using the Operator Control Panel (Control > Move Cartridge) or the Web User Interface (Manage Library > Move Media). 2. Cycle drive power using the Operator Control Panel (Service > Service > Drive Power) or the Web User Interface (Configure Library > Drives). 3. Try unloading the cartridge from the drive again using the Operator Control Panel (Control > Move Cartridge) or the Web User Interface (Manage Library > Move Media). 4. If the cartridge will not unload from the drive, contact technical support.
59	WORM Medium – integrity check failed	Set when the drive determines that the data on tape is suspect from a WORM point of view.	<ol style="list-style-type: none"> 1. Copy the data to another WORM tape cartridge. 2. Discard the old WORM tape.
60	WORM Medium – Overwrite attempted	Set when the drive rejects a write operation because the rules for allowing WORM writes have not been met. Data can only be appended to WORM media. Overwrites to WORM media are not allowed.	Append the information on a WORM tape cartridge or write the data to a non-WORM cartridge.

Appendix C. Sense Data

When a drive encounters an error, it makes sense data available. You can use device drivers to examine the sense data and determine errors. The device drivers may conflict with some commercial software applications unless properly configured. To avoid conflicts on Windows operating systems, refer to your device driver's procedures for setting the driver to manual startup mode.

If your application uses other device drivers, see the appropriate documentation for those drivers to obtain the sense data.

In addition to device drivers, other methods exist for obtaining sense data and error information. The sections that follow describe alternatives for gathering such information.

Library sense data

The following table lists the Additional Sense Codes (ASC) and Additional Sense Code Qualifiers (ASCQ) associated with the reported Sense Keys.

A sense key of 00h (no sense) has no ASC/ASCQ associated with it. A few ASC/ASCQs are associated with more than one sense key. The sense keys that gives particular ASC/ASCQs are indicated within the Sense Key column. ASC/ASCQs can indicate an abnormal element state as part of element descriptor.

Table 50. Library Sense Keys, ASC and ASCQ

Sense Key	ASC	ASCQ	Description
Recovered Error (01)	0Ah	00h	Error log overflow
	47h	00h	SCSI parity error
Not Ready (02)	00h	17h	Drive cleaning requested
	04h	00h	Cause not reportable
	04h	01h	In progress becoming ready, scanning magazines, etc.
	04h	02h	Initializing command required
	04h	03h	Manual intervention required
	04h	07h	Operation in progress
	04h	12h	Offline
	04h	83h	Door open
	04h	85h	Firmware upgrade in progress
	04h	87h	The drive is not enabled
	04h	88h	The drive is busy
	04h	89h	The drive is not empty
	04h	9Ah	Drive fibre down
	04h	8Eh	The media changer is in sequential mode
	30h	03h	Cleaning in progress
	3Bh	12h	Magazine removed
04h	8Fh	No free storage slots	

Table 50. Library Sense Keys, ASC and ASCQ (continued)

Sense Key	ASC	ASCQ	Description
Medium Error (03)	30h	00h	Incompatible media installed
	30h	03h	Cleaning tape installed
	30h	07h	Cleaning failure

Table 50. Library Sense Keys, ASC and ASCQ (continued)

Sense Key	ASC	ASCQ	Description
Hardware Error (04)	81h	80h	Cannot initialize bar code reader
	81h	81h	No response from bar code reader
	81h	82h	No response from EEPROM
	81h	83h	Slave robotic generic problem
	81h	84h	Setting of gripper pic value failed
	81h	85h	Setting of slider pic value failed
	81h	86h	Setting of elevator pic value failed
	81h	87h	Setting of rotation pic value failed
	81h	88h	Setting of sled pic value failed
	81h	89h	Gripper blocked
	81h	8Ah	Slider blocked
	81h	8Bh	Elevator blocked
	81h	8Ch	Rotation blocked
	81h	8Dh	Sled blocked
	81h	8Eh	Cannot find gripper block
	81h	8Fh	Cannot find slider block
	81h	90h	Cannot find elevator block
	81h	91h	Cannot find rotation block
	81h	92h	Cannot find sled block
	81h	93h	Gripper outside range
	81h	94h	Slider outside range
	81h	95h	Elevator outside range
	81h	96h	Rotation outside range
	81h	97h	Sled outside range
	81h	98h	No cartridge present sensor found
	81h	99h	No slider home sensor found
	81h	9Ah	No rotation home sensor found
	81h	9Bh	No sled position sensor found
	81h	9Ch	The range of gripper is wrong
	81h	9Dh	The range of slider is wrong
	81h	9Eh	The range of elevator is wrong
	81h	9Fh	The range of rotation is wrong
	81h	A0h	The range of sled is wrong
	81h	A1h	Open import/export element failed
81h	A2h	Locking failed	
81h	A3h	SE2 Block	
81h	A4h	SE2 No Block	
81h	A5h	No Sled2 Home Sensor	
81h	A6h	No Elev Home Sensor	

Table 50. Library Sense Keys, ASC and ASCQ (continued)

Sense Key	ASC	ASCQ	Description
Hardware Error (04) (continued)	81h	B0h	Slave robotic controller response timeout
	81h	B1h	NACK received from slave robotic controller
	81h	B2h	Slave robotic controller communication failed
	81h	B3h	Slave robotic controller urgent stop
	81h	B4h	Cartridge did not transport completely
	81h	B5h	Slave robotic controller does not respond on command
	80h	C0h	Network init
	80h	C1h	Telnet interface
	80h	C2h	Webserver
	80h	C3h	EEPROM parameter
	80h	C4h	Cannot init LAN card
	80h	C5h	Write to EEPROM failed
	80h	C6h	Ping command did not reach target
	80h	C7h	Cannot upgrade from USB
	80h	C9h	Cannot Upgrade Robotic from Flash
	80h	D0h	ROM error
	80h	D1h	RAM error
	80h	D2h	NVRAM error
	80h	D3h	CTC error
	80h	D4h	UART error
	80h	D5h	Display error
	80h	D6h	Memory error
	80h	D7h	Fatal system error
	80h	D8h	dBase error
	80h	D9h	No SCSI IC detected
	80h	DAh	Different bar code labels
	80h	DBh	External cooling fan failure
	80h	DCh	Internal I2C bus error
	80h	DFh	Power good signal changed from 2 to 1 PS
	80h	E0h	Incompatible magazine detected
	80h	E2h	Unsupported accessory detected
	80h	EBh	Power supply health check failed due to a power supply failure. Please contact service.
	82h	F0h	Over temperature problem
	82h	F1h	Drive communication error
82h	F2h	Drive sled not present	
82h	F3h	Drive broken: needs repair	

Table 50. Library Sense Keys, ASC and ASCQ (continued)

Sense Key	ASC	ASCQ	Description
Hardware Error (04) (continued)	82h	F4h	Drive load timeout
	82h	F5h	Drive unload timeout
	82h	F6h	Drive never present
	82h	F7h	Drive support ticket error
	82h	F8h	Drive invalid command
	82h	F9h	Drive invalid parameter
	82h	FAh	SDCI microcode error
	82h	FBh	Drive logged out
	82h	FCh	Internal drive command failed with Check Condition
	82h	FDh	Internal drive command timeout

Table 50. Library Sense Keys, ASC and ASCQ (continued)

Sense Key	ASC	ASCQ	Description
Illegal Request (05h)	1Ah	00h	Parameter length error
	20h	00h	Invalid command operation code
	21h	01h	<ul style="list-style-type: none"> Invalid element address - associated with Error Code 33 Invalid drive specified - associated with Error Code 35
	24h	00h	<ul style="list-style-type: none"> Invalid field in the CDB - associated with Error Code 34 SEND DIAG Invalid test number - associated with Error Code 36
	3Dh	00h	SCSI invalid ID message
	25h	00h	Invalid LUN
	2Ch	00h	Command sequence error
	26h	00h	Invalid field in parameter list
	26h	01h	Parameter list error: parameter not supported
	26h	02h	Parameter value invalid
	26h	90h	Wrong firmware image, does not fit boot code
	26h	91h	Wrong personality firmware image
	26h	93h	Wrong firmware image, checksum error
	30h	12h	Incompatible medium
	39h	00h	Saving parameters not supported
	3Bh	0Dh	Medium destination element full
	3Bh	0Eh	Medium source element empty
	3Bh	11h	Medium magazine not accessible
	3Bh	81h	Medium belongs to another partition
	3Bh	A0h	Medium transfer element full
	53h	02h	Library media removal prevented state set
	53h	03h	Drive media removal prevented state set
	44h	80h	Bad status library controller
	44h	81h	Source not ready
	44h	82h	Destination not ready
	44h	83h	Cannot make reservation
	44h	84h	Wrong drive type
	44h	85h	Invalid slave robotic controller request
	44h	86h	Accessor not initialized
	80h	5Bh	Incompatible medium generation (sense key medium error)
	80h	5Dh	Wrong drive fw for drive
	80h	5Eh	Full height drive at illegal position
	80h	75h	Download prevented due to incompatible bar code reader hardware
	80h	77h	Download prevented due to incompatible LCM
	80h	78h	Download prevented due to incompatible Robot Code
	80h	79h	Download prevented due to incompatible drive version
	83h	00h	Failure in LME interface

Table 50. Library Sense Keys, ASC and ASCQ (continued)

Sense Key	ASC	ASCQ	Description
Unit Attention (06h)	28h	00h	Not ready to ready transition
	28h	01h	Import/export element accessed
	29h	01h	Power on occurred
	29h	02h	SCSI Bus reset occurred
	29h	05h	Bus type changed to Single Ended (SE)
	29h	06h	Bus type changed to Low Voltage Differential (LVD)
	2Ah	01h	Mode parameters changed
	2Ah	10h	Time stamp changed
	3Bh	13h	Medium magazine inserted
	3Fh	01h	Microcode has changed
	53h	02h	Media removal prevented
Command Aborted (0Bh)	3Fh	0Fh	ECHO buffer overwritten
	43h	00h	SCSI message error
	47h	00h	SCSI parity error
	49h	00h	SCSI invalid message
	4Eh	00h	Overlapped command attempt

Drive Sense Data

LTO Ultrium 4 and later drives contain hardware which performs user data write encryption and read decryption, protecting all user data written to the medium from unauthorized use, provided it is integrated into a secure system design.

Table 51. LTO Tape Drive Sense Data

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
0	Address valid When set to 1, the info byte field contains a valid logical block address.	Error Code						
1	Segment Number (0)							

Table 51. LTO Tape Drive Sense Data (continued)

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
2	Filemark	EOM (end of medium)	ILI (Incorrect length indicator)	Reserved	Sense Key Description			
					0 - No sense 1 - Recovered error 2 - Not ready 3 - Media error 4 - Hardware error 5 - Illegal request 6 - Unit attention 7 - Data protect 8 - Blank Check 9 - Reserved A - Reserved B - Aborted command C - Reserved D - Volume overflow E - Reserved F - Reserved			
3	Information byte (most significant byte)							
4	Information byte							
5	Information byte							
6	Information byte (least significant byte)							
7	Additional Sense Length							
8-11	Command specific information							

Table 51. LTO Tape Drive Sense Data (continued)

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
12-13	Additional Sense Code (ASC) Additional Sense Code Qualifier (ASCQ) Byte 12 Byte 13 ASC ASCQ							
00	00	00 - No additional sense - The flags in the sense data indicate the reason for the command failure						
00	01	01 - Filemark detected - A Read or Space command terminated early due to an FM. The FM flag is set.						
00	02	02 - EOM - A Write or Write File Marks command failed because the physical end of tape was encountered, or a Read or Space command encountered EOM. The EOM flag is set						
00	04	04 - BOM - A space command ended at Beginning of Tape. The EOM bit is also set						
00	05	05 - EOD - Read or Space command terminated early because End of Data was encountered						
00	16	16 - Operation in Progress						
04	00	00 - Cause not reportable - A cartridge is present in the drive, but it is in the process of being unloaded						
04	01	01 - Becoming Ready - A media access command was received during a front panel initiated load or an immediate reported load command						
04	02	02 - Initializing Command Required - A cartridge is present in the drive, but is not logically loaded. A Load command is required						
04	03	03 - Manual Intervention Required - A cartridge is present in the drive but could not be loaded or unloaded without manual intervention						
04	10	10 - Logical unit not ready, auxiliary memory not accessible						
04	12	12 - Logical unit not ready, offline						
08	01	01 - Logical unit communication failure						
09	00	00 - Track following error (servo)						
0C	00	00 - Write Error - A Write operation has failed. This is probably due to bad media, but may be hardware related						
11	00	00 - Unrecovered Read Error - A Read operation failed. This is probably due to bad media, but may be hardware related						
11	12	12 - Auxiliary memory read error. The drive reported that it is unable to read the Auxiliary Memory in a WORM cartridge.						
14	00	00 - Recorded Entity Not Found - A space or Locate command failed because a format violation prevented the target from being found.						
14	03	03 - End Of Data not found - A Read type operation failed because a format violation related to a missing EOD data set						
14	10	10 - Not Ready - Auxiliary memory not accessible. The drive is not able to become ready because it is unable to access the Auxiliary Memory in a WORM cartridge.						
17	01	01 - Recovered data with retries						
1A	00	00 - Parameter list length error - The amount of parameter data sent is incorrect						
20	00	00 - Invalid Command Operation Code - The Operation Code in the command was not a valid Operation Code						
24	00	00 - Invalid field in CDB - An invalid field has been detected in a Command Descriptor Block						
25	00	00 - LUN not supported - The command was addressed to a non-existent logical unit number						
26	00	00 - Invalid Field in Parameter List - An invalid field has been detected in the data sent during the data phase						

Table 51. LTO Tape Drive Sense Data (continued)

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
12-13	Additional Sense Code (ASC) - Additional Sense Code Qualifier (ASCQ) (Continued)							
	Byte 12 Byte 13							
	ASC ASCQ							
27	00	- Write Protect - A Write type operation has been requested on a cartridge which has been write protected						
28	00	- Not Ready to Ready Transition - A cartridge has been loaded successfully into the drive and is now ready to be accessed						
28	01	- Import or export element accessed						
29	00	- Reset - The drive has powered on, received a reset signal or a bus device reset signal since the initiator last accessed it						
29	04	- Device internal reset						
2A	01	- Mode Parameters Changed - The Mode parameters for the drive have been changed by an initiator other than the one issuing the command						
2C	00	- Command sequence error						
2C	0B	- Not reserved - The OIR bit of the sequential access device page is set and the I-T nexus attempting to communicate with the drive does not hold a reservation.						
2F	00	- Commands cleared by another initiator						
30	00	- Incompatible Media Installed - A write type operation could not be executed because it is not supported on the cartridge type that is loaded.						
30	01	- Unknown Format - An operation could not be carried out because the cartridge in the drive is of a format not supported by the drive						
30	02	- Incompatible Format - An operation could not be completed because the Logical Format is not correct						
30	03	- Cleaning Cartridge Installed - An operation could not be carried out because the cartridge in the drive is a cleaning cartridge						
30	05	- Cannot write medium, incompatible format						
30	07	- Cleaning Failure - A cleaning operation was attempted, but could not be completed for some reason						
30	0C	- Data Protect - WORM overwrite attempted. The drive rejected a write operation because it would have resulted in an overwrite. Overwrite is not allowed on WORM media.						
30	0D	- Medium Error - WORM integrity check. The drive rejected a Read or Write operation because the cartridge is a suspicious WORM cartridge.						
31	00	- Media format corrupted - Data could not be read because the format on tape is not valid, but is a known format. A failure occurred attempting to write the FID						
37	00	- Rounded parameter - A Mode Select command parameter has been rounded because the drive can not store it with the accuracy of the command.						
3A	00	- Media Not Present - A media access command has been received when there is no cartridge loaded						
3B	00	- Sequential Positioning Error - A command has failed and left the logical position at an unexpected location						
3B	0C	- Position past beginning of medium						
3D	00	- Invalid bits in identify Message - An illegal Identify Message has been received at the drive at the start of a command						
3E	00	- Logical Unit has not Self-Configured - The drive has just powered on and has not completed its self test sequence and can not process commands						
3F	01	- Code Download - The firmware in the drive has just been changed by a Write Buffer command						
3F	03	- Inquiry data has changed						
3F	0E	- Reported LUNs data has changed						
3F	0F	- Echo buffer overwritten						
40	xx	- Diagnostic failure - A diagnostic test has failed. The xx (ASCQ) is a vendor specific code indicating the failing component.						

Table 51. LTO Tape Drive Sense Data (continued)

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
12-13	Additional Sense Code (ASC) - Additional Sense Code Qualifier (ASCQ) (Continued)							
	Byte 12 Byte 13							
	ASC ASCQ							
41	00	- Data path failure						
43	00	- Message Error - A message could not be sent or received due to excessive transmission errors						
44	00	- Internal target failure - A hardware failure has been detected in the drive that has caused the command to fail						
45	00	- Select/Reset Failure - An attempt to reselect an initiator in order to complete the command has failed						
48	00	- Initiator detected error message received						
49	00	- Invalid message error						
4A	00	- Command phase error						
4B	00	- Data Phase Error - A command could not be completed because too many parity errors occurred during the Data phase						
4E	00	- Overlapped Commands - An initiator selected the drive even though it already had a command outstanding in the drive						
50	00	- Write Append Error - A write type command failed because the point at which to append data was unreadable						
51	00	- Erase failure - An Erase command failed to erase the required area on the media						
52	00	- Cartridge fault - A command could not be completed due to a fault in the tape cartridge						
53	00	- Media Load/Eject Failed - (Sense Key 03) An attempt to load or eject the cartridge failed due to a problem with the cartridge.						
53	00	- Media Load/Eject Failed - (Sense Key 04) An attempt to load or eject the cartridge failed due to a problem with the drive						
53	02	- Media Removal Prevented - An Unload command has failed to eject the cartridge because media removal has been prevented						
5A	01	- Operator medium removal request						
5D	00	- Failure Prediction Threshold - Failure Prediction thresholds have been exceeded indicating that a failure may occur soon						
5D	FF	- Failure Prediction False - A Mode Select command has been used to test for Failure Prediction system.						
82	82	- Drive requires cleaning - The drive has detected that a cleaning operation is required to maintain good operation						
82	83	- Bad Code Detected - The data transferred to the drive during a firmware upgrade is corrupt or incompatible with drive hardware						

Table 51. LTO Tape Drive Sense Data (continued)

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
12-13	Additional Sense Code (ASC) - Additional Sense Code Qualifier (ASCQ) (Continued) Byte 12 Byte 13 ASC ASCQ Sense Key 0 (No Sense) EE 13 - Encryption - Key Translate EF 13 - Encryption - Key Translate EKM Sense Key 3 (Medium Error) 30 02 - Encryption - Encryption feature is not enabled so format/processing is not supported EE 60 - Encryption - Proxy Command Error EE D0 - Encryption - Data Read Decryption Failure EE D1 - Encryption - Data Read after Write Decryption Failure EE E0 - Encryption - Key Translation Failure EE E1 - Encryption - Key Translation Ambiguous EE F0 - Encryption - Decryption Fenced (Read) EE F1 - Encryption - Encryption Fenced (Write) Sense Key 4 (Hardware Error) EE 0E - Encryption - Key Service Timeout EE 0F - Encryption - Key Service Failure 40 00 - Encryption - Failure Hardware, POST or Module Failure Sense Key 5 (Illegal Request) EE 00 - Encryption - Key Service Not Enabled EE 01 - Encryption - Key Service Not Configured EE 02 - Encryption - Key Service Not Available EE 10 - Encryption - Key Required EE 20 - Encryption - Key Count Exceeded EE 21 - Encryption - Key Alias Exceeded EE 22 - Encryption - Key Reserved EE 23 - Encryption - Key Conflict EE 24 - Encryption - Key Method Change EE 25 - Encryption - Key Format Not Supported EE 26 - Encryption - Unauthorized Request - dAK EE 27 - Encryption - Unauthorized Request - dSK EE 28 - Encryption - Unauthorized Request - eAK EE 29 - Encryption - Authentication Failure EE 2A - Encryption - Invalid RDKi EE 2B - Encryption - Key Incorrect EE 2C - Encryption - Key Wrapping Failure EE 2D - Encryption - Sequencing Failure EE 2E - Encryption - Unsupported Type EE 2F - Encryption - New Key Encrypted Write Pending EE 30 - Encryption - Prohibited Request EE 31 - Encryption - Key Unknown EE 32 - Encryption - Keystore Related Problem EE 42 - Encryption - EKM Challenge Pending EE E2 - Encryption - Key Translation Disallowed EE FF - Encryption - Security Prohibited Function EF 01 - Encryption - Key Service Not Configured 26 11 - Encryption - Incomplete Key - Associate Data Set 26 12 - Encryption (T10) - Vendor Specific Reference Key Not Found 55 08 - Encryption (T10) - Maximum Number of Supplemental Keys Exceeded							

Table 51. LTO Tape Drive Sense Data (continued)

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
12-13	Sense Key 6 (Unit Attention) EE 12 - Encryption - Key Change Detected EE 18 - Encryption - Changed (Read) EE 19 - Encryption - Changed (Write) EE 40 - Encryption - EKM Identifier Changed EE 41 - Encryption - EKM Challenge Changed EE 50 - Encryption - Initiator Identifier Changed EE 51 - Encryption - Initiator Response Changed 2A 11 - Encryption - Data Encryption Parameters Changed by Another I_T Nexus 2A 12 - Encryption - Data Encryption Parameters Changed by Vendor Specific Event Sense Key 7 (Data Protect) EF 10 - Encryption - Key Required EF 11 - Encryption - Key Generation EF 13 - Encryption - Key Translate EF 1A - Encryption - Key Optional EF C0 - Encryption - No Operation 26 10 - Encryption - Data Decryption Key Fail Limit 2A 13 - Encryption - Data Encryption Key Instance Counter Has Changed 74 00 - Security Error 74 01 - Encryption - Unable to Decrypt Data 74 02 - Encryption - Unencrypted Data Encountered While Decrypting 74 03 - Encryption - Incorrect Data Encryption Key 74 04 - Encryption - Cryptographic Integrity Validation Failed 74 05 - Encryption - Error Decrypting Data							
14	FRU code							
15	SKSV	C/D	Reserved		BPV	Bit pointer		
					When set to 1, the bit pointer is valid.			
16 -17	SKSV = 0: First Error Fault Symptom Code (FSC). SKSV = 1: Field Pointer							
18-19	First Error Flag Data							
20	Reserved (0)							
21					CLN	Reserved	Reserved	VolValid
22-28	Volume Label							
29	Current Wrap							
30-33	Relative LPOS							
34	SCSI Address							
35	Frame number				Drive number			

Table 51. LTO Tape Drive Sense Data (continued)

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
36-39	<p>Port Identifier (Relative Target Port Address) Reporting Sense (This is the port address of the drive port through which sense is being reported.)</p> <p>On Fibre Channel drives, it is the Fibre Channel Fabric Port Address [for example, 011E13 or 000026] with byte 36 being reserved.</p> <p>On SAS drives, it is the Hashed SAS Address of the drive port [for example, F32A94] with byte 36 being reserved.</p> <p>On SCSI, bytes 36 through 38 are reserved, and byte 39 is set to the port's SCSI address [i.e., byte 39 = byte 34].)</p>							
40	Tape Directory Valid	Reserved	Reserved	Reserved	Reserved	Relative Tgt Port Reporting Sense 0: Reserved 1: Relative Tgt Port 1 (Port 0) 2: Relative Tgt Port 2 (Port 1) 3: Relative Tgt Port 3 (Library Port)		
41	Host Command (SCSI Opcode)							
42	Density Type 0: No media present 1: Gen1 (384 track) 2: Gen2 (512 track) 3: Gen3 (704 track)				Media Type (Vendor Reserved)			
43	Volume Label Cartridge Type							
44								
45-48	Logical Block Number (Current LBA that would be reported in Read Position command)							
49-52	Data set Number							
53	1st Error FSC							
54								
55	1st Error Flag Data							
56								
57	2nd Error FSC							
58								
59	2nd Error Flag Data							
60								
61	Next-to-Last Error FSC							
62								
63	Next-to-Last Error Flag Data							
64								

Table 51. LTO Tape Drive Sense Data (continued)

Byte	Bit Address or Name							
	7	6	5	4	3	2	1	0
65	Last Error FSC							
66								
67	Last Error Flag Data							
68								
69	LPOS Region							
70-85	ERP Summary Information							
86-89	Product Revision Level: YMDV (as defined in Standard Inquiry; this is also known as the Code Level)							
90-95	Reserved (0)							

The descriptions below serve only as an overview of sense reporting in the tape drive. This tape drive conforms to all sense field reporting as specified in the SCSI standards.

Note:

1. The Error Code field (Byte 0) is set to 70h to indicate a current error, that is one associated with the most recently received command. It is set to 71h to indicate a deferred error which is not associated with the current command.
2. The segment number (Byte 1) is zero since the Copy, Compare, and Copy and Verify commands are not supported.
3. The File Mark flag (Byte 2, bit 7) is set if a Space, Read, or Verify command did not complete because a file mark was read.
4. The End of Media (EOM) flag (Byte 2, bit 6) is set if a Write or Write File Marks command completed in the early warning area. Spacing into BOM also causes this flag to be set. It is also set on an attempt to read or space past EOD, or if an attempt is made to space into Beginning of Media.
5. The Illegal Length Indicator (ILI) flag (Byte 2, bit 5) is set if a Read or Verify ended because a block was read from tape that did not have the block length requested in the command.
6. The Information Bytes (Bytes 3-5) are only valid if the Valid flag is set. This occurs only for current errors and not for deferred errors.
7. The Field Replaceable Unit field (Byte 14) is set to either zero or to a non-zero, vendor-specific code indicating which part of the drive is suspected of causing the failure.
8. The Clean (CLN) flag (Byte 21, bit 3) is set if the drive needs cleaning and clear otherwise.
9. The Volume Label Fields Valid (VolValid) bit (Byte 21, bit 0) is set if the Volume Label being reported is valid.
10. The Volume Label field (Bytes 22-28) reports the volume label if a cartridge is loaded in the drive and Volume Label Fields Valid is set.
11. The Current Wrap field (Byte 29) reports the physical wrap of the tape. The least significant bit reflects the current physical direction. A 0 means that the current direction is away from the physical beginning of the tape. A 1 means that the current direction is towards the physical beginning of the tape.
12. Relative LPOS fields (Bytes 30-33) reports the current physical position on the tape.
13. SCSI Address field (Byte 34) reports the SCSI Bus Address for the drive. Values returned range from 00h to 0Fh.
14. This field (Byte 35) contains the frame and drive number, passed across the RS-422 serial interface.

Appendix D. Enabling LUN Support in Linux

To verify the detection of a tape drive, administrators should check for its entry in `/proc/scsi/scsi`. Current versions of Linux may not scan the logical storage unit (LUN) ID of every device. This can result in some TL2000/TL4000 devices not being identified or listed in the `/proc/scsi/scsi` output. Administrators can follow these steps to enable support for such devices.

1. Type `cat /proc/scsi/scsi`. The output will look similar to the following:

```
Attached devices:
Host: scsi0 Channel: 00 Id: 01 Lun: 00
  Vendor:   IBM Model: ULT3580-HH3   Rev: 88M3
  Type:     Sequential-Access ANSI SCSI revision: 03
```

2. Identify the host adapter, channel number, target ID number, and LUN number for the first LUN of the device to be configured. In this example, the IBM Model ULT3580 (a drive in the TL2000/TL4000) is shown at the address, or nexus, 0 0 0 0 — which means host adapter 0, channel number 0, ID 1, and LUN 0. The TL2000/TL4000 always has the tape drive at LUN 0 and the robot at LUN 1.
3. For each LUN that needs to be discovered by Linux, issue the following command: `echo "scsi-add-single-device H C I L">/proc/scsi/scsi` H C I L refers to the nexus described in step 2. So, with the TL2000/TL4000 robot configured at LUN 1, type: `echo "scsi-add-single-device 0 0 1 0">/proc/scsi/scsi`. The echo command will force a scan of each device at the given nexus.
4. Type `cat /proc/scsi/scsi` again to verify that all devices are now listed. The output will look similar to the following:

```
Attached devices:
Host: scsi0 Channel: 00 Id: 01 Lun: 00
  Vendor:   IBM Model: ULT3580-HH3   Rev: 88M3
  Type:     Sequential-Access ANSI SCSI revision: 03

Attached devices:
Host: scsi0 Channel: 00 Id: 02 Lun: 01
  Vendor:   IBM Model: 3573-TL   Rev: 7.10
  Type:     Medium Changer ANSI SCSI revision: 05
```

Administrators should add the echo command to the Linux boot scripts because the device information is not persistent and must be created each time the system boots up. One example file that can be used for storing the commands is `/etc/rc.local`. Note that configuring additional devices on a server or a storage area network (SAN) can cause the devices to be reordered, which requires administrators to modify the commands. If the Fibre Channel adapter supports Persistent Bindings or an equivalent function, it can be enabled to reduce the chance of devices being reordered upon discovery.

Note: This procedure must be run each time the server is booted. Also, if backup application services are running (for example, they automatically start when the OS loads), they must be disabled and re-enabled after the above procedure.

The other way to enable LUN support is to recompile the kernel and enable LUN scanning in the Adaptec driver, but it requires advanced knowledge of Linux and will not be covered here. However, it will allow the server to always boot and see the device without any manual procedures.

Red Hat Enterprise Linux

RHEL doesn't automatically probe all LUNs on SCSI devices. The symptom shows LUN 0, which would be the drive, but not the loader.

1. Type `#cat /proc/scsi/scsi`.

Attached devices:

```
Host: scsi0 Channel: 00 Id: 06 Lun: 00
  Vendor: IBM Model: ULT3580-HH3 Rev: 88M3
  Type: Sequential-Access ANSI SCSI revision: 03
```

2. You will need to add the following to `/etc/modules.conf`
`options scsi_mod max_scsi_luns=255`

Note: In RHEL 4, it is `max_luns=255`

3. Once that's added, you will have to rebuild the `initrd` and reboot the server. There is a way to test this before editing the files and rebooting, but there's too much of a risk of taking down other SCSI devices in the process. Rebuilding the `initrd` will be the tricky part. You have to know exactly which kernel version you want to use to do this properly. You can find out the kernel version by using the `uname` command.

```
#uname -r
2.4.9-e.38
```

Note: There is a list of known kernel versions on the Red Hat Enterprise Linux page.

4. So, given the version is 2.4.9-e.38

```
# cp /boot/initrd-2.4.9-e.38.img /boot/initrd-2.4.9-e.38.img.bak
# mkinitrd -f -v /boot/initrd-2.4.9-e.38.img 2.4.9-e.38
```

This should give some output, then go to a new prompt. If it gives any errors, check the syntax you put into `/etc/modules.conf` or contact someone knowledgeable with Linux.

5. If successful, the server WILL need to be rebooted. Once it comes back up, check `/proc/scsi/scsi` again.

```
#cat /proc/scsi/scsi
```

Attached devices:

```
Host: scsi0 Channel: 00 Id: 06 Lun: 00
  Vendor: IBM Model: ULT3580-HH3 Rev: 88M3
  Type: Sequential-Access ANSI SCSI revision: 03
Host: scsi0 Channel: 00 Id: 06 Lun: 01
  Vendor: IBM Model: 3573-TL Rev: 7.10
  Type: Medium Changer ANSI SCSI revision: 05
```

Enabling LUN Support in Netware

1. From the System Console, verify the LUN device is not being detected by using the `list storage adapters` command. Typical output where only the tape drive is being recognized:

```
0x08 [V321-A3] Adaptec SCSI Card 39160/3960D - Ultra160 SCSI [slot 201]
  0x15 [V321-A3-D5:0] IBM ULT3580-TD3 5BG2
0x09 [V321-A4] Adaptec SCSI Card 39160/3960D - Ultra160 SCSI [slot 202]
```

2. From the System Console, type `nwconfig`.
3. Select **NCF files Options** from the Configuration Options screen.
4. Select **Edit STARTUP.NCF** from the Available NCF Files Options screen.
5. Add the `/LUNS` switch to the load line of the appropriate SCSI driver. If a dual channel card is installed and you are unsure which channel the LUN device is attached to, simply edit both lines.

```
LOAD ADPT160M.HAM SLOT=201 /LUNS
LOAD ADPT160M.HAM SLOT=202 /LUNS
```

6. After the `STARTUP.NCF` file has been edited, save the file and reboot the server to activate the new `STARTUP.NCF`.
7. Upon reboot navigate to the System Console and type `scan all`. This will start a scan of all the LUNS on each adapter.
8. When the scan is complete, verify the LUN device has been detected using the `list storage adapters` command. Typical output with both the tape drive and loader being recognized:

```
0x08 [V321-A3] Adaptec SCSI Card 39160/3960D - Ultra160 SCSI [slot 201]
  0x16 [V321-A3-D5:1] DELL PV-124T 0031
  0x15 [V321-A3-D5:0] IBM ULT3580-TD3 5BG2
0x09 [V321-A4] Adaptec SCSI Card 39160/3960D - Ultra160 SCSI [slot 202]
```

Netware may display **unbound device**, meaning a driver is not bound to the loader unless a driver from a backup software is loaded. This does not prevent the backup application from detecting the LUN and binding the appropriate driver.

Note: The command **scan all** must be typed upon OS boot every time. If backup software services automatically start on OS boot, you must disable them, run the scan all command, and re-enable the services.

Appendix E. Notes on IPv6 Compatibility with Windows 2003/XP and 2008/Vista

IPv6 addressing is different from traditional IPv4 addressing. IPv4 addressing is listed in the format 255.255.255.255, with each value 1 byte, a total address of 4 bytes. IPv6 addresses require 16 bytes, and are listed in the format FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF, where there are 8 segments each 2 bytes long.

Windows 2003/XP

IPv6 support in Windows 2003 is not turned on by default. Use the following instructions to enable IPv6 support.

1. Go to **Control Panel > Network Connections**, and right-click on the Local Area Connection interface that is to be enabled with IPv6 support.
2. Select **Properties** from the drop-down menu, and the **Local Area Connection Properties** window should open. Click on the **Install** button.
3. In the new **Select Network Component Type** window, select **Protocol** and click on the **Add** button.
4. In the **Select Network Protocol** window, select **Microsoft TCP/IP version 6** and click on the **OK** button. IPv6 is now enabled.

Windows 2003 and XP comes with a WinINet API that does not fully support IPv6 literals. Upgrading to Internet Explorer 7 in Windows 2003 is recommended for IPv6 browser support as the WinINet API is updated with the installation of Internet Explorer 7. Third party browsers (such as Firefox) also use the WinINet API either directly or indirectly, so an upgrade to IE7 will be recommended for all users.

As multiple IPv6 addresses can be associated with one physical interface, Windows 2003 and XP use an interface number associated with each link-local IPv6 address that must be included for connectivity to any link-local IPv6 address. The interface number then must be appended to any outgoing IPv6 traffic; otherwise, the IPv6 packet does not know which logical interface to egress from.

The interface number can be determined through the command line of Windows.

1. Go to **Start > Run** and type **cmd** to enter the command prompt.
2. At the command prompt, type **ipconfig** and find the link-local IPv6 address. Appended to the end of this will be a %x where x is the interface number.

Browser connectivity to a global unicast IPv6 address

- Global unicast IPv6 addresses can be browsed to by entering this syntax into the browser address line:
HYPERLINK "http://[%3cIPv6_Global_Unicast_Address%3e]"/"http://<[IPv6_Global_Unicast_Address]/"
- The IPv6 address must be enclosed in square brackets ("[]").

Browser connectivity to a link-local IPv6 address

- The IPv6 address cannot be entered into a browser window in the same way an IPv4 address is when connecting via a link-local IPv6 address.
- After upgrading the WinINet API (by upgrading to IE 7), the library RMU can be accessed from the browser by using the following format.
 - Replace all : with -.
 - Append **s<interface#>.ipv6-literal.net** to the end of the IPv6 address.

- For example, if the IPv6 address is **fe80::1234:5678:abc** and the interface number is **13**, the address to browse to would be **http://fe80--1234-5678-abcs13.ipv6-literal.net**.
- Using the same IPv6 address as above, another alternative to this would be to edit the hosts file in the **<Windows Base Directory\system32\drivers\etc** directory and add the following line:
fe80::1234:5678:abc%13<hostname> .
 - The address to browse to would be HYPERLINK "**http://%3choostname%3e"**http://<hostname>
 - Note that the interface number can change with a reboot of the Windows host.

Windows 2008/Vista

Windows 2008 and Vista natively support IPv6. Also, interface numbers have been removed from these versions of Windows. All that is needed to browse to an address would be to add brackets ([]) around the IPv6 address. Thus, if the TL2000/4000 IPv6 address is **fe80::1234:5678:abc**, enter **http://[fe80::1234:5678:abc]** into the browser window. This is applicable for both link-local and global unicast IPv6 addresses.

Notes on IPv6 Compatibility with Linux

1. While IPv6 is supported under Linux, IPv6 literals for link-local addresses are not currently supported in Linux browsers, so the RMU will not be accessible in Linux via a link-local IPv6 address. Global unicast IPv6 addresses are supported in the same manner as in Windows 2008/Vista browsers.
2. The RMU is accessible through IPv4.

Appendix F. SNMP Status MIB Variables and Traps

Note: For additional information, refer to “SNMP Messaging” on page 7.

Table 52. SNMP Status Events

Event	Trap ID	Definition
Cold Start	0	Library has rebooted.
Status Change	1	Library status has changed.
Door Open	2	Library door has been opened.
Mail Slot Accessed	3	Library I/O Station has been accessed.
Fault Posted	4	Library has posted a hard fault/error.
Request Drive Clean	5	Drive has requested a clean.
Drive Error	6	Drive has reported an error.
Loader Retries Excessive	7	Library has reported excessive load retries.
Loader OK	8	Library has resumed normal operations.
Account Password Change	9	Account password in the library has changed.
Note: Trap ID 9 requires library firmware level 8.0 or greater, and the latest SNMP MIB file.		
Configuration Change	10	Library or drive configuration has changed.
Library Login	11	Someone has logged into the library via the Web User Interface.
Library Logout	12	Someone has logged out of the library via the Web User Interface.
Note: Trap IDs 10, 11, and 12 require library firmware level 9.00 or greater and the latest SNMP MIB file.		

Appendix G. Library Configuration Form

Use this form when planning your library configuration. Keep this document in a secure location and update it when changes are made to the library configuration.

General Information				
Library type	TL2000		TL4000	
Library Serial Number				
Library name				
I/O Station	Enabled		Disabled	
AutoClean	Enabled		Disabled	
Library Network Settings				
DHCP	Enabled		Disabled	
IP Address				
Netmask Address				
Gateway Address				
DNS Servers IP Addresses				
EKM Servers IP Addresses				
Encryption Settings				
Logical Libraries				
Number in library	1	2	3	4
Mode	Random: ON/OFF Sequential: ON/OFF Autoload: ON/OFF Loop: ON/OFF	Random: ON/OFF Sequential: ON/OFF Autoload: ON/OFF Loop: ON/OFF	Random: ON/OFF Sequential: ON/OFF Autoload: ON/OFF Loop: ON/OFF	Random: ON/OFF Sequential: ON/OFF Autoload: ON/OFF Loop: ON/OFF
Magazine Assignment	<input type="checkbox"/> Upper Left <input type="checkbox"/> Lower Left <input type="checkbox"/> Upper Right <input type="checkbox"/> Lower Right	<input type="checkbox"/> Upper Left <input type="checkbox"/> Lower Left <input type="checkbox"/> Upper Right <input type="checkbox"/> Lower Right	<input type="checkbox"/> Upper Left <input type="checkbox"/> Lower Left <input type="checkbox"/> Upper Right <input type="checkbox"/> Lower Right	<input type="checkbox"/> Upper Left <input type="checkbox"/> Lower Left <input type="checkbox"/> Upper Right <input type="checkbox"/> Lower Right
Number of Active Slots				
Drive Serial Numbers	4U Position 4: 4U Position 3: 2U/4U Position 2: 2U/4U Position 1:	4U Position 4: 4U Position 3: 2U/4U Position 2: 2U/4U Position 1:	4U Position 4: 4U Position 3: 2U/4U Position 2: 2U/4U Position 1:	4U Position 4: 4U Position 3: 2U/4U Position 2: 2U/4U Position 1:

Drive types	4U Position 4: 4U Position 3: 2U/4U Position 2: 2U/4U Position 1:	4U Position 4: 4U Position 3: 2U/4U Position 2: 2U/4U Position 1:	4U Position 4: 4U Position 4: 4U Position 3: 2U/4U Position 2: 2U/4U Position 1:4U Position 3: 2U/4U Position 2: 2U/4U Position 1:	4U Position 4:4U Position 3:2U/4U Position 2:2U/4U Position 1:
Fibre Channel Drive settings	Logical Library: Position: Speed: Port type: Loop ID:	Logical Library: Position: Speed: Port type: Loop ID:	Logical Library: Position: Speed: Port type: Loop ID:	Logical Library: Position: Speed: Port type: Loop ID:
SAS Drive settings	Logical Library: Position: ID:	Logical Library: Position: ID:	Logical Library: Position: ID:	Logical Library: Position: ID:
SCSI Drive settings	Logical Library: Position: ID:	Logical Library: Position: ID:	Logical Library: Position: ID:	Logical Library: Position: ID:
User Accounts				
Role: Password:				
Role: Password:				
Role: Password:				
Role: Password:				

Appendix H. Accessibility

Accessibility features help a user who has a physical disability, such as restricted mobility or limited vision, to use the HTML version of the customer documentation successfully.

Features

The major accessibility features for the HTML version of this document are:

- You can use screen-reader software and a digital speech synthesizer to hear what is displayed on the screen. The following screen readers are tested: WebKing and Window-Eyes.
- You can operate all features with the keyboard instead of the mouse.

Navigating by keyboard

You can use keys or key combinations to complete operations and initiate many menu actions that are also done through mouse actions. You can navigate the HTML version of the *Dell PowerVault TL2000 Tape Library and TL4000 Tape Library User's Guide* help system from the keyboard with the following key combinations:

- To traverse to the next link, button, or topic, press Tab inside a frame (page).
- To move to the previous topic, press ^ or Shift+Tab.
- To scroll all the way up or down, press Home or End.
- To print the current page or active frame, press Ctrl+P.
- To select, press Enter.

Accessing the publications

You can view the publications for this library in Adobe Portable Document Format (PDF) with the Adobe Acrobat Reader. The PDFs are provided at the following website:

www.Dell.com/support.

Glossary

This glossary defines the special terms, abbreviations, and acronyms that are used in this publication. If you do not find the term that you are looking for, refer to the index or to the *Dictionary of Computing*, 1994.

Numbers

2:1 compression

The relationship between the quantity of data that can be stored with compression as compared to the quantity of data that can be stored without compression. In 2:1 compression, twice as much data can be stored with compression as can be stored without compression.

A

A Ampere.

ac Alternating current.

access method

A technique for moving data between main storage and input or output devices.

accessor

This component contains the library robot and bar code reader. The accessor moves cartridges to and from the I/O Station, storage slots, and tape drives.

adapter card

A circuit board that adds function to a computer.

adj Adjustment.

AH Authentication Header. An Internet Protocol intended to guarantee connectionless integrity and data origin authentication of IP datagrams. Further, it can optionally protect against replay attacks by using the sliding window technique and discarding old packets.

alphanumeric

Pertaining to a character set that contains letters, numerals, and other characters, such as punctuation marks.

alter To change.

ambient temperature

The temperature of air or other media in a designated area, particularly the area that is surrounding equipment.

AME Application Managed Encryption.

ampere (A)

A unit of measure for electric current that is equivalent to a flow of 1 coulomb per second, or to the current produced by 1 volt applied across a resistance of 1 ohm.

ANSI American National Standards Institute.

application-managed encryption

Tape encryption that is controlled by an application.

archive

To collect and store files in a designated place.

ASCII American National Standard Code for Information Interchange. A 7 bit coded character set (8 bits including parity check) that consists of control characters and graphic characters.

assigning a device

The establishing of the relationship of a device to a running task, process, job, or program.

assignment

The naming of a specific device to perform a function.

asynchronous

Pertaining to two or more processes that do not depend upon the occurrence of specific events such as common timing signals.

attention (notice)

A word for calling attention to the possibility of danger to a program, device, or system, or to data. Contrast with *caution* and *danger*.

ATTN Attention.

B**backup**

To make extra copies of documents or software for safekeeping.

bar code

A code that represents characters by sets of parallel bars of varying thickness and separation, which are read optically by transverse scanning.

bar code label

Paper bearing a bar code and having an adhesive backing. The bar code label must be affixed to a tape cartridge to enable the library to identify the cartridge and its volume serial number.

bar code reader

A laser device that is specialized for scanning and reading bar codes and converting them into either the ASCII or EBCDIC digital character code.

bezel Decorative and safety cover.

bicolored

Having two colors.

bit Either of the digits 0 or 1 when used in the binary numbering system.

BOM or bill of materials

A list of specific types and amounts of direct materials that are expected to be used to produce a specific job or quantity of output.

Border Gateway Protocol (BGP)

BGP is the core routing protocol of the Internet. It works by maintaining a table of IP networks or 'prefixes' that designate network reachability among autonomous systems (AS).

BRMS Backup Recovery and Media Services.

browser

A client program that initiates requests to a web server and displays the information that the server returns.

buffer

A routine or storage that is used to compensate for a difference in rate of flow of data or time of occurrence of events, when data is transferred from one device to another.

bus A facility for transferring data between several devices that are located between two end points, only one device able to transmit at a specified moment.

byte A string that consists of some bits (usually 8) that are treated as a unit and represent a character. A fundamental data unit.

C

CA certification

In cryptography, a certificate from a certificate authority (CA).

capacity

The amount of data that can be contained on storage media and expressed in bytes of data.

cartridge manual rewind tool

A device that can be fitted into the reel of a cartridge and used to rewind tape into or out of the cartridge.

cartridge memory (CM)

Within each data cartridge, an embedded electronics and interface module that can store and retrieve a cartridge's historical usage and other information.

cartridge storage slot

Individual slot that is located within a magazine that is used to house tape cartridges.

caution (notice)

A word to call attention to possible personal harm to people. Contrast with *attention* and *danger*.

centimeter (cm)

One one-hundredth of a meter (0.01 m). Approximately 0.39 inch.

channel command

An instruction that directs a data channel, control unit, or device to perform an operation or set of operations.

char Character.

CHK Check.

cleaning cartridge

A tape cartridge that is used to clean the heads of a tape drive. Contrast with *data cartridge*.

COD Capacity On Demand.

command

A control signal that initiates an action or the start of a sequence of actions.

compact disc (CD)

A disc, usually 4.75 inches in diameter, from which data is read optically by using a laser.

compression

The process of eliminating gaps, empty fields, redundancies, and unnecessary data to shorten the length of records or blocks.

concurrent

Refers to diagnostic procedures that can be run on one control unit while the rest of the subsystem remains available for customer applications.

contingent connection

A connection between a channel path and a drive that is caused when a unit check occurs during an I/O operation.

controller

A device that provides the interface between a system and one or more tape drives.

control path drive

controller A device that provides the interface between a system and one or more tape drives. *control path drive* A drive that communicates messages from the host computer to the library in which the drive is installed.

cookie A packet of data that is exchanged between the library and a web browser to track configuration.

CP Circuit protector.
CPF Control Path Failover.
CRU Customer Replaceable Unit.
CSA Canadian Standards Association.
ctrl Control.
CU Control unit.

D

danger (notice)

A word to call attention to possible lethal harm to people. Contrast with *attention* and *caution*.

data Any representations such as characters or analog quantities to which meaning is or might be assigned.

data buffer

The storage buffer in the control unit. This buffer is used to increase the data transfer rate between the control unit and the channel.

data cartridge

A tape cartridge that is dedicated to storing data. Contrast with *cleaning cartridge*.

data check

A synchronous or asynchronous indication of a condition that is caused by invalid data or incorrect positioning of data.

dc Direct current.

DCS Designated Cleaning Slot.

degauss

To make a magnetic tape nonmagnetic by using electrical coils that carry currents that neutralize the magnetism of the tape.

degausser

A device that makes magnetic tape nonmagnetic.

degradation

A decrease in quality of output or throughput or an increase in machine error rate.

degraded

Decreased in quality of output or throughput or increased machine error rate.

deserialize

To change from serial-by-bit to parallel-by-byte.

detented

A part that is held in position with a catch or lever.

device Any hardware component or peripheral device, such as a tape drive or tape library, that can receive and send data.

device driver

A file that contains the code that is needed to use an attached device.

DHCPv6

The Dynamic Host Configuration Protocol for IPv6. Although IPv6's stateless address autoconfiguration removes the primary motivation for DHCP in IPv4, DHCPv6 can still be used to statefully assign addresses if the network administrator wants more control over addressing.

DH group

Diffie-Hellman group.

DIAG

Diagnostic section of maintenance information manual.

differential

See *High Voltage Differential (HVD)*.

direct access storage

A storage device in which the access time is independent of the location of the data.

display contrast

The brightness of the display on the Operator Panel.

DLL Dynamic Link Library. The Microsoft implementation of the shared library concept. These libraries usually have the file extension `dll`, `ocs` (for libraries that contain activeX controls, or `drv` (for legacy system drivers).

DNS Directory Name System. This allows the library to recognize text-based addresses instead of numeric IP addresses.

download

To transfer programs or data from a computer to a connected device, typically a personal computer.

To transfer data from a computer to a connected device, such as a workstation or personal computer.

DPF Data Path Failover.

DRAM

Dynamic random-access memory.

drive, magnetic tape

A mechanism for moving magnetic tape and controlling its movement.

Drive Not Configured

This message occurs during the first boot after a factory settings restore is run. This message is not a real issue since it takes time for the library to configure.

DRV Drive.

DSA key

Encryption key type.

DSE Data security erase.

DSP Digital signal processor.

E**EBCDIC**

Extended binary-coded decimal interchange code.

EC Edge connector. Engineering change.

ECC Error correction code.

EEB Ethernet Expansion Blade

EEPROM

Electrically erasable programmable read-only memory.

EIA Electronics Industries Association.

EIA unit

A unit of measure, which is established by the Electronic Industries Association, equal to 44.45 millimeters (1.75 inches).

eject To remove or force out from within.

EKM Encryption Key Manager.

electronic mail

Correspondence in the form of messages that are transmitted between user terminals over a computer network.

email See *electronic mail*.

encryption

A method of storing data in a format that helps protect data from inadvertent or deliberate compromise. An encryption-enabled drive contains the necessary hardware and firmware to encrypt and decrypt host tape application data. Encryption policy and encryption keys are provided by the host application or host server.

encryption key manager (EKM)

A software program that assists encrypting tape drives in generating, protecting, storing, and maintaining encryption keys that encrypt information that is written to and decrypt information that is read from tape media.

entitlement

Entitlement is the official right to receive service and support for your tape library.

EPO Emergency power off.

EPROM

Erasable programmable read only memory.

EQC Equipment check.

equipment check

An asynchronous indication of a malfunction.

Error log

A data set or file in a product or system where error information is stored for later access.

ESD Electrostatic discharge.

ESP Encapsulating Security Payload. An Internet Protocol that provides origin authenticity, integrity, and confidentiality protection of a packet. ESP also supports encryption-only and authentication-only configurations, but encryption without authentication is discouraged because it is insecure.

F

fault symptom code (FSC)

A hexadecimal code that is generated by the drive or the control unit microcode in response to a detected subsystem error.

FC Feature code.

FCC Federal communications commission.

FH Full height.

fiducial

A target that is used for teaching a physical location to a robot.

field replaceable unit (FRU)

An assembly that is replaced in its entirety when any one of its components fails.

file A named set of records that are stored or processed as a unit. Also referred to as a data set.

file protection

The processes and procedures that are established in an information system that are designed to inhibit unauthorized access to, contamination of, or deletion of a file.

file transfer protocol (FTP)

In the Internet suite of protocols, an application layer protocol that uses TCP and Telnet services to transfer bulk-data files between machines or hosts.

firmware

Proprietary code that is delivered as microcode as part of an operating system. Firmware is more efficient than software loaded from an alterable medium and more adaptable to change than pure hardware circuitry. An example of firmware is the Basic input/output system (BIOS) in read-only memory (ROM) on a PC system board.

FLASH EEPROM

An electrically erasable programmable read-only memory (EEPROM) that can be updated.

FMR Field microcode replacement.

format

The arrangement or layout of data on a data medium.

formatter

Part of a magnetic tape subsystem that performs data conversion, speed matching, encoding, first level error recovery, and interfaces to one or more tape drives.

FP File protect.

frayed Damaged as if by an abrasive substance.

FRU Field replaceable unit.

FSC Fault symptom code.

FSI Fault symptom index.

FTSS Field Technical Sales Support.

functional microcode

Microcode that is resident in the machine during normal customer operation.

G

g Gram.

GB gigabyte.

GBIC Gigabit Interface Converter.

Gbs gigabits/second

Gbi gigabit

gigabit (Gbit)

1 000 000 000 bits.

gigabyte (GB)

1 000 000 000 bytes.

Gigabit Interface Converter (GBIC)

Converts copper interface to optic interface.

gnd Ground.

H

HBA Host Bus Adapter.

HD Slot Technology

High-density (HD) slot technology. Allows multiple cartridges to be stored in a tiered architecture.

hertz (Hz)

Unit of frequency. 1 hertz equals one cycle per second.

hex Hexadecimal.

HH Half height

High Voltage Differential (HVD)

A logic signaling system that enables data communication between a supported host and the library. HVD signaling uses a paired plus and minus signal level to reduce the effects of noise on the SCSI bus. Any noise that is injected into the signal is present in both a plus and minus state, and is canceled. Synonymous with *differential*.

HVD SCSI Bus High Voltage Differential

Hz Hertz (cycles per second).

I**IBM Security Key Lifecycle Manager (SKLM)**

IBM's EKM application that assists encrypting tape drives in generating, protecting, storing, and maintaining encryption keys that encrypt information that is written to and decrypt information that is read from tape media.

ID Identifier.

identifier (ID)

(1) In programming languages, a lexical unit that names a language object; for example, the names of variables, arrays, records, labels, or procedures. An identifier usually consists of a letter optionally followed by letters, digits, or other characters. (2) One or more characters that are used to identify or name data element and possibly to indicate certain properties of that data element. (3) A sequence of bits or characters that identifies a program, device, or system to another program, device, or system.

IEC International Electrotechnical Commission.

IML Initial microprogram load.

incompatible magazine

This message might display on the Operator Panel during library initialization. It occurs during factory restore or VPD. This message is not a real issue since it takes time for the library to configure.

initial microprogram load (IML)

The action of loading a microprogram from an external storage to writable control storage.

initiator

The component that runs a command. The initiator can be the host system or the tape control unit.

INST Installation.

interface

A shared boundary. An interface might be a hardware component to link two devices or it might be a portion of storage or registers accessed by two or more computer programs.

Internet Protocol Version 4 (IPv4)

See *IPv4*.

Internet Protocol Version 6 (IPv6)

See *IPv6*.

intervention required

Manual action is needed.

INTRO

Introduction.

I/O Input/output.

I/O Station

Cartridge location that is dedicated for the insertion of cartridges into and the removal of cartridges from the library.

IOP Input/output processor.

IP Internet Protocol.

IP address

An identifier for a computer or device on an Internet Protocol (TCP/IP) network. Networks that use the TCP/IP protocol route messages that are based on the IP address of the destination. See *IPv4* and *IPv6*.

IPL Initial program load.

IP Stack

A TCP/IP protocol stack that manages static IP addresses.

IPv4 A network layer protocol for packet-switched networks. IPv4 supports 2^{32} (about 4.3 billion) addresses.

IPv6 A network layer protocol for packet-switched networks. It is the designated successor of IPv4 for general use on the Internet. The main improvement that is brought by IPv6 is the increase in the number of addresses available for networked devices, allowing, for example, each mobile phone and mobile electronic device to have its own unique address.

ISV Independent software vendor.

ITDT IBM Tape Diagnostic tool.

ITST Idle-time self-test.

K**Kerberos**

Kerberos Authentication is a standard (RFC 1510) third-party authentication protocol that provides end-to-end security for distributed computing environments.

kilogram (kg)

1000 grams (approximately 2.2 pounds).

km kilometer. 1000 Meters, Approximately 5/8 mile.

L

LAN Local area network. A computer network within a limited area.

LCB Library Control Blade

LCD See *liquid crystal display*.

LDAP Lightweight Directory Access Protocol. This allows the library to use login and password information that is stored on a server to grant access to the library functionality.

LDAPS

Secure LDAP over SSL.

LDI Library Drive Interface.

LED Light-emitting diode.

library certification

In cryptography, a certificate that is provided by the library.

library-managed encryption

Tape encryption that is controlled by the tape library.

Linear Tape-Open (LTO)

A type of tape storage technology that is developed by the IBM Corporation, Hewlett-Packard, and Quantum. LTO technology is an "open format" technology, which means that its users have multiple sources of product and media. The "open" nature of LTO technology enables compatibility between different vendors' offerings by ensuring that vendors comply with verification standards. The LTO technology is implemented in two formats: the Accelis format focuses on fast access; the Ultrium format focuses on high capacity. The Ultrium format is the preferred format when capacity (rather than fast access) is the key storage consideration. The latest LTO cartridge, Ultrium 8, has a compressed data capacity of up to 30000 GB (2.5:1 compression) and a native data capacity of up to 12000 GB.

liquid crystal display (LCD)

A low-power display technology that is used in computers and other I/O devices.

loadable

The ability to be loaded.

LME Library Managed Encryption.

LTO cartridge memory (LTO-CM)

Within each LTO Ultrium data cartridge, an embedded electronics and interface module that can store and retrieve a cartridge's historical usage and other information.

LUN Logical Unit Number.

LVD SCSI Bus Low Voltage Differential

M

MAC address

The Media Access Control address of a computer networking device.

magnetic tape

A tape with a magnetic surface layer on which data can be stored by magnetic recording.

MAP Maintenance analysis procedure.

mask A pattern of characters that controls the retention or elimination of portions of another pattern of characters. To use a pattern of characters to control the retention or elimination of portions of another pattern of characters.

master file

A file that is used as an authority in a job and that is relatively permanent, even though its contents might change. Synonymous with main file.

Maximum Transmission Unit (MTU)

The size of the largest packet that a network protocol can transmit.

MB Megabyte (expressed as data rate in MB/s or MB/second).

media capacity

The amount of data that can be contained on a storage medium, expressed in bytes of data.

media-type identifier

Pertaining to the bar code on the bar code label of the Ultrium tape cartridge, a 2-character code,

L1, that represents information about the cartridge. L identifies the cartridge as one that can be read by devices that incorporate LTO technology; 1 indicates that it is the first generation of its type.

mega One million of.

meter In the Metric System, the basic unit of length; equal to approximately 39.37 inches.

MIB Management Information Base. Information repository that is used by SNMP.

micro One millionth of.

microcode

(1) One or more micro instructions. (2) A code, representing the instructions of an instruction set, which is implemented in a part of storage that is not program-addressable. (3) To design, write, and test one or more micro instructions. (4) See also *microprogram*.

microdiagnostic routine

A program that runs under the control of a supervisor, usually to identify field replaceable units.

microdiagnostic utility

A program that is run by the customer engineer to test the machine.

microinstruction

A basic or elementary machine instruction.

microprogram

A group of microinstructions that when run performs a planned function.

The term microprogram represents a dynamic arrangement or selection of one or more groups of microinstructions for execution to perform a particular function. The term microcode represents microinstructions that are used in a product as an alternative to hard-wired circuitry to implement certain functions of a processor or other system component.

MIM Media information message.

mm Millimeter.

modifier

That which changes the meaning.

mount a device

To assign an I/O device with a request to the operator.

MP Microprocessor.

ms Millisecond.

MSG Message.

multipath

Pertaining to using more than one path.

N

N/A Not applicable.

Network Address Translation (NAT)

NAT involves rewriting the source or destination addresses of IP packets as they pass through a router or firewall. Most systems that use NAT do so to enable multiple hosts on a private network to access the Internet over a single public IP address.

NEMA

National Electrical Manufacturers Association.

node In a network, a point at which one or more functional units connect channels or data circuits.

- NTP** Network Time Protocol. This protocol allows the library to set its internal date and time that is based on the date and time of a server.
- NVS** Nonvolatile storage. A storage device whose contents are not lost when power is cut off.

O

oersted

The unit of magnetic field strength in the unrationalized centimeter-gram-second (cgs) electromagnetic system. The oersted is the magnetic field strength in the interior of an elongated, uniformly wound solenoid that is excited with a linear current density in its winding of 1 abampere per 4π centimeters of axial length.

offline

Pertaining to the operation of a functional unit without the continual control of a computer. Contrast with *online*.

online Pertaining to the operation of a functional unit that is under the continual control of a computer. Contrast with *offline*.

OPER Operation.

ov Over voltage.

overrun

Loss of data because a receiving device is unable to accept data at the rate it is transmitted.

overtightening

To tighten too much.

P

parameter

A variable that is given a constant value for a specified application and that might denote the application.

p bit Parity bit.

PC Parity check.

PCC Power control compartment.

PDF Portable Document Format.

PE Parity error. Product engineer.

PFS Perfect forward secrecy.

pick Pertaining to the library, to remove, by using a robotic device, a tape cartridge from a storage slot or drive.

picker A robotic mechanism that is located inside the library that moves cartridges between the cartridge storage slots and the drive.

PM Preventive maintenance.

POR Power-on reset.

port A physical connection for communication between the 3590 and the host processor. The 3590 has 2 SCSI ports.

Portable Document Format (PDF)

A standard that is specified by Adobe Systems, Incorporated, for the electronic distribution of documents. PDF files are compact, can be distributed globally (by way of email, the web, intranets, or CD-ROM), and can be viewed with the Acrobat Reader, which is software from Adobe Systems that can be downloaded at no cost from the Adobe Systems home page.

Private key

A cryptographic key that is used to decrypt a message.

PROM

Programmable read only memory.

PS Power supply.

PTF Program temporary fix. A single bugfix or group of bugfixes that are distributed in a form ready to install for customers.

PWR Power.

R

rack A unit that houses the components of a storage subsystem, such as the library.

rackmount kit

A packaged collection of articles that are used to install the rack mounted version of the library.

RAM Random access memory.

Random access memory

A storage device into which data is entered and from which data is retrieved in a nonsequential manner.

RAS Reliability, availability, and serviceability.

record A collection of related data or words, which are treated as a unit.

recording density

The number of bits in a single linear track measured per unit of length of the recording medium.

recoverable error

An error condition that allows continued execution of a program.

ref Reference.

reg Register.

reinventor

To inventory again.

retension

The process or function of tightening the tape onto the cartridge, if it is sensed that the tape has a loose wrap on the cartridge.

RFC (Request for Comments)

Request for Comments (RFC) documents are a series of memoranda, which encompasses new research, innovations, and methodologies applicable to Internet technologies.

RH Relative humidity.

RML Rack Mount Line.

robot Picker.

robotics

Picker assembly.

root CA certification

In cryptography, a root certificate from a certificate authority (CA).

RPQ Request for price quotation.

RSA key

Encryption key type.

R/W read/write.

S

s Seconds of time.

SAN Storage area network.

SAS Serial Attached SCSI. A computer bus technology and serial communication protocol for direct attached storage devices. SAS is a replacement for parallel SCSI with higher speeds, but still utilizing SCSI commands.

scratch cartridge

A data cartridge that contains no useful data, but can be written to with new data.

SCD Single Character Display.

SCSI Small computer system interface.

SE Single-ended.

segment

A part.

sel Select.

Serial Attached SCSI (SAS)

A drive with a SAS interface can be linked directly to controllers. SAS is a performance improvement over traditional SCSI because SAS enables multiple devices (up to 128) of different sizes and types to be connected simultaneously with thinner and longer cables. It supports full-duplex signal transmission up to 3 Gb/s. In addition, SAS drives can be hot-plugged.

serialize

To change from parallel-by-byte to serial-by-bit.

serializer

A device that converts a space distribution of simultaneous states, which represents data into a corresponding time sequence of states.

Service tag

Repair identification tag.

servo, servos

An adjective for use in qualifying some part or aspect of a servomechanism.

servomechanism

A feedback control system in which at least one of the system signals represents mechanical motion.

signature

A digital signature that is used in cryptography to identify one party to ensure authenticity.

SKLM (IBM Security Key Lifecycle Manager)

IBM's EKM application that assists encrypting tape drives in generating, protecting, storing, and maintaining encryption keys that encrypt information that is written to and decrypt information that is read from tape media.

slot blocker

A slot blocker is used to restrict/close off a data cell so a data cartridge cannot be inserted.

Small Computer Systems Interface (SCSI)

A standard that is used by computer manufacturers for attaching peripheral devices (such as tape drives, hard disks, CD-ROM players, printers, and scanners) to computers (servers). Pronounced "scuzzy". Variations of the SCSI interface provide for faster data transmission rates than standard serial and parallel ports (up to 320 megabytes per second). The variations include:

- Fast/Wide SCSI: Uses a 16-bit bus, and supports data rates of up to 20 MBps.
- SCSI-1: Uses an 8-bit bus, and supports data rates of 4 MBps.
- SCSI-2: Same as SCSI-1, but uses a 50-pin connector instead of a 25-pin connector, and supports multiple devices.
- Ultra SCSI: Uses an 8- or 16-bit bus, and supports data rates of 20 or 40 MBps.
- Ultra2 SCSI: Uses an 8- or 16-bit bus and supports data rates of 40 or 80 MBps.
- Ultra3 SCSI: Uses a 16-bit bus and supports data rates of 80 or 160 MBps.
- Ultra160 SCSI: Uses a 16-bit bus and supports data rates of 80 or 160 MBps.
- Ultra320 SCSI: Uses a 16-bit bus and supports data rates of 320 MBps.

SME System Managed Encryption.

SMI-S See *Storage Management Initiative Specification (SMI-S)*.

SMTP Simple Mail Transfer Protocol. SMTP is a standard for email transmissions across the internet.

SNMP

Simple Network Management Protocol. SNMP is used by network management systems to monitor network-attached devices for conditions that warrant administrative attention.

SNTP Simple Network Time Protocol. Used to synchronize the clocks of network-attached devices.

SMW Servo Manufacturer's Word.

SNS Sense.

special feature

A feature that can be ordered to enhance the capability, storage capacity, or performance of a product, but is not essential for its basic work.

SPI Security Parameters Index.

SR Service representative, see also *CE*.

SRAM

Static random access memory.

SS Status store.

SSL (Secure Sockets Layer)

A set of cryptographic protocols for secure communications on the Internet for such things as web browsing, email, Internet faxing, instant messaging, and other data transfer. SSL allows applications to communicate across a network in a way that is designed to prevent eavesdropping, tampering, and message forgery.

SSP Serial SCSI Protocol.

ST Store.

standard feature

The significant design elements of a product that are included as part of the fundamental product.

START

Start maintenance.

StartTLS

Secure LDAP communication that uses TLS.

Storage Management Initiative Specification (SMI-S)

A storage standard that is developed and maintained by the Storage Networking Industry Association (SNIA). It is also ratified as an ISO standard. The main objective of SMI-S is to enable broad interoperable management of heterogeneous storage vendor systems.

subsystem

A secondary or subordinate system, capable of operating independently of, or asynchronously with, a controlling system.

SUPP Support.

sync Synchronous, synchronize. Occurring with a regular or predictable time relationship.

System-managed encryption

Tape encryption is set up implicitly through the device driver.

T**tachometer, tach**

A device that emits pulses that are used to measure/check speed or distance.

tape cartridge

A container that holds magnetic tape, that can be processed without separating it from the container.

tape void

An area in the tape in which no signal can be detected.

TCP/IP

Transmission Control Protocol/Internet Protocol.

TCU Tape control unit.

TH Thermal.

thread/load operation

A procedure that places tape along the tape path.

TM Tapemark.

transport mode

End-to-end communications security in which the end-point computers do the security processing.

trusted certification

In cryptography, a trustworthy certificate that is not registered with a certificate authority.

tunnel mode

Port-to-port communications security in which security is provided to several machines by a single node.

U

UART Universal asynchronous receiver/transmitter.

UL Underwriter's Laboratories.

unload

Prepare the tape cartridge for removal from the drive.

utilities

Utility programs.

utility programs

A computer program in general support of the processes of a computer; for instance, a diagnostic program.

uv Under voltage.

V

VOLSER

Volume serial number.

volume

A certain portion of data, together with its data carrier, that can be handled conveniently as a unit.

VPD Vital product data. The information that is contained within the tape drive that requires nonvolatile storage that is used by functional areas of the drive, and information that is required for manufacturing, RAS, and engineering.

W

word A character string that is convenient for some purpose to consider as an entity.

World Wide Node Name (WWNN)

A unique character string which identifies Fibre Channel Host Bus adapters (HBA).

WORM

Write Once Read Many.

Write Write command.

WT World trade.

WWCID

Worldwide Cartridge Identifier.

WWN Worldwide Name.

WWNN

Worldwide Node Name.

WWPN

Worldwide port name.

X

XR External register.

XRA External register address register.

Index

A

- Access PIN, Operator Control Panel 98
- accessibility
 - keyboard 241
 - repeat rate of up and down buttons 241
 - shortcut keys 241
- accessor 5
- accessory package 36
- active slots 94, 116
- Active Slots 57
- air quality 35
- air vents, front panel 1
- AME 118
- Application Managed Encryption (AME) 60
- ASC 215
- ASCQ 215
- auto clean 94, 116
- Auto Clean 57

B

- Bar Code Labels 142
 - guidelines for using 144
- bar code reader 5
- bootcode firmware, current level 106
- BOP 110
- Border Gateway Protocol (BGP) 7

C

- cable, host interface 50
- Cartridge 11, 139
 - capacity scaling 139
 - cleaning 142
 - compatibility 141
 - data 139
 - proper handling 145
 - specifications 147
 - Write-Protect Switch 144
- cartridge magazines 1, 69
- Cartridge, environment 146
- cartridge, suspect 18
- cartridges
 - inserting in library 73
 - populating library 73
- Cartridges, insert and remove 135
- channel calibration 10
- choosing a location 35
- clean drive 129
- cleaning slot 136
- clearance 35
- Configure menu
 - network settings 54
- configuring library using Web User Interface 53
- configuring the library 53
- control keys 81
- control path drive 107, 120

- control path failover 26, 118
- control paths 96
 - multiple 26
 - using multiple for control path failover 26

D

- daisy-chaining 32
- Data Cartridge 135
- data transfer rate 8
- DCS 136
- dedicated cleaning slot 204
- default settings 99
- description 1
- desktop installation 35
- Device drivers supported 15
- DHCP 54, 62, 97, 122
- Diagnostics 132
- display contrast 104
- dll 69, 159
- Drive
 - channel calibration 10
 - power management 11
 - speed matching 10
- drive configuration 120
- Drive Density 110
- Drive Diagnostics 104, 132
- drive dump, saving to host 131
- drive firmware, current version 107
- drive interface 96
- Drive Log 131
- drive serial number 107
- drive sled
 - description 9
- drive status 110
- drive, clean 129

E

- EC 88
- ED 88
- element addresses 26, 204, 205
- element addressing 203
- element types 203
- Encryption 6, 60
- environment 15
 - operating 15
 - particulates 15
- environmental specifications 12
- Error codes 161
- Error LEDs 155
- Error log 161
- Ethernet Port 3
- Export Media 73, 91, 114, 135, 175

F

- factory default settings 99
- fan vents 3

- feature activation key 118
- features
 - optional
 - drives 9
- Fibre Channel 30
- Fibre Channel interface
 - cables and speeds 33
 - sharing on a SAN 34
 - zoning 33
- Fibre Channel ports 33
- Firmware
 - updating
 - using ITDT Tool 177
- firmware, upgrade 134
- foot pads, installing 37
- front panel components 1

G

- Gateway address 54
- Gateway Address 62, 97, 122
- glossary 243

H

- Host Attachment 159
- host bus adapter 30
- host connection, verifying 69
- host interface cable 50
- host interface connectors 3
- host interfaces 30
- host preparation 69
- humidity 35

I

- I/O station 69
- I/O Station 1, 135
- I/O Station, configuring 136
- I/O Station, open and close 136
- identifying a suspect cartridge 1, 18
- Import Media 73, 91, 114, 135
- installation 35
 - rack
 - safety xviii
- Interface 159
- interfaces 30
- interfaces, supported 9
- Internet Protocol version 4 7
- Internet Protocol version 6 7
- Inventory 88, 115
- IP address 54, 106
- IP Address 62, 97, 122
- IP Stack 97
- IPv4 7
- IPv6 7
- ITDT Tool 177

K

Key Path 110
Key Path Diagnostics 133
keyboard 241

L

Labels
 bar code 142
 guidelines for using 144
laser
 compliance xviii
 safety xviii
LED, amber 160
LEDs 18, 155
LEDs, front panel 1
library configuration form 239
library firmware, current level 106
library logs 130
library mode 57, 94, 106, 116
library name 116
library network configuration 62, 122
library recovery 155
library SNMP configuration 66, 127
library status 109
Library Verify 102
library weight 12
license activation key 59, 60, 102
Link-local IPv6 address 84
Linux 231
LME 118
locating the library 35
logical libraries 58, 92, 117
 determining number 25
 basic guidelines 25
 using multiple for sharing 25
logical libraries, assigning 58
logs 130
low voltage differential (LVD) SCSI interface 9
low-power mode 11
LUN 30, 231
LUN scanning 30
LVD SCSI interface 9

M

MAC Address 7
magazines 1, 69
Maximum Transmission Unit (MTU) 7
media 11
Media 139
media capacity 1
menu shortcuts 75
menu tree
 Operator Control Panel 83
Menus
 Configure
 network settings 54
MIB 7, 209
Monitor menu
 Drive 86
 Library 84
Move Media 73, 91, 114
Multiple control paths 26

N

Navigation 81
Netmask 54
Network Address Translation (NAT) 7
network configuration 97
Network Mask 62, 97, 122
network settings 97

O

OCP 68
ON/OFF power button 20
operation specifications 12
Operator Control Panel
 Access PIN 98
 Configure: Save/Restore 99
 control keys on front panel 1
 display 1
 menu tree 83
 Monitor menu
 Drive 86
 Library 84
 power ON display 18
Operator Control Panel menus
 Configure: Drive 96
 Configure: Library 94
Ordering Media
 Ordering WORM cartridges 141

P

packaging materials 36
partitioning 26, 58, 205
partitioning your 4U library 117
path failover 59, 102
physical specifications 12
power button 1, 20
power connector 3
power management 11
power ON display 18
power source 35
power specifications 12
Power Supply Problem 155
product ID 106
PTF 69, 159

Q

Quiesce 133

R

rack installation 35, 40
 safety xviii
rack mounting the library 40
rack requirements 35
RAID controllers 30
Read/Write capability 141
rear panel of library 3
Remove/replace procedures 179
reserve slot, active slot 136
Reserved Slots 57
RFC (Request for Comments) 7
Router assigned IPv6 address 84

S

safety information
 laser compliance xviii
 laser safety xviii
SAS interface 32
screens displayed at power ON 18
SCSI interface 30
 bus termination 32
 description 9
 multiple buses 32
 physical characteristics 31
SCSI LVD 30, 32
SCSI Trade Association Web site 32
sending your comments v
Sense data
 using 215
sense data, library 215
sequential mode, starting 94
sequential mode, stopping 94
serial number 106
serial number, drive 107
Serial Port 3
server attachment
 SCSI interface 30
Sharing the library 25
shipment verification 36
shipping container 36
shipping label, removing and storing 38
shipping lock and label storage
 location 3
shipping lock, removing and storing 38
shortcut keys 241
Simple Network Management Protocol 7
SKLM 60, 118
SKLM (Security Key Lifecycle Manager) 6
SKLM Server Setting 60
sled, description of tape drive 9
slot physical locations 204
SME 118
SNMP 7, 66, 122, 127, 209, 237
specifications 12
 environmental 12
 operation 12
 physical 12
 power 12
Specifications
 cartridges 147
speed matching 10
SSL 62, 122
storage capacity 8
support notification v

T

tape cartridge 11
tape drive sled 3
Tape drives
 channel calibration 10
 power management 11
 quantity in library 9
 speed matching 10
TapeAlert Flags
 for drives 211
TapeAlert Flags, library 209

- technical support v
- Telnet Service Port 105
- Traps 237
- troubleshooting 149

U

- Ultra160 8
- Ultra320 8
- Ultrium Tape Drives 9
- unpacking the library 36
- Updating firmware
 - using ITDT Tool 177
- upgrade firmware 134
- USB port 3

V

- verifying the shipment 36
- View Drive Logs 131

W

- Web User Interface
 - Configure Library: Event Notification 126
 - Configure Library: Save/Restore 128
 - configuring library 53
 - drive information 61
 - event notification 66
 - general library information 57
 - logging on 55
 - logs and traces 65
 - user access information 64
- Web User Interface menus
 - Configure Library: User Access 123
- Web User InterfaceConfigure Library
 - date and time 65
- worldwide node name 106
- WORM 141
- WORM (Write Once, Read Many) 141
- Write Once, Read Many (see WORM) 141
- write-protect switch
 - Write Protect Switch Setting 211
- Write-Protect Switch
 - setting 144
- WWNN 106

Printed in USA