

Inspiron 15 5000

Service Manual



Notes, cautions, and warnings

 **NOTE:** A NOTE indicates important information that helps you make better use of your product.

 **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

Chapter 1: Before working inside your computer	8
Before you begin	8
Safety instructions.....	8
Recommended tools.....	9
Screw list.....	9
Chapter 2: After working inside your computer	11
Chapter 3: Removing the optical drive	12
Procedure.....	12
Chapter 4: Replacing the optical drive	14
Procedure.....	14
Chapter 5: Removing the base cover	15
Prerequisites.....	15
Procedure.....	15
Chapter 6: Replacing the base cover	17
Procedure.....	17
Post-requisites.....	17
Chapter 7: Removing the memory modules	18
Prerequisites.....	18
Procedure.....	18
Chapter 8: Replacing the memory modules	20
Procedure.....	20
Post-requisites.....	21
Chapter 9: Removing the wireless card	22
Prerequisites.....	22
Procedure.....	22
Chapter 10: Replacing the wireless card	24
Procedure.....	24
Post-requisites.....	25
Chapter 11: Removing the optical-drive interposer	26
Prerequisites.....	26
Procedure.....	26
Chapter 12: Replacing the optical-drive interposer	28

Procedure.....	28
Post-requisites.....	28
Chapter 13: Removing the coin-cell battery.....	29
Prerequisites.....	29
Procedure.....	29
Chapter 14: Replacing the coin-cell battery.....	30
Procedure.....	30
Post-requisites.....	30
Chapter 15: Removing the I/O board.....	31
Prerequisites.....	31
Procedure.....	31
Chapter 16: Replacing the I/O board.....	32
Procedure.....	32
Post-requisites.....	32
Chapter 17: Removing the hard drive.....	33
Prerequisites.....	33
Procedure.....	33
Chapter 18: Replacing the hard drive.....	35
Procedure.....	35
Post-requisites.....	35
Chapter 19: Removing the battery.....	36
Lithium-ion battery precautions.....	36
Prerequisites.....	36
Procedure.....	36
Chapter 20: Replacing the battery.....	38
Lithium-ion battery precautions.....	38
Procedure.....	38
Post-requisites.....	38
Chapter 21: Removing the status-light board.....	40
Prerequisites.....	40
Procedure.....	40
Chapter 22: Replacing the status-light board.....	42
Procedure.....	42
Post-requisites.....	42
Chapter 23: Removing the speakers.....	43
Prerequisites.....	43
Procedure.....	43

Chapter 24: Replacing the speakers	45
Procedure.....	45
Post-requisites.....	45
Chapter 25: Removing the system-board assembly	46
Prerequisites.....	46
Procedure.....	46
Chapter 26: Replacing the system-board assembly	50
Procedure.....	50
Post-requisites.....	50
Chapter 27: Removing the heat-sink assembly	51
Prerequisites.....	51
Procedure.....	51
Chapter 28: Replacing the heat-sink assembly	53
Procedure.....	53
Post-requisites.....	53
Chapter 29: Removing the touchpad	54
Prerequisites.....	54
Procedure.....	54
Chapter 30: Replacing the touchpad	57
Procedure.....	57
Post-requisites.....	57
Chapter 31: Removing the display assembly	58
Prerequisites.....	58
Procedure.....	58
Chapter 32: Replacing the display assembly	60
Procedure.....	60
Post-requisites.....	60
Chapter 33: Removing the display bezel	61
Prerequisites.....	61
Procedure.....	61
Chapter 34: Replacing the display bezel	62
Procedure.....	62
Post-requisites.....	62
Chapter 35: Removing the camera	63
Prerequisites.....	63
Procedure.....	63

Chapter 36: Replacing the camera.....	64
Procedure.....	64
Post-requisites.....	64
Chapter 37: Removing the display panel.....	65
Prerequisites.....	65
Procedure.....	65
Chapter 38: Replacing the display panel.....	67
Procedure.....	67
Post-requisites.....	67
Chapter 39: Removing the display hinges.....	68
Prerequisites.....	68
Procedure.....	68
Chapter 40: Replacing the display hinges.....	70
Procedure.....	70
Post-requisites.....	70
Chapter 41: Removing the display cable.....	71
Prerequisites.....	71
Procedure.....	71
Chapter 42: Replacing the display cable.....	73
Procedure.....	73
Post-requisites.....	73
Chapter 43: Removing the display back-cover and antenna assembly.....	74
Prerequisites.....	74
Procedure.....	74
Chapter 44: Replacing the display back-cover and antenna assembly.....	75
Procedure.....	75
Post-requisites.....	75
Chapter 45: Removing the power-button module.....	76
Prerequisites.....	76
Procedure.....	76
Chapter 46: Replacing the power-button module.....	78
Procedure.....	78
Post-requisites.....	78
Chapter 47: Removing the power-adaptor port.....	79
Prerequisites.....	79
Procedure.....	79

Chapter 48: Replacing the power-adapter port.....	81
Procedure.....	81
Post-requisites.....	81
Chapter 49: Removing the palm-rest and keyboard assembly.....	82
Prerequisites.....	82
Procedure.....	82
Chapter 50: Replacing the palm-rest and keyboard assembly.....	84
Procedure.....	84
Post-requisites.....	84
Chapter 51: Troubleshooting.....	85
Diagnostics.....	85
Dell Enhanced Pre-Boot System Assessment (ePSA) diagnostic 3.0.....	86
Handling swollen Lithium-ion batteries.....	86
Chapter 52: Getting help and contacting Dell.....	87

Before working inside your computer

 **NOTE:** The images in this document may differ from your computer depending on the configuration you ordered.

Before you begin

Steps

1. Save and close all open files and exit all open applications.
2. Shut down your computer. Click **Start** >  **Power** > **Shut down**.
 **NOTE:** If you are using a different operating system, see the documentation of your operating system for shut-down instructions.
3. Disconnect your computer and all attached devices from their electrical outlets.
4. Disconnect all attached network devices and peripherals, such as keyboard, mouse, and monitor from your computer.
5. Remove any media card and optical disc from your computer, if applicable.

Safety instructions

Use the following safety guidelines to protect your computer from potential damage and to ensure your personal safety. Unless otherwise noted, each procedure included in this document assumes that you have read the safety information that shipped with your computer.

 **WARNING:** Before working inside your computer, read the safety information that is shipped with your computer. For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

 **WARNING:** Disconnect your computer from all power sources before opening the computer cover or panels. After you finish working inside the computer, replace all covers, panels, and screws before connecting your computer to an electrical outlet.

 **CAUTION:** To avoid damaging the computer, ensure that the work surface is flat, dry, and clean.

 **CAUTION:** To avoid damaging the components and cards, handle them by their edges, and avoid touching the pins and the contacts.

 **CAUTION:** You should only perform troubleshooting and repairs as authorized or directed by the Dell technical assistance team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. See the safety instructions that is shipped with the product or at www.dell.com/regulatory_compliance.

 **CAUTION:** Before touching anything inside your computer, ground yourself by touching an unpainted metal surface, such as the metal at the back of the computer. While you work, periodically touch an unpainted metal surface to dissipate static electricity which could harm internal components.

 **CAUTION:** When you disconnect a cable, pull it by its connector or its pull tab, not the cable itself. Some cables have connectors with locking tabs or thumbscrews that you must disengage before disconnecting the cable. When disconnecting cables, keep them evenly aligned to avoid bending the connector pins. When connecting cables, ensure that the ports and the connectors are correctly oriented and aligned.

 **CAUTION:** Press and eject any installed card from the media-card reader.

CAUTION: Exercise caution when handling Lithium-ion batteries in laptops. Swollen batteries should not be used and should be replaced and disposed properly.

NOTE: The color of your computer and certain components may appear differently than shown in this document.

Recommended tools

The procedures in this document may require the following tools:

- Phillips screwdriver #1
- Plastic scribe

Screw list

Component	Secured to	Screw type	Quantity	Screw image
Base cover	Palm rest and keyboard assembly	M2x2 Big Head	3	
Base cover	Palm rest and keyboard assembly	M2x4	2	
Base cover	Palm rest and keyboard assembly	M2.5x8	13	
Battery	Palm rest and keyboard assembly	M2.5x5	1	
Fan	Palm rest and keyboard assembly	M2.5x5	1	
Hard drive	Hard-drive bracket	M3x3	4	
Hard-drive bracket	Palm rest and keyboard assembly	M2.5x5	3	
Heat-sink assembly	System board	M2x3	3	
Hinge brackets	Display back-cover and antenna assembly	M2.5x3	6	
Hinge brackets	Palm rest and keyboard assembly	M2.5x5	4	
Hinge (LCD side)	Display back-cover and antenna assembly	M2x3	2	
I/O board	Palm rest and keyboard assembly	M2.5x5	1	
Optical-drive bracket	Optical drive	M2x3	2	
Optical-drive interposer	Palm rest and keyboard assembly	M2x2 Big Head	2	

Component	Secured to	Screw type	Quantity	Screw image
Palm rest and keyboard assembly bridge	Palm rest and keyboard assembly	M2.5x5	2	
Panel	Palm rest and keyboard assembly	M2x3	4	
Power-adapter port	Palm rest and keyboard assembly	M2x3	1	
Power-button board	Palm rest and keyboard assembly	M2x2 Big Head	1	
System board	Palm rest and keyboard assembly	M2.5x5	1	
Touch pad	Palm rest and keyboard assembly	M2x2	4	
Touch-pad bracket	Palm rest and keyboard assembly	M2x2	3	
Wireless-card bracket	System board	M2x3	1	

After working inside your computer

About this task

 **CAUTION:** Leaving stray or loose screws inside your computer may severely damage your computer.

Steps

1. Replace all screws and ensure that no stray screws remain inside your computer.
2. Connect any external devices, peripherals, or cables you removed before working on your computer.
3. Replace any media cards, discs, or any other parts that you removed before working on your computer.
4. Connect your computer and all attached devices to their electrical outlets.
5. Turn on your computer.


Removing the optical drive

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure


Steps

1. Remove the screw that secures the optical-drive assembly to the base cover.
2. Using a plastic scribe, push the optical drive through the screw hole to release the optical-drive assembly.
3. Slide the optical-drive assembly out of the optical-drive bay.




- | | |
|---------------------------|---------------|
| 1. optical-drive assembly | 2. M2x4 screw |
| 3. plastic scribe | 4. base cover |

4. Remove the screws that secure the optical-drive bracket to the optical drive.
5. Remove the optical-drive bracket.



- a. optical drive
- b. M2x3 screws (2)
- c. optical-drive bracket

6. Pull the optical-drive bezel carefully to remove it from the optical drive.



- a. optical-drive bezel
- b. optical drive
- c. tabs (3)

Replacing the optical drive

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

Steps

1. Align the tabs on the optical-drive bezel with the slots on the optical drive and snap the optical-drive bezel into place.
2. Align the screw holes on the optical-drive bracket with the screw holes on the optical drive.
3. Replace the screws that secure the optical-drive bracket to the optical drive.
4. Slide the optical-drive assembly into the optical-drive bay.
5. Align the screw hole on the optical-drive bracket with the screw hole on the base cover.
6. Replace the screw that secures the optical-drive assembly to the base cover.

Removing the base cover

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


About this task

Remove the optical drive.

Procedure

Steps

1. Remove the screws that secure the base cover to the palm rest and keyboard assembly.



- | | |
|-----------------------|--------------------|
| 1. M2.5x8 screws (13) | 2. M2x2 screws (3) |
| 3. M2x4 screw | 4. base cover |


2. Using a plastic scribe, pry the base cover starting from the top-left corner of the computer base.
3. Lift the base cover off the palm rest and keyboard assembly at an angle.



- a. palm rest and keyboard assembly
- b. plastic scribe
- c. base cover

i **NOTE:** Follow step 4 and 5 only if you want to further remove any component from the computer.

4. Disconnect the battery cable from the system board.



- a. battery cable
- b. system board

5. Press and hold the power button for 5 seconds to ground the system board.

Replacing the base cover

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

Steps

1. Connect the battery cable to the system board, if applicable.

CAUTION: To avoid accidental damage to the power-adapter port, do not press the base cover against the power-adapter port when you snap the base cover to the computer base.

2. Place the base cover on the palm rest and keyboard assembly, and snap the base cover into place starting from the power-adapter port.



- a. base cover
- b. power-adapter port

3. Replace the screws that secure the base cover to the palm rest and keyboard assembly.

Post-requisites

About this task

Replace the [optical drive](#).

Removing the memory modules

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).

Procedure

Steps

1. Use your fingertips to carefully spread apart the securing-clips on each end of the memory-module slot until the memory module pops up.
2. Remove the memory module from the memory-module slot.



- a. securing clips (2)

- b. memory module
- c. memory-module slot

Replacing the memory modules


NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

Steps

1. Align the notch on the memory module with the tab on the memory-module slot.
2. Slide the memory module firmly into the slot at an angle and press the memory module down until it clicks into place.

NOTE: If you do not hear the click, remove the memory module and reinstall it.



1. notch

3. memory-module slot

2. tab

4. memory module

3. Connect the battery cable to the system board.

Post-requisites

Steps

1. Replace the [base cover](#).
2. Replace the [optical drive](#).

Removing the wireless card

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).

Procedure

Steps

1. Remove the screw that secures the wireless-card bracket to the system board.
2. Slide and remove the wireless-card bracket and disconnect the antenna cables from the wireless card.
3. Slide and remove the wireless card from the wireless-card slot.



1. M2x3 screw
3. antenna cables (2)
5. wireless-card slot

2. wireless-card bracket
4. wireless card

Replacing the wireless card

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

About this task

CAUTION: To avoid damage to the wireless card, do not place any cables under it.


Steps

1. Align the notch on the wireless card with the tab on the wireless-card slot.
2. Insert the wireless card at an angle into the wireless-card slot.
3. Connect the antenna cables to the wireless card.

The following table provides the antenna-cable color scheme for the wireless card supported by your computer.

Connectors on the wireless card	Antenna-cable color
Main (white triangle)	White
Auxiliary (black triangle)	Black

4. Slide and replace the wireless-card bracket on the wireless-card slot.
5. Align the screw hole on the wireless-card bracket with the screw hole on the wireless card and the palm rest and keyboard assembly.
6. Replace the screw that secures the wireless-card bracket to the wireless card and the palm rest and keyboard assembly.



1. wireless card
2. notch
3. wireless-card slot
4. tab
5. antenna cables (2)
6. M2x3 screw
7. wireless-card bracket

Post-requisites

Steps

1. Replace the [base cover](#).
2. Replace the [optical drive](#).

Removing the optical-drive interposer

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).

Procedure

Steps

1. Open the latch and disconnect the display cable from the system board.
2. Lift the latch and pull the optical-drive interposer cable from the system board and the optical-drive board connector.
3. Remove the screws that secure the optical-drive interposer to the palm rest and keyboard assembly.
4. Lift the optical-drive interposer off the palm rest and keyboard assembly.



1. display cable
3. latch

2. routing guide
4. optical-drive interposer cable

5. M2x2 screws (2)

6. optical-drive interposer

Replacing the optical-drive interposer

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

Steps

1. Align the screw holes on the optical-drive interposer with the screw holes on the palm rest and keyboard assembly.
2. Replace the screws that secure the optical-drive interposer to the palm rest and keyboard assembly.
3. Connect the optical-drive interposer cable to the system board and the optical-drive interposer.
4. Insert the optical-drive interposer cable into the latch and press the latch down to secure the cable.
5. Close the latch that secures the optical-drive interposer cable to the system board.
6. Route the display cable through the routing guide and connect it to the system board.

Post-requisites

Steps

1. Replace the [base cover](#).
2. Replace the [optical drive](#).

Removing the coin-cell battery

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

CAUTION: Removing the coin-cell battery resets the BIOS setup program's settings to default. It is recommended that you note the BIOS setup program's settings before removing the coin-cell battery.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).

Procedure

Steps

1. Disconnect the coin-cell battery cable from the system board.
2. Note the coin-cell battery cable routing on the palm rest and keyboard assembly.
3. Remove the coin-cell battery cable from the routing guide on the palm rest and keyboard assembly.
4. Peel off the coin-cell battery from the palm rest and keyboard assembly.



1. system board
3. coin-cell battery cable
5. routing guide

2. palm rest and keyboard assembly
4. coin-cell battery

Replacing the coin-cell battery

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

Steps

1. Adhere the coin-cell battery to the palm rest and keyboard assembly.
2. Route the coin-cell battery cable through the routing guide on the palm rest and keyboard assembly.
3. Connect the coin-cell battery cable to the system board.

Post-requisites

Steps

1. Replace the [base cover](#).
2. Replace the [optical drive](#).

Removing the I/O board

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).

Procedure

Steps

1. Lift the latch and using the pull tab disconnect the I/O-board cable from the system board.
2. Remove the screw that secures the I/O board to the palm rest and keyboard assembly.
3. Lift the I/O board off the palm rest and keyboard assembly.



- | | |
|------------------------------------|--------------------|
| 1. latch | 2. I/O-board cable |
| 3. M2.5x5 screw | 4. I/O board |
| 5. palm rest and keyboard assembly | |

Replacing the I/O board

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

Steps

1. Using the alignment posts, place the I/O board on the palm rest and keyboard assembly.
2. Align the screw hole on the I/O board with the screw hole on the palm rest and keyboard assembly.
3. Replace the screw that secures the I/O board to the palm rest and keyboard assembly.
4. Connect the I/O board-cable to the system board and close the latch to secure the cable.

Post-requisites

Steps

1. Replace the [base cover](#).
2. Replace the [optical drive](#).

Removing the hard drive

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

CAUTION: Hard drives are fragile. Exercise care when handling the hard drive.

CAUTION: To avoid data loss, do not remove the hard drive while the computer is in sleep or on state.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [I/O board](#).

Procedure

Steps

1. Lift the latch and using the pull tab, disconnect the hard-drive cable from the system board.
2. Remove the screws that secure the hard-drive assembly to the palm rest and keyboard assembly.
3. Lift the hard-drive assembly along with its cable off the palm rest and keyboard assembly.




1. pull tab
3. hard-drive cable

2. latch
4. M2.5x5 screws (3)

5. hard-drive assembly

6. palm rest and keyboard assembly

4. Disconnect the interposer from the hard-drive assembly.



- a. hard-drive assembly
- b. interposer

5. Remove the screws that secure the hard-drive bracket to the hard drive.
6. Lift the hard drive off the hard-drive bracket.



- a. M3x3 screws (4)
- b. hard-drive bracket
- c. hard drive

Replacing the hard drive

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

CAUTION: Hard drives are fragile. Exercise care when handling the hard drive.

Procedure

Steps

1. Align the screw holes on the hard-drive bracket with the screw holes on the hard drive.
2. Replace the screws that secure the hard-drive bracket to the hard drive.
3. Connect the interposer to the hard-drive assembly.
4. Align the screw holes on the hard-drive assembly with the screw holes on the palm rest and keyboard assembly.
5. Replace the screws that secure the hard-drive assembly to the palm rest and keyboard assembly.
6. Connect the hard-drive cable to the system board and close the latch to secure the cable.

Post-requisites

Steps

1. Replace the [I/O board](#).
2. Replace the [base cover](#).
3. Replace the [optical drive](#).

Removing the battery

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Lithium-ion battery precautions

CAUTION:

- Exercise caution when handling Lithium-ion batteries.
- Discharge the battery completely before removing it. Disconnect the AC power adapter from the system and operate the computer solely on battery power—the battery is fully discharged when the computer no longer turns on when the power button is pressed.
- Do not crush, drop, mutilate, or penetrate the battery with foreign objects.
- Do not expose the battery to high temperatures, or disassemble battery packs and cells.
- Do not apply pressure to the surface of the battery.
- Do not bend the battery.
- Do not use tools of any kind to pry on or against the battery.
- Ensure any screws during the servicing of this product are not lost or misplaced, to prevent accidental puncture or damage to the battery and other system components.
- If the battery gets stuck inside your computer as a result of swelling, do not try to release it as puncturing, bending, or crushing a lithium-ion battery can be dangerous. In such an instance, contact Dell technical support for assistance. See www.dell.com/contactdell.
- Always purchase genuine batteries from www.dell.com or authorized Dell partners and resellers.
- Swollen batteries should not be used and should be replaced and disposed properly. For guidelines on how to handle and replace swollen Lithium-ion batteries, see [Handling swollen Lithium-ion batteries](#).

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [I/O board](#).
4. Remove the [hard drive](#).

Procedure

Steps

1. Remove the screws that secure the battery bracket to the system board and palm rest and keyboard assembly.
2. Lift and remove the battery bracket.




- 1. system board
- 2. M2.5x5 screws (2)
- 3. battery bracket
- 4. battery
- 5. palm rest and keyboard assembly

3. Remove the screw that secures the battery to the palm rest and keyboard assembly.

i **NOTE:** Note the location of the screw that secures the battery to the palm rest and keyboard assembly.

4. Lift the battery off the palm rest and keyboard assembly.



- a. M2.5x5 screw
- b. battery
- c. palm rest and keyboard assembly

Replacing the battery

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Lithium-ion battery precautions

CAUTION:

- Exercise caution when handling Lithium-ion batteries.
- Discharge the battery completely before removing it. Disconnect the AC power adapter from the system and operate the computer solely on battery power—the battery is fully discharged when the computer no longer turns on when the power button is pressed.
- Do not crush, drop, mutilate, or penetrate the battery with foreign objects.
- Do not expose the battery to high temperatures, or disassemble battery packs and cells.
- Do not apply pressure to the surface of the battery.
- Do not bend the battery.
- Do not use tools of any kind to pry on or against the battery.
- Ensure any screws during the servicing of this product are not lost or misplaced, to prevent accidental puncture or damage to the battery and other system components.
- If the battery gets stuck inside your computer as a result of swelling, do not try to release it as puncturing, bending, or crushing a lithium-ion battery can be dangerous. In such an instance, contact Dell technical support for assistance. See www.dell.com/contactdell.
- Always purchase genuine batteries from www.dell.com or authorized Dell partners and resellers.
- Swollen batteries should not be used and should be replaced and disposed properly. For guidelines on how to handle and replace swollen Lithium-ion batteries, see [Handling swollen Lithium-ion batteries](#).

Procedure

Steps

1. Align the screw holes on the battery with the screw holes on the palm rest and keyboard assembly.
2. Replace the screw that secures the battery to the palm rest and keyboard assembly.
3. Align the screw holes on the battery bracket with the screw holes on the system board and palm rest and keyboard assembly.
4. Replace the screws that secure the battery bracket to the system board and palm rest and keyboard assembly.

Post-requisites

Steps

1. Replace the [hard drive](#).
2. Replace the [I/O board](#).
3. Replace the [base cover](#).

4. Replace the [optical drive](#).

Removing the status-light board

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [I/O board](#).
4. Remove the [hard drive](#).
5. Remove the [battery](#).

Procedure

Steps

1. Open the latch and disconnect the status-light board cable from the system board.
2. Peel off the status-light board cable from the palm rest and keyboard assembly.
3. Push the tab that secures the status-light board to the palm rest and keyboard assembly.
4. Lift the status-light board along with its cable off the palm rest and keyboard assembly.



1. system board
3. palm rest and keyboard assembly
5. tab
7. status-light board cable

2. latch
4. touch-pad bracket
6. status-light board

Replacing the status-light board

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

Steps

1. Place the status-light board into the slot on the palm rest and keyboard assembly.
2. Press down the status-light board until it snaps into place.
3. Adhere the status-light board cable to the palm rest and keyboard assembly.
4. Slide the status-light board cable into the connector on the system board and close the latch to secure the cable.

Post-requisites

Steps

1. Replace the [battery](#).
2. Replace the [hard drive](#).
3. Replace the [I/O board](#).
4. Replace the [base cover](#).
5. Replace the [optical drive](#).

Removing the speakers

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [I/O board](#).
4. Remove the [hard drive](#).
5. Remove the [battery](#).

Procedure

Steps

1. Open the latch and disconnect the status-light board cable from the system board.
2. Disconnect the speaker cable from the system board.
3. Remove the speaker cable from the routing guides on the palm rest and keyboard assembly.
4. Lift the speakers along with its cable off the palm rest and keyboard assembly.



1. system board
3. speakers (2)

2. speaker cable
4. palm rest and keyboard assembly

5. routing guides

Replacing the speakers

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

Steps

1. Using the alignment posts, place the speakers in the slots on the palm rest and keyboard assembly and snap the speakers into place.
2. Route the speaker cable through the routing guides on the palm rest and keyboard assembly.

NOTE: Push the rubber grommets inside if it pops out while replacing the speakers.

3. Connect the speaker cable to the system board.
4. Slide the status-light board cable into the connector on the system board and close the latch to secure the cable.

Post-requisites

Steps

1. Replace the [battery](#).
2. Replace the [hard drive](#).
3. Replace the [I/O board](#).
4. Replace the [base cover](#).
5. Replace the [optical drive](#).

Removing the system-board assembly

- NOTE:** Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.
- NOTE:** Your computer's Service Tag is stored in the system board. You must enter the Service Tag in the BIOS setup program after you replace the system board.
- NOTE:** Replacing the system board removes any changes you have made to the BIOS using the BIOS setup program. You must make the appropriate changes again after you replace the system board.
- NOTE:** Before disconnecting the cables from the system board, note the location of the connectors so that you can reconnect the cables correctly after you replace the system board.

Prerequisites

Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [I/O board](#).
4. Remove the [hard drive](#).
5. Remove the [battery](#).
6. Remove the [memory modules](#).
7. Remove the [wireless card](#).


Procedure

Steps

1. Remove the screws that secure the right display hinge to the palm rest and keyboard assembly.
2. Open the right display hinge.




- a. M2.5x5 screws (2)
 - b. right display hinge
 - c. system board
3. Open the latch and disconnect the display cable from the system board.
 4. Lift the latch and pull the optical-drive interposer cable from the system board and the optical-drive interposer.
 5. Open the latch and disconnect the status-light board cable from the system board.
 6. Open the latches and disconnect the touch-pad cable, keyboard backlight cable, and the keyboard cable from the system board.
 7. Disconnect the speaker cable and coin-cell battery cable from the system board.



- 1. optical-drive interposer cable
- 3. status-light board cable
- 5. coin-cell battery cable
- 7. touch-pad cable
- 9. display cable


- 2. latches (4)
- 4. speaker cable
- 6. keyboard cable
- 8. keyboard backlight cable

- 8. Remove the screws that secures the system board to the palm rest and keyboard assembly.
- 9. Remove the screw that secures the heat-sink assembly to the system board.
- 10. Carefully turn the system-board assembly over.



- a. M2.5x5 screw
- b. system board
- c. M2.5x5 screw

11. Lift the latch and pull the power-adapter port cable from the system board.
12. Disconnect the power-button cable from the system board.
13. Peel off the power-adapter port cable from the back of the heat-sink assembly.



- 1. power-button cable
- 2. power-adapter port cable
- 3. system board
- 4. latch

14. Remove the [heat-sink assembly](#).

Replacing the system-board assembly

- NOTE:** Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.
- NOTE:** Your computer's Service Tag is stored in the system board. You must enter the Service Tag in the BIOS setup program after you replace the system board.
- NOTE:** Replacing the system board removes any changes you have made to the BIOS using the BIOS setup program. You must make the appropriate changes again after you replace the system board.

Procedure

Steps

1. Replace the [heat-sink assembly](#).
2. Connect the power-adaptor port cable and power-button board cable to the back of the system board.
3. Carefully turn the system board over.
4. Using the alignment post, place the system board on the palm rest and keyboard assembly.
5. Align the screw hole on the system board with the screw hole on the palm and keyboard rest assembly.
6. Replace the screw that secures the system board to the palm rest and keyboard assembly.
7. Replace the screw that secures the heat-sink assembly to the system board.
8. Slide the speaker cable and coin-cell battery cable into the connectors on the system board.
9. Slide the touch-pad cable, keyboard backlight cable, and keyboard cable into the connectors and close the latches.
10. Slide the status-light board cable into the connector on the system board and close the latch.
11. Connect the optical-drive interposer cable to the system board and the optical-drive interposer.
12. Close the latch that secures the optical-drive interposer cable to the system board.
13. Close the right display hinge.
14. Connect the display cable to the system board.
15. Replace the screws that secure the right display hinge to the palm rest and keyboard assembly.

Post-requisites

Steps

1. Replace the [wireless card](#).
2. Replace the [memory modules](#).
3. Replace the [battery](#).
4. Replace the [hard drive](#).
5. Replace the [I/O board](#).
6. Replace the [base cover](#).
7. Replace the [optical drive](#).

Removing the heat-sink assembly

 **NOTE:** Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

 **NOTE:** The heat sink may become hot during normal operation. Allow sufficient time for the heat sink to cool before you touch it.

 **CAUTION:** For maximum cooling of the processor, do not touch the heat transfer areas on the heat sink. The oils in your skin can reduce the heat transfer capability of the thermal grease.

Prerequisites

Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [I/O board](#).
4. Remove the [hard drive](#).
5. Remove the [battery](#).
6. Remove the [memory modules](#).
7. Remove the [wireless card](#).
8. Remove the [system-board assembly](#).


Procedure

About this task

 **CAUTION:** Place the system board on a clean and flat surface.

Steps

1. Disconnect the fan cable from the system board.
2. In sequential order (as indicated on the heat-sink assembly), loosen the captive screws that secure the heat-sink assembly to the system board.
3. Remove the screws that secure the heat-sink assembly to the system board.
4. Lift the heat-sink assembly off the system board.



1. heat-sink assembly
3. system board
5. fan cable

2. M2x3 screws (3)
4. captive screws (4)

Replacing the heat-sink assembly

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

CAUTION: Incorrect alignment of the heat sink can damage the system board and processor.

NOTE: If either the system board or the fan and heat-sink assembly is replaced, use the thermal pad/paste provided in the kit to ensure that thermal conductivity is achieved.

Procedure

Steps

1. Place the heat-sink assembly on the system board.
2. Align the screw holes on the heat-sink assembly with the screw holes on the system board.
3. Replace the screws that secure the heat-sink assembly to the system board.
4. In sequential order (indicated on the heat-sink assembly), tighten the captive screws that secure the heat-sink assembly to the system board.
5. Connect the fan cable to the system board.

Post-requisites

Steps

1. Replace the [system-board assembly](#).
2. Replace the [wireless card](#).
3. Replace the [memory modules](#).
4. Replace the [battery](#).
5. Replace the [hard drive](#).
6. Replace the [I/O board](#).
7. Replace the [base cover](#).
8. Replace the [optical drive](#).

Removing the touchpad

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [I/O board](#).
4. Remove the [hard drive](#).
5. Remove the [battery](#).
6. Follow the procedure from step 1 to step 2 in "[Removing the status-light board](#)".
7. Remove the [memory modules](#).
8. Remove the [wireless card](#).
9. Remove the [system-board assembly](#).
10. Remove the [heat-sink assembly](#).

Procedure


Steps

1. Open the latch and disconnect the keyboard backlight cable from the system board.
2. Peel the status-light board cable and keyboard backlight cable off the touch pad.
3. Peel off the tape that secures the touch pad to the palm rest and keyboard assembly.




- | | |
|-----------------------------|------------------------------------|
| 1. touch-pad cable | 2. latch |
| 3. tape | 4. touch pad |
| 5. keyboard backlight cable | 6. palm rest and keyboard assembly |

4. Remove the screws that secure the touch-pad bracket to the palm rest and keyboard assembly.
5. Lift the touch-pad bracket off the palm rest and keyboard assembly.



- | | |
|--------------------|------------------------------------|
| 1. M2x2 screws (3) | 2. touch-pad bracket |
| 3. touch pad | 4. palm rest and keyboard assembly |

6. Remove the screws that secure the touch pad to the palm rest and keyboard assembly.
7. Lift the touch pad off the palm rest and keyboard assembly.



- a. M2x2 screws (4)
- b. palm rest and keyboard assembly
- c. touch pad

Replacing the touchpad

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

About this task

NOTE: Ensure that the touch pad is aligned with the guides available on the palm-rest and keyboard assembly, and the gap on either sides of the touch pad is equal.

Steps

1. Align the screw holes on the touch pad with the screw holes on the palm rest and keyboard assembly.
2. Replace the screws that secure the touch pad to the palm rest and keyboard assembly.
3. Adhere the status-light board cable to the touch pad.
4. Align the screw holes on the touch-pad bracket with the screw holes on the palm rest and keyboard assembly.
5. Replace the screws that secure the touch-pad bracket to the palm rest and keyboard assembly.
6. Adhere the tape that secures the touch pad to the palm rest and keyboard assembly.
7. Slide both ends of the touch-pad cable into their respective connectors and close the latches to secure the cable.
8. Slide the keyboard backlight cable into the connector and close the latch to secure the cable.

Post-requisites

Steps

1. Replace the [heat-sink assembly](#).
2. Replace the [system-board assembly](#).
3. Replace the [wireless card](#).
4. Replace the [memory modules](#).
5. Follow the procedure from step 3 to step 4 in "[Replacing the status-light board](#)".
6. Replace the [battery](#).
7. Replace the [hard drive](#).
8. Replace the [I/O board](#).
9. Replace the [base cover](#).
10. Replace the [optical drive](#).

Removing the display assembly

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [wireless card](#).

Procedure

Steps


1. Remove the battery cable from the system board.
2. Note the display cable routing and remove the cable from its routing guides.
3. Lift the latch and disconnect the display cable from the system board.



1. display cable
3. latch

2. system board
4. routing guides


4. Remove the screws that secure the display hinges to the palm rest and keyboard assembly.
5. Open the display hinges.



- 1. M2.5x5 screws (4)
- 3. display assembly

- 2. display hinges (2)
- 4. palm rest and keyboard assembly

6. Lift the palm rest and keyboard assembly off the display assembly.



- a. display hinges (2)
- b. palm rest and keyboard assembly
- c. display assembly

Replacing the display assembly

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

Steps

1. Place the palm rest and keyboard assembly on the display assembly.
2. Using the alignment posts, press the display hinges down on the palm rest and keyboard assembly.
3. Replace the screws that secure the display hinges to the palm rest and keyboard assembly.
4. Route the display cable through the routing guides on the palm rest and keyboard.
5. Slide the display cable to the connector on the system board and close the latch to secure the cable.
6. Slide the battery cable to the connector on the system board.

Post-requisites

Steps

1. Replace the [wireless card](#).
2. Replace the [optical drive](#).
3. Replace the [base cover](#).

Removing the display bezel

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [display assembly](#).

Procedure

Steps

1. Using a plastic scribe, carefully pry up the inside edge of the display bezel.
2. Remove the display bezel off the display back-cover.



- a. display back-cover
- b. display bezel
- c. plastic scribe

Replacing the display bezel

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

About this task

Align the display bezel with the display back-cover, and gently snap the display bezel into place.

Post-requisites

Steps

1. Replace the [display assembly](#).
2. Replace the [base cover](#).
3. Replace the [optical drive](#).

Removing the camera

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [display assembly](#).
4. Remove the [display bezel](#).

Procedure

Steps

1. Using a plastic scribe, pry the camera module from the display assembly.
2. Lift the camera off the display assembly.
3. Disconnect the camera cable from the camera module.



1. plastic scribe
3. camera cable

2. camera module
4. display assembly

Replacing the camera

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

Steps

1. Connect the camera cable to the camera module.
2. Using the alignment post adhere the camera module on the display assembly and snap it into place.

Post-requisites

Steps

1. Replace the [display bezel](#).
2. Replace the [display assembly](#).
3. Replace the [base cover](#).
4. Replace the [optical drive](#).

Removing the display panel

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [display assembly](#).
4. Remove the [display bezel](#).

Procedure


Steps

1. Remove the screws that secure the display panel to the display back-cover.
2. Lift the display panel gently and turn it over.



- a. M2x3 screws (4)
 - b. display panel
 - c. display back-cover
3. Peel the tape adhering the display cable to the back of the display panel.
 4. Lift the latch and disconnect the display cable from the display-panel cable connector.

5. Lift the display panel away from the display back-cover.



- 1. display panel
- 3. display cable
- 5. latch

- 2. tape
- 4. display back-cover

Replacing the display panel

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

Steps

1. Connect the display cable to the display-panel connector at the back of the display panel.
2. Adhere the tape that secures the display cable to the back of the display panel.
3. Place the display panel gently on the display back-cover.
4. Align the screw holes on the display panel with the screw holes on the display back-cover.
5. Replace the screws that secure the display panel to the display back-cover.

Post-requisites

Steps

1. Replace the [display bezel](#).
2. Replace the [display assembly](#).
3. Replace the [base cover](#).
4. Replace the [optical drive](#).

Removing the display hinges

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [display assembly](#).
4. Remove the [display bezel](#).
5. Remove the [display panel](#).

Procedure

Steps

1. Remove the screws that secure the display hinges to the display back-cover.
2. Remove the screws that secure the display-hinge brackets to the display back-cover.
3. Lift the display-hinge brackets off the display back-cover.



1. M2x3 screws (2)
3. display hinges (2)

2. display-hinge brackets (2)
4. M2.5x3 screws (6)

5. display back-cover

Replacing the display hinges

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

Steps

1. Align the screw holes on the display-hinge brackets with the screw holes on the display back-cover.
2. Align the screw holes on the display hinges with the screw holes on the display back-cover.
3. Replace the screws that secure the display hinges to the display back-cover.

Post-requisites

Steps

1. Replace the [display panel](#).
2. Replace the [display bezel](#).
3. Replace the [display assembly](#).
4. Replace the [base cover](#).
5. Replace the [optical drive](#).

Removing the display cable

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [display assembly](#).
4. Remove the [display bezel](#).
5. Remove the [display panel](#).
6. Remove the [display hinges](#).

Procedure

Steps

1. Disconnect the camera cable from the connector on the camera module.
2. Peel off the tape that secures the camera cable to the display back-cover.
3. Peel off the tape that secures the display cable to the display back-cover.
4. Note the display cable routing and remove the display cable from the display back-cover.



1. display back-cover
3. tapes (2)

2. display cable
4. camera module

5. camera cable

Replacing the display cable

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

Steps

1. Route the display cable through the routing guides on the display back-cover.
2. Adhere the tapes that secure the display cable to the display back-cover.
3. Slide the camera cable into the connector on the camera module to secure the cable.

Post-requisites

Steps

1. Replace the [display hinges](#).
2. Replace the [display panel](#).
3. Replace the [display bezel](#).
4. Replace the [display assembly](#).
5. Replace the [base cover](#).
6. Replace the [optical drive](#).

Removing the display back-cover and antenna assembly

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [display assembly](#).
4. Remove the [display bezel](#).
5. Remove the [display panel](#).
6. Remove the [display hinges](#).
7. Remove the [display cable](#).
8. Remove the [camera](#).

Procedure

About this task

After performing all the prerequisites, we are left with the display back-cover and antenna assembly.



1. display back-cover and antenna assembly

Replacing the display back-cover and antenna assembly

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

About this task

Place the display back-cover on a flat surface.

Post-requisites

Steps

1. Replace the [camera](#).
2. Replace the [display cable](#).
3. Replace the [display hinges](#).
4. Replace the [display panel](#).
5. Replace the [display bezel](#).
6. Replace the [display assembly](#).
7. Replace the [base cover](#).
8. Replace the [optical drive](#).

Removing the power-button module

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [I/O board](#).
4. Remove the [hard drive](#).
5. Remove the [battery](#).
6. Remove the [memory modules](#).
7. Remove the [wireless card](#).
8. Remove the [system-board assembly](#).
9. Remove the [heat-sink assembly](#).
10. Remove the [display panel](#).

Procedure

Steps

1. Remove the screw that secures the power-button board to the palm rest and keyboard assembly.
2. Peel off the tape that secures the power-button board to the palm rest and keyboard assembly.
3. Remove the power-button board cable from the routing guides.
4. Lift the power-button board at an angle along with the cable off the palm rest and keyboard assembly.



- 1. tape
- 2. M2x2 Big Head screw
- 3. power-button board
- 4. palm rest and keyboard assembly
- 5. power-button board cable

Replacing the power-button module

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

Steps

1. Align the screw hole on the power-button board with the screw hole on the palm rest and keyboard assembly.
2. Adhere the power-button board cable to the palm rest and keyboard assembly.
3. Adhere the tape that secures the power-button board to the palm rest and keyboard assembly.
4. Replace the screw that secures the power-button board to the palm rest and keyboard assembly.

Post-requisites

Steps

1. Replace the [display panel](#).
2. Replace the [heat-sink assembly](#).
3. Replace the [system-board assembly](#).
4. Replace the [wireless card](#).
5. Replace the [memory modules](#).
6. Replace the [battery](#).
7. Replace the [hard drive](#).
8. Replace the [I/O board](#).
9. Replace the [base cover](#).
10. Replace the [optical drive](#).

Removing the power-adapter port

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [I/O board](#).
4. Remove the [hard drive](#).
5. Remove the [battery](#).
6. Remove the [status-light board](#).
7. Remove the [memory modules](#).
8. Remove the [wireless card](#).
9. Remove the [system-board assembly](#).
10. Remove the [heat-sink assembly](#).
11. Remove the [display panel](#).

Procedure

Steps

1. Remove the screw that secures the power-adapter port to the palm rest and keyboard assembly.
2. Remove the power-adapter port cable from the routing guides on the palm rest and keyboard assembly.
3. Lift the power-adapter port along with its cable off the palm rest and keyboard assembly.



- 1. power-adapter port
- 3. routing guides
- 5. palm rest and keyboard assembly

- 2. M2x3 screw
- 4. power-adapter port cable

Replacing the power-adapter port

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

Steps

1. Place the power-adapter port into the slot on the palm rest and keyboard assembly.
2. Align the screw hole on the power-adapter port with the screw hole on the palm rest and keyboard assembly.
3. Replace the screw that secures the power-adapter port to the palm rest and keyboard assembly.
4. Route the power-adapter port cable through the routing guides on the palm rest and keyboard assembly.

Post-requisites

Steps

1. Replace the [display panel](#).
2. Replace the [heat-sink assembly](#).
3. Replace the [system-board assembly](#).
4. Replace the [wireless card](#).
5. Replace the [memory modules](#).
6. Replace the [status-light board](#).
7. Replace the [battery](#).
8. Replace the [hard drive](#).
9. Replace the [I/O board](#).
10. Replace the [base cover](#).
11. Replace the [optical drive](#).

Removing the palm-rest and keyboard assembly

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Prerequisites


Steps

1. Remove the [optical drive](#).
2. Remove the [base cover](#).
3. Remove the [I/O board](#).
4. Remove the [hard drive](#).
5. Remove the [battery](#).
6. Remove the [status-light board](#).
7. Remove the [memory modules](#).
8. Remove the [wireless card](#).
9. Remove the [coin-cell battery](#).
10. Remove the [system-board assembly](#).
11. Remove the [heat-sink assembly](#).
12. Remove the [touch pad](#).
13. Remove the [speakers](#).
14. Remove the [display back-cover and antenna assembly](#).
15. Remove the [power-button module](#).
16. Remove the [power-adaptor port](#).

Procedure

About this task

After performing the steps in prerequisites, we are left with the palmrest.



1. palmrest

Replacing the palm-rest and keyboard assembly

NOTE: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before working inside your computer](#). After working inside your computer, follow the instructions in [After working inside your computer](#). For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.

Procedure

About this task

Place the palmrest on a flat surface.

Post-requisites

Steps

1. Replace the [power-adaptor port](#).
2. Replace the [power-button module](#).
3. Replace the [display back-cover and antenna assembly](#).
4. Replace the [speakers](#).
5. Replace the [touch pad](#).
6. Replace the [heat-sink assembly](#).
7. Replace the [system-board assembly](#).
8. Replace the [coin-cell battery](#).
9. Replace the [wireless card](#).
10. Replace the [memory modules](#).
11. Replace the [status-light board](#).
12. Replace the [battery](#).
13. Replace the [hard drive](#).
14. Replace the [I/O board](#).
15. Replace the [base cover](#).
16. Replace the [optical drive](#).

Troubleshooting

Diagnostics

Power and battery-status light/hard-drive activity light

Indicates the battery-charge status or the hard-drive activity.

i **NOTE:** Press Fn+H to toggle this light between power and battery-status light and hard-drive activity light.

Hard-drive activity light

Turns on when the computer reads from or writes to the hard drive.

Power and battery-status light

Indicates the power and battery-charge status.

Solid white — Power adapter is connected and the battery has more than 5 percent charge.

Amber — Computer is running on battery and the battery has less than 5 percent charge.

Off

- Power adapter is connected and the battery is fully charged.
- Computer is running on battery and the battery has more than 5 percent charge.
- Computer is in sleep state, hibernation, or turned off.

The power and battery-status light blinks amber along with beep codes indicating failures.

For example, the power and battery-status light blinks amber two times followed by a pause, and then blinks white three times followed by a pause. This 2,3 pattern continues until the computer is turned off indicating no memory or RAM is detected.

The following table shows the different power and battery-status light patterns and the problems that each light pattern indicate.

Table 1. Light patterns

Light pattern	Problem description
2,1	CPU failure
2,2	System board: BIOS and ROM failure
2,3	No memory or RAM detected
2,4	Memory or RAM failure
2,5	Invalid memory installed
2,6	System board or chipset error
2,7	LCD failure
3,1	CMOS battery failure
3,2	PCI or video card or chip failure
3,3	Recovery image not found
3,4	Recovery image found but invalid

Camera status light: Indicates whether the camera is in use.

- Solid white — Camera is in use.
- Off — Camera is not in use.

Caps Lock status light: Indicates whether Caps Lock is enabled or disabled.

- Solid white — Caps Lock enabled.
- Off — Caps Lock disabled.

Dell Enhanced Pre-Boot System Assessment (ePSA) diagnostic 3.0

For more details, see [Dell EPSA Diagnostic 3.0](#).

Handling swollen Lithium-ion batteries

Like most laptops, Dell laptops use lithium-ion batteries. One type of lithium-ion battery is the lithium-ion polymer battery. Lithium-ion polymer batteries have increased in popularity in recent years and have become standard in the electronics industry due to customer preferences for a slim form factor (especially with newer ultra-thin laptops) and long battery life. Inherent to lithium-ion polymer battery technology is the potential for swelling of the battery cells.

Swollen battery may impact the performance of the laptop. To prevent possible further damage to the device enclosure or internal components leading to malfunction, discontinue the use of the laptop and discharge it by disconnecting the AC adapter and letting the battery drain.

Swollen batteries should not be used and should be replaced and disposed of properly. We recommend contacting Dell product support for options to replace a swollen battery under the terms of the applicable warranty or service contract, including options for replacement by a Dell authorized service technician.

The guidelines for handling and replacing Lithium-ion batteries are as follows:

- Exercise caution when handling Lithium-ion batteries.
- Discharge the battery before removing it from the system. To discharge the battery, unplug the AC adapter from the system and operate the system only on battery power. When the system will no longer power on when the power button is pressed, the battery is fully discharged.
- Do not crush, drop, mutilate, or penetrate the battery with foreign objects.
- Do not expose the battery to high temperatures, or disassemble battery packs and cells.
- Do not apply pressure to the surface of the battery.
- Do not bend the battery.
- Do not use tools of any type to pry on or against the battery.
- If a battery gets stuck in a device as a result of swelling, do not try to free it as puncturing, bending, or crushing a battery can be dangerous.
- Do not attempt to reassemble a damaged or swollen battery into a laptop.
- Swollen batteries that are covered under warranty should be returned to Dell in an approved shipping container (provided by Dell)—this is to comply with transportation regulations. Swollen batteries that are not covered under warranty should be disposed of at an approved recycling center. Contact Dell product support at <https://www.dell.com/support> for assistance and further instructions.
- Using a non-Dell or incompatible battery may increase the risk of fire or explosion. Replace the battery only with a compatible battery purchased from Dell that is designed to work with your Dell computer. Do not use a battery from other computers with your computer. Always purchase genuine batteries from <https://www.dell.com> or otherwise directly from Dell.

Lithium-ion batteries can swell for various reasons such as age, number of charge cycles, or exposure to high heat. For more information on how to improve the performance and lifespan of the laptop battery and to minimize the possibility of occurrence of the issue, see [Dell Laptop Battery - Frequently Asked Questions](#).

Getting help and contacting Dell

Self-help resources

You can get information and help on Dell products and services using these self-help resources:

Table 2. Self-help resources

Self-help resources	Resource location
Information about Dell products and services	www.dell.com
My Dell	
Tips	
Contact Support	In Windows search, type Contact Support , and press Enter.
Online help for operating system	www.dell.com/support/windows www.dell.com/support/linux
Troubleshooting information, user manuals, setup instructions, product specifications, technical help blogs, drivers, software updates, and so on.	www.dell.com/support
Dell knowledge base articles for a variety of computer concerns.	<ol style="list-style-type: none"> 1. Go to https://www.dell.com/support/home/?app=knowledgebase. 2. Type the subject or keyword in the Search box. 3. Click Search to retrieve the related articles.
Learn and know the following information about your product: <ul style="list-style-type: none"> • Product specifications • Operating system • Setting up and using your product • Data backup • Troubleshooting and diagnostics • Factory and system restore • BIOS information 	See <i>Me and My Dell</i> at www.dell.com/support/manuals . To locate the <i>Me and My Dell</i> relevant to your product, identify your product through one of the following: <ul style="list-style-type: none"> • Select Detect Product. • Locate your product through the drop-down menu under View Products. • Enter the Service Tag number or Product ID in the search bar.

Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see www.dell.com/contactdell.

 **NOTE:** Availability varies by country and product, and some services may not be available in your country.

 **NOTE:** If you do not have an active internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.