Dell Latitude 14 Rugged – 5404Series

Getting Started Guide



Notes, Cautions, and Warnings
i NOTE: A NOTE indicates important information that helps you make better use of your computer.
CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.
NOTE: A WARNING indicates a potential for property damage, personal injury, or death.
Copyright © 2015 Dell Inc. All rights reserved. This product is protected by U.S. and international copyright and intellectual property laws. Dell™ and the Dell logo are trademarks of Dell Inc. in the United States and/or other jurisdictions. All other marks and names
mentioned herein may be trademarks of their respective companies.

Contents

1 Finding Information and Resources	
2 Front and Back View	5
3 Quick Setup	7
4 Removing and Installing Components	8
Opening the Hard Drive Bay Doors	8
Closing The Hard Drive Bay Doors	8
Removing the Battery	8
Installing the Battery	9
Removing the hard drive	
Installing the Hard Drive	9
5 Using the Backlit Keyboard	10
Turning the Keyboard Backlight On/Off or Adjusting Brightness	10
Changing the Keyboard Backlight Color	
Customizing the Backlit Keyboard in System Setup (BIOS)	
Function Fn key lock features	11
6 Stealth Mode	12
Turning stealth mode on/off	12
Disabling Stealth Mode in the System Setup (BIOS)	12
7 Enabling and Disabling Wireless (WiFi) Feature	13
8 Smart Cards	14
9 Specifications	15
Information para NOM (únicamente para México)	19
10 Contacting Dell	20

Finding Information and Resources

See the safety and regulatory documents that shipped with your computer and the regulatory compliance website at **www.dell.com/regulatory_compliance** for more information on:


- · Safety best practices
- · Regulatory certification
- · Ergonomics

See **www.dell.com** for additional information on:

- · Warranty
- · Terms and Conditions (U.S. only)
- · End User License Agreement

Additional information on your product is available at www.dell.com/support/manuals

Front and Back View



- 1. Display latch
- 3. Privacy shutter (optional)
- 5. Camera-status light (optional)
- 7. Outdoor readable display/touchscreen (optional)
- 9. Stylus
- 11. USB 2.0 Connector
- 13. Optical Disk Drive

- 2. Microphone
- 4. Camera (optional)
- 6. Speaker
- 8. Power button
- 10. SD Card reader
- 12. USB 3.0 Connector (optional)
- 14. Smartcard reader (optional)

15. Fingerprint reader (optional)

PC/ExpressCard Reader
 Battery status light
 Power status light
 Power status light
 Power Connector
 VGA output
 Vireless status light
 Power Connector
 VGA Serial Connector

25. VGA output 24. Serial Connector 25. USB 2.0 Connector 26. Network Connector

27. Security-cable slot 28. Secondary Network Connector (optional)

29. Secondary serial connector (optional) / Fischer power connector 30. Touchpad (optional)

31. Battery32. USB 3.0 connector33. HDMI Connector34. SIM Card slot

35. Audio output 36. External antenna pass-through interface

37. Docking interface 38. Service tag label

NOTE: Do not block, push objects into, or allow dust to accumulate in the air vents. Do not store your Dell computer in a low-airflow environment, such as a closed briefcase, while it is running. Restricting the airflow can damage the computer or cause a fire. The computer turns on the fan when the computer gets hot. Fan noise is normal and does not indicate a problem with the fan or the computer.

16. Hard drive

Quick Setup

- NOTE: Before you begin any of the procedures in this section, read the safety information that shipped with your computer. For additional best practices information, see www.dell.com/regulatory_compliance
- NOTE: The AC adapter works with electrical outlets worldwide. However, power connectors and power strips vary among countries. Using an incompatible cable or improperly connecting the cable to the power strip or electrical outlet may cause fire or equipment damage.
- CAUTION: When you disconnect the AC adapter cable from the computer, grasp the connector, not the cable itself, and pull firmly but gently to avoid damaging the cable. When you wrap the AC adapter cable, ensure that you follow the angle of the connector on the AC adapter to avoid damaging the cable.
- i NOTE: Some devices may not be included if you did not order them.
- 1. Connect the AC adapter to the AC adapter connector on the computer and to the electrical outlet.



Figure 1. AC Adapter

2. Connect the network cable (optional).




Figure 2. Network Connector

3. Connect USB devices, such as a mouse or keyboard (optional).




Figure 3. USB Connector

4. Open the computer display and press the power button to turn on the computer.



Figure 4. Power Button


NOTE: It is recommended that you turn on and shut down your computer at least once before you install any cards or connect the computer to a docking device or other external device, such as a printer.

Removing and Installing Components

Opening the Hard Drive Bay Doors

There are six press-latch doors. Two on the right side, two on the left and two on back side of the computer.

- 1. Hold the latch button down.
- 2. Pull the door open and away from the computer.




Closing The Hard Drive Bay Doors

Follow the steps below to close the press-latch doors:


- 1. Rotate the door back towards the computer.
- 2. Press firmly on the door until a click is heard and latch is engaged.

Removing the Battery

- WARNING: Using an incompatible battery may increase the risk of fire or explosion. Replace the battery only with a compatible battery purchased from Dell. The battery is designed to work with your Dell computer. Do not use a battery from any other computer with your computer.
- WARNING: Before removing or replacing the battery, turn off the computer, disconnect the AC adapter from the electrical outlet and the computer, disconnect the modem from the wall connector and computer, and remove any other external cables from the computer.
- **MARNING:** Not for use in hazardous locations. See installation instructions.
- 1. Hold the latch button down.
- 2. Pull the door open and away from the computer to expose the battery compartment.



- **3.** To remove the battery:
 - a) Push and hold the battery release button to the right while pulling on the plastic battery tab




Installing the Battery

- 1. Slide the battery into its slot until it clicks into place.
- 2. Press firmly on the door until a click is heard and latch is engaged.

Removing the hard drive

- 1. Push the latch button down.
- 2. Pull the door open and away from the computer to expose the hard drive compartment
- 3. To remove the hard drive:
 - a) Push and hold the hard drive release button to the left while pulling on the plastic hard drive tab.



Installing the Hard Drive

- 1. Push the hard drive into its compartment until it snaps in place.
- 2. Press firmly on the door until a click is heard and latch is engaged.

Using the Backlit Keyboard

The Latitude rugged series comes equipped with a backlit keyboard that can be customized. The system comes with the following colors enabled:

- 1. White
- 2. Red
- 3. Green
- 4. Blue

Alternatively, the system can be configured with 2 additional custom colors in the System Setup (BIOS)


Topics:

- Turning the Keyboard Backlight On/Off or Adjusting Brightness
- · Changing the Keyboard Backlight Color
- Customizing the Backlit Keyboard in System Setup (BIOS)
- · Function Fn key lock features

Turning the Keyboard Backlight On/Off or Adjusting Brightness

To turn backlight On/Off or adjust the backlight brightness settings, perform the steps:


- 1. Press <Fn> + <F10> (Fn key not needed if function key <Fn> lock is activated) to initialize the keyboard backlight switch.
- 2. The first use of the above key combination will turn on the backlight to its lowest setting.
- 3. Additional pressing of the key combinations will cycle the brightness settings through 25%, 50%,75% and 100%.
- 4. Cycle through the key combination to either adjust the brightness or completely turn off the keyboard backlight.



Changing the Keyboard Backlight Color

To change the keyboard backlight color:

- 1. Press <FN> + < C> keys to cycle through the available backlight colors.
- 2. White, Red, Green and Blue are active by default; up to two custom colors can be added to the cycle in the System Setup (BIOS).



Customizing the Backlit Keyboard in System Setup (BIOS)

- 1. Power off the computer.
- 2. Power on the computer and at the Dell logo, tap the <F2> key repeatedly to bring up the system setup menu.
- 3. Expand and open the **System Configuration** menu.
- 4. Select RGB Keyboard Backlight.
 - You can enable/disable the standard colors (White, Red, Green and Blue).
- 5. To set a custom RGB value, use the input boxes on the right side of the screen.
- 6. Click Apply changes and click Exit close the system setup.

Function Fn key lock features

NOTE: The keyboard has Function key Fn lock capability. When activated, the secondary functions on the top row of keys become default and will not require use of the Fn key.




Figure 5. Fn key callouts

- 1. Fn lock key
- 2. Affected Fn keys
- 3. Fn key
- NOTE: Fn lock affects only the above keys (F1 to F12). Secondary functions will not require the Fn key to be pressed while enabled.

Stealth Mode

Latitude fully rugged products come equipped with a Stealth mode. Stealth mode allows you to turn off the Display, all the LED lights, internal speakers, the fan and all wireless radios with a single key combination.


NOTE: This mode is aimed at using the computer in covert operations. When the stealth mode is activated, the computer remains functional but will not emit any light or sound.

Topics:

- Turning stealth mode on/off
- · Disabling Stealth Mode in the System Setup (BIOS)

Turning stealth mode on/off

- 1. Press the Fn+F7 key combination (Fn key not needed if Fn lock is enabled) to turn on stealth mode.
 - NOTE: Stealth mode is a secondary function of the F7 key. The key can be used to perform other functions on the computer when not used with the Fn key to enable stealth mode.
- 2. All the lights and sounds are turned off.
- 3. Press the Fn+F7 key combination again to turn off the stealth mode.




Disabling Stealth Mode in the System Setup (BIOS)

- 1. Power off the computer.
- 2. Power on the computer and at the Dell logo, tap the <F2> key repeatedly to bring up the System Setup menu.
- 3. Expand and open the **System Configuration** menu.
- 4. Select Stealth Mode Control.
 - i NOTE: Stealth mode is enabled by default.
- 5. Select **Disable** to disable the stealth mode.
- 6. When complete, Apply changes and Exit the BIOS or system setup.

Enabling and Disabling Wireless (WiFi)Feature

- 1. To enable wireless network, press the <Fn>+ <PrtScr> keys.
- 2. Press the <Fn> +< PrtScr> keys again to disable wireless networking.



Smart Cards

There are two main types of Smart or Common Access Cards (CAC):

- 1. Enclosed Smart Cards These cards have a contact area with many gold plated connection pads. When inserted into a card reader, the information from the chip can be read and written
 - Insert the card into the smart card slot with the gold contact pad facing upward and pointing toward the smart card slot. Slide the card into the slot until it is fully seated in its connector.
- 2. Contactless Smart Cards These cards do not require any physical contact with the reader. The chip communicates with the card reader through RFID induction technology.

These cards require only close proximity to an antenna of a card reader to complete transactions.

Specifications

NOTE: Offerings may vary by region. For more information regarding the configuration of your computer, click Start (Start icon) > Help and Support, and then select the option to view information about your computer.

Table 1. System Information

Feature	Specification
Chipset	Intel Mobile Express Series 6 chipset
DRAM bus width	64-bit
Flash EPROM	SPI 32 Mbits
PCle Gen1 bus	100 MHz

Table 2. Processor

Feature	Specification
Types	 Intel Core i3 series Intel Core i5 series Intel Core i7 series
L3 cache	up to 4 MB
External bus frequency	1600 MHz

Table 3. Memory

Feature	Specification	
Memory connector	two SODIMM slots	
Memory capacity	4 GB, or 8 GB	
Memory type	DDR3 SDRAM 1600 Mhz	
Minimum memory	4 GB	
Maximum memory	16 GB	

Table 4. Audio

Feature	Specification
Туре	four-channel high definition audio
Controller	Realtek ALC3226
Stereo conversion	24-bit (analog-to-digital and digital-to-analog)
Interface:	
Internal	HD audio
External	microphone-in/stereo headphones/external speakers connector
Speakers	one mono speaker
Internal speaker amplifier	2W (RMS)
Volume controls	Volume Up/Volume Down buttons

CAUTION: Excessive sound pressure from earphones or headphones can cause hearing damage or loss. Adjustment of the volume control as well as the equalizer to settings other than the center position may increase the earphone or headphones output voltage, and therefore the sound pressure level. The use of factors influencing the earphones or headphones output other than those specified by the manufacturers (e.g. operating system, equalizer software, firmware, driver etc.) may increase the earphones or headphones output voltage and therefore the sound pressure level. The use of earphones and headphones other than those specified by the manufacturer may lead to heightened sound pressure level.

Table 5. Video

Feature	Specification
Туре	integrated on system board
Controller	
UMA	
Intel Core i3/i5	Intel HD Graphics 4400
Intel Core i7	Intel HD Graphics 5000
Discrete (Optional)	Nvidia GeForce (N14M-GE) Discrete Graphics Card, 2 GB Graphics

Table 6. Communications

Feature	Specification	
Network adapter	10/100/1000 MB/s Ethernet (RJ-45)	
Wireless	WLAN with Bluetooth 4.0	
	WWAN	

Table 7. Ports and Connectors

Feature	Specification
Audio (optional)	one microphone/stereo headphone/speaker connector
Video	one 15-pin VGA connectorone 19-pin HDMI connector
Network adapter	one RJ-45 connector (second optional)
USB 2.0	two 4-pin USB 2.0 compliant connector
USB 3.0	 one 9-pin USB 3.0 compliant connector one 9-pin USB 3.0 compliant connector with PowerShare
Memory card reader	one SD card reader
Expansion card	one ExpressCard readeroptional PCMCIA reader (replaces ExpressCard reader)
Serial	one DB9 serial connector (second optional)
Docking port	one
Subscriber Identity Module (SIM) port	one micro-SIM slot with security feature

Table 8. Display

Feature	Specification
Туре	WLED display
Size	14.0 inches
Dimensions:	
Height	190.00 mm (7.48 inches)

Feature	Specification
Width	323.5 mm (12.59 inches)
Diagonal	375.2 mm (14.77 inches)
Active area (X/Y)	309.4 mm x 173.95 mm
Maximum resolution	1366 x 768 pixels
Operating angle	0° (closed) to 180°
Refresh rate	60 Hz
Minimum Viewing angles:	
Horizontal	· +/- 70° for HD
Vertical	· +/- 70° for HD
Pixel pitch	1875 mm
Table 9. Keyboard	
Feature	Specification
Number of keys	84 keys: US English, Thai, French-Canadian, Korean, Russian, Hebrew, English-International
Layout	QWERTY/AZERTY/Kanji
Table 10. Touchpad	
Feature	Specification
Active Area:	
X-axis	99.5 mm
Y-axis	53 mm
Table 11. Battery	
Feature	Specification
Туре	6-cell or 9-cell "smart" lithium ion
Dimensions:	
Height	21 mm (0.82 inches)
Width	166.9 mm (6.57 inches)
Depth	80 mm (3.14 inches)
Weight	6-cell : 365.5 g (0.80 lbs) ; 9-cell : 520 g (1.14 lbs)
Voltage	14.8 VDC
Life span	300 discharge/charge cycles
Temperature range:	
Operating	 Charging: 0 °C to 60 °C (32 °F to 140 °F) Discharging: 0 °C to 70 °C (32 °F to 158 °F)
Non-Operating	-51 °C to 71 °C (-60 °F to 160 °F) (i) NOTE: The battery pack is capable of safely withstanding the above storage temperatures with 100% charge.
	i NOTE: The battery pack is also capable of withstanding storage temperatures from -20 °C to +60 °C with no degradation in its performance.
Coin-cell battery	3V CR2032 lithium coin cell

Table 12. AC Adapter

Type 65 W/90 W

Input voltage 100 VAC to 240 VAC

Input current (maximum) 1.5A / 1.7A
Input frequency 50 Hz to 60 Hz
Output power 65 W/90 W

Output current 3.34 A/4.62 A(continuous)

Rated output voltage 19.5 +/- 1.0 VDC

Temperature range:

Operating 0 °C to 40 °C (32 °F to 104 °F)

Non-Operating -40 °C to 70 °C (-40 °F to 158 °F)

Table 13. Auto-air Adapter

Type 90 W

Input voltage 11 VDC to 16 VDC

Input current (maximum) 9.0 A
Output power 90 W

Output current 4.86 A(continuous)
Rated output voltage 19.5 +/- 1.0 VDC

Temperature range:

Operating 0 °C to 35 °C (32 °F to 95 °F)

Table 14. Physical

Feature	Specification
Height	44 mm (1.73 inches)
Width	347 mm (13.66 inches)
Depth	243 mm (9.57 inches)
Weight	6.5 lbs (2.95 kg)

Table 15. Environmental

Feature	Specification
Temperature:	
Operating	-29 °C to 63 °C (-20 °F to 140 °F)
Storage	-51 °C to 71 °C (-60 °F to 160 °F))
Relative humidity (maximum):	
Operating	10 % to 90 % (non condensing)
Storage	5 % to 95 % (non condensing)
Altitude (maximum):	
Operating	-15.24 m to 4572 (-50 ft to 15,000 ft)3048 2000 (–50 ft to 10,000 ft 6560 ft)
Non-Operating	'-15.24 m to 4572 (-50 ft to 15,000 ft)
Airborne contaminant level	G1 as defined by ISA-71.04–1985

Topics:

· Information para NOM (únicamente para México)

Information para NOM (únicamente para México)

The following information is provided on the device described in this document in compliance with the requirements of the official Mexican standards (NOM).

Table 16. NOM Information

Voltaje de alimentación 100 VAC – 240 VAC

Frecuencia 50 Hz - 60 Hz

Consumo eléctrico 1,5 A/1,7 A

Voltaje de salida 19,50 V de CC

Intensidad de salida 3,34 A/4,62 A

Contacting Dell

NOTE: If you do not have an active internet connection, you can find the contact information on your purchase invoice, packing slip, bill, or Dell product catalog.

Dell provides several online and telephone-based support and service options. Availability varies by country and product, and some services may not be available in your area. To contact Dell for sales, technical support, or customer service issues:

Go to Dell.com/contactdell.