

# CHANGING THE DEFAULT ADMINISTRATOR PASSWORD

デフォルト管理者パスワードの変更



---

**Information in this document is subject to change without notice.**

**© 2001 Dell Computer Corporation. All rights reserved. Printed in Malaysia  
Printed on recycled paper**

Trademarks used in this text: *Dell*, the *DELL* logo, and *PowerVault* are trademarks of Dell Computer Corporation. *Microsoft* and *Windows* are registered trademarks of Microsoft Corporation. Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Computer Corporation disclaims any proprietary interest in trademarks and trade names other than its own.

---

本書の内容は予告なく変更されることがあります。

© 2001 すべての著作権は Dell Computer Corporation にあります。Printed in Malaysia  
Printed on recycled paper

本書に使用されている商標 : Dell、DELL のロゴおよび PowerVault は、Dell Computer Corporation の商標です。Microsoft および Windows は、Microsoft Corporation の登録商標です。本書では、上記記載以外の商標や会社名が使用されている場合があります。これらの商標や会社名は、一切 Dell Computer Corporation に所属するものではありません。

2001 年 2 月 P/N 2E055 Rev. A01



# Changing the Default Administrator Password for Dell™ PowerVault™ 735N NAS Appliances

This document describes how to change the Microsoft® Windows® default administrator password for your PowerVault 735N network attached storage (NAS) appliance.

## Default Administrator Account Information

The default administrator password for your PowerVault system, in its original configuration, is `powervault`.

**NOTICE: For improved system security, Dell recommends that you change the administrator password after completing the initial configuration of your system.**

## Changing the Administrator Password

Your system, in its original configuration, has a set of default accounts. Only the administrator account has administrative privileges. By default, the administrator account is set to use the user name `administrator`, with the password `powervault`.

You must enter this administrator account information when you connect to the PowerVault NAS Manager in order to have administrator privileges. Leave the **Domain** field blank unless you are logging on using a domain administrator account. To log on as a domain administrator, enter the domain administrator user name, password, and domain.



*NOTE: If an administrator adds a domain account to the local administrators group, the domain user may access and administer the system. However, the administrator cannot use the **Change Administrator Password** page to change the (domain account) password. This page can only be used to change the local administrator's account password.*

**NOTICE: Any information you send from the NAS Manager can be viewed by others on the network. To prevent others from seeing your information, use the method explained in "Using Terminal Service Advanced Client to Send Encrypted Password Commands," found later in this document, to change the administrator password.**

To change the administrator password for the system, perform the following steps:

1. Connect to the PowerVault NAS Manager from a supported Web browser and enter the following in the browser address line:

`http://systemname:1278`

where *systemname* is *Dellservice tag number*. The line must appear in a format similar to this:

`http://Dell11234567:1278`

You also can enter:

`http://system_ipaddress:1278`

See the *System Administrator's Guide* for a list of supported Web browsers.

2. On the primary menu bar, click **Network Setup**.
3. On the **Network Setup** page, click **Change Administrator Password**.
4. Type the current administrator password in the **Current password** text box.
5. Type the new administrator password in the **New password** text box.



*NOTE: The new administrator password must conform to any password complexity rules in effect for the domain to which the appliance belongs.*

6. Type the new administrator password again in the **Confirm new password** text box.
7. Click **OK**.

## **Using Terminal Service Advanced Client to Send Encrypted Password Commands**



*NOTE: This procedure works only on a Windows client because the Terminal Service Advanced Client only works on Windows operating systems.*

This method sends encrypted text across the network to prevent others from seeing your administrator password.

1. Connect to the PowerVault NAS Manager from a supported Web browser using the information in step 1 of the previous procedure.
2. On the primary menu bar, click **Maintenance**.

3. On the **Maintenance** page, click **Terminal Server Advanced Client**.

The login dialog box appears.

4. Type `administrator` in the user name field, and `powervault` in the password field.

Leave the **Domain** field blank unless you are logging on using a domain administrator account. To log on as a domain administrator, enter the domain administrator user name, password and domain.



*NOTE: If the NAS appliance is in a domain, the local system administrator can add a domain user to the local administrators group. After this step is completed, the domain user has administrator access to the system. The local administrator can use the **Change Administrator Password** page to change only the local administrator password, but not the domain user password.*

5. From the **Advanced Administration Menu**, select **User Management**, found under **Administration Tools**.

A users window appears.

6. Right-click **Administrator** and select **Set Password** from the pop-up menu.

7. Type your new administrator password into the **New Password** and **Confirm Password** fields.

8. Click **OK**.

Your new administrator password is set.



# Dell™ PowerVault™ 735N NAS アプライアンスのデフォルト 管理者パスワードの変更

本書では、Microsoft® Windows® のデフォルトの管理者パスワードを、お使いの PowerVault 735N NAS (network attached storage) アプライアンス用に変更する方法について説明します。

## デフォルトの管理者アカウント情報

PowerVault システムに元から設定されているデフォルトの管理者パスワードは、`powervault` です。

注意：システムのセキュリティを向上させるため、システムの初期設定が完了したら管理者パスワードを変更するようお勧めします。

## 管理者パスワードの変更

システムには、元から設定されているデフォルトのアカウントセットがあります。管理者権限があるのは、管理者アカウントだけです。デフォルトの管理者アカウントは、ユーザ名として `administrator` を、パスワードとして `powervault` を使用するように設定されています。

管理者権限を取得するために PowerVault NAS Manager に接続する場合、この管理者アカウントの情報を入力する必要があります。ドメイン管理者アカウントを使用してログオンする場合以外は、[Domain (ドメイン)] フィールドは空欄にしておきます。ドメイン管理者としてログオンするには、ドメイン管理者のユーザ名、パスワード、およびドメインを入力します。



メモ：管理者がドメインアカウントをローカルの管理者グループに追加すると、ドメインユーザはシステムにアクセスしたり管理したりできます。ただし、管理者は [Change Administrator Password (管理者パスワードの変更)] ページを使用して (ドメインアカウントの) パスワードを変更すること

はできません。このページは、ローカルの管理者アカウントのパスワードを変更するときに限り使用できます。

注意：NAS Manager から送ったすべての情報は、誰でもネットワーク上で見ることができます。他人に情報を見られないようにするには、本書で後述の「Terminal Service Advanced Client を使用した暗号化パスワードコマンドの送信」で説明されている方法で管理者パスワードを変更します。

システムの管理者パスワードを変更するには、次の手順に従ってください。

1. サポートされている Web ブラウザから PowerVault NAS Manager に接続し、次の URL をブラウザのアドレスラインに入力します。

```
http://systemname:1278
```

systemname は、Dell のサービスタグナンバーです。URL は次のような形式になっている必要があります。

```
http://Dell1234567:1278
```

また、次のようにも入力できます。

```
http://system_ipaddress:1278
```

サポートされている Web ブラウザの一覧については、『System Administrator's Guide (システムアドミニストレータズガイド)』を参照してください。

2. プライマリメニューバーの [Network Setup (ネットワークの設定)] をクリックします。
3. [Network Setup (ネットワークの設定)] ページの [Change Administrator Password (管理者パスワードの変更)] をクリックします。
4. 現在の管理者パスワードを [Current password (現在のパスワード)] テキストボックスに入力します。
5. 新しい管理者パスワードを [New password (新しいパスワード)] テキストボックスに入力します。





メモ：新しい管理者パスワードは、アプライアンスが属しているドメインにおいて有効な複雑なパスワード規則のすべてに適合している必要があります。

6. 新しい管理者パスワードを [Confirm new password (新しいパスワードの確認)] テキストボックスに再度入力します。
7. [OK] をクリックします。

## Terminal Service Advanced Client を使用した暗号化パスワードコマンドの送信



メモ：Terminal Service Advanced Client が動作するのは Windows オペレーティングシステムだけなので、この手順は Windows クライアント専用となります。

この方法では、管理者パスワードを他人に見られないようにするため、暗号化テキストをネットワークを介して送信します。

1. 前述の手順 1 の内容を使用して、サポートされている Web ブラウザから PowerVault NAS Manager に接続します。
2. プライマリメニューバーの [Maintenance (メンテナンス)] をクリックします。
3. [Maintenance (メンテナンス)] ページの [Terminal Server Advanced Client (ターミナルサーバアドバンスドクライアント)] をクリックします。

ログインダイアログボックスが表示されます。

4. `administrator` をユーザ名フィールドに、`powervault` をパスワードフィールドに入力します。

ドメイン管理者アカウントを使用してログオンする場合以外は、[Domain (ドメイン)] フィールドは空欄にしておきます。ドメイン管理者としてログオンするには、ドメイン管理者のユーザ名、パスワード、およびドメインを入力します。



メモ：NAS アプライアンスがドメイン内にある場合、ローカルのシステム管理者は、ドメインユーザをローカルの管理者グループに追加できます。この手順を完了すると、ドメインユーザは管理者としてシステムにアクセスできるようになります。ローカル管理者は、[Change Administrator

Password（管理者パスワードの変更）ページを使用してローカルの管理者パスワードを変更できますが、ドメインユーザパスワードは変更できません。

5. [Advanced Administration Menu（詳細管理メニュー）] から [Administration Tools（管理ツール）] の [User Management（ユーザ管理）] を選択します。

ユーザウィンドウが表示されます。

6. [Administrator（管理者）] を右クリックして、ポップアップメニューから [Set Password（パスワードの設定）] を選択します。

7. 新しい管理者パスワードを [New Password（新しいパスワード）] フィールドおよび [Confirm Password（パスワードの確認）] フィールドに入力します。

8. [OK] をクリックします。

新しい管理者パスワードが設定されます。





02E055 A01

P/N 2E055 Rev. A01

Printed in Malaysia  
Printed on recycled paper

