iDRAC 8/7 v2.81.81.81 RACADM CLI Guide

2021
Rev. A00

DELL EMC

Notes, cautions, and warnings

NOTE: A NOTE indicates important information that helps you make better use of your product.

CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

© 2021 July Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

Contents

Chapter 1: Introduction **33**
New in this release 33
Supported RACADM Interfaces 33
RACADM Syntax Usage 34
SSH, Telnet, or Remote RACADM 34
Remote RACADM 34
Accessing Indexed-Based Device Groups and Objects 34
RACADM Command Options 35
Using autocomplete feature 36
Lifecycle Controller Log 37
Proxy parameters 37
Supported RACADM Subcommands 38
Other Documents You May Need 40
Accessing support content from the Dell EMC support site 40
Contacting Dell 41

Chapter 2: RACADM Subcommand Details **42**
Guidelines to Quote Strings Containing Special Characters When Using RACADM Commands 43
Help and help subcommand 44
arp 45
autoupdatescheduler 45
cd 47
cd 48
clearasrscreen 48
clearpending 48
closessn 49
clrsel 50
config 50
coredump 51
coredumpdelete 52
diagnostics 52
eventfilters 53
fcstatistics 55
frontpanelerror 55
fwupdate 56
get 61
getconfig 63
gethostnetworkinterfaces 66
getled 67
getniccfg 67
getraclog 69
getractime 71
getremoteservicesstatus 72
getsel 72

getsensorinfo....73
getssninfo....77
getsvctag....77
getsysinfo....78
gettracelog....80
getversion....81
hwinventory....83
ifconfig....87
inlettemphistory....87
jobqueue....89
krbkeytabupload....90
lclog....91
license....94
netstat....96
nicstatistics....96
ping....97
ping6....98
RACADM Proxy....98
racdump....100
racreset....104
racresetcfg....105
remoteimage....106
rollback....107
sensorsettings....108
serveraction....108
set....110
setled....113
setniccfg....114
sshpkauth....116
sslcertdownload....117
sslcertupload....118
sslcertview....118
sslcertdelete....120
sslcsrgen....121
sslkeyupload....122
sslresetcfg....122
storage....122
swinventory....142
systemconfig....143
systemerase....145
systemperfstatistics....146
techsupreport....147
testemail....148
testtrap....149
testalert....150
traceroute....150
traceroute6....151
update....151
usercertupload....154
usercertview....155

vflashsd....156
vflashpartition....156
vmdisconnect....157

Chapter 3: iDRAC Property Database Group and Object Descriptions....158
Displayable Characters....159
idRacInfo....160
idRacProductInfo (Read Only)....160
idRacDescriptionInfo (Read Only)....161
idRacVersionInfo (Read Only)....161
idRacBuildInfo (Read Only)....161
idRacName (Read Only)....161
iDRAC Type (Read Only)....161
cfgStaticLanNetworking....162
cfgNicStaticEnable (Read or Write)....162
cfgNicStaticIPv4Enable (Read or Write)....162
cfgNicStaticIpAddress (Read or Write)....163
cfgNicStaticUseDhcp (Read or Write)....163
cfgNicStaticNetmask (Read or Write)....163
cfgNicStaticGateway (Read or Write)....163
cfgDNSStaticServersFromDHCP (Read or Write)....164
cfgDNSStaticServer1 (Read or Write)....164
cfgDNSStaticServer2 (Read or Write)....164
cfgDNSStaticDomainName (Read or Write)....164
cfgDNSStaticDomainNameFromDHCP (Read or Write)....164
cfgRemoteHosts....165
cfgRhostsFwUpdateTftpEnable (Read or Write)....165
cfgRhostsFwUpdateIpAddr (Read or Write)....165
cfgRhostsFwUpdatePath (Read or Write)....165
cfgRhostsSmtpServerIpAddr (Read or Write)....166
cfgRhostsSyslogEnable (Read or Write)....166
cfgRhostsSyslogPort (Read or Write)....166
cfgRhostsSyslogServer1 Read or Write)....166
cfgRhostsSyslogServer2 Read or Write)....167
cfgRhostsSyslogServer3 Read or Write)....167
cfgUserAdmin....167
cfgUserAdminIndex - Read Only....167
cfgUserAdminIpmiLanPrivilege (Read or Write)....168
cfgUserAdminIpmiSerialPrivilege (Read or Write)....168
cfgUserAdminPrivilege - Read or Write....168
cfgUserAdminUserName - Read or Write....170
cfgUserAdminPassword - Write Only....170
cfgUserAdminEnable - Read or Write....170
cfgUserAdminSolEnable (Read or Write)....171
cfgEmailAlert....171
cfgEmailAlertIndex - Read Only....171
cfgEmailAlertEnable - Read or Write....171
cfgEmailAlertAddress - Read or Write....172
cfgEmailAlertCustomMsg (Read or Write)....172
cfgEmailAlertEmailName - Read Only....172

cfgSessionManagement....172
cfgSsnMgtRacadmTimeout (Read or Write)....172
cfgSsnMgtConsRedirMaxSessions (Read or Write)....173
cfgSsnMgtWebserverTimeout (Read or Write)....173
cfgSsnMgtSshIdleTimeout (Read or Write)....173
cfgSsnMgtTelnetIdleTimeout - Read or Write....174
cfgSerial....174
cfgSerialBaudRate - Read or Write....174
cfgSerialConsoleEnable - Read or Write....175
cfgSerialConsoleQuitKey (Read or Write)....175
cfgSerialConsoleIdleTimeout - Read or Write....175
cfgSerialConsoleNoAuth - Read or Write....175
cfgSerialConsoleCommand - Read or Write....176
cfgSerialHistorySize - Read or Write....176
cfgSerialCom2RedirEnable (Read or Write)....176
cfgSerialHistorySize - Read or Write....176
cfgSerialSshEnable - Read or Write....177
cfgSerialTelnetEnable - Read or Write....177
cfgOobSnmp....177
cfgOobSnmpAgentCommunity (Read or Write)....178
cfgOobSnmpAgentEnable (Read or Write)....178
cfgRacTuning....178
cfgRacTuneConRedirPort (Read or Write)....179
cfgRacTuneRemoteRacadmEnable (Read or Write)....179
cfgRacTuneCtrlEConfigDisable....179
cfgRacTuneHttpPort (Read or Write)....179
cfgRacTuneHttpsPort (Read or Write)....179
cfgRacTuneIpRangeEnable (Read or Write)....180
cfgRacTuneIpRangeAddr (Read or Write)....180
cfgRacTuneIpRangeMask (Read or Write)....180
cfgRacTuneSshPort (Read or Write)....180
cfgRacTuneTelnetPort (Read or Write)....181
cfgRacTuneConRedirEnable (Read or Write)....181
cfgRacTuneConRedirEncryptEnable (Read or Write)....181
cfgRacTuneAsrEnable (Read or Write)....181
cfgRacTuneDaylightOffset (Read Only)....182
cfgRacTuneTimezoneOffset (Read Only)....182
cfgRacTuneLocalServerVideo (Read or Write)....183
cfgRacTuneLocalConfigDisable (Read or Write)....183
cfgRacTuneWebserverEnable (Read or Write)....183
cfgRacTuneVirtualConsoleAuthorizeMultipleSessions (Read or Write)....183
cfgRacTunePluginType (Read or Write)....184
ifcRacManagedNodeOs....184
ifcRacMnOsHostname (Read Only)....184
ifcRacMnOsOsName (Read Only)....184
cfgRacVirtual....184
cfgVirMediaAttached (Read or Write)....185
cfgVirtualBootOnce (Read or Write)....185
cfgVirMediaFloppyEmulation (Read or Write)....185
cfgSDWriteProtect (Read Only)....185

cfgServerInfo....186
cfgServerName (Read Or Write)....186
cfgServerNic3MacAddress (Read Only)....186
cfgServerNic4MacAddress (Read Only)....186
cfgServerDNSIMCName (Read or Write)....187
cfgServerFirstBootDevice (Read or Write)....187
cfgServerBootOnce (Read or Write)....188
cfgActiveDirectory....188
cfgADSSOEnable (Read or Write)....189
cfgADDomainController1 (Read or Write)....189
cfgADDomainController2 (Read or Write)....189
cfgADDomainController3 (Read or Write)....189
cfgADRacName (Read or Write)....190
cfgADRacDomain (Read or Write)....190
cfgADAuthTimeout (Read or Write)....190
cfgADEnable (Read or Write)....190
cfgADType (Read or Write)....191
cfgADGlobalCatalog1 (Read or Write)....191
cfgADGlobalCatalog2 (Read or Write)....191
cfgADGlobalCatalog3 (Read or Write)....191
cfgADCertValidationEnable (Read or Write)....191
cfgADDcSRVLookupEnable (Read or Write)....192
cfgADDcSRVLookupbyUserdomain (Read or Write)....192
cfgADDcSRVLookupDomainName (Read or Write)....192
cfgADGcSRVLookupEnable (Read or Write)....192
cfgADGcRootDomain (Read or Write)....193
cfgLDAP....193
cfgLDAPEnable (Read or Write)....193
cfgLDAPServer (Read or Write)....193
cfgLDAPPort (Read or Write)....194
cfgLDAPBaseDN (Read or Write)....194
cfgLDAPUserAttribute (Read or Write)....194
cfgLDAPGroupAttribute (Read or Write)....194
cfgLDAPGroupAttributeIsDN (Read or Write)....195
cfgLDAPBindDN (Read or Write)....195
cfgLDAPBindPassword (Write Only)....195
cfgLDAPSearchFilter (Read or Write)....195
cfgLDAPCertValidationEnable (Read or Write)....196
cfgLDAPSRVLookupDomainName (Read Only)....196
cfgLDAPSRVLookupServiceName (Read or Write)....196
cfgLdapRoleGroup....196
cfgLDAPRoleGroupIndex (Read Only)....197
cfgLdapRoleGroupDN (Read or Write)....197
cfgLdapRoleGroupPrivilege (Read or Write)....197
cfgStandardSchema....197
cfgSSADRoleGroupIndex (Read Only)....198
cfgSSADRoleGroupName (Read or Write)....198
cfgSSADRoleGroupDomain (Read or Write)....198
cfgSSADRoleGroupPrivilege (Read or Write)....198
cfgThermal....199

cfgThermalEnhancedCoolingMode (Read or Write) 199
cfgIpmiSol 199
cfgIpmiSolEnable (Read or Write) 199
cfgIpmiSolBaudRate (Read or Write) 199
cfgIpmiSolMinPrivilege (Read or Write) 200
cfgIpmiSolAccumulateInterval (Read or Write) 200
cfgIpmiSolSendThreshold (Read or Write) 200
cfgIpmiLan 200
cfgIpmiLanEnable (Read or Write) 200
cfgIpmiLanPrivLimit (Read or Write) 201
cfgIpmiLanAlertEnable (Read or Write) 201
cfgIpmiLanEncryptionKey (Read or Write) 201
cfgIpmiLanPetCommunityName (Read or Write) 201
cfgIpmiPetIpv6 201
cfgIpmiPetIPv6Index (Read Only) 202
cfgIpmiPetIPv6AlertDestIpAddr 202
cfgIpmiPetIPv6AlertEnable (Read or Write) 202
cfgIpmiPef 202
cfgIpmiPefName (Read Only) 202
cfgIpmiPefIndex (Read or Write) 203
cfgIpmiPefAction (Read or Write) 203
cfgIpmiPefEnable (Read or Write) 203
cfgIpmiPet 203
cfgIpmiPetIndex (Read Only) 203
cfgIpmiPetAlertDestIpAddr (Read/Write) 204
cfgIpmiPetAlertEnable (Read or Write) 204
cfgUserDomain 204
cfgUserDomainIndex (Read Only) 204
cfguserdomainname (Read Only) 204
cfgServerPower 204
cfgServerPowerStatus (Read Only) 205
cfgServerPowerAllocation (Read Only) 205
cfgServerActualPowerConsumption (Read Only) 205
cfgServerPowerCapEnable (Read or Write) 205
cfgServerMinPowerCapacity (Read Only) 205
cfgServerMaxPowerCapacity (Read Only) 206
cfgServerPeakPowerConsumption (Read Only) 206
cfgServerPeakPowerConsumptionTimestamp (Read Only) 206
cfgServerPowerConsumptionClear (Write Only) 206
cfgServerPowerCapWatts (Read or Write) 206
cfgServerPowerCapBtuhr (Read or Write) 207
cfgServerPowerCapPercent (Read or Write) 207
cfgServerPowerLastHourAvg (Read Only) 207
cfgServerPowerLastDayAvg (Read Only) 207
cfgServerPowerLastWeekAvg (Read Only) 208
cfgServerPowerLastHourMinPower (Read Only) 208
cfgServerPowerLastHourMinTime (Read Only) 208
cfgServerPowerLastHourMaxPower (Read Only) 208
cfgServerPowerLastHourMaxTime (Read Only) 209
cfgServerPowerLastDayMinPower (Read Only) 209

cfgServerPowerLastDayMinTime (Read Only)....209
cfgServerPowerLastDayMaxPower (Read Only)....209
cfgServerPowerLastDayMaxTime (Read Only)....210
cfgServerPowerLastWeekMinPower (Read Only)....210
cfgServerPowerLastWeekMinTime (Read Only)....210
cfgServerPowerLastWeekMaxPower (Read Only)....211
cfgServerPowerLastWeekMaxTime (Read Only)....211
cfgServerPowerInstHeadroom (Read Only)....211
cfgServerPowerPeakHeadroom (Read Only)....211
cfgServerActualAmperageConsumption (Read Only)....212
cfgServerPeakAmperage (Read Only)....212
cfgServerPeakAmperageTimeStamp (Read Only)....212
cfgServerCumulativePowerConsumption (Read Only)....212
cfgServerCumulativePowerConsumptionTimeStamp (Read Only)....213
cfgServerCumulativePowerClear (Write Only)....213
cfgServerPowerPCIeAllocation (Read or Write)....213
cfgServerPowerSupply....213
cfgServerPowerSupplyIndex....214
cfgServerPowerSupplyMaxInputPower (Read Only)....214
cfgServerPowerSupplyMaxOutputPower (Read Only)....214
cfgServerPowerSupplyOnlineStatus (Read Only)....214
cfgServerPowerSupplyFwVer (Read Only)....215
cfgServerPowerSupplyCurrentDraw (Read Only)....215
cfgServerPowerSupplyType....215
cfgIPv6LanNetworking....215
cfgIPv6Enable (Read or Write)....215
cfgIPv6Address1 (Read or Write)....216
cfgIPv6Gateway (Read or Write)....216
cfgIPv6AutoConfig (Read or Write)....216
cfgIPv6PrefixLength (Read or Write)....216
cfgIPv6LinkLocalAddress (Read Only)....217
cfgIPv6Address2 (Read Only)....217
cfgIPv6Address3 (Read Only)....217
cfgIPv6Address4 (Read Only)....217
cfgIPv6Address5 (Read Only)....217
cfgIPv6Address6 (Read Only)....218
cfgIPv6Address7 (Read Only)....218
cfgIPv6Address8 (Read Only)....218
cfgIPv6Address9 (Read Only)....218
cfgIPv6Address10 (Read Only)....218
cfgIPv6Address11 (Read Only)....219
cfgIPv6Address12 (Read Only)....219
cfgIPv6Address13 (Read Only)....219
cfgIPv6Address14 (Read Only)....219
cfgIPv6Address15 (Read Only)....219
cfgIPv6DNSServersFromDHCP6 (Read or Write)....220
cfgIPv6DNSServer1 (Read or Write)....220
cfgIpv6StaticLanNetworking....220
cfgIPv6StaticEnable (Read or Write)....220
cfgIPv6StaticAddress1 (Read or Write)....220

cfgIPv6StaticGateway (Read or Write) 221
cfgIPv6StaticPrefixLength (Read or Write) 221
cfgIPv6StaticAutoConfig (Read/Write) 221
cfgIPv6StaticDNSServersFromDHCP6 (Read or Write) 221
cfgIPv6StaticDNSServer1 (Read or Write) 222
cfgIPv6StaticDNSServer2 (Read or Write) 222
cfgIPv6DNSServer2 (Read or Write) 222
cfgIPv6URL 223
cfgIPv6URLstring (Read Only) 223
cfgIpmiSerial 223
cfgIpmiSerialBaudRate (Read or Write) 223
cfgIpmiSerialChanPrivLimit (Read or Write) 223
cfgIpmiSerialConnectionMode (Read or Write) 224
cfgIpmiSerialDeleteControl (Read or Write) 224
cfgIpmiSerialEchoControl (Read or Write) 224
cfgIpmiSerialFlowControl (Read or Write) 224
cfgIpmiSerialHandshakeControl (Read or Write) 224
cfgIpmiSerialNewLineSequence (Read or Write) 225
cfgIpmiSerialLineEdit (Read or Write) 225
cfgIpmiSerialInputNewLineSequence (Read or Write) 225
cfgSmartCard 225
cfgSmartCardLogonEnable (Read or Write) 225
cfgSmartCardCRLEnable (Read or Write) 226
cfgNetTuning 226
cfgNetTuningNicAutoneg (Read or Write) 226
cfgNetTuningNic100MB (Read or Write) 227
cfgNetTuningNicFullDuplex (Read or Write) 227
cfgNetTuningNicMtu (Read or Write) 227
cfgSensorRedundancy 227
cfgSensorRedundancyIndex (Read Only) 228
cfgSensorRedundancyPolicy (Read or Write) 228
cfgSensorRedundancyCapabilities (Read Only) 228
cfgSensorRedundancyStatus (Read Only) 228
cfgVFlashSD 229
cfgVFlashSDInitialized (Read Only) 229
cfgVFlashSDEnable (Read or Write) 229
cfgVFlashSDSize (Read Only) 229
cfgVFlashSDLicensed (Read Only) 229
cfgVFlashSDAvailableSize (Read Only) 230
cfgVFlashSDHealth (Read Only) 230
cfgVFlashSDWriteProtect (Read Only) 230
cfgVFlashPartition 230
cfgVFlashPartitionIndex (Read Only) 231
cfgVFlashPartitionSize (Read Only) 231
cfgVFlashPartitionEmulationType (Read or Write) 231
cfgVFlashPartitionFlashOSVolLabel (Read Only) 231
cfgVFlashPartitionFormatType (Read Only) 231
cfgVFlashPartitionAccessType (Read or Write) 232
cfgVFlashPartitionAttachState (Read or Write) 232
cfgLogging 232

cfgLoggingSELOEMEventFilterEnable (Read or Write)....232
cfgRacSecurity....232
cfgRacSecCsrCommonName (Read or Write)....233
cfgRacSecCsrOrganizationName (Read or Write)....233
cfgRacSecCsrOrganizationUnit (Read or Write)....233
cfgRacSecCsrLocalityName (Read or Write)....233
cfgRacSecCsrStateName (Read or Write)....233
cfgRacSecCsrCountryCode (Read/Write)....234
cfgRacSecCsrEmailAddr (Read or Write)....234
cfgRacSecCsrKeySize (Read or Write)....234

Chapter 4: Database Objects With Get and Set Commands....235
System.Backplane....239
System.Backplane.BackplaneBusMode (Read Only)....239
System.ChassisControl....239
System.ChassisControl.ChassisManagementMonitoring (Read or Write)....239
System.ChassisInfo....240
System.ChassisInfo.Model (Read Only)....240
System.ChassisInfo.Name (Read Only)....240
System.ChassisInfo.ServiceTag (Read Only)....240
System.OpenIDConnectServer....240
System.OpenIDConnectServer.ClientToken (Read or Write)....241
System.OpenIDConnectServer.ClientURI (Read or Write)....241
System.OpenIDConnectServer.DiscoveryURL (Read or Write)....241
System.OpenIDConnectServer.Enabled (Read or Write)....241
System.OpenIDConnectServer.HttpsCertificate (Read or Write)....242
System.OpenIDConnectServer.RegistrationDetails(Read or Write)....242
System.OpenIDConnectServer.RegistrationStatus (Read or Write)....242
System.OpenIDConnectServer.Name (Read or Write)....242
System.QuickSync....243
System.QuickSync.Access (Read or Write)....243
System.QuickSync.InactivityTimeout (Read or Write)....243
System.QuickSync.InactivityTimerEnable (Read or Write)....243
System.QuickSync.Presence (Read or Write)....244
System.LCD....244
System.LCD.Configuration (Read or Write)....244
System.LCD.vConsoleIndication (Read or Write)....245
System.LCD.CurrentDisplay (Read Only)....245
System.lcd.FrontPanelLocking (Read or Write)....245
System.LCD.LCDUserString (Read or Write)....246
System.LCD.QualifierTemp (Read or Write)....246
System.LCD.QualifierWatt (Read or Write)....246
System.LCD.UserDefinedString (Read or Write)....246
System.Location....247
System.Location.Aisle (Read or Write)....247
System.Location.DataCenter (Read or Write)....247
System.Location.DeviceSize (Read Only)....247
System.Location.Rack.Name (Read or Write)....248
System.Location.Rack.Slot (Read or Write)....248
System.Location.RoomName (Read or Write)....248

System.Location.Chassis.Name (Read Only)....249
System.Location.Chassis.Slot (Read or Write)....249
System.OpenIDConnectServer....249
System.OpenIDConnectServer.DiscoveryURL (Read or Write)....249
System.Power....249
System.Power.Status (Read Only)....250
System.Power.ServerAllocation (Read Only)....250
System.Power.Avg.LastDay (Read Only)....250
System.Power.Avg.LastHour (Read Only)....251
System.Power.Avg.LastWeek (Read Only)....251
System.Power.Cap.ActivePolicy.Btuhr (Read Only)....251
System.Power.Cap.ActivePolicy.Name (Read Only)....251
System.Power.Cap.ActivePolicy.Watts (Read Only)....252
System.Power.Cap.Btuhr (Read or Write)....252
System.Power.Cap. Enable (Read or Write)....252
System.Power.Cap.MaxThreshold (Read Only)....253
System.Power.Cap.MinThreshold (Read Only)....253
System.Power.Cap.Percent (Read or Write)....253
System.Power.Redundancypolicy (Read or Write)....254
System.Power.Cap.Watts (Read or Write)....254
System.Power.EnergyConsumption (Read Only)....254
System.Power.EnergyConsumption.Clear (Read or Write)....255
System.Power.EnergyConsumption.StarttimeStamp (Read Only)....255
System.Power.Hotspare.Enable (Read or Write)....255
System.Power.Hotspare.PrimaryPSU (Read or Write)....256
System.Power.Max.Amps (Read Only)....256
System.Power.Max.Amps.TimeStamp (Read Only)....256
System.Power.Max.Headroom (Read Only)....257
System.Power.Max.LastDay (Read Only)....257
System.Power.Max.LastDay.TimeStamp (Read Only)....257
System.Power.Max.LastHour (Read Only)....258
System.Power.Max.LastHour.TimeStamp (Read Only)....258
System.Power.Max.LastWeek (Read Only)....258
System.Power.Max.LastWeek.TimeStamp (Read Only)....258
System.Power.Max. Power (Read Only)....259
System.Power.Max.Power.Timestamp (Read Only)....259
System.Power.Max.PowerClear (Read or Write)....259
System.Power.Min.LastDay (Read Only)....260
System.Power.Min.LastDay.TimeStamp (Read Only)....260
System.Power.Min.LastHour (Read Only)....260
System.Power.Min.LastHour.Timestamp (Read Only)....261
System.Power.Min.LastWeek (Read Only)....261
System.Power.Min.LastWeek.TimeStamp (Read Only)....261
System.Power.PCIeAllocation (Read or Write)....261
System.Power.PFCEnable (Read or Write)....262
System.Power.RedundancyCapabilities (Read Only)....262
System.Power.RedundantState (Read Only)....263
System.Power.Realtime.Headroom (Read Only)....263
System.Power.Realtime.Amps (Read Only)....263
System.Power.Realtime.Power (Read Only)....264

System.Power.Supply....264
System.Power.Supply.CurrentDraw (Read Only)....264
System.Power.Supply.FwVer (Read Only)....264
System.Power.Supply.[i].MaxInputPower (Read Only)....265
System.Power.Supply.[i].MaxOutputPower (Read Only)....265
System.Power.Supply.[i].Status (Read Only)....265
System.Power.Supply.[i].Type (Read Only)....265
System.Power.Supply.[i].LineStatus (Read Only)....266
System.Power.Supply.[i].PMBusMonitoring (Read Only)....266
System.ServerOS....266
System.ServerOS.HostName (Read or Write)....266
System.ServerOS.OSName (Read or Write)....267
System.ServerOS.OSVersion (Read Only)....267
System.ServerOS.ServerPoweredOnTime (Read Only)....267
System.ThermalSettings....268
System.ThermalSettings.AirExhaustTemp (Read or Write)....268
System.ThermalSettings.BaseAlgorithm (Read or Write)....268
System.ThermalSettings.MinimumFanSpeed (Read or Write)....268
System.ThermalSettings.FanSpeedOffset (Read or Write)....269
System.ThermalSettings.FanSpeedLowOffsetVal (Read Only)....269
System.ThermalSettings.FanSpeedMediumOffsetVal (Read Only)....269
System.ThermalSettings.FanSpeedHighOffsetVal (Read Only)....270
System.ThermalSettings.FanSpeedMaxOffsetVal (Read Only)....270
System.ThermalSettings.MFSMinimumLimit (Read Only)....270
System.ThermalSettings.MFSMaximumLimit (Read Only)....270
System.ThermalSettings.ThermalProfile (Read or Write)....271
tails ofSystem.ThermalSettings.ThirdPartyPCIFanResponse (Read or Write)....271
System.ThermalConfig....271
System.ThermalConfig.CriticalEventGenerationInterval (Read or Write)....271
System.ThermalConfig.EventGenerationInterval (Read or Write)....272
System.ThermalConfig.FreshAirCompliantConfiguration (Read Only)....272
LifecycleController.LCAttributes....272
LifecycleController.LCAttributes.autobackup (Read or Write)....272
LifecycleController.LCAttributes.AutoDiscovery (Read Only)....273
LifecycleController.LCAttributes.autoupdate (Read or Write)....273
LifecycleController.LCAttributes.BiosRTDRequested (Read or Write)....273
LifecycleController.LCAttributes.CollectSystemInventoryOnRestart (Read or Write)....274
LifecycleController.LCAttributes.DiscoveryFactoryDefaults (Read Only)....274
LifecycleController.LCAttributes.IgnoreCertWarning (Read and Write)....274
LifecycleController.LCAttributes.IPChangeNotifyPS (Read or Write)....275
LifecycleController.LCAttributes.Licensed (Read Only)....275
LifecycleController.LCAttributes.LifecycleControllerState (Read or Write)....275
LifecycleController.LCAttributes.ProvisioningServer (Read or Write)....276
LifecycleController.LCAttributes.PartConfigurationUpdate (Read or Write)....276
LifecycleController.LCAttributes.PartFirmwareUpdate (Read or Write)....276
LifecycleController.LCAttributes.SystemID (Read Only)....277
LifecycleController.LCAttributes.UserProxyName (Read and Write)....277
LifecycleController.LCAttributes.UserProxyPassword(Read and Write)....277
LifecycleController.LCAttributes.UserProxyPort (Read and Write)....277
LifecycleController.LCAttributes.UserProxyServer (Read and Write)....278

LifecycleController.LCAttributes.UserProxyType (Read and Write)....278
LifecycleController.LCAttributes.UserProxyUserName (Read or Write)....278
LifecycleController.LCAttributes.VirtualAddressManagementApplication (Read or Write)....278
iDRAC.ActiveDirectory....279
iDRAC.ActiveDirectory.AuthTimeout (Read or Write)....279
iDRAC.ActiveDirectory.CertValidationEnable (Read or Write)....279
iDRAC.ActiveDirectory.DCLookupByUserDomain (Read or Write)....279
iDRAC.ActiveDirectory.DCLookupDomainName (Read or Write)....280
iDRAC.ActiveDirectory.DCLookupEnable (Read or Write)....280
iDRAC.ActiveDirectory.DomainController1 (Read or Write)....280
iDRAC.ActiveDirectory.DomainController2 (Read or Write)....281
iDRAC.ActiveDirectory.DomainController3 (Read or Write)....281
iDRAC.ActiveDirectory.Enable (Read or Write)....281
iDRAC.ActiveDirectory.GCLookupEnable (Read or Write)....282
iDRAC.ActiveDirectory.GCRootDomain (Read or Write)....282
iDRAC.ActiveDirectory.GlobalCatalog1 (Read or Write)....282
iDRAC.ActiveDirectory.GlobalCatalog2 (Read or Write)....283
iDRAC.ActiveDirectory.GlobalCatalog3 (Read or Write)....283
iDRAC.ActiveDirectory.RacDomain (Read or Write)....283
iDRAC.ActiveDirectory.RacName (Read or Write)....283
iDRAC.ActiveDirectory.Schema (Read or Write)....284
iDRAC.ActiveDirectory.SSOEnable (Read or Write)....284
iDRAC.ADGroup....284
iDRAC.ADGroup.Domain (Read or Write)....284
iDRAC.ADGroup.Name (Read or Write)....285
iDRAC.ADGroup.Privilege (Read or Write)....285
iDRAC.ASRConfig....285
iDRAC.ASRConfig.Enable (Read or Write)....285
iDRAC.AutoOSLock....286
iDRAC.AutoOSLock.AutoOSLockState (Read or Write)....286
iDRAC.EmailAlert....286
iDRAC.EmailAlert.Address (Read or Write)....286
iDRAC.EmailAlert.CustomMsg (Read or Write)....286
iDRAC.EmailAlert.Enable (Read or Write)....287
iDRAC.IMC....287
iDRAC.IMC.AdministrativeState (Read or Write)....287
iDRAC.Info....287
iDRAC.Info.Build (Read or Write)....288
iDRAC.Info.Description (Read or Write)....288
iDRAC.Info.Name (Read or Write)....288
iDRAC.Info.Product (Read or Write)....288
iDRAC.Info.Type (Read or Write)....289
iDRAC.Info.Version (Read Only)....289
iDRAC.Info.ServerGen (Read or Write)....289
iDRAC.IOIDOpt....290
iDRAC.IOIDOpt.IOIDOptEnable (Read or Write)....290
iDRAC.IOIDOptEnable (Read or Write)....290
iDRAC.IOIDOpt.InitiatorPersistencePolicy (Read or Write)....290
iDRAC.IOIDOpt.StorageTargetPersistencePolicy (Read or Write)....291
iDRAC.IOIDOpt.VirtualAddressPersistencePolicyAuxPwrd (Read or Write)....291

iDRAC.IOIDOpt.VirtualAddressPersistencePolicyNonAuxPwrd (Read or Write) 292
iDRAC.IPBlocking 292
iDRAC.IPBlocking.BlockEnable (Read or Write) 292
iDRAC.IPBlocking.FailCount (Read or Write) 293
iDRAC.IPBlocking.FailWindow (Read or Write) 293
iDRAC.IPBlocking.PenaltyTime (Read or Write) 293
iDRAC.IPBlocking.RangeAddr (Read or Write) 293
iDRAC.IPBlocking.RangeEnable (Read or Write) 294
iDRAC.IPBlocking.RangeMask (Read or Write) 294
iDRAC.IPMILan 294
iDRAC.IPMILan.AlertEnable (Read or Write) 294
iDRAC.IPMILan.CommunityName (Read or Write) 295
iDRAC.IPMILan.Enable (Read or Write) 295
iDRAC.IPMILan.EncryptionKey (Read or Write) 295
iDRAC.IPMILan.PrivLimit (Read or Write) 296
iDRAC.IPMISerial 296
iDRAC.IPMISerial.BaudRate (Read or Write) 296
iDRAC.IPMISerial.ChanPrivLimit (Read or Write) 297
iDRAC.IPMISerial.ConnectionMode (Read or Write) 297
iDRAC.IPMISerial.DeleteControl (Read or Write) 297
iDRAC.IPMISerial.EchoControl (Read or Write) 298
iDRAC.IPMISerial.FlowControl (Read or Write) 298
iDRAC.IPMISerial.HandshakeControl (Read or Write) 298
iDRAC.IPMISerial.InputNewLineSeq (Read or Write) 299
iDRAC.IPMISerial.LineEdit (Read or Write) 299
iDRAC.IPMISerial.NewLineSeq (Read or Write) 299
iDRAC.IPMISOL 300
iDRAC.IPMISOL.AccumulateInterval (Read or Write) 300
iDRAC.IPMISOL.BaudRate (Read or Write) 300
iDRAC.IPMISOL.Enable (Read or Write) 300
iDRAC.IPMISOL.MinPrivilege (Read or Write) 301
iDRAC.IPMISOL.SendThreshold (Read or Write) 301
iDRAC.IPv4 301
iDRAC.IPv4.Address (Read or Write) 301
iDRAC.IPv4.DHCPEnable (Read or Write) 302
iDRAC.IPv4.DNS1 (Read or Write) 302
iDRAC.IPv4.DNS2 (Read or Write) 302
iDRAC.IPv4.DNSFromDHCP (Read or Write) 303
iDRAC.IPv4.Enable (Read or Write) 303
iDRAC.IPv4.Gateway (Read or Write) 303
iDRAC.IPv4.Netmask (Read or Write) 304
iDRAC.IPv4Static 304
iDRAC.IPv4Static.Address (Read or Write) 304
iDRAC.IPv4Static.DNS1 (Read or Write) 304
iDRAC.IPv4Static.DNS2 (Read or Write) 305
iDRAC.IPv4Static.DNSFromDHCP (Read or Write) 305
iDRAC.IPv4Static.Gateway (Read or Write) 305
iDRAC.IPv4Static.Netmask (Read or Write) 305
iDRAC.IPv6 306
iDRAC.IPv6.Address1 (Read or Write) 306

iDRAC.IPv6.Address2 (Read or Write) 306
iDRAC.IPv6.Address3 (Read or Write) 306
iDRAC.IPv6.Address4 (Read or Write) 307
iDRAC.IPv6.Address5 (Read or Write) 307
iDRAC.IPv6.Address6 (Read or Write) 307
iDRAC.IPv6.Address7 (Read or Write) 308
iDRAC.IPv6.Address8 (Read or Write) 308
iDRAC.IPv6.Address9 (Read or Write) 308
iDRAC.IPv6.Address10 (Read or Write) 309
iDRAC.IPv6.Address11 (Read or Write) 309
iDRAC.IPv6.Address12 (Read or Write) 309
iDRAC.IPv6.Address13 (Read or Write) 309
iDRAC.IPv6.Address14 (Read or Write) 310
iDRAC.IPv6.Address15 (Read or Write) 310
iDRAC.IPv6.AutoConfig (Read or Write) 310
iDRAC.IPv6.DNS1 (Read or Write) 311
iDRAC.IPv6.DNS2 (Read or Write) 311
iDRAC.IPv6.DNSFromDHCP6 (Read or Write) 311
iDRAC.IPv6.Enable (Read or Write) 312
iDRAC.IPv6.Gateway (Read or Write) 312
iDRAC.IPv6.LinkLocalAddress (Read or Write) 312
iDRAC.IPv6.PrefixLength (Read or Write) 312
iDRAC.IPv6Static 313
iDRAC.IPv6Static.Address1 (Read or Write) 313
iDRAC.IPv6Static.DNS1 (Read or Write) 313
iDRAC.IPv6Static.DNS2 (Read or Write) 313
iDRAC.IPv6Static.DNSFromDHCP6 (Read or Write) 314
iDRAC.IPv6Static.Gateway (Read or Write) 314
iDRAC.IPv6Static.PrefixLength (Read or Write) 314
iDRAC.IPv6URL 315
iDRAC.IPv6URL.URL (Read Only) 315
iDRAC.LDAP 315
iDRAC.LDAP.BaseDN (Read or Write) 315
iDRAC.LDAP.BindDN (Read or Write) 315
iDRAC.LDAP.BindPassword (Write Only) 316
iDRAC.LDAP.CertValidationEnable (Read or Write) 316
iDRAC.LDAP.Enable (Read or Write) 316
iDRAC.LDAP.GroupAttribute (Read or Write) 316
iDRAC.LDAP.GroupAttributeIsDN (Read or Write) 317
iDRAC.LDAP.Port (Read or Write) 317
iDRAC.LDAP.SearchFilter (Read or Write) 317
iDRAC.LDAP.Server (Read or Write) 318
iDRAC.LDAP.UserAttribute (Read or Write) 318
iDRAC.LDAPRoleGroup 318
iDRAC.LDAPRoleGroup.DN (Read or Write) 318
iDRAC.LDAPRoleGroup.Privilege(Read or Write) 319
iDRAC.LocalSecurity 319
iDRAC.LocalSecurity.LocalConfigDisabled (Read or Write) 319
iDRAC.LocalSecurity.PrebootConfig (Read or Write) 319
iDRAC.Logging 320

iDRAC.Logging.SELOEMEventFilterEnable (Read or Write) 320
iDRAC.NIC 320
iDRAC.NIC.Autoconfig (Read or Write) 320
iDRAC.NIC.AutoDetect (Read or Write) 321
iDRAC.NIC.Autoneg (Read or Write) 321
iDRAC.NIC.DedicatedNICScanTime (Read or Write) 322
iDRAC.NIC.DNSDomainFromDHCP (Read or Write) 322
iDRAC.NIC.DNSDomainName (Read or Write) 322
iDRAC.NIC.DNSDomainNameFromDHCP (Read or Write) 323
iDRAC.NIC.DNSRacName (Read or Write) 323
iDRAC.NIC.DNSRegister (Read or Write) 323
iDRAC.NIC.Duplex (Read or Write) 324
iDRAC.NIC.Enable (Read or Write) 324
iDRAC.NIC.Failover (Read or Write) 324
iDRAC.NIC.MACAddress (Read or Write) 325
iDRAC.NIC.MTU (Read or Write) 325
iDRAC.NIC.Selection (Read or Write) 325
iDRAC.NIC.SharedNICScanTime (Read or Write) 326
iDRAC.NIC.Speed (Read or Write) 326
iDRAC.NIC.TopologyLldp (Read or Write) 326
iDRAC.NIC.VLanEnable (Read Only) 327
iDRAC.NIC.VLanID (Read Only) 327
iDRAC.NIC.VLanPort (Read or Write) 327
iDRAC.NIC.VLanPriority (Read Only) 328
iDRAC.NICStatic 328
iDRAC.NICStatic.DNSDomainFromDHCP (Read or Write) 328
iDRAC.NICStatic.DNSDomainName (Read or Write) 328
iDRAC.NTPConfigGroup 329
iDRAC.NTPConfigGroup.NTP1 (Read or Write) 329
iDRAC.NTPConfigGroup.NTP2 (Read or Write) 329
iDRAC.NTPConfigGroup.NTP3 (Read or Write) 329
iDRAC.NTPConfigGroup.NTPEnable (Read or Write) 330
iDRAC.NTPConfigGroup.NTPMaxDist (Read or Write) 330
iDRAC.OS-BMC 330
iDRAC.OS-BMC.AdminState (Read or Write) 330
iDRAC.OS-BMC.OSIpAddress (Read or Write) 331
iDRAC.OS-BMC.PTCapability (Read or Write) 331
iDRAC.OS-BMC.PTMode (Read or Write) 331
iDRAC.OS-BMC.UsbNicIpAddress (Read or Write) 332
iDRAC.Racadm 332
iDRAC.Racadm.Enable (Read or Write) 332
iDRAC.Racadm.Timeout (Read or Write) 332
iDRAC.Redfish 333
iDRAC.Redfish.Enable (Read or Write) 333
iDRAC.Redfisheventing 333
iDRAC.Redfisheventing.DeliveryRetryAttempts (Read or Write) 333
iDRAC.Redfisheventing.DeliveryRetryIntervalInSeconds (Read or Write) 334
iDRAC.Redfisheventing.IgnoreCertificateErrors (Read Only) 334
iDRAC.RemoteHosts 334
iDRAC.RemoteHosts.SMTPPort (Read or Write) 334

iDRAC.RemoteHosts.SMTPServerIPAddress (Read or Write)....335
iDRAC.RFS....335
iDRAC.RFS.IgnoreCertWarning (Read or Write)....335
iDRAC.RFS.MediaAttachState (Read Only)....335
iDRAC.RFS.WriteProtected (Read Only)....336
iDRAC.RSM....336
iDRAC.RSM.RSMCapability (Read Only)....336
iDRAC.RSM.RSMSetting (Read Only)....336
iDRAC.SecureDefaultPassword....336
iDRAC.SecureDefaultPassword.ForceChangePassword (Read or Write)....337
iDRAC.Security....337
iDRAC.Security.CsrCommonName (Read or Write)....337
iDRAC.Security.CsrCountryCode (Read or Write)....337
iDRAC.Security.CsrEmailAddr (Read or Write)....338
iDRAC.Security.CsrKeySize (Read or Write)....338
iDRAC.Security.CsrLocalityName (Read or Write)....338
iDRAC.Security.CsrOrganizationName (Read or Write)....338
iDRAC.Security.CsrOrganizationUnit (Read or Write)....339
iDRAC.Security.CsrStateName (Read or Write)....339
iDRAC.Security.CsrSubjectAltName (Read or Write)....339
iDRAC.Security.FIPSMode (Read or Write)....340
iDRAC.Serial....340
iDRAC.Serial.BaudRate (Read or Write)....340
iDRAC.Serial.Command (Read or Write)....341
iDRAC.Serial.Enable (Read or Write)....341
iDRAC.Serial.HistorySize (Read or Write)....341
iDRAC.Serial.IdleTimeout (Read or Write)....342
iDRAC.Serial.NoAuth (Read or Write)....342
iDRAC.SerialRedirection....342
iDRAC.SerialRedirection.Enable (Read or Write)....342
iDRAC.SerialRedirection.QuitKey (Read or Write)....343
iDRAC.serverboot....343
iDRAC.serverboot.BootOnce (Read or Write)....343
iDRAC.serverboot.FirstBootDevice (Read or Write)....343
iDRAC.ServiceModule....344
iDRAC.ServiceModule.ChipsetSATASupported (Read or Write)....344
iDRAC.ServiceModule.HostSNMPGet (Read or Write)....344
iDRAC.ServiceModule.HostSNMPAlert (Read or Write)....344
iDRAC.ServiceModule.HostSNMPGet....345
iDRAC.ServiceModule.iDRACHardReset (Read or Write)....345
iDRAC.ServiceModule.LCLReplication (Read or Write)....345
iDRAC.ServiceModule.OMSAPresence (Read Only)....346
iDRAC.ServiceModule.OSInfo (Read or Write)....346
iDRAC.ServiceModule.ServiceModuleEnable (Read or Write)....346
iDRAC.ServiceModule.ServiceModuleState (Read or Write)....346
iDRAC.ServiceModule.ServiceModuleVersion (Read)....347
iDRAC.ServiceModule.SSEventCorrelation(Read or Write)....347
iDRAC.ServiceModule.WatchdogRecoveryAction (Read and Write)....347
iDRAC.ServiceModule.WatchdogResetTime (Read and Write)....348
iDRAC.ServiceModule.WatchdogState (Read and Write)....348

iDRAC.ServiceModule.WMIInfo (Read or Write) 348
iDRAC.SmartCard 348
iDRAC.SmartCard.SmartCardCRLEnable (Read or Write) 348
iDRAC.SmartCard.SmartCardLogonEnable (Read or Write) 349
iDRAC.SNMP 349
iDRAC.SNMP.AgentCommunity (Read or Write) 349
iDRAC.SNMP.AgentEnable (Read or Write) 350
iDRAC.SNMP.AlertPort (Read or Write) 350
iDRAC.SNMP.DiscoveryPort (Read or Write) 350
iDRAC.SNMP.SNMPProtocol (Read or Write) 350
iDRAC.SNMP.TrapFormat (Read or Write) 351
iDRAC.SNMP.Alert 351
iDRAC.SNMP.Alert.DestAddr (Read or Write) 351
iDRAC.SNMP.Alert.Enable (Read or Write) 352
iDRAC.SNMP.Alert.SNMPv3UserID (Read Only) 352
iDRAC.SNMP.Alert.SNMPv3Username (Read or Write) 352
iDRAC.SSH 352
iDRAC.SSH.Enable (Read or Write) 353
iDRAC.SSH.Port (Read or Write) 353
iDRAC.SSH.Timeout (Read or Write) 353
iDRAC.SupportAssist 353
iDRAC.SupportAssist.HostOSProxyAddress 354
iDRAC.SupportAssist.HostOSProxyConfigured 354
iDRAC.SupportAssist.HostOSProxyPassword 354
iDRAC.SupportAssist.HostOSProxyPort 354
iDRAC.SupportAssist.HostOSProxyUserName 355
iDRAC.SysLog 355
iDRAC.SysLog.Port (Read or Write) 355
iDRAC.SysLog.PowerLogEnable (Read or Write) 355
iDRAC.SysLog.PowerLogInterval (Read or Write) 356
iDRAC.SysLog.Server1 (Read or Write) 356
iDRAC.SysLog.Server2 (Read or Write) 356
iDRAC.SysLog.Server3 (Read or Write) 357
iDRAC.SysLog.SysLogEnable (Read or Write) 357
iDRAC.Telnet 357
iDRAC.Telnet.Enable (Read or Write) 357
iDRAC.Telnet.Port (Read or Write) 358
iDRAC.Time 358
iDRAC.Time.DayLightOffset (Read or Write) 358
iDRAC.Time.Timezone (Read or Write) 358
iDRAC.Time.TimeZoneOffset (Read or Write) 359
iDRAC.Tuning 359
iDRAC.Tuning.DefaultCredentialWarning (Read or Write) 359
iDRAC.Update 359
iDRAC.Update.FwUpdateIPAddr (Read or Write) 359
iDRAC.Update.FwUpdatePath (Read or Write) 360
iDRAC.Update.FwUpdateTFTPEnable (Read or Write) 360
iDRAC.USB 360
iDRAC.USB.ConfigurationXML (Read or Write) 360
iDRAC.USB.ManagementPortMode (Read Only) 361

iDRAC.USB.PortStatus (Read or Write) 361
iDRAC.Telnet.Timeout (Read or Write) 361
iDRAC.UserDomain 362
iDRAC.UserDomain.Name (Read or Write) 362
iDRAC.Users 362
iDRAC.Users.Enable (Read or Write) 362
iDRAC.Users.IpmiLanPrivilege (Read or Write) 362
iDRAC.Users.IpmiSerialPrivilege (Read or Write) 363
iDRAC.Users.MD5v3Key (Read or Write) 363
iDRAC.Users.Password (Read or Write) 363
iDRAC.Users.SHA256Password (Read or Write) 364
iDRAC.Users.SHA256PasswordSalt (Read or Write) 364
iDRAC.Users.Privilege (Read or Write) 364
iDRAC.Users.SHA1v3Key (Read or Write) 364
iDRAC.Users.SNMPv3AuthenticationType (Read or Write) 365
iDRAC.Users.SNMPv3Enable (Read or Write) 365
iDRAC.Users.SNMPv3PrivacyType (Read or Write) 365
iDRAC.Users.SolEnable (Read or Write) 366
iDRAC.Users.UserName (Read or Write) 366
iDRAC.vflashpartition 366
iDRAC.vflashpartition.AccessType (Read or Write) 366
iDRAC.vflashpartition.AttachState (Read or Write) 367
iDRAC.vflashpartition.EmulationType (Read or Write) 367
iDRAC.vflashpartition.FormatType (Read or Write) 367
iDRAC.vflashpartition.Size (Read or Write) 368
iDRAC.vflashpartition.VolumeLabel (Read or Write) 368
iDRAC.vflashsd 368
iDRAC.vflashsd.AvailableSize (Read or Write) 368
iDRAC.vflashsd.Enable (Read or Write) 369
iDRAC.vflashsd.Health (Read or Write) 369
iDRAC.vflashsd.Initialized (Read or Write) 369
iDRAC.vflashsd.Licensed (Read or Write) 369
iDRAC.vflashsd.Size (Read or Write) 370
iDRAC.vflashsd.WriteProtect (Read or Write) 370
iDRAC.VirtualConsole 370
iDRAC.VirtualConsole.AccessPrivilege (Read or Write) 370
iDRAC.VirtualConsole.AttachState (Read or Write) 371
iDRAC.VirtualConsole.Enable (Read or Write) 371
iDRAC.VirtualConsole.EncryptEnable (Read or Write) 371
iDRAC.VirtualConsole.LocalVideo (Read or Write) 372
iDRAC.VirtualConsole.MaxSessions (Read or Write) 372
iDRAC.VirtualConsole.PluginType (Read or Write) 372
iDRAC.VirtualConsole.Port (Read or Write) 373
iDRAC.VirtualConsole.Timeout (Read or Write) 373
iDRAC.VirtualMedia 373
iDRAC.VirtualMedia.Attached (Read or Write) 373
iDRAC.VirtualMedia.BootOnce (Read or Write) 374
iDRAC.VirtualMedia.Enable (Read or Write) 374
iDRAC.VirtualMedia.EncryptEnable (Read or Write) 374
iDRAC.VirtualMedia.FloppyEmulation (Read or Write) 375

iDRAC.VirtualMedia.KeyEnable (Read or Write) 375
iDRAC.VNCServer 375
iDRAC.VNCServer.Enable (Read or Write) 375
iDRAC.VNCServer.LowerEncryptionBitLength (Read or Write) 376
iDRAC.VNCServer.Password (Read or Write) 376
iDRAC.VNCServer.Port (Read or Write) 376
iDRAC.VNCServer.SSLEncryptionBitLength (Read or Write) 376
iDRAC.VNCServer.Timeout (Read or Write) 377
iDRAC.WebServer 377
iDRAC.Webserver.CustomCipherString(Read or Write) 377
iDRAC.WebServer.Enable (Read or Write) 377
iDRAC.WebServer.HostHeaderCheck(Read or Write) 378
iDRAC.WebServer.HttpPort (Read or Write) 378
iDRAC.WebServer.HttpsPort (Read or Write) 378
iDRAC.Webserver.Httpsredirection (Read or Write) 379
iDRAC.WebServer.LowerEncryptionBitLength (Read or Write) 379
iDRAC.WebServer.ManualDNSEntry(Read or Write) 379
iDRAC.WebServer.MaxNumberOfSessions (Read Only) 380
iDRAC.WebServer.SSLEncryptionBitLength (Read or Write) 380
iDRAC.webServer.TitleBarOption (Read or Write) 380
iDRAC.webServer.TitleBarOptionCustom (Read or Write) 381
iDRAC.WebServer.Timeout (Read or Write) 381
iDRAC.WebServer.TLSProtocol (Read or Write) 381
BIOS.BiosBootSettings 381
BIOS.BiosBootSettings.BootSeq (Read or Write) 382
BIOS.BiosBootSettings.BootMode (Read or Write) 382
BIOS.BiosBootSettings.BootSeqRetry (Read or Write) 382
BIOS.BiosBootSettings.HddFailover (Read or Write) 383
BIOS.BiosBootSettings.HddSeq (Read or Write) 383
BIOS.BiosBootSettings.UefiBootSeq (Read or Write) 383
BIOS.BiosBootSettings.SetBootOrderDis (Read or Write) 383
BIOS.BiosBootSettings.SetBootOrderEn (Read or Write) 384
BIOS.BiosBootSettings.SetBootOrderFqddn (Read or Write) 384
BIOS.BiosBootSettings.SetLegacyHddOrderFqddn (Read or Write) 384
BIOS.EmbServerMgmt 384
BIOS.EmbServerMgmt.FrontLcd (Read or Write) 385
BIOS.EmbServerMgmt.UserLcdStr (Read or Write) 385
BIOS.IntegratedDevices 385
BIOS.IntegratedDevices.CurrentEmbVideoState (Read or Write) 385
BIOS.IntegratedDevices.EmbNic1 (Read or Write) 386
BIOS.IntegratedDevices.EmbNic1Nic2 (Read or Write) 386
BIOS.IntegratedDevices.EmbNic2 (Read or Write) 386
BIOS.IntegratedDevices.EmbNic3 (Read or Write) 387
BIOS.IntegratedDevices.EmbNic3Nic4 (Read or Write) 387
BIOS.IntegratedDevices.EmbNic4 (Read or Write) 387
BIOS.IntegratedDevices.EmbVideo (Read or Write) 388
BIOS.IntegratedDevices.GlobalSlotDriverDisable 388
BIOS.IntegratedDevices.IntegratedNetwork1 (Read or Write) 388
BIOS.IntegratedDevices.IntegratedNetwork2 (Read or Write) 389
BIOS.IntegratedDevices.IntegratedRaid (Read or Write) 389

BIOS.IntegratedDevices.IntegratedSas (Read or Write)....389
BIOS.IntegratedDevices.InternalSdCard (Read or Write)....390
BIOS.IntegratedDevices.InternalSdCardRedundancy (Read or Write)....390
BIOS.IntegratedDevices.InternalUsb (Read or Write)....390
BIOS.IntegratedDevices.InternalUsb1 (Read or Write)....391
BIOS.IntegratedDevices.InternalUsb2 (Read or Write)....391
BIOS.IntegratedDevices.IONonPostedPrefetch....391
BIOS.IntegratedDevices.IoatEngine (Read or Write)....392
BIOS.IntegratedDevices.IONonPostedPrefetch....392
BIOS.IntegratedDevices.MmioAbove4GB (Read or Write)....392
BIOS.IntegratedDevices.OsWatchdogTimer (Read or Write)....392
BIOS.IntegratedDevices.SriovGlobalEnable (Read or Write)....393
BIOS.IntegratedDevices.Usb3Setting (Read or Write)....393
BIOS.IntegratedDevices.UsbPorts (Read or Write)....393
BIOS.MemSettings....394
BIOS.MemSettings.CorrEccSmi (Read or Write)....394
BIOS.MemSettings.MemLowPower (Read or Write)....394
BIOS.MemSettings.MemOpMode (Read or Write)....395
BIOS.MemSettings.MemOptimizer (Read or Write)....395
BIOS.MemSettings.MemOpVoltage (Read Only)....395
BIOS.MemSettings.MemTest (Read or Write)....396
BIOS.MemSettings.NodeInterleave (Read or Write)....396
BIOS.MemSettings.RedundantMem (Read or Write)....396
BIOS.MemSettings.RedundantMemCfgValid (Read or Write)....397
BIOS.MemSettings.RedundantMemInUse (Read Only)....397
BIOS.MemSettings.Serialdbgout (Read or Write)....397
BIOS.MemSettings.SnoopFilter (Read or Write)....397
BIOS.MemSettings.SnoopMode (Read or Write)....398
BIOS.MemSettings.SysMemSize (Read or Write)....398
BIOS.MemSettings.SysMemSpeed (Read or Write)....399
BIOS.MemSettings.SysMemType (Read or Write)....399
BIOS.MemSettings.SysMemVolt (Read or Write)....399
BIOS.MemSettings.VideoMem (Read or Write)....399
BIOS.MiscSettings....400
BIOS.MiscSettings.AssetTag (Read or Write)....400
BIOS.MiscSettings.ErrPrompt (Read or Write)....400
BIOS.MiscSettings.InSystemCharacterization (Read or Write)....400
BIOS.MiscSettings.NumLock (Read or Write)....401
BIOS.MiscSettings.ReportKbdErr (Read or Write)....401
BIOS.MiscSettings.SystemUefiShell (Read or Write)....401
BIOS.MiscSettings.SysMgmtNVByte1 (Read or Write)....402
BIOS.MiscSettings.SysMgmtNVByte2 (Read or Write)....402
BIOS.MiscSettings.SystemUefiShell (Read or Write)....402
BIOS.MiscSettings.ForceInt10 (Read or Write)....403
BIOS.NetworkSettings....403
BIOS.NetworkSettings.PxeDevnEnDis (Read or Write)....403
BIOS.OneTimeBoot....403
BIOS.OneTimeBoot.OneTimeBootMode (Read or Write)....403
BIOS.OneTimeBoot.OneTimeBootSeqDev (Read or Write)....404
BIOS.OneTimeBoot.OneTimeCustomBootStr (Read or Write)....404

BIOS.OneTimeBoot.OneTimeHddSeqDev (Read or Write) 404
BIOS.OneTimeBoot.OneTimeUefiBootSeqDev (Read or Write) 405
BIOS.ProcSettings 405
BIOS.ProcSettings.CorePerfBoost (Read or Write) 405
BIOS.ProcSettings.DataReuse (Read or Write) 405
BIOS.ProcSettings.DcuIpPrefetcher (Read or Write) 406
BIOS.ProcSettings.DcuStreamerPrefetcher (Read or Write) 406
BIOS.ProcSettings.DmaVirtualization (Read or Write) 406
BIOS.ProcSettings.DynamicCoreAllocation (Read or Write) 407
BIOS.ProcSettings.LogicalProc (Read or Write) 407
BIOS.ProcSettings.PerfMonitorDevices (Read or Write) 407
BIOS.ProcSettings.Proc1Brand (Read or Write) 408
BIOS.ProcSettings.Proc1ControlledTurbo (Read or Write) 408
BIOS.ProcSettings.Proc1Id (Read or Write) 408
BIOS.ProcSettings.Proc1L2Cache (Read or Write) 409
BIOS.ProcSettings.Proc1L3Cache (Read or Write) 409
BIOS.ProcSettings.Proc1NumCores (Read or Write) 409
BIOS.ProcSettings.Proc2Brand (Read or Write) 409
BIOS.ProcSettings.Proc2ControlledTurbo (Read or Write) 410
BIOS.Procsettings.Proc2Cores 410
BIOS.ProcSettings.Proc2Id (Read or Write) 410
BIOS.ProcSettings.Proc2L2Cache (Read or Write) 411
BIOS.ProcSettings.Proc2L3Cache (Read or Write) 411
BIOS.ProcSettings.Proc2NumCores (Read or Write) 411
BIOS.ProcSettings.Proc3Brand (Read or Write) 412
BIOS.ProcSettings.Proc3ControlledTurbo (Read or Write) 412
BIOS.Procsettings.Proc3Cores 412
BIOS.ProcSettings.Proc3Id (Read or Write) 413
c(Read or Write) 413
BIOS.ProcSettings.Proc3L3Cache (Read or Write) 413
BIOS.ProcSettings.Proc3NumCores (Read or Write) 413
BIOS.ProcSettings.Proc4Brand (Read or Write) 414
BIOS.ProcSettings.Proc4ControlledTurbo (Read or Write) 414
BIOS.Procsettings.Proc4Cores 414
BIOS.ProcSettings.Proc4Id (Read or Write) 415
BIOS.ProcSettings.Proc4L2Cache (Read or Write) 415
BIOS.ProcSettings.Proc4L3Cache (Read or Write) 415
BIOS.ProcSettings.Proc4NumCores (Read or Write) 416
BIOS.ProcSettings.Proc64bit (Read or Write) 416
BIOS.ProcSettings.ProcAdjCacheLine (Read or Write) 416
BIOS.ProcSettings.ProcBusSpeed (Read or Write) 416
BIOS.ProcSettings.ProcConfigTdp (Read or Write) 417
BIOS.ProcSettings.ProcCores (Read or Write) 417
BIOS.ProcSettings.ProcCoreSpeed (Read or Write) 418
BIOS.ProcSettings.ProcDramPrefetcher (Read or Write) 418
BIOS.ProcSettings.ProcExecuteDisable (Read or Write) 418
BIOS.ProcSettings.ProcHpcMode (Read or Write) 419
BIOS.ProcSettings.ProcHtAssist (Read or Write) 419
BIOS.ProcSettings.ProcHwPrefetcher (Read or Write) 419
BIOS.ProcSettings.ProcHyperTransport (Read or Write) 420

BIOS.ProcSettings.ProcSoftwarePrefetcher (Read or Write) 420
BIOS.ProcSettings.ProcVirtualization (Read or Write) 420
BIOS.ProcSettings.ProcX2Apic (Read or Write) 421
BIOS.ProcSettings.QpiBandwidthPriority (Read or Write) 421
BIOS.ProcSettings.QpiSpeed (Read or Write) 421
BIOS.ProcSettings.RtidSetting (Read or Write) 422
BIOS.ProxyAttributes 422
BIOS.ProxyAttributes.EmbNicPortnBootproto (Read or Write) 422
BIOS.ProxyAttributes.IntNic1PortnBootproto (Read or Write) 422
BIOS.PxeDev1Settings 423
BIOS.PxeDev1Settings.PxeDevnInterface (Read or Write) 423
BIOS.PxeDev1Settings.PxeDevnProtocol (Read or Write) 423
BIOS.PxeDev1Settings.PxeDevnVlanEnDis (Read or Write) 423
BIOS.PxeDev1Settings.PxeDevnVlanId (Read or Write) 424
BIOS.PxeDev1Settings.PxeDevnVlanPriority (Read or Write) 424
BIOS.SataSettings 424
BIOS.SataSettings.EmbSata (Read or Write) 424
BIOS.SataSettings.eSataPort1 (Read or Write) 425
BIOS.SataSettings.eSataPort1Capacity (Read or Write) 425
BIOS.SataSettings.eSataPort1DriveType (Read or Write) 425
BIOS.SataSettings.eSataPort1Model (Read or Write) 426
BIOS.SataSettings.SataPortA (Read or Write) 426
BIOS.SataSettings.SataPortACapacity (Read or Write) 426
BIOS.SataSettings.SataPortADriveType (Read or Write) 426
BIOS.SataSettings.SataPortAModel (Read or Write) 427
BIOS.SataSettings.SataPortB (Read or Write) 427
BIOS.SataSettings.SataPortBCapacity (Read or Write) 427
BIOS.SataSettings.SataPortBDriveType (Read or Write) 428
BIOS.SataSettings.SataPortBModel (Read or Write) 428
BIOS.SataSettings.SataPortC (Read or Write) 428
BIOS.SataSettings.SataPortCCapacity (Read or Write) 429
BIOS.SataSettings.SataPortCDriveType (Read or Write) 429
BIOS.SataSettings.SataPortCModel (Read or Write) 429
BIOS.SataSettings.SataPortD (Read or Write) 429
BIOS.SataSettings.SataPortDCapacity (Read or Write) 430
BIOS.SataSettings.SataPortDDriveType (Read or Write) 430
BIOS.SataSettings.SataPortDModel (Read or Write) 430
BIOS.SataSettings.SataPortE (Read or Write) 431
BIOS.SataSettings.SataPortECapacity (Read or Write) 431
BIOS.SataSettings.SataPortEDriveType (Read or Write) 431
BIOS.SataSettings.SataPortEModel (Read or Write) 432
BIOS.SataSettings.SataPortF (Read or Write) 432
BIOS.SataSettings.SataPortFCapacity (Read or Write) 432
BIOS.SataSettings.SataPortFDriveType (Read or Write) 432
BIOS.SataSettings.SataPortFModel (Read or Write) 433
BIOS.SataSettings.SataPortG (Read or Write) 433
BIOS.SataSettings.SataPortGCapacity (Read or Write) 433
BIOS.SataSettings.SataPortGDriveType (Read or Write) 434
BIOS.SataSettings.SataPortGModel (Read or Write) 434
BIOS.SataSettings.SataPortH (Read or Write) 434

BIOS.SataSettings.SataPortHCapacity (Read or Write) 434
BIOS.SataSettings.SataPortHDriveType (Read or Write) 435
BIOS.SataSettings.SataPortHModel (Read Only) 435
BIOS.SataSettings.SataPortI (Read or Write) 435
BIOS.SataSettings.SataPortICapacity (Read or Write) 436
BIOS.SataSettings.SataPortIDriveType (Read or Write) 436
BIOS.SataSettings.SataPortIModel (Read or Write) 436
BIOS.SataSettings.SataPortJ (Read or Write) 437
BIOS.SataSettings.SataPortJCapacity (Read or Write) 437
BIOS.SataSettings.SataPortJDriveType (Read or Write) 437
BIOS.SataSettings.SataPortJModel (Read or Write) 437
BIOS.SataSettings.SecurityFreezeLock (Read or Write) 438
BIOS.SataSettings.WriteCache (Read or Write) 438
BIOS.SerialCommSettings 438
BIOS.SerialCommSettings.ConTermType (Read or Write) 438
BIOS.SerialCommSettings.ExtSerialConnector (Read or Write) 439
BIOS.SerialCommSettings.FailSafeBaud (Read or Write) 439
BIOS.SerialCommSettings.RedirAfterBoot (Read or Write) 439
BIOS.SerialCommSettings.SerialComm (Read or Write) 440
BIOS.SerialCommSettings.SerialPortAddress (Read or Write) 440
BIOS.SlotDisablement 440
BIOS.SlotDisablement.Slot1 (Read or Write) 441
BIOS.SlotDisablement.Slot2 (Read or Write) 441
BIOS.SlotDisablement.Slot3 (Read or Write) 441
BIOS.SlotDisablement.Slot4 (Read or Write) 442
BIOS.SlotDisablement.Slot5 (Read or Write) 442
BIOS.SlotDisablement.Slot6 (Read or Write) 442
BIOS.SlotDisablement.Slot7 (Read or Write) 443
BIOS.SlotDisablement.Slot8 (Read or Write) 443
BIOS.SlotDisablement.Slot9 (Read or Write) 443
BIOS.SlotDisablement.Slot10 (Read or Write) 444
BIOS.SysInformation 444
BIOS.SysInformation.SystemMeVersion (Read or Write) 444
BIOS.SysInformation.SysMfrContactInfo (Read or Write) 445
BIOS.SysInformation.SystemBiosVersion (Read or Write) 445
BIOS.SysInformation.SystemCpldVersion (Read or Write) 445
BIOS.SysInformation.SystemManufacturer (Read or Write) 446
BIOS.SysInformation.SystemModelName (Read or Write) 446
BIOS.SysInformation.SystemServiceTag (Read or Write) 446
BIOS.SysInformation.UefiComplianceVersion (Read or Write) 446
BIOS.SysProfileSettings 447
BIOS.SysProfileSettings.CollaborativeCpuPerfCtrl (Read/Write) 447
BIOS.SysProfileSettings.EnergyEfficientTurbo (Read or Write) 447
BIOS.SysProfileSettings.EnergyPerformanceBias (Read or Write) 447
BIOS.SysProfileSettings.MemFrequency (Read or Write) 448
BIOS.SysProfileSettings.MemPatrolScrub (Read or Write) 448
BIOS.SysProfileSettings.MemPwrMgmt (Read or Write) 449
BIOS.SysProfileSettings.MemRefreshRate (Read or Write) 449
BIOS.SysProfileSettings.MemVolt (Read or Write) 449
BIOS.SysProfileSettings.MonitorMwait (Read or Write) 450

BIOS.SysProfileSettings.PowerDelivery (Read or Write) 450
BIOS.SysProfileSettings.Proc1TurboCoreNum (Read or Write) 450
BIOS.SysProfileSettings.Proc2TurboCoreNum (Read or Write) 451
BIOS.SysProfileSettings.ProcC1E (Read or Write) 451
BIOS.SysProfileSettings.ProcCStates (Read or Write) 451
BIOS.SysProfileSettings.ProcPwrPerf (Read or Write) 452
BIOS.SysProfileSettings.PowerSaver (Read or Write) 452
BIOS.SysProfileSettings.ProcTurboMode (Read or Write) 452
BIOS.SysProfileSettings.SysProfile (Read or Write) 453
BIOS.SysProfileSettings.TpmCommand (Read or Write) 453
BIOS.SysProfileSettings.UncoreFrequency (Read or Write) 453
BIOS.SysProfileSettings.WorkloadProfile (Read or Write) 454
BIOS.SysProfileSettings.WriteDataCrc 454
BIOS.SysSecurity 454
BIOS.SysSecurity.AcPwrRcvry (Read or Write) 454
BIOS.SysSecurity.AcPwrRcvryDelay (Read or Write) 455
BIOS.SysSecurity.AcPwrRcvryUserDelay (Read or Write) 455
BIOS.SysSecurity.Aesni (Read or Write) 455
BIOS.SysSecurity.BiosUpdateControl (Read or Write) 456
BIOS.SysSecurity.IntelTxt (Read or Write) 456
BIOS.SysSecurity.NmiButton (Read or Write) 457
BIOS.SysSecurity.PasswordStatus (Read or Write) 457
BIOS.SysSecurity.PwrButton (Read or Write) 457
BIOS.SysSecurity.SecureBoot (Read or Write) 457
BIOS.SysSecurity.SecureBootPolicy (Read or Write) 458
BIOS.SysSecurity.SetupPassword (Read or Write) 458
BIOS.SysSecurity.SHA256SetupPassword (Read or Write) 459
BIOS.SysSecurity.SHA256SetupPasswordSalt (Read or Write) 459
BIOS.SysSecurity.SignedFirmwareUpdate (Read or Write) 459
BIOS.SysSecurity.SysPassword (Read or Write) 459
BIOS.SysSecurity.SHA256SystemPassword (Read or Write) 460
BIOS.SysSecurity.SHA256SystemPasswordSalt (Read or Write) 460
BIOS.SysSecurity.TcmActivation (Read or Write) 460
BIOS.SysSecurity.TcmClear (Read or Write) 461
BIOS.SysSecurity.TcmSecurity (Read or Write) 461
BIOS.SysSecurity.TpmActivation (Read or Write) 461
BIOS.SysSecurity.TpmClear (Read or Write) 462
BIOS.SysSecurity.TpmFirmware 462
BIOS.SysSecurity.TpmInfo (Read Only) 462
BIOS.SysSecurity.TpmPpiBypassClear 463
BIOS.SysSecurity.TpmPpiBypassProvision 463
BIOS.SysSecurity.TpmSecurity (Read or Write) 463
BIOS.SysSecurity.TPMStatus (Read Only) 464
BIOS.SysSecurity.UefiVariableAccess (Read or Write) 464
BIOS.UefiBootSettings 464
BIOS.UefiBootSettings.UefiBootSeq (Read or Write) 464
BIOS.UefiBootSettings.UefiPxeIpVersion (Read or Write) 465
FC.FCDevice 465
FC.FCDevice.BusDeviceFunction (Read Only) 465
FC.FCDevice.ChipMdl (Read Only) 465

FC.FCDevice.EFIVersion (Read Only)....466
FC.FCDevice.FamilyVersion (Read Only)....466
FC.FCDevice.PCIDeviceID (Read Only)....466
FC.FCTarget....466
FC.FCTarget.BootScanSelection (Read or Write)....466
FC.FCTarget.FirstFCTargetLUN (Read or Write)....467
FC.FCTarget.SecondFCTargetLUN (Read or Write)....467
FC.FCTarget.FirstFCTargetWWPN (Read or Write)....467
FC.FCTarget.SecondFCTargetWWPN (Read or Write)....468
FC.HBAConfig....468
FC.HBAConfig.FCTape (Read or Write)....468
FC.HBAConfig.FabricLoginTimeout (Read or Write)....468
FC.HBAConfig.FabricLoginRetryCount (Read or Write)....469
FC.HBAConfig.FramePayloadSize (Read or Write)....469
FC.HBAConfig.HardZone (Read or Write)....469
FC.HBAConfig.HardZoneAddress (Read or Write)....470
FC.HBAConfig.LinkDownTimeout (Read or Write)....470
FC.HBAConfig.LoopResetDelay (Read or Write)....470
FC.HBAConfig.PortDownRetryCount (Read or Write)....470
FC.HBAConfig.PortDownTimeout (Read or Write)....471
FC.HBAConfig.PortLoginRetryCount (Read or Write)....471
FC.HBAConfig.PortLoginTimeout (Read or Write)....471
FC.PortConfig....472
FC.PortConfig.DeviceName (Read Only)....472
FC.PortConfig.FCDevice (Read Only)....472
FC.PortConfig.FCTarget (Read Only)....472
FC.PortConfig.HBAConfig (Read Only)....472
FC.PortConfig.PortNumber (Read Only)....473
FC.PortConfig.PortSpeed (Read or Write)....473
FC.PortConfig.VirtualWWN (Read or Write)....473
FC.PortConfig.VirtualWWPN (Read or Write)....474
FC.PortConfig.WWN (Read Only)....474
FC.PortConfig.WWPN (Read Only)....474
NIC.ConfigureFormn....475
NIC.ConfigureFormn.BusDeviceFunction (Read Only)....475
NIC.ConfigureFormn.MacAddr (Read Only)....475
NIC.ConfigureFormn.FIPMacAddr (Read Only)....475
NIC.ConfigureFormn.IscsiMacAddr (Read Only)....475
NIC.ConfigureFormn.iScsiOffloadMode (Read or Write)....476
NIC.ConfigureFormn.FCoEOffloadMode (Read or Write)....476
NIC.ConfigureFormn.NicMode (Read or Write)....476
NIC.ConfigureFormn.PCIDeviceID (Read Only)....477
NIC.ConfigureFormn.WWN (Read Only)....477
NIC.ConfigureFormn.WWPN (Read Only)....477
NIC_ConfigureFormn.VirtWWN (Read or Write)....478
NIC_ConfigureFormn.VirtWWPN (Read or Write)....478
NIC_ConfigureFormn.VirtMacAddr (Read or Write)....478
NIC_ConfigureFormn.VirtIscsiMacAddr (Read or Write)....478
NIC_ConfigureFormn.VirtFIPMacAddr (Read or Write)....479
NIC.DCBSettings....479

NIC.DCBSettings.CongestionNotification (Read Only) 479
NIC.DCBSettings.DCBExchangeProtocol (Read Only) 479
NIC.DCBSettings.EnhancedTransmissionSelection (Read Only) 480
NIC.DCBSettings.PriorityFlowControl (Read Only) 480
NIC.DeviceLevelConfig 480
NIC.DeviceLevelConfig.EVBModesSupport (Read Only) 480
NIC.DeviceLevelConfig.FlowControlSetting (Read or Write) 481
NIC.DeviceLevelConfig.NParEP (Read or Write) 481
NIC.DeviceLevelConfig.NumberVFSupported (Read Only) 481
NIC.DeviceLevelConfig.SRIOVSupport (Read Only) 482
NIC.DeviceLevelConfig.VFAllocBasis (Read Only) 482
NIC.DeviceLevelConfig.VFAllocMult (Read Only) 482
NIC.DeviceLevelConfig.VirtualizationMode (Read or Write) 483
NIC.FCOECapabilities 483
NIC.FCOECapabilities.AddressingMode (Read Only) 483
NIC.FCOECapabilities.MaxFrameSize (Read Only) 483
NIC.FCOECapabilities.MaxIOsPerSession (Read Only) 484
NIC.FCOECapabilities.MaxNPIVPerPort (Read Only) 484
NIC.FCOECapabilities.MaxNumberExchanges (Read Only) 484
NIC.FCOECapabilities.MaxNumberLogins (Read Only) 485
NIC.FCOECapabilities.MaxNumberOfFCTargets (Read Only) 485
NIC.FCOECapabilities.MaxNumberOutStandingCommands (Read Only) 485
NIC.FCOECapabilities.MTUReconfigurationSupport (Read Only) 485
NIC.FCoEConfiguration 486
NIC.FCoEConfiguration.ConnectFirstFCoETarget (Read or Write) 486
NIC.FCoEConfiguration.BootOrderFirstFCoETarget (Read or Write) 486
NIC.FCoEConfiguration.BootOrderSecondFCoETarget (Read or Write) 487
NIC.FCoEConfiguration.BootOrderThirdFCoETarget (Read or Write) 487
NIC.FCoEConfiguration.BootOrderFourthFCoETarget (Read or Write) 487
NIC.FCoEConfiguration.FirstFCoEBootTargetLUN (Read or Write) 487
NIC.FCoEConfiguration.FirstFCoEFCFVLANID (Read or Write) 488
NIC.FCoEConfiguration.FirstFCoEWWPNTarget (Read or Write) 488
NIC.FCoEConfiguration.MTUParams (Read or Write) 488
NIC.FCoEGenParams 489
NIC.FCoEGenParams.FCoEBootScanSelection (Read or Write) 489
NIC.FCoEGenParams.FCoEFabricDiscoveryRetryCnt (Read or Write) 489
NIC.FCoEGenParams.FCoEFirstHddTarget (Read or Write) 490
NIC.FCoEGenParams.FCoELnkUpDelayTime (Read or Write) 490
NIC.FCoEGenParams.FCoELunBusyRetryCnt (Read or Write) 490
NIC.FCoEGenParams.FCoETgtBoot (Read or Write) 491
NIC.FrmwImgMenu 491
NIC.FrmwImgMenu.ControllerBIOSVersion (Read Only) 491
NIC.FrmwImgMenu.EFIVersion (Read Only) 491
NIC.FrmwImgMenu.FamilyVersion (Read Only) 492
NIC.GlobalBandwidthAllocation 492
NIC.GlobalBandwidthAllocation.MaxBandwidth (Read or Write) 492
NIC.GlobalBandwidthAllocation.MinBandwidth (Read or Write) 492
NIC.IscsiFirstTgtParams 493
NIC.IscsiFirstTgtParams.AddressingMode (Read or Write) 493
NIC.IscsiFirstTgtParams.ConnectFirstTgt (Read or Write) 493

NIC.IscsiFirstTgtParams.FirstTgtBootLun (Read or Write) 493
NIC.IscsiFirstTgtParams.FirstTgtChapId (Read or Write) 494
NIC.IscsiFirstTgtParams.FirstTgtChapPwd (Password) 494
NIC.IscsiFirstTgtParams.FirstTgtIpAddress (Read or Write) 494
NIC.IscsiFirstTgtParams.FirstTgtIpVer (Read or Write) 494
NIC.IscsiFirstTgtParams.FirstTgtIscsiName (Read or Write) 495
NIC.IscsiFirstTgtParams.FirstTgtTcpPort (Read or Write) 495
NIC.IscsiGenParams 495
NIC.IscsiGenParams.ChapAuthEnable (Read or Write) 496
NIC.IscsiGenParams.ChapMutualAuth (Read or Write) 496
NIC.IscsiGenParams.DhcpVendId (Read or Write) 496
NIC.IscsiGenParams.FirstHddTarget (Read or Write) 497
NIC.IscsiGenParams.IpAutoConfig (Read or Write) 497
NIC.IscsiGenParams.IpVer (Read or Write) 497
NIC.IscsiGenParams.IscsiTgtBoot (Read or Write) 498
NIC.IscsiGenParams.IscsiViaDHCP (Read or Write) 498
NIC.IscsiGenParams.IscsiVLanId (Read or Write) 498
NIC.IscsiGenParams.IscsiVLanMode (Read or Write) 498
NIC.IscsiGenParams.LnkUpDelayTime (Read or Write) 499
NIC.IscsiGenParams.LunBusyRetryCnt (Read or Write) 499
NIC.IscsiGenParams.TcpIpViaDHCP (Read or Write) 499
NIC.IscsiGenParams.TcpTimestmp (Read or Write) 500
NIC.IscsiGenParams.WinHbaBootMode (Read or Write) 500
NIC.IscsiInitiatorParams 500
NIC.IscsiInitiatorParams.IscsiInitiatorChapId (Read or Write) 500
NIC.IscsiInitiatorParams.IscsiInitiatorChapPwd (Read or Write) 501
NIC.IscsiInitiatorParams.IscsiInitiatorGateway (Read or Write) 501
NIC.IscsiInitiatorParams.IscsiInitiatorIpAddr (Read or Write) 501
NIC.IscsiInitiatorParams.IscsiInitiatorName (Read or Write) 502
NIC.IscsiInitiatorParams.IscsiInitiatorPrimDns (Read or Write) 502
NIC.IscsiInitiatorParams.IscsiInitiatorSecDns (Read or Write) 502
NIC.IscsiInitiatorParams.IscsiInitiatorSubnet (Read or Write) 503
NIC.IscsiInitiatorParams.IscsiInitiatorSubnetPrefix (Read or Write) 503
NIC.IscsiSecondaryDeviceParams 503
NIC.IscsiSecondaryDeviceParams.SecondaryDeviceMacAddr (Read or Write) 503
NIC.IscsiSecondaryDeviceParams.UseIndTgtName (Read or Write) 504
NIC.IscsiSecondaryDeviceParams.UseIndTgtPortal (Read or Write) 504
NIC.IscsiSecondTgtParams 504
NIC.IscsiSecondTgtParams.ConnectSecondTgt (Read or Write) 504
NIC.IscsiSecondTgtParams.SecondTgtBootLun (Read or Write) 505
NIC.IscsiSecondTgtParams.SecondTgtChapId (Read or Write) 505
NIC.IscsiSecondTgtParams.SecondTgtChapPwd (Read or Write) 505
NIC.IscsiSecondTgtParams.SecondTgtIpAddress (Read or Write) 505
NIC.IscsiSecondTgtParams.SecondTgtIpVer (Read or Write) 506
NIC.IscsiSecondTgtParams.SecondTgtIscsiName (Read or Write) 506
NIC.IscsiSecondTgtParams.SecondTgtTcpPort (Read or Write) 506
NIC.NICConfig 507
NIC.NICConfig.BannerMessageTimeout (Read or Write) 507
NIC.NICConfig.BootOptionROM (Read or Write) 507
NIC.NICConfig.BootRetryCnt (Read or Write) 507

NIC.NICConfig.BootStrapType (Read or Write) 508
NIC.NICConfig.HideSetupPrompt (Read or Write) 508
NIC.NICConfig.LegacyBootProto (Read or Write) 509
NIC.NICConfig.LnkSpeed (Read or Write) 509
NIC.NICConfig.NumberVFAdvertised (Read or Write) 509
NIC.NICConfig.VLanId (Read or Write) 510
NIC.NICConfig.VLanMode (Read or Write) 510
NIC.NICConfig.WakeOnLan (Read or Write) 510
NIC.NICConfig.WakeOnLanLnkSpeed (Read or Write) 510
NIC.NICPartitioningConfig 511
NIC.NICPartitioningConfig.NicPartitioning (Read or Write) 511
NIC.NICPartitioningConfig.PartitionState (Read Only) 511
NIC.NICPartitioningConfig.ConfigureFormn (Read Only) 512
NIC.NICPartitioningConfig.NumberPCIEFunctionsEnabled (Read Only) 512
NIC.NICPartitioningConfig.NumberPCIEFunctionsSupported (Read Only) 512
NIC.VndrConfigGroup 512
NIC.VndrConfigGroup.BusDeviceFunction (Read Only) 513
NIC.VndrConfigGroup.BlnkLeds (Read or Write) 513
NIC.VndrConfigGroup.ChipMdl (Read Only) 513
NIC.VndrConfigGroup.EnergyEfficientEthernet (Read Only) 513
NIC.VndrConfigGroup.DCBXSupport (Read Only) 514
NIC.VndrConfigGroup.DeviceName (Read Only) 514
NIC.VndrConfigGroup.FCoEBootSupport (Read Only) 514
NIC.VndrConfigGroup.FCoEOffloadMode (Read or Write) 515
NIC.VndrConfigGroup.FCoEOffloadSupport (Read Only) 515
NIC.VndrConfigGroup.FeatureLicensingSupport (Read Only) 515
NIC.VndrConfigGroup.FIPMacAddr (Read Only) 515
NIC.VndrConfigGroup.FlexAddressing (Read Only) 516
NIC.VndrConfigGroup.iSCSIBootSupport (Read Only) 516
NIC.VndrConfigGroup.ISCSIMacAddr (Read Only) 516
NIC.VndrConfigGroup.iSCSIOffloadMode (Read or Write) 517
NIC.VndrConfigGroup.iSCSIOffloadSupport (Read Only) 517
NIC.VndrConfigGroup.LinkStatus (Read Only) 517
NIC.VndrConfigGroup.MacAddr (Read Only) 518
NIC.VndrConfigGroup.NicMode (Read or Write) 518
NIC.VndrConfigGroup.NicPartitioningSupport (Read Only) 518
NIC.VndrConfigGroup.NWManagementPassThrough (Read Only) 518
NIC.VndrConfigGroup.OnChipThermalSensor (Read Only) 519
NIC.VndrConfigGroup.OSBMCManagementPassThrough (Read Only) 519
NIC.VndrConfigGroup.PCIDeviceID (Read Only) 519
NIC.VndrConfigGroup.PXEBootSupport (Read Only) 520
NIC.VndrConfigGroup.RemotePHY (Read Only) 520
NIC.VndrConfigGroup.RXFlowControl (Read Only) 520
NIC.VndrConfigGroup.TOESupport (Read Only) 521
NIC.VndrConfigGroup.TXBandwidthControlMaximum (Read Only) 521
NIC.VndrConfigGroup.TXBandwidthControlMinimum (Read Only) 521
NIC.VndrConfigGroup.TXFlowControl (Read Only) 521
NIC.VndrConfigGroup.VirtFIPMacAddr (Read or Write) 522
NIC.VndrConfigGroup.VirtIscsiMacAddr (Read or Write) 522
NIC.VndrConfigGroup.VirtMacAddr (Read or Write) 522

NIC.VndrConfigGroup.VirtualLinkControl (Read or Write) 523
NIC.VndrConfigGroup.VirtWWN (Read or Write) 523
NIC.VndrConfigGroup.VirtWWPN (Read or Write) 523
NIC.VndrConfigGroup.WWN (Read Only) 524
NIC.VndrConfigGroup.WWPN (Read Only) 524
NIC.VndrConfigPage 524
NIC.VndrConfigPage.BlnkLeds (Read or Write) 524
NIC.VndrConfigPage.BusDeviceFunction (Read Only) 524
NIC.VndrConfigPage.ChipMdl (Read Only) 525
NIC.VndrConfigPage.DeviceName (Read Only) 525
NIC.VndrConfigPage.FCoEBootSupport (Read Only) 525
NIC.VndrConfigPage.FIPMacAddr (Read Only) 525
NIC.VndrConfigPage.FlexAddressing (Read Only) 526
NIC.VndrConfigPage.iSCSIBootSupport (Read Only) 526
NIC.VndrConfigPage.iSCSIDualIPVersionSupport (Read Only) 526
NIC.VndrConfigPage.iScsiOffloadMode (Read or Write) 526
NIC.VndrConfigPage.iSCSIOffloadSupport (Read Only) 527
NIC.VndrConfigPage.LinkStatus (Read Only) 527
NIC.VndrConfigPage.MacAddr (Read Only) 527
NIC.VndrConfigPage.NicPartitioningSupport (Read Only) 527
NIC.VndrConfigPage.PCIDeviceID (Read Only) 528
NIC.VndrConfigPage.PXEBootSupport (Read Only) 528
NIC.VndrConfigPage.TOESupport (Read Only) 528
NIC.VndrConfigPage.VirtFIPMacAddr (Read or Write) 528
NIC.VndrConfigPage.VirtMacAddr (Read or Write) 529
NIC.VndrConfigPage.VirtWWN (Read or Write) 529
NIC.VndrConfigPage.VirtWWPN (Read or Write) 529
NIC.VndrConfigPage.WWN (Read Only) 529
NIC.VndrConfigPage.WWPN (Read Only) 530
Storage.Controller 530
Storage.Controller.BackgroundInitializationRate (Read or Write) 530
Storage.Controller.BatteryLearnMode (Read Only) 530
Storage.Controller.CheckConsistencyMode (Read or Write) 531
Storage.Controller.CheckConsistencyRate (Read or Write) 531
Storage.Controller.ControllerBootMode (Read or Write) 531
Storage.Controller.CopybackMode (Read or Write) 531
Storage.Controller.CurrentControllerMode (Read Only) 532
Storage.Controller.EnhancedAutoImportForeignConfig (Read or Write) 532
Storage.Controller.PatrolReadMode (Read or Write) 532
Storage.Controller.PatrolReadRate (Read or Write) 533
Storage.Controller.PatrolReadUnconfiguredArea (Read or Write) 533
Storage.Controller.Persisthotspare(Read or Write) 533
Storage.Controller.PossibleloadBalancedMode (Read or Write) 534
Storage.Controller.RebuildRate (Read or Write) 534
Storage.Controller.ReconstructRate (Read or Write) 534
Storage.Controller.RequestedControllerMode (Read or Write) 534
Storage.Controller.SupportControllerBootMode (Read Only) 535
Storage.Controller.SupportEnhancedAutoForeignImport (Read Only) 535
Storage.Controller.SupportRAID10UnevenSpans (Read Only) 535
Storage.Controller.T10PICapability (Read Only) 536

Storage.enclosure....536
Storage.enclosure.BackplaneCurrentMode (Read Only)....536
Storage.enclosure.BackplaneRequestedMode (Read or Write)....536
Storage.enclosure.BackplaneType (Read Only)....537
Storage.PhysicalDisk....537
Storage.PhysicalDisk.BlockSizeInBytes (Read Only)....537
Storage.PhysicalDisk.MaxCapableSpeed (Read Only)....538
Storage.PhysicalDisk.RaidNominalMediumRotationRate (Read Only)....538
Storage.PhysicalDisk.T10PICapability (Read Only)....538
Storage.VirtualDisk....538
Storage.VirtualDisk.BlockSizeInBytes (Read Only)....539
Storage.VirtualDisk.DiskCachePolicy (Read or Write)....539
Storage.VirtualDisk.ReadPolicy (Read or Write)....539
Storage.VirtualDisk.T10PIStatus (Read or Write)....540
Storage.VirtualDisk.WritePolicy (Read or Write)....540

Appendix A: Deprecated and New Subcommands....541

Appendix B: Legacy and New Groups and Objects....542
cfgSSADRoleGroupPrivilege (Read or Write)....552

1

Introduction

This document provides information about the RACADM subcommands, supported RACADM interfaces, and property database groups and object definitions for the following:

- iDRAC for Blade Servers
- iDRAC on Rack and Tower Servers

Most of the commands mentioned in this document are applicable for multi-generation servers. That is, the commands are applicable for iDRAC6, iDRAC7, and iDRAC8. For more information on the commands applicable for a particular iDRAC version, see the *iDRAC RACADM Support Matrix* available athttps://www.dell.com/esmmanuals

NOTE:

- From iDRAC version 2.00.00.00, the guide provides information specific to iDRAC. For information specific to Chassis Management Controller (CMC) M1000e, refer to *Chassis Management Controller M1000e Version 6.2 RACADM Command Line Reference Guide* available at https://www.dell.com/cmcmanuals.
- The appendix section in the guide provides:
  - List of deprecated sub-commands.
  - List of legacy groups and objects with the equivalent new groups and objects.

Topics:

- New in this release
- Supported RACADM Interfaces
- RACADM Syntax Usage
- Proxy parameters
- Supported RACADM Subcommands
- Other Documents You May Need
- Accessing support content from the Dell EMC support site
- Contacting Dell

New in this release

- Added idrac.webserver.HostHeaderCheck attribute to enable or disable HTTP Host request header validation.
- Added idrac.webserver.ManualDNSEntry attribute to configure TLS SAN domain names for validating HTTP Host header.

Supported RACADM Interfaces

The RACADM command-line utility provides a scriptable interface that allows you to locally configure or remotely configure your iDRAC. The utility runs on the management station and the managed system. It is available on the *Dell OpenManage Systems Management and Documentation* DVD or at www.dell.com/support/home.

The RACADM utility supports the following interfaces:

- Local — Supports running RACADM commands from the managed server's operating system. To run local RACADM commands, install the OpenManage software on the managed server. Only one instance of Local RACADM can be executed on a system at a time. If you try to open another instance, an error message is displayed and the second instance of Local RACADM closes immediately. To download the local RACADM tool from www.dell.com/support/home, select **Drivers and Downloads**, select a server, and then select **Systems Management** > **Dell Toolkit**.

  NOTE: Local racadm and local racadm proxy runs with root user privilege.
- SSH or Telnet — Also known as Firmware RACADM. Firmware RACADM is accessible by logging in to iDRAC using SSH or Telnet. Similar to Remote RACADM, at the RACADM prompt, directly run the commands without the RACADM prefix.

- Remote — Supports running RACADM commands from a remote management station such as a laptop or desktop. To run Remote RACADM commands, install the DRAC Tools utility from the OpenManage software on the remote computer. To run Remote RACADM commands:
  - Formulate the command as a SSH or Telnet RACADM command.

  For more information about the options, see RACADM Subcommand Details. To download the local RACADM tool from www.dell.com/support/home, click **Servers, Storage & Networking** in the **General Support** section. Click **PowerEdge**, click the required PowerEdge system, and then click **Drivers & downloads**.

RACADM Syntax Usage

The following section describes the syntax usage for SSH or Telnet, and Remote RACADM.

NOTE: The RACADM command-line interface in CMC does not ignore single or double quotation. When you enter an open quotation mark, ensure that you enter the close quotation mark too.

SSH, Telnet, or Remote RACADM

```
racadm -r <racIPAddr><cmcIPAddr> -u username -p password <subcommand>
```

```
racadm -r <racIPAddr><cmcIPAddr> -u username -p password getconfig -g <group name> -o
<object name>
```

```
racadm <subcommand>
```

Example

```
racadm getsysinfo
```

```
racadm -r 192.168.0.2 -u username -p xxx getsysinfo
```

```
racadm -r 192.168.0.2 -u username -p xxx getconfig -g cfgchassispower
```

Remote RACADM

```
racadm -r <racIPAddr><cmcIPAddr> -u <username> -p <password> <subcommand>
```

Example

```
racadm -r 192.168.0.2 -u root -p xxxx getsysinfo
Security Alert: Certificate is invalid - Certificate is not signed by Trusted Third
Party Continuing execution.
```

NOTE: The following command does not display a security error:

```
racadm -r 192.168.0.2 -u noble -p xxx getsysinfo --nocertwarn
```

Accessing Indexed-Based Device Groups and Objects

- To access any object, run the following syntax:

  ```
  device.<group name>.[<index>].<object name>
  ```

- To display the supported indexes for a specified group, run:

```
racadm get device.<group name>
```

Example

```
racadm get nic.nicconfig
NIC.nicconfig.1 [Key=NIC.Integrated.1-1-1#nicconfig]
NIC.nicconfig.2 [Key=NIC.Integrated.1-2-1#nicconfig]
NIC.nicconfig.3 [Key=NIC.Integrated.1-3-1#nicconfig]
NIC.nicconfig.4 [Key=NIC.Integrated.1-4-1#nicconfig]
```

- To display the object list for the specified group, run:

```
racadm get device.<group name>.<index>
```

Example

```
racadm get nic.nicconfig.2
[Key=NIC.Integrated.1-2-1#nicconfig]
BannerMessageTimeout=5
BootStrapType=AutoDetect
HideSetupPrompt=Disabled
LegacyBootProto=NONE
LnkSpeed=AutoNeg
#VLanId=1
VLanMode=Disabled
```

- To display a single object for the specified group, run:

```
racadm get device.<group name>.<index>.<object name>
```

Example

```
racadm get nic.nicconfig.3.legacybootproto
[Key=NIC.Integrated.1-3#NICConfig]
Legacybootproto=PXE
```

RACADM Command Options

The following table lists the options for the RACADM command:

Table 1. RACADM Command Options

Option	Description
`-r <cmcIpAddr>`	Specifies the IP address of the controller.
`-r <racIpAddr>` `-r <racIpAddr> : <port number>`	Specifies the remote IP address of the controller. Use `<port number>` if the iDRAC port number is not the default port (443).
`-u <username>`	Specifies the username that is used to authenticate the command transaction. If the `-u` option is used, the `-p` option must be used, and the `-i` option (interactive) is not allowed. **NOTE:** If you are using CIFS that is registered with a domain, and are accessing the CIFS using the IP with the CIFS local user credentials, it is mandatory to enter the hostname or host IP with the -u option. The format is - `<hostname/username>` or `<host IP/username>`
`-p <password>`	Specifies the password that is used to authenticate the command transaction. If the `-p` option is used, the `-i` option is not allowed.

Table 1. RACADM Command Options (continued)

Option	Description
	NOTE: CMC does not support extended ASCII characters, such as ß, å, é, ü, or other characters used primarily in non-English languages. Setting values with these characters causes unpredictable behavior.
`--nocertwarn`	Does not display certificate-related warning message.
`-i <indexnumber>`	Specifies the index number for the indexed group, if applicable.
`-g <groupname>`	Specifies the group name if applicable.
`-o <objectname>`	Specifies the object name if applicable.

Using autocomplete feature

Use the autocomplete feature to:

- Display all the available RACADM commands in the alphabetical order on pressing the **Tab** key at the prompt.
- View the complete list, enter the starting letter of the command at the prompt and press **Tab** key.
- Navigate the cursor within a command, press:

  Home key: Directs to the starting of the command.

  End key: Directs to the end of the command.
- View the history of the commands that were run in the current session, press **up** and **down** arrow key.
- Exit the Autocomplete mode, enter `Quit`, `Exit`, or press **Ctrl+D** key.

For example:

- **Example 1**: `racadm> <press tab>`

```
arp
autoupdatescheduler
clearasrscreen
clearpending
closessn
clrraclog
.
.
.
.
.
.
.
vflashsd
vflashpartition
vmdisconnect
cd
quit
```

- **Example 2**: `racadm> get <press tab>`

```
get
getconfig
getled
getniccfg
getraclog
getractime
getsel
getsensorinfo
getssninfo
getsvctag
getsysinfo
```

```
gettracelog
getversion
```

- **Example 3**:

```
racadm> getl<press tab>
```

```
racadm> getled <press enter> or <racadm getled>
LEDState: Not-Blinking
```

- **Example 4**:

```
racadm>> get bios.uefiBootSettings
BIOS.UefiBootSettings
BIOS.UefiBootSettings.UefiBootSeq
BIOS.UefiBootSettings.UefiPxeIpVersion
```

NOTE: In the RACADM autocomplete mode, some of the RACADM commands specific to certain server platforms may not be available. In such scenarios, execute the RACADM command in the normal execution mode.

NOTE: In the RACADM autocomplete mode, type the commands directly without giving racadm as prefix.

NOTE: The RACADM get or set attributes with value length up to 512 characters are supported from autocomplete mode. If the value length is 512 characters or more, execute the RACADM command in the normal execution mode.

Lifecycle Controller Log

Lifecycle Controller logs provide the history of changes related to components installed on a managed system. You can also add work notes to each log entry.

The following events and activities are logged:

- System events
- Storage devices
- Network devices
- Configuration
- Audit
- Updates

You can view and filter logs based on the category and severity level. You can also export and add a work note to a log event.

If you initiate configuration jobs using RACADM CLI or iDRAC web interface, the Lifecycle log captures the information about the user, interface used, and the IP address of the system from which you initiate the job.

Proxy parameters

Some commands do not support setting the proxy parameters if the share location (-l) is HTTP/HTTPS. To perform the operation with HTTP or HTTPS through a proxy, the proxy parameters must be first configured using the lifecyclecontroller.lcattributes. Once these proxy parameters are configured, they become the part of default configuration; the proxy attributes should be cleared to end use of the HTTP/HTTPS proxy.

The valid lifecyclecontroller.lcattributes HTTP/HTTPS proxy parameters are:

- `UserProxyUserName`
- `UserProxyPassword`
- `UserProxyServer`
- `UserProxyPort`
- `UserProxyType`

To view the list of proxy attributes, use `racadm get lifecycleController.lcAttributes`.

NOTE: Squid proxy configuration is not supported to access HTTP/HTTPS shares.

Supported RACADM Subcommands

The following table provides the list of RACADM subcommands and their corresponding interface support. For more information about the RACADM subcommands including syntax and valid entries, see RACADM Subcommand Details on page 42.

Table 2. Supported RACADM Subcommands

Subcommand	iDRAC on Blade Servers		
	Telnet/SSH/ Serial	Local RACADM	Remote RACADM
autoupdatescheduler on page 45	Yes	Yes	Yes
arp on page 45	Yes	Yes	Yes
clearasrscreen on page 48	Yes	Yes	Yes
clearpending on page 48	Yes	Yes	Yes
closessn on page 49	Yes	Yes	Yes
clrsel on page 50	Yes	Yes	Yes
config on page 50	Yes	Yes	Yes
coredump on page 51	Yes	Yes	Yes
coredumpdelete on page 52	Yes	Yes	Yes
diagnostics on page 52	Yes	Yes	Yes
eventfilters on page 53	Yes	Yes	Yes
fcstatistics on page 55	Yes	Yes	Yes
frontpanelerror on page 55	Yes	Yes	Yes
fwupdate on page 56	Yes	Yes	Yes
get on page 61	Yes	Yes	Yes
getconfig on page 63	Yes	Yes	Yes
gethostnetworkinterfaces on page 66	Yes	Yes	Yes
getled on page 67	Yes	Yes	Yes
getniccfg on page 67	Yes	Yes	Yes
getraclog on page 69	Yes	Yes	Yes
getractime on page 71	Yes	Yes	Yes
getsel on page 72	Yes	Yes	Yes
getsensorinfo on page 73	Yes	Yes	Yes
getssninfo on page 77	Yes	Yes	Yes
getsvctag on page 77	Yes	Yes	Yes
getsysinfo on page 78	Yes	Yes	Yes
gettracelog on page 80	Yes	Yes	Yes
getversion on page 81	Yes	Yes	Yes
Help and help subcommand on page 44	Yes	Yes	Yes
hwinventory on page 83	Yes	Yes	Yes
ifconfig on page 87	Yes	Yes	Yes
inlettemphistory on page 87	Yes	Yes	Yes

Table 2. Supported RACADM Subcommands (continued)

Subcommand	iDRAC on Blade Servers		
	Telnet/SSH/ Serial	Local RACADM	Remote RACADM
jobqueue on page 89	Yes	Yes	Yes
krbkeytabupload on page 90	No	Yes	Yes
lclog on page 91	Yes	Yes	Yes
license on page 94	Yes	Yes	Yes
nicstatistics on page 96	Yes	Yes	Yes
ping on page 97	Yes	Yes	Yes
ping6 on page 98	Yes	Yes	Yes
racdump on page 100	Yes	No	Yes
racreset on page 104	Yes	Yes	Yes
racresetcfg on page 105	Yes	Yes	Yes
remoteimage on page 106	Yes	Yes	Yes
rollback on page 107	Yes	Yes	Yes
sensorsettings on page 108	Yes	Yes	Yes
serveraction on page 108	Yes	Yes	Yes
set on page 110	Yes	Yes	Yes
setled on page 113	Yes	Yes	Yes
setniccfg on page 114	Yes	Yes	Yes
sshpkauth on page 116	Yes	Yes	Yes
sslcertupload on page 118	No	Yes	Yes
sslcertview on page 118	Yes	Yes	Yes
sslcertdelete on page 120	Yes	Yes	Yes
sslcsrgen on page 121	Yes	Yes	Yes
sslkeyupload on page 122	No	Yes	Yes
sslresetcfg on page 122	Yes	Yes	Yes
storage on page 122	Yes	Yes	Yes
swinventory on page 142	Yes	Yes	Yes
systemconfig on page 143	Yes	Yes	Yes
systemerase on page 145	Yes	Yes	Yes
systemperfstatistics on page 146	Yes	Yes	Yes
techsupreport on page 147	Yes	Yes	Yes
testemail on page 148	Yes	Yes	Yes
testtrap on page 149	Yes	Yes	Yes
testalert on page 150	Yes	Yes	Yes
traceroute on page 150	Yes	Yes	Yes
traceroute6 on page 151	Yes	Yes	Yes
update on page 151	Yes	Yes	Yes

Table 2. Supported RACADM Subcommands (continued)

Subcommand	iDRAC on Blade Servers		
	Telnet/SSH/ Serial	Local RACADM	Remote RACADM
usercertupload on page 154	No	Yes	Yes
usercertview on page 155	Yes	Yes	Yes
vflashsd on page 156	Yes	Yes	Yes
vflashpartition on page 156	Yes	Yes	Yes
vmdisconnect on page 157	Yes	Yes	Yes

Other Documents You May Need

In addition to this guide, you can access the following guides available on the Dell Support website at https://www.dell.com/esmmanuals. To access the documents, click the appropriate product link.

- The *Integrated Dell Remote Access Controller 8 (iDRAC8) User's Guide* provides information about configuring and using an iDRAC to remotely manage and monitor your system and its shared resources through a network.
- The *iDRAC RACADM Support Matrix* provides the list of sub commands and objects that are applicable for a particular iDRAC version.
- Documentation specific to your third-party management console application.
- The *Dell OpenManage Server Administrator's User's Guide* provides information about installing and using Dell OpenManage Server Administrator.
- The *Dell Update Packages User's Guide* provides information about obtaining and using Dell Update Packages as part of your system update strategy.
- The *Glossary* provides information about the terms used in this document.

The following system documents are also available to provide more information about the system in which iDRAC is installed:

- The *Hardware Owner's Manual* provides information about system features and describes how to troubleshoot the system and install or replace system components.
- Documentation for any components you purchased separately provides information to configure and install the options.
- Release notes or readme files may be included to provide last-minute updates to the system or documentation or advanced technical reference material intended for experienced users or technicians.

Updates are sometimes included with the system to describe changes to the system, software, and/or documentation. Always read the updates first because they often supersede information in other documents.

See the *Safety and Regulatory* information that is shipped with your system.

NOTE: Warranty information may be included within this document or as a separate document.

Accessing support content from the Dell EMC support site

Access supporting content related to an array of systems management tools using direct links, going to the Dell EMC support site, or using a search engine.

- Direct links:
  - For Dell EMC Enterprise Systems Management and Dell EMC Remote Enterprise Systems Management—https://www.dell.com/esmmanuals
  - For Dell EMC Virtualization Solutions—www.dell.com/virtualizationsolutions
  - For Dell EMC OpenManage—https://www.dell.com/openmanagemanuals
  - For iDRAC—https://www.dell.com/idracmanuals
  - For Dell EMC OpenManage Connections Enterprise Systems Management—https://www.dell.com/OMConnectionsEnterpriseSystemsManagement
  - For Dell EMC Serviceability Tools—https://www.dell.com/serviceabilitytools

- Dell EMC support site:
  1. Go to https://www.dell.com/support.
  2. Click **Browse all products**.
  3. From the **All products** page, click **Software**, and then click the required link.
  4. Click the required product and then click the required version.

Using search engines, type the name and version of the document in the search box.

Contacting Dell

NOTE: If you do not have an active Internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.

Dell provides several online and telephone-based support and service options. Availability varies by country and product, and some services may not be available in your area. To contact Dell for sales, technical support, or customer service issues:

1. Go to **Dell.com/support**.
2. Select your support category.
3. Verify your country or region in the **Choose a Country/Region** drop-down list at the bottom of the page.
4. Select the appropriate service or support link based on your need.

2

RACADM Subcommand Details

This section provides detailed description of the RACADM subcommands including the syntax and valid entries.

Topics:

- Guidelines to Quote Strings Containing Special Characters When Using RACADM Commands
- Help and help subcommand
- arp
- autoupdatescheduler
- cd
- cd..
- clearasrscreen
- clearpending
- closessn
- clrsel
- config
- coredump
- coredumpdelete
- diagnostics
- eventfilters
- fcstatistics
- frontpanelerror
- fwupdate
- get
- getconfig
- gethostnetworkinterfaces
- getled
- getniccfg
- getraclog
- getractime
- getremoteservicesstatus
- getsel
- getsensorinfo
- getssninfo
- getsvctag
- getsysinfo
- gettracelog
- getversion
- hwinventory
- ifconfig
- inlettemphistory
- jobqueue
- krbkeytabupload
- lclog
- license
- netstat
- nicstatistics
- ping
- ping6
- RACADM Proxy
- racdump

- racreset
- racresetcfg
- remoteimage
- rollback
- sensorsettings
- serveraction
- set
- setled
- setniccfg
- sshpkauth
- sslcertdownload
- sslcertupload
- sslcertview
- sslcertdelete
- sslcsrgen
- sslkeyupload
- sslresetcfg
- storage
- swinventory
- systemconfig
- systemerase
- systemperfstatistics
- techsupreport
- testemail
- testtrap
- testalert
- traceroute
- traceroute6
- update
- usercertupload
- usercertview
- vflashsd
- vflashpartition
- vmdisconnect

Guidelines to Quote Strings Containing Special Characters When Using RACADM Commands

When using strings that contain special characters, use the following guidelines:

Strings containing the following special characters must be quoted using double quotation marks:

- $ (dollar sign)
- " (double quotation mark)
- ` (backward quotation mark)
- \ (backward slash)
- ~ (tilde)
- ; (semicolon)
- | (vertical bar)
- ((left parentheses)
-) (right parentheses)
- & (ampersand)
- > (greater than)
- < (less than)
- # (pound)
- ASCII code 32 (space)

NOTE: The - (dash) character cannot be the first character of the string, regardless of whether the string is quoted.

There are different escaping rules for double quotation marks.

There are different escaping rules for using single quotation mark and double quotation marks.

For using double quotation marks:

The following characters must be escaped by prepending a backward slash:

- $ (dollar sign)
- " (double quotation mark)
- ' (single quotation marks)
- ` (back quotation mark)
- \ (backward slash)

For example, use the following for a string that contains the special characters, $, ",',`and \.

For using single quotation marks:

- No character escaping is necessary.
- A single quotation mark cannot be used even with a backslash escaped.

NOTE: An empty string may be specified as ” “(using double quotation marks).

NOTE: An empty string may be specified as either "" (using double quotation marks) or '' (using single quotation mark).

Help and help subcommand

Table 3. Help and help subcommand

Description	Lists all the subcommands available for use with **RACADM** and provides a short description about each subcommand. You may also type a subcommand, group, object or Fully Qualified Descriptor (FQDD) name after `help`.
Synopsis	• `racadm help` • `racadm help <subcommand>` • `racadm help –g <groupname>` • `racadm help -g <groupname> –o <objectname>`
Input	• `<subcommand>` — specifies the subcommand for which you need the help information. • `<device name>` — specifies the device name such as iDRAC, BIOS, NIC, LifecycleController, FC, system, or Storage. • `<group>` — specifies the group name supported by the corresponding device. • `<object>` — specifies the object for the entered group.
Output	• The `help` command displays a complete list of subcommands. • The `racadm help <subcommand>` command displays information for the specified subcommand only. • The `racadm help –g <groupname>` command displays information for the specified group. • The `racadm help –o <objectname>` command displays information for the specified object. • The `racadm help <device name> <Group>` command displays information for the specified group. • The `racadm help <device name> <Object>` command displays information for the specified object. • The `racadm help <device name> <Group> <Object>` command displays information for the specified object.

arp

Table 4. arp table

Description	Displays the contents of the Address Resolution Protocol (ARP) table. ARP table entries cannot be added or deleted. To use this subcommand, you must have Debug privilege. To use this subcommand, you must have Execute Diagnostic Commands.
Synopsis	`racadm arp`
Input	N/A
Example	`racadm arp`

Table 5. Output

Address	HW Type	HW Address	Mask	Device
192.168.1.1	Ether	00:0d:65:f3:7c:bf	C	eth0

autoupdatescheduler

Table 6. Details of autoupdatescheduler

Description	You can automatically update the firmware of the devices on the server. To run this subcommand, you must have the Server Control privilege. **NOTE:** • The `autoupdatescheduler` subcommand can be enabled or disabled. • Lifecycle Controller and CSIOR may not be enabled to run this subcommand. • The autoupdatescheduler can be enabled or disabled. For more information, see LifecycleController.LCAttributes.autoupdate (Read or Write) • The minimum Lifecycle Controller version that is required is Lifecycle Controller 1.3. • When a job is already scheduled and the `clear` command is run, the scheduling parameters are cleared. • If the network share is not accessible or the catalog file is missing when the job is scheduled, then the job is unsuccessful.

Synopsis	• To create the AutoUpdateScheduler, run the command.
	`racadm autoupdatescheduler create -u <user> -p <password> -l <location> -f <filename> -time <time> -dom <DayOfMonth> -wom <WeekOfMonth> -dow <DayofWeek> -rp <repeat> -a <applyreboot> -ph <proxyHost> -pu <proxyUser> -pp <proxyPassword> -po <proxyPort> -pt <proxyType>`
	• To view AutoUpdateScheduler parameter, run the command.
	`racadm autoupdatescheduler view`
	• To clear and display AutoUpdateScheduler parameter, run the command.
	`racadm autoupdatescheduler clear`
	NOTE: After the parameters are cleared, the AutoUpdateScheduler is disabled. To schedule the update again, enable the AutoUpdateScheduler.

Table 6. Details of autoupdatescheduler (continued)

Input	Valid options: • `-u` — Specifies the user name of the remote share that stores the catalog file. **NOTE:** For CIFS, enter the domain name as domain or username. • `-p` — Specifies the password of the remote share that stores the catalog file. • `-l` — Specifies the network share (NFS, CIFS, FTP, TFTP, HTTP, or HTTPS) location of the catalog file. IPv4 and IPv6 addresses are supported. • `-f` — Specifies the catalog location and the filename. If the filename is not specified, then the default file that is used is `catalog.xml`. **NOTE:** If the file is in a subfolder within the share location, then enter the network share location in the `-l` option and enter the subfolder location and the filename in the `-f` option. • `-ph` — Specifies the FTP/HTTP proxy hostname. • `-pu` — Specifies the FTP/HTTP proxy user name. • `-pp` — Specifies the FTP/HTTP proxy password. • `-po` — Specifies the FTP/HTTP proxy port. • `-pt` — Specifies the FTP/HTTP proxy type. • `-time` — Specifies the time to schedule an autoupdate in the HH:MM format. This option must be specified. • `-dom` — Specifies the day of month to schedule an autoupdate. Valid values are 1–28, L (Last day) or `'*'` (default—any day). • `-wom` — Specifies the week of month to schedule an autoupdate. Valid values are 1–4, L (Last week) or `'*'` (default—any week). • `-dow` — Specifies the day of week to schedule an autoupdate. Valid values are sun, mon, tue, wed, thu, fri, sat, or `'*'` (default—any day). **NOTE:** The `-dom`, `-wom`, or `-dow` option must be in the command for the autoupdate schedule. The `*` value for the options must be included within `' '` (single quotation mark). • If the `-dom` option is specified, then the `-wom` and `-dow` options are not required. • If the`-wom` option is specified, then the`-dow` is required and `-dom` is not required. • If the`-dom` option is non-`'*'`, then the schedule repeats by month. • If the`-wom` option is non-`'*'`, then the schedule repeats by month. • If the`-dom` and `-wom` options are `'*'` and the `-dow` option is non-`'*'`, then the schedule repeats by week. • If all the three `-dom`, `-wom` and `-dow` options are `'*'`, then the schedule repeats by day. • `-rp` — Specifies the repeat parameter. This parameter must be specified. ○ If the`-dom` option is specified, then the valid values for `-rp` are 1–12. ○ If the`-wom` option is specified, then the valid values for `-rp` are 1–52. ○ If the`-dow` option is specified, then the valid values for `-rp` are 1–366. • `-a` — Applies reboot (1 — Yes, 0 — No). This option must be specified.

Example	Usage examples:
	• To configure autoupdate feature settings.
	○ For CIFS, run the command:
	`racadm autoupdatescheduler create -u domain/admin -p xxx -l // 1.2.3.4/share -f cat.xml -time 14:30 -wom 1 -dow sun -rp 1 -a 1`
	○ For NFS, run the command:
	`racadm autoupdatescheduler create -u nfsadmin -p nfspwd -l 1.2.3.4:/share -f cat.xml -time 14:30 -dom 1 -rp 5 -a 1`
	○ For FTP, run the command:
	`racadm autoupdatescheduler create -u ftpuser -p ftppwd -l` **`ftp.test.com`** `-f cat.xml.gz -ph 10.20.30.40 -pu padmin -pp ppwd -po 8080 -pt http -time 14:30 -dom 1 -rp 5 -a 1`

Table 6. Details of autoupdatescheduler (continued)

	○ For HTTP, run the command:
	`racadm autoupdatescheduler create -u httpuser -p httppwd -l http://test.com -f cat.xml -ph 10.20.30.40 -pu padmin -pp ppwd -po 8080 -pt http -time 14:30 -dom 1 -rp 5 -a 1`
	○ For HTTPS, run the command:
	`racadm autoupdatescheduler create -u httpuser -p httppwd -l https://test.com -f cat.xml -ph 10.20.30.40 -pu padmin -pp ppwd -po 8080 -pt http -time 14:30 -dom 1 -rp 5 -a 1`
	○ For TFTP, run the command:
	`racadm autoupdatescheduler create -l tftp://1.2.3.4 -f cat.xml.gz -time 14:30 -dom 1 -rp 5 -a 1`
	○ To view AutoUpdateScheduler parameter:
	`racadm autoupdatescheduler view`
	`hostname = 192.168.0`
	`sharename = nfs`
	`sharetype = nfs`
	`catalogname = Catlog.xml`
	`time = 14:30dayofmonth =1`
	`repeat = 5`
	`applyreboot = 1`
	`idracuser = racuser`
	○ To clear and display AutoUpdateScheduler parameter:
	`racadm autoupdatescheduler clear`
	`RAC1047: Successfully cleared the Automatic Update (autoupdate) feature settings`

cd

Table 7. Details of cd

Description	To change the current working object, use this command.
Synopsis	`racadm> cd <object>`
Input	`racadm> cd <object>`
Output	Displays the new prompt.

Example	• **Example 1:** To navigate to the system device type directory:
	`racadm>>cd system`
	`racadm/system>`
	• **Example 2**: To run all the power-related `get` or `set` commands:
	`racadm/system>cd power`
	`racadm/Power>`

cd..

Table 8. Details of cd..

Description	To go back to the previous directory, use this command.
Synopsis	`racadm> cd..`
Input	`racadm> cd..`
Output	To traverse back to the previous directory, use the command.

Example	• **Example 1**: To traverse back from power to system object:
	○ Input: racadm/`power> cd..`
	○ Output:
	`system>>`
	• **Example 2**: To traverse back from system object to the prompt:
	○ Input: `racadm/system> cd..`
	○ Output:
	`racadm>>`

clearasrscreen

Table 9. Details of clearasrscreen

Description	Clears the last crash (ASR) screen that is in memory. For more information, see "Enabling Last Crash Screen" section in the *iDRAC User's Guide*. **NOTE:** To run this subcommand, you must have the Clear Logs permission.
Synopsis	`racadm clearasrscreen`
Input	None
Output	Clears the last crash screen buffer.
Example	`racadm clearasrscreen`

clearpending

Table 10. Details of clearpending

Description	Deletes the pending values of all the attributes (objects) in the device (NIC, BIOS, FC, and Storage). **NOTE:** If any attribute is not modified or a job is already scheduled for the same device, then the pending state is not cleared or deleted.
Synopsis	`racadm clearpending <FQDD>`
Input	`<FQDD>` — The values are:

Table 10. Details of clearpending (continued)

	• BIOS FQDD • NIC FQDD • FC FQDD • Storage controller FQDD <FQDD>: The values are: • BIOS.Setup.1–1 • NIC.Integrated.1–1 • RAID.Integrated.1–1
Output	A message is displayed indicating that the pending state is cleared or deleted.
Example	`racadm clearpending NIC.Integrated.1-1`

closessn

Table 11. Details of closessn attribute

Description	Closes a communication session on the device. Use `getssninfo` to view a list of sessions that can be closed using this command. To run this subcommand, you must have the Administrator permission. **NOTE:** This subcommand ends all the sessions other than the current session.
Synopsis	• `racadm closessn -i <session_ID>` • `racadm closessn -a` • `racadm closessn -u <username>`
Input	• `–i <session_ID>` — The session ID of the session to close, which can be retrieved using RACADM `getssninfo` subcommand. Session running this command cannot be closed. • `–a` — Closes all sessions. • `–u <username>` — Closes all sessions for a particular user name. • For Remote RACADM, use either the `–u` option or the `–i` option.
Output	Successful or error message is displayed.

Example	• Closes the session 1234.
	`racadm closessn -i 1234`
	• Closes all the sessions other then the active session for root user.
	`racadm closessn -u root`
	• Closes all the sessions.
	`racadm closessn -a`

clrsel

Table 12. Details of clrsel attribute

Description	Removes all the existing records from the System Event Log (SEL). To use this subcommand, you must have **Clear Logs** permission.
Synopsis	`racadm clrsel [-m <module>]`
Input	`-m <module>` must be one of the following values: • `server-<n>` — where n=1 to 16 • `server-<nx>` — where n=1 to 8; x = a, b, c, d (lower case)
Example	• `racadm clrsel` The SEL was cleared successfully • `racadm clrsel -m server-1` Clear SEL log on server 1

config

Table 13. Details of config attribute

Description	Allows you to set iDRAC configuration parameters individually or to batch them as part of a configuration file and then modify iDRAC configuration properties. If the data is different, the iDRAC object is written with a new value. **NOTE:** This subcommand will be deprecated in the later versions. For information about configurations, see the `set` subcommand.
Synopsis	• `racadm config -g <group> -o <object> <value>` • `racadm config -g <group> -o <object> -i <index> <value>` • `racadm config -f <filename> -o [-c] [-p] [-continue]` **NOTE:** • The configuration file retrieved using remote RACADM is not interoperable. For the config `racadm -r 192.168.0 -u root -p xxx config -f c:\config.txt` command, use the configuration file retrieved from the same interface. For example, for the config `racadm -r 192.168.0 -u root -p xxx config -f c:\config.txt` , use the file generated from getconfig command `racadm -r 192.168.0 -u root -p xxx getconfig -f c:\config.txt`. • -f is only applicable for remote RACADM. `racadm config -g <group> -o <object> <value> [-m <module>]`
Input	• `-f` — The `-f <filename>` option causes `config` to read the contents of the file specified by `<filename>` and configure iDRAC. The file must contain data in the format specified in the section Parsing Rules in the *iDRAC User's Guide* available at www.dell.com/idracmanuals. **NOTE:** The `-f` option is not supported for the Serial or Telnet or SSH console. **NOTE:** When the `-f` option is specified and configuration of an attribute fails, then configuration of other attributes in that group is skipped.

Table 13. Details of config attribute (continued)

	• `-continue` — This option is used with `-f` option only. If configuration through file is unsuccessful for a group, then configuration continues with the next group in the file. If this option is not used, then configuration stops when it is unsuccessful for a particular group. After the unsuccessful group, the rest of the groups are not configured. • `-p` — This option must be used with the `-f` option. It directs `config` to delete the password entries contained in the config file `-f <filename>` after the configuration is complete. To apply the password, you must remove the preceding Read-Only marker '#' in the config file before executing the `config -f` command. • `-g` — The `-g <groupName>`, or `group` option, must be used with the `-o` option. The `<group>` specifies the group containing the object that is to be set. • `-o` — The `-o <objectName>`, or `object` option, must be used with the `-g` option. This option specifies the object name that is written with the string • `<value>` — Value to set to configuration object. • `-i` — The `-i <index>`, or `index` option, is valid only for indexed groups and can be used to specify a unique group (used with -g and -o). The `<index>` is a decimal integer from 1 through n, where n can vary from 1 to maximum number of indexes a particular group supports. If `-i <index>` is not specified, a value of 1 is assumed for groups, which are tables that have multiple entries. The index is specified by the index value, not a named value. 'nx' is allowed for servers. • `-c` — This option performs validation but do not configure.
Output	This subcommand generates error output for any of the following reasons: • Invalid syntax, group name, object name, index or other invalid database members. • If the RACADM command-line interface is unsuccessful.

Examples	• To configure a single property of a group:
	`racadm config -g cfgSerial -o cfgSerialBaudRate`
	• Modify a user password:
	`racadm config -g cfgUserAdmin -o cfgUserAdminPassword -i 3 newpassword`
	• Configure a RAC from a configuration file:
	`racadm config -f config.txt`
	• Configure a RAC from a configuration file and continue if a group fails to get configured:
	`racadm set -f config.txt --continue`

coredump

Table 14. Details of coredump

Description	Displays detailed information related to any recent critical issues that have occurred with iDRAC. The coredump information can be used to diagnose these critical issues. If available, the coredump information is persistent across iDRAC power cycles and remains available until either of the following conditions occur: The coredump information is deleted using the coredumpdelete subcommand. For more information about clearing the `coredump`, see the coredumpdelete. **NOTE:** To use this subcommand, you must have the **Execute Debug** privilege.
Synopsis	`racadm coredump`

Table 14. Details of coredump (continued)

Example	• `racadm coredump`
	`There is no coredump currently available.`
	
	• `racadm coredump`
	`Feb 19 15:51:40 (none) last message repeated 5 times`
	`Feb 19 15:52:41 (none) last message repeated 4 times`
	`Feb 19 15:54:12 (none) last message repeated 4 times`
	`Feb 19 15:56:11 (none) last message repeated 2 times`
	`Feb 22 11:46:11 (none) kernel:`

coredumpdelete

Table 15. Details of coredumpdelete

Description	Deletes any currently available coredump data stored in the RAC. To use this subcommand, you must have **Execute Debug** Command permission. To use this subcommand, you must have **Clear Logs** or **Execute Debug**Commands permission. **NOTE:** If a `coredumpdelete` command is issued and a `coredump` is not currently stored in the RAC, the command displays a success message. This behavior is expected. See the `coredump` subcommand for more information about viewing a coredump.
Synopsis	`racadm coredumpdelete`
Output	Coredump is deleted.

Example	`racadm coredumpdelete`
	
	`Coredump request completed successfully`

diagnostics

Table 16. Details of diagnostics

Description	Collects and exports remote diagnostics report from iDRAC. The results of the latest successfully run remote diagnostics are available and retrievable remotely through an NFS or a CIFS share.

Synopsis	To run a remote diagnostic report:
	`racadm diagnostics run -m <mode> -r <reboot type> -s <start time> -e <expiration time>`
	To export a remote diagnostic report:
	`racadm diagnostics export -f <file name> -l <NFS or CIFS share location> -u <username> -p <password>`

Input	• `–m <mode>` — Specifies the type of diagnostic mode. The types are:
	  ○ Collect and export remote diagnostics report from the iDRAC.
	  The results of the latest successfully executed remote Diagnostics will be available and retrievable remotely through an NFS or a CIFS share.

Table 16. Details of diagnostics (continued)

	○ 0(Express) — The express mode executes a subset of diagnostic tests. ○ 1(Extended) — The extended mode executes all available diagnostics tests. ○ 2(Both) — Runs express and extended tests serially in sequence. ● -f <filename> — Specifies the name of the configuration file. ● -l — Specifies the location of the network share (NFS or CIFS). ● -u <username> — Specifies the user name of the remote share to import the file. ● -p <password> — Specifies the password of the remote share to import the file. ● -r <reboot type> — Specifies the reboot type. The type can be one of the following: ○ pwrcycle — Power cycle ○ Graceful — Graceful reboot without forced shutdown ○ Forced — Graceful reboot with forced shutdown ● -s <start time> — Specifies the start time for the scheduled job in yyyymmddhhmmss format. The default value TIME_NOW starts the job immediately. ● -e <expiration time> — Specifies the expiry time for the scheduled job in yyyymmddhhmmss format. The default value TIME_NA does not apply the waiting time. **NOTE:** For the diagnostic report run operation, the time difference between the -s and -e options must be more than five minutes.
Output	Provides the Job ID for the diagnostic operation.

Examples	● To initiate a remote diagnostic operation:
	`racadm diagnostics run -m 1 -r forced -s 20121215101010 -e TIME_NA`
	● To export a remote diagnostics report to CIFS share:
	`racadm diagnostics export -f diagnostics -l //192.168.0/cifs -u administrator -p xxx`
	● To export a remote diagnostics report to NFS share:
	`racadm diagnostics export -f diagnostics -l 192.168.0:/nfs -u administrator -p xxx`

eventfilters

Table 17. Details of eventfilters

Description	Displays the list of event filter settings. To use this subcommand with the set and test option, you must have the **Administrator** privilege.

Synopsis	`racadm eventfilters <eventfilters command type>`
	`racadm eventfilters get -c <alert category>`
	`racadm eventfilters set -c <alert category> -a <action> -n <notifications>`
	`racadm eventfilters set -c <alert category> -a <action> -r <recurrence>`
	`racadm eventfilters test -i <Message ID to test>`
	NOTE: The general format of an alert category:
	`idrac.alert.category.[subcategory].[severity]`

Table 17. Details of eventfilters (continued)

	where, category is mandatory, but subcategory and severity are optional. A severity cannot precede a subcategory. Valid Category values are: • `All` • `System` • `Storage` • `Updates` • `Audit` • `Config` • `Worknotes` Valid Severity values are: • `Critical` • `Warning` • `Info` Valid examples of alert queries are: • `idrac.alert.all` • `idrac.alert.audit` • `idrac.alert.audit.lic` • `idrac.alert.audit.warning` • `idrac.alert.audit.lic.critical`
Input	• `get` — Displays the list of eventfilter settings. • `set` — Configures the actions and notifications for a given eventfilter configuration. • `-i` — Message ID for which the simulation is needed. • `-c` — Alert category of the specific event filter. • `-a` — The action that must be invoked when the event occurs. Valid values are `none`, `powercycle`, `power off`, or `systemreset`. • `-n` — The notification is sent when the event occurs. Valid values are `all`, `snmp`, `ipmi`, `ws-events`, `oslog`, `email`, `remotesyslog` or `none`. You can append multiple notifications separated by a comma. You cannot enter the values `all` or `none` with other notifications. If incorrect notification is specified along with other valid notifications, the valid and invalid notification set is failed. • `-r` — Event generation interval. This option is applicable only to the temperature statistics subcategory `tmps`. You can use this option as a stand-alone or with `-n` and `-a`. **NOTE:** If both **event generation interval** and **notifications** are configured and there is an error while configuring the notifications, the event generation interval is not set. The valid values are 0–365. 0 disables the event generation.

Example	• Display all available event filter configurations:
	`racadm eventfilters get -c idrac.alert.all`
	• Display eventfilter configurations for a specific category. For example, audit:
	`racadm eventfilters get -c idrac.alert.audit`
	• Display eventfilter configurations for a specific subcategory. For example, licensing under the audit category:
	`racadm eventfilters get -c idrac.alert.audit.lic`
	• Display eventfilter configurations for a specific severity. For example, warning under the audit category:
	`racadm eventfilters get -c idrac.alert.audit.warning`

Table 17. Details of eventfilters (continued)

	• Display eventfilter configurations for a specific severity and subcategory. For example, a severity of warning in the subcategory licensing under audit category:
	`racadm eventfilters get -c idrac.alert.audit.lic.warning`
	• Clear all available alert settings:
	`racadm eventfilters set -c idrac.alert.all -a none -n none`
	• Configure using severity as a parameter. For example, all informational events in storage category are assigned power off as action, and email and snmp as notifications:
	`racadm eventfilters set -c idrac.alert.storage.info -a poweroff -n email,snmp`
	• Configure using subcategory as a parameter. For example, all configurations under the licensing subcategory in the audit category are assigned power off as action and all notifications are enabled:
	`racadm eventfilters set -c idrac.alert.audit.lic -a poweroff -n all`
	• Configure using subcategory and severity as parameters. For example, all information events under the licensing subcategory in the audit category are assigned power off as action and all notifications are disabled:
	`racadm eventfilters set -c idrac.alert.audit.lic.info -a poweroff -n none`
	• Configure the event generation interval for temperature statistics:
	`racadm eventfilters set -c idrac.alert.system.tmps.warning -r 10`
	• Configure the event generation interval and notifications for temperature statistics:
	`racadm eventfilters set -c idrac.alert.system.tmps -r 5 -a none -n snmp`
	• Send a test alert for the fan event:
	`racadm eventfilters test -i FAN0001`

fcstatistics

Table 18. Details of fcstatistics

Description	Displays a list of FCs (FQDDs), managed server for which statistics is available.
Synopsis	`racadm fcstatistics <FC fqdd>`
Input	`<FC fqdd>` — Specify the FQDD of the target FC device.
Example	`racadm fcstatistics <FC fqdd>`

frontpanelerror

Table 19. Details of frontpanelerror

Description	Enables or disables the live-feed of the errors currently being displayed on the LCD screen. For error acknowledge use `hide`, and error assert use `show`.

Table 19. Details of frontpanelerror (continued)

Synopsis	`racadm frontpanelerror show` `racadm frontpanelerror hide`
Input	• `show` — to view the errors currently being displayed on the LCD screen. • `hide` — to hide the errors currently being displayed on the LCD screen.

Example	• `racadm frontpanelerror show`
	`Front Panel Error—Show Enabled.`
	• `racadm frontpanelerror hide`
	`Front Panel Error—Hide Enabled.`

fwupdate

Table 20. Details of fwupdate

Description	Allows you to update the firmware on the server iDRACs device. You can: • Check the firmware update process status. • Update iDRAC firmware from FTP or TFTP server by providing an IP address and optional path. • Update iDRAC firmware from the local file system using Local and Remote RACADM. • Roll back to the standby firmware. Allows you to update the firmware on the KVM, active CMC, standby CMC, iDRAC or an IOM infrastructure device. You can: • Check the firmware update process status. • Update CMC from FTP or TFTP server by providing an IP address and optional path. • Update CMC from the local file system using Remote RACADM. • There can only be a single update operation in progress at any time. In addition, the `fwupdate` subcommand may only update one or more devices of a single kind at a time. **NOTE:** CMC firmware update is supported only for the firmware versions 3.10, 3.20, 3.21, 4.0, 4.10, 4.11, 4.30, 4.31, 4.45, and 4.5. For any version other than these, first update to any of these versions, and then update to the required version. To use this subcommand, you must have **Configure iDRAC** permission. To use this subcommand, you must have the Chassis Configuration Administrator privilege. **NOTE:** The fwupdate command is not supported for iDRAC7 or later. Use the CMC GUI to perform the operation. **NOTE:** • Running the `fwupdate` subcommand to update the firmware on the active CMC resets itself and all the network connections are dropped. During update of all other modules, including the standby CMC, the active CMC continues to run normally without resetting. • In a chassis supported by DC PSUs, an error message is displayed if you attempt to update the firmware with a version without DC PSU support. • The `fwupdate` subcommand generates an error when used on the extension slot of a multi-slot server. • While Lifecycle Controller is running for racadm commands, you cannot perform other operations which need Lifecycle Controller Partition. If the Lifecycle Controller Partition is unreleased (because of improper closure of racadm command in the partition), then wait 20-35 minutes to clear the Lifecycle Controller Partition Signed CMC Firmware Image

Table 20. Details of fwupdate (continued)

	• For Dell's 13th generation of PowerEdge servers and later, CMC firmware includes a signature which is verified by CMC before update to ensure the authenticity of the uploaded firmware. The firmware update process is successful only if the firmware image is authenticated by CMC to be a valid image from the service provider and has not been altered. The firmware update process is stopped if CMC cannot verify the signature of the uploaded firmware image. • Upload firmware image from TFTP server and start firmware update. **NOTE:** Run the firmware update command through only one remote racadm session at a time.

Synopsis	`racadm fwupdate -s`
	`racadm fwupdate -g -u -a <TFTP_Server_IP_Address> [-d <path> [--clearcfg]`
	`racadm -r <iDRAC IP_Address> -u <username> -p <password> fwupdate -f <ftpserver ip> <ftpserver username> <ftpserver password> -d <path> where path is the location on the ftp server where firmimg.d7 is stored.`
	`racadm fwupdate -r`
	`racadm fwupdate -p -u [-d <path>]`
	For SSH or Telnet or Serial:
	`racadm fwupdate -g -u -a <tftp_server_ip_address_or_FQDN> -d <path> [-m <module>]`
	`racadm fwupdate -f <ftp_server_ip_address_or_FQDN> <username> <password> -d <path> [-m <module>]`
	`racadm fwupdate -u -m iominf-<n>`
	`racadm fwupdate -s [-m <module>]`
	`racadm fwupdate -c [-m <module>]`
	For Remote RACADM:
	`racadm fwupdate -p -u -d <path> [-m <module>]`
	`racadm fwupdate -g -u -a 192.168.0.10 -d firmimg.cmc -m cmc-active`
	`racadm fwupdate -r [-m <module>]`
	`racadm -r 192.168.0.120 -u <username> -p <password> fwupdate -p -u -d firming.cmc`
	When using `FTP`, if you provide the full path to the image file on the `CLI`, then the CMC uses that path to locate that file on the host. If full path is not provided and the host system is running Linux or another variant of UNIX, then CMC searches the home directory of the specified user for the file. If the host system is running Windows, then a default folder, such as `C:\ftproot` is searched.
	NOTE: When attempting to run firmware update task, if the firmware image path length is greater than 256 characters, remote RACADM client exits with the error message "`ERROR: Specified path is too long`".

Table 20. Details of fwupdate (continued)

	NOTE: When attempting to run firmware update task using `racadm fwupdate` command, if the firmware image path length is greater than 256 characters. Remote RACADM client exits with the error message "`ERROR: Specified path is too long`".
Input	• –u — The update option performs a checksum of the firmware update file and starts the actual update process. This option may be used along with the –g or –p options. At the end of the update, iDRAC performs a soft reset. • –s — This option returns the status of the update process. • -a — The -a option specifies TFTP server IP address used for firmware image. This option must be used with the -g option. • -clearcfg — The -clearcfg option removes the previous iDRAC configuration after firmware update. • –s — This option returns the status of the update process. Use this option by itself. Lists active SD card features and SD card status. • –u — Performs the firmware update operation (used with -p and -g). • –s — Displays the status of the firmware update. Use this option by itself. Lists active SD card features and SD card status. **NOTE:** Use –m to display the status of the module update. Omit -m to display the status of the active CMC update. **NOTE:** The value `all` is used only to obtain the status of all targets to update. • -g — The get option instructs the firmware to get the firmware update file from the TFTP server. Specify the -a -u, and –d options. In the absence of the –a option, the defaults are read from properties in the group `cfgRemoteHosts`, using properties `cfgRhostsFwUpdateIpAddr` and `cfgRhostsFwUpdatePath`. • -g — Downloads the firmware update using the TFTP server. • -a — The IP Address option specifies the TFTP server IP address, used with -g option. Specifies the TFTP server IP address or FQDN used for the firmware image (used with -g). • -p — The -p, or put, option is used to update the firmware file from the managed system to iDRAC. The -u option must be used with the -p option. • -d — The -d, or directory option specifies the directory on the TFTP server or on CMC's host server, where the firmware update file resides. Specifies the source path where the firmware image resides. `Default`: Designated TFTP default directory on that host for the file if -g option is absent. If -g is used, it defaults to a directory configured on the TFTP server. **NOTE:** The-p option is supported on local and remote RACADM and is not supported with the `serial/Telnet/ssh` console and on the Linux operating systems. • -r — The rollback option is used to roll back to the standby firmware. • -p — The -p option is used to upload the firmware image from the client. **NOTE:** This option is only supported on the remote interface(s) and Windows operating systems. • -m <module> — Specifies the module or device to be updated. <module> is one of the following values: ○ `cmc-active` — default state if –m is not specified. ○ `cmc-standby` ○ `kvm` ○ `server-<n>` — where n=1–16 ○ `server-<nx>` — where n=1–8; x = a, b, c, d (lowercase) ○ `server-<g> <generation>` — where `generation` = iDRAC or iDRAC6 only. ○ `iominf-<n>` — where n = 1–6 **NOTE:** Multiple modules can be specified except iominf-<n>, for example, –m <module 1> –m <module 2> and so on.

Table 20. Details of fwupdate (continued)

	• `-f` — Specifies the FTP server IP address or FQDN, username, and password used for firmware image. Applies FTP download process for firmware update.
	• `-c` — Cancels an ongoing firmware update. The cancel operation is supports the following values:
	  ○ `cmc-active` — This is the default option if `-m` is not specified.
	  ○ `cmc-standby`
	  ○ `server-<n>` — where n = 1 to 16
	  ○ `server-<nx>` — where n = 1 to 8; x = a to d (lowercase)
	  ○ `server-<g>` — where g = generation (iDRAC, iDRAC6)
	  ○ `iominf-<n>` — where n = 1 to 6
	  ○ `kvm`
	  NOTE: Omit `-m` to cancel an active CMC update.
	
	CMC version 3.00 accepts `IPv4` or `fully qualified domain names (FQDN)` for both FTP and TFTP servers.
	
	NOTE: CMC does not support FTP over IPv6.
	
	NOTE: You can specify the **cmc-active** and **cmc-standby** modules at the same time along with one or more server-n modules. This option enables the devices to be updated together.
	
	NOTE: Verify that the update applied to servers for a particular generation has been validated for all impacted server models.

Output	Displays a message indicating the operation that is being performed.

Example	• Upload the firmware image from the TFTP server and start the firmware update.
	`racadm fwupdate -g -u -a 192.168.0.2 -d firmimg.cmc -m cmc-active`
	
	TFTP firmware update has been initiated. This update process may take several minutes to complete.
	• Upload the firmware image from the FTP server and start the firmware update.
	`racadm fwupdate -f 192.168.0.100 fred xxx -d firmimg.cmc -m cmc-active`
	• Upload a firmware image from the client and start firmware update.
	`racadm fwupdate -p -u -d firmimg.cmc`
	• Start IOM infrastructure firmware update.
	`racadm fwupdate -u -m iominf-1`
	• Update firmware on both the CMCs.
	`racadm fwupdate -g -u -a 192.168.0.2 -d firmimg.cmc -m cmc-active -m cmc-standby`
	• Update firmware on multiple servers.
	`racadm fwupdate -g -u -a 192.168.0.2 -d firmimg.imc -m server-1 -m server-2 -m server-3`
	• Update firmware on servers of iDRAC generation.
	`racadm fwupdate -g -u -a 192.168.0.2 -d firmimg.imc -m server-iDRAC`
	• Update firmware on multiple IOM infrastructure devices.
	`racadm fwupdate -u -m iominf-4 -m iominf-5 -m iominf-6`
	• Query the status of all firmware targets to be updated.
	`racadm fwupdate -s -m all`
	• Query the current status of the firmware update process for a particular module.
	`racadm fwupdate -s -m <module>`
	• Download firmware update file from a specified location on the TFTP server at a specific IP address.

Table 20. Details of fwupdate (continued)

	`racadm fwupdate -g -u -a 192.168.0.2 -d <path>`
	After the image file is downloaded from the TFTP server, the update process begins. When completed, CMC is reset.
	● Read the status of the firmware update.
	`racadm fwupdate -s`
	● Cancel a firmware update in progress.
	`racadm fwupdate -c`
	● Uploads a firmware image from the client and start firmware update:
	`racadm fwupdate -p -u -d /tmp/images`
	● Upload firmware image from FTP server and start firmware update:
	`racadm fwupdate -f 192.168.0.10 test test -d firmimg.d7`
	● Upload firmware image from TFTP server and start firmware update:
	`racadm fwupdate -g -u -a 192.168.0.100 -d /tmp/images`
	● Query the current status of the firmware update process:
	`racadm fwupdate -s`
	● Rollback to the standby firmware:
	`racadm fwupdate -r`
	● Upload firmware image from TFTP server, start firmware update. After firmware update is complete, delete previous iDRAC configuration:
	`racadm fwupdate -g -u -a 192.168.0.100 -d /tmp/images --clearcfg`
	NOTE: Firmware update from local RACADM (using `-p -u -d` options) is not supported on Linux OS.
	NOTE: These commands specifically apply to an active-CMC update.
	Signed CMC Firmware Image:
	● To get the firmware update status:
	`racadm fwupdate -s -m cmc-active`
	Invalid firmware: The uploaded firmware image does not contain a verification signature.

Table 21. Firmware update methods on Blade, Rack and Tower servers

FW Update Method	iDRAC on Blade Servers	iDRAC on Rack and Tower Servers
Local RACADM	Yes	Yes
Local RACADM-TFTP	Yes	Yes
Local RACADM-FTP	Yes	Yes
Remote RACADM	Yes	Yes
Remote RACADM-TFTP	Yes	Yes
Remote RACADM-FTP	Yes	Yes
Firmware RACADM-TFTP	Yes	Yes

Table 21. Firmware update methods on Blade, Rack and Tower servers (continued)

FW Update Method	iDRAC on Blade Servers	iDRAC on Rack and Tower Servers
Firmware RACADM-FTP	Yes	Yes

Table 22. Firmware update methods on CMC servers

FW Update Method	CMC
Local RACADM	No
Local RACADM-TFTP	No
Local RACADM-FTP	No
Remote RACADM	Yes
Remote RACADM-TFTP	Yes
Remote RACADM-FTP	Yes
Firmware RACADM-TFTP	Yes
Firmware RACADM-FTP	Yes

get

Table 23. Details of get

Description	Displays the value of one or more objects. The `get`sub-command has two forms. • Displays the value of a single object. • Exports the value of multiple objects to a file. It supports multiple object value export in two file formats • JSON format— SCP JSON files can be exported to a network share file. • INI format — The INI format files can be exported to a local file only **NOTE:** INI file format is deprecated. It is recommended to use XML or JSON formats. • Server Configuration Profile XML/JSON format — XML/JSON format files can be exported to a local file, to an NFS network share or to a CIFS network share. **NOTE:** To run the`Get` sub-command for Server Configuration Profile XML files, use the Lifecycle Controller version 1.1 or later. **NOTE:** Some objects may have a pending value if a `Set` operation is performed on the object through a reboot job. To complete the pending operation, schedule the job using a jobqueue command, and then check for completion of the job using the returned Job ID. For more information, see jobqueue **NOTE:** This command supports both IPV4 and IPV6 formats. IPV6 is applicable only for CIFS, HTTP, and HTTPS remote shares.

Synopsis	**Single-object Get**
	`racadm get <FQDD Alias>.<group>`
	`racadm get <FQDD Alias>.<group>.<object>`
	`racadm get <FQDD Alias>.<group>.[<index>].<object>`
	`racadm get <FQDD Alias>.<index>.<group>.<index>.<object>`

Table 23. Details of get (continued)

	Multi-object Get
	`racadm get -f <filename>`
	`racadm get -f <filename> -t xml -l <NFS share> [--clone | --replace ] [--includeph]`
	`racadm get -f <filename> -t xml -l <NFS share> -c <FQDD>[,<FQDD>*]`
	`racadm get -f <filename> -t xml -u <username> -p <password> -l <CIFS share> [--clone | --replace ] [--includeph]`
	`racadm get -f <filename> -t xml -u <username> -p <password> -l <CIFS share> -c <FQDD>[,<FQDD>*]`

Input	• `<FQDD Alias>`
	  ○ Examples for FQDDs
	  ▪ `System.Power`
	  ▪ `System.Power.Supply`
	  ▪ `System.Location`
	  ▪ `LifecycleController.LCAttributes`
	  ▪ `System.LCD`
	  ▪ `iDRAC.Serial`
	For the list of supported groups and objects under the get command, see Database Objects With Get and Set Commands
	• `<group>`—Specifies the group containing the object that must be read.
	• `<object>`—Specifies the object name of the value that must be read.
	• `<index>`—Specifies where FQDD Aliases or Groups must be indexed.
	• `-f <filename>`—This option enables you to export multiple object values to a file. This option is not supported in the Firmware RACADM interface.
	• `-u`—Specifies user name of the remote CIFS share to which the file has to be exported.
	• `-p`—Specifies password for the remote CIFS share to which the file has to be exported.
	• `-l`—Specifies network share location to which the file will be exported.
	• `-t`—Specifies the file type to be exported.
	The valid values are:
	  ○ `JSON`—It exports the SCP JSON file to a network share file.
	  ○ `xml`—It exports the SCP xml format file, either to a local or network share file.
	  ○ `ini`—It exports the legacy configuration file. If -t is not specified, then the ini format file is exported. It can only be exported to a local file.
	  NOTE: To import or export Server Configuration Profile xml/JSON files, Lifecycle Controller version 1.1 or later is required.
	• `--clone`—Gets the configuration `.xml` files without system-related details such as service tag. The `.xml` file received does not have any virtual disk creation option.
	• `--replace`—Gets the configuration `.xml` files with the system-related details such as service tag.
	• `-c`—Specifies the FQDD or list of FQDDs separated by ',' of the components for which the configurations should be exported. If this option is not specified, the configuration related to all the components are exported.
	• `--includeph`—Specifies that the output of the passwords included in the exported configuration `.xml/JSON` file are in the hashed format.
	  NOTE: if –includeph is not used, the output of the passwords will be in the .xml/JSON file in clear text.
	NOTE: For `--clone` and `--replace` options, only `.xml` file template is received. These options `--clone` and `--replace` cannot be used in the same command.

Table 23. Details of get (continued)

Examples	• Get system LCD information.
	`racadm get system.lcdLCDUserString`
	• Display an entire group, in this case the topology configuration.
	`racadm get system.location`
	• Display a single object from a particular group.
	`racadm get system.location.rack.name`
	• Export the xml configuration to a CIFS share.
	`racadm get -f file -t xml -u myuser -p xxx -l //192.168.0/share`
	• Export the xml configuration to an NFS share.
	`racadm get -f file -t xml -l 192.168.0:/myshare`
	• Export a “cloned” xml configuration to a CIFS share
	`racadm get -f xyz_temp_clone -t xml -u Administrator -p xxx -l // 192.168.0/xyz --clone`
	• Export a “replace” xml configuration to a CIFS share
	`racadm get -f xyz_temp_replace -t xml -u Administrator -p xxx -l // 192.168.0/xyz --replace`
	• Export the xml configuration to an HTTP share
	`racadm get -f file -t xml -u httpuser -p httppwd -l http://test.com/ myshare`
	• Export the xml configuration to an HTTPS share
	`racadm get -f file -t xml -u httpuser -p httpspwd -l https://test.com/ myshare`
	• Export the xml configuration of the iDRAC component to a CIFS share.
	`racadm get -f file -t xml -u myuser -p xxx -l //192.168.0/share -c iDRAC.Embedded.1`
	• Include password hash in the configuration `.xml` file.
	`racadm get -f<filename> -t xml -l<NFS or CIFS share> -u<username> -p<password> -t xml --includeph`

getconfig

Table 24. Details of getconfig attribute

Description	Retrieves iDRAC configuration parameters individually or all iDRAC configuration groups may be retrieved and saved to a file. **NOTE:** This subcommand is deprecated. For viewing the configuration objects and its values, use `get` subcommand. For more information, see the *Integrated Dell Remote Access Controller (iDRAC8) and iDRAC7 RACADM Command Line Interface Reference Guide* available at www.dell.com/support/manuals.

Table 24. Details of getconfig attribute (continued)

Synopsis	`racadm getconfig -f <filename>`
	`racadm getconfig -g <groupName> [-i <index>]`
	`racadm getconfig -u <username>`
	`racadm getconfig -h`
	`racadm getconfig -g <groupName> -o <objectName> [-i index]`

Input	• `-f` — The `-f <filename>` option directs `getconfig` to write the entire iDRAC configurations to a configuration file. This file can be used for batch configuration operations using the `config` subcommand. **NOTE:** This option is supported only on remote interfaces. • `-g` — The `-g <groupName>` or group option, is used to display the configuration for a single group. The `<groupName>` is the name for the group used in the `racadm.cfg` files. If the group is an indexed group, then use the`-i` option. • `-h` — The `-h` or help option, displays a list of all available configuration groups in alphabetical order. This option is useful when you do not remember exact group names. • `-i` — The `-i <index>` or index option, is valid only for indexed groups and is used to specify a unique group. The `<index>` is a decimal integer from 1 through n, where n can vary from 1 to maximum number of indexes a particular group supports. If `-i <index>` is not specified, then a value of 1 is assumed for groups, which are tables that have multiple entries. The `-i` option enters the index value and not a *named* value • `-o` — The `-o <objectname>` or object option specifies the object name that is used in the query. This option is optional and can be used with the `-g` option. • `-u` — The`-u <username>` or user name option, is used to display the configuration for the specified user. The `<username>` option is the login name for the user. • `-v` — The `-v` option displays more information with the display of the properties and is used with the `-g` option.
Output	The subcommand displays error message when: • Invalid syntax, group name, object name, index, or any other invalid database members are entered. • The RACADM CLI transport is unsuccessful. If errors are not encountered, this subcommand displays the content of the specified configuration.
Example	• Displays the configuration properties (objects) that are contained in the group `cfgLanNetworking`. `racadm getconfig -g cfgLanNetworking` • Saves all group configuration objects from

Table 24. Details of getconfig attribute (continued)

- iDRAC to `myrac.cfg`.

```
racadm getconfig -f myrac.cfg
```

If you do not configure the following key attributes in their respective groups for a particular index, the groups are not saved in to the file. This is applicable for all the index groups.

Saves all group configuration objects from iDRAC to `myrac.cfg`.

```
racadm getconfig -f myrac.cfg
```

Saves all group configuration objects from iDRAC to `myrac.cfg`.

```
racadm getconfig -f myrac.cfg
```

Table 25. Details

Groups	Key Attributes
cfgEmailAlert	cfgEmailAlertAddress
cfgLDAPRoleGroup	cfgLDAPRoleGroupDN
cfgServerInfo	cfgServerBmcMacAddress
cfgStandardSchema	cfgSSADRoleGroupName
cfgTraps	cfgTrapsAlertDestIPAddr
cfgUserAdmin	cfgUserAdminUserName

- Displays a list of the available configuration groups on iDRAC in an alphabetical order.

```
racadm getconfig -h
```

- Displays the configuration properties for the user named **root**.

```
racadm getconfig -u root
```

- Displays the user group instance at index 2 with verbose information for the property values.

```
racadm getconfig -g cfgUserAdmin -i 2
-v
```

- Displays an entire group of serial configuration.

```
racadm getconfig -g cfgSerial
```

- Displays a single object from a particular group.

```
racadm getconfig -g cfgSerial -o
cfgSerialBaudRate
```

- Displays an indexed group.

```
racadm getconfig -g cfgUserAdmin -o
cfgUserAdminUserName -i 2
```

Table 24. Details of getconfig attribute (continued)

	• Displays the current Enhanced Cooling Mode property configuration. `racadm getconfig -g cfgThermal`

gethostnetworkinterfaces

Table 26. Details of gethostnetworkinterfaces

Description	Displays host network interface details. **NOTE:** To run this subcommand, you must have iDRAC service module installed on the server operating system.
Synopsis	`racadm gethostnetworkinterfaces` `racadm gethostnetworkinterfaces <NIC FQDD>`
Examples	• To display the details of all the network interfaces on the server. • To display the details of a particular NIC on the server.

```
racadm gethostnetworkinterfaces

Local Area Connection 12
Description                : iDRAC Virtual NIC USB Device #8
Status                     : Up
Interface Type             : Ethernet
DHCP                       : Enabled
DHCPServerV4               : 169.254.0.1
MAC Address                : 00-25-64-F9-7A-E7
IPv4 Address               : 169.254.0.2
Subnet Mask                : 255.255.255.0
IPv6 Address               : fe80::1cce:a0a7:f30e:54fc
Prefix Length              : 64
IPv6 DNSServer Address  0: fec0:0:0:ffff::1
IPv6 DNSServer Address  1: fec0:0:0:ffff::2
IPv6 DNSServer Address  2: fec0:0:0:ffff::3
```

```
racadm gethostnetworkinterfaces NIC.Integrated.1-1-1

Local Area Connection
Description                : Broadcom NetXtreme Gigabit Ethernet
Status                     : Up
Interface Type             : Ethernet
DHCP                       : Enabled
DHCPServerV4               : 10.94.224.25
MAC Address                : 14-FE-B5-FF-B1-9C
FQDD                       : NIC.Integrated.1-1-1
IPv4 Address               : 10.94.225.189
Subnet Mask                : 255.255.255.128
IPv6 Address               : fe80::7c5f:a114:84d4:17f6
Prefix Length              : 64
IPv4 Gateway Address       : 10.94.225.129
IPv4 DNSServer Address  0: 10.116.2.250
IPv4 DNSServer Address  1: 10.116.2.251
```

getled

Table 27. Details of getled attribute

Description	Displays the LED settings on a module: blinking, not blinking, or unknown (for empty slots). To run this subcommand, you must have the Login User privilege.
Synopsis	`racadm getled` `racadm getled -m <module>`
Input	`–m <module>` can be one of the following: • server-<n> where n=1–16 • server-<nx> where n=1–8; x=a, b, c, d (lower case) • switch-<n> where n=1–6 • chassis • cmc-active
Output	• LED is blinking • LED is not-blinking

Example	• `racadm getled -m server-10`
	`<module> <LED state>`
	server-10 Blinking
	• `racadm getled -m chassis`
	`<module> <LED state>`
	server-10 Not blinking
	• `racadm getled -m server-1`
	`<module> <LED state>`
	server-1 ON
	• `racadm getled -m server-9`
	`<module> <LED state>`
	server-9 Extension(1)
	`racadm getled`
	`LED State : Blinking`
	`racadm getled`
	`LED State : Not-Blinking`

getniccfg

Table 28. Details of getniccfg attribute

Description	Displays the current and static NIC settings for iDRAC. Displays the current NIC settings.
Synopsis	`racadm getniccfg [-m <module>]`
Input	`-m <module>` must be one of the following values:

Table 28. Details of getniccfg attribute (continued)

	• `chassis` : Default state if `-m` is not specified. • `server-<n>` : where n=1–16 • `server-<nx>` : where n=1–8; x = a, b, c, d (lower case) • `switch-<n>` : where n=1–6
Output	**NOTE:** **Table 29. Output**

IPv4 settings:	
NIC Enabled	=1
IPv4 Enabled	=1
DHCP Enabled	=1
IP Address	=10.94.225.165
Subnet Mask	=255.255.255.128
Gateway	=10.94.225.129
IPv6 settings:	
IPv6 Enabled	=1
DHCP6 Enabled	=0
IP Address 1	=2000:de11:bcd1:fc14:1234:5678:2468:abcd
Gateway	=::
Link Local Address	=fe80::f21f:afff:fed0:82d6/64
IP Address 2	=::
IP Address 3	=::
IP Address 4	=::
IP Address 5	=::
IP Address 6	=::
IP Address 7	=::
IP Address 8	=::
IP Address 9	=::
IP Address 10	=::
IP Address 11	=::
IP Address 12	=::
IP Address 13	=::
IP Address 14	=::
IP Address 15	=::
LOM Status:	
NIC Selection	=dedicated
Link Detected	=Yes

Table 28. Details of getniccfg attribute (continued)

Table 29. Output (continued)

Speed	=1Gb/s
Duplex Mode	=Full Duplex
Active NIC	=Dedicated
Static IPv4 settings:	
Static IP Address	=192.168.0.120
Static Subnet Mask	=255.255.255.0
Static Gateway	=192.168.0.1
Static IPv6 settings:	
Static IP Address 1	=2000:de11:bcd1:fc14:1234:5678:2468:abcd/64
Static Prefix Length	=64
Static Gateway	=::

IPv6 information is displayed only if IPv6 is enabled in iDRAC.

NOTE: IPv6 Address 1 field indicates static IP and IPv6 Address 2 field indicates dynamic IP.

NOTE: LOM Status is displayed only for iDRAC on Rack and Tower servers and is not displayed for iDRAC Enterprise on Blade servers.

Example

- Display CMC network settings

```
racadm getniccfg -m chassis
```

- Display iDRAC network settings in server slot 1

```
racadm getniccfg -m server-1
```

getraclog

Table 30. Details of getraclog attribute

Description

The `getraclog` command displays RAC log entries.

The `getraclog` command displays CMC log entries.

Synopsis

- `racadm getraclog [-i]`
- `racadm getraclog [-s <start>] [-c <count>] [--more]`

```
racadm getraclog [-c <count>] [-s <start-record>] [--more]
```

NOTE: If options are not provided, the entire log is displayed.

Input

- `-c` — Specifies the number of records to display.

  NOTE: On Local RACADM, the number of logs are restricted to 100 by default.
- `--more` — Displays one screen at a time and prompts you to continue (similar to the UNIX `more` command).
- `-s` — Specifies the starting record used for the display.

Table 30. Details of getraclog attribute (continued)

	• `-c` — Specifies the number of records to display. **NOTE:** On Remote RACADM, the number of logs are restricted to 25 by default. • `-i` — Displays the number of entries in the CMC log. • `--more` — Displays one screen at a time and prompts you to continue (similar to the UNIX `more` command). • `-s` — Specifies the starting record used for the display. **NOTE:** When Enhanced Chassis Logging and Events feature is enabled, then -i and --more options are not displayed.

Output	`SeqNumber = 286`
	`Message ID = USR0005`
	`Category = Audit`
	`AgentID = RACLOG`
	`Severity = Information`
	`Timestamp = 2012-10-05 06:25:27`
	`Message = Login failed from processdisco06a: 192.168.0`
	`Message Arg 1 = processdisco06a`
	`Message Arg 2 = 10.92.68.245`
	`FQDD = iDRAC.Embedded.1`

Example	• Display the starting record and the number of records.
	`racadm getraclog -s 10 -c 2`
	• Display a few records and prompt to display another set of records.
	`$ racadm getraclog --more`
	`Dec 4 22:23:09 CMC-JP4BF2S Login success from 192.168.0 (username=root, type=SSH, sid=16393)`
	`Dec 4 22:24:54 CMC-JP4BF2S Login success from 192.168.0 (username=test, type=SSH, sid=35885)`
	`Dec 4 22:26:20 CMC-JP4BF2S Login success from 192.168.0 (username=root, type=GUI, sid=27476)`
	`Dec 4 22:28:06 CMC-JP4BF2S Mod password of user puser succeeds`
	`Dec 4 22:28:06 CMC-JP4BF2S Mod privileges of user puser succeeds`
	`Dec 4 22:28:21 CMC-JP4BF2S Login success from 192.168.0 (username=puser, type=SSH, sid=39229)`
	`Dec 4 22:29:12 CMC-JP4BF2S Mod password of user nuser succeeds`
	`Dec 4 22:29:12 CMC-JP4BF2S Mod privileges of user nuser succeeds`
	`Dec 4 22:29:51 CMC-JP4BF2S SSH login failed (username=nuser, ip=192.168.0, reason=Local user fails to login )`
	`Dec 4 22:30:23 CMC-JP4BF2S last message repeated 3 times`
	`Dec 4 22:30:23 CMC-JP4BF2S Mod privileges of user nuser succeeds`
	`Dec 4 22:30:38 CMC-JP4BF2S SSH login failed (username=nuser, ip=192.168.0, reason=Local user fails to login )`
	`[more]`
	• Entry in the RAC log when Extended Power Performance control is enabled or disabled.
	`racadm getraclog`
	`Jul 31 14:16:11 CMC-4C2WXF1 Log Cleared`
	`Jul 31 14:15:49 CMC-4C2WXF1 Extended Power Performance is Enabled`
	`Jul 31 14:15:49 CMC-4C2WXF1 Extended Power Performance is Disabled`
	• When Enhanced Logging mode is enabled, the output of `getraclog` is displayed similar to `chassislog` output.
	Using `racadm config -g cfgRacTuning -o cfgRacTuneEnhancedLog 1` command, Enhanced Logging feature is enabled.
	`SeqNumber = 38`
	`Message ID = USR8501`
	`Category = Audit`
	`AgentID = CMC`
	`Severity = Information`

Table 30. Details of getraclog attribute (continued)

	`Timestamp = 2014-10-18 15:48:10`
	`Message Arg 1 = 14503`
	`Message Arg 2 = 48186`
	`Message = Successfully closed Session process: pid=14503 sid=4818`

Example	Display the recent 2 records for RAC log
	`racadm getraclog -c 2`
	`SeqNumber = 4102`
	`Message ID = LIC201`
	`Category = Audit`
	`AgentID = DE`
	`Severity = Warning`
	`Timestamp = 2014-06-12 01:38:19`
	`Message = License yPMRJGuEf7z5HG8LO7gh assigned to device iDRAC expires in 4 days.`
	`Message Arg 1 = yPMRJGuEf7z5HG8LO7ghMessage Arg 2 = iDRACMessage Arg 3 = 4`
	`----------`
	`SeqNumber = 4101`
	`Message ID = USR0032`
	`Category = Audit`
	`AgentID = RACLOG`
	`Severity = Information`
	`Timestamp = 2014-06-11 19:54:00`
	`Message = The session for root from 192.168.0 using RACADM is logged off.`
	`Message Arg 1 = root`
	`Message Arg 2 = 10.94.98.92`
	`Message Arg 3 = RACADM`
	`FQDD = iDRAC.Embedded.1`
	`----------`

getractime

Table 31. Details of getractime attribute

Description	Displays the current CMCiDRAC time.
Synopsis	• `racadm getractime [-d]` • `racadm getractime [-d] [-z]` • `racadm getractime [-n]`
Input	• `-d` — Displays the time in the format, YYYYMMDDhhmmss. • `-z` — Displays timezone. • `-n` — Displays NTP peer information. **NOTE:** If the options are not provided, then the `getractime` subcommand displays the time in a common readable format.
Output	The current CMCiDRAC time is displayed.

Example	• `racadm getractime`
	`Mon May 13 17:17:12 2013`
	• `racadm getractime -d`
	`20141126114423`

getremoteservicesstatus

Table 32. Details of getremoteservicesstatus

Description	Displays the status of a system.			
Synopsis	`racadm getremoteservicesstatus`			
Input	`racadm getremoteservicesstatus`			
Output	Possible values for the host system status • Powered Off • In POST • Out of POST • Collecting System Inventory • Automated Task Execution • Lifecycle Controller Unified Server Configurator • Server has halted at F1/F2 error prompt because of a POST error • Server has halted at F1/F2/F11 prompt because there are no bootable devices available • Server has entered F2 setup menu • Server has entered F11 Boot Manager menu	Possible values for the for LifeCycle controller(LC) status • Ready • Not Initialized • Reloading data • Disabled • In Recovery • In Use	Possible values for the real time status • Ready • Not ready	Possible values for the overall status status • Ready • Not ready
Example	• `racadm getremoteservicesstatus`			

getsel

Table 33. Details of getsel attribute

Description	Displays all system event log (SEL) entries in iDRACCMC.
Synopsis	• `racadm getsel [-i] [-m <module>]` • `racadm getsel [-s <start>][-c <count>] [-m <module>] [--more]` ⓘ **NOTE:** If no arguments are specified, the entire log is displayed.

Input	• `–i` — Displays the number of entries in the SEL.
	• `-s` — Displays the starting record number.
	• `-c` — Specifies the number of records to display.
	• `-m <module>` — Must be one of the following values:
	  ○ `server-<n>` : where n = 1–16
	  ○ `server-<nx>` : where n = 1–8; x = a, b, c, d (lower case)
	• `--more` — Displays one screen at a time and prompts the user to continue (similar to the UNIX `more` command.)

Table 33. Details of getsel attribute (continued)

Example	• Display entire log.
	`racadm getsel`
	• Display number of records in log.
	`racadm getsel -i`

getsensorinfo

Table 34. Details of getsensorinfo

Description	Displays the status for system sensors. **NOTE:** For Dell PowerEdge FX2 chassis with FM120x4 server, the power related information is not displayed. **NOTE:** General purpose graphical processing unit (GPGPU) status is displayed only on PowerEdge C4130 servers.
Synopsis	• `racadm getsensorinfo` • `racadm getsensorinfo -c`
Input	`-c` — Compact output format.

NOTE: Chassis Controller is supported only on Dell PowerEdge FX2 and GPU sensors are displayed only on PowerEdge C4130 servers.

Table 35. Example

<Num>	<sensorName>	<status>
1	IO-Cable	OK
2	FPC-Cable	OK

Table 36. Sensor Type

<Sensor Name>	<Status>	<Type>
PS1 Status	Present	AC

Table 37. Sensor info

<Sensor Name>	<Status>	<Reading>	<lc>	<uc>	<lnc>[R/W]	<Unc>[R/W]
System Board Inlet Temp	Ok	20 C	-7 C	47 C	3 C [Y]	42C [Y]
System Board Exhaust Temp	Ok	19 C	0 C	75 C	0 C [N]	70 C [N]
CPU1 Temp	Ok	59 C	3 C	97 C	8 C [N]	92 C [N]

Table 38. Temperature sensor

<Sensor Name>	<Status>	<Reading>	<lc>	<uc>	<PWM %>

Table 38. Temperature sensor (continued)

System Board Fan1 RPM	Ok	5880 RPM	600 RPM	NA	21%
System Board Fan2 RPM	Ok	6000 RPM	600 RPM	NA	0%
System Board Fan3 RPM	Ok	5880 RPM	600 RPM	NA	0%
System Board Fan4 RPM	Ok	5880 RPM	600 RPM	NA	0%
System Board Fan5 RPM	Ok	5640 RPM	600 RPM	NA	144%
System Board Fan6 RPM	Ok	5880 RPM	600 RPM	NA	152%

Table 39. Voltage sensor

<Sensor Name>	<Status>	<Reading>	<lc>	<uc>
CPU1 VCORE PG	Ok	Good	NA	NA
System Board 3.3V PG	Ok	Good	NA	NA
System Board 5V AUX PG	Ok	Good	NA	NA
CPU1 M23 VPP PG	Ok	Good	NA	NA
System Board 1.05V PG	Ok	Good	NA	NA
CPU1 M23 VDDQ PG	Ok	Good	NA	NA
CPU1 M23 VTT PG	Ok	Good	NA	NA
System Board 5V SWITCH PG	Ok	Good	NA	NA
System Board VCCIO PG	Ok	Good	NA	NA
System Board 2.5V AUX PG	Ok	Good	NA	NA
CPU1 M01 VDDQ PG	Ok	Good	NA	NA
System Board NDC PG	Ok	Good	NA	NA
CPU1 M01 VPP PG	Ok	Good	NA	NA
System Board 1.5V PG	Ok	Good	NA	NA
System Board PS2 PG Fail	Ok	Good	NA	NA
System Board PS1 PG Fail	Ok	Good	NA	NA
System Board 1.5V AUX PG	Ok	Good	NA	NA
CPU1 M01 VTT PG	Ok	Good	NA	NA
PS1 Voltage 1	Ok	240 V	NA	NA

Table 39. Voltage sensor (continued)

System Board DIMM PG	Ok	Good	NA	NA

Table 40. Current sensor

<Sensor Name>	<Status>	<Reading>	<lc>	<uc>	<lnc> [R/W]	<unc> [R/W]
PS1 Current 1	Ok	0.4 Amps	NA	NA	0 Amps [N]	0 Amps [N]
System Board Pwr Consumption	Ok	56 Watts	NA	1386 Watts	0 Watts [N]	1260 Watts [N]

Table 41. PROCESSOR sensor

<Sensor Name>	<Status>	<State>	<lc>	<uc>
CPU1 Status	Ok	Presence Detected	NA	NA
CPU2 Status	N/A	Absent	NA	NA

Table 42. MEMORY sensor

<Sensor Name>	<Status>	<State>	<lc>	<uc>
DIMM A1	N/A	Presence Detected	NA	NA
DIMM A2	N/A	Absent	NA	NA
DIMM A3	Ok	Absent	NA	NA
DIMM A4	N/A	Absent	NA	NA
DIMM A5	N/A	Absent	NA	NA
DIMM A6	N/A	Absent	NA	NA
DIMM A7	N/A	Absent	NA	NA
DIMM A8	N/A	Absent	NA	NA
DIMM A9	N/A	Absent	NA	NA
DIMM A10	N/A	Absent	NA	NA
DIMM A11	N/A	Absent	NA	NA
DIMM A12	N/A	Absent	NA	NA
DIMM B1	N/A	Absent	NA	NA
DIMM B2	N/A	Absent	NA	NA
DIMM B3	N/A	Absent	NA	NA
DIMM B4	N/A	Absent	NA	NA
DIMM B5	N/A	Absent	NA	NA
DIMM B6	N/A	Absent	NA	NA
DIMM B7	N/A	Absent	NA	NA
DIMM B8	N/A	Absent	NA	NA
DIMM B9	N/A	Absent	NA	NA
DIMM B10	N/A	Absent	NA	NA
DIMM B11	N/A	Absent	NA	NA

Table 42. MEMORY sensor (continued)

DIMM B12	N/A	Absent	NA	NA

Table 43. Chassis Controller sensor

<Sensor Name>	<Status>	<State>
Chassis Controller	OK	OK

```
/tmp # vi idraclogs
4 23:09:39 idrac8 L4, S3 [2440]: sessionmanagement_dmmapping_thread() confd (2)
4 23:09:39 idrac8 L4, S3 [2440]: request.command is 13
4 23:09:39 idrac8 L4, S3 [10297]: AddMessageToLclogEI() Obtained MUT Flag
4 23:09:39 idrac8 L4, S3 [10297]: ___ AddMessageToLclogEI : DCLCLWRAPCreateTLVLi
4 23:09:39 idrac8 L4, S3 [10297]: GetSledType() shmStatus 0 shmData0
4 23:09:39 idrac8 L5, S3 [10297]: RacadmcheckRSMStatus: This is RSM capable syst
4 23:09:40 idrac8 L4, S3 [10297]: ret is 0
4 23:09:40 idrac8 L4, S3 [10297]: probename is Chassis Controller
4 23:09:40 idrac8 L4, S3 [10297]: pCMCStatusobj->offsetKey is 24
4 23:09:40 idrac8 L4, S3 [10297]: pCMCStatusobj->sensorValue is 0
4 23:09:40 idrac8 L4, S3 [10297]: MAP Uninitialized, time to uninit = 0 millisec
4 23:09:40 idrac8 L4, S3 [10297]: RACADM total execution time: 1680 milliseconds
```

Table 44. Battery sensor

<Sensor Name>	<Status>	<Reading>	<lc>	<uc>
System Board CMOS Battery	Ok	Present	NA	NA
PERC1 ROMB Battery	Ok	Unknown	NA	NA
PERC2 ROMB Battery	Ok	Unknown	NA	NA

Table 45. PERFOMANCE sensor

<Sensor Name>	<Status>	<Status>	<lc>	<uc>
System Board Power Optimized	Ok	Not Degraded	NA	NA

Table 46. INTRUSION sensor

<Sensor Name>	<Intrusion>	<Status>
System Board Intrusion	Closed	Power ON

Table 47. REDUNDANCY sensor

<Sensor Name>	<Status>	<Type>
System Board Fan Redundancy	Full Redundant	Fan
System Board PS Redundancy	Disabled	PSU

Table 48. SYSTEM PERFORMANCE sensor

<Sensor Name>	<Status>	<Reading>	<lc>	<uc>	<lnc> [R/W]	<unc> [R/W]
System Board CPU Usage	Non-Critical	0%	0%	100%	0% [N]	99% [Y]

Table 48. SYSTEM PERFORMANCE sensor (continued)

System Board IO Usage	Non-Critical	0%	0%	100%	0% [N]	99% [Y]
System Board MEM Usage	Non-Critical	0%	0%	100%	0% [N]	99% [Y]
System Board SYS Usage	Non-Critical	0%	0%	100%	0% [N]	99% [Y]

getssninfo

Table 49. Details of getssninfo attribute

Description	Displays a list of users that are connected to iDRACCMC. The following information is displayed: • Session ID • Username • IP address (if applicable) • Session type (for example, serial or Telnet) • Login date and time in MM/DD/YYYY HH:MM:SS format **NOTE:** Based on the Session ID (SSNID) or the user name (User), the iDRACCMC administrator can close the respective sessions or all the sessions using the `closessn` subcommand. For more information, see closessn.
Synopsis	`racadm getssninfo [-u <username>] [-A]` `racadm getssninfo [-u <username> | -u *] [-A]`
Input	• `-u` — displays only sessions associated with a specific user. • `-A` — does not display headers or labels.

Table 50. Example

SSNID	Type	User	IP Address	Login Date/Time
58999	SSH	root	192.168.0.10	04/07/2016 12:00:34

Display the details of sessions without header

```
racadm getssninfo -A
```

```
"43584" "SSH" "root" "192.168.0.10" "04/07/2016 12:00:34"
```

- Display all currently active sessions for a specific user

```
racadm getssninfo -u root
```

getsvctag

Table 51. Details of attribute

Description	Displays the service tag of the host system.

Table 51. Details of attribute (continued)

Synopsis	`racadm getsvctag [-m <module>]`
Input	`-m <module>` — Must be one of the following values: • `chassis` • `server-<n>` — where n = 1–16 • `server-<nx>` — where n = 1–8; x = a, b, c, d (lower case) • `switch-<n>` — where n = 1–6
Output	Any system tag as applicable.

Example	• Display Service tag of Server in Slot 1
	`racadm getsvctag -m server-1`
	• Display Service tag of all the components in the chassis
	`racadm getsvctag`

getsysinfo

Table 52. Details of attribute

Description	Displays information related to iDRAC, managed system, and watchdog configuration. Displays information related to CMC, managed system, and watchdog configuration. **NOTE:** The host name and OS Name fields in the `getsysinfo` output display accurate information only if the **Dell OpenManage Server Administrator** is installed on the managed system. Else, these fields may be blank or inaccurate. An exception to this are VMware operating system names, which are displayed even if the **Server Administrator** is not installed on the managed system.
Synopsis	`racadm getsysinfo [-d] [-A] [-c] [-4] [-6]`
Input	• `–4` — Displays IPv4 settings • `–6` — Displays IPv6 settings • `–c` — Displays common settings • `–d` — Displays iDRAC information • `–d` — Displays CMC information • `–A` — Eliminates the printing of headers or labels

Output

```
racadm getsysinfo
CMC Information:
CMC Date/Time              = Wed Sep 17 2014 23:13
Primary CMC Location         = CMC-1
Primary CMC Version       = 5.00
Standby CMC Version       = 5.00
Last Firmware Updated     = Tue Sep 16 2014 22:11
Hardware Version          = A09
```

```
CMC Network Information:
NIC Enabled              = 1
MAC Address              = 78:2B:CB:46:5C:8A
Register DNS CMC Name    = 1
DNS CMC Name             = cmc-effort
Current DNS Domain       = cmc.com
VLAN ID                  = 1
```

```
VLAN Priority           = 0
VLAN Enabled            = 0
```

```
CMC IPv4 Information:
IPv4 Enabled            = 1
Current IP Address      = 192.168.0.10
Current IP Gateway      = 192.168.0.10
Current IP Netmask      = 255.255.255.0
DHCP Enabled            = 1
Current DNS Server 1    = 0.0.0.0
Current DNS Server 2    = 0.0.0.0
DNS Servers from DHCP   = 0
```

```
CMC IPv6 Information:
IPv6 Enabled            = 0
Autoconfiguration Enabled = 0
Link Local Address      = ::
Current IPv6 Address 1  = ::
Current IPv6 Gateway    = ::
Current IPv6 DNS Server 1 = ::
Current IPv6 DNS Server 2 = ::
DNS Servers from DHCPv6  = 0
```

```
Chassis Information:
System Model            = PowerEdge M1000e
System AssetTag         = 12345678901234567890123456781234456771234567890asvcdefrtghyhytg
Service Tag             = JGB6B2S
Chassis Name            = CMC-JGB6B2S
Chassis Location        = 3rdflor
Chassis Midplane Version= 1.1
Power Status            = ON
```

Output

```
RAC Information:
RAC Date/Time           = Thu Sep  3 17:25:06 2015

Firmware Version        = 2.20.20.20
Firmware Build          = 41
Last Firmware Update    = 09/02/2015 22:18:35
Hardware Version        = 0.01
MAC Address             = B8:2A:72:FC:4F:B0

Common settings:
Register DNS RAC Name   = 1
DNS RAC Name            = ipmierrata
Current DNS Domain      = sha512.com
Domain Name from DHCP   = Disabled

IPv4 settings:
Enabled                 = 1
Current IP Address      = 10.94.195.33
Current IP Gateway      = 10.94.195.1
Current IP Netmask      = 255.255.255.0
DHCP Enabled            = 1
Current DNS Server 1    = 10.94.192.67
Current DNS Server 2    = 0.0.0.0
DNS Servers from DHCP   = Disabled

IPv6 settings:
Enabled                 = 1
Current IP Address 1    = 2011:de11:bdc:195::16e/64
Current IP Gateway      = fe80::21c:23ff:fe6a:1106
Autoconfig              = 1
Link Local IP Address   = fe80::ba2a:72ff:fefc:4fb0/64
Current IP Address 2    = ::
Current IP Address 3    = ::
Current IP Address 4    = ::
```

```
Current IP Address 5     = ::
Current IP Address 6     = ::
Current IP Address 7     = ::
Current IP Address 8     = ::
Current IP Address 9     = ::
Current IP Address 10    = ::
Current IP Address 11    = ::
Current IP Address 12    = ::
Current IP Address 13    = ::
Current IP Address 14    = ::
Current IP Address 15    = ::
DNS Servers from DHCPv6 = Disabled
Current DNS Server 1     = 2011:de11:bdc:192::67/64
Current DNS Server 2     = ::

System Information:
System Model             = PowerEdge R630
System Revision          = I
System BIOS Version      = 1.3.6
Service Tag              = 62T3232
Express Svc Code         = 13230477902
Host Name                = WIN-2TA05N3JSLD
OS Name                  = Microsoft Windows Server 2008 R2, Enterprise x64 Edition
OS Version               = Version 6.1 (Build 7601 : Service Pack 1) (x64) Server Full In
Power Status             = OFF
Fresh Air Capable        = Yes
```

Example

- Display systemChassis information

```
racadm getsysinfo -c
```

- Display iDRACCMC information

```
racadm getsysinfo -d
```

- Display IPv4 details without header

```
racadm getsysinfo -A
```

```
"RAC IPv4 Information:"
"1"
"10.94.195.33"
"10.94.195.1"
"255.255.255.0"
"1"
"10.94.192.67"
"0.0.0.0"
"1"
```

```
"CMC IPv4 Information:"
"1"
"192.168.0.10"
"192.168.0.10"
"255.255.255.0"
"1"
"192.168.0.10"
"0.0.0.0"
"1"
```

gettracelog

Table 53. Details of attribute

Description	Lists all the trace login entries of iDRAC.

Table 53. Details of attribute (continued)

	Displays the CMC diagnostic trace log.
Synopsis	• `racadm gettracelog [-i]` • `racadm gettracelog [-s <start>] [-c <count>] [--more]`
Input	• `–i` — Displays the number of entries in iDRACCMC trace log. • `--more` — Displays one screen at a time and prompts the user to continue (similar to the UNIX more command). • `-c` — Specifies the number of records to display. • `-s` — Specifies the starting record to display.
Output	The default output display shows the record number, timestamp, source and description. The timestamp begins at midnight, January 1 and increases until the system starts. After the system starts, the system's timestamp is used.

Example	• Display entire log
	`racadm gettracelog`
	• Display number of records in log
	`racadm gettracelog -i`
	`Total Records: 228`

getversion

Table 54. Details of getversion attribute

Description	Displays the current software version, model and generation information, and whether the target device can be updated. **NOTE:** The Linux shell script does not support the characters—$ (dollar),` (back quote), \ (forward slash), & (ampersand), ((open bracket),) (Close bracket), = (equal), | (Pipe), ; (semi colon)," (Double quote), ' (single quote), < (less than), and > (greater than).
Synopsis	• `racadm getversion` • `racadm getversion [-b | -c | –i]` • `racadm getversion [-f <filter>]`

Input	• `-c` — Displays the server's current CPLD version.
	• `-b` — Displays the server's current BIOS version.
	• `-i` — Displays the server's current IDSDM version.
	• `-f <filter>` — Filters the components and must be one of the following values:
	  ○ `bios`: BIOS
	  ○ `idrac`: iDRAC
	  ○ `lc`: Lifecycle Controller
	  ○ `idsdm`: SD card

Table 55. Details

<server>	<iDRAC version>	<Blade Type>	<Gen>	<Updatable>
server-1	1.40.40 (Build 08)	PowerEdge M520	iDRAC	Y
server-2	3.50 (Build 2)	PowerEdgeM610x	iDRAC6	Y
server-4	3.50 (Build 4)	PowerEdgeM710HD	iDRAC6	

Table 56. Details

<Server>	*<CPLD Version>*	*<Blade Type>*
server-1	1.0.5	PowerEdgeM520
server-2	1.0.3	PowerEdgeM610x
server-4	1.0.0	PowerEdgeM710HD
server-5	1.0.3	PowerEdgeM710
server-7	1.0.6	PowerEdgeM620
server-9	1.0.5	PowerEdgeM520

```
racadm getversion
Bios Version = 2.0.18
iDRAC Version = 2.00.00.00
Lifecycle Controller Version = 2.00.00.00
```

Table 57. Details

<Server>	*<BIOS Version>*	*<Blade Type>*
server-1	1.6.0	PowerEdgeM520
server-2	6.3.0	PowerEdgeM610x
server-4	7.0.0	PowerEdgeM710HD

Table 57. Details (continued)

server-5	6.3.0	PowerEdgeM710
server-7	1.7.1	PowerEdgeM620
server-9	1.7.1	PowerEdgeM520

Table 58. Details

<Switch>	*<Model Name>*	*<HW Version>*	*<FW Version>*
switch-1	MXL 10/40GbE	X01	9-2(0-296)
switch-2	M8024-k 10GbE SW	A00	5.0.1.3
switch-3	Dell PowerConnect M8024	X00	
switch-4	Dell PowerConnect M8024	X00	
switch-5	Dell PowerConnect M6348	X02	
switch-6	Dell PowerConnect M6220	A01	

hwinventory

Table 59. Details of hwinventory

Description	Allows you to display or export current internal hardware inventory or shipped hardware inventory by device. **NOTE:** iDRAC supports a maximum of 12 parallel sessions of hardware inventory.
Synopsis	• racadm hwinventory • racadm hwinventory NIC|FC • racadm hwinventory <FQDD> • racadm hwinventory export -f <filename> -u <username> -p <password> -l <CIFS or NFS share>
Input	• <FQDD> — Specifies the FQDD of the target device. ○ FQDD — NIC.Slot.1–2 • -f — Exported Hardware Inventory filename. • -u — Username of the remote share to where the file must be exported. Specify user name in a domain as **domain/username** • -p — Password for the remote share to where the file must be exported. • -l — Network share location to where the Hardware Inventory must be exported.

Examples

- To get the list of NIC FQDDs, type the following command:

```
racadm hwinventory nic
NIC.Slot.2-1-1:Emulex OCe14102-U1-D - 00:90:FA:4C:FE:C2
PartitionCapable :                              1

NIC.Slot.2-1-2:Emulex OCe14102-U1-D - 00:90:FA:4C:FE:C3
PartitionCapable :                              2

NIC.Slot.2-1-3:Emulex OCe14102-U1-D - 00:90:FA:4C:FE:C4
PartitionCapable :                              3

NIC.Slot.2-1-4:Emulex OCe14102-U1-D - 00:90:FA:4C:FE:C5
PartitionCapable :                              4
```

- To display the statistics for the NIC FQDD, type the following command:

```
$racadm hwinventory <NIC FQDD>
```

```
Total RDMA Packets Received:            0

Total RDMA Packets Transmitted:            0

Total RDMA Bytes Transmitted:            0

Total RDMA Bytes Received:            0

Total RDMA Transmitted ReadRequest Packets:    0

Total RDMA Transmitted Send Packets:        0

Total RDMA Transmitted Write Packets:        0

Total RDMA Protocol Errors:            0

Total RDMA Protection Errors:            0
```

- To get the complete details for NIC.Integrated.1-4-1, type the following command:

```
racadm hwinventory NIC.Integrated.1-4-1
Device Description:                          Integrated NIC 1 Port 4 Partition 1
PCI Vendor ID:                                 14e4
PCI Sub Vendor ID:                             1028
PCI Device ID:                                 165F
PCI Sub Device ID:                             1f5b
Current MAC Address:                           74:86:7A:D6:E0:EF
Permanent MAC Address:                         74:86:7A:D6:E0:EF
Virtual iSCSI MAC Address:                     Unavailable
Permanent iSCSI MAC Address:                   Unavailable
Virtual FIP MAC Address:                       Unavailable
Permanent FIP MAC Address:                     Unavailable
Permanent FCoE MAC Address:                    Unavailable
Slot Type:                                     Not Applicable
Data Bus Width:                                Unknown
Slot Length:                                   Not Applicable
Bus Number:                                    2
DeviceNumber:                                  0
Function Number:                               1
Last Update Time:                              20140508190902.000000+000
Last System Inventory Time:                    20140515163940.000000+000
ProductName:                                   BRCM GbE 4P 5720-t rNDC
WWN:                                           Unavailable
VirtWWN:                                       Unavailable
WWPN:                                          Unavailable
VirtWWPN:                                      Unavailable
Family Version:                                7.8.16
Controller BIOS Version:                       1.32
EFI Version:                                   16.2.4
```

```
Max Bandwidth:                                  0
Min Bandwidth:                                  0
FCoE WWNN:
Vendor Name:                                    Broadcom Corp
Number of PCI-e Functions
Supported per Port:                             1
Number of PCI-e Functions
Currently Enabled per Port:                     1
Family Driver Version:                          Unavailable
Protocol:                                       1
Link Duplex:                                    Not Applicable
Link Speed:                                     Not Applicable
Auto Negotiated:                                Disabled
Transmit Flow Control:                          Off
Receive Flow Control:                           Off
Media Type:                                     Unavailable
NIC Mode:                                       Disabled
FCoE Offload Mode:                              Disabled
iSCSI Offload Mode:                             Disabled
Max Number of IOs per session supported:        0
Number of Max LOGINs per port:                  0
Max Number of exchanges:                        0
Max NPIV WWN per port:                          0
Number of Targets Supported:                    0
Max Number of outstanding commands
supported across all sessions:                  0
Flex Addressing:                                Capable
UEFI:                                           Capable
iSCSI Offload:                                  Not Capable
iSCSI Boot:                                     Capable
TCP OffloadEngine:                              Not Capable
FCoE:                                           Not Capable
FCoE Boot:                                      Not Capable
PXE Boot:                                       Capable
SRIOV:                                          Not Capable
Wake on LAN:                                    Capable
Network Management Pass Through:                Capable
OS2BMC PassThrough:                             Capable
Energy Efficient Ethernet:                      Capable
On Chip Thermal Sensor:                         Capable
NPar:                                           Not Capable
Remote PHY:                                     Not Capable
Feature Licensing:                              Not Capable
IPSec Offload:                                  Not Capable
MAC Sec:                                        Not Capable
RDMA:                                           Not Capable
Enhanced Transmission Selection:                Not Capable
Priority Flow Control:                          Not Capable
DCB Exchange Protocol:                          Not Capable
Congestion Notification:                        Not Capable
VEB-VEPA Single Channel:                        Not Capable
VEB-VEPA Multi Channel:                         Not Capable
EVB:                                            Not Capable
BPE:                                            Not Capable
Open Flow:                                      Not Capable
Partition WOL Support:                          Not Capable
Virtual Link Control                            Not Capable
Partition RX Flow Control:                      Not Capable
Partition TX Flow Control:                      Not Capable
TX Bandwidth Control Maximum:                   Not Capable
TX Bandwidth Control Minimum:                   Not Capable
```

- To export the inventory to a remote CIFS share, type the following command:

```
racadm hwinventory export -f Myinventory.xml -u admin -p xxx
  -l //1.2.3.4/share
```

- To export the inventory to a remote NFS share, type the following command:

```
racadm hwinventory export -f Myinventory.xml -u admin -p xxx
  -l 1.2.3.4:/share
```

- To export the inventory to local file system using local Racadm, type the following command:

```
racadm hwinventory export -f Myinventory.xml
```

- To display the Standard hardware inventory verbose description for the FC.Slot.2–1, type the following command:

```
racadm hwinventory FC.Slot.2-1
PCI Vendor ID:                                  1077
PCI Sub Vendor ID:                              1077
PCI Device ID:                                  2532
PCI Sub Device ID:                              015c
PCI Bus:                                        67
PCI Device:                                     0
PCI Function:                                   0
Vendor Name:                                    Unavailable
Device Name:                                    QLogic QLE2560 8Gb Fibre Channel
Adapter - 21000024FF089D8A
WWN:                                            20:00:00:24:FF:08:9D:8A
VirtWWN:                                        20:00:00:24:FF:08:9D:8A
WWPN:                                           21:00:00:24:FF:08:9D:8A
VirtWWPN:                                       21:00:00:24:FF:08:9D:8A
Chip Type:                                      ISP2532
Family Version:                                 02.57.14
EFI Version:                                    2.34
OS Driver Version:                              Unavailable
First FC Target WWPN:                           50:06:01:60:44:60:28:8C
First FC Target LUN:                            0
Second FC Target WWPN:                          00:00:00:00:00:00:00:00
Second FC Target LUN:                           0
Hard Zone Address:                              0
Hard Zone Enable:                               Disabled
FC Tape Enable:                                 Disabled
Loop reset Delay:                               5
Frame Payload Size :                            2048
Fabric Login Retry Count:                       0
Fabric Login Timeout:                           0
Port Login Retry Count:                         8
Port Login Timeout:                             3000
Port Down Retry Count:                          45
Port Down Timeout:                              0
Link Down Timeout:                              45000
Port Number:                                    1
Port Speed:                                     0
No capabilities found for FQDD "FC.Slot.2-1"
/admin1-> racadm hwinventory FC.Slot.3-1
PCI Vendor ID:                                  1077
PCI Sub Vendor ID:                              1077
PCI Device ID:                                  2031
PCI Sub Device ID:                              0256
PCI Bus:                                        4
PCI Device:                                     0
PCI Function:                                   0
Vendor Name:                                    QLogic
Device Name:                                    QLogic QLE2660 16Gb FC Adapter -
2001000E1E091075
WWN:                                            20:00:00:0E:1E:09:10:75
VirtWWN:                                        20:00:00:0E:1E:09:10:75
WWPN:                                           20:01:00:0E:1E:09:10:75
VirtWWPN:                                       20:01:00:0E:1E:09:10:75
Chip Type:                                      8324, Rev. 02
Family Version:                                 02.00.84
EFI Version:                                    5.30
OS Driver Version:                              9.1.10.27
First FC Target WWPN:                           00:00:00:00:00:00:00:00
First FC Target LUN:                            0
```

```
Second FC Target WWPN:                          00:00:00:00:00:00:00:00
Second FC Target LUN:                           0
Hard Zone Address:                              0
Hard Zone Enable:                               Disabled
FC Tape Enable:                                 Disabled
Loop reset Delay:                               5
Frame Payload Size :                            2048
Fabric Login Retry Count:                       0
Fabric Login Timeout:                           0
Port Login Retry Count:                         8
Port Login Timeout:                             3000
Port Down Retry Count:                          30
Port Down Timeout:                              0
Link Down Timeout:                              30000
Port Number:                                    1
Port Speed:                                     0
Max Number of IOs per connection supported:     9
Maximum number of Logins per port:              8
Maximum number of exchanges:                    9
Maximum NPIV per port:                          1
Maximum number of FC Targets supported:         8
Maximum number of outstanding commands across all connections: 9
Flex Addressing:                                Capable
UEFI:                                           Capable
FC Start:                                        Capable
On Chip Thermal Sensor:                         Capable
Feature Licensing:                              Not Capable
```

ifconfig

Table 60. Details of ifconfig attribute

Description	Displays the contents of the network interface table. To use this subcommand, you must have the Execute Diagnostic Commands permission. To use this subcommand, you must have the Administrator privilege.
Synopsis	`racadm ifconfig`
Input	N/A

Table 61. Example

`eth0`	`Link encap:Ethernet  HWaddr 00:1D:09:FF:DA:23`
	`inet addr:192.168.0.0 Bcast:192.168.0.255 Mask:255.255.255.0`
	`UP BROADCAST RUNNING MULTICAST  MTU:1500 Metric:1`
	`RX packets:2550665 errors:0 dropped:0 overruns:0 frame:0`
	`TX packets:0 errors:0 dropped:0 overruns:0 carrier:0`
	`collisions:0 txqueuelen:1000`
	`RX bytes:272532097 (259.9 MiB)  TX bytes:0 (0.0 B)`

inlettemphistory

Table 62. Details of inlettemphistory

Description	Displays the average and the peak temperatures during the last hour, day, week, month, or year. Also Exports the inlet temperature history data file. The file can be exported to a remote file share, local file system, or the management station.

Table 62. Details of inlettemphistory (continued)

	NOTE: For FM120x4 systems, this subcommand provides the historical data for system board temperature.
Synopsis	• `racadm inlettemphistory export -f <filename> -t <type> [-u <username of the network share>] [-p <password for the remote share>] [-i <network share location>]` • `racadm inlettemphistory get`
Input	• `-f` — Exports inlet temperature history filename. The maximum length of this parameter is 64 characters. **NOTE:** If a file with the specified filename exists, then the older file is replaced with the new history file. • `-u` — User name of the remote share to export the file. Specify user name in a domain as domain or username. • `-p` — Password for the remote share to where the file must be exported. • `-l` — Network share location to where the inlet temperature history must be exported. The maximum length of this parameter is 256 characters. **NOTE:** Export to an IPv6 NFS share is not supported. • `-t` — Specifies the exported file type. Valid values are `xml` and `csv`. These values are case-insensitive. **NOTE:** From firmware RACADM, only export to a remote share is supported. The behavior of remote share is not defined when the path specified (`-l`) contains special characters.

Example	• Export the log to a remote CIFS share.
	`racadm inlettemphistory export -f Mylog.xml -u admin -p xxx -l // 1.2.3.4/share -t xml`
	• Export the log to local file system using Local RACADM.
	`racadm inlettemphistory export -f Mylog.xml -t xml`
	• Export the log to management station using Remote RACADM.
	`racadm -r 1.2.3.4 -u user -p xxx inlettemphistory export -f Mylog.csv -t csv`
	• View the inlet temperature history.
	`racadm inlettemphistory get`
	`Duration Above Warning Threshold as Percentage = 0.0%`
	`Duration Above Critical Threshold as Percentage = 0.0%`
	
	`Average Temperatures`
	`Last Hour  = 23C ( 73.4F )`
	`Last Day  = 24C ( 75.2F )`
	`Last Week  = 24C ( 77.0F )`
	`Last Month = 25C ( 77.0F )`
	`Last Year  = 23C ( 73.4F )`
	
	`Peak Temperatures`
	`Last Hour  = 23C ( 73.4F ) [At Wed, 30 May 2012 11:00:57]`
	`Last Day  = 25C ( 77.0F ) [At Tue, 29 May 2012 15:37:23]`
	`Last Week  = 27C ( 80.6F ) [At Fri, 25 May 2012 10:38:20]`
	`Last Month = 29C ( 84.2F ) [At Wed, 16 May 2012 15:34:13]`
	`Last Year  = 29C ( 84.2F ) [At Wed, 16 May 2012 15:34:13]`

jobqueue

Table 63. Details of jobqueue

Description	Enables you to view and delete a job or jobs in the current Job Queue. **NOTE:** • To run this subcommand, you must have the **Server control** privilege. • If an unexpected error message is displayed for any operation, ensure you delete some jobs in the jobqueue and retry the operation. • Use jobqueue create command after applying a pending device configuration. Else, you may see a job creation and deletion in the lclog. • Multi-object Set commands using INI, XML, JSON files do NOT require a jobqueue create command; jobs will be automatically created by the Set command.

Synopsis	`racadm jobqueue view -i<jobid>`
	`racadm jobqueue delete [-i<jobid>][--all]`
	valid options are `-i` and `--all`.
	`racadm jobqueue create <fqdd> [-r <reboot type> ] [-s <start time> ] [-e <expiry time>]`
	`racadm jobqueue create <fqdd> [-r <reboot type>] [-s <start time>] [-e <expiration time>] [--realtime]`

Input	• `-i`—Specifies a job ID that is displayed or deleted. **NOTE:** The value `JID_CLEARALL` forces delete all the possible jobs in the queue. • `--all`—The job IDs that are not applicable are deleted. • `-fqdd`—Specifies an FQDD for which a job should be created. • `–r <reboot type>`—Specifies a reboot type. ○ `none`—No Reboot Job. This option is the default value. ○ `pwrcycle`—Power cycle. ○ `graceful`—Graceful Reboot without forced shutdown. ○ `forced` —Graceful Reboot with forced shutdown. • `start time`—Specifies a start time for job scheduled in the yyyymmddhhmmss format. TIME_NOW means immediate. Next Reboot means job is in scheduled state until the next manual restart. • `expiry time`—Specifies expiry time for the job execution in the yyyymmddhhmmss format. The job must start by this time. TIME_NA means expiry time is not applicable. • `--realtime`—Specifies the real time job. **NOTE:** ○ `--realtime` is applicable for storage configuration commands run on systems with PERC 9 cards with firmware version 9.1 and later. ○ `-r` option is not valid for real time configuration.

Example	• View jobs in the current job queue.
	`racadm jobqueue view`
	• View status of a specific job ID.
	`racadm jobqueue view -i <JobID>`

Table 63. Details of jobqueue (continued)

	• Issue configuration changes for a PERC controller then start a real time job to execute the changes.
	`racadm set RAID.Slot.3-1.RAIDdefaultWritePolicy WriteBack`
	`racadm set RAID.Slot.3-1.Name "Prod Workload"`
	`racadm jobqueue create RAID.Slot.3-1 -realtime`
	• Delete all possible jobs from the current job queue.
	`racadm jobqueue delete --all`
	• Delete a specific job from the current job queue.
	`racadm jobqueue delete -i <JobID>`
	• To clear all the jobs in the job queue.
	`racadm jobqueue delete -i JID_CLEARALL`
	• Create a Job for the provided FQDD and add to the job queue.
	`racadm jobqueue create NIC.Integrated.1-1 -r pwrcycle -s TIME_NOW -e 20120501100000`
	• Create a real time configuration job for the specified RAID controller.
	`racadm jobqueue create RAID.Integrated.1-1 -s TIME_NOW --realTime`
	`RAC1024: Successfully scheduled a job.`
	`Verify the job status using "racadm jobqueue view -i JID_xxxxx" command.`
	`Commit JID = JID_927008261880`

krbkeytabupload

Table 64. Details of krbkeytabupload

Description	Uploads a `Kerberos keytab` file to CMC. To run this subcommand, you must have the Configure iDRAC permission. Uploads a `Kerberos keytab` file to iDRAC. To run this subcommand, you must have the Server Control privilege.
Synopsis	`racadm krbkeytabupload [-f <filename>]` `<filename>` is the name of the file including the path.
Input	`-f` — Specifies the filename of the keytab uploaded. If the file is not specified, the keytab file in the current directory is selected.
Output	Returns 0 when successful and nonzero number when unsuccessful.
Output	When successful `Kerberos Keytab successfully uploaded to the RAC` message is displayed. If unsuccessful, appropriate error message is displayed.
Example	`racadm krbkeytabupload -f c:\keytab\krbkeytab.tab`

lclog

Table 65. Details of lclog

Description	Allows you to: • Export the lifecycle log history. The log exports to remote or local share location. • View the lifecycle log for a particular device or category. • Add comment to a record in lifecycle log. • Add a work note (an entry) in the lifecycle log. • View the status of a configuration job. **NOTE:** • When you run this command on Local RACADM, the data is available to RACADM as a USB partition and may display a pop-up message. • While Lifecycle Controller is running for racadm commands, you cannot perform other operation which needs Lifecycle Controller Partition. If the Lifecycle Controller Partition is unreleased (because of improper closure of racadm command in the partition), then you must wait 20-35 minutes to clear the Lifecycle Controller Partition

Synopsis	`racadm lclog view -i <number of records> -a <agent id>  -c <category> -s <severity> -b <sub-category> -q <sequence no> -n <number of records> -r <start timestamp> -e <end timestamp>`
	`racadm lclog comment edit -q <sequence number> -m <Text to be added>`
	`racadm lclog export -f <filename> -u <username> -p <password> -l <CIFS or NFS share>`
	`racadm lclog export -f <filename> -u <username> -p <password> -l <CIFS or NFS share> --complete`
	`racadm lclog viewconfigresult -j <job ID>`
	`racadm lclog worknote add -m <text to be added>`

Input	• `-i`—Displays the number of records present in the active log.
	• `-a`—The agent ID used to filter the records. Only one agent ID is accepted. The value is case-insensitive. Valid Agent-ID values:
	  ○ `UEFI_SS_USC`
	  ○ `CusOsUp`
	  ○ `UEFI_Inventory`
	  ○ `iDRAC`
	  ○ `UEFI_DCS`
	  ○ `SEL`
	  ○ `RACLOG`
	  ○ `DE`
	  ○ `WSMAN`
	  ○ `RACADM`
	  ○ `iDRAC_GUI`
	• `-k`—Filters the records based on the filter string provided in **racadm lclog view** command.
	• `-c`—The category used to filter the records. Provides multiple categories using a "," as the delimiter. The value is case-insensitive. Valid category values:
	  ○ `System`
	  ○ `Storage`
	  ○ `Worknotes`

Table 65. Details of lclog (continued)

	○ Config ○ Updates ○ Audit ● -b —The subcategory used to filter the records. Provides multiple subcategories using a "," as the delimiter. ● -q—The sequence number from which the records must be displayed. Records older than this sequence number is displayed. **NOTE:** This parameter input is an integer. If an alphanumeric input is provided, then invalid subcommand syntax error is displayed. ● -n—Specifies the n number of records that must be displayed. On Local RACADM, if this parameter is not specified, by default 100 logs are retrieved. ● -r—Displays events that have occurred after this time. The time format is yyyy-mm-dd HH:MM:SS. The time stamp must be provided within double quotation marks. ● -e—Displays events that have occurred before this time. The time format is yyyy-mm-dd HH:MM:SS. The time stamp must be provided within double quotation marks. ● -f <filename>—Specifies the file location and name where lifecycle log is exported. ● -a <name>—Specifies the FTP Server IP address or FQDN, user name, and password. ● -l <location>—Specifies the location of the network share or area on file system where lifecycle log is exported. Two types of network shares are supported: ○ SMB-mounted path: //<ipaddress or domain name>/<share_name>/<path to image> ○ NFS-mounted path: <ipaddress>:/<path to image>. ● -u <user>—Specifies the user name for accessing the FTP server, or Domain and user name for accessing network share location. ● -p <password>—Specifies the password for accessing the FTP server or share location. ● -s—The severity used to filter the records. Provide multiple severities using a "," as the delimiter. The value is case-insensitive. Valid Severity values: ○ Warning ○ Critical ○ Info ● —m <Comment> —User comment string for a record that must be inserted in the Lifecycle Controller log. This comment string must be less than 128 characters. The text must be specified within double quotation mark. **NOTE:** HTML-specific characters may appear as escaped text. ● -m <Worknote>—Adds a worknote (an entry) in the Lifecycle log. This worknote must be less than 256 characters. The text must be specified within double quotation mark. **NOTE:** HTML-specific characters may appear as escaped text. **NOTE:** For -m <worknote> and —m <comment> options, you need **test alert** privilege. ● --complete—Export the complete Lifecycle log as a compressed file. The exported file will be of the type .xml.gz. ● -j<Job ID>—Specifies the Job ID.

Example	● Display the number of records present in the Lifecycle log.
	`racadm lclog view -i`
	● Display the records containing the string session
	`racadm lclog view -k session`
	● Display the iDRAC agent idrac records, under the storage category and storage physical disk drive subcategory, with severity set to warning.
	`racadm lclog view -a idrac -c storage -b pdr -s warning`

Table 65. Details of lclog (continued)

	• Display the records under storage and system categories with severities set to `warning` or `critical`.
	`racadm lclog view -c storage,system -s warning,critical`
	• Display the records having severities set to `warning` or `critical`, starting from sequence number 4.
	`racadm lclog view -s warning,critical -q 4`
	• Display 5 records starting from sequence number 20.
	`racadm lclog view -q 20 -n 5`
	• Display all records of events that have occurred between 2011-01-02 23:33:40 and 2011-01-03 00:32:15.
	`racadm lclog view -r "2011-01-02 23:33:40" -e "2011-01-03 00:32:15"`
	• Display all the available records from the active Lifecycle log.
	`racadm lclog view`
	NOTE: If output is not returned when this command is used remotely, then retry increasing the remote RACADM timeout value. To increase the timeout value, run the command `racadm set iDRAC.Racadm.Timeout <value>`. Alternatively, you can retrieve few records.
	• Add a comment to record number 5 in the Lifecycle log.
	`racadm lclog comment edit -q 5 -m "This is a test comment."`
	• Add a worknote to the Lifecycle log.
	`racadm lclog worknote add -m "This is a test worknote."`
	• Export the Lifecycle log to a remote CIFS share.
	`racadm lclog export -f Mylog.xml -u admin -p xxx -l //192.168.0/share`
	• Export the complete Lifecycle log in gzip format to a remote CIFS share.
	`racadm lclog export -f log.xml.gz -u admin -p xxx -l //192.168.0/share --complete`
	• Export the Lifecycle log to a remote NFS share.
	`racadm lclog export -f Mylog.xml -l 192.168.0:/home/lclog_user`
	• Export the Lifecycle log to a local share using Local RACADM.
	`racadm lclog export -f Mylog.xml`
	• Export the complete Lifecycle login gzip format to a local share using Local RACADM.
	`racadm lclog export -f log.xml.gz --complete`
	• Export the Lifecycle log `lclog` to a local share using Remote RACADM.
	`racadm -r 192.168.0 -u admin -p xxx lclog export -f Mylog.xml`
	• Display the status of the specified Job ID with Lifecycle Controller.
	`racadm lclog viewconfigresult -j JID_123456789012`

license

Table 66. Details of license

Description	Manages the hardware licenses.
Synopsis	• `racadm license view [-c <component>]` • `racadm license import [-f <licensefile>] -l <location> -u <username> -p <password> -c <component> [-o]` • `racadm license export -f <license file> [-l <location>] [-u <username>] [-p <password>] -e <ID> -c <component>` • `racadm license delete -t <transaction ID> [-o]` • `racadm license delete -e <entitlement ID> [-o]` • `racadm license delete -c <component> [-o]` • `racadm license replace -u <username> -p <password> -f <license file name> -l <NFS/CIFS share> -t <transaction ID> [-o]`
Input	• `view` — View license information. • `import` — Installs a new license. • `export` — Exports a license file. • `delete` — Deletes a license from the system. • `replace` — Replaces an older license with a given license file. • `-l <remote share location>` — Network share location from where the license file must be imported. If the file is on a shared location, then `-u <share user>` and `-p <share password>` must be used. • `-f` — Filename or path to the license file • `-e <ID>` — Specifies the entitlement ID of the license file that must be exported • `-t <ID>` — Specifies the transaction ID. • `-c <component>` — Specifies the component name on which the license is installed. • `-o` — Overrides the End User License Agreement (EULA) warning and imports, replaces or deletes the license. **NOTE:** Only a user with **Server Control** and **Configure iDRAC** privilege can run the `import`, `delete`, and `replace` commands. **NOTE:** For export license, you need **Login** and **Configure iDRAC** privilege.

Examples

- View all License Information on System.

```
$racadm license view
```

```
iDRAC.Embedded.1
        Status                = OK
        Device                = iDRAC.Embedded.1
        Device Description    = iDRAC
        Unique Identifier     = H1VGF2S
                License #1
                        Status                = OK
                        Transaction ID        = 5
                        License Description   = iDRAC Enterprise License
                        License Type          = PERPETUAL
                        Entitlement ID        = Q3XJmvoxZdJVSuZemDehlcrd
```

```
                        License Bound        = H1VGF2S
                        Expiration           = Not Applicable
```

- Import a new license to a specific device in a known location.

```
$racadm license import -f license.xml -l //shareip/sharename
-u <share user> -p <share user password> -c idrac.embedded.1
```

- Import a license from a CIFS share to a device, in this case Embedded iDRAC.

```
 racadm license import -u admin -p xxx -f License.xml
-l //192.168.0/licshare -c idrac.embedded.1
```

- Import a license from an NFS share to a device, in this case Embedded iDRAC.

```
 racadm license import -f Licen.xml -l 192.168.0:/share
-c idrac.embedded.1
```

- Import a license by overriding the EULA warning.

```
racadm license import -u admin -p passwd -f License.xml
-l //192.168.0/licshare -c idrac.embedded.1 -o
```

- Import a license from the local file system using Local RACADM.

```
 racadm license import -f License.xml -c idrac.embedded.1
```

- Import a license from the local file system using Remote RACADM.

```
 racadm -r 192.168.0.1 -u admin -p xxx license import -f C:\Mylicdir\License.xml -c
idrac.embedded.1
```

- Export a license file.

```
racadm license export -f license.xml -l 192.168.0:/share -u uname -p xxx -c
iDRAC.Embedded.1
```

  Instead of `-c`, you can use `-e <ID>` or `-t <ID>`

  For Remote RACADM, if filename is not specified, the files are exported to the directory where RACADM is running.

- Export license to an NFS share using transaction ID, in this case transaction 27.

```
racadm license export -f License.xml -l 192.168.0:/licshare
-t 27
```

- Export license to a CIFS share specifying the entitlement ID, in this case abcdxyz.

```
racadm license export -u admin -p passwd -f License.xml
-l //192.168.0/licshare -e abcdxyz
```

- Export license to a CIFS share specifying the FQDD. While using the `-c` option and exporting a license from a device, more than one license file may be exported. Therefore if a filename is given, an index is appended to the end of the filename such as`LicenseFile0.xml`, `LicenseFile1.xml`. In this case, the device is Embedded iDRAC.

```
racadm license export -u admin -p xxx -f LicenseFile.xml -l //192.168.0/licshare -c
idrac.embedded.1
```

- Delete licenses on a particular device, in this case Embedded iDRAC.

```
racadm license delete -c idrac.embedded.1
```

- Delete a license using entitlement ID, in this case xYZabcdefg.

```
racadm license delete -e xYZabcdefg
```

- Delete a license using transaction ID, in this case 2.

```
racadm license delete -t 2
```

- Replace a license on a device with a license file on an NFS share using transaction ID. In this case, transaction 27.

```
racadm license replace -f License.xml -l 192.168.0:/licshare
-t 27
```

- Replace a license on a device with a license file on a CIFS share using transaction ID. In this case, transaction 27.

```
racadm license replace -u admin -p xxx -f License.xml
-l //192.168.0/licshare -t 27
```

netstat

Table 67. Details of netstat

Description	Display the routing table and network statistics.
Synopsis	`racadm netstat`

Examples

- To display the routing table and network statistics, type the following command:

```
$ racadm netstat
```

nicstatistics

Table 68. Details of nicstatistics

Description	Displays the statistics for the NIC FQDD.
Synopsis	• `racadm nicstatistics` • `racadm nicstatistics <NIC FQDD>` • `racadm hwinventory NIC.Integrated.1-1`

Examples

- To displays the statistics for the NIC FQDD, type the following command:

```
$racadm nicstatistics <NIC FQDD>
```

```
Total RDMA Packets Received:            0

Total RDMA Packets Transmitted:            0

Total RDMA Bytes Transmitted:            0

Total RDMA Bytes Received:            0

Total RDMA Transmitted ReadRequest Packets:    0

Total RDMA Transmitted Send Packets:        0

Total RDMA Transmitted Write Packets:        0

Total RDMA Protocol Errors:            0

Total RDMA Protection Errors:            0
```

- To display the statistics for the integrated NIC, type the following command:

```
$ racadm nicstatistics NIC.Integrated.1-1
```

```
Total Bytes Received:            0

Total Bytes Transmitted:        0

Total Unicast Bytes Received:        0

Total Multicast Bytes Received:        0

Total Broadcast Bytes Received:        0

Total Unicast Bytes Transmitted:    0
```

- To get the network statistics, type the following command:

```
$ racadm nicstatistics
```

```
NIC.Slot.5-2-1 : QLogic CNA Gigabit Ethernet-B8:AC:6F:B3:BF:10
```

```
NIC.Slot.5-2-1 : QLogic CNA Gigabit Ethernet-B8:AC:6F:B3:BF:11
```

```
NIC.Slot.5-2-1 : QLogic CNA Gigabit Ethernet-B8:AC:6F:B3:BF:12
```

```
NIC.Slot.5-2-1 : QLogic CNA Gigabit Ethernet-B8:AC:6F:B3:BF:13
```

```
NIC.Slot.5-2-1 : QLogic CNA Gigabit Ethernet-B8:AC:6F:B3:BF:14
```

ping

Table 69. Details of ping attribute

Description	Verifies if the destination IP address is reachable from iDRACCMC with the current routing-table contents. A destination IP address is required. Based on the current routing-table contents, an ICMP echo packet is sent to the destination IP address. To run this subcommand, you must have the **Administrator** privilege. To run this subcommand, you must have the **Debug** privilege.
Synopsis	`racadm ping <ipaddress>`
Input	`<ipaddress>` — The IP address of the remote endpoint to ping.

Output	`PING 192.168.0 (192.168.0): 56 data bytes64 bytes from 192.168.0: seq=0 ttl=64 time=4.121 ms`
	`192.168.0 ping statistics`
	`1 packets transmitted, 1 packets received, 0 percent packet lossround-trip min/avg/max = 4.121/4.121/4.121 ms`

ping6

Table 70. Details of ping6 attribute

Description	Verifies if the destination IPv6 address is reachable from iDRAC or with the current routing-table contents. A destination IPv6 address is required. Based on the current routing-table contents, an ICMP echo packet is sent to the destination IPv6 address. Verifies if the destination IPv6 address is reachable from CMC or with the current routing-table contents. A destination IPv6 address is required. Based on the current routing-table contents, an ICMP echo packet is sent to the destination IPv6 address. To run this subcommand, you must have the **Administrator** privilege. To run this subcommand, you must have **Debug** privilege.
Synopsis	`racadm ping6 <ipv6address>`
Input	`<ipv6address>` — the IPv6 address of the remote endpoint to ping.

Example	`Pinging 2011:de11:bdc:194::31 from 2011:de11:bdc:194::101 with 32 bytes of data:`
	`Reply from 2011:de11:bdc:194::31: time<1ms`
	`Reply from 2011:de11:bdc:194::31: time<1ms`
	`Reply from 2011:de11:bdc:194::31: time<1ms`
	`Reply from 2011:de11:bdc:194::31: time<1ms`
	
	`Ping statistics for 2011:de11:bdc:194::31:`
	`  Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),`
	`Approximate round trip times in milli-seconds:`
	`  Minimum = 0ms, Maximum = 0ms, Average = 0ms`

RACADM Proxy

Table 71. Details of RACADM Proxy

Description	On the PowerEdge FX2/FX2s systems, you can manage the compute sleds and CMC using the iDRAC's RACADM Proxy feature that redirects commands from iDRAC to CMC. You can return the CMC response to local or remote RACADM.to access the CMC configuration and reporting features without placing the CMC on the management network. The CMC configuration commands are supported through local proxy when local configuration is enabled on iDRAC. **NOTE:** Local racadm and local racadm proxy runs with root user privilege.

Synopsis	Local RACADM proxy usage
	`racadm <CMC racadm subcommand> --proxy`
	Remote RACADM proxy usage
	`racadm <CMC racadm subcommand> -u <username> -p <password> -r <idrac-ip connected to cmc> --proxy`
	NOTE:

Table 71. Details of RACADM Proxy (continued)

- The attribute `racadm getconfig -g cfgractuning -o cfgRacTuneChassisMgmtAtServer` must be set as non-zero in CMC.
- The attribute `racadm get system.ChassisControl.ChassisManagement Monitoring` attribute must be enabled in iDRAC.
- `--proxy` must be entered at the end of the command.
- **Table 72. The root privilege is the default privilege for Local RACADM proxy.**

Required CMC Privilege for an operation	Required iDrac Privilege for proxy operation
CMC Login User	Login
Chassis Configuration Administrator	Configure
User Configuration Administrator	Configure User
Clear Logs Administrator	Logs
Chassis Control Administrator	System Control
Server Administrator	System Control
Test Alert User	System Operations
Debug Command Administrator	Debug
Fabric x Administrator (where x is A, B, or C)	System Control

  The user privilege in the Remote RACADM proxy for CMC maps to iDRAC privilege.
- When CMC is not placed on the network, the import, export, and file operation commands to CIFS, NFS, or FTP will fail.
- When the Remote or Local RACADM Proxy operation is in progress, if the iDRAC is reset, then the Proxy operation fails and the output is not displayed in Remote or Local RACADM.
- When racadm `getsystem.ChassisControl.ChassisManagementMonitoring` attribute is set to `monitor`, all the users including root users can only view the attribute.

  To configure, set the attribute to `monitor and manage` in CMC.

Table 71. Details of RACADM Proxy (continued)

Input	• `-u` — Specifies the user name of the remote share that stores the catalog file. • `-p` — Specifies the password of the remote share that stores the catalog file. • `-r` — Specifies the iDRAC IP address connected to CMC.

Example	Local RACADM
	`racadm getractime --proxy`
	Remote RACADM
	`racadm getractime -u root -p xxx -r 192.168.0 getractime --proxy`

racdump

Table 73. Details of racdump attribute

Description	Provides a single command to get dump, status, and general iDRACCMC board information. This subcommand displays the comprehensive chassis status, configuration state information, and historic event logs. Used for post deployment configuration verification and during debugging sessions. To run this subcommand, you must have the Administrator privilege. To run this subcommand, you must have the Debug permission. Racdump includes the following subsystems and aggregates the following RACADM commands: • General System/RAC Information • Coredump Information • Network Interface Statistics • Session Information • Process Information • RAC Firmware Build Log • General System/RAC information — `getsysinfo` • Session information — `getssinfo` • Sensor information — `getsensorinfo` • Switches information (IO Module) — `getioinfo` • Mezzanine card information (Daughter card) — `getdcinfo` • All modules information — `getmodinfo` • Power budget information — `getpbinfo` • KVM information — `getkvminfo` • NIC information (CMC module) — `getniccfg` • Redundancy information — `getredundancymode` • Trace log information — `gettracelog` • RAC event log — `getraclog` • System event log — `getsel`
Synopsis	`racadm racdump` `racadm racdump`
Input	N/A

Table 73. Details of racdump attribute (continued)

Output	The following information is displayed when this subcommand is processed: • General system or RAC information • Coredump • Session information • Process information • Firmware build information

Example

```
================================================================================
 General System/RAC Information
================================================================================

RAC Information:
RAC Date/Time           = Thu Jul  3 13:35:32 2014

Firmware Version        = 2.05.05.05
Firmware Build          = 12
Last Firmware Update    = 07/02/2014 19:41:38
Hardware Version        = 0.01
MAC Address             = 18:03:73:F7:B7:CA

Common settings:
Register DNS RAC Name   = 0
DNS RAC Name            = idrac
Current DNS Domain      =
Domain Name from DHCP   = Disabled

IPv4 settings:
Enabled                 = 1
Current IP Address      = 192.168.0.1
Current IP Gateway      = 192.168.0.1
Current IP Netmask      = 192.168.0.1
DHCP Enabled            = 0
Current DNS Server 1    = 0.0.0.0
Current DNS Server 2    = 0.0.0.0
DNS Servers from DHCP   = Disabled

IPv6 settings:
Enabled                 = 0
Current IP Address 1    = ::
Current IP Gateway      = ::
Autoconfig              = 1
Link Local IP Address   = ::
Current IP Address 2    = ::
Current IP Address 3    = ::
Current IP Address 4    = ::
Current IP Address 5    = ::
Current IP Address 6    = ::
Current IP Address 7    = ::
Current IP Address 8    = ::
Current IP Address 9    = ::
Current IP Address 10   = ::
Current IP Address 11   = ::
Current IP Address 12   = ::
Current IP Address 13   = ::
Current IP Address 14   = ::
Current IP Address 15   = ::
DNS Servers from DHCPv6 = Disabled
Current DNS Server 1    = ::
Current DNS Server 2    = ::

System Information:
System Model            = PowerEdge R720
System Revision         = I
System BIOS Version     = 2.0.18
Service Tag             =
Express Svc Code        =
```

```
Host Name               = localhost.localdomain
OS Name                 =
OS Version              =
Power Status            = ON
Fresh Air Capable       = No

Watchdog Information:
Recovery Action         = None
Present countdown value = 478 seconds
Initial countdown value = 480 seconds

Embedded NIC MAC Addresses:
NIC.Integrated.1-3-1    Ethernet                = 78:2B:CB:4B:C2:ED
NIC.Integrated.1-1-1    Ethernet                = 78:2B:CB:4B:C2:EB


================================================================================
 Coredump Information
================================================================================
There is no coredump currently available.

================================================================================
 Network Interface Statistics
================================================================================
Kernel IPv6 routing table
Destination                                 Next Hop
Flags Metric Ref    Use Iface
::1/128                                     ::                                      U
 0      1        1 lo
::1/128                                     ::                                      U
 256    0        0 lo
fe80::1a03:73ff:fef7:b7ca/128               ::                                      U
 0      0        1 lo
fe80::/64                                   ::                                      U
 256    0        0 eth1
ff00::/8                                    ::                                      U
 256    0        0 eth1


Kernel IP routing table
Destination     Gateway         Genmask         Flags   MSS Window  irtt Iface
0.0.0.0         192.168.0.1     0.0.0.0         UG        0 0          0 bond0
192.168.0.1     0.0.0.0         192.168.0.1     U         0 0          0 bond0


Active Internet connections (w/o servers)
Proto Recv-Q Send-Q Local Address             Foreign Address           State
tcp        0      0 192.168.0.1:53986         192.168.0.1:199           ESTABLISHED
tcp        0      0 192.168.0.1:53985         192.168.0.1:199           ESTABLISHED
tcp        0      0 192.168.0.1:199           192.168.0.1:53986         ESTABLISHED
tcp        0      0 192.168.0.1:199           192.168.0.1:53985         ESTABLISHED


================================================================================
 Session Information
================================================================================
No active sessions currently exist.

================================================================================
 Process Information
================================================================================
  PID USER       VSZ STAT COMMAND
    1 root      5236 S    {systemd} /sbin/init
    2 root         0 SW   [kthreadd]
    3 root         0 SW   [ksoftirqd/0]
    6 root         0 SW   [watchdog/0]
    7 root         0 SW<  [khelper]
    8 root         0 SW   [kdevtmpfs]
    9 root         0 SW<  [netns]
  153 root         0 SW   [sync_supers]
  155 root         0 SW   [bdi-default]
  157 root         0 SW<  [kblockd]
  166 root         0 SW   [khubd]
```

```
16233 root     40916 S    racadm racdump
16246 root      3824 S    sh -c /bin/ps
16247 root      3828 R    /bin/ps
26851 root         0 SW   [kworker/u:3]


================================================================================
 RAC Firmware Build Log
================================================================================
BLD_TAG=idracfw_bldtag_2.05.05.05_691231_1800_00
BLD_VERSION=2.05.05.05
BLD_NUMBER=69.12.31
BLD_DATE=2.00.00.00.733
BLD_TYPE=idrac
BLD_KERNEL=ZIMAGE
```

```
racadm racdump
```

```
================================================================================
 General System/RAC Information
================================================================================

CMC Information:
CMC Date/Time           = Wed, 28 Nov 2007 11:55:49 PM
Active CMC Version      = X08
Standby CMC Version     = N/A
Last Firmware Update    = Wed Nov 21 21:37:56 2007
Hardware Version        = 2
Current IP Address      = 192.168.0.1
Current IP Gateway      = 192.168.0.1
Current IP Netmask      = 192.168.0.1
DHCP Enabled            = 1
MAC Address             = 00:55:AB:39:10:0F
Current DNS Server 1    = 0.0.0.0
Current DNS Server 2    = 0.0.0.0
DNS Servers from DHCP   = 0
Register DNS CMC Name   = 0
DNS CMC Name            = cmc-servicetag
Current DNS Domain      =


Chassis Information:
System Model            = PowerEdgeM1000eControlPanel
System AssetTag         = 00000
Service Tag             =
Chassis Name            = Dell Rack System
Chassis Location        = [UNDEFINED]
Power Status            = ON

================================================================================
 Session Information
================================================================================

Type    User     IP Address      Login Date/Time
SSH     root     192.168.0.2     11/28/2007 23:40:53
KVM     root     169.254.31.30   11/28/2007 18:44:51
```

```
================================================================================
 Sensor Information
================================================================================

<senType> <Num> <sensorName> <status> <reading> <units> <lc>
<uc>
FanSpeed    1    Fan-1         OK      14495    rpm     7250 14500
FanSpeed    2    Fan-2         OK      14505    rpm     7250 14500
FanSpeed    3    Fan-3         OK       4839    rpm     2344 14500
FanSpeed    4    Fan-4         OK      14527    rpm     7250 14500
FanSpeed    5    Fan-5         OK      14505    rpm     7250 14500
FanSpeed    6    Fan-6         OK       4835    rpm     2344 14500
```

```
FanSpeed     7     Fan-7          OK       14521     rpm      7250 14500
FanSpeed     8     Fan-8        Not OK         1     rpm      7250 14500
FanSpeed     9     Fan-9          OK        4826     rpm      2344 14500

<senType> <Num> <sensorName> <status> <reading> <units> <lc>
<uc>
Temp         1   Ambient_Temp    OK        21      celcius   N/A   40

<senType> <Num>  <sensorName>  <status>   <AC-OK status>
PWR          1       PS-1        Online          OK
PWR          2       PS-2        Online          OK
PWR          3       PS-3        Online          OK
PWR          4       PS-4       Slot Empty       N/A
PWR          5       PS-5        Failed          OK
PWR          6       PS-6        Slot Empty      N/A
```

racreset

Table 74. Details of racreset attribute

Description	Resets iDRAC. The reset event is logged in the iDRAC log. Resets CMC. The reset event is logged in the hardware (SEL) and CMC (RAC) logs. To run this subcommand, you must have the Chassis Administrator privilege. To run this subcommand, you must have the Configure iDRAC permission and configure user privilege. **NOTE:** After you run the `racreset` subcommand, iDRAC may require up to two minutes to return to a usable state. **NOTE:** After you run the `racreset` subcommand, CMC may require up to two minutes to return to a usable state. **NOTE:** There is a 100 percent fan request when the command is run against the servers.

Synopsis	`racadm racreset soft`
	`racadm racreset hard`
	`racadm racreset soft -f`
	`racadm recreset hard -f`
	`racadm racreset [-m <module> [-f]]`

Input	• `-f` — This option is used to force the reset.
	• `-m` — The values must be one of the following:
	  ○ server–<n> — where n=1–16
	  ○ server–<nx> — where n=1–8; x = a, b, c, d (lower case)
	NOTE:
	• Multiple modules may be specified, such as `-m <module1> -m <module 2>`.
	• `-f` option is used to force the reset and is available only with an `-m` option.

Output	`racadm racreset` `RAC reset operation initiated successfully. It may take up to a minute for the RAC to come online again.`

Table 74. Details of racreset attribute (continued)

Example	• iDRAC reset
	`racadm racreset`
	• To reset CMC.
	`racadm racreset`
	• To reset server 1
	`racadm racreset -m server-1`
	• To reset servers 1 and 3
	`racadm racreset -m server-1 -m server-3`

racresetcfg

Table 75. Details of racresetcfg attribute

Description	Deletes your current iDRAC configuration and resets iDRAC to the factory default settings. After reset, the default name and password are **root** and **calvin**, respectively, and the IP address is 192.168.0.120. Only for iDRAC Enterprise on Blade servers, IP address and the number of the slot the server inhabits in the chassis. If you run `racresetcfg` from a network client (for example, a supported web browser, Telnet or SSH, or Remote RACADM), use the default IP address. The `racresetcfg` subcommand does not reset the **cfgDNSRacName** object. To run this subcommand, you must have the Configure iDRAC privilege and configure user privilege. **NOTE:** Certain firmware processes must be stopped and restarted to complete the reset to defaults. iDRAC becomes unresponsive for about 30 seconds while this operation completes.
Synopsis	• RAC reset operation initiated successfully. It may take several minutes for the RAC to come online again. `racadm racresetcfg` • `racadm racresetcfg -f` • `racadm racresetcfg -all`
Input	• `-f` — Force `resetcfg`. If any vFlash partition creation or formatting is in progress, iDRAC returns a warning message. You can perform a force reset using this option. • `-all`—Perform `resetcfg`.

Example	• Reset the configuration on iDRAC.
	`racadm racresetcfg`
	The RAC configuration has initiated restoration to factory defaults.
	Wait up to a minute for this process to complete before accessing the RAC again.
	• Reset the iDRAC configuration to factory default.
	`racadm racresetcfg`
	`racadm racresetcfg -all`

Table 75. Details of racresetcfg attribute (continued)

	• Force a reset of the iDRAC configuration to factory default.
	`racadm racresetcfg -f`
	• Reset when vFlash Partition creation is in progress.
	`racadm racresetcfg`
	A vFlash SD card partition operation is in progress. Resetting the iDRAC may corrupt the vFlash SD card. To force `racresetcfg`, use the `-f` flag.

remoteimage

Table 76. Details of remoteimage attribute

Description	Connects, disconnects, or deploys a media file on a remote server. To run this subcommand, you must log in with virtual media privilege for iDRAC.
Synopsis	• `racadm remoteimage -d` • `racadm remoteimage -s` • `racadm remoteimage -c -u <username> -p <password> -l <image_location>`
Input	• `-c`—Connect the image. • `-d`—Disconnect image. • `-p`—Password to access shared folder. • `-u`—username to access shared folder. • `-l`—Image location on the network share; use single quotation marks around the location. • `-s`—Display status. • **NOTE:** Use a forward slash (`/`) when providing the image location. If backward slash (`\`) is used, override the backward slash for the command to run successfully. For example: `racadm remoteimage -c -u user -p xxx -l /\/\192.168.0.2/\CommonShare/\diskette` **NOTE:** The following options only apply to connect and deploy actions • `-u` —Username User name to access the network share. For domain users, you can use the following formats: ○ domain/user ○ domain\user ○ user@domain • `-p` —Password to access the network share.

Example	• Configure a Remote image.
	`racadm remoteimage -c -u "user" -p "xxx" -l //shrloc/foo.iso`
	`Remote Image is now Configured`

Table 76. Details of remoteimage attribute (continued)

	• Disable Remote File Sharing.
	`racadm remoteimage -d`
	`Disable Remote File Started. Please check status using -s option to know Remote File Share is ENABLED or DISABLED.`
	• Check Remote File Share status.
	`racadm remoteimage -s`
	`Remote File Share is Enabled`
	`UserName`
	`Password`
	`ShareName //192.168.0/xxxx/dtk_3.3_73_Linux.iso`
	• Deploy a remote image on iDRAC CIFS Share.
	`racadm remoteimage -c -u admin -p xxx -l 192.168.0.1:/dev/floppy.img`
	• Deploy a remote image on iDRAC NFS Share.
	`racadm remoteimage -c -u admin -p xxx -l 192.168.0.1:/dev/floppy.img`
	• Deploy a remote image on iDRAC HTTP Share.
	`racadm remoteinage -c -u "user" -p "xxx" -l http://shrloc/foo.iso`
	• Deploy a remote image on iDRAC HTTPS Share.
	`racadm remoteinage -c -u "user" -p "xxx" -l https://shrloc/foo.iso`
	NOTE: The -p and -u options are mandatory only for CIFS share and not mandatory for NFS, HTTP, and HTTPS.

rollback

Table 77. Details of rollback

Description	Allows you to roll back the firmware to an earlier version.
Synopsis	`racadm rollback <FQDD> [--reboot]` **NOTE:** To get the list of available rollback versions and FQDDs, run the `racadm swinventory` command.
Input	• `<FQDD>`: Specify the FQDD of the device for which the rollback is required. • `--reboot`: Performs a graceful system reboot after the BIOS firmware rollback.

Example	• To perform BIOS firmware rollback:
	`racadm rollback iDRAC.Embedded.1-1`
	`RAC1056: Rollback operation initiated successfully.`
	• To perform a graceful system reboot after BIOS firmware rollback:
	`racadm rollback BIOS.Setup.1-1 --reboot`

sensorsettings

Table 78. Details of sensorsettings

Description	Allows you to perform threshold settings of the sensor. To run this subcommand, you must have **Configure iDRAC** privilege. **NOTE:** An error message is displayed when the following is performed: • A set operation is performed on an unsupported FQDD. • Out of range settings is entered. • Invalid sensor FQDD is entered. • Invalid threshold level filter is entered.
Synopsis	`racadm sensorsettings set <FQDD> -level Min <value>`
Input	• `<FQDD>` — Sensor or corresponding sensor FQDD which needs a threshold configuration. Run the command, `racadm getsensorinfo` to view the sensor FQDD. The `R/W` field in the output getsensorinfo indicates if the sensor thresholds can be configured. Replace the `<FQDD>` field with the corresponding sensor FQDD that needs a threshold configuration. • `-level` — threshold level for the sensor setting. Values are `Max` or `Min`.
Examples	To set the minimum noncritical threshold level for a power sensor type. `racadm sensorsettings set iDRAC.Embedded.1#SystemBoardCPUUsage -level Max 95` **NOTE:** The entered value must be lesser or higher than the sensor critical threshold limit.

serveraction

Table 79. Details of serveraction attribute

Description	Enables you to perform power management operations on the blade system. To run this subcommand, you must have the Execute Server Control Commands permission.
Synopsis	`racadm serveraction <action> -f` • `racadm serveraction -a <action>` • `racadm serveraction -m <module> <action>`

Input	• `-m <module>` — Must be one of the following values:
	  ○ server–<n>: where n=1–16
	  ○ server–<nx>: where n=1–8; x=a–d (enter lowercase letter only).
	• `-a` — Performs power action on all servers. Not allowed with the `powerstatus` action.
	`<action>` — Specifies the power management operation to perform. The options are:
	• `hardreset` — Performs a force reset (reboot) operation on the managed system.
	• `powercycle` — Performs a power-cycle operation on the managed system. This action is similar to pressing the power button on the system's front panel to turn off and then turn on the system.
	NOTE: The `-m` and `-a` options are applicable only to CMC platforms.
	NOTE: If the server is in turned off state, the `powercycle` option power-up the server.

Table 79. Details of serveraction attribute (continued)

	• `powerdown` — Powers down the managed system. • `powerup` — Powers up the managed system. • `powerstatus` — Displays the current power status of the server (ON or OFF). • `graceshutdown` — Performs a graceful shutdown of the server. If the operating system on the server cannot shut down completely, then this operation is not performed. • `nmi` — Generates the Non-masking interrupt (NMI) to halt the system operation. The NMI sends a high-level interrupt to the operating system, which causes the system to halt the operation to allow critical diagnostic or troubleshooting activities. **NOTE:** The halt system operation does not occur on systems running the Linux operating system. • `-f` — Force the server power management operation. This option is applicable only for the PowerEdge-VRTX platform. It is used with `powerdown`,`powercycle`, and `hardreset` options. • `reseat` — Performs virtual reseat of the server. This operation simulates reseating the blade by resetting the iDRAC on that blade. `-f` is required for this operation. **NOTE:** The action `powerstatus` is not allowed with `-a` option.
Output	Displays an error message if the requested operation is not completed, or a success message if the operation is completed.

Example	Get Power Status on iDRAC
	`racadm serveraction powerstatus`
	`Server Power Status: ON`
	`racadm serveraction powercycle`
	`Server power operation successful`
	• Power down the operating system on the server by using the following command:
	`racadm serveraction powerdown`
	`Powers down the managed system`
	• Reseat blade 2 on CMC by using the following command:
	`racadm serveraction -m server-2 reseat -f`
	`Server power operation successful`
	• Turn off the server 16 from CMC by using the following command:
	`racadm serveraction -m server-16 powerdown`
	`Server power operation successful`
	• Get Power Status of blade 16 on CMC by using the following command:
	`racadm serveraction -m server-16 powerstatus`
	` ON`
	• Turn off the server 16 from CMC, when the power is already turned off on that server by using the following command:
	`racadm serveraction -m server-16 powerdown`
	`Server is already powered OFF.`
	• Power action on all servers by using the following command:
	`racadm serveraction -a powerup`

set

Table 80. Details of set

Description	Modifies the value of configuration objects on a component. The `Set` sub-command has two forms: ● The modification of a single object to a new value specified in the command line. ● The modification of multiple objects to new values using a configuration file. It supports multi-object value import from two configuration file formats. ○ INI format — The INI format files can be imported from a local file only ○ Server Configuration Profile XML format — XML format files can be imported from a local file, from an NFS network share or from a CIFS network share. **NOTE:** To run the`Set` sub-command for Server Configuration Profile XML files, use the Lifecycle Controller version 1.1 or later. Depending on the type of configuration object being modified, the new values could be applied immediately (in "real-time") or require staging and a reboot of the system to apply the new values. The following components support either real-time or staged application of new values: ○ iDRAC with Lifecycle Controller ○ PERC RAID controllers **NOTE:** Use PERC RAID controllers with firmware version 9.1 or later. The real-time support is provided only while performing hardware RAID configuration. The following components require staging and system reboot for application of new values: ● BIOS ● Other PERC RAID controllers — For software RAID configuration ● Networking devices – Ethernet and Fibre Channel **NOTE:** ● To modify the value of staged objects such as BIOS or NIC, commit and reboot job creation must be used to apply the pending values. When single object `Set`operations are used to stage value modification, use the jobqueue command to schedule a job to reboot the server and apply the new values. For staged multi-object `Set`operations using ini and xml configuration files, a job will automatically be created by the `Set` command; use the –b, -w and -s options to specify how the staged reboot will be performed. For more information, see jobqueue. ● To run this subcommand for configuration xml file type, the Lifecycle Contoller version 1.1 or later is required. **NOTE:** This command supports both IPV4 and IPV6 formats. IPV6 is applicable only for CIFS, HTTP, and HTTPS remote shares.
Synopsis	Single-object Set ● `racadm set <FQDD Alias>.<group> <value>` ● `racadm get <FQDD Alias>.<group>.<object> <value>` ● `racadm get <FQDD Alias>.<group>.[<index>].<object> <value>` ● `racadm get <FQDD Alias>.<index>.<group>.<index>.<object> <value>` Multi-object Set ● `racadm set -f <filename> [-t ini] [--continue]` ● `racadm set -f <filename> -t xml -l <NFS share> [--preview] [--continue]` ● `racadm set -f <filename> -t xml -l <NFS share> -c <FQDD>[,<FQDD>*]`

Table 80. Details of set (continued)

	• `racadm set -f <filename> -t xml -u <username> -p <password> -l <CIFS share> [--preview] [--continue]` • `racadm set -f <filename> -t xml -u <username> -p <password> -l <CIFS share> -c <FQDD>[,<FQDD>*]`
Input	• `<FQDD Alias>` Examples for FQDDs: ○ System.Power ○ System.Power.Supply ○ System.Location ○ LifecycleController.LCAttributes ○ System.LCD ○ iDRAC.Serial • `<group>` — Specifies the group containing the object that must be written. • `<object>` — Specifies the object name of the value that must be written. • `<index>` — This option is specified where FQDD Aliases or Groups must be indexed. • `-f <filename>` — Enables set to configure the device from a specified file. This option is not supported in the Firmware RACADM interface. • `--continue` — This option is used with –f only and is applicable for only for INI file operation.. If a multi-object `Set` is unsuccessful for a <group>, then `Set` continues with the next <group> in the file. If this option is not used, then `Set` stops when it is unsuccessful for a particular <group>. After the unsuccessful <group>, the remaining <group>s are not configured. **NOTE:** This option is applicable only for INI file operation. • `-u` — Specifies user name of the CIFS remote share from which the file must be imported • `-p` — Specifies password for the remote CIFS share from which the file must be imported. • `-l` — Specifies network share location from where the file must be imported. • `-t` — Specifies the file type to be imported. Valid values are `xml` and `INI`.`INI` files can only be imported from a local file. `XML`imports the Server Configuration Profile in `XML`format either from a local or network share file. **NOTE:** To import or export Server Configuration Profile `.xml`, use the Lifecycle Controller version 1.1 or later. Staging and reboot control options The following options control when and how system reboots are performed when using the –f option. As noted above, some `FQDD`s require a system reboot to apply the new values; other `FQDD`s optionally support immediate application of new values. If the imported file contains ONLY immediate application-capable `FQDD`s such as iDRAC, do NOT use the –b option and the Set command will schedule a real-time job to immediately apply the new values. **NOTE:** The –b, -w, –s, and --preview options are applicable only with –f option. • `-b` — . Specifies the type of shutdown for the system after a file import operation completes. The parameters are `Graceful`, `Forced`, and `NoReboot` for graceful shutdown, forced shutdown, and no reboot respectively. If -b is not specified, graceful shutdown is taken as the default except as noted above for files containing new values for immediate application-capable <FQDD>s. **NOTE:** If the operating system is in use, then the `graceful` shutdown option may time out within 300 seconds. If this operation is unsuccessful, then retry with the `force` option. • `-w` — Maximum time to wait for the graceful shutdown to occur. The value must be entered in seconds. Minimum accepted value is 300 seconds and the maximum accepted value is 3600 seconds. The default value is 1800 seconds. • `-s` — Power state of the host when the import operation completes. The parameters are "On" for powered ON and "Off" for powered OFF. If this parameter is not specified, power ON is taken as default. • `--preview` — Validates the configuration `.xml` file and view the status.

Table 80. Details of set (continued)

	The `--preview` option provides the **Job ID** to verify the status of the file preview operation. The **Job ID** can be tracked by running the `racadm jobqueue view -I <JID>` command. **NOTE:** ○ The `--preview` option does not restart the system. ○ The`-b`,`-w` options cannot be included with the `--preview` option. ○ A scheduled job or pending configuration should not be running while using the `--preview` option. ● `-c` — Specifies the FQDD or list of FQDDs separated by ',' of the components for which the configurations should be imported. If this option is not specified, configuration related to all the components are imported. **NOTE:** To use the `-c` or `--preview` option, the minimum Lifecycle Controller version required is 1.2. **NOTE:** On certain devices, importing the server configuration profile requires two imports to apply the configuration to all the devices. The first import of the profile enables hidden devices which are then configured with a second import. The devices that require two imports are as follows: ● PERC S110 and PERC S130 controllers ● PCI slots in the system that are disabled in the BIOS

Example	**Single-object Set of real-time objects**
	● Configure LCD String.
	`$ racadm set system.lcd.LCDUserString test`
	● ○ Configure iDRAC name.
	`racadm set iDRAC.Info.Name idrac-server100`
	Single-object Set of staged objects
	● Configure several BIOS settings, create a job to initiate application of new values, reboot the system, then wait for the job to complete.
	`racadm set BIOS.SysProfileSettings.ProcTurboMode Disabled`
	`racadm set BIOS.ProcSettings.ProcVirtualization Enabled`
	`racadm set BIOS.ProcSettings.ControlledTurbo Enabled`
	`racadm jobqueue create BIOS.Setup.1-1 -r Graceful`
	○ Make note of the Job ID output by the jobqueue command
	○ After reboot, wait for the job to complete by checking the job status
	`racadm jobqueue view -i <Job ID>`
	Multi-object Set of real-time objects
	● Configure the iDRAC using a local INI file.
	`racadm set -f myidrac.ini`
	● Configure the iDRAC using a local Server Configuration Profile XML file containing only iDRAC settings.
	`racadm set -f myidrac.xml -t xml`
	● Configure the iDRAC using a Server Configuration Profile XML file stored on an NFS share containing only iDRAC settings.
	`racadm set -f myidrac.xml -t xml -l 10.1.2.3:/myshare`
	● Configure a RAC from an XML configuration file located on a remote HTTP share.
	racadm set -f myfile.xml -t xml -u httpuser -p httppwd -l http://test.com/myshare
	● Configure a RAC from an XML configuration file located on a remote HTTPS share.
	racadm set -f myfile.xml -t xml -u httpsuser -p httpspwd -l https://test.com/myshare
	● Import a Server Configuration Profile from a CIFS share, using only the iDRAC component.
	`racadm set -f file -t xml -u myuser -p mypassword -l //192.168.0/share -c iDRAC.Embedded.1`

Table 80. Details of set (continued)

	Multi-object Set of staged objects
	● Configure a systems using a local Server Configuration Profile XML file containing a mix of real-time and staged objects; reboot the server gracefully with a wait time of ten minutes, leaving the server powered on after the reboot.
	`racadm set -f myfile.xml -t xml -b "graceful" -w 600 -s "on"`
	○ Make note of the Job ID output by the Set command.
	○ After reboot, wait for the job to complete by checking the job status.
	`racadm jobqueue view -i <Job ID>`
	● Configure a systems using a local Server Configuration Profile XML file containing a mix of real-time and staged objects; postpone reboot until other operations have been completed.
	`racadm set -f myfile.xml -t xml -b NoReboot`
	○ Make note of the Job ID output by the Set command; because of the NoReboot option, the job will be pending until the server is rebooted
	○ Complete other operations, then perform a reboot
	○ After reboot, wait for the job to complete by checking the job status
	`racadm jobqueue view -i <Job ID>`
	● Verify the Server Configuration Profile XML file content located in a remote CIFS share.
	`racadm set -f temp_Configuration_file -t xml -u Administrator -p Password -l //192.168.0/xyz -preview`

setled

Table 81. Details of setled attribute

Description	Sets the state (blinking or not blinking) of the LED on the specified module. To blink or unblink the chassis, I/O modules or the CMC, you must have the Debug Administrator privilege. To enable the servers to blink or unblink, you must have the Server Administrator or the Debug Administrator privilege. To run this subcommand, you must have the Configure iDRAC permission.
Synopsis	`racadm setled -l <ledState>` `racadm setled -m <module> -l <ledState>`
Input	● `-m <module>` — Specifies the module whose LED you want to configure. `<module>` can be one of the following: ○ server–<n>, where n=1–16 ○ server–<nx>, where n=1–8; x = a, b, c, d (lower case) ○ switch–<n>, where n=1–6 ○ cmc-active ○ chassis ● `-l <ledState>` — Specifies the LED state. The values are: ○ 0 — No Blinking ○ 1 — Blinking
Example	● `racadm setled -m chassis -l 1`

Table 81. Details of setled attribute (continued)

	Sets LED state on Chassis to Blink
	• `racadm setled -m server-1 -1 1`
	LED state was set successfully.
	• `racadm setled -m server-9 -1 1`
	`ERROR: Server in slot 9 is an extension of the server in slot 1.`
	NOTE: The `setled` command generates an error when run on the extension slot of a multi-slot server.
	• From iDRAC stop LED from blinking.
	`racadm setled -l 0`
	`RAC0908: System ID LED blink off.`
	• From iDRAC start LED to blink.
	`racadm setled -l 1`
	`RAC0907: System ID LED blink on.`

setniccfg

Table 82. Details of setniccfg attribute

Description	Sets the iDRACCMC IP address for static and DHCP modes. To run this subcommand, you must have the **Configure iDRACConfigure Chassis Administrator** privilege. **NOTE:** The command helps to modify network configuration properties. **NOTE:** The terms NIC and Ethernet management port may be used interchangeably.
Synopsis	• `racadm setniccfg -d` • `racadm setniccfg -d6` • `racadm setniccfg -s <IPv4Address> <netmask> <IPv4 gateway>` • `racadm setniccfg -s6 <IPv6 Address> <IPv6 Prefix Length> <IPv6 Gateway>` • `racadm setniccfg -o` • `racadm setniccfg [-m <module>] -d [-6]` • `racadm setniccfg [-m <module>] -s <ipAddress> <netmask> <gateway>` • `racadm setniccfg [-m <module>] -s -6 <ipv6Address> <prefixlen> <gateway>` • `racadm setniccfg [-m <module>] -v [<vlan_id> <vlan_priority>]` • `racadm setniccfg [-m chassis] -o` • `racadm setniccfg -p [-6]` • `racadm setniccfg [-m <module>] -k [<speed> <duplex>]`

Table 82. Details of setniccfg attribute (continued)

	• `racadm setniccfg [-i <slot>] -v [<vlan_id> <vlan_priority>]`

Input	• `-d` — Enables DHCP for the NIC. It is enabled by default.
	• `-d6` — Enables AutoConfig for the NIC (default is disabled).
	• `-s` — Enables static IP settings. The IPv4 address, netmask, and gateway must be specified. Otherwise, the existing static settings are used. `<ipaddress>`, `<netmask>`, and `<gateway>` must be typed as dot-separated strings.
	`racadm setniccfg -s 192.168.0 255.255.255.0 192.168.0`
	• `-s6` — Enables static IPv6 settings. The IPv6 address, Prefix Length, and the IPv6 Gateway can be specified.
	• `-o` — Enable or disable NIC.
	• `-m<module>` — Must be one of the following values:
	  ○ `chassis` — Default state if `-m` is not specified
	  ○ server–<n>: where n=1–16
	  ○ server–<nx>: where n=1–8; x=a–d (lower case)
	  ○ switch–<n>: where n=1–6
	• `-v` — VLAN settings has following legal values: no arguments imply remove VLAN tag, not compatible with server–nx (for example "server–4b") notation `<vlan_id>`=between 1 and 4000, 4021 and 4094, inclusive `<vlan_priority>`=between 0 and 7, inclusive.
	• `-p` — Disables IPv4(default) or IPv6 protocol.
	• `-k` — Option has following legal values: no arguments imply autonegotiate `<speed>`=10, 100 `<duplex>` =half, full.
	NOTE:
	• `-o`, `-k`, `-p`: These options can be specified for chassis only
	• `-6`: Sets static IPv6 addresses (with `-s`option). Enables `autoconfig` for IPv6 (with`-d` option) disables IPv6 (with`-p` option) can be specified for chassis or servers.
	• `-v`: When performing on a switch, release and renew any DHCP lease on that port for changes to take effect.

Example	• To Configure static IPv4 address for iDRAC NIC
	`racadm setniccfg -s 192.168.0 255.255.255.0 192.168.0`
	`Static IP configuration enabled and modified successfully`
	• Configure DHCP mode for iDRAC IPv4
	`racadm setniccfg -d`
	`DHCP is now ENABLED`
	• Configure DHCP mode for iDRAC IPv6
	`racadm setniccfg -d6`
	`DHCP6 is now ENABLED`
	• Configuration of Speed= 100 Mbps and duplex= full duplex.
	`racadm setniccfg -k 100 full`
	• Configuration of Speed and Duplex to Autonegotiate.
	`racadm setniccfg -k`
	• Configuration of VLAN id and priority of a slot or all blades in a sleeve.
	`racadm setniccfg -i 5 -v 1000  7`

Table 82. Details of setniccfg attribute (continued)

	• Configuration of CMC to a static IPv6 address.
	`racadm setniccfg -m chassis -s -6 2001:DB8::2 64 2001:DB8::1`
	• Configuration of server to use stateless autoconfiguration address.
	`racadm setniccfg -m server-1 -d -6`
	• Configuration of VLAN id and priority for a switch.
	`racadm setniccfg -m switch-1 -v 1000 7`
	• Removal of VLAN configuration from a switch.
	`racadm setniccfg -m switch-1 -v`
	• Configuration of redundant mode
	`racadm setniccfg -r 1`

sshpkauth

Table 83. Details of sshpkauth attribute

Description	Enables you to upload and manage up to 4 different SSH public keys for each user. You can upload a key file or key text, view keys, or delete keys. This command has three mutually exclusive modes determined by the options — `upload`, `view`, and `delete`. To run this subcommand, you must have Configure user privilege. **NOTE:** CMC accepts RSA keys up to key strength 4096, but the recommended key strength is 2048. **NOTE:** CMC does not support DSA algorithm.
Synopsis	• `racadm sshpkauth -i svcacct -k <key_index> -p <privilege> -t <PK_key_text>` • `racadm sshpkauth -i svcacct -k <key_index> -p <privilege> -f <PK_key_text>` • `racadm sshpkauth -v -i svcacct -k all|<key_index>` • `racadm sshpkauth -d -i svcacct -k all|<key_index>`
Input	• `-i <user_index>` — Index for the user. It must be svcacct for CMC. • `-k [<key_index> | all]` — Index to assign the PK key being uploaded. *all* only works with the `-v` or `-d` options. `<key_index>` must be between 1 to 46 or `all` on iDRACCMC. • `-p <privilege>` — Level to give to user for this PK key. • `-r <cmcIpAddr>` — Specifies the controller's remote IP address. • `-u <username>` — Specifies the user name. • `-t <PK_Key_Text>` — Key text for the SSH Public key. • `-f <filename>` — File containing the key text to upload. **NOTE:** The `-f` option is not supported on Telnet or SSH or serial RACADM. • `-v` — View the key text for the index provided. • `-d` — Delete the key for the index provided.

Example

- Upload an invalid key to iDRAC User 2 in the first key space using a string.

```
$ racadm sshpkauth -i 2 -k 1 -t "This is invalid key
Text"
```

```
ERROR: Key text appears to be corrupt
```

- Upload a valid key to iDRAC User 2 in the first key space using a file.

```
$ racadm sshpkauth -i 2 -k 1 -f pkkey.key
```

```
Key file successfully uploaded.
```

- Get all keys for User 2 on iDRAC.

```
$ racadm sshpkauth -v -i 2 -k all
```

```
********************* User ID 2 ******************
```

```
Key ID 1:
```

```
ssh-rsa    AAAAB3NzaC1yc2EAAAABIwAAAIEAzzy+k2npnKqVEXGXIzo0sbR6JgA5YNbWs3ekoxXV
               fe3yJVpVc/
5zrrr7XrwKbJAJTqSw8Dg3iR4n3vUaP+lPHmUv5Mn55Ea6LHUslAXFqXmOdlThd
               wilU2VLw/iRH1ZymUFnut8ggbPQgqV2L8bsUaMqb5PooIIvV6hy4isCNJU=
1024-bit RSA, converted from OpenSSH by xx_xx@xx.xx
```

```
Key ID 2:
```

```
Key ID 3:
```

```
Key ID 4:
```

sslcertdownload

Table 84. Details of sslcertdownload attribute

Description	Downloads an SSL certificate from iDRAC to the client's file system. To run this subcommand, you must have the **Server Control** privilege. **NOTE:** This subcommand is only supported on one or more remote interfaces.
Synopsis	`racadm sslcertdownload -f <filename> -t <type>`

Input	• `-f` — Specifies the target filename on local file system to download the certificate.
	• `-t <type>` — Specifies the type of certificate to download, either the CA certificate for Directory Service or the server certificate.
	  ○ `1`=server certificate
	  ○ `2`=Active Directory
	  ○ `3`=Custom Signing Certificate
	  ○ `4`=Client Trust certificate for SSL

Output	Returns 0 when successful and nonzero number when unsuccessful.
Example	• Download server certificate: `racadm -r 192.168.0 -u root -p xxx sslcertdownload -t 1 -f cert.txt`

Table 84. Details of sslcertdownload attribute (continued)

	• Download Active Directory certificate: `racadm -r 192.168.0 -u root -p xxx sslcertdownload -t 2 -f ad_cert.txt`

NOTE: This command is not supported in the firmware RACADM interface as it is not a file system.

sslcertupload

Table 85. Details of sslcertupload attribute

Description	Uploads a custom SSL server or CA certificate for Directory Service from the client to iDRAC. To run this subcommand, you must have the **Server Control** privilege.
Synopsis	`racadm sslcertupload -t <type> -f <filename> -p <passphrase> [-k <key file>]`

Input	• `-t <type>`—Specifies the type of certificate to upload. The type of certificate must be:
	  ○ `1`—Server Certificate
	  ○ `2`—Active Directory
	  ○ `3`—Public Key Cryptography Standards (PKCS) format
	  ○ `4`—Client Trust certificate for SSL
	• `-f`—Specifies the source filename in the local file system of the certificate uploaded.
	• `-p`—Pass phrase for decrypting the PKCS12 file uploaded.
	• `-k`—Filename of the private key file while using type 6 The private key is generated when the CSR is generated. If the CSR is generated on another server, then it is necessary to upload the private key with the certificate.
	• `-k`—Specifies optional source filename for private key when using type 6.

Output	`racadm -r 192.168.0.2 -u root -p xxx sslcertupload -t 2 -f cert.txt` Certificate successfully uploaded to the RAC.

Example	• Uploading a server certificate.
	`racadm -r 192.168.0.2 -u root -p xxx sslcertupload -t 1 -f cert.txt`
	• Upload web server certificate and key
	`racadm -r 192.168.0.2 -u root -p xxx sslcertupload -t 6 -f cert.txt -k key.txt`
	• Uploading Active Directory Certificate
	`racadm -r 192.168.0.2 -u root -p xxx sslcertupload -t 2 -f ad_cert.txt`

sslcertview

Table 86. Details of sslcertview attribute

Description	Displays the SSL server or CA certificate that exists on iDRACCMC.
Synopsis	`racadm sslcertview -t <type> [-A]`
Input	• `-t` — Specifies the type of certificate to view, either the CA certificate or server certificate.

Table 86. Details of sslcertview attribute (continued)

	○ 1=server certificate ○ 2=Active Directory • -A — Prevents printing headers or labels. **NOTE:** If a certificate is generated using comma ',' as one of the parameters for the Organization Name, Common Name, Location Name, or State Name, then this command displays the partial name in the respective fields only up to the comma. The rest of the string is not displayed. **NOTE:** For self-signed certificate, the common name includes PQDN (Partially qualified domain name) or FQDN (Fully qualified domain name).

Table 87. Output

Serial Number	01
Subject Information:	
Country Code (CC)	US
State (S)	Texas
Locality (L)	Round Rock
Organization (O)	Dell Inc.
Organizational Unit (OU)	Remote Access Group
Common Name (CN)	iDRACCMC Default certificate
Issuer Information:	
Country Code (CC)	US
State (S)	Texas
Locality (L)	Round Rock
Organization (O)	Dell Inc.
Organizational Unit (OU)	Remote Access Group
Common Name (CN)	iDRACCMC Default certificate
Valid From	Jul 7 23:54:19 2011 GMT

Table 87. Output (continued)

Valid To	Jun 4 23:54:19 2021 GMT

```
racadm sslcertview -t 1 -A
00
US
Texas
Round Rock
Dell Inc.
Remote Access Group
iDRACCMC default certificate
US
Texas
Round Rock
Dell Inc.
Remote Access Group
iDRACCMC default certificate
Jun 7 23:54:19 2011 GMT
Jun 4 23:54:19 2021 GMT
```

sslcertdelete

Table 88. Details of sslcertdelete

Description	Command to delete a custom signing certificate from iDRAC. To run this subcommand, you must have the **Server Control** privilege.
Synopsis	`racadm sslcertdelete -t <type>`
Input	`-t` — Specifies the type of certificate to delete. The type of certificate is: • `1&2` — Reserved • `3` — Custom signing certificate • `4` — Client Trust certificate for SSL
Output	The following information is displayed: • The custom signing certificate was deleted.

Table 88. Details of sslcertdelete (continued)

	• The iDRAC resets and may be offline temporarily.
Example	Use Remote RACADM to delete the custom signing certificate. `$ racadm -r 192.168.0 -u root -p xxx sslcertdelete -t 3`

sslcsrgen

Table 89. Details of sslcsrgen attribute

Description	Generates and downloads a certificate signing request (CSR) file to the client's local file system. The CSR can be used for creating a custom SSL certificate that can be used for SSL transactions on iDRACCMC. To run this subcommand, you must have the Configure iDRACchassis administrator privilege.
Synopsis	• `racadm sslcsrgen -g` • `racadm sslcsrgen [-g] [-f <filename>]` • `racadm sslcsrgen -s`
Input	• `-g` — Generates a new CSR. • `-s` — Returns the status of a CSR generation process (generation in progress, active, or none). • `-f` — Specifies the filename of the location, `<filename>`, where the CSR is downloaded. **NOTE:** • If the `-f` option is not specified, the filename defaults to `sslcsr` in your current directory. • The `-f` option is only supported on the remote interface(s).
Output	If no options are specified, a CSR is generated and downloaded to the local file system as `sslcsr` by default. The `-g` option cannot be used with the `-s` option, and the `-f` option can only be used with the `-g` option. The `sslcsrgen -s` subcommand returns one of the following status codes: • CSR was generated successfully. • CSR does not exist.

Example	• Display current status of CSR operation:
	`racadm sslcsrgen -s`
	or
	`racadm sslcsrgen -g -f c:\csr\csrtest.txt`
	• Generate and download a CSR to local file system:
	`racadm -r 192.168.0.120 -u root -p calvin sslcsrgen -g -f csrtest.txt`

NOTE: Before a CSR can be generated, the CSR fields must be configured in the RACADM `iDRAC.Security` group. For example:

```
racadm set iDRAC.security.commonname MyCompany
```

NOTE: Before a CSR can be generated, the CSR fields must be configured in the RACADM `config –g cfgracsecurity` group. For example:

```
racadm config -g cfgracsecurity -o cfgRacSecCsrCommonName cmc-effort.cmc.com
```

NOTE: In Telnet or SSH console, you can only generate and not download the CSR file.

NOTE: The duration for generating a CSR key depends on the length specified for the key.

sslkeyupload

Table 90. Details of sslkeyupload

Description	Uploads SSL key from the client to iDRAC. To run this subcommand, you must have the **Server Control** privilege. **NOTE:** This option is only supported on the remote interface (s).
Synopsis	`racadm sslkeyupload -t <type> -f <filename>`
Input	• `-t` — Specifies the key to upload. The value is: ○ `1` — SSL key used to generate the server certificate. • `-f` — Specifies the filename of the SSL key that must be uploaded.
Output	If upload is successful, the message `SSL key successfully uploaded to the RAC` is displayed. if upload is unsuccessful, error message is displayed.
Example	`racadm sslkeyupload -t 1 -f c:\sslkey.txt`

sslresetcfg

Table 91. Details of sslresetcfg attribute

Description	Restores the web-server certificate to factory default and restarts web-server. The certificate takes effect 30 seconds after the command is entered. To run this subcommand,you must have the Chassis Configuration Administrator privilege. To run this subcommand, you must have the Configure iDRAC privilege.
Synopsis	`racadm sslresetcfg`
Input	N/A
Example	`racadm sslresetcfg` `Certificate generated successfully and webserver restarted.`

storage

Table 92. Details of storage

Description	Allows you to run the commands to control storage arrays.

Table 92. Details of storage (continued)

	To run this subcommand for configuring the storage properties, you must have the server control permission. **NOTE:** You can also run the command using `raid` in place of the `storage` command.

Synopsis	**Inventory**
	• To view the help details for get command, run the following command:
	`racadm storage help get`
	• To generate and view information about the inventory of storage root node, run the following command:
	`racadm storage get status`
	• To generate and view information about the inventory of controllers, run the following command:
	`racadm storage get controllers -o`
	`racadm storage get controllers -o -p <property names separated by comma>`
	• To get the list of controllers, run the following command:
	`racadm storage get controllers`
	• To get the properties of PCIeSSD controller, run the following command:
	`racadm storage get controllers:<PcieSSD controller FQDD>`
	• To generate and view information about the inventory of batteries, run the following command:
	`racadm storage get batteries -o`
	`racadm storage get batteries --refkey <controller FQDD's separated by comma>`
	`racadm storage get batteries --refkey <controller FQDD's separated by comma> -o`
	`racadm storage get batteries --refkey <controller FQDD's separated by comma> -o -p <property names separated by comma>`

Table 92. Details of storage (continued)

	• To generate and view information about the inventory of virtual disks, run the following command:
	`racadm storage get vdisks`
	`racadm storage get vdisks --refkey <controller FQDDs separated by comma>`
	`racadm storage get vdisks --refkey <controller FQDDs separated by comma> -o`
	`racadm storage get vdisks --refkey <controller FQDDs separated by comma> -o -p <property names separated by comma>`
	• To generate and view information about the inventory of enclosures, run the following command:
	`racadm storage get enclosures -o`
	`racadm storage get enclosures --refkey <connector FQDDs separated by comma>`
	`racadm storage get enclosures --refkey <connector FQDDs separated by comma> -o -p <property names separated by comma>`
	• To get the list of enclosures, run the following command:
	`racadm storage get enclosures`
	• To get the properties of the PCIeSSD enclosure, run the following command:
	`racadm storage get enclosures:<PCIeSSD enclosure FQDD>`
	• To generate and view information about the inventory of physical disk drives, run the following command:
	`racadm storage get pdisks`
	`racadm storage get pdisks -o`
	`racadm storage get pdisks -o -p <property names separated by comma>`
	`racadm storage get pdisks --refkey <enclosure/Backplanes FQDDs separated by comma>`
	`racadm storage get pdisks --refkey <enclosure/Backplanes FQDDs separated by comma> -o`
	`racadm storage get pdisks --refkey <enclosure/Backplanes FQDDs separated`

Table 92. Details of storage (continued)

	`by comma> -o -p <property names separated by comma>`
	● To get the list of physical disks, run the following command:
	`racadm storage get pdisks`
	● To get the properties of PCIeSSD physical disk, run the following command:
	`racadm storage get pdisks:<PCIeSSD FQDD>`
	● To generate and view information about the inventory of fans, run the following command:
	`racadm storage get fans --refkey <enclosure FQDDs separated by comma>`
	`racadm storage get fans --refkey <enclosure FQDDs separated by comma > -o`
	`racadm storage get fans --refkey <enclosure FQDDs separated by comma> -o -p <property names separated by comma>`
	● To generate and view information about the inventory of EMMs, run the following command:
	`racadm storage get emms -refkey <enclosure FQDDs separated by comma>`
	`racadm storage get emms --refkey <enclosure FQDDs separated by comma> -o`
	`racadm storage get emms --refkey <enclosure FQDDs separated by comma> -o -p <property names separated by comma>`
	● To generate and view information about the inventory of PSU, run the following command:
	`racadm storage get psus -refkey <enclosure FQDDs separated by comma>`
	`racadm storage get psus --refkey <enclosure FQDDs separated by comma> -o`
	`racadm storage get psus --refkey <enclosure FQDDs separated by comma> -o -p <property names separated by comma>`
	Configuration

Table 92. Details of storage (continued)

	• To view the help details for a configuration command, run the following command: `racadm storage help <command>` `where command can take below values converttoraid, converttononraid, controllers, clearconfig, createsecuritykey, createvd, deletesecuritykey, deletevd, encryptvd, enclosures, emms, fans, hotspare, importconfig, ccheck, secureerase, preparetoremove, blink, unblink, cancelcheck, init, modifysecuritykey, psus, pdisks, resetconfig, tempprobes, vdisks, cancelbgi, replacephysicaldisk, setbootvd, forceonline, forceoffline, unlock and patrolread.` • To create, delete, and secure the virtual disks. To start or stop the consistency check on the specified virtual disk, run the following command: `racadm storage createvd:<Controller FQDD> -rl {r0|r1|r5|r6|r10|r50|r60}[-wp {wt|wb|wbf}] [-rp {nra|ra|ara}] [-ss {1k|2k|4k|8k|16k|32k|64k|128k|256k|512k|1M|2M|4M|8M|16M}]-pdkey:<comma separated PD FQDD> [-dcp {enabled|disabled|default}] [-name <VD name>] [-size <VD size>{b|k|m|g|t}] [-T10PIEnable]` **NOTE:** T10PI is not supported on PERC 9 and PERC 10. `racadm storage init:<VD FQDD> -speed {fast|full}` `racadm storage deletevd:<VD FQDD>` `racadm storage encryptvd:<VD FQDD>` `racadm storage createsecuritykey:<Controller FQDD> -key <Key id> -xxx <passphrase>` **NOTE: createsecuritykey** command is not supported on H3xx PERC controllers. `racadm storage modifysecuritykey:<Controller FQDD>`

Table 92. Details of storage (continued)

	`-key <Key id>-xxx <old passphrase> -xxx <new passphrase>`
	
	`racadm storage deletesecuritykey:<Controller FQDD>`
	
	`racadm storage ccheck:<vdisk fqdd>`
	
	`racadm storage cancelcheck:<vdisk fqdd>`
	
	• To convert the physical disk drives and assign or delete a hotspare. To scan physical disks connected to a controller and detect problem, run the following command:
	
	`racadm storage converttononraid:<PD FQDD>`
	
	NOTE: Convert to RAID and non-RAID is not supported on PERC 10 and BOSS controllers.
	
	`racadm storage converttoraid:<PD FQDD>`
	
	`racadm storage hotspare:<Physical Disk FQDD> -assign yes -type dhs -vdkey: <FQDD of VD>`
	
	`racadm storage hotspare:<Physical Disk FQDD> -assign yes -type ghs`
	
	`racadm storage hotspare:<Physical Disk FQDD> -assign no`
	
	`racadm storage patrolread:<controller FQDD> -state start|stop`
	
	`racadm raid cancelbgi:<VD FQDD>`
	
	`racadm raid replacephysicaldisk:<PD FQDD> -dstpd <PD FQDD>`
	
	NOTE: **replacephysicaldisk** method is not supported on non-redundant RAID volumes.
	
	`racadm raid setbootvd:<Controller FQDD> -vd <VD FQDD>`
	
	`racadm raid forceonline:<PD FQDD>`
	
	`racadm raid forceoffline:<PD FQDD>`
	
	`racadm storage unlock:<Controller FQDD> -key <Key id> -passwd <passphrase>`
	
	NOTE: If the `-assign` option is `no`, you cannot add other options. If the `-assign` option is `yes` and if the

Table 92. Details of storage (continued)

	`-type` option is not present, the global hotspare (ghs) is created by default.
	● To reset, clear, and import the storage configuration to the controller, run the following command:
	`racadm storage importconfig:<Controller FQDD>`
	`racadm storage resetconfig:<Controller FQDD>`
	`racadm storage clearconfig:<Controller FQDD>`
	● To start or stop a blink or identify operation on the specified or PCIeSSD device, run the following command:
	`racadm storage blink:<FQDD>`
	`racadm storage blink:<PCIeSSD FQDD>`
	`racadm storage unblink:<FQDD>`
	`racadm storage unblink:<PCIeSSD FQDD>`
	NOTE: The Start or Stop a Blink feature is not supported for HHHL PCIe SSD devices.
	● To prepare the PCIeSSD drive for removal, run the following command:
	`racadm storage preparetoremove <PCIeSSD FQDD>`
	NOTE: The **preparetoremove** task is not supported for HHHL PCIe SSD devices.
	NOTE: Ensure that the ISM is installed and running to perform the **preparetoremove** operation.
	● To perform a secure erase operation on PCIeSSD device, run the following command:
	`racadm storage secureerase:<PCIeSSD FQDD>`
	NOTE: **securerase** is now supported on SED drives along with PCIe SSD devices.

Input	● `-o`—Specifies the optimized version. ● `-p`—Specifies the property name. ● `--refkey`—Specifies the controller or enclosure FQDDs. ● `-rl`—Sets the storage level. ○ `r0`—storage 0-Striping ○ `r1`—storage 1-Mirroring ○ `r5`—storage 5-Striping with Parity ○ `r6`—storage 6-Striping with Extra Parity ○ `r10`—storage 10-Spanned Striping with Mirroring ○ `r50`—storage 50-Spanned Striping with Parity ○ `r60`—storage 60-Spanned Striping with Extra Parity

Table 92. Details of storage (continued)

	• -wp{wt|wb|wbf}—Sets the write policy to Write Through, Write Back, or Write Back Force
	• -rp {nra|ra|ara}—Sets the read policy to No Read Ahead, Read Ahead, Adaptive Read Ahead
	• -ss—Specifies the stripe size to use.
	• -pdkey:<PD FQDD list>—Specifies the physical disk drive to use in the virtual disk.
	• -dcp—Sets the Disk Cache Policy in the Virtual Disk.
	  ○ enabled—Allows the virtual disk to use the cache.
	  ○ disabled—Does not allow the virtual disk to use the cache.
	  ○ default—Uses the default cache policy. For SAS drives, use the disabled option and for SATA drives, use the enabled option by default.
	• -name <VD name>—Specifies the name of the virtual disk.
	• -size <VD size>—Specifies the size of each virtual disk.
	  ○ b—Specifies the size in bytes
	  ○ k—Specifies the size in kilobytes
	  ○ m—Specifies the size in megabytes
	  ○ g—Specifies the size in gigabytes
	  ○ t—Specifies the size in terabytes
	• -sc—Number of spans in a virtual disk (required for multi-span RAID level).
	  NOTE:
	  ○ For PERC9, if the value of controller.SupportRAID10UnevenSpans is supported, you can enter only 0 for this option while creating RAID level 10. The created RAID10 virtual disk displays the spandepth as 1 (default).
	  ○ For other controllers:
	  ▪ The default value for multi-span RAID levels is 2 and for basic RAID level is 1.
	  ▪ For hybrid RAID levels such as RAID10, RAID50, and RAID60, this option is mandatory.
	  ▪ The value for-sc option can be 0 only for RAID10.
	• -T10PIEnable—Creates a virtual disk with protection information.
	• -key <Key id>—Specifies the key id.
	• -passwd <passphrase>—Specifies the passphrase.
	• -newpasswd <passphrase>—Specifies the new passphrase.
	• -assign {yes | no}—Assigns or unassigns the disk as a hotspare.
	• -type { ghs | dhs}—Assigns a global or dedicated hotspare.
	• -vdkey:<VD FQDD>—Assigns the dedicated hotspare to the specified virtual disk. This option is required for dedicated hotspare.
	• -state <start|stop>—start value starts a patrol read operation. stop value stops a running patrol read operation.

Table 92. Details of storage (continued)

	NOTE: To start the operation, the `Controller.PatrolReadMode` must be in `Manual` mode.
	• `-dstpd`-replaces a physical disk in virtual disk configuration.
	• `-vd`-virtual disk fqdd to make it as a bootable drive.
	• `-speed`—Specifies the initialization of the Virtual disk.
	  ○ `fast`—Performs fast initialization.
	  ○ `full`—Performs slow initialization.
	• `blink: <FQDD>` or `unblink: <FQDD>`—`<FQDD>` can be physical disk drives, virtual disks, or PCIeSSD.
	• `<PCIeSSD FQDD>`—Specifies the PCIeSSD FQDD.
	• `<PCIeSSD controller|enclosure FQDD>`—Specifies the PCIeSSD controller or enclosure FQDD.
	• `preparetoremove`—Specifies the PCIeSSD drive to prepare for removal.
	NOTE: Ensure that ISM is installed and running to perform the `preparetoremove` operation.
	• `secureerase`—Specifies the PCIeSSD drive to perform the secure erase operation.

Example

Inventory

- To view the help details for get command, run the following command:

```
racadm>>storage help get
racadm storage help get
Storage monitoring and inventory of hardware RAID connected to the system.

Usage :
racadm storage get status
racadm storage help <Object type I/II>
racadm storage get <Object type I>
racadm storage get <Object type I> -current
racadm storage get <Object type I> -pending
racadm storage get <Object type I> -o
racadm storage get <Object type I> -o -p <property names separated by comma>
racadm storage get <Object type I>:<FQDD's of Object type I separated by comma> -p
<property names separated by comma>
racadm storage get <Object type I>:<FQDD's of Object type I separated by comma>
racadm storage get <Object type II> --refkey <reference keys separated by comma>
racadm storage get <Object type II> --refkey <reference keys separated by comma> -o
racadm storage get <Object type II> --refkey <reference keys separated by comma> -o
-p <property names separated by comma>
--------------------------------------------------------------------------------

Valid Options:
Object type I      : controllers, batteries, vdisks, pdisks, fans, emms, tempprobes,
psus, enclosures.
Object type II     : batteries, vdisks, pdisks, fans, emms, psus, tempprobes,
enclosures.
-current <optional>: Displays only the current Raid objects from storage.If -pending
not mentioned it will consider as the default option
-pending           : Displays only the Pending Raid Objects from Storage.
-o                 : Displays all the properties of the selected Key or Object.
-p                 : Displays the property names with filter.
FQDD's             : Displays all the properties of the FQDD's Key.
--refkey           : Displays all the reference key of Object type.
help               : Displays each object type help.
NOTE: Maximum Property names can be specified in -p option is = 10.
NOTE: Maximum FQDD's or refkey can be specified is = 3.
```

```
--------------------------------------------------------------------------------

Usage Examples :
racadm storage get controllers
racadm storage get psus
racadm storage get controllers -o
racadm storage get controllers -o -current
racadm storage get controllers -o -pending
racadm storage get enclosures -o
racadm storage get controllers -o -p name,status
racadm storage get vdisks -o -p layout,status
racadm storage get controllers:RAID.INTEGRATED.0
racadm storage get emms:EMM.Slot.0:ENCLOSURE.EXTERNAL.0-0:RAID.INTEGRATED.0
racadm storage get controllers:RAID.INTEGRATED.0 -p status
racadm storage get emms:EMM.Slot.0:ENCLOSURE.EXTERNAL.0-0:RAID.INTEGRATED.0 -p status
racadm storage get batteries --refkey RAID.INTEGRATED.0
racadm storage get pdisks --refkey ENCLOSURE.EXTERNAL.0-0:RAID.INTEGRATED.0
racadm storage get batteries --refkey RAID.INTEGRATED.0 -o -p status,state,name
racadm storage get fans --refkey RAID.INTEGRATED.0 -o -p status,speed,name
```

- To generate and view information about the inventory of controllers, virtual disks, storage enclosures, and physical drives.
  - To generate and view information about the inventory of storage root node.

    This command retrieves the status of the inventory for storage root node.

    ```
    racadm storage get status
    raid Root Node Status : Ok
    ```

  - To generate and view information about the inventory of controllers connected to the server.

    ```
    racadm storage get controllers
    RAID.Integrated.1-1
    ```

    The following command is an optimized version and displays the full controller objects along with their keys:

    ```
    racadm storage get controllers -o
    RAID.Integrated.1-1
       Status                          = Ok
       DeviceDescription               = Integrated RAID Controller 1
       RollupStatus                    = Ok
       Name                            = PERC H730P Mini (Embedded)
       FirmwareVersion                 = 25.2.1.0025
       DriverVersion                   = Information Not Available
       RebuildRate                     = 45
       BgiRate                         = 13
       CheckConsistencyRate            = 18
       ReconstructRate                 = 12
       PatrolReadRate                  = 21
       PatrolReadMode                  = Disabled
       PatrolReadState                 = Stopped
       CheckConsistencyMode            = Normal
       LoadBalanceSetting              = Disabled
       CopybackMode                    = OFF
       PreservedCache                  = Not Present
       CacheMemorySize                 = 2048 MB
       PersistHotspare                 = Disabled
       SpindownUnconfiguredDrives      = Disabled
       SpindownHotspare                = Disabled
       Timeintervalforspindown         = 30 (Minutes)
       SecurityStatus                  = Security Key Assigned
       EncryptionMode                  = Supported with LKM
       SasAddress                      = 0x5B8CA3A0F3073700
       PciDeviceId                     = 0x5d
       PciSubdeviceId                  = 0x1f47
       PciVendorId                     = 0x1000
       PciSubvendorId                  = 0x1028
       PciBus                          = 0x3
       PciDevice                       = 0x0
       PciFunction                     = 0x0
       BusWidth                        = Unknown
       SlotLength                      = Unknown
    ```

```
   SlotType                          = Unknown
   MaxCapableSpeed                   = 12.0 Gb/s
   LearnMode                         = Not supported
   T10PICapability                   = Capable
   SupportRAID10UnevenSpans          = Supported
   SupportEnhancedAutoForeignImport = Supported
   EnhancedAutoImportForeignConfig  = Enabled
   SupportControllerBootMode         = Supported
   ControllerBootMode                = Continue Boot On Error
   RealtimeConfigurationCapability  = Capable
   CurrentControllerMode             = RAID
   BootVD                            = Disk.Virtual.0:RAID.Integrated.1-1
```

The following command displays the filtered property values for all returned controller objects:

```
racadm storage get controllers -o -p Name
RAID.Integrated.1-1
Name = PERC H710P Adapter (Embedded)
```

The following examples show the pending operation when used with `storage get <object>` commands:

To list storage objects without displaying the properties:

- This operation displays `vdisk`, which has pending operation:

  ```
  racadm storage get vdisks -pending
  DISK.Virtual.267386880:RAID.Slot.5-1
  ```

- This operation displays controllers, which have pending operations:

  ```
  racadm storage get controllers -pending
  RAID.Integrated.1-1
  ```

- This operation displays `pdisk`, which has pending operation:

  ```
  racadm storage get pdisks -pending
  Disk.Bay.20:Enclosure.Internal.0-1:RAID.Integrated.1-1
  ```

- This operation displays enclosures, which have pending operations:

  ```
  racadm storage get enclosures -pending
  Enclosure.Internal.0-1:RAID.Integrated.1-1
  ```

  Changing the attribute by using `racadm set storage` or storage configuration command displays the storage object in the `-pending` command output. If there are no pending objects, the following error message is displayed:

  ```
  racadm storage get pdisks -pending
  ERROR: STOR0103 : No physical disks are displayed.
  Check if the server has power, physical disks are available, and physical disks
  are connected to the enclosure or backplane.
  ```

The following examples show the pending operation while listing the properties:

By default, if there is no change in properties, the `-pending` command displays the current value. If the property has any pending objects, the `-pending` command displays the pending value.

- This operation displays the current state of `pdisk`, which is in `Ready` state:

  ```
  /admin1-> racadm storage get pdisks -o -p state
  Disk.Bay.4:Enclosure.Internal.0-1:RAID.Integrated.1-1
     State                             = Ready
  ```

- This operation displays state of a `pdisk` on which `createvd` operation is pending:

  ```
  /admin1-> racadm storage get pdisks -o -p state -pending
  Disk.Bay.4:Enclosure.Internal.0-1:RAID.Integrated.1-1
  ```

The following command displays the output for PowerEdge FD332 support and full controller objects along with their keys:

```
racadm storage get controllers -o
RAID.Modular.3-1
   Status                           = Ok
   DeviceDescription                = Integrated RAID Controller 1 in Front Chassis
Slot 3
   RollupStatus                     = Ok
   Name                             = Slot 3,PERC FD33xS(Controller 1)
   FirmwareVersion                  = 25.2.2-0001
   RebuildRate                      = 55
   BgiRate                          = 55
   CheckConsistencyRate             = 55
   ReconstructRate                  = 55
   PatrolReadRate                   = 50
   PatrolReadMode                   = Manual
   PatrolReadState                  = Stopped
   CheckConsistencyMode             = Normal
   LoadBalanceSetting               = Disabled
   CopybackMode                     = OFF
   PreservedCache                   = Not Present
   CacheMemorySize                  = 2048 MB
   PersistHotspare                  = Disabled
   SpindownUnconfiguredDrives       = Disabled
   SpindownHotspare                 = Disabled
   Timeintervalforspindown          = 30 (Minutes)
   SecurityStatus                   = Encryption Capable
   EncryptionMode                   = None
   SasAddress                       = 0x5B083FE0E3EF5A00
   PciDeviceId                      = 0x5d
   PciSubdeviceId                   = 0x1f4d
   PciVendorId                      = 0x1000
   PciSubvendorId                   = 0x1028
   PciBus                           = 0x7
   PciDevice                        = 0x0
   PciFunction                      = 0x0
   BusWidth                         = 8x or x8
   SlotLength                       = Other
   SlotType                         = PCI Express Gen3
   MaxCapableSpeed                  = 12.0 Gb/s
   LearnMode                        = Not supported
   T10PICapability                  = Capable
   SupportRAID10UnevenSpans         = Supported
   SupportEnhancedAutoForeignImport = Supported
   EnhancedAutoImportForeignConfig  = Disabled
   SupportControllerBootMode        = Supported
   ControllerBootMode               = Continue Boot On Error
   RealtimeConfigurationCapability  = Capable
   CurrentControllerMode            = RAID
   BootVD                           = Disk.Virtual.0:RAID.Integrated.1-1
```

The following command displays the output for software RAID and full controller objects along with their keys:

```
racadm storage get controllers -o
RAID.Embedded.1-1
   Status                           = Unknown
   DeviceDescription                = Embedded RAID Controller 1
   RollupStatus                     = Unknown
   Name                             = PERC S130 Controller (PCI Slot 0)
   PciSlot                          = 0
   FirmwareVersion                  = 4.0.0-0037
   DriverVersion                    = Information Not Available
   RebuildRate                      = 0
   BgiRate                          = 0
   CheckConsistencyRate             = 0
   ReconstructRate                  = 0
   PatrolReadRate                   = 0
   PatrolReadMode                   = Not supported
   PatrolReadState                  = Unknown
   CheckConsistencyMode             = Not supported
   LoadBalanceSetting               = Not Supported
```

```
   CopybackMode                      = Not supported
   PreservedCache                    = Not Present
   CacheMemorySize                   = 0 MB
   PersistHotspare                   = Disabled
   SpindownUnconfiguredDrives        = Disabled
   SpindownHotspare                  = Disabled
   Timeintervalforspindown           = 0 (Minutes)
   SecurityStatus                    = Unknown
   EncryptionMode                    = None
   SasAddress                        = Not applicable
   PciDeviceId                       = 0x8d66
   PciSubdeviceId                    = 0x61b
   PciVendorId                       = 0x8086
   PciSubvendorId                    = 0x1028
   PciBus                            = 0x0
   PciDevice                         = 0x0
   PciFunction                       = 0x0
   BusWidth                          = Unknown
   SlotLength                        = Unknown
   SlotType                          = Unknown
   MaxCapableSpeed                   = 6.0 Gb/s
   LearnMode                         = Not supported
   T10PICapability                   = Not Capable
   SupportRAID10UnevenSpans          = Not Supported
   SupportEnhancedAutoForeignImport = Not Supported
   EnhancedAutoImportForeignConfig  = Unknown
   SupportControllerBootMode         = Not Supported
   RealtimeConfigurationCapability  = Incapable
   CurrentControllerMode             = Not Supported
   BootVD                            = Disk.Virtual.0:RAID.Integrated.1-1
```

- To generate and view information about the inventory of batteries connected to the controller, run the following command:

```
racadm storage get batteries
```

The following command is an optimized version and displays the batteries along with their keys:

```
racadm storage get batteries -o
Battery.Integrated.1:RAID.Integrated.1-1
Name                              = Battery
DeviceDescription                 = Battery on Integrated raid Controller 1
Status                            = Ok
State                             = Ready
```

The following command displays the filtered property values for all battery objects:

```
racadm storage get batteries -o -p Name
Battery.Integrated.1:RAID.Integrated.1-1
Name  = Battery
```

The following command displays all battery keys connected to the controllers:

```
racadm storage get batteries --refkey RAID.Integrated.1-1
Battery.Integrated.1:RAID.Integrated.1-1
```

The following command is an optimized and filtered version:

```
racadm storage get batteries --refkey RAID.Integrated.1-1 -o -p Name
Battery.Integrated.1:RAID.Integrated.1-1
Name                              = Battery
```

- To generate and view information about the inventory of virtual disks connected to the controller., run the following command:

```
racadm storage get vdisks
Disk.Virtual.0:RAID.Integrated.1-1
```

The following command displays all virtual disk keys connected to the controllers:

```
racadm storage get vdisks --refkey RAID.Integrated.1-1
Disk.Virtual.0:RAID.Integrated.1-1
```

The following command is an optimized and filtered version:

```
racadm storage get vdisks -o -p DeviceDescription,OperationalState
Disk.Virtual.0:RAID.Integrated.1-1
DeviceDescription        = Virtual Disk 0 on Integrated raid Controller 1
OperationalState         = Not applicable
```

- **Table 93. To generate and view information about the inventory of virtual disks**

Status	Ok
DeviceDescription	Virtual Disk 2 on Integrated RAID Controller 1
Name	OS
RollupStatus	Ok
State	Online
OperationalState	Not applicable
Layout	Raid-0
Size	278.88 GB
SpanDepth	1
AvailableProtocols	SAS
MediaType	HDD
ReadPolicy	Read Ahead
WritePolicy	Write Back
StripeSize	64K
DiskCachePolicy	Default
BadBlocksFound	NO

Table 93. To generate and view information about the inventory of virtual disks (continued)

Secured	NO
RemainingRedundancy	0
EnhancedCache	Not Applicable
T10PIStatus	Disabled
BlockSizeInBytes	512

- **Table 94. To generate and view information about the inventory of storage enclosures**

Status	Ok
State	Ready
DeviceDescription	Backplane 1 on Connector 0 of Integrated RAID Controller 1
RollupStatus	Ok
Name	BP13G+EXP 0:1
BayId	1
FirmwareVersion	0.23
SasAddress	0x500056B31234ABFD
SlotCount	24

The following command displays all enclosure keys connected to the connectors:

```
racadm storage get enclosures --refkey RAID.Integrated.1-1
Enclosure.Internal.0-1:RAID.Integrated.1-1
```

The following command is an optimized and filtered version:

```
racadm storage get enclosures --refkey RAID.Integrated.1-1 -o -p Name
Enclosure.Internal.0-1:RAID.Integrated.1-1
Name = BP12G+EXP 0:1
```

- To generate and view information about the inventory of physical disk drives connected to the enclosure or backplanes, run the following command:

```
racadm storage get pdisks
Disk.Bay.0:Enclosure.Internal.0-1:RAID.Integrated.1-1
```

The following command is an optimized version and displays the full controller physical disks along with their keys:

```
racadm storage get pdisks -o
racadm storage get pdisks
Disk.Bay.23:Enclosure.Internal.0-1:RAID.Integrated.1-1
   Status                          = Ok
   DeviceDescription               = Disk 23 in Backplane 1 of Integrated RAID
Controller 1
   RollupStatus                    = Ok
   Name                            = Physical Disk 0:1:23
   State                           = Online
   OperationState                  = Not Applicable
   PowerStatus                     = Spun-Up
   Size                            = 558.38 GB
   FailurePredicted                = NO
```

```
   RemainingRatedWriteEndurance     = Not Applicable
   SecurityStatus                   = Not Capable
   BusProtocol                      = SAS
   MediaType                        = HDD
   UsedRaidDiskSpace                = 136.13 GB
   AvailableRaidDiskSpace           = 0.00 GB
   Hotspare                         = NO
   Manufacturer                     = SEAGATE
   ProductId                        = ST9600204SS
   Revision                         = FM08
   SerialNumber                     = 6WN09DXN
   PartNumber                       = CN07T0DW7262211M01Y6A00
   NegotiatedSpeed                  = 6.0 Gb/s
   ManufacturedDay                  = 2
   ManufacturedWeek                 = 4
   ManufacturedYear                 = 2011
   SasAddress                       = 0x5000C5003324E93D
   FormFactor                       = 2.5 Inch
   RaidNominalMediumRotationRate    = 10000
   T10PICapability                  = Not Capable
   BlockSizeInBytes                 = 512
   MaxCapableSpeed                  = 6 Gb/s
```

The following command displays the filtered property values for all returned controller objects:

```
racadm storage get pdisks -o -p State
Disk.Bay.0:Enclosure.Internal.0-1:RAID.Integrated.1-1
State = Online
```

The following command displays all physical disk drive keys connected to the enclosures:

```
racadm storage get pdisks --refkey RAID.Integrated.1-1
Disk.Bay.0:Enclosure.Internal.0-1:RAID.Integrated.1-1
```

The following command is an optimized version and displays all disk objects for the enclosure FQDD:

```
racadm storage get pdisks --refkey Enclosure.Internal.0-1:RAID.Integrated.1-1 -o
racadm storage get pdisks -o
Disk.Bay.0:Enclosure.Internal.0-1:RAID.Integrated.1-1
Status                           = Ok
DeviceDescription                = Disk 0 in Backplane 1 of Integrated raid
Controller 1
RollupStatus                     = Ok
Name                             = Physical Disk 0:1:0
State                            = Online
OperationState                   = Not Applicable
PowerStatus                      = Spun-Up
Size                             = 278.88 GB
FailurePredicted                 = NO
RemainingRatedWriteEndurance     = Not Applicable
SecurityStatus                   = Not Capable
BusProtocol                      = SAS
MediaType                        = HDD
UsedraidDiskSpace                = 278.88 GB
AvailableraidDiskSpace           = 0.00 GB
Hotspare                         = NO
Manufacturer                     = SEAGATE
ProductId                        = ST9300605SS
Revision                         = CS05
SerialNumber                     = 6XP40SA9
PartNumber                       = CN0745GC7262228706R7A00
NegotiatedSpeed                  = 6.0 Gb/s
ManufacturedDay                  = 4
ManufacturedWeek                 = 32
ManufacturedYear                 = 2012
SasAddress                       = 0x5000C5005952386D
FormFactor                       = 2.5 Inch
raidNominalMediumRotationRate    = 10000
T10PICapability                  = Not Capable
BlockSizeInBytes                 = 512
```

```
MaxCapableSpeed                   = 6 Gb/s
ForeignKeyIdentifier              = dellkey1
```

The following command is an optimized and filtered version:

```
racadm storage get pdisks --refkey Enclosure.Internal.0-1:RAID.Integrated.1-1 -o -p
State
Disk.Bay.0:Enclosure.Internal.0-1:RAID.Integrated.1-1
State = Online
```

- To generate and view information about the inventory of fans connected to the enclosure.

  The following command displays all the fan keys connected to the enclosures:

```
racadm storage get fans --refkey <enclosure FQDDs separated
by comma>
```

  The following command displays all the fan objects for the enclosure FQDD:

```
racadm storage get fans --refkey <enclosure FQDDs separated
by comma > -o
```

```
racadm storage get fans --refkey <enclosure FQDDs separated
by comma> -o -p <property names separated by comma>
```

- To generate and view information about the inventory of EMMs connected to the enclosure.

  The following command returns all the EMM keys connected to the enclosures:

```
racadm storage get emms -refkey <enclosure FQDDs separated
by commaenclosure FQDDs separated
by comma>
```

  The following command is an optimized version and displays all the EMM objects for the enclosure FQDD:

```
racadm storage get emms --refkey <enclosure FQDDs separated
by comma> -o
```

  The following command is an optimized and filtered version:

```
racadm storage get emms --refkey <enclosure FQDDs separated
by comma > -o -p <property names separated by comma>
```

- To generate and view information about the inventory of PSU connected to the enclosure.

  The following command displays all the PSUs connected to the enclosures:

```
racadm storage get psus --refkey <enclosure FQDD's separated
by comma>
```

  The following command is an optimized version and displays all the PSUs objects for the enclosure FQDD:

```
racadm storage get psus --refkey <enclosure FQDD's separated
by comma > -o
```

  The following command is an optimized and filtered version:

```
racadm storage get psus --refkey <enclosure FQDD's separated
by comma> -o -p <property names separated by comma>
```

- To get the list of enclosures and properties of the PCIeSSD enclosure.
  - The following command provides the list of enclosures:

```
racadm storage get enclosures
Enclosure.Internal.0-1:RAID.Integrated.1-1\
Enclosure.Internal.0-1:PCIeExtender.Slot.3
```

- The following command provides the properties of the specified PCIeSSD enclosure:

```
racadm storage get enclosures:Enclosure.Internal.0-1:PCIeExtender.Slot.3
Enclosure.Internal.0-1:PCIeExtender.Slot.3
RollupStatus = Ok
DeviceDescription = Enclosure.Internal.0-1:PCIeExtender.Slot.3
Name = PCIe SSD BP 1
SlotCount = 4
FirmwareVersion = 0.80
```

- To get the list of physical disks and properties of the specified PCIeSSD physical disk.

  The following command provides the list of physical disks:

```
racadm storage get pdisks
Disk.Bay.0:Enclosure.Internal.0-1:RAID.Integrated.1-1
Disk.Bay.1:Enclosure.Internal.0-1:RAID.Integrated.1-1
Disk.Bay.2:Enclosure.Internal.0-1:RAID.Integrated.1-1
Disk.Bay.3:Enclosure.Internal.0-1:RAID.Integrated.1-1
Disk.Bay.4:Enclosure.Internal.0-1:RAID.Integrated.1-1
Disk.Bay.5:Enclosure.Internal.0-1:RAID.Integrated.1-1
Disk.Bay.8:Enclosure.Internal.0-1:PCIeExtender.Slot.3
Disk.Bay.6:Enclosure.Internal.0-1:PCIeExtender.Slot.3
Disk.Bay.7:Enclosure.Internal.0-1:PCIeExtender.Slot.3
Disk.Bay.9:Enclosure.Internal.0-1:PCIeExtender.Slot.3
```

  The following command provides the properties of the specified PCIeSSD physical disk:

```
racadm storage get pdisks:Disk.Bay.8:Enclosure.Internal.0-1:PCIeExtender.Slot.3
Disk.Bay.8:Enclosure.Internal.0-1:PCIeExtender.Slot.3
Status = Ok
DeviceDescription = PCIe Solid-State Drive in Slot 8 in Bay 1
Name = Physical Device 8
State = Ready
Size = 745.21 GB
BusProtocol = PCIe
MediaType = SSD
Model = SAMSUNG MZWEI800HAGM 000D3
ProductId = a820
SerialNumber = S1J1NYAD90019
DeviceProtocol = NVMe1.0
Manufacturer = SAMSUNG
PCIeNegotiatedLinkWidth = x4
PCIeCapableLinkWidth = x4
MaxCapableSpeed = 8 GT/s
NegotiatedSpeed = 8 GT/s
FormFactor = 2.5 Inch
Revision = IPM0ED35SAM SAMSUNG MZWEI800HAGM 000D3
RemainingRatedWriteEndurance = 100 %
FailurePredicted = NO
```

  To get the list of controllers and properties of the PCIeSSD controller.

  The following command provides the list of controllers:

```
racadm storage get controllers
RAID.Integrated.1-1
PCIeExtender.Slot.3
```

  The following command provides the properties of the specified PCIeSSD controller:

```
racadm storage get controllers:PCIeExtender.Slot.3
PCIeExtender.Slot.3
RollupStatus = Ok
DeviceDescription = PCIe Extender in PCIe Slot 3
Status = Ok
Name = PCIeExtender 3 (PCI Slot 3)
```

Configuration

- To view the help details for a configuration command, run the following command:

```
admin1-> racadm storage help createvd
Storage configuration of hardware RAID connected to the system.

Usage:
racadm storage createvd:<Controller FQDD> -rl {r0|r1|r5|r6|r10|r50|r60}[-wp {wt|wb|
wbf}] [-rp {nra|ra|ara}]
[-ss {1k|2k|4k|8k|16k|32k|64k|128k|256k|512k|1M|2M|4M|8M|16M}]
-pdkey:<comma separated PD FQDD> [-dcp {enabled|disabled|default}]
[-name <VD name>] [-size <VD size>{b|k|m|g|t}] [-T10PIEnable]
--------------------------------------------------------------------------------

Options :
-rl                    : Set the RAID Level
 r0                 : RAID 0  - Striping
 r1                 : RAID 1  - Mirroring
 r5                 : RAID 5  - Striping with Parity
 r6                 : RAID 6  - Striping with Extra Parity
 r10                : RAID 10 - Spanned Striping with Mirroring
 r50                : RAID 50 - Spanned Striping with Parity
 r60                : RAID 60 - Spanned Striping with Extra Parity
 -wp {wt | wb | wbf}    : Set the write policy to Write Through or Write Back or
Write Back Force
 -rp {nra|ra|ara}       : Set the read policy to No Read Ahead, Read Ahead, Adaptive
Read Ahead
 -ss                    : Specify the stripe size to use
 -pdkey:<PD FQDD list>  : The PDs to use in the VD.
 -dcp                   : Set the Disk Cache Policy in the VD
 enabled           : Enabled - Allow the disk to use it's cache
 disabled          : Disabled - Disallow the disk from using it's cache
 default           : Default - Use the default cache policy.
 SAS Drives  - Use Disabled by Default
 SATA Drives - Use Enabled by Default
 -name <VD name>        : The name to give the VD
 -size <VD size>        : The size of the VD
 b                : Specify the size in bytes
 k                : Specify the size in kilobytes
 m                : Specify the size in megabytes
 g                : Specify the size in gigabytes
 t                : Specify the size in terabytes
 -sc               : Spandepth: Number of spans in a virtual disk

Note:
 - This option is mandatory for hybrid raid level like RAID 10, RAID50 and RAID60.
 - The default value is one for basic RAID levels.
 - If RAID10 Uneven Span is Supported then for RAID10:
 -    -sc option will be optional.
 -    Will allow only 0 value for this option.
 -T10PIEnable                : To create a VD with PI
--------------------------------------------------------------------------------
Description :
Create a VD.
--------------------------------------------------------------------------------

Examples :
racadm storage createvd:RAID.Integrated.1-1 -rl r0
-pdkey:Disk.Bay.0:Enclosure.Internal.0-0:RAID.Integrated.1-1
```

- To create, delete, and secure the virtual disks.
  - The following command creates a virtual disk:

    ```
    racadm storage createvd:RAID.Integrated.1-1 -rl r0
    -pdkey:Disk.Bay.0:Enclosure.Internal.0-0:RAID.Integrated.1-1
    ```

  - The following command starts an initialization operation on a specified virtual disk:

    ```
    racadm storage init:Disk.Virtual.0:RAID.Integrated.1-1 -speed fast
    ```

  - The following command deletes the specified virtual disk:

    ```
    racadm storage deletevd:Disk.Virtual.0:RAID.Integrated.1-1
    ```

- The following command encrypts the specified virtual disk:

```
racadm storage encryptvd:Disk.Virtual.0:RAID.Integrated.1-1
```

NOTE: Virtual disk must be created with SED.

- The following command assigns security key for controller:

```
racadm storage createsecuritykey:RAID.Integrated.1-1 -key <Key id> -xxx <passphrase>
```

- The following command modifies security key for controller:

```
racadm storage modifysecuritykey:RAID.Integrated.1-1 -key <Key id> -oldpasswd
<oldpassphrase> -newpasswd <newpassphrase>
```

- The following command deletes security key for controller:

```
racadm storage deletesecuritykey:RAID.Integrated.1-1
```

- To convert the physical disk drive and assign hotspare.
  - The following command converts the specified non-storage physical disk drive to a storage capable physical disk drive:

```
racadm storage converttoraid:Disk.Bay.0:Enclosure.Internal.0-0:RAID.Integrated.1-1
```

  - The following command converts the specified physical disk drive to a non-storage physical disk drive:

```
racadm storage
converttononraid:Disk.Bay.0:Enclosure.Internal.0-0:RAID.Integrated.1-1
```

  - The following command assigns or unassigns a global or dedicated Hot spare:

```
racadm storage hotspare:Disk.Bay.0:Enclosure.Internal.0-0:RAID.Integrated.1-1
-assign no
```

```
racadm storage hotspare:Disk.Bay.0:Enclosure.Internal.0-0:RAID.Integrated.1-1
-assign yes -type ghs
```

```
racadm storage hotspare:Disk.Bay.0:Enclosure.Internal.0-0:RAID.Integrated.1-1
-assign yes -type dhs -vdkey:Disk.Virtual.0:RAID.Integrated.1-1
```

- To reset, clear, and import the storage configuration to the controller.
  - The following command imports the current foreign configuration from the controller:

```
racadm storage importconfig:RAID.Integrated.1-1
```

  - The following command deletes all virtual disks and un-assign hot spare from the associated controller:

```
racadm storage resetconfig:RAID.Integrated.1-1
```

  - The following command clears the current foreign configuration from the controller:

```
racadm storage clearconfig:RAID.Integrated.1-1
```

NOTE: After a `resetconfig` or `clearconfig` operation, the data cannot be reversed.

- To blink or unblink the PCIeSSD device.
  - The following command blinks the specified PCIeSSD device:

```
racadm storage blink:Disk.Bay.8:Enclosure.Internal.0-1:PCIeExtender.Slot.3
STOR095 : Storage operation is successfully completed.
```

  - The following command unblinks the specified PCIeSSD device:

```
racadm storage unblink:Disk.Bay.8:Enclosure.Internal.0-1:PCIeExtender.Slot.3
STOR095 : Storage operation is successfully completed.
```

- To prepare the specified PCIeSSD device for removal, run the following command:

```
racadm storage preparetoremove: Disk.Bay.8:Enclosure.Internal.0-1:PCIeExtender.Slot.3
STOR089 : Successfully accepted the storage configuration operation.
To apply the configuration operation, create a configuration job with --realtime
option.
To create the required commit jobs, run the jobqueue command.
For more information about the jobqueue command, enter the RACADM command "racadm
help jobqueue”
```

- To perform a secure erase operation on the specified PCIeSSD device, run the following command:

```
racadm storage secureerase: Disk.Bay.8:Enclosure.Internal.0-1:PCIeExtender.Slot.3
RAC1040 : Successfully accepted the storage configuration operation.
To apply the configuration operation, create a configuration job, and then restart
the server.
To create the required commit and reboot jobs, run the jobqueue command.
For more information about the jobqueue command, enter the RACADM command "racadm
help jobqueue”
```

- To cancel background initialization of a virtual disk

```
racadm raid cancelbgi:Disk.Virtual.0:RAID.Integrated.1-1
```

- To replace physical disk in a virtual disk configuration

```
  racadm raid
replacephysicaldisk:Disk.Bay.0:Enclosure.Internal.0-0:RAID.Integrated.1-1 -dstpd
Disk.Bay.1:Enclosure.Internal.0-0:RAID.Integrated.1-1
```

- To set virtual disk as a boot drive

```
racadm raid setbootvd:RAID.Integrated.1-1 -vd Disk.Virtual.0:RAID.Integrated.1-1
```

- To set virtual disk as a boot drive

```
racadm raid setbootvd:RAID.Integrated.1-1 -vd Disk.Virtual.0:RAID.Integrated.1-1
```

- To force physical disk online or retrive data on physical/virtual disk

```
racadm raid forceonline:Disk.Bay.0:Enclosure.Internal.0-0:RAID.Integrated.1-1
```

- To force physical disk offline or remove disk from virtual disk configuration

```
racadm raid forceoffline:Disk.Bay.0:Enclosure.Internal.0-0:RAID.Integrated.1-1
```

- To unlock storage

```
racadm storage unlock:RAID.Integrated.1-1 -key 1234 -passwd Dell@333
```

swinventory

Table 95. Details of swinventory

Description	Displays the list of software objects and associated properties installed on a server. **NOTE:** Lifecycle Controller and CSIOR may not be enabled to run this subcommand.
Synopsis	`racadm swinventory`
Input	`racadm swinventory`

Table 95. Details of swinventory (continued)

Output	`racadm swinventory`
	
	`----------SOFTWARE INVENTORY----------`
	`ComponentType = FIRMWARE`
	`ElementName = Power Supply.Slot.2`
	`FQDD = PSU.Slot.2`
	`InstallationDate = 2013-06-11T13:02:46Z`
	`Current Version = 07.2B.7D`
	`----------`
	`ComponentType = FIRMWARE`
	`ElementName = Integrated Remote Access Controller`
	`FQDD = iDRAC.Embedded.1-1`
	`InstallationDate = NA`
	`Rollback Version = 1.50.50`
	`----------`
	`ComponentType = FIRMWARE`
	`ElementName = Integrated Remote Access Controller`
	`FQDD = iDRAC.Embedded.1-1`
	`InstallationDate = 2013-06-11T13:02:48Z`
	`Current Version = 1.50.50`

NOTE: Configuration changes and firmware updates that are made within the operating system may not reflect properly in the inventory until you perform a server restart.

systemconfig

Table 96. Details of systemconfig

Description	Enables you to perform the following: • Backup and restore for iDRAC and entire system configuration. • Automatic scheduling of backup operation. • View the auto backup feature settings. • Clear the auto backup feature settings. **NOTE:** • To run this subcommand, you require the Server Profile Export and Import license. • Backup operation is licensed (Enterprise) but restore operation is not licensed. • If Lifecycle Controller is disabled, starting a restore operation is unsuccessful. • If CSIOR is disabled, the system inventory can have old data during the backup operation. An appropriate warning message is displayed. • The `autobackupscheduler` can be enabled or disabled. For more information about enable or disable, see LifecycleController.LCAttributes.autobackup • The minimum Lifecycle Controller version 1.3 is required. • The minimum Lifecycle Controller version 2 1.3 is required.
Synopsis	• `racadm systemconfig backup -f <filename> <target> [-n passphrase] [-l <location> -u <user name> -p <password>] [--vFlash]` • `racadm systemconfig restore -f <filename> <target> [-n passphrase ] [--nopreserve] [-l <location> -u <user name> -p <password>] [--vFlash]` • To create an AutoBackup Schedule. `racadm systemconfig backup [-f <filename>] <target> [-n <passphrase>][-l <location> -u <user name> -p <password>] [--vFlash] -time <time> [-dom <DayOfMonth>] [-wom <WeekOfMonth>] [-dow <DayofWeek>] -rp <repeat> -mb <MaxBackup>`

Table 96. Details of systemconfig (continued)

	• To view an AutoBackup Schedule.
	`racadm systemconfig getbackupscheduler`
	• To delete an AutoBackup Schedule.
	`racadm systemconfig clearbackupscheduler`
	NOTE: After the parameters are cleared, the AutoBackupScheduler is disabled. To schedule the backup again, enable the AutoBackupScheduler.

Input	• `-n` — Specifies a pass phrase used to encrypt or decrypt the configuration data. The pass phrase must have 8 to 32 characters, and one upper and lower case character. **NOTE:** This pass phrase is optional. • `-l` — Specifies the network share location, can be either CIFS or NFS. • `-f` — Specifies the image location and the file name. **NOTE:** If the file is in a subfolder within the share location, then specify the network share location in the `-l` option and specify the subfolder location and the filename in the `-f` option. • `-u` — Specifies the user name for the remote share access. • `-p` — Specifies the password for the remote share access. • `--vFlash` — Selects vFlash SD as target location for back up. • `--nopreserve` — Deletes all the virtual disks and configurations. • `-time`: Specifies the time to schedule an autobackup in HH:MM format. This parameter must be specified. • `-dom`: Specifies the day of month to schedule an autobackup. Valid values are 1–28, L(Last day) or `'*'` (default — any day). • `-wom`: Specifies the week of month to schedule an autobackup. Valid values are 1–4, L(Last week) or `'*'` (default — any week). • `-dow`: Specifies the day of week to schedule an autobackup. Valid values are sun, mon, tue, wed, thu, fri, sat, or `'*'` (default — any day). **NOTE:** The `-dom`, `-wom`, or `-dow` option must be included in the command for the autoupdate schedule. The `*` value for the options must be included within `' '` (single quotation mark). • If the `-dom` option is specified, then the `-wom` and `-dom` options are not required. • If the`-wom` option is specified, then the`-dow` is required and `-dom` is not required. • If the`-dom` option is non-`'*'`, then the schedule repeats by month. • If the`-wom` option is non-`'*'`, then the schedule repeats by month. • If the`-dom` and `-wom` options are `'*'` and the `-dow` option is non-`'*'`, then the schedule repeats by week. • If all the three `-dom`, `-wom` and `-dow` options are `'*'`, then the schedule repeats by day. • `-rp`: Specifies the repeat parameter. This parameter must be specified. ○ If the`-dom` option is specified, then the valid values for `-rp` are 1–12. ○ If the`-wom` option is specified, then the valid values for `-rp` are 1–52 ○ If the`-dow` option is specified, then the valid values for `-rp` are 1–366. • `-mb`: Specifies the maximum backup parameter. For `--vflash` maximum backup is 1. **NOTE:** • Avoid using the `-l`, `-u`, and `-p` options with `--vFlash` option. • If a backup file is created in a subfolder within the CIFS shared folder, then the subfolder name must be mentioned in the filename option.
Output	Job ID is displayed when the back up or restore operation is successful.
Example	• Back up system to CIFS share and encrypt the data. `racadm systemconfig backup -f image.img -l //192.168.0/share -u admin -p xxx -n Encryptp@sswd123`

Table 96. Details of systemconfig (continued)

	• Back up system to NFS share and encrypt the data.
	`racadm systemconfig backup -f image.img -l 192.168.0 :/share -u admin -p xxx -n Encryptp@sswd123`
	• Back up system to vFlash SD.
	`racadm systemconfig backup --vFlash`
	• Restore system from vFlash SD and clear the VD configurations.
	`racadm systemconfig restore -vFlash --nopreserve`
	• Restore system from NFS share without clearing the VD configurations.
	`racadm systemconfig restore -f image.img -l 192.168.0:/share -u admin -p xxx`
	• Create a backup file in a subfolder within the CIFS shared folder.
	`racadm systemconfig backup -f rts/Backup.img -l //192.168.0/CIFSshare -u username -p xxx`
	• To enable or disable AutoBackupScheduler.
	`racadm set lifecyclecontroller.lcattributes.autobackup 1`
	`racadm set lifecyclecontroller.lcattributes.autobackup 0`
	• AutoBackup system to CIFS share and encrypt the data.
	`racadm systemconfig backup -f image.img -l //192.168.0/share -u admin -p xxx -n encryptpasswd123 -time 14:30 -dom 1 -rp 6 -mb 10`
	• AutoBackup system to NFS share and encrypt the data.
	`racadm systemconfig backup -f image.img -l 192.168.0:/share -u admin -p xxx -n encryptpasswd123 -time 14:30 -dom 1 -rp 6 -mb 20`
	• AutoBackup system to vFlash SD.
	`racadm systemconfig backup --vFlash -time 10:30 -wom 1 -dow mon -rp 6 -mb 1`

systemerase

Table 97. Details of systemerase

Description	Allows you to erase the components to remove the server from use.

Synopsis	• To erase a specific component.
	`racadm systemerase <component>`
	• To erase multiple components.
	`racadm systemerase <component>,<component>,<component>`

Input	• `<component>` — the valid types of components are: ○ `bios` ○ `diag`

Table 97. Details of systemerase (continued)

	○ drvpack ○ idrac ○ lcdata
Examples	• `racadm systemerase bios` • `racadm systemerase diag` • `racadm systemerase drvpack` • `racadm systemerase idrac` • `racadm systemerase lcdata` • `racadm systemerase bios,diag,drvpack` • `racadm systemerase bios,idrac,lcdata`

systemperfstatistics

Table 98. Details of systemperfstatistics

Description	Allows you to view and manage the system performance monitoring operations.

Synopsis	• To view the FQDD's of system performance monitoring sensors
	`racadm systemperfstatistics view`
	• To list the usage statistics of a specific sensor
	`racadm systemperfstatistics <sensor_FQDD>`
	• To reset the utilization peaks of system performance monitoring sensors
	`racadm systemperfstatistics PeakReset <FQDD>`
	• To run the peakreset operation you must have configure iDRAC privilege.

Examples:

- To view the FQDD's of system performance monitoring sensors

```
racadm systemperfstatistics view
[key = iDRAC.Embedded.1#SystemBoardCPUUsageStat]
[key = iDRAC.Embedded.1#SystemBoardIOUsageStat]
[key = iDRAC.Embedded.1#SystemBoardMEMUsageStat]
[key = iDRAC.Embedded.1#SystemBoardSYSUsageStat]
```

- To list the usage statistics of a specific sensor

```
racadm systemperfstatistics iDRAC.Embedded.1#SystemBoardCPUUsageStat

Minimum Readings
Last Hour     = 0% [At Mon, 05 May 2014 17:13:04]
Last Day      = 0% [At Mon, 05 May 2014 15:59:53]
Last Week     = 0% [At Mon, 05 May 2014 15:59:53]

Maximum Readings
Last Hour     = 0% [At Thu, 01 Jan 1970 00:00:00]
Last Day      = 0% [At Thu, 01 Jan 1970 00:00:00]
Last Week     = 0% [At Thu, 01 Jan 1970 00:00:00]
```

```
Average Readings
Last Hour     = 0%
Last Day      = 0%
Last Week     = 0%

Peak Readings
Last Week     0% [At Mon, 05 May 2014 15:58:35]
```

- To reset the peak utilization of a specific sensor

```
racadm systemperfstatistics PeakReset iDRAC.Embedded.1#SystemBoardCPUUsageStat
RAC1163: The peak utilization value of Out-Of-Band performance monitoring sensor CPU
Usage is successfully reset.
```

techsupreport

Table 99. Details of techsupreport

Description	Allows you to perform the technical support report operations. The type of operations are: • `collect` — Collects the technical support report data to export. You can specify the various types of logs to be included in the report. This operation generates a Job ID. Use this Job ID to check the status of the collect operation. To run this operation, you must have the Server Control Commands permission. • `export` — Exports the collected Tech Support Report data. To run this subcommand, you must have the Execute Server Control Commands permission. • `getupdatetime` — Gets the timestamp of the last operating system application data collection. • `updateosapp` — Updates the operating system application data collection. To run this subcommand, you must have the Execute Server Control Commands permission.

Synopsis	• To perform the technical support report operation by specifying the type of operation.
	`racadm techsupreport <tech support report command type>`
	• To collect the report data.
	`racadm techsupreport collect [-t <type of logs>]`
	• To export the collected report data.
	`racadm techsupreport export -l <CIFS or NFS share> -u <username> -p <password>`
	• To get the timestamp of the last operating system application data collection.
	`racadm techsupreport getupdatetime`
	• To update the operating system application data collection.
	`racadm techsupreport updateosapp -t <type of OS App logs>`
	• To export the collected report data to local share.
	`racadm techsupreport export -f <filename>`

Input	• `-t` — type of logs. You can specify any of the following values separated by a ',' (comma) ○ `SysInfo` — System Information ○ `OSAppNoPII` — Filtered OS and Application data ○ `OSAppAll` — OS and Application data

Table 99. Details of techsupreport (continued)

	○ `TTYLog` — TTYLog data **NOTE:** ○ For updating the operating system application data collection, enter the value `OSAppNoPII` or `OSAppAll` to the `-t` option. ○ If no value is specified then system information data is collected. ○ To perform the Oslog collection, make sure that ISM is installed and running. ○ TTYLog includes PCIeSSD data. ● `-l` — network share location to export the report ● `-u` — user name for the remote share to export the report ● `-p` — password for the remote share to export the report ● `-f`— target filename for the exported log. **NOTE:** The file name must have .zip as the extension.

Examples	● To collect the system information data.
	`racadm techsupreport collect –t <type of logs>`
	● To collect the system information and TTYLog data.
	`racadm techsupreport collect -t SysInfo,TTYLog`
	● To collect the operating system application data.
	`racadm techsupreport collect -t OSAppAll`
	● To export the collected Tech Support Report, to a CIFS share.
	`racadm techsupreport export -l //192.168.0/share -u myuser -p xxx`
	● To export the collected Tech Support Report, to an NFS share.
	`racadm techsupreport export -l 192.168.0:/share`
	● To export the collected Tech Support Report to the local file system.
	`racadm techsupreport export -f tsr_report.zip`

testemail

Table 100. Details of testemail attribute

Description	Sends a test email from iDRACCMC to a specified destination. Prior to running the test email command, make sure that the SMTP server is configured. The specified index in the **idrac.EmailAlert** group must be enabled and configured properly. For more information, see the see the *Integrated Dell Remote Access Controller (iDRAC8) and iDRAC7 RACADM Command Line Interface Reference Guide* available at www.dell.com/support/manuals.
Synopsis	`racadm testemail -i <index>`
Input	`-i <index>` — Specifies the index of the email alert to test.

Table 100. Details of testemail attribute (continued)

Output	`Success: Test e-mail sent successfully` `Failure: Unable to send test e-mail`

Example	Commands for the **idrac.EmailAlert** group:
	• Enable the alert.
	`racadm set idrac.EmailAlert.1.Enable 1`
	• Set the destination email address.
	`racadm set idrac.EmailAlert.1.Address user1@mycompany.com`
	• Set the custom message that is sent to the destination email address.
	`racadm set idrac.emailalert.1.CustomMsg "This is a test!"`
	• Make sure that the SMTP IP address is configured properly.
	`racadm set idrac.remotehosts.SMTPServerIPAddress 192.168.0`
	• View the current email alert settings.
	`racadm get idrac.EmailAlert.<index>`
	where `<index>` is a number from 1 to 8.

testtrap

Table 101. Details of testtrap attribute

Description	Tests the RAC's SNMP trap alerting feature by sending a test trap from iDRACCMC to a specified destination trap listener on the network. To run this subcommand, you must have the **Test Alert** permission. **NOTE:** • Before you run the `testtrap` subcommand, make sure that the specified index in the `RACADM iDRAC.SNMP.Alert` group is configured properly. • The indices of `testtrap` subcommand is co-related to the indices of **iDRAC.SNMP.Alert** group. **NOTE:** Before you run the `testtrap` subcommand, make sure that the specified index in the **cfgAlerting** group is configured properly.
Synopsis	`racadm testtrap -i <index>`
Input	`-i <index>` — Specifies the index of the trap configuration that must be used for the test. Valid values are from 1 to 4.

Example	• Enable the alert.
	`racadm set idrac.emailalert.1.CustomMsg 1`
	`racadm set iDRAC.SNMP.Alert.1.Enable 1`
	• Set the destination email IP address.
	`racadm set iDRAC.SNMP.Alert.1.DestIpAddr 192.168.0`

Table 101. Details of testtrap attribute (continued)

	• View the current test trap settings.
	`racadm get iDRAC.SNMP.Alert.<index>`
	where `<index>` is a number from 1 to 8
	• Send a test trap to the destination configured for index 1:
	`racadm testtrap -i 1`

testalert

Table 102. Details of testalert

Description	Tests FQDN supported SNMP trap notifications. To run this subcommand, you must have the Test Alert User Access.
Synopsis	`racadm testalert -i <index>`
Input	`-i` — Specifies the index of the trap test. *index* must be an integer from 1 to 8 on iDRAC.
Output	`Success: Test trap sent successfully` `Failure: Unable to send test trap`

Example	• Test a trap with index as 1.
	`racadm testalert -i 1`
	`Test trap sent successfully.`
	• Test a trap that has not been configured yet.
	`racadm testalert -i 2`
	`ERROR: Trap at specified index is not currently enabled.`

traceroute

Table 103. Details of traceroute attribute

Description	Traces network path of the routers as the packets traverse from the system to a destination IPv4 address. To run this subcommand, you must have the Administrator privilege. To run this subcommand, you must have the Execute Diagnostic Commands permission.
Synopsis	`racadm traceroute <IPv4 address>`
Input	`IPv4` — Specifies IPv4 address.

Table 103. Details of traceroute attribute (continued)

Output	`traceroute to 192.168.0.1 (192.168.0.1), 30 hops max, 40 byte packets` `1 192.168.0.1 (192.168.0.1) 0.801 ms 0.246 ms 0.253 ms`

traceroute6

Table 104. Details of traceroute6 attribute

Description	Traces the network path of routers as the packets traverse from the system to a destination IPv6 address. To run this subcommand, you must have the Administrator privilege. To run this subcommand, you must have the Execute Diagnostic Commands permission.
Synopsis	`racadm traceroute6 <IPv6address>`
Input	<IPv6address> – Specifies IPv6 address.

Output	`traceroute to fd01::1 (fd01::1) from fd01::3,`
	`30 hops max, 16 byte packets`
	`1 fd01::1 (fd01::1) 14.324 ms 0.26 ms 0.244 ms`

update

Table 105. Details of update

Description	Allows you to update the firmware of devices on the server. The supported firmware image file types are: • `.exe` — Windows-based Dell Update Package (DUP) • `.d7` • `.pm` The supported catalog files are: • `.xml` • `xml.gzip` **NOTE:** Updating the platforms from the repository is not supported for IPv6. **NOTE:** Depending on the network traffic, the HTTP packet transfer may fail if you perform update operation from a remote RACADM through a local share. In such cases, retry the operation. If the issue persists, use remote RACADM with the CIFS or NFS share. **NOTE:** This command supports both IPV4 and IPV6 formats. IPV6 is applicable only for CIFS, HTTP and HTTPS remote shares.

Table 105. Details of update (continued)

Synopsis	`racadm update -f <updatefile> [--reboot]`
	
	`racadm update -f <updatefile> -l <Remote CIFS Share> -u <username for CIFS share> -p <password for CIFS share> [--reboot]`
	
	`racadm update -f <updatefile> -l <Remote NFS Share> [--reboot]`
	
	`racadm update -f <catalog file> -t <Repository type> -l <Remote CIFS/NFS Share> -u <username for CIFS share> -p <password for CIFS share> [-a <FALSE|TRUE>] [--verifycatalog]`
	
	`racadm update -f <catalog file> -t <Repository type> -l <Remote CIFS/NFS Share> -u <username for CIFS share> -p <password for CIFS share>`
	
	`racadm update -f <catalog file> -t <Repository type> -e <FTP server with the path to the catalog file> [-a <FALSE|TRUE>] [--verifycatalog]`
	
	`racadm update viewreport`

Input	• `-f`—Update filename for Windows DUP, `.d7`, `.pm`, `.pm` only. For update from repository `.xml` files are allowed. If a file name is not specified for repository update, then the `Catalog.xml` is taken as default. • `-u`—Specifies username of the remote share that stores the update file. Specify username in a domain as domain/username. • `-p`—Specifies password of the remote share that stores the update file. • `-l`—Specifies network share location (CIFS/NFS/HTTP/HTTPS) that stores the update file. For more information about these shares, see the Usage examples section. • `-a`—This option indicates whether the server must be restarted after the update from repository operation completes. It takes TRUE and FALSE as options. These options are case-insensitive. • `-t`—Type of repository being used for update. The valid options are `FTP`, `CIFS`, `NFS`, `TFTP`, `HTTP`, and `HTTPS`. These options are case-insensitive. If the repository update functionality is invoked, then this option must be run. • `-e`—Specifies the server path for the FTP, TFTP, HTTP, and HTTPS. • `--verifycatalog`—Tests the list of DUPs that are applied and generates a report. • `–reboot`—Performs a graceful system reboot after the firmware update. • `-ph`—Specifies the IP address of the proxy server. • `-pp`—Specifies the password for proxy credentials. • `-pu`—Specifies the username for proxy credentials. • `-po`—Specifies the port for proxy server. • `-pt`—Specifies the proxy type. Valid values are `HTTP` and `SOCKS4`. These values are case-insensitive. **NOTE:** ○ If the repository must be through a proxy, then the proxy server address, proxy username and the proxy password must be specified. ○ The Lifecycle Controller must be enabled for repository update.
Output	Firmware update job for `<filename>` is initiated. This firmware update job may take several minutes to complete depending on the component or firmware being updated. To view the progress of the job, run the `racadm jobqueue view` command. For repository update command, the output is: `Update from repository operation has been initiated. Check the progress of the operation using "racadm jobqueue view -i JID_809364633532" command.`

Table 105. Details of update (continued)

	For devices that perform update process without rebooting the host, the update status changes from `Downloading` to `Completed`. For devices that require host reboot to perform update process, the update status changes from `Downloading` to `Scheduled`. When the status is displayed as `Scheduled`, reboot the host to start the update process. The following devices require host reboot to perform the update process: ● Backplanes ● BIOS ● Complex programmable logic device (CPLD) ● Hard disk drives ○ Solid state drives (SSD) ● Network interface cards (NIC) or Fibre Channel (FC) cards ● PCIe SSD devices ● Power supply unit (PSU) ● Storage controllers

Example	● Upload the update file from a remote CIFS share.
	`racadm update -f <updatefile> -u admin -p mypass -l //1.2.3.4/share`
	● Upload the update file from a remote CIFS share and under a user domain "dom"
	`racadm update -f <updatefile> -u dom/admin -p mypass -l //1.2.3.4/share`
	● Upload the update file from a remote NFS share:
	`racadm update -f <updatefile> -l 1.2.3.4:/share`
	● Configure a RAC from an XML configuration file located on a remote HTTP share:
	`racadm set -f myfile.xml -t xml -u httpuser -p httppwd -l http://test.com/myshare`
	● Configure a RAC from an XML configuration file located on a remote HTTPS share.
	`racadm set -f myfile.xml -t xml -u httpsuser -p httpspwd -l https://test.com/myshare`
	● Upload the update file from the local file system using local racadm
	`racadm update -f <updatefile>`
	● Upload the update file from the local file system using local racadm and to perform a graceful system reboot after update
	`racadm update -f <updatefile> --reboot`
	● Upload the update file from a remote CIFS share and to perform a graceful system reboot after update
	`racadm update -f <updatefile> -u admin -p mypass -l //1.2.3.4/share --reboot`
	● Upload the update file from a remote NFS share and to perform a graceful system reboot after update:
	`racadm update -f <updatefile> -l 1.2.3.4:/share --reboot`
	● Upload the update file from the local file system using local racadm and perform a graceful system reboot after the firmware update:
	`racadm update -f <updatefile> --reboot`

Table 105. Details of update (continued)

	• Perform update from a CIFS repository and reboot the server to apply the updates.
	`racadm update -f Catalog.xml -l //192.168.11.10/Repo -u admin -p mypass -a TRUE -t CIFS`
	• Generate a comparison report using about the available updates in the repository.
	`racadm update -f Catalog.xml -l 192.168.11.10:/Repo -t NFS -a FALSE --verifycatalog`
	• Perform update from an FTP repository and reboot the server to apply the updates.
	`racadm update -f Catalog.xml -e 192.168.11.10/Repo/MyCatalog -a TRUE -t FTP`
	• Perform update from an FTP repository with authentication and reboot the server to apply the updates.
	`racadm update -f Catalog.xml -e 192.168.11.10/Repo/MyCatalog -u user -p mypass -a TRUE -t FTP`
	• Perform update from an HTTP repository and reboot the server to apply the updates.
	`racadm update -f Catalog.xml -e 192.168.11.10/Repo/MyCatalog -a TRUE -t HTTP`
	• Perform update from a TFTP repository and reboot the server to apply the updates.
	`racadm update -f Catalog.xml -e 192.168.11.10/Repo/MyCatalog -a TRUE -t TFTP`
	• Perform update from an FTP repository through a proxy server.
	`racadm update -f Catalog.xml -e 192.168.11.10/Repo/MyCatalog -a TRUE -ph 145.140.12.56 -pu prxyuser -pp prxypass -po 80 -pt http -t FTP`
	• Perform update from ftp.dell.com
	`racadm update -f Catalog.xml.gz -e ftp.dell.com/Catalog -a TRUE -t FTP`
	• View the comparison report generated when --verifycatalog is used.
	`racadm update viewreport`
	• View the comparison report generated.
	`racadm update viewreport`
	`ComponentType = Firmware`
	`ElementName = PERC H730P Mini`
	`FQDD = RAID.Integrated.1-1`
	`Current Version = 25.2.1.0025`
	`Available Version = 25.2.1.0029`

usercertupload

Table 106. Details of usercertupload

Description	Uploads a user certificate or a user CA certificate from the client to iDRAC. To run this subcommand, you must have the Configure iDRAC permission. **NOTE:** This option is only supported on the remote interface (s).
Synopsis	`racadm usercertupload -t <type> [-f <filename>] -i <index>`

Table 106. Details of usercertupload (continued)

Input	• `-t` — Specifies the type of certificate to upload, either the CA certificate or server certificate.
	  ○ `1`=user certificate
	  ○ `2`=user CA certificate
	• `-f` — Specifies the filename of the certificate that must be uploaded. If the file is not specified, the `sslcert` file in the current directory is selected.
	• `-i` — Index number of the user. Valid values 2–16.

Output	If upload is successful, the message `User certificate successfully uploaded to the RAC`. If unsuccessful, appropriate error message is displayed.
Example	To upload user certificate for user 6. `racadm usercertupload -t 1 -f c:\cert\cert.txt -i 6`

usercertview

Table 107. Details of usercertview

Description	Displays the user certificate or user CA certificate that exists on iDRAC.
Synopsis	`racadm usercertview -t <type> [-A] -i <index>`

Input	• `-t` — Specifies the type of certificate to view, either the user certificate or the user CA certificate.
	  ○ 1=user certificate
	  ○ 2=user CA certificate
	• `-A` — Prevents printing headers or labels.
	• `-i` — Index number of the user. Valid values are 2–16.

Example	To view user certificate for user 6.
	`racadm usercertview -t 1 -i 6`
	`Serial Number : 01`
	`Subject Information:`
	`Country Code (CC) : US`
	`State (S) : Texas`
	`Locality (L) : Round Rock`
	`Organization (O) : Dell Inc.`
	`Common Name (CN) : iDRAC default certificate`
	`Issuer Information:`
	`Country Code (CC) : US`
	`State (S) : Texas`
	`Locality (L) : Round Rock`
	`Organization (O) : Dell Inc.`
	`Organizational Unit (OU): Remote Access Group`
	`Common Name (CN) : iDRAC default certificate`
	`Valid From : Jun 7 23:54:19 2011 GMT`
	`Valid To : Jun 4 23:54:19 2021 GMT`

vflashsd

Table 108. Details of vflashsd

Description	Allows you to initialize or get the status of the vFlash SD card. The initialize operation removes all the existing partitions and resets the card. The status operation displays the status of the last operation performed on the card. To run this subcommand, you must have the Access Virtual Media privilege. **NOTE:** After you restart the iDRAC, the status of the previous initialize operation is erased.
Synopsis	• `racadm vflashsd initialize` • `racadm vflashsd status`
Input	• `Initialize`— performs initialize operation on SD card. • `Status` — indicates to view the progress or status report of the initialize operation.
Output	If initialization is in progress, the message `Initialization of the vFlash SD Card is now in progress` is displayed. If unsuccessful, appropriate error message is displayed. If the status of the last operation performed is successful, the message `LastAction Progress Status==========Initialize SD Card 100 % Complete` is displayed. If unsuccessful, appropriate error message is displayed.

vflashpartition

Table 109. Details of vflashpartition

Description	Manages the partitions on the vFlash SD card. **NOTE:** • To run this subcommand, you must have the iDRAC Enterprise license. • After iDRAC restart, the status of the previous operation performed on the partition(s) is erased.
Synopsis	`racadm vflashpartition <create | delete | status | list> -i<index> -o<label> -e<emulation type> -s<size> -f<format type> -t<partition type> -l<path> -u<user> -p<password> -a`

Input	• `-o` — Label that is displayed when the partition is mounted on the operating system. This option must be a string of upto six alphanumeric characters. VFLASH is the only accepted volume label for non-Dell SD card.
	• `-e` — Emulation type must be either floppy, cddvd, or hdd.
	  ○ `floppy` — emulates a floppy disk
	  ○ `cddvd` — emulates a CD or DVD
	  ○ `hdd` — emulates a hard disk
	• `-s` — Partition size in MB.
	• `-f` — Format type for the partition based on the type of the file system. Valid options are `raw`, `ext2`, `ext3`, `fat16`, and `fat32`.
	• `-t` — Create a partition of the following type:
	  ○ `empty` — Creates an empty partition
	  ○ `image` — Creates a partition using an image relative to iDRAC.
	  NOTE: Creating an empty partition with emulation type as floppy with ext2 format type by using the Telnet session might result in a state where the partition creation status is shown as zero. If this happens then it is recommended to remove the SD card and format it in order to reuse.
	  Creation of a partition may be unsuccessful if:
	  ○ The network share is not reachable.

Table 109. Details of vflashpartition (continued)

	○ The user name or password provided is not correct. ○ The file provided does not exist. ○ The memory available on the SD card is lesser than size of the image file. ● `-l` — Specifies the remote path relative to iDRAC. ● `-u` — User name for accessing the remote image. ● `-p` — Password for accessing the remote image. ● `-a` — Display the status of operations on all the existing partitions. ● `list` — Lists the existing partitions and its properties.

Example	● Create a 20MB empty partition.
	`racadm vflashpartition create -i 1 -o Drive1 -e hdd -t empty -f fat16 -s 20`
	● Create a partition from a remote image.
	`racadm vflashpartition create -i 1 -o Drive1 -e cddvd -t image -l //ipaddress/sharefolder/isoimge.iso -u username -p xxx`
	A new partition is created. By default, the created partition is read-only. This command is case-sensitive for the image filename extension. If the filename extension is in uppercase, for example FOO.ISO instead of FOO.iso, then the command returns a syntax error.
	NOTE:
	○ This feature is not supported in Local RACADM.
	○ Creating vFlash partition from an image file on the CFS or NFS IPv6 enabled network share is not supported.
	● Delete a partition.
	`racadm vflashpartition delete -i 1`
	● Status of operation on partition 1.
	`racadm vflashpartition status -i 1`
	● Status of all the existing partitions.
	`racadm vflashpartition status -a`
	● List all the existing partitions and its properties.
	`racadm vflashpartition list`

vmdisconnect

Table 110. Details of vmdisconnect

Description	Allows you to end another Virtual Media session. After the session ends, the web-based interface reflects the correct connection status. Enables an iDRAC user to disconnect all active Virtual Media sessions. The active Virtual Media sessions are displayed on iDRAC web-based interface or by running the RACADM subcommands `remoteimage` or `getssninfo`. To run this subcommand, you must have the Access Virtual Media permission.
Synopsis	`racadm vmdisconnect`

3

iDRAC Property Database Group and Object Descriptions

The iDRAC property database contains the configuration information for iDRAC. Associated object is organizing data, and object group is organizing object. The IDs for the groups and objects that the property database supports are listed in this section for iDRAC Enterprise on Blade Servers and iDRAC Enterprise or Express on Rack and Tower Servers.

To configure iDRAC, use the group and object IDs with the RACADM subcommands.

NOTE: You can configure a setting that does not have a hash symbol (#) as the prefix in its output name. To modify a configurable object, use the `-o` option.

NOTE: Racadm sets the value of objects without performing any functional validation on them. For example, RACADM allows you to set the Certificate Validation object to 1 with the Active Directory object set to 0, even though Certificate Validation can happen only if Active Directory is enabled. Similarly, the `cfgADSSOEnable` object can be set to 0 or 1 even if the `cfgADEnable` object is 0, but it takes effect only if Active Directory is enabled.

All string values are limited to displayable ASCII characters, except where otherwise noted.

Topics:

- Displayable Characters
- idRacInfo
- cfgStaticLanNetworking
- cfgRemoteHosts
- cfgUserAdmin
- cfgEmailAlert
- cfgSessionManagement
- cfgSerial
- cfgOobSnmp
- cfgRacTuning
- ifcRacManagedNodeOs
- cfgRacVirtual
- cfgServerInfo
- cfgActiveDirectory
- cfgLDAP
- cfgLdapRoleGroup
- cfgStandardSchema
- cfgThermal
- cfgIpmiSol
- cfgIpmiLan
- cfgIpmiPetIpv6
- cfgIpmiPef
- cfgIpmiPet
- cfgUserDomain
- cfgServerPower
- cfgServerPowerSupply
- cfgIPv6LanNetworking
- cfgIpv6StaticLanNetworking
- cfgIPv6URL
- cfgIpmiSerial
- cfgSmartCard
- cfgNetTuning

- cfgSensorRedundancy
- cfgVFlashSD
- cfgVFlashPartition
- cfgLogging
- cfgRacSecurity

Displayable Characters

Displayable characters include the following set:

```
abcdefghijklmnopqrstuvwxwz
ABCDEFGHIJKLMNOPQRSTUVWXYZ
0123456789~`!@#$%^&*()_+-={}[]|\:";'<>,.?/
```

Table 111. Details

Subcommand	iDRAC on Blade Servers	iDRAC on Rack and Tower Servers
idRacInfo	Yes	Yes
cfgStaticLanNetworking		
cfgRemoteHosts	Yes	Yes
cfgUserAdmin	Yes	Yes
cfgEmailAlert	Yes	Yes
cfgSessionManagement	Yes	Yes
cfgSerial	Yes	Yes
cfgOobSnmp	Yes	Yes
cfgRacTuning	Yes	Yes
ifcRacManagedNodeOs	Yes	Yes
cfgRacVirtual	Yes	Yes
cfgServerInfo	No	Yes
cfgActiveDirectory	Yes	Yes
cfgLDAP	Yes	Yes
cfgLdapRoleGroup	Yes	Yes
cfgStandardSchema	Yes	Yes
cfgThermal		
cfgIpmiSol	Yes	Yes
cfgIpmiLan	Yes	Yes
cfgIpmiPetIpv6	Yes	Yes
cfgIpmiPef	Yes	Yes
cfgIpmiPet	Yes	Yes

Table 111. Details (continued)

Subcommand	iDRAC on Blade Servers	iDRAC on Rack and Tower Servers
cfgUserDomain	Yes	Yes
cfgServerPower	Yes	Yes
cfgServerPowerSupply	No	Yes
cfgIPv6LanNetworking	Yes	Yes
cfgIpv6StaticLanNetworking		
cfgIPv6URL	Yes	Yes
cfgIpmiSerial	No	Yes
cfgSmartCard	Yes	Yes
cfgNetTuning	No	Yes
cfgSensorRedundancy	No	Yes
cfgVFlashSD	Yes	Yes
cfgVFlashPartition	Yes	Yes
cfgLogging	Yes	Yes
cfgRacSecurity	Yes	Yes

idRacInfo

This group contains display parameters to provide information about the specifics of iDRAC being queried. One instance of the group is allowed.

This group contains display parameters to provide information about the specifics of CMC being queried. One instance of the group is allowed. Use this object with the `getconfig` subcommand.

To use this object, you must have the CMC Login User privilege.

The following sections provide information about the objects in the `idRACInfo` group.

idRacProductInfo (Read Only)

Table 112. Details of Read only attribute - idRacProductInfo

Description	A text string that identifies the product.
Legal Values	A string of up to 63 ASCII characters.
Default	`iDRAC` – Integrated Dell Remote Access Controller
Default	Chassis Management Controller

idRacDescriptionInfo (Read Only)

Table 113. Details of Read only attribute - idRacDescriptionInfo

Description	A text description of the RAC type.
Legal Values	A string of up to 255 ASCII characters.
Default	This system component provides a complete set of remote management functions for **Dell PowerEdge** servers.

idRacVersionInfo (Read Only)

Table 114. Details of Read only attribute - idRacVersionInfo

Description	String containing the current product firmware version
Legal Values	A string of up to 63 ASCII characters.
Default	The current version number.

idRacBuildInfo (Read Only)

Table 115. Details of Read only attribute - idRacBuildInfo

Description	String containing the current RAC firmware build version.
Legal Values	A string of up to 16 ASCII characters.
Default	The current iDRAC firmware build version.
Default	The current CMC firmware build version.

idRacName (Read Only)

Table 116. Details of Read only attribute - idRacName

Description	A user-assigned name to identify this controller.
Legal Values	A string of up to 15 ASCII characters.
Default	iDRAC
Default	CMC

iDRAC Type (Read Only)

Table 117. Details of Read only attribute - iDRAC Type

Description	Identifies the remote access controller type.
Legal Values	Product ID
Default	9

Table 117. Details of Read only attribute - iDRAC Type (continued)

	• For 10G iDRAC: 8 • For 11G iDRAC6 on Rack and Tower Servers: 10 • For 11G iDRAC6 Enterprise on Blade Servers: 11 • For 12G iDRAC on Rack and Tower Servers: 16 • For 12G iDRAC Enterprise on Blade Servers: 17

Example

```
racadm getconfig -g idRacInfo
```

```
# idRacType=8
# idRacProductInfo=Chassis Management Controller
# idRacDescriptionInfo=This system component provides a complete
set of remote management functions for blade servers
# idRacVersionInfo=P21
# idRacBuildInfo=200708301525
# idRacName=CMC-1
```

```
racadm getconfig -g idRacInfo
```

```
# idRacType=16
# idRacProductInfo=Integrated Dell Remote Access Controller
# idRacDescriptionInfo=This system component provides a complete set of remote
management functions for Dell PowerEdge Servers
# idRacVersionInfo=1.06.06
# idRacBuildInfo=15
# idRacName=idrac-GSRS3V1
```

cfgStaticLanNetworking

This group contains parameters to configure the device NIC for IPv4.

NOTE: A few objects in this group may require the device NIC to be reset, that may cause a brief loss in connectivity.

cfgNicStaticEnable (Read or Write)

Table 118. Details of cfgNicStaticEnable

Description	Enables or disables the NIC.
Legal Values	• 0 — Disabled • 1 — Enabled
Default	1 — Enabled

NOTE: If this object is modified, then the object `cfgNicEnable` is also modified.

cfgNicStaticIPv4Enable (Read or Write)

Table 119. Details of cfgNicStaticIPv4Enable

Description	Enables or disables the IPv4 stack.

Table 119. Details of cfgNicStaticIPv4Enable (continued)

Legal Values	• 0 — Disabled • 1 — Enabled
Default	1 — Enabled

NOTE: If this object is modified, then the object `cfgNicIPv4Enable` is also modified.

cfgNicStaticIpAddress (Read or Write)

Table 120. Details of cfgNicStaticIpAddress

Description	Returns or sets the current IPv4 address. **NOTE:** Only set the current IPv4 address if `cfgNicUseDhcp` is set to 0(false).
Legal Values	Any Valid IPv4 address
Default	192.168.0

cfgNicStaticUseDhcp (Read or Write)

Table 121. Details of cfgNicStaticUseDhcp

Description	Specifies whether DHCP is used to configure the IPv4 network.
Legal Values	• 0 — IP Address, subnet mask and gateway are configured on the device. • 1 — IP Address, subnet mask and gateway are assigned from the DHCP server.
Default	0 — Do not use DHCP

NOTE: If this object is modified, then the object `cfgNicUseDhcp` is also modified.

cfgNicStaticNetmask (Read or Write)

Table 122. Details of cfgNicStaticNetmask

Description	Returns or sets the static IPv4 Netmask. **NOTE:** Only set the current IPv4 netmask, if `cfgNicUseDhcp` is set to 0 (false).
Legal Values	Any Valid IPv4 Netmask
Default	255.255.255.0

cfgNicStaticGateway (Read or Write)

Table 123. Details of cfgNicStaticGateway

Description	Returns or sets the static IPv4 address.
Legal Values	Any Valid IPv4 address
Default	192.168.0.120

cfgDNSStaticServersFromDHCP (Read or Write)

Table 124. Details of cfgDNSStaticServersFromDHCP

Description	Specifies the DNS server static IP addresses.
Legal Values	• DNS Addresses are configured on the Device • DNS Addresses are assigned via DHCP
Default	0

cfgDNSStaticServer1 (Read or Write)

Table 125. Details of cfgDNSStaticServer1

Description	Specifies the IP address for DNS server 1. **NOTE:** This property is only valid if `cfgDNSServersFromDHCP` is set to `0` (FALSE).
Legal Values	• `0` — IP Address, subnet mask and gateway are configured on the device. • `1` — IP Address, subnet mask and gateway are assigned from the DHCP server.
Default	`0` — Do not use DHCP

NOTE: If this object is modified, then the object `cfgNicUseDhcp` is also modified.

cfgDNSStaticServer2 (Read or Write)

Table 126. Details of cfgDNSStaticServer2

Description	Specifies the static IP address for DNS server 2.
Legal Values	A Valid IPv4 Address
Default	`0.0.0.0`

cfgDNSStaticDomainName (Read or Write)

Table 127. Details of cfgDNSStaticDomainName

Description	The DNS static domain name.
Legal Values	String of up to 254 ASCII characters. Characters are restricted to alphanumeric, hyphens and periods. At least one of the characters must be alphabetic. **NOTE:** Microsoft Active Directory only supports Fully Qualified Domain Names (FQDN) of 64 characters or fewer lengths.
Default	Null

cfgDNSStaticDomainNameFromDHCP (Read or Write)

Table 128. Details of cfgDNSStaticDomainNameFromDHCP

Description	Specifies the device DNS static domain name.

Table 128. Details of cfgDNSStaticDomainNameFromDHCP (continued)

Legal Values	• 0 — Do not use DHCP to get the Domain Name • 1 — Use DHCP to get the Domain Name
Default	0 — Disabled

cfgRemoteHosts

This group provides properties that allow configuration of the SMTP server for email alerts.

This group enables/disables and configures firmware updates, NTP, remote syslogging and SMTP email alerting.

To apply this setting to iDRAC, use the `-m` option.

Use this object with the `config` or `getconfig` subcommands.

To use this object property, you must have the Chassis Configuration Administrator privilege.

The following sections provide information about the objects in the `cfgRemoteHosts` group.

cfgRhostsFwUpdateTftpEnable (Read or Write)

Table 129. Details of attribute - cfgRhostsFwUpdateTftpEnable

Description	Enables or disables firmware update from a network TFTP server. **NOTE:** This object is read-only for iDRAC Modular servers.
Legal Values	• 1 — (TRUE) • 0 — (FALSE)
Default	1

cfgRhostsFwUpdateIpAddr (Read or Write)

Table 130. Details of attribute - cfgRhostsFwUpdateIpAddr

Description	Specifies the network TFTP server IPv4 or IPv6 address that is used for TFTP firmware update operations.
Legal Values	A string representing a valid IPv4 or IPv6 address. For example, `192.168.0.61`
Default	For IPv4, it is `0.0.0.0`

cfgRhostsFwUpdatePath (Read or Write)

Table 131. Details of attribute - cfgRhostsFwUpdatePath

Description	Specifies TFTP path where firmware image file exists on the TFTP server. The TFTP path is relative to the TFTP root path on the TFTP server. **NOTE:** The server may still require you to specify the drive (for example, `C:`).
Legal Values	A string with a maximum length of 255 ASCII characters.
Default	`<blank>`

cfgRhostsSmtpServerIpAddr (Read or Write)

Table 132. Details of attribute - cfgRhostsSmtpServerIpAddr

Description	The IPv4 or IPv6 address of the network SMTP server. The SMTP server transmits email alerts from iDRAC if the alerts are configured and enabled. The SMTP server transmits email alerts from CMC if the alerts are configured and enabled.
Legal Values	A string representing a valid SMTP server IPv4 or IPv6 address. For example: `192.168.0.2`.
Default	For IPv4, it is 0.0.0.0 `localhost.localdomain`

cfgRhostsSyslogEnable (Read or Write)

Table 133. Details of attribute - cfgRhostsSyslogEnable

Description	To allow the RAC and SEL logs to be written to up to three remote syslog servers Enables or disables remote syslog.
Legal Values	• `1` (TRUE) • `0` (FALSE)
Default	0

cfgRhostsSyslogPort (Read or Write)

Table 134. Details of attribute - cfgRhostsSyslogPort

Description	Remote syslog port number to use for writing the RAC and SEL logs to a remote syslog server. This setting takes effect only if the `cfgRhostsSyslogEnable` parameter is set to `1`(enabled).
Legal Values	10–65535 **NOTE:** The following port numbers are reserved and cannot be used: 21, 68, 69, 123, 161, 546, 801, 4096, 5988, 5989, 6900, 9000, 60106.
Default	514

cfgRhostsSyslogServer1 Read or Write)

Table 135. Details of attribute - cfgRhostsSyslogServer1

Description	To store the RAC and SEL logs specify the first of three possible remote syslog servers. This property is only valid if `cfgRhostsSyslogEnable` is set to `1` (enabled).
Legal Values	String from 0 to 63 characters. Valid host name or IPv4 or IPv6 address.
Default	`<blank>`

cfgRhostsSyslogServer2 Read or Write)

Table 136. Details of attribute - cfgRhostsSyslogServer2

Description	To store the RAC and SEL logs Specify the second of three possible remote syslog servers. This property is only valid if `cfgRhostsSyslogEnable` is set to `1` (enabled).
Legal Values	String from 0 to 63 characters. Valid host name or IPv4 or IPv6 address.
Default	`<blank>`

cfgRhostsSyslogServer3 Read or Write)

Table 137. Details of attribute - cfgRhostsSyslogServer3

Description	To store the RAC and SEL logs specify the third of three possible remote syslog servers. This property is only valid if `cfgRhostsSyslogEnable` is set to `1`(enabled).
Legal Values	String from 0 to 63 characters. Valid host name or IPv4 or IPv6 address.
Default	`<blank>`

cfgUserAdmin

This group provides configuration information about the users allowed to access iDRAC through the available remote interfaces.

This group provides configuration information about the users allowed to access CMC through the available remote interfaces.

Up to 16 instances of the user group are allowed. Each instance represents the configuration for an individual user.

NOTE: In the current CMC firmware version, the objects `cfgUserAdminEnable` and `cfgUserAdminPrivilege` are interrelated; changing the value of one property causes the value of the other property to change. For example, if a user does not have login privilege, the user is disabled by default. When you enable the user by changing the value of the UserAdminEnable to 1, the right-most digit of the UserAdminPrivilege also becomes 1. On the other hand, if you change the right-most digit of the UserAdminPrivilege to 0, the value of the UserAdminEnable becomes 0.

Use this object with the `config` or `getconfig` subcommands. To use the command as follows: `-i <index group>`, supply an index group number

To use this object property, you must have the Chassis Configuration Administrator privilege.

NOTE: You can configure a setting that does not have the hash sign (#) prefixed in the output. To modify a configurable object, use the `–o` option.

The following sections provide information about the objects in the `cfgUserAdmin` group.

cfgUserAdminIndex - Read Only

Table 138. Details of cfgUserAdminIndex attribute

Description	The unique index of a user. The index number is used to specify a unique group name. Only valid for indexed groups.
Legal Values	This parameter is populated based on the existing instances. The parameter specifies decimal integer 1–16.

Table 138. Details of cfgUserAdminIndex attribute (continued)

Default	<index of the instance>

cfgUserAdminIpmiLanPrivilege (Read or Write)

Table 139. Details of cfgUserAdminIpmiLanPrivilege

Description	The maximum privilege on the IPMI LAN channel.
Legal Values	• 2(User) • 3(Operator) • 4(Administrator) • 15(No access)
Default	• 4(User 2) • 15(All others)

cfgUserAdminIpmiSerialPrivilege (Read or Write)

Table 140. Details of cfgUserAdminIpmiSerialPrivilege

Description	The maximum privilege on the IPMI LAN channel. This object is applicable only for iDRAC on Rack and Tower Servers and not for iDRAC Enterprise on Blade Servers.
Legal Values	• 2 (User) • 3 (Operator) • 4 (Administrator) • 15 (No access)
Default	• 4 (User 2) • 15 (All others)

cfgUserAdminPrivilege - Read or Write

Table 141. Details of cfgUserAdminPrivilege attribute

Description	This property specifies the role-based authority privileges allowed for the user. The value is represented as a bit mask that allows for any combination of privilege values. The table below describes the user privilege bit values that can be combined to create bit masks.
Legal Values	0x00000000 to 0x000001ff, and 0x0 0x0000000-0x0000fff, and 0x0
Default	0x00000000

Table 142. Example

iDRAC Specific User Privilege	Privilege Bit Mask
Log in to iDRAC	0x00000001
Configure iDRAC	0x00000002
Configure Users	0x00000004

Table 142. Example (continued)

Clear Logs	0x00000008
Execute Server Control Commands	0x00000010
Access Virtual Console	0x00000020
Access Virtual Media	0x00000040
Test Alerts	0x00000080
Execute Debug Commands	0x00000100
CMC Specific User Privilege	
CMC Login User	0x0000001
Chassis Configuration Administrator	0x0000002
User Configuration Administrator	0x0000004
Clear Logs Administrator	0x0000008
Chassis Control Administrator	0x0000010
Super User	0x0000020
Server Administrator	0x0000040
Test Alert User	0x0000080
Debug Command Administrator	0x0000100
Fabric A Administrator	0x0000200
Fabric B Administrator	0x0000400
Fabric C Administrator	0x0000800

Table 143. Examples

User Privileges	Privilege Bit Mask
The user is not allowed to	0x00000000

Table 143. Examples (continued)

access iDRAC or CMC	
The user may only log in to iDRAC or CMC and view iDRAC or CMC and server configuration information.	0x00000001
The user may log in to iDRAC or CMC and change configuration.	0x00000001 + 0x00000002 = 0x00000003
The user may log in to iDRAC, access Virtual Media, and Virtual Console.	0x00000001 + 0x00000040 + 0x00000080 = 0x000000C1

cfgUserAdminUserName - Read or Write

Table 144. Details of cfgUserAdminUserName attribute

Description	The name of the user for this index. Writing a string of double quotation mark (" ") disables the user. The string cannot contain / (forward slash), \ (backward slash), . (period), @ (at symbol), quotation marks, ; (semicolon), or ‘ (backward quotation mark). **NOTE:** This property value must be unique among user names.
Legal Values	A string of up to 16 ASCII characters.
Default	• `root` (User 2) • `<blank>` (All others)

cfgUserAdminPassword - Write Only

Table 145. Details of cfgUserAdminPassword attribute

Description	The password for this user. User passwords are encrypted and cannot be seen or displayed after the property is written.
Legal Values	A string of up to 20 ASCII characters.
Default	`********`

cfgUserAdminEnable - Read or Write

Table 146. Details of cfgUserAdminEnable attribute

Description	Enables or disables an individual user. **NOTE:** You can enable a user for a given index, only if you set the password for the same user.

Table 146. Details of cfgUserAdminEnable attribute (continued)

Legal Values	• 1 (TRUE) • 0(FALSE)
Default	1 (User 2), 0 (All others) 0

cfgUserAdminSolEnable (Read or Write)

Table 147. Details of cfgUserAdminSolEnable

Description	Enables or disables Serial Over LAN (SOL) user access for the user.
Legal Values	• 1 (TRUE) • 0(FALSE)
Default	0

cfgEmailAlert

This group contains parameters to configure iDRAC email alerting capabilities. Up to four instances of this group are allowed.

This group contains parameters to configure CMC email alerting capabilities. Up to four instances of this group are allowed.

Use this object with the `config` or `getconfig` subcommands.

To use this object property, you must have the Chassis Configuration Administrator privileges.

NOTE: You can configure a setting that does not have the hash sign (#) prefixed in the output. To modify a configurable object, use the `–o` option.

The following sections provide information about the objects in the `cfgEmailAlert` group.

cfgEmailAlertIndex - Read Only

Table 148. Details of cfgEmailAlertIndex attribute

Description	The unique index of an alert instance.
Legal Values	1–4
Default	`<instance>`

cfgEmailAlertEnable - Read or Write

Table 149. Details of cfgEmailAlertEnable attribute

Description	Enables or disables the alert instance.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	0

cfgEmailAlertAddress - Read or Write

Table 150. Details of cfgEmailAlertAddress attribute

Description	Specifies the destination email address for email alerts, for example, `user1@company.com`.
Legal Values	Email address format, with a maximum length of 64 ASCII characters.
Default	`<blank>`

cfgEmailAlertCustomMsg (Read or Write)

Table 151. Details of cfgEmailAlertCustomMsg

Description	Specifies a custom message that forms the subject of the alert.
Legal Values	A string of up to 32 characters
Default	`<blank>`

cfgEmailAlertEmailName - Read Only

Table 152. Details of cfgEmailAlertEmailName attribute

Description	Specifies name or other identifier associated with the destination email address. The email name can refer to an individual, group, location, department, and so on.
Legal Values	A string of up to 32 characters
Default	`<blank>`

Example

```
racadm getconfig -g cfgEmailAlert -i 2
```

```
# cfgEmailAlertIndex=1
cfgEmailAlertEnable=1
cfgEmailAlertAddress=kfulton@dell.com
cfgEmailAlertName=Kevin Fulton
```

cfgSessionManagement

This group contains parameters to configure the number of sessions that can connect to iDRACCMC. One instance of the group is allowed. Displays current settings for and configures the idle timeout properties for web server, Telnet, SSH and RACADM sessions. Changes to idle time out settings take effect at the next login. To disable the idle time out property for a connection, set this property to 0.

To apply this setting to iDRAC, use the `–m` option

The following sections provide information about the objects in the `cfgSessionManagement` group.

cfgSsnMgtRacadmTimeout (Read or Write)

Table 153. Details of cfgSsnMgtRacadmTimeout attribute

Description	Defines the `idle` timeout in seconds for the Remote RACADM interface. If a remote RACADM session remains inactive for more than the specified sessions, the session closes.

Table 153. Details of cfgSsnMgtRacadmTimeout attribute (continued)

Legal Values	10–1920
Default	`60` `30 minutes`

Example

```
racadm getconfig -g cfgSessionManagement cfgSsnMgtWebserverTimeout=0
cfgSsnMgtTelnetIdleTimeout=0
cfgSsnMgtSshIdleTimeout=1800
cfgSsnMgtRacadmTimeout=0
```

cfgSsnMgtConsRedirMaxSessions (Read or Write)

Table 154. Details of cfgSsnMgtConsRedirMaxSessions

Description	Specifies the maximum number of Virtual Console sessions allowed on iDRAC.
Legal Values	1–4
Default	4

cfgSsnMgtWebserverTimeout (Read or Write)

Table 155. Details of cfgSsnMgtWebserverTimeout attribute

Description	Defines the web server time-out. This property sets the amount of time (in seconds) that a connection is allowed to remain idle (there is no user input). The session is canceled if the time limit exceeds this property. Changes to this setting do not affect the current session. Log out and log in again to make the new settings effective. An expired web server session logs out the current session.
Legal Values	60–10800
Default	1800

cfgSsnMgtSshIdleTimeout (Read or Write)

Table 156. Details of cfgSsnMgtSshIdleTimeout attribute

Description	Defines the secure shell idle time-out. This property sets the amount of time (in seconds) that a connection is allowed to remain idle (there is no user input). The session is canceled if the time limit exceeds this property. Changes to this setting do not affect the current session; log out and log in again to make the new settings effective. An expired secure shell session displays the following error message: • For iDRAC on Rack and Tower Servers: Connection timed out • For iDRAC Enterprise on Blade Servers: `Session timed out. Closing the session.` After the message is displayed, the system returns to the shell that generated the Secure Shell session.
Legal Values	• `0` —(No timeout) • 60–10800 **NOTE:** If 0 (no timeout), the network connection does not send alive packets to probe the client. Otherwise, keep alive packets are sent to guarantee that the client is responding.

Table 156. Details of cfgSsnMgtSshIdleTimeout attribute (continued)

Default	• For iDRAC on Rack and Tower Servers: 300 • For iDRAC Enterprise on Blade Servers: 1800 1800

cfgSsnMgtTelnetIdleTimeout - Read or Write

Table 157. Details of cfgSsnMgtTelnetIdleTimeout attribute

Description	Defines the Telnet idle timeout. This property sets the amount of time in seconds that a connection is allowed to remain idle (there is no user input). The session is canceled if the time limit exceeds this property. Changes to this setting do not affect the current session (you must log out and log in again to make the new settings effective.) An expired Telnet session displays the following error message: • For iDRAC on Rack and Tower Servers: `Connection timed out` • For iDRAC Enterprise on Blade Servers: `Session timed out. Closing the session.` After the message is displayed, the system returns you to the shell that generated the Telnet session.
Legal Values	• 0 (No timeout) • 60–10800 **NOTE:** If 0 (no timeout is specified), the network connection does not send alive packets to probe the client. Otherwise, keep alive packets are sent to guarantee that the client is responding.
Default	• For iDRAC on Rack and Tower Servers: 300 • For iDRAC Enterprise on Blade Servers: 1800 1800

cfgSerial

This group contains configuration parameters for the serial configuration. One instance of the group is allowed.

Use this object with the `config` or `getconfig` subcommands.

To use this object property, you must have the Chassis Configuration Administrator privilege.

The following sections provide information about the objects in the `cfgSerial` group.

NOTE: The `cfgSerial` object group is applicable for iDRAC Enterprise on Blade Servers for only two properties — `cfgSerialTelnetEnable=1` and `cfgSerialSshEnable=1`.

cfgSerialBaudRate - Read or Write

Table 158. Details of cfgSerialBaudRate attribute

Description	Sets the baud rate on the serial port.
Legal Values	9600, 19200, 57600, 115200 2400, 4800, 9600, 19200, 28800, 38400, 57600, 115200
Default	57600 115200

cfgSerialConsoleEnable - Read or Write

Table 159. Details of cfgSerialConsoleEnable attribute

Description	Enables or disables the serial console interface.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	0 1

cfgSerialConsoleQuitKey (Read or Write)

Table 160. Details of cfgSerialConsoleQuitKey attribute

Description	This key or key combination terminates Virtual Console text for iDRAC when using the `console com2` command.
Legal value:	^ follows any alphabet (a-z, A-Z) ^ follows the listed special characters: [ ] \ ^ _ **NOTE:** The CTRL key is represented by using the ^ (carat) character. **NOTE:** The CTRL key does not generate a character by itself, but must be struck simultaneously with another key to generate a character. For example, striking both the CTRL key and the \ key simultaneously (rather than sequentially) is denoted as ^\. Configuration options: The value must start with the ^ character, and must follow one of the characters — a-z, A-Z, [,], \ In the input command, use \ without the quotes. For example: `config -g cfgSerial -o cfgSerialConsoleQuitKey "SHIFT+6"\\`
Default:	`<Ctrl> \`

cfgSerialConsoleIdleTimeout - Read or Write

Table 161. Details of cfgSerialConsoleIdleTimeout attribute

Description	The maximum number of seconds to wait before an idle serial session is disconnected.
Legal Values	• 0 = No timeout • 60–1920
Default	300 1800

cfgSerialConsoleNoAuth - Read or Write

Table 162. Details of cfgSerialConsoleNoAuth attribute

Description	Enables or disables the serial console login authentication.
Legal Values	• 0 — (enables serial login authentication)

Table 162. Details of cfgSerialConsoleNoAuth attribute (continued)

	• 1 — (disables serial login authentication)
Default	0

cfgSerialConsoleCommand - Read or Write

Table 163. Details of cfgSerialConsoleCommand attribute

Description	Specifies a serial command that is executed after a user logs in to the serial console interface.
Legal Values	A string of up to 128 characters. A string representing a valid serial command. For example, connect server-1.
Default	`<blank>`

cfgSerialHistorySize - Read or Write

Table 164. Details of cfgSerialHistorySize attribute

Description	Specifies the maximum size of the serial history buffer.
Legal Values	0–8192
Default	8192

cfgSerialCom2RedirEnable (Read or Write)

Table 165. Details of cfgSerialCom2RedirEnable

Description	Enables or disables the console for COM 2-port redirection. The `cfgSerialCom2RedirEnable` object property is applicable only for iDRAC on Rack and Tower Servers.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	1

cfgSerialHistorySize - Read or Write

Table 166. Details of cfgSerialHistorySize attribute

Description	Specifies the maximum size of the serial history buffer.
Legal Values	0–8192
Default	8192

cfgSerialSshEnable - Read or Write

Table 167. Details of cfgSerialSshEnable attribute

Description	Enables or disables the secure shell (SSH) interface.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	1

Example

```
racadm getconfig -g cfgSerial
```

```
cfgSerialBaudRate=115200
cfgSerialConsoleEnable=1
cfgSerialConsoleQuitKey=^\
cfgSerialConsoleIdleTimeout=1800
cfgSerialConsoleNoAuth=0
cfgSerialConsoleCommand=
cfgSerialConsoleColumns=0
cfgSerialHistorySize=8192
cfgSerialTelnetEnable=0
cfgSerialSshEnable=1
```

cfgSerialTelnetEnable - Read or Write

Table 168. Details of cfgSerialTelnetEnable attribute

Description	Enables or disables the Telnet console interface.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	0

cfgOobSnmp

This group contains parameters to configure the SNMP agent and trap capabilities of iDRAC. One instance of the group is allowed.

This group contains parameters to configure the SNMP agent and trap capabilities of CMC. One instance of the group is allowed.

The CMC SNMP agent supports the standard RFC1213 mib-2 and the Dell enterprise-specific the MIB.

This group is not applicable for iDRAC on Rack and Tower Servers.

Use this object with the `config` or `getconfig` subcommands.

To use this object property, you must have the Chassis Configuration Administrator privilege.

NOTE: You can configure a setting that does not have the hash sign (#) prefixed in the output. To modify a configurable object, use the `–o` option.

The following sections provide information about the objects in the `cfgOobSnmp` group.

cfgOobSnmpAgentCommunity (Read or Write)

Table 169. Details of cfgOobSnmpAgentCommunit attribute

Description	Specifies the SNMP Community Name used for SNMP traps. The community string acts as a password shared between different hosts over the network. This community string value must match with the other hosts for any kind of communication through SNMP.
Legal Values	A string of up to 31 characters.
Default	public

Example

```
racadm getconfig -g cfgOobSnmp
```

```
cfgOobSnmpTrapsEnable=1
cfgOobSnmpAgentCommunity=public
```

cfgOobSnmpAgentEnable (Read or Write)

Table 170. Details of cfgOobSnmpAgentEnable attribute

Description	Enables or disables the SNMP agent in iDRAC. Enables or disables the SNMP agent in CMC.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	0

cfgRacTuning

This group is used to configure various configuration properties, such as valid ports and security port restrictions.

Use this object with the `config` or `getconfig` subcommands.

To use this object property, you must have the Chassis Configuration Administrator privilege.

NOTE: You can configure a setting that does not have the hash sign (#) prefixed in the output. To modify a configurable object, use the `–o` option.

To apply this setting to iDRAC, use the `–m` option.

The following sections provide information about the objects in the `cfgRacTuning` group.

NOTE: Only the following objects are displayed, if `–m` option is used:

- `cfgRacTuneWebserverEnable`
- `cfgRacTuneHttpPort`
- `cfgRacTuneHttpsPort`
- `cfgRacTuneTelnetPort`
- `cfgRacTuneSshPort`

cfgRacTuneConRedirPort (Read or Write)

Table 171. Details of cfgRacTuneConRedirPort

Description	To use for keyboard, mouse, video and Virtual Media traffic to iDRAC, specify the port.
Legal Values	1024–65535
Default	5900

cfgRacTuneRemoteRacadmEnable (Read or Write)

Table 172. Details of cfgRacTuneRemoteRacadmEnable attribute

Description	Enables or disables the Remote RACADM interface.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	1

cfgRacTuneCtrlEConfigDisable

Table 173. Details of cfgRacTuneCtrlEConfigDisable

Description	To configure iDRAC from the BIOS POST option-ROM, enables or disables the ability of the local user. This object is applicable only for iDRAC on Rack and Tower Servers and not for iDRAC Enterprise on Blade Servers.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	0

cfgRacTuneHttpPort (Read or Write)

Table 174. Details of cfgRacTuneHttpPort attribute

Description	To use HTTP network communication, specify the port number.
Legal Values	10–65535 **NOTE:** The following port numbers are reserved and cannot be used: 21, 68, 69, 111, 123, 161, 546, 801, 4096, 5988, 5989, 6900, 9000, and 60106.
Default	80

cfgRacTuneHttpsPort (Read or Write)

Table 175. Details of cfgRacTuneHttpsPort attribute

Description	To use HTTPS network communication, specify the port number.
Legal Values	10–65535

Table 175. Details of cfgRacTuneHttpsPort attribute (continued)

	NOTE: The following port numbers are reserved and cannot be used: 21, 68, 69, 111, 123, 161, 546, 801, 4096, 5988, 5989, 6900, 9000, and 60106.
Default	443

cfgRacTuneIpRangeEnable (Read or Write)

Table 176. Details of cfgRacTuneIpRangeEnable attribute

Description	Enables or disables the IPv4 Address Range validation feature.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	0

cfgRacTuneIpRangeAddr (Read or Write)

Table 177. Details of cfgRacTuneIpRangeAddr attribute

Description	Specifies the acceptable IPv4 address bit pattern in the positions of the "1"s in the range mask property (`cfgRacTuneIpRangeMask`). Alogin from the incoming IP address is allowed only if the following are identical: • `cfgRacTuneIpRangeMask` bit-wise and with incoming IP address • `cfgRacTuneIpRanbeMask` bit-wise and with `cfgRacTuneIpRangeAddr`
Legal Values	An IPv4 address formatted string, for example, `192.168.0`.
Default	192.168.0

cfgRacTuneIpRangeMask (Read or Write)

Table 178. Details of cfgRacTuneIpRangeMask attribute

Description	Standard IP mask values with left-justified bits. For example, `255.255.255.0`. Login from the incoming IP address is allowed only if both of the following are identical: • `cfgRacTuneIpRangeMask` bit-wise and with incoming IP address • `cfgRacTuneIpRanbeMask` bit-wise and with `cfgRacTuneIpRangeAddr`
Legal Values	An IPv4 address formatted string, for example, `255.255.255.0`.
Default	255.255.255.0

cfgRacTuneSshPort (Read or Write)

Table 179. Details of cfgRacTuneSshPort attribute

Description	Specifies the port number used for the SSH interface. **NOTE:** The following port numbers are reserved and cannot be used: 21, 68, 69, 111, 123, 161, 546, 801, 4096, 5988, 5989, 6900, 9000, and 60106.

Table 179. Details of cfgRacTuneSshPort attribute (continued)

Legal Values	1–65535 10–65535
Default	22

cfgRacTuneTelnetPort (Read or Write)

Table 180. Details of cfgRacTuneTelnetPort attribute

Description	Specifies the port number used for the Telnet interface. **NOTE:** The following port numbers are reserved and cannot be used: 21, 68, 69, 111, 123, 161, 546, 801, 4096, 5988, 5989, 6900, 9000, and 60106.
Legal Values	1–65535 10–65535
Default	23

cfgRacTuneConRedirEnable (Read or Write)

Table 181. Details of cfgRacTuneConRedirEnable

Description	Enables or disables Virtual Console.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	1

cfgRacTuneConRedirEncryptEnable (Read or Write)

Table 182. Details of cfgRacTuneConRedirEncryptEnable

Description	Encrypts the video in a Virtual Console session.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	1

cfgRacTuneAsrEnable (Read or Write)

Table 183. Details of cfgRacTuneAsrEnable

Description	Enables or disables iDRAC last crash screen capture feature. This object property requires an iDRAC reset before it becomes active.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	0

cfgRacTuneDaylightOffset (Read Only)

Table 184. Details of cfgRacTuneDaylightOffset attribute

Description	Specifies the daylight savings offset (in minutes) to use for the RAC Time. This value is 0 if the time zone is not a Daylight Saving time zone.
Legal Values	0–60
Default	0

Example

```
racadm getconfig -g cfgRacTuning [-m server-<n>] -o
<
object name
> <
object value
>
```

```
cfgRacTuneRemoteRacadmEnable=1
cfgRacTuneWebserverEnable=1
cfgRacTuneHttpPort=80
cfgRacTuneHttpsPort=443
cfgRacTuneTelnetPort=23
cfgRacTuneSshPort=22
cfgRacTuneIpRangeEnable=0
cfgRacTuneIpRangeAddr=192.168.1.1
cfgRacTuneIpRangeMask=255.255.255.0
# cfgRacTuneTimezoneOffset=-18000
# cfgRacTuneDaylightOffset=3600
```

cfgRacTuneTimezoneOffset (Read Only)

Table 185. Details of cfgRacTuneTimezoneOffset attribute

Description	Specifies the time zone offset (in minutes) from Greenwich Mean Time (GMT) / Coordinated Universal Time (UTC) to use for the RAC Time. Some common time zone offsets for time zones in the United States are: ● –480 (PST — Pacific Standard Time) ● –420 (MST — Mountain Standard Time) ● –360 (CST — Central Standard Time) ● –300 (EST — Eastern Standard Time) This object property is read only. Specifies the difference in number of seconds, from the UTC/GMT. This value is negative if the current time zone is west of Greenwich.
Legal Values	–720–7800 None
Default	0

Example

```
racadm getconfig -g cfgRacTuning
```

```
cfgRacTuneRemoteRacadmEnable=1
cfgRacTuneWebserverEnable=1
cfgRacTuneHttpPort=80
cfgRacTuneHttpsPort=443
cfgRacTuneTelnetPort=23
```

```
cfgRacTuneSshPort=22
cfgRacTuneIpRangeEnable=0
cfgRacTuneIpRangeAddr=192.168.1.1
cfgRacTuneIpRangeMask=255.255.255.0
# cfgRacTuneTimezoneOffset=-18000
# cfgRacTuneDaylightOffset=3600
```

cfgRacTuneLocalServerVideo (Read or Write)

Table 186. Details of cfgRacTuneLocalServerVideo

Description	Enables or disables the local server video.
Legal Values	• 1 (TRUE — Enables) • 0 (FALSE— Disables)
Default	1

cfgRacTuneLocalConfigDisable (Read or Write)

Table 187. Details of cfgRacTuneLocalConfigDisable attribute

Description	Disables write access to iDRAC configuration data. **NOTE:** Access can be disabled using the local RACADM or iDRAC web interface; however, once disabled, access can be re-enabled only through iDRAC web interface.
Legal Values	• 0 (TRUE-Enables) • 1 (FALSE-Disables)
Default	0

cfgRacTuneWebserverEnable (Read or Write)

Table 188. Details of cfgRacTuneWebserverEnable attribute

Description	Enables or disables the web server. If this property is disabled then it is not accessible using client web browsers. This property has no effect on the `Telnet/SSH` or `racadm interfaces`.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	1

cfgRacTuneVirtualConsoleAuthorizeMultipleSessions (Read or Write)

Table 189. Details of cfgRacTuneVirtualConsoleAuthorizeMultipleSessions

Description	If a first user is already using the Virtual Console, the value of this object affects the privileges granted to the subsequent user's shared request after the timeout of 30 seconds. This object is applicable only for iDRAC on Rack and Tower Servers and not for iDRAC Enterprise on Blade Servers. **NOTE:** To modify this property, you must have Configure iDRAC permission. This object can be used only with remote or firmware (SSH or Telnet) RACADM and not with local RACADM or with earlier DRAC products.

Table 189. Details of cfgRacTuneVirtualConsoleAuthorizeMultipleSessions (continued)

Legal Values	0 — (If the user of the first session has not responded for session sharing request by subsequent user. The next session user gets an access denied error after the default timeout value of 30 seconds.) 1 — (If the user of the first session has not responded for session sharing request by subsequent user. The next session user gets a read-only access after the default timeout value of 30 seconds.) 2 — (If the user of the first session has not responded for session sharing request by subsequent user. The next session user gets administrator access after default timeout value of 30 seconds.)
Default	0

cfgRacTunePluginType (Read or Write)

Table 190. Details of cfgRacTunePluginType

Description	To virtual console from browser, specifies the plug-in type.
Legal Values	• 0 = Use Active X /Native Plugin • 1 = Use Java Plugin
Default	0 = Active X /Native Plugin

ifcRacManagedNodeOs

This group contains properties that describe the managed server operating system. One instance of the group is allowed.

The following sections provide information about the objects in the `ifcRacManagedNodeOs`.

ifcRacMnOsHostname (Read Only)

Table 191. Details of ifcRacMnOsHostname

Description	The host name of the managed server.
Legal Values	A string of up to 255 characters.
Default	`<blank>`

ifcRacMnOsOsName (Read Only)

Table 192. Details of ifcRacMnOsOsName

Description	The operating system name of the managed server.
Legal Values	A string of up to 255 characters.
Default	`<blank>`

cfgRacVirtual

This group contains parameters to configure the iDRAC Virtual Media feature. One instance of the group is allowed.

The following sections provide information about the objects in the `cfgRacVirtual`.

cfgVirMediaAttached (Read or Write)

Table 193. Details of cfgVirMediaAttached

Description	This object is used to attach virtual devices to the system via the USB bus. When the devices are attached, the server recognizes valid USB mass storage devices attached to the system. Which is equivalent to attaching a local `USB CDROM/floppy` drive to a USB port on the system. When the devices are attached, they can be connected to the virtual devices remotely using iDRAC web interface or the CLI. Setting this object to 0 causes the devices to detach from the USB bus. **NOTE:** Modifying this property does not impact the remote file sharing operation.
Legal Values	• `0` = Detach • `1` = Attach • `2` = AutoAttach
Default	0

cfgVirtualBootOnce (Read or Write)

Table 194. Details of cfgVirtualBootOnce

Description	Enables or disables the `Virtual Media Boot Once` feature of iDRAC. If this property is enabled when the host server is rebooted, this feature attempts to start from the virtual media devices — if the appropriate media is installed in the device.
Legal Values	• `1` (TRUE) • `0` (FALSE)
Default	0

cfgVirMediaFloppyEmulation (Read or Write)

Table 195. Details of cfgVirMediaFloppyEmulation

Description	When set to `0`, the virtual floppy drive is recognized as a removable disk by Windows operating systems. Windows operating systems assigns a drive letter that is `C:` or higher during enumeration. When set to`1`, the Virtual Floppy drive is seen as a floppy drive by Windows operating systems. Windows operating systems assigns a drive letter of `A:` or `B:`. **NOTE:** Virtual Media has to be reattached (using `cfgVirMediaAttached`) for this change to take effect.
Legal Values	• `1` (TRUE) • `0`(FALSE)
Default	0

cfgSDWriteProtect (Read Only)

Table 196. Details of cfgSDWriteProtect

Description	Displays if the physical write protect latch on the SD card is enabled or disabled. **NOTE:** This command is deprecated from 12G iDRAC 1.0 release onwards. The functionality of this command is covered by `cfgVFlashSDWriteProtect`. While execution of the

Table 196. Details of cfgSDWriteProtect (continued)

	`cfgSDWriteProtect` command is successful, use the `cfgVFlashSDWriteProtect` command. For more information, see cfgVFlashSDWriteProtect Read Only.
Legal Values	• `1` (TRUE) • `0`(FALSE)
Default	0

cfgServerInfo

This group allows you to select the BIOS first boot device and provides the option to start the selected device only once.

This group allows you to display and configure a server in the chassis.

Use this object with the `config` or `getconfig` subcommands.

To use this object property, you must have the Chassis Configuration Administrator privilege.

NOTE: You can configure a setting does not have the hash sign (#) prefixed in the output. To modify a configurable object, use the `–o` option

The following sections provide information about the objects in the `cfgServerInfo`.

cfgServerName (Read Or Write)

Table 197. Details of cfgServerName attribute

Description	Displays the name of the specified server.
Legal Values	Maximum of 15 non-extended (ASCII characters (ASCII codes 32 through 126). For more information, see Guidelines to Quote Strings Containing Special Characters.
Default	SLOT — `<slot number>`

cfgServerNic3MacAddress (Read Only)

Table 198. Details of cfgServerNic3MacAddress

Description	Displays the MAC address of the server NIC 3.
Legal Values	None
Default	None

cfgServerNic4MacAddress (Read Only)

Table 199. Details of cfgServerNic4MacAddress

Description	Displays the MAC address of the server NIC 4.
Legal Values	None
Default	None

cfgServerDNSIMCName (Read or Write)

Table 200. Details of cfgServerDNSIMCName attribute

Description	Displays the DNS domain name for iDRAC or IMC.
Legal Values	A valid string values
Default	None

Usage	You can get and set the iDRAC DNS name using the `cfgServerDNSIMCName` attribute.
	To set the iDRAC DNS name in:
	● Firmware RACADM:
	`racadm config -g cfgserverinfo -i <server_slot_number> -o cfgServerDNSIMCName <Valid_iDRAC_Name>`
	● Remote RACADM:
	`racadm -r <cmc_ip> -u <cmc_username> -p <cmc_password> config -g cfgserverinfo -i <server_slot_number> -o cfgServerDNSIMCName <Valid_iDRAC_Name>`
	● Proxy:
	`racadm -r <iDRAC_ip> -u <iDRAC_username> -p <iDRAC_password> config -g cfgserverinfo -i <server_slot_number> -o cfgServerDNSIMCName <Valid_iDRAC_Name> --proxy`
	To get the iDRAC DNS name in:
	● Firmware RACADM:
	`racadm getconfig -g cfgserverinfo -i <server_slot_number> -o cfgServerDNSIMCName`
	● Remote RACADM:
	`racadm -r <cmc_ip> -u <cmc_username> -p <cmc_password> getconfig -g cfgserverinfo -i <server_slot_number> -o cfgServerDNSIMCName`
	● Proxy:
	`racadm -r <iDRAC_ip> -u <iDRAC_username> -p <iDRAC_password> getconfig -g cfgserverinfo -i <server_slot_number> -o cfgServerDNSIMCName --proxy`

cfgServerFirstBootDevice (Read or Write)

Table 201. Details of cfgServerFirstBootDevice

Description	Sets or displays the first boot device. You can also set a vFlash partition that is attached as a bootable device. For more information, see cfgVFlashPartitionOSVolLabel. **NOTE:** If RFS is configured as the next boot device, during restart, the system starts normally and not from RFS. This object is Write only.

Table 201. Details of cfgServerFirstBootDevice (continued)

	NOTE: First attach, to configure vFlash as First Boot Device. When a detached / non-existent vFlash partition or a nonstandard boot device is configured as first boot device, the following error message is displayed: `Invalid object value`
Legal Values	• No-Override • PXE • HDD • DIAG • CD-DVD • BIOS • vFDD • VCD-DVD • iSCSI • FDD • SD • RFS (Remote File Share) • F10 • F11 • 0 — None • 0 — Default • 4 — PXE • 8 — HDD • 20 — CD-DVD • 24 — BIOS • 28 — vFDD • 32 — vCD-DVD • 40 — SD • 44 — RFS (Remote File Share) • 48 — F11 • 52 — F10 • 60 — FDD
Default	No-Override 0 — None

cfgServerBootOnce (Read or Write)

Table 202. Details of cfgServerBootOnce

Description	Enables or disables the server start once feature. This object is Write only.
Legal Values	• `1`(True) • `0` (False)
Default	`1`(True)

cfgActiveDirectory

This group contains parameters to configure iDRAC Active Directory feature.

This group contains parameters to configure CMC Active Directory feature.

Use this object with the `config` or `getconfig` subcommands.

To use this object property, you must have the Chassis Configuration Administrator privilege.

NOTE: You can configure a setting that does not have the hash sign (#) prefixed in the output. To modify a configurable object, use the `–o` option.

The following sections provide information about the objects in the `cfgActiveDirectory`.

cfgADSSOEnable (Read or Write)

Table 203. Details of cfgADSSOEnable attribute

Description	Enables or disables Active Directory single sign-on authentication on iDRACCMC.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	0

cfgADDomainController1 (Read or Write)

Table 204. Details of cfgADDomainController1

Description	To obtain user names, specify the LDAP server from which you want the iDRAC.
Legal Values	A string of up to 254 ASCII characters representing a valid IP address or a fully qualified domain name (FQDN).
Default	None

cfgADDomainController2 (Read or Write)

Table 205. Details of cfgADDomainController2

Description	To obtain user names, specify the LDAP server from which you want the iDRAC. This object is applicable only to iDRAC.
Legal Values	A string of up to 254 ASCII characters representing a valid IP address or a fully qualified domain name (FQDN).
Default	None

cfgADDomainController3 (Read or Write)

Table 206. Details of cfgADDomainController3

Description	To obtain user names, specify the LDAP server from which you want the iDRAC. This object is applicable only to iDRAC.
Legal Values	A string of up to 254 ASCII characters representing a valid IP address or a fully qualified domain name (FQDN).
Default	None

cfgADRacName (Read or Write)

Table 207. Details of cfgADRacName attribute

Description	Name of iDRAC as recorded in the Active Directory forest. Name of CMC as recorded in the Active Directory forest.
Legal Values	Any printable text string of up to 254 characters, with no white space.
Default	`<blank>`

cfgADRacDomain (Read or Write)

Table 208. Details of cfgADRacDomain attribute

Description	Active Directory Domain in which iDRAC resides. Active Directory Domain in which CMC resides.
Legal Values	Any printable text string of up to 254 characters, with no white space.
Default	`<blank>`

cfgADAuthTimeout (Read or Write)

Table 209. Details of cfgADAuthTimeout attribute

Description	To wait for Active Directory authentication requests to complete before timing out, specify the number of seconds. **NOTE:** To modify this property, you must have the Configure iDRAC permission.
Legal Values	15–300 seconds
Default	120

cfgADEnable (Read or Write)

Table 210. Details of cfgADEnable attribute

Description	Enables or disables Active Directory user authentication on iDRAC. If this property is disabled, only local iDRAC authentication is used for user login. Enables or disables Active Directory user authentication on CMC. If this property is disabled then either local CMC or LDAP authentication may be used for user login.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	0

cfgADType (Read or Write)

Table 211. Details of cfgADType attribute

Description	To use the Active Directory, determine the schema type.
Legal Values	• 1 — (Enables Active Directory with the extended schema) • 2 — (Enables Active Directory with the standard schema)
Default	1

cfgADGlobalCatalog1 (Read or Write)

Table 212. Details of cfgADGlobalCatalog1

Description	To obtain user names, specify the Global Catalog server from which you want the iDRAC. This object is applicable only to iDRAC.
Legal Values	A string of up to 254 ASCII characters representing a valid IP address or a fully qualified domain name (FQDN).
Default	None

cfgADGlobalCatalog2 (Read or Write)

Table 213. Details of cfgADGlobalCatalog2

Description	To obtain user names, specify the Global Catalog server from which you want the iDRAC. This object is applicable only to iDRAC.
Legal Values	A string of up to 254 ASCII characters representing a valid IP address or a fully qualified domain name (FQDN).
Default	None

cfgADGlobalCatalog3 (Read or Write)

Table 214. Details of cfgADGlobalCatalog3

Description	To obtain user names, specify the Global Catalog server from which you want the iDRAC. This object is applicable only to iDRAC.
Legal Values	A string of up to 254 ASCII characters representing a valid IP address or a fully qualified domain name (FQDN).
Default	None

cfgADCertValidationEnable (Read or Write)

Table 215. Details of cfgADCertValidationEnable attribute

Description	Enables or disables Active Directory certificate validation as a part of the Active Directory configuration process.
Legal Values	• 1 (TRUE)

Table 215. Details of cfgADCertValidationEnable attribute (continued)

	• 0 (FALSE)
Default	1

cfgADDcSRVLookupEnable (Read or Write)

Table 216. Details of cfgADDcSRVLookupEnable

Description	Configures iDRAC to use pre-configured domain controllers or to use DNS to find the domain controller. If using pre-configured domain controllers, then the domain controllers to use are specified under `cfgAdDomainController1` ,`cfgAdDomainController2` and `cfgAdDomainController3`. iDRAC does not failover to the specified domain controllers when DNS lookup is unsuccessful or none of the servers returns to the DNS lookup works. This object is applicable only to iDRAC.
Legal Values	• 1 (TRUE) — use DNS to look up domain controllers • 0 (FALSE) — use pre-configured domain controllers
Default	0

cfgADDcSRVLookupbyUserdomain (Read or Write)

Table 217. Details of cfgADDcSRVLookupbyUserdomain

Description	Chooses the way the user domain is looked up for Active Directory. This object is applicable only to iDRAC.
Legal Values	• 1 (TRUE) — use user domain as the search domain to look up DCs. The user domain is chosen from either the user domain list or by entering into the user login. • 0 (FALSE) — use the configured search domain `cfgADDcSrvLookupDomainName` to look up DCs.
Default	1

cfgADDcSRVLookupDomainName (Read or Write)

Table 218. Details of cfgADDcSRVLookupDomainName

Description	Use the Active Directory Domain when `cfgAddcSrvLookupbyUserDomain` is set to `0`. This object is applicable only to iDRAC.
Legal Values	String. Maximum length = 254
Default	Null

cfgADGcSRVLookupEnable (Read or Write)

Table 219. Details of cfgADGcSRVLookupEnable

Description	Determines how the global catalog server is looked up. If using pre-configured global catalog servers, then iDRAC uses the values `cfgAdGlobalCatalog1`, `cfgAdGlobalCatalog2` and `cfgAdGlobalCatalog3`. This object is applicable only to iDRAC.

Table 219. Details of cfgADGcSRVLookupEnable (continued)

Legal Values	• 0(FALSE) — use pre-configured Global Catalog Servers (GCS) • 1(TRUE) — use DNS to look up GCS
Default	0

cfgADGcRootDomain (Read or Write)

Table 220. Details of cfgADGcRootDomain

Description	The names of the Active Directory root domain used for DNS look up, to locate Global Catalog servers. This object is applicable only to iDRAC.
Legal Values	String. Maximum length = 254
Default	Null

cfgLDAP

This group allows you to configure settings related to the Lightweight Directory Access Protocol (LDAP).

Use this object with the `config` or `getconfig` subcommands.

To use this object property, you must have the Chassis Configuration Administrator privilege.

NOTE: You can configure a setting that does not have the hash sign (#) prefixed in the output. To modify a configurable object, use the `-o` option.

The following sections provide information about the objects in the `cfgLDAP`.

cfgLDAPEnable (Read or Write)

Table 221. Details of cfgLDAPEnable attribute

Description	Enables or disables LDAP service. If this property is disabled, local iDRACCMC authentication is used for user logins. **NOTE:** Enabling this option turns off `cfgADEnable`.
Legal Values	• 1 — Enable • 0 — Disable
Default	0

cfgLDAPServer (Read or Write)

Table 222. Details of cfgLDAPServer attribute

Description	Configures the address of the LDAP Server. IPv4 and IPv6 are supported. **NOTE:** You can specify multiple servers by separating each server with a comma. For example, example.com, sub1.example.com
Legal Values	String. Maximum length = 1024

Table 222. Details of cfgLDAPServer attribute (continued)

	Maximum length = 254
Default	Null

cfgLDAPPort (Read or Write)

Table 223. Details of cfgLDAPPort attribute

Description	Port of LDAP over SSL. Non-SSL port is not supported.
Legal Values	1–65535
Default	636

cfgLDAPBaseDN (Read or Write)

Table 224. Details of cfgLDAPBaseDN attribute

Description	The domain name of the branch of the directory where all searches must start.
Legal Values	String. Maximum length = 254
Default	Null

cfgLDAPUserAttribute (Read or Write)

Table 225. Details of cfgLDAPUserAttribute attribute

Description	To search for, specify the user attribute. It is recommended to be unique within the chosen baseDN, otherwise a search filter must be configured to make sure the uniqueness of the login user. If the userDN cannot be uniquely identified, login is unsuccessful with error.
Legal Values	String. Maximum length = 254
Default	Null

cfgLDAPGroupAttribute (Read or Write)

Table 226. Details of cfgLDAPGroupAttribute attribute

Description	Specifies which LDAP attribute is used to check for group membership. It must be an attribute of the group class. If not specified then the member and unique member attributes are used.
Legal Values	String maximum length = 254
Default	Null

cfgLDAPGroupAttributeIsDN (Read or Write)

Table 227. Details of cfgLDAPGroupAttributeIsDN attribute

Description	When it is set to `1`, iDRAC compares the `userDN` retrieved from the directory to compare to the members of the group. If it is set to `0`, the user name provides the login user to compare to the members of the group. It does not affect the search algorithm for the bind. iDRAC always searches the `userDN` and uses the `userDN` to bind. If enabled, the CMC performs DN matching, otherwise the CMC uses the user name provided at login for matching.
Legal Values	• `1`(TRUE) — Use the `userDN` from the LDAP Server • `0`(FALSE) — Use the `userDN` to provide the login user
Default	1

cfgLDAPBindDN (Read or Write)

Table 228. Details of cfgLDAPBindDN attribute

Description	The distinguished name of a user used to bind to the server when searching for the login user's DN. If not provided, an anonymous bind is used. If necessary It is optional to support anonymous bind. **NOTE:** If `cfgLDAPBindDN` is [null] and `cfgLDAPBindPassword` is [null], then the iDRACCMC attempts an anonymous bind.
Legal Values	String maximum length = 254
Default	Null

cfgLDAPBindPassword (Write Only)

Table 229. Details of cfgLDAPBindPassword attribute

Description	A bind password is used with the bindDN. The bind password is a sensitive data, and must be protected. It is optional to support anonymous bind.
Legal Values	String maximum length = 254
Default	Null

cfgLDAPSearchFilter (Read or Write)

Table 230. Details of cfgLDAPSearchFilter attribute

Description	To validate LDAP search filter, use the user attribute that cannot uniquely identify the login user within the chosen baseDN. The search filter only applies to userDN search and not the group membership search.
Legal Values	String of maximum length = 254 characters String of maximum length = 1024 characters
Default	(objectless=*) Searches for all objects in tree.

cfgLDAPCertValidationEnable (Read or Write)

Table 231. Details of cfgLDAPCertValidationEnable attribute

Description	Controls certificate validation during SSL handshake.
Legal Values	• 1 (TRUE) — Uses the CA certificate to validate the LDAP server certificate during SSL handshake. • 0 (FALSE) —Skips the certificate validation step of SSL handshake.
Default	1

cfgLDAPSRVLookupDomainName (Read Only)

Table 232. Details of cfgLDAPSRVLookupDomainName attribute

Description	To use in the SRV lookup, configure the domain name.
Legal Values	String of maximum length of 254 alphanumeric characters and hyphens. The string must begin with a letter.
Default	[null]

cfgLDAPSRVLookupServiceName (Read or Write)

Table 233. Details of cfgLDAPSRVLookupServiceName attribute

Description	To use in the SRV lookup, configure the service name.
Legal Values	String of maximum length of 254 characters.
Default	LDAP

cfgLdapRoleGroup

This group allows the user to configure role groups for LDAP.

This group configures Generic LDAP Role group descriptions and defines the privileges that LDAP-authenticated users are granted.

Use this object with the `config` or `getconfig` subcommands.

To use this object property, you must have the Chassis Configuration Administrator privilege.

NOTE: You can configure a setting that does not have the hash sign (#) prefixed in the output. To modify a configurable object, use the `–o` option.

`cfgLDAPRoleGroup` is indexed, containing instances numbered from 1 to 5. Each object instance consists of a pair of properties:

- `cfgLDAPRoleGroupDN` — an LDAP distinguished name (DN)
- `cfgLDAPRoleGroupPrivilege` — a iDRACCMC privilege map

Each LDAP-authenticated user assumes the total set of iDRACCMC privileges assigned to the matching LDAP distinguished names that the user belongs to. That is, if the user belongs to multiple role group DNs, the user receives all associated privileges for that DNs.

The following sections provide information about the objects in the `cfgLdapRoleGroup`.

cfgLDAPRoleGroupIndex (Read Only)

Table 234. Details of cfgLDAPRoleGroupIndex attribute

Description	It is the index value of the Role Group Object.
Legal Values	An integer between 1 and 5
Default	`<instance>`

cfgLdapRoleGroupDN (Read or Write)

Table 235. Details of cfgLdapRoleGroupDN

Description	It is the Domain Name of the group in this index. Configures the LDAP distinguished name (DN) for the role group instance.
Legal Values	String. Maximum length = 1024
Default	None

Example

```
racadm getconfig -g cfgLDAPRoleGroup -o cfgLDAPRoleGroupDN
-i 1 cn=everyone,ou=groups,dc=openldap,dc=com
```

cfgLdapRoleGroupPrivilege (Read or Write)

Table 236. Details of cfgLdapRoleGroupPrivilege

Description	A bit–mask defining the privileges associated with this particular group.
Legal Values	0x00000000 to 0x000001ff
Default	0x000

Example

```
racadm getconfig -g cfgLDAPRoleGroup -o cfgLDAPRoleGroupPrivilege
-i 1 0x0
```

cfgStandardSchema

This group contains parameters to configure the Active Directory standard schema settings.

Use this object with the `config` or `getconfig` subcommands.

To use this object property, you must have the Chassis Configuration Administrator privilege.

NOTE: You can configure a setting that does not have hash sign (#) prefixed in the output. To modify a configurable object, use the –o option.

The following sections provide information about the objects in the `cfgStandardSchema`.

cfgSSADRoleGroupIndex (Read Only)

Table 237. Details of cfgSSADRoleGroupIndex attribute

Description	Index of the Role Group as recorded in the Active Directory.
Legal Values	An integer from 1 to 5
Default	`<instance>`

cfgSSADRoleGroupName (Read or Write)

Table 238. Details of cfgSSADRoleGroupName attribute

Description	Name of the Role Group as recorded in the Active Directory forest.
Legal Values	Any printable text string of up to 254 characters, with no white space.
Default	`<blank>`

cfgSSADRoleGroupDomain (Read or Write)

Table 239. Details of cfgSSADRoleGroupDomain attribute

Description	Active Directory Domain in which the Role Group resides.
Legal Values	Any printable text string of up to 254 characters, with no white space.
Default	`<blank>`

cfgSSADRoleGroupPrivilege (Read or Write)

Table 240. Details of cfgSSADRoleGroupPrivilege attribute

Description	Use the bit mask numbers listed in the table below to set role-based authority privileges for a Role Group.
Legal Values	0x00000000 to 0x000001ff
Default	`<blank>`

- **Table 241. Example**

Role Group Privilege	Bit Mask
Login to iDRAC	0x00000001
Configure iDRAC	0x00000002
Configure Users	0x00000004
Clear Logs	0x00000008
Execute Server Control Commands	0x00000010
Access Virtual Console	0x00000020

Table 241. Example (continued)

Access Virtual Media	0x00000040
Test Alerts	0x00000080
Execute Debug Commands	0x00000100

cfgThermal

This group displays and configures the thermal settings. Use this object with the `config` or `getconfig` subcommands.

To set the configurations, you must have the **Chassis Configuration Administrator** privileges.

cfgThermalEnhancedCoolingMode (Read or Write)

Table 242. Details of cfgThermalEnhancedCoolingMode attribute

Description	Configures the enhanced cooling mode.
Legal Values	• `1` — Enabled • `0` — Disabled
Default	0 — Disabled

cfgIpmiSol

This group is used to configure the Serial Over LAN (SOL) capabilities of the system.

The following sections provide information about the objects in the **cfgIpmiSol** group.

cfgIpmiSolEnable (Read or Write)

Table 243. Details of cfgIpmiSolEnable

Description	Enables or disables SOL.
Legal Values	• `1`(TRUE) • `0`(FALSE)
Default	1

cfgIpmiSolBaudRate (Read or Write)

Table 244. Details of cfgIpmiSolBaudRate

Description	Specifies baud rate for serial communication over LAN.
Legal Values	9600, 19200, 57600, 115200
Default	115200

cfgIpmiSolMinPrivilege (Read or Write)

Table 245. Details of cfgIpmiSolMinPrivilege

Description	Specifies the minimum privilege level required for SOL access.
Legal Values	• 2(User) • 3(Operator) • 4(Administrator)
Default	4

cfgIpmiSolAccumulateInterval (Read or Write)

Table 246. Details of cfgIpmiSolAccumulateInterval

Description	Specifies the typical amount of time that iDRAC waits before transmitting a partial SOL character data packet. This value is *1-based 5ms* increments.
Legal Values	1–255
Default	10

cfgIpmiSolSendThreshold (Read or Write)

Table 247. Details of cfgIpmiSolSendThreshold

Description	To buffer before sending an SOL data packet, specify the SOL threshold limit value and the maximum number of bytes.
Legal Values	1–255
Default	255

cfgIpmiLan

This group is used to configure the IPMI over LAN capabilities of the system.

The following sections provide information about the objects in the `cfgIpmiLan` group.

cfgIpmiLanEnable (Read or Write)

Table 248. Details of cfgIpmiLanEnable

Description	Enables or disables the IPMI over LAN interface.
Legal Values	• 1(TRUE) • 0(FALSE)
Default	0

cfgIpmiLanPrivLimit (Read or Write)

Table 249. Details of cfgIpmiLanPrivLimit

Description	Specifies the maximum privilege level allowed for IPMI over LAN access.
Legal Values	• 2(User) • 3(Operator) • 4(Administrator)
Default	4

cfgIpmiLanAlertEnable (Read or Write)

Table 250. Details of cfgIpmiLanAlertEnable

Description	Enables or disables global email alerting. This property overrides all individual email alerting enable or disable properties.
Legal Values	• 1(TRUE) • 0(FALSE)
Default	0

cfgIpmiLanEncryptionKey (Read or Write)

Table 251. Details of cfgIpmiLanEncryptionKey

Description	Specifies the IPMI encryption key.
Legal Values	A string of hexadecimal digits from 0 to 40 characters with no spaces. Only an even number of digits is allowed.
Default	0000000000000000000000000000000000000000

cfgIpmiLanPetCommunityName (Read or Write)

Table 252. Details of cfgIpmiLanPetCommunityName

Description	Specifies the SNMP community name for traps.
Legal Values	A string of up to 18 characters.
Default	public

cfgIpmiPetIpv6

This group is used to configure IPv6 platform event traps on the managed server.

The following sections provide information about the objects in the `cfgIpmiPetIpv6` group.

cfgIpmiPetIPv6Index (Read Only)

Table 253. Details of cfgIpmiPetIPv6Index

Description	Unique identifier for the index corresponding to the trap.
Legal Values	1–4
Default	`<index Values>`

cfgIpmiPetIPv6AlertDestIpAddr

Table 254. Details of cfgIpmiPetIPv6AlertDestIpAddr

Description	Configures the IPv6 alert destination IP address for the trap.
Legal Values	IPv6 address
Default	`<blank>`

cfgIpmiPetIPv6AlertEnable (Read or Write)

Table 255. Details of cfgIpmiPetIPv6AlertEnable

Description	Enables or disables the IPv6 alert destination for the trap.
Legal Values	• `1` (TRUE) • `0` (FALSE)
Default	0

cfgIpmiPef

This group is used to configure the platform event filters available on the managed server.

The event filters can be used to control policy related to actions that are triggered when critical events occur on the managed server.

The following sections provide information about the objects in the `cfgIpmiPef` group.

cfgIpmiPefName (Read Only)

Table 256. Details of cfgIpmiPefName

Description	Specifies the name of the platform event filter.
Legal Values	A string of up to 255 characters.
Default	The name of the index filter.

cfgIpmiPefIndex (Read or Write)

Table 257. Details of cfgIpmiPefIndex

Description	Specifies the index of a specific platform event filter.
Legal Values	• For iDRAC on Rack and Tower Servers: `1-22` • For iDRAC Enterprise on Blade Servers: `1-9`
Default	The index value of a platform event filter object.

cfgIpmiPefAction (Read or Write)

Table 258. Details of cfgIpmiPefAction

Description	Specifies the action that is performed on the managed server when the alert is triggered. **NOTE:** For iDRAC on Rack and Tower servers, this object is read-only for indexes 20, 21, and 22.
Legal Values	• `0` (None) • `1` (Power Down) • `2`(Reset) • `3`(Power Cycle)
Default	0

cfgIpmiPefEnable (Read or Write)

Table 259. Details of cfgIpmiPefEnable

Description	Enables or disables a specific platform event filter.
Legal Values	• `1`(TRUE) • `0`(FALSE)
Default	1

cfgIpmiPet

This group is used to configure platform event traps on the managed server.

The following sections provide information about the objects in the `cfgIpmiPet` group.

cfgIpmiPetIndex (Read Only)

Table 260. Details of cfgIpmiPetIndex

Description	Unique identifier for the index corresponding to the trap.
Legal Values	1–4
Default	The index value of a specific platform event trap.

cfgIpmiPetAlertDestIpAddr (Read/Write)

Table 261. Details of cfgIpmiPetAlertDestIpAddr

Description	Specifies the destination IPv4 address for the trap receiver on the network. The trap receiver receives an SNMP trap when an event is triggered on the managed server.
Legal Values	A string representing a valid IPv4 address. For example, `192.168.0.67`.
Default	0.0.0.0

cfgIpmiPetAlertEnable (Read or Write)

Table 262. Details of cfgIpmiPetAlertEnable

Description	Enables or disables a specific trap.
Legal Values	• `1` (TRUE) • `0` (FALSE)
Default	0

cfgUserDomain

This group is used to configure the Active Directory user domain names. A maximum of 40 domain names can be configured at any given time.

The following sections provide information about the objects in the `cfgUserDomain` group.

cfgUserDomainIndex (Read Only)

Table 263. Details of cfgUserDomainIndex

Description	Represents a specific domain.
Legal Values	1–40
Default	The index value.

cfguserdomainname (Read Only)

Table 264. Details of cfguserdomainname

Description	Specifies the Active Directory user domain name.
Legal Values	A string of up to 254 ASCII characters
Default	`<blank>`

cfgServerPower

This group provides several power management features.

The following sections provide information about the objects in the `cfgServerPower` group.

cfgServerPowerStatus (Read Only)

Table 265. Details of cfgServerPowerStatus

Description	Represents the server power state, either ON or OFF.
Legal Values	• 1 (ON) • 0 (OFF)
Default	0

cfgServerPowerAllocation (Read Only)

Table 266. Details of cfgServerPowerAllocation

Description	Represents the available allocated power supply for server usage. **NOTE:** If there is more than one power supply, this object represents the minimum capacity power supply. **NOTE:** This object is applicable only for iDRAC Enterprise on Rack and Tower Servers and not for iDRAC on Blade Servers.
Legal Values	A string of up to 32 characters
Default	`<blank>`

cfgServerActualPowerConsumption (Read Only)

Table 267. Details of cfgServerActualPowerConsumption

Description	Represents the power consumption by the server at the current time.
Legal Values	Not applicable
Default	`<blank>`

cfgServerPowerCapEnable (Read or Write)

Table 268. Details of cfgServerPowerCapEnable

Description	Enables or disables the user specified power budget threshold. This object is Read only for iDRAC Enterprise on Blade Servers.
Legal Values	• 0 — Disables the user specified power budget threshold • 1 — Enables the user specified power budget threshold
Default	1

cfgServerMinPowerCapacity (Read Only)

Table 269. Details of cfgServerMinPowerCapacity

Description	Represents the minimum server power capacity on a blade based on the current component inventory.

Table 269. Details of cfgServerMinPowerCapacity (continued)

Legal Values	Not applicable
Default	`<blank>`

cfgServerMaxPowerCapacity (Read Only)

Table 270. Details of cfgServerMaxPowerCapacity

Description	Represents the maximum server power capacity based on the current component consumption.
Legal Values	Not applicable
Default	`<blank>`

cfgServerPeakPowerConsumption (Read Only)

Table 271. Details of cfgServerPeakPowerConsumption

Description	Represents the servers maximum power consumption until the current time.
Legal Values	Not applicable
Default	Peak power consumption of the server

cfgServerPeakPowerConsumptionTimestamp (Read Only)

Table 272. Details of

Description	Specifies time when the maximum power consumption was recorded.
Legal Values	A string of up to 32 characters.
Default	Timestamp of the peak power consumption of the server.

cfgServerPowerConsumptionClear (Write Only)

Table 273. Details of cfgServerPowerConsumptionClear

Description	Clears the current recorded power statistics.
Legal Values	`1` — Clears the Power Consumption Statistics
Default	None

cfgServerPowerCapWatts (Read or Write)

Table 274. Details of cfgServerPowerCapWatts

Description	Represents the server power threshold in Watts. **NOTE:** This value is applicable only if the `cfgServerPowerCapEnable` is set to `1`.

Table 274. Details of cfgServerPowerCapWatts (continued)

Legal Values	None
Default	Server power threshold in Watts.

cfgServerPowerCapBtuhr (Read or Write)

Table 275. Details of cfgServerPowerCapBtuhr

Description	Represents the server power threshold in BTU/hr. **NOTE:** This value is applicable only if `cfgServerPowerCapEnable` is set to `1`.
Legal Values	None
Default	Server power threshold in BTU/hr.

cfgServerPowerCapPercent (Read or Write)

Table 276. Details of cfgServerPowerCapPercent

Description	Represents the server power threshold in percentage. **NOTE:** This value is applicable only if `cfgServerPowerCapEnable` is set to `1`.
Legal Values	None
Default	Server power threshold in percentage.

cfgServerPowerLastHourAvg (Read Only)

Table 277. Details of cfgServerPowerLastHourAvg

Description	Displays the average power value during the last hour.
Legal Values	None
Default	Average power value during the last hour.

cfgServerPowerLastDayAvg (Read Only)

Table 278. Details of cfgServerPowerLastDayAvg

Description	Displays the average power value during the last day.
Legal Values	None
Default	Average power value during the last day.

cfgServerPowerLastWeekAvg (Read Only)

Table 279. Details of cfgServerPowerLastWeekAvg

Description	Displays the average power value during the last week.
Legal Values	None
Default	Average power value during the last week.

cfgServerPowerLastHourMinPower (Read Only)

Table 280. Details of cfgServerPowerLastHourMinPower

Description	Displays the minimum power value during the last hour.
Legal Values	Not applicable
Default	Minimum power value during the last hour.

cfgServerPowerLastHourMinTime (Read Only)

Table 281. Details of cfgServerPowerLastHourMinTime

Description	Displays the timestamp of minimum power value during the last minute.
Legal Values	Time in the format: DD MM Date HH:MM:SS YYYY cfgServerPowerLastHourMinTime=Mon Sep 26 19:10:56 2011 where, ● DD= Day of the week ● MM= Month ● Date=Date ● YYYY = Year ● HH = hour ● MM=Minutes ● SS = Seconds
Default	Minimum power value during the last minute.

cfgServerPowerLastHourMaxPower (Read Only)

Table 282. Details of cfgServerPowerLastHourMaxPower

Description	Displays the maximum power value during the last hour.
Legal Values	Not applicable
Default	Maximum power value during the last hour.

cfgServerPowerLastHourMaxTime (Read Only)

Table 283. Details of cfgServerPowerLastHourMaxTime

Description	Displays the timestamp of maximum power value during the last hour.
Legal Values	Time in the format: DD MM Date HH:MM:SS YYYY where, ● DD= Day of the week ● MM= Month ● Date=Date ● YYYY = Year ● HH = hour ● MM=Minutes ● SS = Seconds
Default	Maximum power value during the last hour.

cfgServerPowerLastDayMinPower (Read Only)

Table 284. Details of cfgServerPowerLastDayMinPower

Description	Displays the minimum power value during the last day.
Legal Values	Not applicable
Default	Minimum power value during the last day.

cfgServerPowerLastDayMinTime (Read Only)

Table 285. Details of cfgServerPowerLastDayMinTime

Description	Displays the timestamp of minimum power value during the last day.
Legal Values	Time in the format: DD MM Date HH:MM:SS YYYY where, ● DD = Day of the week ● MM = Month ● Date = Date ● YYYY = Year ● HH = hour ● MM = Minutes ● SS = Seconds
Default	Timestamp of the minimum power value during the last day.

cfgServerPowerLastDayMaxPower (Read Only)

Table 286. Details of cfgServerPowerLastDayMaxPower

Description	Displays the maximum power value during the last day.
Legal Values	Not applicable

Table 286. Details of cfgServerPowerLastDayMaxPower (continued)

Default	Maximum power value during the last day.

cfgServerPowerLastDayMaxTime (Read Only)

Table 287. Details of cfgServerPowerLastDayMaxTime

Description	Displays the timestamp of maximum power value during the last day.
Legal Values	Time in the format: DD MM Date HH:MM:SS YYYY where, ● DD = Day of the week ● MM = Month ● Date = Date ● YYYY = Year ● HH = hour ● MM = Minutes ● SS = Seconds
Default	Timestamp of the maximum power value during the last day.

cfgServerPowerLastWeekMinPower (Read Only)

Table 288. Details of cfgServerPowerLastWeekMinPower

Description	Displays the minimum power value during the last week.
Legal Values	Not applicable
Default	Minimum power value during the last week.

cfgServerPowerLastWeekMinTime (Read Only)

Table 289. Details of cfgServerPowerLastWeekMinTime

Description	Displays the timestamp of minimum power value during the last week.
Legal Values	A string of up to 32 characters. Time in the format: DD MM Date HH:MM:SS YYYY where, ● DD = Day of the week ● MM = Month ● Date = Date ● YYYY = Year ● HH = hour ● MM = Minutes ● SS = Seconds
Default	Timestamp of the minimum power value during the last week.

cfgServerPowerLastWeekMaxPower (Read Only)

Table 290. Details of cfgServerPowerLastWeekMaxPower

Description	Displays the maximum power value during the last week.
Legal Values	None
Default	Maximum power value during the last week.

cfgServerPowerLastWeekMaxTime (Read Only)

Table 291. Details of cfgServerPowerLastWeekMaxTime

Description	Displays the timestamp of maximum power value during the last week.
Legal Values	A string of up to 32 characters. Time in the format: DD MM Date HH:MM:SS YYYY where, ● DD = Day of the week ● MM= Month ● Date = Date ● YYYY = Year ● HH = hour ● MM = Minutes ● SS = Seconds
Default	Timestamp of the maximum power value during the last week.

cfgServerPowerInstHeadroom (Read Only)

Table 292. Details of cfgServerPowerInstHeadroom

Description	Displays the difference between the available power and the current power consumption. This object is applicable only for iDRAC on Rack and Tower Servers and not for iDRAC Enterprise on Blade Servers.
Legal Values	Not applicable
Default	Difference between the available power and the current power consumption.

cfgServerPowerPeakHeadroom (Read Only)

Table 293. Details of cfgServerPowerPeakHeadroom

Description	Displays the difference between the available power and the peak power consumption. This object is applicable only for iDRAC on Rack and Tower Servers and not for iDRAC Enterprise on Blade Servers.
Legal Values	None
Default	Difference between the available power and the peak power consumption.

cfgServerActualAmperageConsumption (Read Only)

Table 294. Details of cfgServerActualAmperageConsumption

Description	Displays the current power consumption.
Legal Values	Not applicable
Default	Current power consumption.

cfgServerPeakAmperage (Read Only)

Table 295. Details of cfgServerPeakAmperage

Description	Displays the current peak power consumption.
Legal Values	Not applicable
Default	Current peak power consumption.

cfgServerPeakAmperageTimeStamp (Read Only)

Table 296. Details of cfgServerPeakAmperageTimeStamp

Description	Displays the timestamp of the current peak power consumption.
Legal Values	A string of up to 32 characters. Time in the format: DD MM Date HH:MM:SS YYYY where, ● DD = Day of the week ● MM = Month ● Date = Date ● YYYY = Year ● HH = hour ● MM = Minutes ● SS = Seconds
Default	Timestamp of the current peak power consumption.

cfgServerCumulativePowerConsumption (Read Only)

Table 297. Details of cfgServerCumulativePowerConsumption

Description	Displays the cumulative power consumption.
Legal Values	Not applicable
Default	Cumulative power consumption.

cfgServerCumulativePowerConsumptionTimeStamp (Read Only)

Table 298. Details of cfgServerCumulativePowerConsumptionTimeStamp

Description	Displays the timestamp of the cumulative power consumption.
Legal Values	A string of up to 32 characters. Time in the format: DD MM Date HH:MM:SS YYYY where, ● DD = Day of the week ● MM= Month ● Date=Date ● YYYY = Year ● HH = hour ● MM=Minutes ● SS = Seconds
Default	Timestamp of the cumulative power consumption.

cfgServerCumulativePowerClear (Write Only)

Table 299. Details of cfgServerCumulativePowerClear

Description	Clears the `cfgServerCumulativePowerConsumption` and `cfgServerCumulativePowerConsumptionTimeStamp` values.
Legal Values	1
Default	None

cfgServerPowerPCIeAllocation (Read or Write)

Table 300. Details of cfgServerPowerPCIeAllocation

Description	Amount of power allocated to the PCIe cards. This object is applicable for iDRAC Enterprise only for specific Blade Servers and not for iDRAC on Rack and Tower Servers. You must have the Administrator privileges to modify the value for this object.
Legal Values	0 W: For platforms that do not support PCIe cards. 100 W — 500 W: For platforms that support PCIe cards.
Default	0: For platforms that do not support PCIe cards. 500 W: For platforms that support PCIe cards.

cfgServerPowerSupply

This group contains information related to the power supplies.

The `cfgServerPowerSupply` object group is applicable only for iDRAC on Rack and Tower Servers and not for iDRAC Enterprise on Blade Servers.

NOTE: The `getconfig` subcommand always shows eight `cfgServerPowerSupply` indexes, even if two power supplies are installed in the system or the system supports a maximum of two PSUs. For the uninstalled and unsupported units, all the objects in the `cfgServerPowerSupply` group displays a value of `0`.

The following sections provide information about the objects in the `cfgServerPowerSupply` group.

cfgServerPowerSupplyIndex

Table 301. Details of cfgServerPowerSupplyIndex

Description	Specifies index of the PSU. **NOTE:** Indexes 1–8 are supported to support up to 8 PSUs. If any PSU is not present then `cfgServerPowerSupplyOnlineStatus` does not exist and for all the other properties, it is 0.
Legal Values	Integer 1–8
Default	None

cfgServerPowerSupplyMaxInputPower (Read Only)

Table 302. Details of cfgServerPowerSupplyMaxInputPower

Description	Displays the AC input rated power in Watts.
Legal Values	A string of up to 32 characters.
Default	0

cfgServerPowerSupplyMaxOutputPower (Read Only)

Table 303. Details of cfgServerPowerSupplyMaxOutputPower

Description	Displays the AC output rated power in Watts.
Legal Values	A string of up to 32 characters.
Default	0

cfgServerPowerSupplyOnlineStatus (Read Only)

Table 304. Details of cfgServerPowerSupplyOnlineStatus

Description	Displays the status of the PSU.
Legal Values	• 0 — Present • 1 — Absent • 2 — Failure • 3 — Predictive failure
Default	0 — Present

cfgServerPowerSupplyFwVer (Read Only)

Table 305. Details of cfgServerPowerSupplyFwVer

Description	Displays the firmware version of the PSU, in the format x.xx.xxx.
Legal Values	A string up to 8 characters.
Default	Null

cfgServerPowerSupplyCurrentDraw (Read Only)

Table 306. Details of cfgServerPowerSupplyCurrentDraw

Description	Displays the instantaneous current consumption in 0.1 amps.
Legal Values	A string of up to 32 characters.
Default	0

cfgServerPowerSupplyType

Table 307. Details of cfgServerPowerSupplyType

Description	Displays whether the power supply is AC or DC.
Legal Values	A string of up to 32 characters.
Default	0

cfgIPv6LanNetworking

This group is used to configure the IPv6 over LAN networking capabilities.

Use this object with the `config` or `getconfig` subcommands.

To use this object property, you must have Chassis Configuration Administrator privilege.

NOTE: To apply this setting, use the `-m` option.

The following sections provide information about the objects in the `cfgIPv6LanNetworking` group.

cfgIPv6Enable (Read or Write)

Table 308. Details of cfgIPv6Enable attribute

Description	Enables or disables `iDRAC IPv6` stack. Enables or disables CMC IPv6 stack.
Legal Values	• `1` (TRUE) • `0` (FALSE)
Default	0

cfgIPv6Address1 (Read or Write)

Table 309. Details of cfgIPv6Address1

Description	Specifies iDRAC IPv6 address. Specifies CMC IPv6 address.
Legal Values	String representing a valid IPv6 entry.
Default	:

cfgIPv6Gateway (Read or Write)

Table 310. Details of cfgIPv6Gateway attribute

Description	iDRAC gateway IPv6 address. CMC gateway IPv6 address. **NOTE:** This property is used only if `cfgIPv6AutoConfig` is set to `0` (false).
Legal Values	Specifies string representing a valid IPv6 entry.
Default	" :: "

cfgIPv6AutoConfig (Read or Write)

Table 311. Details of cfgIPv6AutoConfig attribute

Description	Enables or disables the `IPv6 Auto Configuration` option. **NOTE:** If this value is set to `0`, the iDRACCMC disables auto configuration and statically assigns IPv6 addresses. If this value is set to `1`, the iDRACCMC obtains address and route information using stateless `auto configuration` and `DHCPv6`. **NOTE:** The iDRACCMC uses its MAC address for its DUID (DUID-LL) when communicating with a DHCPv6 server.
Legal Values	• `1` (TRUE) • `0` (FALSE)
Default	`0` `1`

cfgIPv6PrefixLength (Read or Write)

Table 312. Details of cfgIPv6PrefixLength attribute

Description	Specifies the prefix length for IPv6 address. Specifies the prefix length for IPv6 address. **NOTE:** • This property is used only if `cfgIPv6AutoConfig` is set to `0`(false) • This property can be configured even when `cfgIPv6AutoConfig` is enabled.
Legal Values	1–128

Table 312. Details of cfgIPv6PrefixLength attribute (continued)

	0–128
Default	64

cfgIPv6LinkLocalAddress (Read Only)

Table 313. Details of cfgIPv6LinkLocalAddress

Description	The iDRAC IPv6 link local address.
Legal Values	Specifies a string representing a valid IPv6 entry.
Default	:

cfgIPv6Address2 (Read Only)

Table 314. Details of cfgIPv6Address2

Description	The iDRAC IPv6-second address.
Legal Values	A string representing a valid IPv6 entry.
Default	:

cfgIPv6Address3 (Read Only)

Table 315. Details of cfgIPv6Address3

Description	The iDRAC IPv6 third address.
Legal Values	String representing a valid IPv6 entry.
Default	:

cfgIPv6Address4 (Read Only)

Table 316. Details of cfgIPv6Address4

Description	The iDRAC IPv6 fourth address.
Legal Values	String representing a valid IPv6 entry.
Default	:

cfgIPv6Address5 (Read Only)

Table 317. Details of cfgIPv6Address5

Description	The iDRAC IPv6 fifth address.
Legal Values	String representing a valid IPv6 entry.

Table 317. Details of cfgIPv6Address5 (continued)

Default	:

cfgIPv6Address6 (Read Only)

Table 318. Details of cfgIPv6Address6

Description	The iDRAC IPv6 sixth address.
Legal Values	String representing a valid IPv6 entry.
Default	:

cfgIPv6Address7 (Read Only)

Table 319. Details of cfgIPv6Address7

Description	The iDRAC IPv6 seventh address.
Legal Values	String representing a valid IPv6 entry.
Default	:

cfgIPv6Address8 (Read Only)

Table 320. Details of cfgIPv6Address8

Description	The iDRAC IPv6 eighth address.
Legal Values	String representing a valid IPv6 entry.
Default	:

cfgIPv6Address9 (Read Only)

Table 321. Details of cfgIPv6Address9

Description	The iDRAC IPv6 ninth address.
Legal Values	String representing a valid IPv6 entry.
Default	:

cfgIPv6Address10 (Read Only)

Table 322. Details of cfgIPv6Address10

Description	The iDRAC IPv6 tenth address.
Legal Values	String representing a valid IPv6 entry.
Default	:

cfgIPv6Address11 (Read Only)

Table 323. Details of cfgIPv6Address11

Description	The iDRAC IPv6 eleventh address.
Legal Values	String representing a valid IPv6 entry.
Default	:

cfgIPv6Address12 (Read Only)

Table 324. Details of cfgIPv6Address12

Description	The iDRAC IPv6 twelfth address.
Legal Values	String representing a valid IPv6 entry.
Default	:

cfgIPv6Address13 (Read Only)

Table 325. Details of cfgIPv6Address13

Description	The iDRAC IPv6 thirteenth address.
Legal Values	String representing a valid IPv6 entry.
Default	:

cfgIPv6Address14 (Read Only)

Table 326. Details of cfgIPv6Address14

Description	The iDRAC IPv6 fourteenth address.
Legal Values	String representing a valid IPv6 entry.
Default	:

cfgIPv6Address15 (Read Only)

Table 327. Details of cfgIPv6Address15

Description	The iDRAC IPv6 fifteenth address.
Legal Values	String representing a valid IPv6 entry.
Default	:

cfgIPv6DNSServersFromDHCP6 (Read or Write)

Table 328. Details of cfgIPv6DNSServersFromDHCP6 attribute

Description	Specifies whether `cfgIPv6DNSServer1` and `cfgIPv6DNSServer2` are `static` or `DHCP IPv6 addresses`. **NOTE:** This property is used only if `cfgIPv6AutoConfig` is set to `1`(true).
Legal Values	`1` (TRUE) `0` (FALSE)
Default	`0` `1`

cfgIPv6DNSServer1 (Read or Write)

Table 329. Details of cfgIPv6DNSServer1 attribute

Description	Specifies the IPv6 DNS server address. **NOTE:** This property is used only if `cfgIPv6DNSServersFromDHCP6` is set to `0` (false).
Legal Values	A string representing a valid IPv6 entry. For example, `2001:DB8:1234:5678:9ABC:DE11:C00C:BEEF`
Default	" :: "

cfgIpv6StaticLanNetworking

This group is used to configure the IPv6 Static over LAN networking capabilities.

cfgIPv6StaticEnable (Read or Write)

Table 330. Details of cfgIPv6StaticEnable

Description	Enables or disables the static IPv6 stack.
Legal Values	• `0` — Disabled • `1` — Enabled
Default	`0` — Disabled

NOTE: If this object is modified, then the object `cfgIPv6Enable` is also modified.

cfgIPv6StaticAddress1 (Read or Write)

Table 331. Details of cfgIPv6StaticAddress1

Description	Returns or sets the static IPv6 address1. **NOTE:** Only set the current IPv4 address if `cfgNicUseDhcp` is set to 0 (false).

Table 331. Details of cfgIPv6StaticAddress1 (continued)

Legal Values	Any IPv6 address
Default	

cfgIPv6StaticGateway (Read or Write)

Table 332. Details of cfgIPv6StaticGateway

Description	Returns or sets gateway static IPv6 address.
Legal Values	Any IPv6 address
Default	

cfgIPv6StaticPrefixLength (Read or Write)

Table 333. Details of cfgIPv6StaticPrefixLength

Description	The prefix length for static IPv6 address 1.
Legal Values	0–128
Default	64

cfgIPv6StaticAutoConfig (Read/Write)

Table 334. Details of cfgIPv6StaticAutoConfig

Description	Enables or disables the static IPv6 AutoConfig option.
Legal Values	• `0` — Disabled • `1` — Enabled
Default	`1` — Enabled

NOTE: If this object is modified, then the object `cfgIPv6Autoconfig` is also modified.

cfgIPv6StaticDNSServersFromDHCP6 (Read or Write)

Table 335. Details of cfgIPv6StaticDNSServersFromDHCP6

Description	Specifies the DNS server static IP addresses.
Legal Values	• `0` — DNS Server must be configured as static. • `1` — The device will get the DNS servers from DHCPv6.
Default	`0` — Disabled

cfgIPv6StaticDNSServer1 (Read or Write)

Table 336. Details of cfgIPv6StaticDNSServer1

Description	Specifies the DNS server 1 static IPv6 address.
Legal Values	Any IPv6 Address
Default	

cfgIPv6StaticDNSServer2 (Read or Write)

Table 337. Details of cfgIPv6StaticDNSServer2

Description	Specifies the DNS server 2 static IPv6 address.
Legal Values	Any IPv6 address
Default	

cfgIPv6DNSServer2 (Read or Write)

Table 338. Details of cfgIPv6DNSServer2 attribute

Description	Specifies the IPv6 DNS server address. **NOTE:** This property is only valid if `cfgIPv6DNSServersFromDHCP6` is set to `0` (false).
Legal Values	A string representing a valid IPv6 entry. For example, `2001:DB8:1234:5678:9ABC:DE11:C00C:BEEF`
Default	" :: "

Example

```
$ racadm getconfig -g cfgIPv6LanNetworking
```

```
cfgIPv6Enable=1
```

```
cfgIPv6AutoConfig=1
```

```
cfgIPv6Address=::
```

```
cfgIPv6PrefixLength=64
```

```
cfgIPv6Gateway=::
```

```
cfgIPv6DNSServersFromDHCP6=1
```

```
cfgIPv6DNSServer1=::
```

```
cfgIPv6DNSServer2=::
```

If both IPv4 and IPv6 are enabled on the iDRACCMC, IPv6 DNS servers take priority. The order of preference for DNS servers is:

- cfgIPv6DNSServer1
- cfgIPv6DNSServer2
- cfgDNSServer1
- cfgDNSServer2

cfgIPv6URL

This group specifies properties used to configure iDRAC IPv6 URL.

The following sections provide information about the objects in the cfgIPv6URL group.

cfgIPv6URLstring (Read Only)

Table 339. Details of cfgIPv6URLstring

Description	The iDRAC IPv6 URL.
Legal Values	A string of up to 80 characters.
Default	<blank>

cfgIpmiSerial

This group specifies properties used to configure the IPMI serial interface of the BMC.

It is applicable only for iDRAC on Rack and Tower Servers and not for iDRAC Enterprise on Blade Servers.

cfgIpmiSerialBaudRate (Read or Write)

Table 340. Details of cfgIpmiSerialBaudRate

Description	Specifies the baud rate for a serial connection over IPMI.
Legal Values	9600, 19200, 57600, 115200
Default	57600

cfgIpmiSerialChanPrivLimit (Read or Write)

Table 341. Details of cfgIpmiSerialChanPrivLimit

Description	Specifies the maximum privilege level allowed on the IPMI serial channel.
Legal Values	• 2 (User) • 3 (Operator) • 4 (Administrator)
Default	4

cfgIpmiSerialConnectionMode (Read or Write)

Table 342. Details of cfgIpmiSerialConnectionMode

Description	When the iDRAC `cfgSerialConsoleEnable` property is set to `0`(disabled), the iDRAC serial port becomes the IPMI serial port. This property determines the IPMI defined mode of the serial port. In Basic mode, the port uses binary data with the intent of communicating with an application program on the serial client. In Terminal mode, the port assumes that a dumb ASCII terminal is connected and allows simple commands to be entered.
Legal Values	• `0`(Terminal) • `1`(Basic)
Default	1

cfgIpmiSerialDeleteControl (Read or Write)

Table 343. Details of cfgIpmiSerialDeleteControl

Description	Enables or disables delete control on the IPMI serial interface.
Legal Values	• `0` (FALSE) • `1` (TRUE)
Default	0

cfgIpmiSerialEchoControl (Read or Write)

Table 344. Details of cfgIpmiSerialEchoControl

Description	Enables or disables echo control on the IPMI serial interface.
Legal Values	• `0`(FALSE) • `1` (TRUE)
Default	1

cfgIpmiSerialFlowControl (Read or Write)

Table 345. Details of cfgIpmiSerialFlowControl

Description	Specifies the flow control setting for the IPMI serial port.
Legal Values	• `0` (None) • `1` (CTS or RTS)
Default	1

cfgIpmiSerialHandshakeControl (Read or Write)

Table 346. Details of cfgIpmiSerialHandshakeControl

Description	Enables or disables the IPMI terminal mode handshake control.
Legal Values	• `0`(FALSE)

Table 346. Details of cfgIpmiSerialHandshakeControl (continued)

	• 1 (TRUE)
Default	1

cfgIpmiSerialNewLineSequence (Read or Write)

Table 347. Details of cfgIpmiSerialNewLineSequence

Description	Specifies the new line sequence specification for the IPMI serial interface.
Legal Values	• 0 — None • 1 — CR-LF • 2 — NULL • 3 — CR • 4 — LF-CR • 5 — LF
Default	1

cfgIpmiSerialLineEdit (Read or Write)

Table 348. Details of cfgIpmiSerialLineEdit

Description	Enables or disables line editing on the IPMI serial interface.
Legal Values	• 0(FALSE) • 1(TRUE)
Default	1

cfgIpmiSerialInputNewLineSequence (Read or Write)

Table 349. Details of cfgIpmiSerialInputNewLineSequence

Description	Specifies the input new line sequence specification for the IPMI serial interface.
Legal Values	• 1 — ENTER • 2 — NULL
Default	1

cfgSmartCard

This group specifies properties used to support access to iDRAC using a smart card.

The following sections provide information about the objects in the `cfgSmartCard` group.

cfgSmartCardLogonEnable (Read or Write)

Table 350. Details of cfgSmartCardLogonEnable

Description	To iDRAC using a smart card, enable or disable with Remote RACADM support for access.

Table 350. Details of cfgSmartCardLogonEnable (continued)

	NOTE: Enabling with remote RACADM is only applicable for iDRAC on Rack and Tower Servers.
Legal Values	• 0 (Disabled) • 1 (Enabled) • 2 (Enabled with Remote RACADM) — It is not applicable for iDRAC Enterprise on Blade Servers.
Default	0

cfgSmartCardCRLEnable (Read or Write)

Table 351. Details of cfgSmartCardCRLEnable

Description	Enables or disables the Certificate Revocation List (CRL). This object is applicable only for iDRAC on Rack and Tower Servers and not for iDRAC Enterprise on Blade Servers.
Legal Values	• 1 (TRUE) • 0 (FALSE)
Default	0

cfgNetTuning

This group enables users to configure the advanced network interface parameters for the RAC NIC. When configured, the updated settings may take up to a minute to become active.

This group enables users to configure the advanced network interface parameters. When configured, the updated settings may take up to a minute to become active.

NOTE: This group is applicable only for iDRAC on Rack and Tower Servers and not for iDRAC Enterprise on Blade Servers.

CAUTION: Use extra precaution when modifying properties in this group. Inappropriate modification of the properties in this group can result in your RAC NIC become inoperable.

The following sections provide information about the objects in the `cfgNetTuning` group.

cfgNetTuningNicAutoneg (Read or Write)

Table 352. Details of cfgNetTuningNicAutoneg attribute

Description	Enables auto negotiation of physical link speed and duplex. If enabled, auto negotiation takes priority over other values set in this group.
Legal Values	• 0 = Auto Negotiation is Disabled • 1 = Auto Negotiation is Enabled
Default	1

Example

```
racadm getconfig -g cfgNetTuning
```

```
cfgNetTuningNicSpeed=100
cfgNetTuningNicFullDuplex=1
cfgNetTuningNicMtu=1500
cfgNetTuningNicAutoneg=1
```

cfgNetTuningNic100MB (Read or Write)

Table 353. Details of cfgNetTuningNic100MB

Description	Specifies the speed for iDRAC NIC. **NOTE:** To set this property: • iDRAC NIC selection must be set to `Dedicated` mode. • iDRAC NIC Auto negotiation must be disabled. • iDRAC IPv4 must be enabled. • iDRAC IPv4 DHCP must be enabled. • iDRAC IPv6 must be enabled. • iDRAC IPv6 auto configuration must be enabled.
Legal Values	• `0` (10 MBit) • `1` (100 MBit) • `2` (1000 MBit) **NOTE:** You cannot manually set the Network Speed to 1000 MBit. This option is available only if `cfgNetTuningNicAutoNeg` is set to `1` (Enabled).
Default	1

cfgNetTuningNicFullDuplex (Read or Write)

Table 354. Details of cfgNetTuningNicFullDuplex attribute

Description	Specifies the duplex setting for the NIC. This property is used only if the`cfgNetTuningNicAutoNeg` is set to `0` (disabled).
Legal Values	• `0` (Half Duplex) • `1` (Full Duplex)
Default	1

cfgNetTuningNicMtu (Read or Write)

Table 355. Details of cfgNetTuningNicMtu attribute

Description	Indicated the maximum size of units in bytes transmitted by NIC.
Legal Values	576–1500
Default	1500

NOTE: IPv6 requires a minimum MTU of 1280. If IPv6 is enabled, and `cfgNetTuningMtu` is set to a lower value, the CMC uses an MTU of 1280.

cfgSensorRedundancy

This group is used to set the power supply redundancy.

The following sections provide information about the objects in the `cfgSensorRedundancy` group.

This group is applicable only for iDRAC on Rack and Tower Servers and not for iDRAC Enterprise on Blade Servers.

cfgSensorRedundancyIndex (Read Only)

Table 356. Details of cfgSensorRedundancyIndex

Description	Specifies index for the sensor redundancy group being read. Only power supply redundancy is supported.
Legal Values	1
Default	None

cfgSensorRedundancyPolicy (Read or Write)

Table 357. Details of cfgSensorRedundancyPolicy

Description	Sets the power supply redundancy policy.
Legal Values	• 2 — N/A, for systems that are not supported • 3 — Non Redundant • 4–1+1 Redundant • 4–2+1 Redundant • 16–2+2 Redundant
Default	Any legal value at that particular execution instance.

cfgSensorRedundancyCapabilities (Read Only)

Table 358. Details of cfgSensorRedundancyCapabilities

Description	Returns the redundancy capabilities in the form of a bitmask. This bitmask allows the user to know which values can be set for `cfgSensorRedundancyPolicy`.
Legal Values	A bit mask. More than 1 bit can be set at a time to indicate multiple redundancy support. • 0- N/A, for systems that are not supported • 1- Non-Redundant • 2- 1+1 — Redundant • 4- 2+1 — Redundant • 8- 2+2 — Redundant
Default	0

cfgSensorRedundancyStatus (Read Only)

Table 359. Details of cfgSensorRedundancyStatus

Description	Indicates the redundancy status. The status is N/A on platforms that do not support the power supply sensor redundancy.
Legal Values	String: • N/A • Full • Lost • Degraded
Default	None

cfgVFlashSD

This group is used to configure the properties for the Virtual Flash SD card.

NOTE: If the vFlash card is present but is not enabled, the query for any property under this group displays:

```
ERROR: vFlash is not enabled.
```

To view the properties of this group, enable the vFlash using the command:

```
racadm config -g cfgvFlashSD -o cfgvFlashSDEnable 1
```

The following sections provide information about the objects in the `cfgVFlashSD` group.

cfgVFlashSDInitialized (Read Only)

Table 360. Details of cfgVFlashSDInitialized

Description	Displays whether an SD card is initialized.
Legal Values	• 0 • 1
Default	None

cfgVFlashSDEnable (Read or Write)

Table 361. Details of cfgVFlashSDEnable

Description	Enables or disables the vFlash SD card. **NOTE:** Disabling `vFlashPartition` by setting `cfgVFlashSDEnable` to `0` does not require a license.
Legal Values	• 0 (Disable) • 1 (Enable)
Default	1

cfgVFlashSDSize (Read Only)

Table 362. Details of cfgVFlashSDSize

Description	Displays the size of the vFlash SD card in megabytes (MB).
Legal Values	A string of up to 64 characters.
Default	`<card size>`

cfgVFlashSDLicensed (Read Only)

Table 363. Details of cfgVFlashSDLicensed

Description	Displays whether an SD card or vFlash SD card is inserted. The vFlash SD card supports the new enhanced vFlash features and the SD card supports only the limited vFlash features.

Table 363. Details of cfgVFlashSDLicensed (continued)

Legal Values	• 0(SD card is inserted) • 1(vFlash SD card is inserted)
Default	None

cfgVFlashSDAvailableSize (Read Only)

Table 364. Details of cfgVFlashSDAvailableSize

Description	Displays the available memory (in MB) on the vFlash SD card that can be used to create new partitions.
Legal Values	A string of up to 64 characters.
Default	If the card is not initialized, default is 0. If initialized, displays the unused memory on the card.

cfgVFlashSDHealth (Read Only)

Table 365. Details of cfgVFlashSDHealth

Description	Displays the current health status of the vFlash SD card.
Legal Values	String: • OK • Warning • Critical • Unknown
Default	OK

cfgVFlashSDWriteProtect (Read Only)

Table 366. Details of cfgVFlashSDWriteProtect

Description	Displays whether the physical WriteProtect latch on the vFlash SD card is enabled or disabled.
Legal Values	• 0 (vFlash is not write-protected) • 1 (vFlash is write-protected)
Default	None

cfgVFlashPartition

This group is used to configure properties for individual partitions on the vFlash SD Card. Up to 16 partitions are supported, indexed from 1 to 16.

NOTE: For SD cards, the index value is limited to 1 because only a single partition of size 256MB is allowed.

The following sections provide information about the objects in the `cfgVFlashPartition` group.

cfgVFlashPartitionIndex (Read Only)

Table 367. Details of cfgVFlashPartitionIndex

Description	The index value of the partition.
Legal Values	Integer 1–16
Default	None

cfgVFlashPartitionSize (Read Only)

Table 368. Details of cfgVFlashPartitionSize

Description	Displays the size of the partition.
Legal Values	1 MB to 4 GB
Default	None

cfgVFlashPartitionEmulationType (Read or Write)

Table 369. Details of cfgVFlashPartitionEmulationType

Description	View or modify the emulation type for the partition.
Legal Values	String: ● HDD ● Floppy ● CD-DVD
Default	None

cfgVFlashPartitionFlashOSVolLabel (Read Only)

Table 370. Details of cfgVFlashPartitionFlashOSVolLabel

Description	Displays the label for the partition that is visible to the operating system.
Legal Values	An alphanumeric string of up to six characters.
Default	None

cfgVFlashPartitionFormatType (Read Only)

Table 371. Details of cfgVFlashPartitionFormatType

Description	Displays the format type of the partition.
Legal Values	String: ● FAT16 ● FAT32 ● EXT2

Table 371. Details of cfgVFlashPartitionFormatType (continued)

	• EXT3 • CD • RAW
Default	None

cfgVFlashPartitionAccessType (Read or Write)

Table 372. Details of cfgVFlashPartitionAccessType

Description	Indicates the partition access permissions. It configures the access type to read-write.
Legal Values	• 0 (Read Only) • 1 (Read-Write)
Default	0

cfgVFlashPartitionAttachState (Read or Write)

Table 373. Details of cfgVFlashPartitionAttachState

Description	View or modify the partition to attached or detached. **NOTE:** Detaching the vFlashPartition by setting the `cfgVFlashPartitionAttachState` to `0` does not require a license.
Legal Values	• 1 — Attached • 0 — Detached
Default	0 — Detached

cfgLogging

This group contains parameters to enable or disable the OEM event log filtering.

The following section provide information about the objects in the `cfgLogging` group:

cfgLoggingSELOEMEventFilterEnable (Read or Write)

Table 374. Details of cfgLoggingSELOEMEventFilterEnable

Description	Enables or disables the SEL Log filtering.
Legal Values	• 0 (Disable) • 1(Enable)
Default	0

cfgRacSecurity

This group is used to configure settings related to CMC SSL certificate signing request (CSR) feature. The properties in this group must be configured before generating a CSR. Use this object with the `config` or `getconfig` subcommands. To use this object property, you must have the Chassis Configuration Administrator privilege.

For more information about generating certificate signing requests, see the subcommand `sslcsrgen`.

For the country code, go to the link **http://www.iso.org/iso/country_codes/iso_3166_code_lists.htm**

The following sections provide information about the objects in the `cfgRacSecurity` group.

cfgRacSecCsrCommonName (Read or Write)

Table 375. Details of cfgRacSecCsrCommonName attribute

Description	Specifies the CSR Common Name (CN) that must be an IP or iDRACCMC name as given in the certificate.
Legal Values	A string of up to 64 characters.
Default	`<blank>`

cfgRacSecCsrOrganizationName (Read or Write)

Table 376. Details of cfgRacSecCsrOrganizationName attribute

Description	Specifies the CSR Organization Name (O).
Legal Values	A string of up to 64 characters.
Default	`<blank>`

cfgRacSecCsrOrganizationUnit (Read or Write)

Table 377. Details of cfgRacSecCsrOrganizationUnit attribute

Description	Specifies the CSR Organization Unit (OU).
Legal Values	A string of up to 64 characters.
Default	`<blank>`

cfgRacSecCsrLocalityName (Read or Write)

Table 378. Details of cfgRacSecCsrLocalityName attribute

Description	Specifies the CSR Locality (L).
Legal Values	A string of up to 128 characters.
Default	`<blank>`

cfgRacSecCsrStateName (Read or Write)

Table 379. Details of cfgRacSecCsrStateName attribute

Description	Specifies the CSR State Name (S).
Legal Values	A string of up to 128 characters.
Default	`<blank>`

cfgRacSecCsrCountryCode (Read/Write)

Table 380. Details of cfgRacSecCsrCountryCode attribute

Description	Specifies the CSR Country Code (CC).
Legal Values	A string of 2 alphabet country code.
Default	US

cfgRacSecCsrEmailAddr (Read or Write)

Table 381. Details of cfgRacSecCsrEmailAddr attribute

Description	Specifies the CSR email address.
Legal Values	A string of up to 64 characters.
Default	`<blank>`

Example

```
racadm config -g cfgRacSecurity
```

```
cfgRacSecCsrKeySize=1024
cfgRacSecCommonName=
cfgRacSecOrganizationName=
cfgRacSecOrganizationUnit=
cfgRacSecLocalityName=
cfgRacSecStateName=
cfgRacSecCountryCode=
cfgRacSecEmailAddr=
```

cfgRacSecCsrKeySize (Read or Write)

Table 382. Details of cfgRacSecCsrKeySize

Description	Specifies the SSL asymmetric key size for the CSRs.
Legal Values	1024, 2048
Default	2048

4

Database Objects With Get and Set Commands

This chapter provides the database groups and objects that must be used with the `get` or `set` subcommands. When using the objects, they must begin with FQDD or FQDD alias.

The set operations for iDRAC, Lifecycle Controller and system objects do not require server restart. However, the set operations for NIC and BIOS objects are staged and job creation and server restart is required to apply and commit the pending values.

NOTE:

- While entering an attribute value that is more than one word, ensure that you enclose the attribute value within single quotation marks in the set command.

  Example:

  ```
  racadm>>set system.thermalsettings.ThermalProfile 'Maximum performance'
  racadm set system.thermalsettings.ThermalProfile 'Maximum performance'
  [Key=system.Embedded.1#ThermalSettings.1]
  Object value modified successfully
  ```

- The staged configuration has the associated pending value in the output of the get operation, after it is configured successfully.
- The object values in the BIOS and NIC groups are case-sensitive.
- For NIC objects, the definition of the key format is: `Key = <Device Class>.<Locator>.<Device Number>–<Port Number>[-<Partition Number>]#GroupName”` where,
  - Device Class: NIC
  - Locator: Integrated, Slot, Mezzanine or Embedded

    Example:

    ```
    $racadm get NIC.NICConfig
    NIC.NICConfig.1 [Key=NIC.Integrated.1-1#NICConfig]
    NIC.NICConfig.2 [Key=NIC.Integrated.1-2#NICConfig]
    NIC.NICConfig.3 [Key=NIC.Integrated.1-3#NICConfig]
    NIC.NICConfig.4 [Key=NIC.Integrated.1-4#NICConfig]
    ```

- The link between the NIC instance and the corresponding key varies from system to system depending on the system configuration.
- The command `racadm help` provides a list of all the attributes along with the description.
- To view the help details of group level, enter the following command: `racadm help <group name>`

  Example:

  ```
  $racadm help NIC.NICConfig
  NICConfig       -- (null)
  These are the objects supported by the group
  ------------------------------------------------------------------------------
  BannerMessageTimeout      -- Specify the number of seconds that the OptionROM banner
  is displayed during POST.
  Usage                     -- Values from 0 - 14
  Required License          -- RACADM
  Dependency                -- None

  BootOptionROM             -- Controls the enablement of legacy Boot Protocols in the
  Option ROM.
  Usage                     -- Enabled; Disabled
  ```

```
Required License          -- RACADM
Dependency                -- None

BootRetryCnt              -- Specify the number of retries to attempt in case of boot
failure.
Usage                     -- NoRetry - 0;1Retry - 1; 2Retries - 2;3Retries -
3;4Retries - 4; 5Retries - 5;6Retries- 6; IndefiniteRetries, Default - NoRetry
Required License          -- RACADM
Dependency                -- None
```

```
BootStrapType             -- Specify the boot strap method used to boot to the
operating system.
Usage                     -- AutoDetect - 0;BBS - 1; Int18h - 2; Int19h- 3; Default -
AutoDetect
Required License          -- RACADM
Dependency                -- None

HideSetupPrompt           -- Specifies whether to display or hide the legacy Option
ROM setup prompt during system Power On Self Test (POST).
Usage                     -- Enabled; Disabled; Default - Disabled
Required License          -- RACADM
Dependency                -- None

LegacyBootProto           -- Select a non-UEFI network boot protocol
Usage                     -- PXE; iSCSI; FCoE; NONE; iSCSIPrimary; iSCSISecondary
Required License          -- RACADM
Dependency                -- None
```

```
LnkSpeed                  -- Specifies the port speed used for the selected boot
protocol
Usage                     -- AutoNeg; 10Mbps Half; 10Mbps Full; 100Mbps Half; 100Mbps
Full
Required License          -- RACADM
Dependency                -- None

NumberVFAdvertised        -- The number of PCI Virtual Functions (VFs) to be
advertised on this port in non-NPAR mode.
Usage                     -- Values from 0 - 256, Default - 0
Required License          -- RACADM
Dependency                -- VLanMode has to be Enabled

VLanId                    -- Specifies the ID (tag) for the VLAN Mode. VLAN ID must
be in the range from 0 to 4095
Usage                     -- Values from 1 - 4095
Required License          -- RACADM
Dependency                -- VLanMode has to be Enabled
```

```
VLanMode                  -- Virtual LAN mode enables use of a VLAN tag to be used by
[vendor defined boot protocols]
Usage                     -- Enabled; Disabled
Required License          -- RACADM
Dependency                -- None

WakeOnLan                 -- Enables the server to be powered on using an in-band
magic packet
Usage                     -- Enabled; Disabled
Required License          -- RACADM
Dependency                -- None

WakeOnLanLnkSpeed         -- Select the port speed used for Wake on LAN mode
Usage                     -- AutoNeg; 10Mbps Half; 10Mbps Full; 100Mbps Half; 100Mbps
Full
Required License          -- RACADM
Dependency                -- None
```

- To view the help details of attribute level, enter the following command: `racadm help <attribute name>`

Example:

```
/tmp # racadm help NIC.NICConfig.WakeOnLanLnkSpeed
WakeOnLanLnkSpeed -- Select the port speed used for Wake on LAN mode
Usage -- AutoNeg; 10Mbps Half; 10Mbps Full; 100Mbps Half; 100Mbps Full
Required License -- RACADM
Dependency -- None/tmp #
```

- The get and set commands for BIOS and NIC provide the list of attributes on the basis of the system configuration, BIOS version used, hardware, and so on.

Topics:

- System.Backplane
- System.ChassisControl
- System.ChassisInfo
- System.OpenIDConnectServer
- System.QuickSync
- System.LCD
- System.Location
- System.OpenIDConnectServer
- System.Power
- System.Power.Supply
- System.ServerOS
- System.ThermalSettings
- System.ThermalConfig
- LifecycleController.LCAttributes
- iDRAC.ActiveDirectory
- iDRAC.ADGroup
- iDRAC.ASRConfig
- iDRAC.AutoOSLock
- iDRAC.EmailAlert
- iDRAC.IMC
- iDRAC.Info
- iDRAC.IOIDOpt
- iDRAC.IPBlocking
- iDRAC.IPMILan
- iDRAC.IPMISerial
- iDRAC.IPMISOL
- iDRAC.IPv4
- iDRAC.IPv4Static
- iDRAC.IPv6
- iDRAC.IPv6Static
- iDRAC.IPv6URL
- iDRAC.LDAP
- iDRAC.LDAPRoleGroup
- iDRAC.LocalSecurity
- iDRAC.Logging
- iDRAC.NIC
- iDRAC.NICStatic
- iDRAC.NTPConfigGroup
- iDRAC.OS-BMC
- iDRAC.Racadm
- iDRAC.Redfish
- iDRAC.Redfisheventing
- iDRAC.RemoteHosts
- iDRAC.RFS
- iDRAC.RSM
- iDRAC.SecureDefaultPassword
- iDRAC.Security

- iDRAC.Serial
- iDRAC.SerialRedirection
- iDRAC.serverboot
- iDRAC.ServiceModule
- iDRAC.SmartCard
- iDRAC.SNMP
- iDRAC.SNMP.Alert
- iDRAC.SSH
- iDRAC.SupportAssist
- iDRAC.SysLog
- iDRAC.Telnet
- iDRAC.Time
- iDRAC.Tuning
- iDRAC.Update
- iDRAC.USB
- iDRAC.UserDomain
- iDRAC.Users
- iDRAC.vflashpartition
- iDRAC.vflashsd
- iDRAC.VirtualConsole
- iDRAC.VirtualMedia
- iDRAC.VNCServer
- iDRAC.WebServer
- BIOS.BiosBootSettings
- BIOS.EmbServerMgmt
- BIOS.IntegratedDevices
- BIOS.MemSettings
- BIOS.MiscSettings
- BIOS.NetworkSettings
- BIOS.OneTimeBoot
- BIOS.ProcSettings
- BIOS.ProxyAttributes
- BIOS.PxeDev1Settings
- BIOS.SataSettings
- BIOS.SerialCommSettings
- BIOS.SlotDisablement
- BIOS.SysInformation
- BIOS.SysProfileSettings
- BIOS.SysSecurity
- BIOS.UefiBootSettings
- FC.FCDevice
- FC.FCTarget
- FC.HBAConfig
- FC.PortConfig
- NIC.ConfigureFormn
- NIC.DCBSettings
- NIC.DeviceLevelConfig
- NIC.FCOECapabilities
- NIC.FCoEConfiguration
- NIC.FCoEGenParams
- NIC.FrmwImgMenu
- NIC.GlobalBandwidthAllocation
- NIC.IscsiFirstTgtParams
- NIC.IscsiGenParams
- NIC.IscsiInitiatorParams
- NIC.IscsiSecondaryDeviceParams

- NIC.IscsiSecondTgtParams
- NIC.NICConfig
- NIC.NICPartitioningConfig
- NIC.VndrConfigGroup
- NIC.VndrConfigPage
- Storage.Controller
- Storage.enclosure
- Storage.PhysicalDisk
- Storage.VirtualDisk

System.Backplane

The objects in this group manage the backplane.

System.Backplane.BackplaneBusMode (Read Only)

Table 383. Details of System.Backplane.BackplaneBusMode

Description	Indicates the backplane Serial General Purpose Input or Output (SGPIO) mode.
Legal Values	• 0 — Unknown • 1 — I2C • 2 — SGPIO
Default Value	1 — I2C
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ChassisControl

The objects in this group are applicable only to modular chassis such as Dell PowerEdge M1000e. To control the chassis related events, use this group.

System.ChassisControl.ChassisManagementMonitoring (Read or Write)

Table 384. Details of System.ChassisControl.ChassisManagementMonitoring

Description	Enables or disables the event forwarding from CMC.
Legal Values	• 0 — Disabled • 1 — Enabled
Default value	1 — Enabled
Write Privilege	Server Control
License Required	Base
Dependency	ChassisMangamentAt server object.

System.ChassisInfo

The objects in this group are applicable only to modular chassis such as Dell PowerEdge M1000e and Dell PowerEdge FX2. To obtain the chassis-specific information, use this group.

System.ChassisInfo.Model (Read Only)

Table 385. Details of System.ChassisInfo.Model

Description	Indicates the LCD string the user modifies.
Legal Values	String of up to 62 ASCII characters
Default Value	None
Write privilege	Not Applicable
License Required	Not Applicable
Dependency	None

System.ChassisInfo.Name (Read Only)

Table 386. Details of System.ChassisInfo.Name

Description	Provides the name of the chassis. For example: CMC-nobel01.
Legal Values	String of up to 62 ASCII characters
Default Value	None
Write Privilege	Not Applicable
License Required	Not Applicable
Dependency	None

System.ChassisInfo.ServiceTag (Read Only)

Table 387. Details of System.ChassisInfo.ServiceTag

Description	Provides the Service Tag of the chassis.
Legal Values	String of up to 62 ASCII characters
Default Value	None
Write Privilege	Not Applicable
License Required	Not Applicable
Dependency	None

System.OpenIDConnectServer

The objects in this group helps in configuration of SSO functionality.

System.OpenIDConnectServer.ClientToken (Read or Write)

Table 388. Details of System.OpenIDConnectServer.ClientToken attribute

Description	Indicates the Client Token.
Legal Values	String of up to 1024 ASCII characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	RACADM
Dependency	None

System.OpenIDConnectServer.ClientURI (Read or Write)

Table 389. Details ofSystem.OpenIDConnectServer.ClientURI attribute

Description	Indicates the Client URI.
Legal Values	String of up to 1024 ASCII characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	RACADM
Dependency	None

System.OpenIDConnectServer.DiscoveryURL (Read or Write)

Table 390. Details of iSystem.OpenIDConnectServer.DiscoveryURL attribute

Description	Indicates the discovery URL.
Legal Values	String of up to 1024 ASCII characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	RACADM
Dependency	None

System.OpenIDConnectServer.Enabled (Read or Write)

Table 391. Details of System.OpenIDConnectServer.Enabled attribute

Description	Indicates the discovery URL.
Legal Values	• 0-Disabled • 1-Enabled
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	RACADM

Table 391. Details of System.OpenIDConnectServer.Enabled attribute (continued)

Dependency	None

System.OpenIDConnectServer.HttpsCertificate (Read or Write)

Table 392. Details of System.OpenIDConnectServer.HttpsCertificate attribute

Description	Displays the HTTPS public certificate.
Legal Values	String of up to 2816 ASCII characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	RACADM
Dependency	None

System.OpenIDConnectServer.RegistrationDetails(Read or Write)

Table 393. Details of System.OpenIDConnectServer.RegistrationDetails attribute

Description	Indicates the registration details.
Legal Values	String of up to 1024 ASCII characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	RACADM
Dependency	None

System.OpenIDConnectServer.RegistrationStatus (Read or Write)

Table 394. Details of System.OpenIDConnectServer.RegistrationStatus attribute

Description	Indicates the registration status.
Legal Values	String of up to 1024 ASCII characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	RACADM
Dependency	None

System.OpenIDConnectServer.Name (Read or Write)

Table 395. Details of System.OpenIDConnectServer.Name attribute

Description	Indicates the server name.
Legal Values	String of up to 128 ASCII characters
Default Value	Not Applicable

Table 395. Details of System.OpenIDConnectServer.Name attribute (continued)

Write Privilege	Not Applicable
License Required	RACADM
Dependency	None

System.QuickSync

The objects in this group manage the configuration and recovery of QuickSync settings.

System.QuickSync.Access (Read or Write)

Table 396. Details of System.QuickSync.Access

Description	Configures the accessibility using Quick Sync on the server.
Legal Values	• 0 — Disabled • 1 — Read-only • 2 — Read-write
Default Value	2 — Read-write
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	To configure, the `System.QuickSync.Presence` property must indicate `Present`

System.QuickSync.InactivityTimeout (Read or Write)

Table 397. Details of System.QuickSync.InactivityTimeout

Description	Configures the inactivity timer (in seconds) for Quick Sync.
Legal Values	15 – 3600 seconds
Default Value	30 seconds
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	To configure, the `System.QuickSync.Presence` property must indicate `Present`

System.QuickSync.InactivityTimerEnable (Read or Write)

Table 398. Details of System.QuickSync.InactivityTimerEnable

Description	Enables or disables the inactivity timer for Quick Sync.
Legal Values	• 1 — Enabled • 0 — Disabled
Default Value	1 — Enabled

Table 398. Details of System.QuickSync.InactivityTimerEnable (continued)

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	To configure, the `System.QuickSync.Presence` property must indicate `Present`

System.QuickSync.Presence (Read or Write)

Table 399. Details of System.QuickSync.Presence

Description	Indicates the presence of Quick Sync feature in the server.
Legal Values	• 0— Not Supported • 1 — Absent • 2 — Present
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.LCD

This group enables you to manage the front panel LCD user string settings.

The following section provides information about the objects in the System.LCD group.

NOTE: The System.LCD `get` and `set` command works on iDRAC on Blade Server, even if the LCD is not present on the server.

NOTE: You can change the LCD group attributes for monolithic servers even if the LCD is not present on servers.

System.LCD.Configuration (Read or Write)

Table 400. Details of System.LCD.Configuration

Description	Current LCD configuration.
Legal Values	• `0` — User Defined • `1` — Model Name • `2` — None • `4` — iDRAC IPv4Address • `8` — iDRAC MAC Address • `16` — OS System Name • `32` — Service Tag • `64` — IPv6Address • `128` — Ambient Temperature • `256` — System Watts • `512` — Asset Tag
Default Value	`32` — Service Tag

Table 400. Details of System.LCD.Configuration (continued)

Write Privilege	Configure iDRAC and Configure User
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.LCD.vConsoleIndication (Read or Write)

Table 401. Details of System.LCD.vConsoleIndication

Description	Specifies the virtual console indication.
Legal Values	• Enabled • Disabled
Default Value	`Enabled`
Write Privilege	• Configure iDRAC • Configure User
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.LCD.CurrentDisplay (Read Only)

Table 402. Details of System.LCD.CurrentDisplay

Description	The string currently displayed on the LCD.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.lcd.FrontPanelLocking (Read or Write)

Table 403. Details of system.lcd.FrontPanelLocking attribute

Description	Sets LCD button interface to Full-Access, View-Only, or No access (Locked)
Legal Values	• 0 - Full Access • 1 - View Only • 2 - Locked
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	RACADM
Dependency	None

System.LCD.LCDUserString (Read or Write)

Table 404. Details of System.LCD.LCDUserString

Description	Indicates the LCD string set. **NOTE:** This property is deprecated from version 2.00.00.00. Use the System.LCD.UserDefinedString to perform the operation.
Legal Values	String of up to 62 ASCII characters
Default Value	0
Write Privilege	Not Applicable
License Required	Not Applicable
Dependency	Not Applicable

System.LCD.QualifierTemp (Read or Write)

Table 405. Details of System.LCD.QualifierTemp

Description	Specifies the ambient temperature qualifier.
Legal Values	• C • F
Default Value	C
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.LCD.QualifierWatt (Read or Write)

Table 406. Details of System.LCD.QualifierWatt

Description	Specifies the system Watt qualifier.
Legal Values	• Watts • BTU per hour
Default Value	Watts
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.LCD.UserDefinedString (Read or Write)

Table 407. Details of System.LCD.UserDefinedString (

Description	Indicates the LCD string set.
Legal Values	String of up to 62 ASCII characters
Default Value	0

Table 407. Details of System.LCD.UserDefinedString ((continued)

Write Privilege	Not Applicable
License Required	Not Applicable
Dependency	Cannot be configured unless LCD Configuration is user defined.

System.Location

This group enables you to manage the server's physical location characteristics.

The following section provides information about the objects in the`<System>.Location` group.

System.Location.Aisle (Read or Write)

Table 408. Details of System.Location.Aisle

Description	Indicates aisle where server is located.
Legal Values	String of up to 128 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Location.DataCenter (Read or Write)

Table 409. Details of System.Location.DataCenter

Description	Indicates name of the data center where the system is located.
Legal Values	String of up to 128 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Location.DeviceSize (Read Only)

Table 410. Details of System.Location.DeviceSize

Description	Indicates server chassis size.
Legal Values	Values: 1–255
Default Value	Depends on the server form factor

Table 410. Details of System.Location.DeviceSize (continued)

Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Location.Rack.Name (Read or Write)

Table 411. Details of System.Location.Rack.Name

Description	Indicates rack where the system is located.
Legal Values	String of up to 128 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Location.Rack.Slot (Read or Write)

Table 412. Details of System.Location.Rack.Slot

Description	Indicates the slot where system is located.
Legal Values	Values: 1–255
Default Value	0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Location.RoomName (Read or Write)

Table 413. Details of System.Location.RoomName

Description	Room name where the system is located.
Legal Values	String of up to 128 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Location.Chassis.Name (Read Only)

Table 414. Details of System.Location.Chassis.Name

Description	Indicates the chassis name.
Legal Values	String of up to 128 ASCII characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Location.Chassis.Slot (Read or Write)

Table 415. Details of System.Location.Chassis.Slot

Description	Indicates chassis slot.
Legal Values	Values: 1–255
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.OpenIDConnectServer

The objects in this group helps in configuration of SSO functionality.

System.OpenIDConnectServer.DiscoveryURL (Read or Write)

Table 416. Details of iSystem.OpenIDConnectServer.DiscoveryURL attribute

Description	Indicates the discovery URL.
Legal Values	String of up to 1024 ASCII characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	RACADM
Dependency	None

System.Power

This group provides power management features for iDRAC.

The following section provides information about the objects in this group.

NOTE: For Dell PowerEdge FM120x4 server with more than one iDRAC, the power is received and shared from CMC. Hence, the information about power and temperature for individual iDRACs are not displayed.

System.Power.Status (Read Only)

Table 417. Details of System.Power.Status

Description	Represents the device power state, either ON or OFF.
Legal Values	• 0 — Server is off • 1 — Server is on.
Default Value	0 — Server is off
Write Privilege	Not Applicable
License Required	Not Applicable
Dependency	Not Applicable

System.Power.ServerAllocation (Read Only)

Table 418. Details of System.Power.ServerAllocation

Description	Indicates the power allocated to running blades. This value is displayed in both watts and BTU/h units.
Legal Values	0–7928
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	Not Applicable
Dependency	None

System.Power.Avg.LastDay (Read Only)

Table 419. Details of System.Power.Avg.LastDay

Description	Indicates the average power value during the last day.
Legal Values	Values: 1–65535
Default Value	Average power value during the last day.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Avg.LastHour (Read Only)

Table 420. Details of System.Power.Avg.LastHour

Description	Displays the average power value during the last hour.
Legal Values	Values: 1–65535
Default Value	Average power value during the last hour.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Avg.LastWeek (Read Only)

Table 421. Details of System.Power.Avg.LastWeek

Description	Indicates the average power value during the last week.
Legal Values	Values: 1–65535
Default Value	Average power value during the last week.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Cap.ActivePolicy.Btuhr (Read Only)

Table 422. Details of System.Power.Cap.ActivePolicy.Btuhr

Description	Represents the active power in BTU/Hr a device is allowed to consume.
Legal Values	Values: 1–65535
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Cap.ActivePolicy.Name (Read Only)

Table 423. Details of System.Power.Cap.ActivePolicy.Name

Description	Displays the Active Power Cap Policy Name
Legal Values	String of up to 128 ASCII characters
Default Value	Not Applicable

Table 423. Details of System.Power.Cap.ActivePolicy.Name (continued)

Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Cap.ActivePolicy.Watts (Read Only)

Table 424. Details of System.Power.Cap.ActivePolicy.Watts

Description	Displays the Active Power Capacity in Watts
Legal Values	Values: 1–65535
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Cap.Btuhr (Read or Write)

Table 425. Details of System.Power.Cap.Btuhr

Description	Represents the maximum power in BTU/Hr a device is allowed to consume. To meet this capacity, throttle the device in order. **NOTE:** This value is applicable only if `System.Power.Cap.Enable` is set to `1`.
Legal Values	Values 1–65535
Default Value	Server power threshold in BTU/hr.
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Enable `System.Power.Cap.Enable`

System.Power.Cap. Enable (Read or Write)

Table 426. Details of System.Power.Cap. Enable

Description	Enables or disables user specified power budget threshold configuration.
Legal Values	• `0` — Disabled • `1` — Enabled
Default Value	`1` — Enabled
Write Privilege	Configure iDRAC

Table 426. Details of System.Power.Cap. Enable (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Cap.MaxThreshold (Read Only)

Table 427. Details of System.Power.Cap.MaxThreshold

Description	Because it is based on the current component inventory, it has maximum server power capacity.
Legal Values	Values: 1–65535
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Cap.MinThreshold (Read Only)

Table 428. Details of System.Power.Cap.MinThreshold

Description	Because it is based on the current component inventory, it is the lowest calculated power consumption of the device.
Legal Values	Values: 1–65535
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Cap.Percent (Read or Write)

Table 429. Details of System.Power.Cap.Percent

Description	Represents the maximum power as a percentage of total power that a server is allowed to consume. To meet this cap, throttle the device. **NOTE:** This value is applicable only if `System.Power.Cap.Enable` is set to `1`.
Legal Values	Values: 0–100
Default Value	Server power threshold in percentage.
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise

Table 429. Details of System.Power.Cap.Percent (continued)

Dependency	Enable `System.Power.Cap.Enable`

System.Power.Redundancypolicy (Read or Write)

Table 430. Details of System.Power.Redundancypolicy

Description	Selects the redundancy policy.
Legal Values	• 255 — N/A, for the systems that are not supported • 0 — Not Redundant — In this mode, even if one PSU stops functioning, the server is automatically turned off. • 1 — Input Power Redundant — In this mode, the system is functional even if one PSU input circuit stops functioning, provided the PSUs are connected to different input circuits. This is also called AC redundancy. • 2 — PSU Redundant — Available only on systems with four PSUs. This is also called DC redundancy. This is only valid in a 2+1 PSU configuration. In this mode, the system is functional even if one PSU stops functioning.
Default Value	N/A
Write Privilege	Login and configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NOTE: In a two PSU system, you must set the primary PSU (that must be ON). In a four PSU system, you must set the pair of PSUs (1+3 or 2+4) that must be ON.

System.Power.Cap.Watts (Read or Write)

Table 431. Details of System.Power.Cap.Watts

Description	Represents the Maximum Power in Watts a device is allowed to consume. To meet this capacity , throttle the device. **NOTE:** This value is applicable only if `System.Power.Cap.Enable` is set to `1`.
Legal Values	Values 0–100
Default Value	Server power threshold in watts
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Enable `System.Power.Cap.Enable`

System.Power.EnergyConsumption (Read Only)

Table 432. Details of System.Power.EnergyConsumption

Description	Represents the Cumulative power consumption by the blade or system.
Legal Values	Values: 1–65535

Table 432. Details of System.Power.EnergyConsumption (continued)

Default Value	Cumulative power consumption
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.EnergyConsumption.Clear (Read or Write)

Table 433. Details of System.Power.EnergyConsumption.Clear

Description	Clears the cumulative power consumption timestamps.
Legal Values	1
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.EnergyConsumption.StarttimeStamp (Read Only)

Table 434. Details of System.Power.EnergyConsumption.StarttimeStamp

Description	Displays the Timestamp of the cumulative power consumption.
Legal Values	String of up to 254 ASCII characters
Default Value	Timestamp of the cumulative power consumption.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Hotspare.Enable (Read or Write)

Table 435. Details of System.Power.Hotspare.Enable

Description	Enables hot-spare functionality for the primary PSU selection. For more information about hot-spare, see the iDRAC User's Guide available at **www.dell.com/esmmanuals**. **NOTE:** This object is supported only for iDRAC on Rack and Tower servers.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC

Table 435. Details of System.Power.Hotspare.Enable (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Hotspare.PrimaryPSU (Read or Write)

Table 436. Details of System.Power.Hotspare.PrimaryPSU

Description	Represents the primary PSU selection. **NOTE:** This object is supported only for iDRAC on Rack and Tower servers.
Legal Values	• 1 — PSU1 • 2 — PSU2 • 5 — PSU1 and PSU3 • 10 — PSU2 and PSU4
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Max.Amps (Read Only)

Table 437. Details of System.Power.Max.Amps

Description	Specifies the device Peak Power Consumption since this value was last cleared.
Legal Values	Values: 1–65535.
Default Value	Current peak power consumption
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Max.Amps.TimeStamp (Read Only)

Table 438. Details of System.Power.Max.Amps.TimeStamp

Description	Specifies the timestamp recorded for the Peak Power Consumption since this value was last cleared.
Legal Values	String up to 254 ASCII characters.
Default Value	Timestamp of the current peak power consumption
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise

Table 438. Details of System.Power.Max.Amps.TimeStamp (continued)

Dependency	None

System.Power.Max.Headroom (Read Only)

Table 439. Details of System.Power.Max.Headroom

Description	Displays the difference between the available power and the peak power consumption. **NOTE:** This object is not applicable on iDRAC on Modular servers.
Legal Values	Values: 1–65535
Default Value	Difference between the available power and the peak power consumption.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Max.LastDay (Read Only)

Table 440. Details of System.Power.Max.LastDay

Description	Displays the maximum power value during the last day.
Legal Values	Values: 1–65535
Default Value	Maximum power value during the last day.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Max.LastDay.TimeStamp (Read Only)

Table 441. Details of System.Power.Max.LastDay.TimeStamp

Description	Displays the timestamp of maximum power value during the last day.
Legal Values	String of up to 254 ASCII characters
Default Value	Timestamp of the maximum power value during the last day.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Max.LastHour (Read Only)

Table 442. Details of System.Power.Max.LastHour

Description	Displays the maximum power value during the last hour.
Legal Values	Values: 1–65535
Default Value	Maximum power value during the last hour.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Max.LastHour.TimeStamp (Read Only)

Table 443. Details of System.Power.Max.LastHour.TimeStamp

Description	Displays the timestamp of maximum power value during the last hour.
Legal Values	String of up to 254 ASCII characters
Default Value	Timestamp of the maximum power value during the last hour.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Max.LastWeek (Read Only)

Table 444. Details of System.Power.Max.LastWeek

Description	Displays the maximum power value during the last week.
Legal Values	Values: 1–65535
Default Value	Maximum power value during the last week.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Max.LastWeek.TimeStamp (Read Only)

Table 445. Details of System.Power.Max.LastWeek.TimeStamp

Description	Displays the timestamp of maximum power value during the last week.
Legal Values	String of up to 254 ASCII characters

Table 445. Details of System.Power.Max.LastWeek.TimeStamp (continued)

Default Value	Timestamp of the maximum power value during the last week.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Max. Power (Read Only)

Table 446. Details of System.Power.Max. Power

Description	The server consumes maximum power, because the last value was cleared.
Legal Values	Values: 1–65535
Default Value	Peak power consumption of the server.
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Max.Power.Timestamp (Read Only)

Table 447. Details of System.Power.Max.Power.Timestamp

Description	Displays time of maximum power consumption.
Legal Values	String of up to 254 ASCII characters
Default Value	Timestamp of the peak power consumption of the server.
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Max.PowerClear (Read or Write)

Table 448. Details of System.Power.Max.PowerClear

Description	Clears the Maximum Power Consumption timestamps.
Legal Values	1 — Clear the Power Consumption Statistics
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise

Table 448. Details of System.Power.Max.PowerClear (continued)

Dependency	None

System.Power.Min.LastDay (Read Only)

Table 449. Details of System.Power.Min.LastDay

Description	Displays the minimum power during the last day.
Legal Values	Values: 1–65535
Default Value	Minimum power value during the last day.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Min.LastDay.TimeStamp (Read Only)

Table 450. Details of System.Power.Min.LastDay.TimeStamp

Description	Displays the minimum power value during the last day.
Legal Values	String of up to 254 ASCII characters
Default Value	Timestamp of the minimum power value during the last day.
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Min.LastHour (Read Only)

Table 451. Details of System.Power.Min.LastHour

Description	Indicates the minimum power value during the last hour.
Legal Values	Values: 1–65535
Default Value	Minimum power value during the last hour.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Min.LastHour.Timestamp (Read Only)

Table 452. Details of System.Power.Min.LastHour.Timestamp

Description	Indicates the timestamp of minimum power during the last hour.
Legal Values	String of up to 254 ASCII characters
Default Value	Timestamp of the minimum power value during the last hour.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Min.LastWeek (Read Only)

Table 453. Details of System.Power.Min.LastWeek

Description	Indicates the minimum power during the last week.
Legal Values	Values: 1–65535
Default Value	Minimum power value during the last week.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Min.LastWeek.TimeStamp (Read Only)

Table 454. Details of System.Power.Min.LastWeek.TimeStamp

Description	Displays the timestamp of minimum power value during the last week.
Legal Values	String of up to 254 ASCII characters
Default Value	Timestamp of the minimum power value during the last week.
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.PCIeAllocation (Read or Write)

Table 455. Details of System.Power.PCIeAllocation

Description	Specifies PCIe power allocation for blade servers. It is applicable only for PowerEdge M610x. **NOTE:** This object only applies to servers that support PCIe Card.

Table 455. Details of System.Power.PCIeAllocation (continued)

Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	• 0 — For platforms that do not support PCIe cards. • 500 W — For platforms that support PCIe cards.
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.PFCEnable (Read or Write)

Table 456. Details of System.Power.PFCEnable

Description	Enables the power factor correction enable. **NOTE:** • This object is supported only for iDRAC on Rack and Tower servers. • This object is applicable only if `System.Power.Cap.Enable` is set to `1`.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.RedundancyCapabilities (Read Only)

Table 457. Details of System.Power.RedundancyCapabilities

Description	Returns the redundancy capabilities in the form of a bitmask. This bitmask indicates the values that are set to `cfgSensorRedundancyPolicy`. **NOTE:** This object is not applicable for iDRAC on Blade servers.
Legal Values	• 0 — not applicable • 1 — Non-Redundant • 2 — 1+1 Redundant • 4 — 2+1 Redundant • 8 — 2+2 Redundant • 16 — 3+x Redundant • 32 — 4+x Redundant • 64 — 5+x Redundant
Default Value	0 — not applicable
Write Privilege	Not Applicable

Table 457. Details of System.Power.RedundancyCapabilities (continued)

License Required	Not Applicable
Dependency	Not Applicable

System.Power.RedundantState (Read Only)

Table 458. Details of System.Power.RedundantState

Description	Retrieves the redundancy state for the chassis. **NOTE:** This object is not applicable for Rack and Tower server.
Legal Values	• 0 — None • 1 — Full
Default	0 — None
Write Privilege	Not Applicable
License Required	Not Applicable
Dependency	Not Applicable

System.Power.Realtime.Headroom (Read Only)

Table 459. Details of System.Power.Realtime.Headroom

Description	Displays the difference of available power and the current power consumed.
Legal Values	Integral values: 1-65535
Default Value	Default
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

System.Power.Realtime.Amps (Read Only)

Table 460. Details of System.Power.Realtime.Amps

Description	Displays the current power consumption
Legal Values	Integral values: 1-65535
Default Value	Default
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

System.Power.Realtime.Power (Read Only)

Table 461. Details of System.Power.Realtime.Power

Description	Displays the power consumed by the server
Legal Values	Integral values: 1-65535
Default Value	0 — Server is off
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

System.Power.Supply

This group provides information relating to the Power Supplies.

This group is indexed from 1 to 4. If there are less than four power supplies on the server, then some of the last indexes of this group are not applicable. This group is applicable for iDRAC on Rack and Tower servers.

The following section provides information about the objects in this group.

System.Power.Supply.CurrentDraw (Read Only)

Table 462. Details of System.Power.Supply.CurrentDraw

Description	Displays the instantaneous current consumption in 0.1 amps.
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Supply.FwVer (Read Only)

Table 463. Details of System.Power.Supply.FwVer

Description	Displays the firmware version of the PSU.
Legal Values	String up to 254 ASCII characters.
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.Power.Supply.[i].MaxInputPower (Read Only)

Table 464. Details of System.Power.Supply.[i].MaxInputPower

Description	Displays the AC input rated power in Watts.
Legal Values	Integer > 0
Default Value	0
Write Privilege	Not Applicable
License Required	Not Applicable
Dependency	Not Applicable

System.Power.Supply.[i].MaxOutputPower (Read Only)

Table 465. Details of System.Power.Supply.[i].MaxOutputPower

Description	Displays the DC output rated power in Watts.
Legal Values	Integer > 0
Default Value	0
Write Privilege	Not Applicable
License Required	Not Applicable
Dependency	Not Applicable

System.Power.Supply.[i].Status (Read Only)

Table 466. Details of System.Power.Supply.[i].Status

Description	Displays the status of the PSU.
Legal Values	• 0 — absent • 1 — present and OK • 2 — failure • 3 — predictive failure
Default	0 — absent
Write Privilege	Not Applicable
License Required	Not Applicable
Dependency	Not Applicable

System.Power.Supply.[i].Type (Read Only)

Table 467. Details of System.Power.Supply.[i].Type

Description	Displays whether the power supply is AC or DC. Either of them are indexed group and the square brackets are only place-holders, and do not form a part of command syntax.

Table 467. Details of System.Power.Supply.[i].Type (continued)

Legal Values	String upto 32 characters.
Default	None
Write Privilege	Not Applicable
License Required	Not Applicable
Dependency	Not Applicable

System.Power.Supply.[i].LineStatus (Read Only)

Table 468. Details of System.Power.Supply.[i].LineStatus

Description	Specifies if this power supply is powered off or on.
Legal Values	Integer > 0
Default	None
Write Privilege	Not Applicable
License Required	Not Applicable
Dependency	Not Applicable

System.Power.Supply.[i].PMBusMonitoring (Read Only)

Table 469. Details of System.Power.Supply.[i].PMBusMonitoring

Description	Specifies if this PMBus is present or not.
Legal Values	Integer > 0
Default	0
Write Privilege	Not Applicable
License Required	Not Applicable
Dependency	Not Applicable

System.ServerOS

Use the objects in this group to manage the host operating system's name and version details.

System.ServerOS.HostName (Read or Write)

Table 470. Details of System.ServerOS.HostName

Description	Displays the host name of the managed server.
Legal Values	String of up to 256 ASCII characters

Table 470. Details of System.ServerOS.HostName (continued)

Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ServerOS.OSName (Read or Write)

Table 471. Details of System.ServerOS.OSName

Description	Displays the operating system name of the managed server.
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ServerOS.OSVersion (Read Only)

Table 472. Details of System.ServerOS.OSVersion

Description	Indicates the operating system version of the managed server.
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ServerOS.ServerPoweredOnTime (Read Only)

Table 473. Details of System.ServerOS.ServerPoweredOnTime

Description	Indicates the time (in seconds) from when the operating system is turned ON.
Legal Values	Any integer value indicating the system powered on time duration.
Default Value	0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ThermalSettings

This group provides information about the thermal settings of the server.

To know more about the platforms supported for **AirExhaustTemp** and **FanSpeedOffset** settings, see the iDRAC User's Guide available at www.dell.com/esmmanuals.

System.ThermalSettings.AirExhaustTemp (Read or Write)

Table 474. Details of System.ThermalSettings.AirExhaustTemp

Description	Displays the air exhaust temperature and sets the exhaust temperature to any appropriate value. **NOTE:** This attribute is platform dependent.
Legal Values	• 0 — 40°C • 1 —45°C • 2 — 50°C • 3 — 55°C • 255 — None
Default value	255 — None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ThermalSettings.BaseAlgorithm (Read or Write)

Table 475. Details of System.ThermalSettings.BaseAlgorithm

Description	Specifies the thermal base algorithm. **NOTE:** This object is not applicable for Rack and Tower server.
Legal Values	• 0 — Auto • 1 — Max Exhaust Temperature • 2 — Min Power
Default values	None
License Required	iDRAC Express
Dependency	None

System.ThermalSettings.MinimumFanSpeed (Read or Write)

Table 476. Details of System.ThermalSettings.MinimumFanSpeed

Description	Specifies the minimum fan speed required. **NOTE:** This attribute is platform dependent.
Legal Values	MFSMinimumLimit — MFSMaximumLimit
Default Value	0
Write Privilege	Not Applicable

Table 476. Details of System.ThermalSettings.MinimumFanSpeed (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ThermalSettings.FanSpeedOffset (Read or Write)

Table 477. Details of System.ThermalSettings.FanSpeedOffset

Description	Specifies the fan speed offset. **NOTE:** This attribute is platform dependent.
Legal Values	• 0 — Low fan speed • 1 — High fan speed • 255 — OFF
Default value	OFF
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ThermalSettings.FanSpeedLowOffsetVal (Read Only)

Table 478. Details of System.ThermalSettings.FanSpeedLowOffsetVal

Description	Indicates the percentage range for low fan Offset speed. **NOTE:** This attribute is platform dependent.
Legal Values	Integral Values: 0 – 100
Default Value	0
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ThermalSettings.FanSpeedMediumOffsetVal (Read Only)

Table 479. Details of System.ThermalSettings.FanSpeedMediumOffsetVal

Description	Indicates the percentage range for medium fan speed offset. **NOTE:** This attribute is platform dependent.
Legal Values	Integral Values: 0 – 100
Default Value	0
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ThermalSettings.FanSpeedHighOffsetVal (Read Only)

Table 480. Details of System.ThermalSettings.FanSpeedHighOffsetVal

Description	Indicates the percentage range for the high fan offset speed. **NOTE:** This attribute is platform dependent.
Legal Values	Integral Values: 0 – 100
Default Value	0
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ThermalSettings.FanSpeedMaxOffsetVal (Read Only)

Table 481. Details of System.ThermalSettings.FanSpeedMaxOffsetVal

Description	Indicates the percentage range for low fan offset speed. **NOTE:** This attribute is platform dependent.
Legal Values	Integral Values: 0 – 100
Default Value	0
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ThermalSettings.MFSMinimumLimit (Read Only)

Table 482. Details of System.ThermalSettings.MFSMinimumLimit

Description	Indicates the minimum limit for MFS. **NOTE:** This attribute is platform dependent.
Legal Values	Integral Values: 0 — MFSMaximumLimit
Default Value	225
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ThermalSettings.MFSMaximumLimit (Read Only)

Table 483. Details of System.ThermalSettings.MFSMaximumLimit

Description	Indicates the maximum limit for MFS. **NOTE:** This attribute is platform dependent.
Legal Values	Integral Values: 1 - 100
Default Value	255

Table 483. Details of System.ThermalSettings.MFSMaximumLimit (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ThermalSettings.ThermalProfile (Read or Write)

Table 484. Details of System.ThermalSettings.ThermalProfile

Description	Sets the thermal base algorithm. **NOTE:** Restart the system to activate the power and thermal settings.
Legal Values	• 0 — Default Thermal Profile Settings • 1 — Maximum performance • 2 — Minimum Power
Default Value	Auto
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

tails ofSystem.ThermalSettings.ThirdPartyPCIFanResponse (Read or Write)

Table 485. Details of tails ofSystem.ThermalSettings.ThirdPartyPCIFanResponse

Description	Enables or disables the automatic fan speed feature when a third-party PCI card is inserted in the system.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	Enabled
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalConfig

The objects in this group manage the thermal configuration.

System.ThermalConfig.CriticalEventGenerationInterval (Read or Write)

Table 486. Details of System.ThermalConfig.CriticalEventGenerationInterval

Description	Indicates the time interval (in days) for critical events to be generated.

Table 486. Details of System.ThermalConfig.CriticalEventGenerationInterval (continued)

Legal Values	Integral Values: 0-365
Default Value	30
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ThermalConfig.EventGenerationInterval (Read or Write)

Table 487. Details of System.ThermalConfig.EventGenerationInterval

Description	Indicates the time interval (in days) for warning events to be generated.
Legal Values	Integral Values: 0-365
Default Value	30
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ThermalConfig.FreshAirCompliantConfiguration (Read Only)

Table 488. Details of System.ThermalConfig.FreshAirCompliantConfiguration

Description	Indicates whether or not the system is configured to be fresh air compliant.
Legal Values	• 0 — Not Applicable • 1 — Yes • 2 — No
Default Value	1 — Yes
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes

The following section provides information about the objects in the `LifecycleController.LCAttributes` group.

NOTE: A job successfully configured using the autoupdate or autobackup feature settings can be deleted only if the job is currently not running or downloading.

LifecycleController.LCAttributes.autobackup (Read or Write)

Table 489. Details of LifecycleController.LCAttributes.autobackup

Description	Enables or disables the automatic backup scheduler.

Table 489. Details of LifecycleController.LCAttributes.autobackup (continued)

Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Server Control
License Required	iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.AutoDiscovery (Read Only)

Table 490. Details of LifecycleController.LCAttributes.AutoDiscovery

Description	Enables or disables the auto discovery scheduler.
Legal Values	• 0 — Off • 1 — ON
Default Value	0 — Off
License Required	iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.autoupdate (Read or Write)

Table 491. Details of LifecycleController.LCAttributes.autoupdate

Description	Enables or disables the automatic update scheduler.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Server Control
License Required	iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.BiosRTDRequested (Read or Write)

Table 492. Details of LifecycleController.LCAttributes.BiosRTDRequested

Description	Reset all the BIOS attributes to the default state. Set the value to 1, and restart the server to reset the BIOS attributes to factory default. After the server restart, the value is set to 0 by default.
Legal Values	• 0 — FALSE • 1 — TRUE
Default Value	0 — FALSE
Write Privilege	Server Control

Table 492. Details of LifecycleController.LCAttributes.BiosRTDRequested (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.CollectSystemInventoryOnRestart (Read or Write)

Table 493. Details of LifecycleController.LCAttributes.CollectSystemInventoryOnRestart

Description	Enables or disables collection of system inventory on host reboot.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.DiscoveryFactoryDefaults (Read Only)

Table 494. Details of LifecycleController.LCAttributes.DiscoveryFactoryDefaults

Description	Enables or disables the discovery factory defaults.
Legal Values	• 0 — Off • 1 — On
Default Value	0 — Off
Write Privilege	Not Applicable
License Required	iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.IgnoreCertWarning (Read and Write)

Table 495. Details of LifecycleController.LCAttributes.IgnoreCertWarning

Description	Enables to set IgnoreCertWarning if the default is not set.
Legal Values	• 0—Off • 1—On
Default Value	1—On
License Required	iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.IPChangeNotifyPS (Read or Write)

Table 496. Details of LifecycleController.LCAttributes.IPChangeNotifyPS

Description	Notifies the provisioning server about the change in IP address.
Legal Values	• 0 — Off • 1 — On
Default Value	0 — Off
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.Licensed (Read Only)

Table 497. Details of LifecycleController.LCAttributes.Licensed

Description	Indicates whether or not the part replacement feature is licensed.
Legal Values	• 0 — No • 1 — Yes
Default Value	0 — No
License Required	iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.LifecycleControllerState (Read or Write)

Table 498. Details of LifecycleController.LCAttributes.LifecycleControllerState

Description	Enables or disables lifecycle controller.
Legal Values	• 0 — Disabled • 1 — Enabled • 2 — Recovery (Read Only Value)
Default Value	1 — Enabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.ProvisioningServer (Read or Write)

Table 499. Details of LifecycleController.LCAttributes.ProvisioningServer

Description	Specifies the Provisioning Server Address.
Legal Values	String of up to 255 ACSII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.PartConfigurationUpdate (Read or Write)

Table 500. Details of LifecycleController.LCAttributes.PartConfigurationUpdate

Description	Apply hardware configuration to the replaced part on part replacement.
Legal Values	• 0 — Disabled • 1 — Apply Always • 2 — Apply only if Firmware Match
Default Value	0 — Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.PartFirmwareUpdate (Read or Write)

Table 501. Details of LifecycleController.LCAttributes.PartFirmwareUpdate

Description	Apply firmware changes to the replaced part on part replacement.
Legal Values	0 — Disabled 1 — Allow version upgrade only 2 — Match firmware of replaced part
Default Value	2 — Match firmware of replaced part
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.SystemID (Read Only)

Table 502. Details of LifecycleController.LCAttributes.SystemID

Description	Specifies the Dell System ID.
Legal Values	Not Applicable
Default Value	None
Write Privilege	Not Applicable
License Required	iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.UserProxyName (Read and Write)

Table 503. Details of LifecycleController.LCAttributes.UserProxyName

Description	Enables to set user proxy name if the default is not set.
Legal Values	String of up to 64 ASCII characters
Default Value	None
License Required	iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.UserProxyPassword(Read and Write)

Table 504. Details of LifecycleController.LCAttributes.UserProxyPassword

Description	Enables to set user proxy password.
Legal Values	String of up to 64 ASCII characters
Default Value	None
License Required	iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.UserProxyPort (Read and Write)

Table 505. Details of LifecycleController.LCAttributes.UserProxyPort

Description	Proxy port default. Proxy port is limited to values in the range of 0-65535.
Legal Values	String of up to 64 ASCII characters
Default Value	None
License Required	iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.UserProxyServer (Read and Write)

Table 506. Details of LifecycleController.LCAttributes.UserProxyServer

Description	Enables to set user proxy server if the default is not set.
Legal Values	String of up to 64 ASCII characters
Default Value	None
License Required	iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.UserProxyType (Read and Write)

Table 507. Details of LifecycleController.LCAttributes.UserProxyType

Description	Enables to set user proxy type if the default is not set.
Legal Values	String of up to 64 ASCII characters
Default Value	None
License Required	iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.UserProxyUserName (Read or Write)

Description	Proxy User name default if not provided.
Legal Values	• String of up to 64 ASCII characters.
Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Basic
Dependancy	None

LifecycleController.LCAttributes.VirtualAddressManagementApplication (Read or Write)

Table 508. Details of

Description	Specifies the console name of Virtual Address Management Application.
Legal Values	String of up to 32 ACSII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory

To manage the configuration of the iDRAC Active Directory features, use the objects in this group.

iDRAC.ActiveDirectory.AuthTimeout (Read or Write)

Table 509. Details of iDRAC.ActiveDirectory.AuthTimeout

Description	To wait for ActiveDirectory authentication requests to complete before timing out, specify the time in seconds.
Legal Values	Integral values: 15–300
Default Value	120
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.CertValidationEnable (Read or Write)

Table 510. Details of iDRAC.ActiveDirectory.CertValidationEnable

Description	Enables or disables Active Directory certificate validation as a part of the Active Directory configuration process.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.DCLookupByUserDomain (Read or Write)

Table 511. Details of iDRAC.ActiveDirectory.DCLookupByUserDomain

Description	To look up the user domain for Active Directory, enables the selection option.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise

Table 511. Details of iDRAC.ActiveDirectory.DCLookupByUserDomain (continued)

Dependency	Cannot be disabled unless the DC Lookup Domain Name is set.

iDRAC.ActiveDirectory.DCLookupDomainName (Read or Write)

Table 512. Details of iDRAC.ActiveDirectory.DCLookupDomainName

Description	The configured search domain is used when `DCLookupByUserDomain` is disabled.
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.DCLookupEnable (Read or Write)

Table 513. Details of iDRAC.ActiveDirectory.DCLookupEnable

Description	Configures iDRAC to use preconfigured domain controllers or to use DNS to find the domain controller
Legal Values	• `0` — Disabled • `1` — Enabled
Default Value	`0` — Disabled
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	Cannot be enabled unless one of the following is configured: • `IPv4.DNS1` • `IPv4.DNS2` • `IPv6.DNS1` • `IPv6.DNS2`

iDRAC.ActiveDirectory.DomainController1 (Read or Write)

Table 514. Details of iDRAC.ActiveDirectory.DomainController1

Description	FQDN that stores the address of the active directory domain controller1.
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise

Table 514. Details of iDRAC.ActiveDirectory.DomainController1 (continued)

Dependency	None

iDRAC.ActiveDirectory.DomainController2 (Read or Write)

Table 515. Details of iDRAC.ActiveDirectory.DomainController2

Description	FQDN that stores the address of the active directory domain controller 2
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.DomainController3 (Read or Write)

Table 516. Details of iDRAC.ActiveDirectory.DomainController3

Description	FQDN that stores the address of the active directory domain controller 3
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.Enable (Read or Write)

Table 517. Details of iDRAC.ActiveDirectory.Enable

Description	Enables or disables Active Directory user authentication on iDRAC.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.GCLookupEnable (Read or Write)

Table 518. Details of iDRAC.ActiveDirectory.GCLookupEnable

Description	Determines how to look up the global catalog server.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	Cannot be enabled unless one of the following is configured: • IPv4.DNS1 • IPv4.DNS2 • IPv6.DNS1 • IPv6.DNS2

iDRAC.ActiveDirectory.GCRootDomain (Read or Write)

Table 519. Details of iDRAC.ActiveDirectory.GCRootDomain

Description	The names of the Active Directory root domain used for DNS look up.
Legal Values	String of up to 254 ASCII characters
Write Privilege	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	None
Dependency	None

iDRAC.ActiveDirectory.GlobalCatalog1 (Read or Write)

Table 520. Details of iDRAC.ActiveDirectory.GlobalCatalog1

Description	Specifies the Global Catalog server from which you want the iDRAC to obtain user names.
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.GlobalCatalog2 (Read or Write)

Table 521. Details of iDRAC.ActiveDirectory.GlobalCatalog2

Description	To obtain user names, specifies the Global Catalog server from which you want the iDRAC.
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.GlobalCatalog3 (Read or Write)

Table 522. Details of iDRAC.ActiveDirectory.GlobalCatalog3

Description	To obtain user names, specifies the Global Catalog server from which you want the iDRAC.
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.RacDomain (Read or Write)

Table 523. Details of iDRAC.ActiveDirectory.RacDomain

Description	Active Directory Domain in which iDRAC resides.
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.RacName (Read or Write)

Table 524. Details of iDRAC.ActiveDirectory.RacName

Description	Name of iDRAC as recorded in the Active Directory forest.
Legal Values	String of up to 254 ASCII characters

Table 524. Details of iDRAC.ActiveDirectory.RacName (continued)

Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.Schema (Read or Write)

Table 525. Details of iDRAC.ActiveDirectory.Schema

Description	To use with Active Directory, determine the schema type.
Legal Values	• 1 — Extended Schema • 2 — Standard Schema
Default Value	1 — Extended Schema
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.SSOEnable (Read or Write)

Table 526. Details of iDRAC.ActiveDirectory.SSOEnable

Description	Enables or disables Active Directory single sign-on authentication on iDRAC.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	Cannot be enabled unless SmartCard Logon Enable is disabled.

iDRAC.ADGroup

To manage the configuration of AD standard schema settings, use these objects in the group. This group is indexed from 1 to 5.

iDRAC.ADGroup.Domain (Read or Write)

Table 527. Details of iDRAC.ADGroup.Domain

Description	Active Directory Domain in which the Role Group resides.

Table 527. Details of iDRAC.ADGroup.Domain (continued)

Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ADGroup.Name (Read or Write)

Table 528. Details of iDRAC.ADGroup.Name

Description	Name of the Role Group as recorded in the Active Directory forest.
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ADGroup.Privilege (Read or Write)

Table 529. Details of iDRAC.ADGroup.Privilege

Description	Role-based authority privileges for a Role Group.
Legal Values	Integral values: 0–511 (0x1FF)
Default Value	0
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ASRConfig

This group contains the attributes that provides details about ASR configuration.

iDRAC.ASRConfig.Enable (Read or Write)

Description Enables or disables iDRAC last crash screen capture feature.

Legal Values
- Disabled-0
- Enabled-1

Default Value	1
Write Privilege	Configure iDRAC
License Required	iDRAC Basic
Dependancy	None

iDRAC.AutoOSLock

To manage the OS Auto lock feature, use these objects in this group.

iDRAC.AutoOSLock.AutoOSLockState (Read or Write)

Table 530. Details of iDRAC.AutoOSLock.AutoOSLockState

Description	Enable or Disable OS Auto lock feature.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.EmailAlert

The objects in this group configure email alerting capabilities. This group is indexed from 1 to 4.

iDRAC.EmailAlert.Address (Read or Write)

Table 531. Details of iDRAC.EmailAlert.Address

Description	Specifies the destination email address for email alerts.
Legal Values	A valid IPv4 or IPv6 address
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.EmailAlert.CustomMsg (Read or Write)

Table 532. Details of iDRAC.EmailAlert.CustomMsg

Description	Specifies the custom message that forms the subject of the alert.

Table 532. Details of iDRAC.EmailAlert.CustomMsg (continued)

Legal Values	A string of up to 32 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.EmailAlert.Enable (Read or Write)

Table 533. Details of iDRAC.EmailAlert.Enable

Description	To receive alerts, enable or disable the destination.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IMC

This group contains the attributes that provides details about IMC configuration.

iDRAC.IMC.AdministrativeState (Read or Write)

Description	Enable or Disable Administrative State of IMC
Legal Values	• Disabled-0 • Enabled-1
Default Value	0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic
Dependancy	iDRAC NIC has to be in shared mode to enable OS to iDRAC pass through.

iDRAC.Info

To manage information about iDRAC being queried, use these objects in the group.

iDRAC.Info.Build (Read or Write)

Table 534. Details of iDRAC.Info.Build

Description	String containing the current product build version.
Legal Values	String of up to 16 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Info.Description (Read or Write)

Table 535. Details of iDRAC.Info.Description

Description	Text description of the iDRAC.
Legal Values	String of up to 255 ASCII characters
Default Value	The system component provides a set of remote management operations for Dell PowerEdge Servers.
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Info.Name (Read or Write)

Table 536. Details of iDRAC.Info.Name

Description	User assigned name identifying this controller.
Legal Values	String of up to 15 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Info.Product (Read or Write)

Table 537. Details of iDRAC.Info.Product

Description	String identifying the Product.
Legal Values	String of up to 63 ASCII characters
Default Value	Integrated Dell Remote Access Controller

Table 537. Details of iDRAC.Info.Product (continued)

Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Info.Type (Read or Write)

Table 538. Details of iDRAC.Info.Type

Description	Identifies the remote access controller type
Legal Values	• 16 (12G iDRAC Monolithic) • 17 (12G iDRAC Modular)
Default Vlaue	12G Monolithic
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Info.Version (Read Only)

Table 539. Details of iDRAC.Info.Version

Description	String containing the current product firmware version.
Legal Values	String of up to 63 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Info.ServerGen (Read or Write)

Table 540. Details of iDRAC.Info.ServerGen

Description	Indicates the server generation.
Legal Values	String of up to 12 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IOIDOpt

The objects in this group manage the IOIDOpt attributes.

iDRAC.IOIDOpt.IOIDOptEnable (Read or Write)

Description	Enable IO Identity Optimization
Legal Values	• Disabled-0 • Enabled-1
Default Value	0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic
Dependancy	None

iDRAC.IOIDOptEnable (Read or Write)

Table 541. Details of iDRAC.IOIDOptEnable

Description	Enables or disables Identity Optimization (IO).
Legal Values	• 0 — Disabled • 1 — Enabled
Default values	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IOIDOpt.InitiatorPersistencePolicy (Read or Write)

Table 542. Details of iDRAC.IOIDOpt.InitiatorPersistencePolicy

Description	Sets the virtual address management .
Legal Values	• 0— None • 1— WarmReset • 2— PowerGoodReset • 3— WarmReset, PowerGoodReset • 4— ACPowerLoss • 5— WarmReset, ACPowerLoss • 6— PowerGoodReset, ACPowerLoss • 7— WarmReset, PowerGoodReset, ACPowerLoss
Default Value	7— WarmReset, PowerGoodReset, ACPowerLoss
Write Privilege	Configure iDRAC and Server Control

Table 542. Details of iDRAC.IOIDOpt.InitiatorPersistencePolicy (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	`IOIDOptEnable` attribute must be enabled.

iDRAC.IOIDOpt.StorageTargetPersistencePolicy (Read or Write)

Table 543. Details of iDRAC.IOIDOpt.StorageTargetPersistencePolicy

Description	Sets the Virtual Address Management StorageTargetPersistencePolicy.
Legal Values	• 0 —None • 1 —WarmReset • 2 — PowerGoodReset • 3 — WarmReset, PowerGoodReset • 4 — ACPowerLoss • 5 — WarmReset, ACPowerLoss • 6 — PowerGoodReset, ACPowerLoss • 7 — WarmReset, PowerGoodReset, ACPowerLoss
Default Value	ACPowerLoss, PowerGoodReset, WarmReset
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	To configure, the `iDRAC.IOIDOpt.Enable` property must indicate `Enabled`.

iDRAC.IOIDOpt.VirtualAddressPersistencePolicyAuxPwrd (Read or Write)

Table 544. Details of iDRAC.IOIDOpt.VirtualAddressPersistencePolicyAuxPwrd

Description	Applied for the Aux powered devices, which persist the virtual address on cold and warm reset.
Legal Values	• 0 —None • 1 —WarmReset • 2 — PowerGoodReset • 3 — WarmReset, PowerGoodReset • 4 — ACPowerLoss • 5 — WarmReset, ACPowerLoss • 6 — PowerGoodReset, ACPowerLoss • 7 — WarmReset, PowerGoodReset, ACPowerLoss
Default Value	ACPowerLoss, PowerGoodReset, WarmReset
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise

Table 544. Details of iDRAC.IOIDOpt.VirtualAddressPersistencePolicyAuxPwrd (continued)

Dependency	To configure, the `iDRAC.IOIDOpt.Enable` property must indicate `Enabled`.

iDRAC.IOIDOpt.VirtualAddressPersistencePolicyNonAuxPwrd (Read or Write)

Table 545. Details of iDRAC.IOIDOpt.VirtualAddressPersistencePolicyNonAuxPwrd

Description	Applied for the Non-Aux powered devices, which persist the virtual address on warm reset.
Legal Values	• 0 —None • 1 —WarmReset • 2 — PowerGoodReset • 3 — WarmReset, PowerGoodReset • 4 — ACPowerLoss • 5 — WarmReset, ACPowerLoss • 6 — PowerGoodReset, ACPowerLoss • 7 — WarmReset, PowerGoodReset, ACPowerLoss
Default Value	ACPowerLoss, PowerGoodReset, WarmReset
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	To configure, the `iDRAC.IOIDOpt.Enable` property must indicate `Enabled`.

iDRAC.IPBlocking

To configure IP address blocking feature of iDRAC, Use the objects in this group.

iDRAC.IPBlocking.BlockEnable (Read or Write)

Table 546. Details of iDRAC.IPBlocking.BlockEnable

Description	Enables or disables the IPv4 address blocking feature of iDRAC.
Legal Values	• `0` — Disabled • `1` — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPBlocking.FailCount (Read or Write)

Table 547. Details of iDRAC.IPBlocking.FailCount

Description	The maximum number of logins that are unsuccessful to occur within the window before logs in attempts from the IP address are rejected.
Legal Values	Integral values: 2–16
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPBlocking.FailWindow (Read or Write)

Table 548. Details of iDRAC.IPBlocking.FailWindow

Description	Defines the time span in seconds that the unsuccessful attempts are counted.
Legal Values	Integral values from 10 to 65535
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPBlocking.PenaltyTime (Read or Write)

Table 549. Details of iDRAC.IPBlocking.PenaltyTime

Description	Defines the time span in seconds that session requests from an IP address with excessive failures are rejected.
Legal Values	Integral values: 2–65535
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPBlocking.RangeAddr (Read or Write)

Table 550. Details of iDRAC.IPBlocking.RangeAddr

Description	Specifies the acceptable IPv4 address bit pattern in positions determined by the 1s in the range mask.
Legal Values	Valid IPv4 Address
Default Value	`192.168.0`

Table 550. Details of iDRAC.IPBlocking.RangeAddr (continued)

Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPBlocking.RangeEnable (Read or Write)

Table 551. Details of iDRAC.IPBlocking.RangeEnable

Description	Enables or disables the IPv4 Address Range validation feature of iDRAC.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPBlocking.RangeMask (Read or Write)

Table 552. Details of iDRAC.IPBlocking.RangeMask

Description	Standard IP mask values with left-justified bits.
Legal Values	Valid IPv4 Address Mask
Default Value	255.255.255.0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMILan

To configure IPMI over LAN of the system, use the objects in this group.

iDRAC.IPMILan.AlertEnable (Read or Write)

Table 553. Details of iDRAC.IPMILan.AlertEnable

Description	Enables or disables global email alerting.
Legal Values	• 0 — Disabled • 1 — Enabled

Table 553. Details of iDRAC.IPMILan.AlertEnable (continued)

Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMILan.CommunityName (Read or Write)

Table 554. Details of iDRAC.IPMILan.CommunityName

Description	Specifies the SNMP community name for traps.
Legal Values	String of up to 18 ASCII characters
Default Value	Public
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMILan.Enable (Read or Write)

Table 555. Details of iDRAC.IPMILan.Enable

Description	Enables or disables the IPMI over LAN interface.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMILan.EncryptionKey (Read or Write)

Table 556. Details of iDRAC.IPMILan.EncryptionKey

Description	Enables or disables the IPMI over LAN interface.
Legal Values	String of up to 18 ASCII characters
Default Value	0000000000000000000000000000000000000000
Write Privilege	Configure iDRAC

Table 556. Details of iDRAC.IPMILan.EncryptionKey (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMILan.PrivLimit (Read or Write)

Table 557. Details of iDRAC.IPMILan.PrivLimit

Description	Specifies the maximum privilege level for IPMI over LAN access.
Legal Values	• 2 — User • 3 — Operator • 4 — Administrator
Default Value	4 — Administrator
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMISerial

To configure the IPMI serial interface, use this objects in this group.

NOTE: This is supported only for rack and tower systems.

iDRAC.IPMISerial.BaudRate (Read or Write)

Table 558. Details of iDRAC.IPMISerial.BaudRate

Description	Specifies the baud rate for serial connection over IPMI.
Legal Values	• 9600 • 19200 • 57600 • 115200
Default Value	115200
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMISerial.ChanPrivLimit (Read or Write)

Table 559. Details of iDRAC.IPMISerial.ChanPrivLimit

Description	Specifies the maximum privilege limit allowed on the IPMI serial channel.
Legal Values	• 2 — User • 3 — Operator • 4 — Administrator
Default Value	4 — Administrator
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMISerial.ConnectionMode (Read or Write)

Table 560. Details of iDRAC.IPMISerial.ConnectionMode

Description	Determines the IPMI defined mode of the serial port.
Legal Values	• 1 — Basic • 0 — Terminal
Default Value	1 — Basic
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMISerial.DeleteControl (Read or Write)

Table 561. Details of iDRAC.IPMISerial.DeleteControl

Description	Enables or disables delete control on the IPMI serial interface.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMISerial.EchoControl (Read or Write)

Table 562. Details of iDRAC.IPMISerial.EchoControl

Description	Enables or disables echo control on the IPMI serial interface.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMISerial.FlowControl (Read or Write)

Table 563. Details of iDRAC.IPMISerial.FlowControl

Description	Specifies the Flow Control setting for IPMI serial port.
Legal Values	• 0 — None • 2 — RTS or CTS
Default Value	2 — RTS or CTS
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMISerial.HandshakeControl (Read or Write)

Table 564. Details of iDRAC.IPMISerial.HandshakeControl

Description	Enables or disables the IPMI terminal mode handshake control.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMISerial.InputNewLineSeq (Read or Write)

Table 565. Details of iDRAC.IPMISerial.InputNewLineSeq

Description	Specifies the input new line sequence for the IPMI serial interface.
Legal Values	• 1 — Enter • 2 — Null
Default Value	2 — Null
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMISerial.LineEdit (Read or Write)

Table 566. Details of iDRAC.IPMISerial.LineEdit

Description	Enables or disables line editing on the IPMI serial interface.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMISerial.NewLineSeq (Read or Write)

Table 567. Details of iDRAC.IPMISerial.NewLineSeq

Description	Specifies the new line sequence for the IPMI serial interface.
Legal Values	• 0 — None • 1 — CR-LF • 2 — Null • 3 — CR • 4 — LF-CR • 5— LF
Default Value	1 — CR-LF
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMISOL

Use the objects in this group to configure the SOL capabilities of the system.

iDRAC.IPMISOL.AccumulateInterval (Read or Write)

Table 568. Details of iDRAC.IPMISOL.AccumulateInterval

Description	Specifies the typical amount of time that iDRAC waits before transmitting a partial SOL character data packet.
Legal Values	Integral values: 1–255
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMISOL.BaudRate (Read or Write)

Table 569. Details of iDRAC.IPMISOL.BaudRate

Description	Specifies the Baud rate for serial communication over LAN.
Legal Values	• 9600 • 19200 • 57600 • 115200
Default Value	115200
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMISOL.Enable (Read or Write)

Table 570. Details of iDRAC.IPMISOL.Enable

Description	Enables or disables SOL.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise

Table 570. Details of iDRAC.IPMISOL.Enable (continued)

Dependency	None

iDRAC.IPMISOL.MinPrivilege (Read or Write)

Table 571. Details of iDRAC.IPMISOL.MinPrivilege

Description	Specifies the minimum privilege level required for serial access.
Legal Values	• 2—User • 3—Operator • 4—Administrator
Default Value	4—Administrator
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMISOL.SendThreshold (Read or Write)

Table 572. Details of iDRAC.IPMISOL.SendThreshold

Description	To buffer before sending an SOL data packet, specifies the SOL threshold limit value and the maximum number of bytes
Legal Values	Integral values: 1–255
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv4

To manage the IPv4 configuration properties of iDRAC, use these objects in this group.

iDRAC.IPv4.Address (Read or Write)

Table 573. Details of iDRAC.IPv4.Address

Description	The current IPv4 address assigned to iDRAC.
Legal Values	Valid IPv4 Address `
Default Value	192.168.0

Table 573. Details of iDRAC.IPv4.Address (continued)

Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Cannot be set unless `IPv4.DHCPEnable` is disabled.

iDRAC.IPv4.DHCPEnable (Read or Write)

Table 574. Details of iDRAC.IPv4.DHCPEnable

Description	Specifies if DHCP is used to assign the iDRAC IPv4 address.
Legal Values	• `0` — Disabled • `1` — Enabled
Default Value	`0` — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Cannot be enabled unless `IPv4.Enable` is enabled.

iDRAC.IPv4.DNS1 (Read or Write)

Table 575. Details of iDRAC.IPv4.DNS1

Description	IPv4 address for DNS server 1.
Legal Values	Valid IPv4 Address
Default Value	0.0.0.0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Cannot be set unless `IPv4.DNSFromDHCP` is disabled.

iDRAC.IPv4.DNS2 (Read or Write)

Table 576. Details of iDRAC.IPv4.DNS2

Description	IPv4 address for DNS Server 2.
Legal Values	Valid IPv4 Address
Default Value	0.0.0.0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise

Table 576. Details of iDRAC.IPv4.DNS2 (continued)

Dependency	Cannot be set unless `IPv4.DNSFromDHCP` is disabled.

iDRAC.IPv4.DNSFromDHCP (Read or Write)

Table 577. Details of iDRAC.IPv4.DNSFromDHCP

Description	Specifies if the DNS server IPv4 addresses must be assigned from the DHCP server on the network.
Legal Values	• `0` — Disabled • `1` — Enabled
Default Value	`0` — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Cannot be enabled unless `IPv4.DHCPEnable` is enabled.

iDRAC.IPv4.Enable (Read or Write)

Table 578. Details of iDRAC.IPv4.Enable

Description	Enables or disables the iDRAC IPv4 stack.
Legal Values	• `0` — Disabled • `1` — Enabled
Default Value	`1` — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv4.Gateway (Read or Write)

Table 579. Details of iDRAC.IPv4.Gateway

Description	The gateway for the iDRAC IPv4 address.
Legal Values	Valid IPv4 gateway
Default Value	`192.168.0`
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Cannot be set unless `IPv4.DHCPEnable` is disabled.

iDRAC.IPv4.Netmask (Read or Write)

Table 580. Details of iDRAC.IPv4.Netmask

Description	The subnet mask used for the iDRAC IPv4 address.
Legal Values	Valid IPv4 netmask
Default Value	`255.255.255.0`
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Cannot be set unless `IPv4.DHCPEnable` is disabled.

iDRAC.IPv4Static

Use the objects in this group to manage the IPv4 Static configuration properties of iDRAC.

iDRAC.IPv4Static.Address (Read or Write)

Table 581. Details of iDRAC.IPv4Static.Address attribute

Description	iDRAC static IPv4 address. This address can be configured even when DHCP is enabled.
Legal Values	Valid IPv4 Address
Default Value	`192.168.0`
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv4Static.DNS1 (Read or Write)

Table 582. Details of iDRAC.IPv4Static.DNS1

Description	Statically configurable DNS Server 1.
Legal Values	Valid IPv4 Address
Default Value	0.0.0.0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv4Static.DNS2 (Read or Write)

Table 583. Details of iDRAC.IPv4Static.DNS2

Description	Statically configurable DNS Server 2.
Legal Values	Valid IPv4 Address
Default Value	0.0.0.0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv4Static.DNSFromDHCP (Read or Write)

Table 584. Details of iDRAC.IPv4Static.DNSFromDHCP

Description	Specifies if the DNS server IPv4 addresses should be assigned from the DHCP server on the network.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv4Static.Gateway (Read or Write)

Table 585. Details of iDRAC.IPv4Static.Gateway

Description	iDRAC static IPv4 gateway. This address can be configured even when DHCP is enabled.
Legal Values	Valid IPv4 gateway
Default Value	`192.168.0`
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv4Static.Netmask (Read or Write)

Table 586. Details of iDRAC.IPv4Static.Netmask

Description	iDRAC static IPv4 subnet mask. This address can be configured even when DHCP is enabled.

Table 586. Details of iDRAC.IPv4Static.Netmask (continued)

Legal Values	Valid IPv4 netmask
Default Value	255.255.255.0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6

To manage the IPv6 configuration properties of iDRAC, use the objects in this group.

iDRAC.IPv6.Address1 (Read or Write)

Table 587. Details of iDRAC.IPv6.Address 1 attribute

Description	iDRAC IPv6 Address.
Legal Values	Valid IPv6 Address
Default Value	
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Cannot be set unless `IPv6.AutoConfig` is disabled.

iDRAC.IPv6.Address2 (Read or Write)

Table 588. Details of iDRAC.IPv6.Address 2 attribute

Description	iDRAC IPv6 second address.
Legal Values	Valid IPv6 Address
Default Value	::
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address3 (Read or Write)

Table 589. Details of iDRAC.IPv6.Address 3 attribute

Description	iDRAC IPv6 third address.

Table 589. Details of iDRAC.IPv6.Address 3 attribute (continued)

Legal Values	Valid IPv6 Address
Default Value	
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address4 (Read or Write)

Table 590. Details of iDRAC.IPv6.Address 4 attribute

Description	iDRAC IPv6 fourth address.
Legal Values	Valid IPv6 Address
Default Value	
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address5 (Read or Write)

Table 591. Details of iDRAC.IPv6.Address 5 attribute

Description	iDRAC IPv6 fifth address.
Legal Values	Valid IPv6 Address
Default Value	::
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address6 (Read or Write)

Table 592. Details of iDRAC.IPv6.Address 6 attribute

Description	iDRAC IPv6 sixth address.
Legal Values	Valid IPv6 Address
Default Value	::
Write Privilege	Configure iDRAC

Table 592. Details of iDRAC.IPv6.Address 6 attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address7 (Read or Write)

Table 593. Details of iDRAC.IPv6.Address 7 attribute

Description	iDRAC IPv6 seventh address.
Legal Values	Valid IPv6 Address
Default Value	
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address8 (Read or Write)

Table 594. Details of iDRAC.IPv6.Address8 attribute

Description	iDRAC IPv6 eighth address.
Legal Values	Valid IPv6 Address
Default Value	::
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address9 (Read or Write)

Table 595. Details of iDRAC.IPv6.Address9 attribute

Description	iDRAC IPv6 ninth address.
Legal Values	Valid IPv6 Address
Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address10 (Read or Write)

Table 596. Details of iDRAC.IPv6.Address10 attribute

Description	iDRAC IPv6 tenth address.
Legal Values	Valid IPv6 Address
Default Value	::
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address11 (Read or Write)

Table 597. Details of iDRAC.IPv6.Address11 attribute

Description	iDRAC IPv6 eleventh address.
Legal Values	Valid IPv6 Address
Default Value	::
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address12 (Read or Write)

Table 598. Details of iDRAC.IPv6.Address12 attribute

Description	iDRAC IPv6 twelfth address.
Legal Values	Valid IPv6 Address
Default Value	::
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address13 (Read or Write)

Table 599. Details of iDRAC.IPv6.Address13 attribute

Description	iDRAC IPv6 thirteenth address.
Legal Values	Valid IPv6 Address

Table 599. Details of iDRAC.IPv6.Address13 attribute (continued)

Default Value	
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address14 (Read or Write)

Table 600. Details of iDRAC.IPv6.Address14 attribute

Description	iDRAC IPv6 fourteenth address.
Legal Values	Valid IPv6 Address
Default Value	::
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address15 (Read or Write)

Table 601. Details of iDRAC.IPv6.Address15 attribute

Description	iDRAC IPv6 fifteenth address.
Legal Values	Valid IPv6 Address
Default Value	::
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.AutoConfig (Read or Write)

Table 602. Details of iDRAC.IPv6.AutoConfig attribute

Description	Enables or disables the iDRAC IPv6 auto configuration option.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC

Table 602. Details of iDRAC.IPv6.AutoConfig attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.DNS1 (Read or Write)

Table 603. Details of iDRAC.IPv6.DNS1 attribute

Description	IPv6 DNS Server 1 Address.
Legal Values	Valid IPv6 Address
Default Value	::
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Cannot be set unless `IPv6.DNSFromDHCP6` is disabled.

iDRAC.IPv6.DNS2 (Read or Write)

Table 604. Details of iDRAC.IPv6.DNS2 attribute

Description	IPv6 DNS Server 2 Address.
Legal Values	Valid IPv6 Address
Default Value	::
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Cannot be set unless `IPv6.DNSFromDHCP6` is disabled.

iDRAC.IPv6.DNSFromDHCP6 (Read or Write)

Table 605. Details of iDRAC.IPv6.DNSFromDHCP6 attribute

Description	Specifies if the DNS Server addresses are obtained from DHCP or not.
Legal Values	• `0` — Disabled • `1` — Enabled
Default Value	`0` — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Cannot be Enabled unless `IPv6.AutoConfig` is enabled.

iDRAC.IPv6.Enable (Read or Write)

Table 606. Details of iDRAC.IPv6.Enable attribute

Description	Enables or Disables iDRAC IPv6 stack.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Gateway (Read or Write)

Table 607. Details of iDRAC.IPv6.Gateway attribute

Description	iDRAC IPv6 Gateway
Legal Values	Valid IPv6 gateway
Default Value	::
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Cannot be set unless `IPv6.AutoConfig` is disabled.

iDRAC.IPv6.LinkLocalAddress (Read or Write)

Table 608. Details of iDRAC.IPv6.LinkLocalAddress attribute

Description	iDRAC IPv6 Link Local Address.
Legal Values	Valid IPv6 Address
Default Value	::
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.PrefixLength (Read or Write)

Table 609. Details of iDRAC.IPv6.PrefixLength attribute

Description	Prefix length for the iDRAC IPv6 Address.

Table 609. Details of iDRAC.IPv6.PrefixLength attribute (continued)

Legal Values	Integral values: 1–128
Default Value	64
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6Static

To manage the IPv6 static configuration properties of iDRAC, use the objects in this group

iDRAC.IPv6Static.Address1 (Read or Write)

Table 610. Details of iDRAC.IPv6Static.Address1 attribute

Description	iDRAC static IPv6 address.
Legal Values	Valid IPv6 Address
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6Static.DNS1 (Read or Write)

Table 611. Details of iDRAC.IPv6Static.DNS1 attribute

Description	Statically configurable DNS Server 1.
Legal Values	Valid IPv6 Address
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6Static.DNS2 (Read or Write)

Table 612. Details of iDRAC.IPv6Static.DNS2 attribute

Description	Statically configurable DNS Server 2.
Legal Values	Valid IPv6 Address
Write Privilege	Configure iDRAC

Table 612. Details of iDRAC.IPv6Static.DNS2 attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6Static.DNSFromDHCP6 (Read or Write)

Table 613. Details of iDRAC.IPv6Static.DNSFromDHCP6 attribute

Description	Specifies if the DNS server IPv6 addresses must be assigned from the DHCP server on the network.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6Static.Gateway (Read or Write)

Table 614. Details of iDRAC.IPv6Static.Gateway attribute

Description	iDRAC static IPv6 gateway.
Legal Values	Valid IPv6 Address
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6Static.PrefixLength (Read or Write)

Table 615. Details of iDRAC.IPv6Static.PrefixLength attribute

Description	Prefix length for the iDRAC IPv6 Address.
Legal Values	Integral values: 1–128
Default Value	64
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPv6URL

Use the objects in this group to manage the IPv6 static configuration properties of iDRAC.

iDRAC.IPv6URL.URL (Read Only)

Table 616. Details of iDRAC.IPv6URL.URL attribute

Description	iDRAC IPv6 URL String of format **'https://[ipv6 address]:<port number>'**
Legal Values	IPv6 URL String
Default Value	
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	iDRAC IPv6 has to be Enabled

iDRAC.LDAP

To configure properties for LDAP settings, use the objects in this group.

iDRAC.LDAP.BaseDN (Read or Write)

Table 617. Details of iDRAC.LDAP.BaseDN attribute

Description	The Domain Name of the branch of the directory where all searches must start.
Legal Values	String of up to 63 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.BindDN (Read or Write)

Table 618. Details of iDRAC.LDAP.BindDN attribute

Description	The domain name of the branch of the directory where all searches must start.
Legal Values	String of up to 255 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.BindPassword (Write Only)

Table 619. Details of iDRAC.LDAP.BindPassword attribute

Description	A bind password to use along with the bindDN.
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.CertValidationEnable (Read or Write)

Table 620. Details of iDRAC.LDAP.CertValidationEnable attribute

Description	Controls certificate validation during SSL handshake.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.Enable (Read or Write)

Table 621. Details of iDRAC.LDAP.Enable attribute

Description	Turns LDAP service on or off.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.GroupAttribute (Read or Write)

Table 622. Details of iDRAC.LDAP.GroupAttribute attribute

Description	Specifies which LDAP attribute is used to check for group membership.

Table 622. Details of iDRAC.LDAP.GroupAttribute attribute (continued)

Legal Values	String of up to 128 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.GroupAttributeIsDN (Read or Write)

Table 623. Details of iDRAC.LDAP.GroupAttributeIsDN attribute

Description	Specifies whether the user domain name must be used from the LDAP server or from the user that provides login.
Legal Values	0 — Disabled 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.Port (Read or Write)

Table 624. Details of iDRAC.LDAP.Port attribute

Description	Port of LDAP over SSL.
Legal Values	Integer values: 1–65535
Default Value	636
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.SearchFilter (Read or Write)

Table 625. Details of iDRAC.LDAP.SearchFilter attribute

Description	A valid LDAP search filter to be used if the user attribute cannot uniquely identify the login user within the chosen baseDN.
Legal Values	String of up to 254 ASCII characters

Table 625. Details of iDRAC.LDAP.SearchFilter attribute (continued)

Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.Server (Read or Write)

Table 626. Details of iDRAC.LDAP.Server attribute

Description	Configures the address of the LDAP Server.
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.UserAttribute (Read or Write)

Table 627. Details of iDRAC.LDAP.UserAttribute attribute

Description	To search, specify the user attribute.
Legal Values	String of up to 128 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAPRoleGroup

The objects in this group enable configuration of role groups for LDAP. This group is indexed from 1 to 5.

iDRAC.LDAPRoleGroup.DN (Read or Write)

Table 628. Details of iDRAC.LDAPRoleGroup.DN attribute

Description	The Domain Name of this group.
Legal Values	String of up to 1024 ASCII characters
Default Value	Not Applicable

Table 628. Details of iDRAC.LDAPRoleGroup.DN attribute (continued)

Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAPRoleGroup.Privilege(Read or Write)

Table 629. Details of iiDRAC.LDAPRoleGroup.Privilege attribute

Description	A bit-mask defining the privileges associated with this particular group.
Legal Values	Integral values: 0–511 (0x1FF)
Default Value	0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LocalSecurity

To manage the ability to configure iDRAC, use the objects in this group.

iDRAC.LocalSecurity.LocalConfigDisabled (Read or Write)

Table 630. Details of iDRAC.LocalSecurity.LocalConfigDisabled attribute

Description	To configure iDRAC from Local RACADM, enable or disable the ability of the local user.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.LocalSecurity.PrebootConfig (Read or Write)

Table 631. Details of iDRAC.LocalSecurity.PrebootConfig attribute

Description	To configure iDRAC from the BIOS POST option-ROM, enable or disable the ability of the local user.
Legal Values	• 0 — Disabled • 1 — Enabled

Table 631. Details of iDRAC.LocalSecurity.PrebootConfig attribute (continued)

Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Logging

iDRAC. Logging Manages the ability to configure iDRAC

iDRAC.Logging.SELOEMEventFilterEnable (Read or Write)

Table 632. Details of iDRAC.Logging.SELOEMEventFilterEnable attribute

Description	Enables or disables the ability of Logging SEL Records with OEM.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NIC

To configure the iDRAC NIC, use the object in this group.

NOTE: The following objects are not valid for the modular systems:

- Auto negotiation
- Auto dedicated NIC
- Network speed
- Duplex
- Dedicated NIC scan time
- Shared NIC scan time

iDRAC.NIC.Autoconfig (Read or Write)

Table 633. Details of iDRAC.NIC.Autoconfig attribute

Description	Sets the DHCP auto configuration operation.
Legal Values	• 0 — Disabled **NOTE:** iDRAC does not perform DHCP configuration.

Table 633. Details of iDRAC.NIC.Autoconfig attribute (continued)

	• 1 — Enable Once **NOTE:** iDRAC performs DHCP configuration once. • 2 — Enable Once After Reset **NOTE:** Configures after iDRAC reset.
Default Values	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.NIC.AutoDetect (Read or Write)

Table 634. Details of iDRAC.NIC.AutoDetect attribute

Description	Enables or disables auto detection feature of iDRAC.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	This object is writable only when NIC Selection is in shared mode.

iDRAC.NIC.Autoneg (Read or Write)

Table 635. Details of iDRAC.NIC.Autoneg attribute

Description	Enables auto-negotiation of physical link speed and duplex.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NIC.DedicatedNICScanTime (Read or Write)

Table 636. Details of iDRAC.NIC.DedicatedNICScanTime attribute

Description	Wait time for the iDRAC to switch from dedicated mode to shared mode.
Legal Values	Integral values: 5–255
Default Value	5
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NIC.DNSDomainFromDHCP (Read or Write)

Table 637. Details of iDRAC.NIC.DNSDomainFromDHCP attribute

Description	Specifies that the iDRAC DNS domain name must be assigned from the network DHCP server.
Legal Values	• `0` — Disabled • `1` — Enabled
Default Value	`0` — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Can be Enabled only if the following are enabled: • `IPv4.Enable` and `IPv4.DHCPEnable` • `IPv6.Enable` and `IPv6.AutoConfig`

iDRAC.NIC.DNSDomainName (Read or Write)

Table 638. Details of iDRAC.NIC.DNSDomainName attribute

Description	The DNS Domain Name.
Legal Values	A string of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Can be set only if `NIC.DNSDomainFromDHCP` is disabled.

iDRAC.NIC.DNSDomainNameFromDHCP (Read or Write)

Table 639. Details of DRAC.NIC.DNSDomainNameFromDHCP attribute

Description	Specifies that the iDRAC DNS domain name must be assigned from the network DHCP server.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NIC.DNSRacName (Read or Write)

Table 640. Details of iDRAC.NIC.DNSRacName attribute

Description	The iDRAC name.
Legal Values	String of up to 63 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NIC.DNSRegister (Read or Write)

Table 641. Details of iDRAC.NIC.DNSRegister attribute

Description	Registers the iDRAC name with the DNS server.
Legal Values	• 0 — Disabled • 1 — Enabled
Default value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Can be Enabled only if `DNSRacName` is set.

iDRAC.NIC.Duplex (Read or Write)

Table 642. Details of iDRAC.NIC.Duplex attribute

Description	Specifies the duplex setting for the iDRAC NIC.
Legal Values	• 0 — Half • 1 — Full
Default value	1 — Full
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NIC.Enable (Read or Write)

Table 643. Details of iDRAC.NIC.Enable attribute

Description	Enables or Disables the iDRAC network interface controller.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NIC.Failover (Read or Write)

Table 644. Details of iDRAC.NIC.Failover attribute

Description	Enables or disables failover for iDRAC to switch from shared to dedicated.
Legal Values	• 0 — None • 2 — LOM1 • 3 — LOM2 • 4 — LOM3 • 5 — LOM4 • 6 — All
Default Value	0 — None
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Possible Values depend on current `NICSelection` settings.

iDRAC.NIC.MACAddress (Read or Write)

Table 645. Details of iDRAC.NIC.MACAddress attribute

Description	The MAC Address of the iDRAC.
Legal Values	String of up to 17 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NIC.MTU (Read or Write)

Table 646. Details of iDRAC.NIC.MTU attribute

Description	The size in bytes of the maximum transmission unit uses the iDRAC NIC.
Legal Values	Integral values: 576–1500
Default Value	1500
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NIC.Selection (Read or Write)

Table 647. Details of iDRAC.NIC.Selection attribute

Description	Specifies the current mode of operation for the iDRAC network interface controller.
Legal Values	• 1 — Dedicated • 2 — LOM1 • 3 — LOM2 • 4 — LOM3 • 5 — LOM4
Default Value	1 — Dedicated
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NOTE: Values for the platforms with single LOM port are, 1 — Dedicated and 2 — LOM1.

iDRAC.NIC.SharedNICScanTime (Read or Write)

Table 648. Details of iDRAC.NIC.SharedNICScanTime attribute

Description	Wait time for the iDRAC to switch from shared mode to dedicated mode.
Legal Values	Integral values: 5–255
Default Value	30
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NIC.Speed (Read or Write)

Table 649. Details of iDRAC.NIC.Speed attribute

Description	Specifies the speed for iDRAC NIC. **NOTE:** To set this property: • `iDRAC.NIC.Selection` must be set to `Dedicated` mode. • `iDRAC.NIC.Autoneg` must be disabled. • `iDRAC.IPv4.Enable`, `iDRAC.IPv4.DHCPEnable`, `iDRAC.IPv6.Enable`, and `iDRAC.IPv6.AutoConfig` must be enabled.
Legal Values	• `0` — 10 • `1` — 100 • `2` — 1000 **NOTE:** You cannot manually set the Network Speed to 1000 MB. This option is available only if `iDRAC.NIC.Autoneg` is set to `1` (Enabled).
Default Value	`1` — 100
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Cannot change NIC Speed unless AutoNeg is set to disabled.

iDRAC.NIC.TopologyLldp (Read or Write)

Table 650. Details of iDRAC.NIC.TopologyLldp attribute

Description	Enables or disables the LLDP Protocol
Legal Values	• Enable-1 • Disable-0
Default Value	0—Disable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise

Table 650. Details of iDRAC.NIC.TopologyLldp attribute (continued)

Dependency	None

iDRAC.NIC.VLanEnable (Read Only)

Table 651. Details of iDRAC.NIC.VLanEnable attribute

Description	Enables or disables the VLAN capabilities of the iDRAC. **NOTE:** This object is applicable only to iDRAC on Racks and Towers.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NIC.VLanID (Read Only)

Table 652. Details of iDRAC.NIC.VLanID attribute

Description	Specifies the VLAN ID for the network VLAN configuration. **NOTE:** This object is applicable only to iDRAC on Racks and Towers.
Legal Values	Integral values: 1–4069
Default Value	1
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NIC.VLanPort (Read or Write)

Table 653. Details of iDRAC.NIC.VLanPort attribute

Description	Enables or disables the VLAN switch of the iDRAC.
Legal Values	• 1 — Dedicated ports only • 2 — LOM ports only • 0 — Both the ports
Default Value	0 — Both
Write Privilege	Configure iDRAC
License Required	RACADM

Table 653. Details of iDRAC.NIC.VLanPort attribute (continued)

Dependency	None

iDRAC.NIC.VLanPriority (Read Only)

Table 654. Details of iDRAC.NIC.VLanPriority attribute

Description	Specifies the VLAN priority for the network VLAN configuration. **NOTE:** This object is applicable only to iDRAC on Racks and Towers.
Legal Values	Integral values: 0–7
Default Value	0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NICStatic

To manage DNS-related properties of iDRAC, use the objects in this group.

iDRAC.NICStatic.DNSDomainFromDHCP (Read or Write)

Table 655. Details of iDRAC.NICStatic.DNSDomainFromDHCP attribute

Description	Specifies that the iDRAC DNS domain name must be assigned from the network DHCP server.
Legal Values	String of up to 254 ASCII characters
Default Value	Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NICStatic.DNSDomainName (Read or Write)

Table 656. Details of iDRAC.NICStatic.DNSDomainName attribute

Description	The DNS Domain Name.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	Not Applicable
Write Privilege	Configure iDRAC

Table 656. Details of iDRAC.NICStatic.DNSDomainName attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NTPConfigGroup

To configure the properties of NTP server, use the objects in this group.

iDRAC.NTPConfigGroup.NTP1 (Read or Write)

Table 657. Details of iDRAC.NTPConfigGroup.NTP1 attribute

Description	Configure NTP Server 1 Address.
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NTPConfigGroup.NTP2 (Read or Write)

Table 658. Details of iDRAC.NTPConfigGroup.NTP2 attribute

Description	Configure NTP Server 2 Address.
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NTPConfigGroup.NTP3 (Read or Write)

Table 659. Details of iDRAC.NTPConfigGroup.NTP3 attribute

Description	Configure NTP Server 3 Address.
Legal Values	String of up to 254 ASCII characters.
Default Value	Not Applicable
Write Privilege	Configure iDRAC

Table 659. Details of iDRAC.NTPConfigGroup.NTP3 attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NTPConfigGroup.NTPEnable (Read or Write)

Table 660. Details of iDRAC.NTPConfigGroup.NTPEnable attribute

Description	On iDRAC, enable or disable NTP server access to iDRAC.
Legal Values	• 0—Disabled • 1—Enabled • 2—Chassis
Default Value	0—Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NTPConfigGroup.NTPMaxDist (Read or Write)

Table 661. Details of iDRAC.NTPConfigGroup.NTPMaxDist attribute

Description	NTP Maximum Distance
Legal Values	Integral values: 1–128
Default Value	16
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.OS-BMC

To manage OS-BMC pass-through feature, use the object in this group.

iDRAC.OS-BMC.AdminState (Read or Write)

Table 662. Details of iDRAC.OS-BMC.AdminState

Description	On iDRAC pass through, enable or disable administrative state of OS.
Legal Values	• 0 — Disabled • 1 — Enabled

Table 662. Details of iDRAC.OS-BMC.AdminState (continued)

Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Can be set only if `iDRAC.OS-BMC.PTCapability` is set to `Capable`.

iDRAC.OS-BMC.OSIpAddress (Read or Write)

Table 663. Details of iDRAC.OS-BMC.OSIpAddress

Description	IPv4 address of the host Operating System.
Legal Values	Valid IPv4 Address
Default Value	0.0.0.0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.OS-BMC.PTCapability (Read or Write)

Table 664. Details of iDRAC.OS-BMC.PTCapability

Description	Operating System to iDRAC Pass Through Capability status.
Legal Values	• 0 — Capable • 1 — Not Capable or Unknown
Default Value	Depends on the server capability.
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.OS-BMC.PTMode (Read or Write)

Table 665. Details of iDRAC.OS-BMC.PTMode

Description	Enables the pass-through with shared LOM or USB. **NOTE:** To enable the pass-through, make sure that `iDRAC.OS-BMC.AdminState` is enabled.
Legal Values	• 0 — lom-p2p • 1 — usb-p2p
Default Value	0 — lom-p2p

Table 665. Details of iDRAC.OS-BMC.PTMode (continued)

Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.OS-BMC.UsbNicIpAddress (Read or Write)

Table 666. Details of iDRAC.OS-BMC.UsbNicIpAddress

Description	Displays the USB NIC IP address.
Legal Values	Valid IPv4 address
Default Value	`169.168.0`
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Racadm

To manage Remote RACADM connection settings, use the object in this group.

iDRAC.Racadm.Enable (Read or Write)

Table 667. Details of iDRAC.Racadm.Enable

Description	Enables or disables Remote RACADM interface.
Legal Values	• `0` — Disabled • `1` — Enabled
Default Value	Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Racadm.Timeout (Read or Write)

Table 668. Details of iDRAC.Racadm.Timeout

Description	Defines the idle timeout in seconds of the Remote RACADM interface.
Legal Values	• `0` — No timeout • Integral values: 60–10800
Default Value	60

Table 668. Details of iDRAC.Racadm.Timeout (continued)

Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Redfish

The objects in this group provide configuration parameters for the Redfish interface to iDRAC.

iDRAC.Redfish.Enable (Read or Write)

Table 669. Details of iDRAC.Redfish.Enable

Description	Enables or disables Redfish service on iDRAC.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	RACADM
Dependency	None

iDRAC.Redfisheventing

The objects in this group provide information on Redfish events.

iDRAC.Redfisheventing.DeliveryRetryAttempts (Read or Write)

Table 670. Details of iDRAC.Redfisheventing.DeliveryRetryAttempts

Description	Specifies the number of retry attempts made for Redfish event delivery.
Legal Values	Value ranges from 0 to 5.
Default Value	3
Write Privilege	Configure iDRAC
License Required	RACADM
Dependency	None

iDRAC.Redfisheventing.DeliveryRetryIntervalInSeconds (Read or Write)

Table 671. Details of iDRAC.Redfisheventing.DeliveryRetryIntervalInSeconds

Description	Specifies the intervals (in seconds) of retry attempts made for Redfish event delivery.
Legal Values	Value ranges from 5 to 60.
Default Value	30
Write Privilege	Configure iDRAC
License Required	RACADM
Dependency	None

iDRAC.Redfisheventing.IgnoreCertificateErrors (Read Only)

Table 672. Details of iDRAC.Redfisheventing.IgnoreCertificateErrors

Description	Enables or disables Ignorance of Certificate Errors notifications.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	None
Dependency	None

iDRAC.RemoteHosts

Use the objects in this group to manage the properties for configuration of the SMTP server.

iDRAC.RemoteHosts.SMTPPort (Read or Write)

Table 673. Details of iDRAC.RemoteHosts.SMTPPort

Description	Specifies the destination port for email alerts.
Legal Values	Integral values: 1–65535
Default Value	25
Write Privilege	Configure iDRAC
License Required	iDRAC Express
Dependency	None

iDRAC.RemoteHosts.SMTPServerIPAddress (Read or Write)

Table 674. Details of iDRAC.RemoteHosts.SMTPServerIPAddress

Description	IPv4 or IPv6 address of the network SMTP server.
Legal Values	String representing a valid SMTP server IPv4 or IPv6 address
Default Value	`0.0.0.0`
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.RFS

To configure Remote file share access to iDRAC, use the object in this group.

NOTE: To perform the complete workflow for RFS and set attributes, see the remoteimage section.

iDRAC.RFS.IgnoreCertWarning (Read or Write)

Table 675. Details of idrac.rfs.ignoreCertWarning attribute

Description	To ignore certificate warning message.
Legal Values	• 0- Ignore • 1- Show error
Default Value	1-Show error
Write Privilege	Not Applicable
License Required	RACADM
Dependency	None

iDRAC.RFS.MediaAttachState (Read Only)

Table 676. Details of iDRAC.RFS.MediaAttachState

Description	RFS Media attach state.
Legal Values	• `0` — Attached • `1` — Detached
Default Value	`1` — Detached
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.RFS.WriteProtected (Read Only)

Description	RFS Write Protection
Legal Values	• Read Only-0 • Read Write-1
Default Value	0
Write Privilege	Server Configuration
License Required	iDRAC Enterprise
Dependancy	None

iDRAC.RSM

The objects in this group manage the Rack Style Management (RSM) settings.

iDRAC.RSM.RSMCapability (Read Only)

Table 677. Details of iDRAC.RSM.RSMCapability

Description	Specifies the status of RSM capability.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.RSM.RSMSetting (Read Only)

Table 678. Details of iDRAC.RSM.RSMSetting

Description	Specifies the status of RSM setting.
Legal Values	• 0 — None • 1 — Monitor • 2 — Manage and Monitor
Default Value	2 — Manage and Monitor
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.SecureDefaultPassword

The objects in this group enable force change password configuration.

iDRAC.SecureDefaultPassword.ForceChangePassword (Read or Write)

Description	Enables or disables force change password.
Legal Values	• 1 - True • 0 - False
Default Value	0 - False
Write Privilege	Server Control
License Required	iDRAC Enterprise
Dependency	Not applicable

iDRAC.Security

Use the objects in this group to configure SSL certificate signing request settings.

For the country code, see **http://www.iso.org/iso/home/standards/country_codes.htm**.

iDRAC.Security.CsrCommonName (Read or Write)

Table 679. Details of iDRAC.Security.CsrCommonName

Description	Specifies the CSR Common Name (CN) that must be an IP as given in the certificate.
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Security.CsrCountryCode (Read or Write)

Table 680. Details of iDRAC.Security.CsrCountryCode

Description	Specifies the CSR Country Code (CC).
Legal Values	String of a 2 Alphabet Country Code. For example: US
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Security.CsrEmailAddr (Read or Write)

Table 681. Details of iDRAC.Security.CsrEmailAddr

Description	Specifies the CSR email address.
Legal Values	Valid email address string of up to 254 ASCII characters.
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Security.CsrKeySize (Read or Write)

Table 682. Details of iDRAC.Security.CsrKeySize

Description	Specifies the SSL asymmetric key size for the CSRs.
Legal Values	• 1024 • 2048
Default Value	2048
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Security.CsrLocalityName (Read or Write)

Table 683. Details of iDRAC.Security.CsrLocalityName

Description	Specifies the CSR Locality (L).
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Security.CsrOrganizationName (Read or Write)

Table 684. Details of iDRAC.Security.CsrOrganizationName

Description	Specifies the CSR Organization Name (O).

Table 684. Details of iDRAC.Security.CsrOrganizationName (continued)

Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Security.CsrOrganizationUnit (Read or Write)

Table 685. Details of iDRAC.Security.CsrOrganizationUnit

Description	Specifies the CSR Organization Unit (OU).
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Security.CsrStateName (Read or Write)

Table 686. Details of iDRAC.Security.CsrStateName

Description	Specifies the CSR State Name (S).
Legal Values	String of up to 254 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Security.CsrSubjectAltName (Read or Write)

Table 687. Details of iDRAC.Security.CsrSubjectAltName attribute

Description	Specifies the CSR subject alternative name.
Legal Values	String of up to 1024 ASCII characters **NOTE:** In the RACADM autocomplete mode, the string value up to 512 characters are supported. If the value length is 512 and more, execute this command in the normal execution mode.
Default Value	Null

Table 687. Details of iDRAC.Security.CsrSubjectAltName attribute (continued)

Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Security.FIPSMode (Read or Write)

Table 688. Details of iDRAC.Security.FIPSMode

Description	Enables or disables the FIPS mode compliance. Enabling FIPS mode resets iDRAC configuration to factory defaults
Legal Values	• 1 - Enabled • 0 - Disabled
Default Value	0 - Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NOTE: Setting FIPSMode to 0 - Disabled, will not have any effect.

NOTE: To disable FIPSmode, reset the iDRAC to factory default setting (racadm racresetcfg).

NOTE: If FIPS is enabled, you cannot perform any actions associated with the vFlash SD card, such as configuring the vFlash SD card, exporting or backing up server profile to the vFlash, or importing server profile using vFlash.

iDRAC.Serial

The objects in this group provide configuration parameters for the serial interface of iDRAC.

NOTE: This is supported only for rack and tower systems.

iDRAC.Serial.BaudRate (Read or Write)

Table 689. Details of iDRAC.Serial.BaudRate

Description	Sets the Baud rate on the iDRAC serial port.
Legal Values	• 9600 • 19200 • 57600 • 115200
Default Value	115200
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise

Table 689. Details of iDRAC.Serial.BaudRate (continued)

Dependency	None

iDRAC.Serial.Command (Read or Write)

Table 690. Details of iDRAC.Serial.Command

Description	Specifies a serial command that is executed after the user logs in to the serial console interface.
Legal Values	String of up to 128 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Serial.Enable (Read or Write)

Table 691. Details of iDRAC.Serial.Enable

Description	Enables or disables the iDRAC serial console interface.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Serial.HistorySize (Read or Write)

Table 692. Details of iDRAC.Serial.HistorySize

Description	Specifies the maximum size of the serial history buffer.
Legal Values	Integral values from 0 to 8192.
Default Value	8192
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Serial.IdleTimeout (Read or Write)

Table 693. Details of iDRAC.Serial.IdleTimeout

Description	The maximum number of seconds to wait before an idle serial console session is disconnected.
Legal Values	• 0 — No timeout • Integral values: 60–10800
Default Value	300
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Serial.NoAuth (Read or Write)

Table 694. Details of iDRAC.Serial.NoAuth

Description	Enables or disables iDRAC serial console login authentication.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.SerialRedirection

The objects in this group manage Serial Redirection properties of iDRAC.

NOTE: It supports only rack and tower systems.

iDRAC.SerialRedirection.Enable (Read or Write)

Table 695. Details of iDRAC.SerialRedirection.Enable

Description	Enables or disables the console for COM2 port redirection.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise

Table 695. Details of iDRAC.SerialRedirection.Enable (continued)

Dependency	None

iDRAC.SerialRedirection.QuitKey (Read or Write)

Table 696. Details of iDRAC.SerialRedirection.QuitKey

Description	This key or key combination terminates the Virtual Console when using the console `COM2` command.
Legal Values	**Ctrl** key followed by alphabets (a-z or A-Z), ^\
Default Value	^\
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.serverboot

The objects in this group manages the server boot options.

iDRAC.serverboot.BootOnce (Read or Write)

Table 697. Details of iDRAC.serverboot.BootOnce

Description	Enables or disables `BootOnce` option for the configured device.
Legal Values	• `0` — Disabled • `1` — Enabled
Default values	`1` — Enabled
Write Privilege	Login and configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read only if **iDRAC.ServerBoot.FirstBootDevice** is set to either BIOS (BIOS Setup), F10 (Lifecycle Controller), or F11 (BIOS Boot Manager).

iDRAC.serverboot.FirstBootDevice (Read or Write)

Table 698. Details of iDRAC.serverboot.FirstBootDevice

Description	Configures the first boot device.
Legal Values	• Normal • PXE • HDD (Hard Disk Drive) • CD-DVD (Local CD/DVD) • BIOS (BIOS Setup) • vFDD (Virtual Floppy) • VCD-DVD (Virtual CD/DVD/ISO) • FDD (Local Floppy/Primary Removable Media)

Table 698. Details of iDRAC.serverboot.FirstBootDevice (continued)

	• SD (Local SD Card) • F10 (Lifecycle Controller) • F11 (BIOS Boot Manager) • Attached vFlash Partition Label
Default value	Normal
Write Privilege	Login and configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.ServiceModule

The objects in this group manages the properties of the ISM modules.

iDRAC.ServiceModule.ChipsetSATASupported (Read or Write)

Description Monitors SMART attributes of devices behind SATA controller and audits appropriately in Lifecycle Log.

Legal Values
- 0 - False
- 1 - True
- 2 - NA

Default Value 1- True

Write Privilege Server Control

License Required iDRAC Enterprise

Dependency Not applicable

iDRAC.ServiceModule.HostSNMPGet (Read or Write)

Table 699. Details of iDRAC.ServiceModule.HostSNMPGet attribute

Description	Enables or disables SNMP get using host OS.
Legal Values	• 0 - Disabled • 1 - Enabled
Default Value	0 - Disabled
Write Privilege	Not Applicable
License Required	RACADM
Dependency	None

iDRAC.ServiceModule.HostSNMPAlert (Read or Write)

Description Specifies the destination port for remote hosts.

Legal Values
- Disabled-0
- Enabled-1

Default Value 0

Write Privilege	Configure iDRAC
License Required	iDRAC Basic
Dependancy	None

iDRAC.ServiceModule.HostSNMPGet

Table 700. Details of iDRAC.ServiceModule.HostSNMPGet attribute

Description	Enable or disable SNMP get via host OS.
Legal Values	• 0 - Disabled • 1 - Enabled, Default - 0
Default Value	0—Default
Write Privilege	Not Applicable
License Required	RACADM
Dependency	None

iDRAC.ServiceModule.iDRACHardReset (Read or Write)

Table 701. Details of iDRAC.ServiceModule.iDRACHardReset

Description	Resets iDRAC when it is unresponsive.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	RACADM
Dependency	iDRAC.ServiceModule.ServiceModuleEnable attribute must be enabled.

iDRAC.ServiceModule.LCLReplication (Read or Write)

Table 702. Details of iDRAC.ServiceModule.LCLReplication

Description	Enables Lifecycle log in operating system log Baud rate on the iDRAC serial port.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	If OpenManage Server Administrator is available, then the attribute is automatically set to 'Disabled'.

iDRAC.ServiceModule.OMSAPresence (Read Only)

Table 703. Details of iDRAC.ServiceModule.OMSAPresence

Description	Verifies if OMSA is present.
Legal Values	• 0 — Not Present • 1 — Present • 2 — NA
Default Value	2 — NA
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.ServiceModule.OSInfo (Read or Write)

Table 704. Details of iDRAC.ServiceModule.OSInfo

Description	Provides information about operating system through iDRAC Service Module.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.ServiceModule.ServiceModuleEnable (Read or Write)

Table 705. Details of iDRAC.ServiceModule.ServiceModuleEnable

Description	Disables the Service Module process on host operating system.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.ServiceModule.ServiceModuleState (Read or Write)

Table 706. Details of iDRAC.ServiceModule.ServiceModuleState

Description	Indicates the status of Service Module process on the host operating system.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled

Table 706. Details of iDRAC.ServiceModule.ServiceModuleState (continued)

Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.ServiceModule.ServiceModuleVersion (Read)

Table 707. Details of iDRAC.ServiceModule.ServiceModuleVersion

Description	Displays the installed version of iDRAC Service Module.
Legal Values	None
Default Value	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.ServiceModule.SSEventCorrelation(Read or Write)

Description	Maps the Storage Spaces events on host OS in Lifecycle Log.
Legal Values	• 0 - False • 1 - True
Default Value	1- True
Write Privilege	Server Control
License Required	iDRAC Enterprise
Dependency	Not applicable

iDRAC.ServiceModule.WatchdogRecoveryAction (Read and Write)

Table 708. Details of iDRAC.ServiceModule.WatchdogRecoveryAction

Description	Configures recovery action on watchdog alert.
Legal Values	• 0 — None • 1 — Reboot • 2 — Poweroff • 3 — Powercycle
Default Value	0 — None
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	If the iDRAC.ServiceModule.WatchdogState object is 'Disabled', then the value cannot be set.

iDRAC.ServiceModule.WatchdogResetTime (Read and Write)

Table 709. Details of iDRAC.ServiceModule.WatchdogResetTime

Description	Configures the system reset time (unit in seconds) on watchdog alert.
Legal Values	Values in range 60–720
Default Value	480
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	If the iDRAC.ServiceModule.WatchdogState object is 'Disabled', then the value cannot be set.

iDRAC.ServiceModule.WatchdogState (Read and Write)

Table 710. Details of iDRAC.ServiceModule.WatchdogState

Description	Enables or disables the watchdog timer through iDRAC Service Module.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	The value is disabled if OpenManage Server Administrator is detected or operating system Watchdog is enabled.

iDRAC.ServiceModule.WMIInfo (Read or Write)

Description	Enable or disable WMIInfo via iDRAC Service Module. Provides WMI Interfaces which otherwise will be provided with OMSA.
Legal Values	• Disabled-0 • Enabled-1
Default Value	0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic
Dependancy	None

iDRAC.SmartCard

The objects in this group enable you to access iDRAC using a smart card.

iDRAC.SmartCard.SmartCardCRLEnable (Read or Write)

Table 711. Details of iDRAC.SmartCard.SmartCardCRLEnable

Description	Enables or disables the Certificate Revocation List (CRL).

Table 711. Details of iDRAC.SmartCard.SmartCardCRLEnable (continued)

Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	To log on, enable Smart Card.

iDRAC.SmartCard.SmartCardLogonEnable (Read or Write)

Table 712. Details of iDRAC.SmartCard.SmartCardLogonEnable

Description	Enables or disables Smart card login support.
Legal Values	• 0 — Disabled • 1 — Enabled • 2 — Enabled with Remote RACADM
Default Value	Not Applicable
Write Privilege	Configure iDRAC and configure user
License Required	iDRAC Enterprise
Dependency	Disable `ActiveDirectory.SSOEnable`

iDRAC.SNMP

The objects in this group enable you to configure the SNMP agent and trap capabilities.

iDRAC.SNMP.AgentCommunity (Read or Write)

Table 713. Details of iDRAC.SNMP.AgentCommunity

Description	Specifies the SNMP community name to be used for SNMP Agent
Legal Values	String of up to 31 ACSII characters
Default value	Public
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.SNMP.AgentEnable (Read or Write)

Table 714. Details of iDRAC.SNMP.AgentEnable

Description	Enables or disables the SNMP Agent on the iDRAC.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.SNMP.AlertPort (Read or Write)

Table 715. Details of iDRAC.SNMP.AlertPort

Description	Specifies the SNMP alert port for traps.
Legal Values	Integral values: 1–65535
Default Value	162
Write Privilege	Configure iDRAC
License Required	iDRAC Express
Dependency	None

iDRAC.SNMP.DiscoveryPort (Read or Write)

Table 716. Details of iDRAC.SNMP.DiscoveryPort

Description	Specifies the SNMP agent port on iDRAC.
Legal Values	Integral values: 1–65535
Default Value	161
Write Privilege	Configure iDRAC
License Required	iDRAC Express
Dependency	None

iDRAC.SNMP.SNMPProtocol (Read or Write)

Table 717. Details of iDRAC.SNMP.SNMPProtocol

Description	Specifies the SNMP protocol.
Legal Values	• 0 — All • 1 — SNMPv3

Table 717. Details of iDRAC.SNMP.SNMPProtocol (continued)

Default Value	0 — All
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.SNMP.TrapFormat (Read or Write)

Table 718. Details of iDRAC.SNMP.TrapFormat

Description	Specifies the SNMP format.
Legal Values	• 0 — SNMPv1 • 1 — SNMPv2 • 2 — SNMPv3
Default Value	0 — SNMPv1
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.SNMP.Alert

The objects in this group configures the SNMP alert settings.

This group is indexed from 1 to 8.

iDRAC.SNMP.Alert.DestAddr (Read or Write)

Table 719. Details of iDRAC.SNMP.Alert.DestAddr

Description	IPv4, IPv6 or FQDN address of the target destination to receive alters.
Legal Values	Valid IPv4 or IPv6 or FQDN address
Default Value	• Index 1–4 — 0.0.0.0 • Index 5–8 — ::
Write Privilege	Configure iDRAC
License Required	None
Dependency	None

iDRAC.SNMP.Alert.Enable (Read or Write)

Table 720. Details of iDRAC.SNMP.Alert.Enable

Description	Enables or disables SNMP alert for the given index.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	None
Dependency	None

iDRAC.SNMP.Alert.SNMPv3UserID (Read Only)

Table 721. Details of iDRAC.SNMP.Alert.SNMPv3UserID

Description	Indicates the index of the user to which this alert is configured.
Legal Values	Integral values: 2–16
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express
Dependency	None

iDRAC.SNMP.Alert.SNMPv3Username (Read or Write)

Table 722. Details of iDRAC.SNMP.Alert.SNMPv3Username

Description	Specifies the SNMP v3 user name for the given index.
Legal Values	String of up to 16 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express
Dependency	None

iDRAC.SSH

The objects in this group provide configuration parameters for the SSH interface to iDRAC.

iDRAC.SSH.Enable (Read or Write)

Table 723. Details of iDRAC.SSH.Enable

Description	Enables or disables SSH.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.SSH.Port (Read or Write)

Table 724. Details of iDRAC.SSH.Port

Description	Specifies the port number for the iDRAC SSH interface.
Legal Values	Integral values: 1–65535
Default Value	22
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.SSH.Timeout (Read or Write)

Table 725. Details of iDRAC.SSH.Timeout

Description	Defines the secure shell idle timeout.
Legal Values	Integral values: 0–10800
Default Value	1800
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.SupportAssist

The objects in this group enable you to configure the SupportAssist capabilities.

iDRAC.SupportAssist.HostOSProxyAddress

Table 726. Details of iDRAC.SupportAssist.HostOSProxyAddress

Description	Host OS proxy address.
Legal Values	String of 0 to 256 characters length
Default Value	NA
License Required	RACADM
Dependency	HostOSProxyConfigured should be 1 - Yes

iDRAC.SupportAssist.HostOSProxyConfigured

Table 727. Details of iDRAC.SupportAssist.HostOSProxyConfigured

Description	Indicates whether Host OS uses proxy configuration to connect to Internet.
Legal Values	0-No 1-Yes
Default Value	0-No
License Required	RACADM
Dependency	None

iDRAC.SupportAssist.HostOSProxyPassword

Table 728. Details of iDRAC.SupportAssist.HostOSProxyPassword

Description	Host OS proxy password.
Legal Values	String of 0 to 64 characters length
Default Value	NA
License Required	RACADM
Dependency	HostOSProxyConfigured should be 1=Yes

iDRAC.SupportAssist.HostOSProxyPort

Table 729. Details of iDRAC.SupportAssist.HostOSProxyPort

Description	Host OS proxy port.
Legal Values	Integer values from 0 to 65535.
Default Value	NA
License Required	RACADM

Table 729. Details of iDRAC.SupportAssist.HostOSProxyPort (continued)

Dependency	HostOSProxyConfigured should be 1=Yes

iDRAC.SupportAssist.HostOSProxyUserName

Table 730. Details of iDRAC.SupportAssist.HostOSProxyUserName

Description	Host OS proxy password.
Legal Values	String of 0 to 64 characters length
Default Value	NA
License Required	RACADM
Dependency	HostOSProxyConfigured should be Yes-1

iDRAC.SysLog

The objects in this group provide the properties for configuration of the SMTP server.

iDRAC.SysLog.Port (Read or Write)

Table 731. Details of iDRAC.SysLog.Port

Description	Remote syslog port number.
Legal Values	Integral values: 1–65535
Default Value	514
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.SysLog.PowerLogEnable (Read or Write)

Table 732. Details of iDRAC.SysLog.PowerLogEnable

Description	Enables or disables the Power Log feature.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise

Table 732. Details of iDRAC.SysLog.PowerLogEnable (continued)

Dependency	None

iDRAC.SysLog.PowerLogInterval (Read or Write)

Table 733. Details of iDRAC.SysLog.PowerLogInterval

Description	Configure time delay for power logging.
Legal Values	Integral values: 1–1440
Default Value	5
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.SysLog.Server1 (Read or Write)

Table 734. Details of iDRAC.SysLog.Server1

Description	Name of remote syslog server 1.
Legal Values	String of up to 63 ACSII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.SysLog.Server2 (Read or Write)

Table 735. Details of iDRAC.SysLog.Server2

Description	Name of remote syslog server 2.
Legal Values	String of up to 63 ACSII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.SysLog.Server3 (Read or Write)

Table 736. Details of iDRAC.SysLog.Server3

Description	Name of remote syslog server 3.
Legal Values	String of up to 63 ACSII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.SysLog.SysLogEnable (Read or Write)

Table 737. Details of iDRAC.SysLog.SysLogEnable

Description	Enables or disables remote syslog.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.Telnet

The objects in this group provide configuration parameters for the Telnet interface to iDRAC.

iDRAC.Telnet.Enable (Read or Write)

Table 738. Details of iDRAC.Telnet.Enable

Description	Enables or disables Telnet.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Telnet.Port (Read or Write)

Table 739. Details of iDRAC.Telnet.Port

Description	Specifies the port number for the iDRAC Telnet interface.
Legal Values	Integral values: 1–65535
Default Value	23
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Time

The objects in this group enable you to manage time zone setting for iDRAC.

iDRAC.Time.DayLightOffset (Read or Write)

Table 740. Details of iDRAC.Time.DayLightOffset

Description	Specifies the daylight savings offset (in minutes) to use for the iDRAC Time.
Legal Values	Integral values: 0 – 60
Default Value	0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Time.Timezone (Read or Write)

Table 741. Details of iDRAC.Time.Timezone

Description	Configure the time zone.
Legal Values	Valid time zone string of up to 32 ASCII characters For example: US/Central
Default Value	CST6CDT
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Time.TimeZoneOffset (Read or Write)

Table 742. Details of iDRAC.Time.TimeZoneOffset

Description	Specifies the time zone offset (in minutes) from Greenwich Mean Time (GMT) or Coordinated Universal Time (UTC) to use for the iDRAC Time.
Legal Values	Integral values: -43200 – 46800
Default Value	0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Tuning

The objects in this group enable you to manage iDRAC tuning and configuration parameters.

iDRAC.Tuning.DefaultCredentialWarning (Read or Write)

Table 743. Details of iDRAC.Tuning.DefaultCredentialWarning

Description	Enables or disables the default credentials warning.
Legal Values	• `0` — Disabled • `1` — Enabled
Default Value	`1` — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Update

The objects in this group enable you to manage configuration parameters for iDRAC firmware update.

NOTE: `fwUpdateIPAddr` attribute is applicable for Monolithic & FX2/FX2s only.

iDRAC.Update.FwUpdateIPAddr (Read or Write)

Table 744. Details of iDRAC.Update.FwUpdateIPAddr

Description	Specifies the TFTP server address to be used for iDRAC firmware update operations.
Legal Values	Valid IPv4, IPv6, or FQDN address of the TFTP server
Default Value	Not Applicable
Write Privilege	Configure iDRAC

Table 744. Details of iDRAC.Update.FwUpdateIPAddr (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Update.FwUpdatePath (Read or Write)

Table 745. Details of iDRAC.Update.FwUpdatePath

Description	Specifies TFTP path where iDRAC firmware image resides on TFTP server. Path is relative to TFTP root folder.
Legal Values	String of up to 255 ACSII characters. For example: /images/12G/
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Update.FwUpdateTFTPEnable (Read or Write)

Table 746. Details of iDRAC.Update.FwUpdateTFTPEnable

Description	Enables or disables iDRAC firmware updates from a TFTP server.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.USB

The objects in this group manages the front panel USB.

iDRAC.USB.ConfigurationXML (Read or Write)

Table 747. Details of iDRAC.USB.ConfigurationXML attribute

Description	Manages the configuration xml feature using the front panel USB.
Legal Values	• Disabled • Enabled while server has default credential settings only • Enabled

Table 747. Details of iDRAC.USB.ConfigurationXML attribute (continued)

Default Value	Enabled while server has default credential settings only.
Write Privilege	Server Control
License Required	iDRAC Express and iDRAC Enterprise
Dependency	Not Applicable

iDRAC.USB.ManagementPortMode (Read Only)

Table 748. Details of iDRAC.USB.ManagementPortMode attribute

Description	Displays the front panel USB mode.
Legal Values	• Automatic • Standard OS Use • iDRAC Direct Only
Default Value	Automatic
Write Privilege	Not Applicable
License Required	iDRAC Express and iDRAC Enterprise
Dependency	Not Applicable

iDRAC.USB.PortStatus (Read or Write)

Description	Displays the status set from BIOS for front panel USB port. This can be either Enabled or Disabled.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Basic
Dependancy	None

iDRAC.Telnet.Timeout (Read or Write)

Table 749. Details of iDRAC.Telnet.Timeout attribute

Description	Defines the Telnet idle timeout.
Legal Values	Integral values: 0–10800
Default Value	1800
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.UserDomain

The objects in this group enable you to manage the Active Directory user domain names. This group is indexed from 1 to 40.

iDRAC.UserDomain.Name (Read or Write)

Table 750. Details of iDRAC.UserDomain.Name attribute

Description	Specifies the Active Directory user domain name for a given index.
Legal Values	String of up to 255 ACSII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Users

The objects in this group enable you to manage information about all iDRAC users. This group is indexed from 1 to 16.

iDRAC.Users.Enable (Read or Write)

Table 751. Details of iDRAC.Users.Enable attribute

Description	Enables or disables an individual user.
Legal Values	• `0` — Disabled • `1` — Enabled
Default Value	`0` — Disabled. However, `Root user` is Enabled.
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Both username and password must be configured prior to enabling the user.

iDRAC.Users.IpmiLanPrivilege (Read or Write)

Table 752. Details of iDRAC.Users.IpmiLanPrivilege attribute

Description	Specifies the maximum privilege on the IPMI LAN channel.
Legal Values	Integral values: • `2` — User • `3` — Operator • `4` — Administrator • `15` — No access

Table 752. Details of iDRAC.Users.IpmiLanPrivilege attribute (continued)

Default Value	15 — No access
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Both user name and password must be configured prior to setting this object.

iDRAC.Users.IpmiSerialPrivilege (Read or Write)

Table 753. Details of iDRAC.Users.IpmiSerialPrivilege attribute

Description	Specifies the maximum IPMI Serial privilege.
Legal Values	Integral values: • 2 — User • 3 — Operator • 4 — Administrator • 15 — No access
Default Value	15 — No access
Write Privilege	Configure iDRAC and user
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Both username and password must be configured prior to setting this object.

iDRAC.Users.MD5v3Key (Read or Write)

Table 754. Details of iDRAC.Users.MD5v3Key attribute

Description	Indicates the MD5 Hash of the SNMP V3 key.
Legal Values	String of 32 characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express
Dependency	User name must be configured prior to setting MD5v3Key.

iDRAC.Users.Password (Read or Write)

Table 755. Details of iDRAC.Users.Password attribute

Description	Configuring the iDRAC user password.
Legal Values	String of up to 20 characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC

Table 755. Details of iDRAC.Users.Password attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Cannot be set without first setting the user name.

iDRAC.Users.SHA256Password (Read or Write)

Table 756. Details of iDRAC.Users.SHA256Password attribute

Description	Indicates the SHA256 hash of the password.
Legal Values	String of 64 characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and Configure User
License Required	iDRAC Express
Dependency	User name must be configured prior to setting this object.

iDRAC.Users.SHA256PasswordSalt (Read or Write)

Table 757. Details of iDRAC.Users.SHA256PasswordSalt attribute

Description	Indicates the Salt string added to password before hash.
Legal Values	String of 32 characters
Write Privilege	Configure iDRAC and Configure User
License Required	iDRAC Express
Dependency	User name must be configured prior to setting this object.

iDRAC.Users.Privilege (Read or Write)

Table 758. Details of iDRAC.Users.Privilege attribute

Description	Specifies the role-based authority privileges allowed for the user.
Legal Values	Integral values: 0–511 (0x1FF)
Default Value	0
Write Privilege	Configure iDRAC and Configure User
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Both user name and password must be configured prior to setting this object.

iDRAC.Users.SHA1v3Key (Read or Write)

Table 759. Details of iDRAC.Users.SHA1v3Key attribute

Description	Indicates the SHA1 Hash of the SNMP V3 key.

Table 759. Details of iDRAC.Users.SHA1v3Key attribute (continued)

Legal Values	String of 40 characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and Configure User
License Required	iDRAC Express
Dependency	User name must be configured prior to setting SHA1v3Key.

iDRAC.Users.SNMPv3AuthenticationType (Read or Write)

Table 760. Details of iDRAC.Users.SNMPv3AuthenticationType attribute

Description	Configure SNMPv3 authentication protocol type.
Legal Values	• 0 — None • 1 — MD5 • 2 — SHA
Default Value	2 — SHA
Write Privilege	Configure iDRAC and Configure User
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Users.SNMPv3Enable (Read or Write)

Table 761. Details of iDRAC.Users.SNMPv3Enable attribute

Description	Enables or disables SNMPv3 support for an iDRAC User.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC and Configure User
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Users.SNMPv3PrivacyType (Read or Write)

Table 762. Details of iDRAC.Users.SNMPv3PrivacyType attribute

Description	Configure SNMPv3 privacy protocol type.
Legal Values	• 0 — None • 1 — DES • 2 — AES

Table 762. Details of iDRAC.Users.SNMPv3PrivacyType attribute (continued)

Default Value	2 — AES
Write Privilege	Configure iDRAC and Configure User
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Users.SolEnable (Read or Write)

Table 763. Details of iDRAC.Users.SolEnable attribute

Description	Enables or Disables SOL for the user.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Configure iDRAC and Configure User
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Both username and password must be configured prior to sets.

iDRAC.Users.UserName (Read or Write)

Table 764. Details of iDRAC.Users.UserName attribute

Description	iDRAC User Name.
Legal Values	String of up to 16 ASCII characters
Default Value	Not Applicable
Write Privilege	Configure iDRAC and Configure User
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.vflashpartition

The objects in this group manage vFlash SD partitions on iDRAC.

This group supports the following objects. Up to 16 partitions are supported, indexed from 1 to 16.

iDRAC.vflashpartition.AccessType (Read or Write)

Table 765. Details of iDRAC.vflashpartition.AccessType attribute

Description	Specifies if the access type of the vFlash SD partition is Read-Only or Read-Write.

Table 765. Details of iDRAC.vflashpartition.AccessType attribute (continued)

Legal Values	• 1 — Read Only • 0 — Read Write
Default value	1 — Read Only
Write Privilege	Login and configure iDRAC
License Required	iDRAC Enterprise
Dependency	vFlash SD card must be enabled. Partition at the specified index must be created.

iDRAC.vflashpartition.AttachState (Read or Write)

Table 766. Details of iDRAC.vflashpartition.AttachState attribute

Description	Specifies if the vFlash SD partition is attached or detached.
Legal Values	• 1 — Attached • 0 — Detached
Default value	0 — Detached
Write Privilege	Login and configure iDRAC
License Required	iDRAC Enterprise
Dependency	vFlash SD card must be enabled. Partition at the specified index must be created.

iDRAC.vflashpartition.EmulationType (Read or Write)

Table 767. Details of iDRAC.vflashpartition.EmulationType attribute

Description	Specifies the emulation type of the vFlash SD partition.
Legal Values	• HDD • FLOPPY • CD-DVD
Default value	None
Write Privilege	Login and configure iDRAC
License Required	iDRAC Enterprise
Dependency	vFlash SD card must be enabled. Partition at the specified index must be created.

iDRAC.vflashpartition.FormatType (Read or Write)

Table 768. Details of iDRAC.vflashpartition.FormatType attribute

Description	Specifies the file system format type of the vFlash SD partition.
Legal Values	• FAT16 • FAT32 • EXT2 • EXT3 • RAW
Default value	None

Table 768. Details of iDRAC.vflashpartition.FormatType attribute (continued)

Write Privilege	Login and configure iDRAC
License Required	iDRAC Enterprise
Dependency	vFlash SD card must be enabled. Partition at the specified index must be created.

iDRAC.vflashpartition.Size (Read or Write)

Table 769. Details of iDRAC.vflashpartition.Size attribute

Description	Specifies the Size of the vFlash SD partition.
Legal Values	Integer value in MB
Default value	None
Write Privilege	Login and configure iDRAC
License Required	iDRAC Enterprise
Dependency	vFlash SD card must be enabled. Partition at the specified index must be created.

iDRAC.vflashpartition.VolumeLabel (Read or Write)

Table 770. Details of iDRAC.vflashpartition.VolumeLabel attribute

Description	Specifies the label assigned to the partition during the vFlash SD partition creation.
Legal Values	String of up to six characters.
Default value	None
Write Privilege	Login and configure iDRAC
License Required	iDRAC Enterprise
Dependency	vFlash SD card must be enabled. Partition at the specified index must be created.

iDRAC.vflashsd

The objects in this group manage vFlash SD properties on iDRAC.

iDRAC.vflashsd.AvailableSize (Read or Write)

Table 771. Details of iDRAC.vflashsd.AvailableSize attribute

Description	Displays the available memory (in MB) on the vFlash SD card that is used to create new partitions.
Legal Values	Integer value in MB.
Default value	If the card is not initialized, then the default value is 0. If initialized, then it displays the unused memory on the card.
Write Privilege	Login and configure iDRAC
License Required	iDRAC Enterprise
Dependency	vFlash SD card must be enabled.

iDRAC.vflashsd.Enable (Read or Write)

Table 772. Details of iDRAC.vflashsd.Enable attribute

Description	Enables or disables the vFlash SD card on iDRAC.
Legal Values	• 0 — Disabled • 1 — Enabled
Default value	0 — Disabled
Write Privilege	Login and configure iDRAC
License Required	iDRAC Enterprise
Dependency	vFlash SD card must be enabled.

iDRAC.vflashsd.Health (Read or Write)

Table 773. Details of iDRAC.vflashsd.Health attribute

Description	Specifies current health status of the vFlash SD Card.
Legal Values	• OK • Warning • Critical • Unknown
Default value	OK
Write Privilege	Login and configure iDRAC
License Required	iDRAC Enterprise
Dependency	vFlash SD card must be enabled.

iDRAC.vflashsd.Initialized (Read or Write)

Table 774. Details of attribute

Description	Specifies if the vFlash SD card is initialized or not.
Legal Values	• 0 — Not Initialized • 1 — Initialized
Default value	None
Write Privilege	Login and configure iDRAC
License Required	iDRAC Enterprise
Dependency	vFlash SD card must be enabled.

iDRAC.vflashsd.Licensed (Read or Write)

Table 775. Details of iDRAC.vflashsd.Licensed attribute

Description	Specifies if the SD card or vFlash SD card is inserted or not.
Legal Values	• 0 — Not Licensed • 1 — Licensed

Table 775. Details of iDRAC.vflashsd.Licensed attribute (continued)

Default value	None
Write Privilege	Login and configure iDRAC
License Required	iDRAC Enterprise
Dependency	vFlash SD card must be enabled.

iDRAC.vflashsd.Size (Read or Write)

Table 776. Details of DRAC.vflashsd.Size attribute

Description	Specifies the remaining size of the vFlash SD card for usage.
Legal Values	Integer value in MB.
Default value	None
Write Privilege	Login and configure iDRAC
License Required	iDRAC Enterprise
Dependency	vFlash SD card must be enabled.

iDRAC.vflashsd.WriteProtect (Read or Write)

Table 777. Details of iDRAC.vflashsd.WriteProtect attribute

Description	Displays if the physical write protect is enabled or disabled on the vFlash SD card.
Legal Values	• 0 — Disabled • 1 — Enabled
Default value	None
Write Privilege	Login and configure iDRAC
License Required	iDRAC Enterprise
Dependency	vFlash SD card must be enabled.

iDRAC.VirtualConsole

The objects in this group enable you to manage virtual console configuration parameters of iDRAC.

iDRAC.VirtualConsole.AccessPrivilege (Read or Write)

Table 778. Details of iDRAC.VirtualConsole.AccessPrivilege attribute

Description	Default action upon session sharing request timeout.
Legal Values	• 0 — Deny Access • 1 — Read Only Access • 2 — Full Access
Default Value	0 — Deny Access

Table 778. Details of iDRAC.VirtualConsole.AccessPrivilege attribute (continued)

Write Privilege	Configure iDRAC
License Required	iDRAC Express (For Blades) or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.AttachState (Read or Write)

Table 779. Details of iDRAC.VirtualConsole.AttachState attribute

Description	Specifies the Attach State for the Virtual Console.
Legal Values	• 0- Detached • 1-Attached • 2-Auto-Attach
Default Value	2-Auto-Attach
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.Enable (Read or Write)

Table 780. Details of iDRAC.VirtualConsole.Enable attribute

Description	Enables or disables the Virtual Console.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express (For Blades) or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.EncryptEnable (Read or Write)

Table 781. Details of iDRAC.VirtualConsole.EncryptEnable attribute

Description	Encrypts the video in a Virtual Console session.
Legal Values	• 0 - Disabled • 1 - Enabled
Write Privilege	Configure iDRAC

Table 781. Details of iDRAC.VirtualConsole.EncryptEnable attribute (continued)

License Required	iDRAC Express (For Blades) or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.LocalVideo (Read or Write)

Table 782. Details of iDRAC.VirtualConsole.LocalVideo attribute

Description	Enables or disables the local server video.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express (For Blades) or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.MaxSessions (Read or Write)

Table 783. Details of iDRAC.VirtualConsole.MaxSessions attribute

Description	Specifies maximum number of virtual console sessions.
Legal Values	Integral values: 1–4
Default Value	4
Write Privilege	Configure iDRAC
License Required	iDRAC Express (For Blades) or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.PluginType (Read or Write)

Table 784. Details of iDRAC.VirtualConsole.PluginType attribute

Description	Specifies the plugin type to use while running virtual console from the browser.
Legal Values	• 0 — Active X • 1 — Java • 2 — HTML5
Default Value	0 — Active X
Write Privilege	Configure iDRAC
License Required	iDRAC Express (For Blades) or iDRAC Enterprise

Table 784. Details of iDRAC.VirtualConsole.PluginType attribute (continued)

Dependency	None

iDRAC.VirtualConsole.Port (Read or Write)

Table 785. Details of iDRAC.VirtualConsole.Port attribute

Description	Specifies the virtual KVM port.
Legal Values	Integral values: 1–65535
Default Value	5900
Write Privilege	Configure iDRAC
License Required	iDRAC Express (For Blades) or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.Timeout (Read or Write)

Table 786. Details of iDRAC.VirtualConsole.Timeout attribute

Description	Defines the idle timeout in seconds for the virtual console.
Legal Values	Integral values: 60–10800
Default Value	1800
Write Privilege	Configure iDRAC
License Required	iDRAC Express (For Blades) or iDRAC Enterprise
Dependency	None

iDRAC.VirtualMedia

The objects in this group enable you to manage virtual media configuration parameters of iDRAC.

iDRAC.VirtualMedia.Attached (Read or Write)

Table 787. Details of iDRAC.VirtualMedia.Attached attribute

Description	Used to attach virtual devices to the system using the USB bus.
Legal Values	• 0 — Detached • 1 — Attached • 2 — AutoAttach
Default Value	2 — AutoAttach
Write Privilege	Virtual Media

Table 787. Details of iDRAC.VirtualMedia.Attached attribute (continued)

License Required	iDRAC Express (For Blades) or iDRAC Enterprise
Dependency	None

iDRAC.VirtualMedia.BootOnce (Read or Write)

Table 788. Details of iDRAC.VirtualMedia.BootOnce attribute

Description	Enables or disables the virtual media boot once feature of the iDRAC.
Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	0 — Disabled
Write Privilege	Virtual Media
License Required	iDRAC Express (For Blades) or iDRAC Enterprise
Dependency	None

iDRAC.VirtualMedia.Enable (Read or Write)

Table 789. Details of iDRAC.VirtualMedia.Enable attribute

Description	Enables or Disables the Virtual Media.
Legal Values	• 0—Disabled • 1—Enabled
Default Value	0—Disabled
Write Privilege	Virtual Media
License Required	iDRAC Express (For Blades) or iDRAC Enterprise
Dependency	None

iDRAC.VirtualMedia.EncryptEnable (Read or Write)

Table 790. Details of iDRAC.VirtualMedia.EncryptEnable attribute

Description	Specifies the Virtual Media encryption
Legal Values	• 0—Disabled • 1—Enabled
Default Value	0—Disabled
Write Privilege	Virtual Media
License Required	iDRAC Express (For Blades) or iDRAC Enterprise

Table 790. Details of iDRAC.VirtualMedia.EncryptEnable attribute (continued)

Dependency	None

iDRAC.VirtualMedia.FloppyEmulation (Read or Write)

Table 791. Details of iDRAC.VirtualMedia.FloppyEmulation attribute

Description	Enables of disables floppy emulation of the attached virtual media.
Legal Values	• 0 — Disabled • 1 — Enabled
Default value	0 — Disabled
Write Privilege	Virtual Media
License Required	iDRAC Express (For Blades) or iDRAC Enterprise
Dependency	None

iDRAC.VirtualMedia.KeyEnable (Read or Write)

Description	Enables or Disables the virtual media key feature of the iDRAC
Legal Values	• Disabled-0 • Enabled-1
Default Value	0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependancy	None

iDRAC.VNCServer

The objects in this group manages configuration of the VNC Server on iDRAC.

iDRAC.VNCServer.Enable (Read or Write)

Table 792. Details of iDRAC.VNCServer.Enable attribute

Description	Enables or disables VNC server on iDRAC.
Legal Values	• 0 — Disabled • 1 — Enabled
Default value	0 — Disabled
Write Privilege	Login or configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.VNCServer.LowerEncryptionBitLength (Read or Write)

Table 793. Details of iDRAC.VNCServer.LowerEncryptionBitLength attribute

Description	Lower encryption bit length.
Legal Values	• 0 — Disabled (Auto Negotiate) • 1 — Enabled (128-Bit or Higher)
Default Value	0 — Disabled (Auto Negotiate)
Write Privilege	Login or configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.VNCServer.Password (Read or Write)

Table 794. Details of iDRAC.VNCServer.Password attribute

Description	Password for logging into VNC session.
Legal Values	String of up to 8 characters
Default Value	None
Write Privilege	Login or configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.VNCServer.Port (Read or Write)

Table 795. Details of iDRAC.VNCServer.Port attribute

Description	Port number for VNC session
Legal Values	Integer values from 1024 to 65535
Default Value	5901
Write Privilege	Login or configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.VNCServer.SSLEncryptionBitLength (Read or Write)

Table 796. Details of iDRAC.VNCServer.SSLEncryptionBitLength attribute

Description	Indicates the VNC server encryption state.
Legal Values	• 0 — Disabled • 1 — Auto negotiate • 2— 128 bit or higher • 3— 168 bit or higher • 4— 256 bit or higher

Table 796. Details of iDRAC.VNCServer.SSLEncryptionBitLength attribute (continued)

Default value	0 — Disabled
Write Privilege	iDRAC Configure
License Required	iDRAC Enterprise
Dependency	None

iDRAC.VNCServer.Timeout (Read or Write)

Table 797. Details of iDRAC.VNCServer.Timeout attribute

Description	VNC server idle timeout period in seconds.
Legal Values	Integer values from 60 to 10800
Default Value	300
Write Privilege	Login or configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.WebServer

The objects in this group provide configuration parameters for iDRACs' Webserver.

iDRAC.Webserver.CustomCipherString(Read or Write)

Table 798. Details of iDRAC.webserver.CustomCipherString attribute

Description	Specifies the custom cipher string to filter the available in-use TLS cipher suite. Examples of cipher string format: • ALL:!DHE-RSA-AES256-GCM-SHA384:!DHE-RSA-AES256-GCM-SHA384 • ALL:+DHE-RSA-AES256-GCM-SHA384 • ALL:-DHE-RSA-CAMELLIA256-SHA • ALL:!DHE-RSA-AES256-GCM-SHA384:!DHE-RSA-AES256-SHA256:+AES256-GCM-SHA384:-DHE-RSA-CAMELLIA256-SHA
Legal Values	String of up to 512 ASCII characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	RACADM
Dependency	None

iDRAC.WebServer.Enable (Read or Write)

Table 799. Details of iDRAC.WebServer.Enable attribute

Description	Enables or disables iDRAC WebServer.

Table 799. Details of iDRAC.WebServer.Enable attribute (continued)

Legal Values	• 0 — Disabled • 1 — Enabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.WebServer.HostHeaderCheck(Read or Write)

Table 800. Details of iDRAC.WebServer.HostHeaderCheck attribute

Description	This attribute when enabled enforces the HTTP Host request header to be validated.
Legal Values	• 0—Disabled • 1—Enabled
Default Value	1—Enabled
Write Privilege	Configure iDRAC
License Required	RACADM
Dependency	None

iDRAC.WebServer.HttpPort (Read or Write)

Table 801. Details of iDRAC.WebServer.HttpPort attribute

Description	Specifies the port number for HTTP communication with the iDRAC.
Legal Values	Integral values: 1–65535
Default Value	80
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.WebServer.HttpsPort (Read or Write)

Table 802. Details of iDRAC.WebServer.HttpsPort attribute

Description	Specifies the port number for HTTPs communication with the iDRAC.
Legal Values	Integral values: 1–65535
Default Value	443

Table 802. Details of iDRAC.WebServer.HttpsPort attribute (continued)

Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Webserver.Httpsredirection (Read or Write)

Table 803. Details of iDRAC.Webserver.Httpsredirection attribute

Description	Enables or disables redirection from the http port (default — 80) to https (default — 443).
Legal Values	• 1 — Enabled • 0 — Disabled
Default Value	1 — Enabled
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.WebServer.LowerEncryptionBitLength (Read or Write)

Table 804. Details of iDRAC.WebServer.LowerEncryptionBitLength attribute

Description	Lower Encryption Bit Length.
Legal Values	• 0 — Disabled (Auto Negotiate) • 1 — Enabled (12 Bit or Higher)
Default Value	1 — Enabled (128 Bit or Higher)
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.WebServer.ManualDNSEntry(Read or Write)

Table 805. Details of iDRAC.WebServer.ManualDNSEntry attribute

Description	Manual FQDN/Hostname or TLS SAN domain name(s) for validating HTTP Host header.
Legal Values	A comma separated list of up to four manual FQDN/Hostname or TLS SAN domain names. (Limit: 1024 ASCII characters)
Default Value	n/a
Write Privilege	Configure iDRAC
License Required	RACADM

Table 805. Details of iDRAC.WebServer.ManualDNSEntry attribute (continued)

Dependency	None

iDRAC.WebServer.MaxNumberOfSessions (Read Only)

Description	Max session allowed
Legal Values	• Integral values from RestUI to iDRAC
Default Values	• 8
Write Privilege	Configure iDRAC
License Required	iDRAC Basic
Dependancy	None

iDRAC.WebServer.SSLEncryptionBitLength (Read or Write)

Table 806. Details of iDRAC.WebServer.SSLEncryptionBitLength attribute

Description	Indicates the web server encryption state.
Legal Values	• 0— Auto negotiate • 1 — 128 bit or higher • 2 — 168 bit or higher • 3 — 256 bit or higher
Default value	1 — 128 bit or higher
Write Privilege	iDRAC Configure
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.webServer.TitleBarOption (Read or Write)

Table 807. Details of iDRAC.webServer.TitleBarOption attribute

Description	Specifies what to display in the title bar.
Legal Values	• 0- Auto • 1- DNS RAC Name • 2- IP Address • 3- Service Tag • 4- System Host Name • 5- Custom
Default Value	Null
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.webServer.TitleBarOptionCustom (Read or Write)

Table 808. Details of iDRAC.webServer.TitleBarOptionCustom attribute

Description	Specifies the custom title when the title bar option is Custom.
Legal Values	String of up to 30 ASCII characters
Default Value	String of up to 30 ASCII characters
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.WebServer.Timeout (Read or Write)

Table 809. Details of iDRAC.WebServer.Timeout attribute

Description	Defines the webserver timeout.
Legal Values	Integral values: 60–10800
Default Value	1800
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.WebServer.TLSProtocol (Read or Write)

Table 810. Details of iDRAC.WebServer.TLSProtocol attribute

Description	Defines the TLS protocol support.
Legal Values	• 0 — TLS 1.0 and higher • 1 — TLS 1.1 and higher • 2 — TLS 1.2 only
Default Value	1 — TLS 1.1 and higher
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.BiosBootSettings

You can manage the BIOS start settings using the objects in this group.

BIOS.BiosBootSettings.BootSeq (Read or Write)

Table 811. Details of BIOS.BiosBootSettings.BootSeq attribute

Description	Determines the Bios start sequence of the system.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if BootMode is set to UEFI **NOTE:** If BootMode is set to UEFI, legacy boot settings are not available in the system. Similarly, if BootMode is set to Legacy BIOS, UEFI settings are not available in the system.

BIOS.BiosBootSettings.BootMode (Read or Write)

Table 812. Details of BIOS.BiosBootSettings.BootMode attribute

Description	Determines the start mode of the system.
Legal Values	• BIOS • UEFI
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.BiosBootSettings.BootSeqRetry (Read or Write)

Table 813. Details of BIOS.BiosBootSettings.BootSeqRetry attribute

Description	Enables or disables the boot sequence retry feature.
Legal Values	Enabled Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.BiosBootSettings.HddFailover (Read or Write)

Table 814. Details of BIOS.BiosBootSettings.HddFailover attribute

Description	Specifies the devices in the Hard-Disk Drive Sequence menu that are attempted in the boot sequence. This property applies to BIOS Boot Mode only, and is disabled when Boot Mode is set to `UEFI`. When set to `Disabled` (default), only the first Hard-Disk device in the list is attempted to boot. When set to `Enabled`, all Hard-Disk devices are attempted in order, as listed in the Hard-Disk Drive Sequence.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

BIOS.BiosBootSettings.HddSeq (Read or Write)

Table 815. Details of BIOS.BiosBootSettings.HddSeq attribute

Description	HDD boot sequence
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if Boot mode is set to UEFI

BIOS.BiosBootSettings.UefiBootSeq (Read or Write)

Table 816. Details of BIOS.BiosBootSettings.UefiBootSeq attribute

Description	UEFI boot sequence
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if Boot mode is set to BIOS

BIOS.BiosBootSettings.SetBootOrderDis (Read or Write)

Description The SetBootOrderDis fields specify a list of Fqdds representing the boot option Disabled to be applied on the next boot.

Legal Values	String of range 0-255
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.SetBootOrderEn (Read or Write)

Description	The SetBootOrderEn fields specify a list of Fqdds representing the boot option Enabled to be applied on the next boot.
Legal Values	String of range 0-255
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.SetBootOrderFqddn (Read or Write)

Table 817. Details of BIOS.BiosBootSettings.SetBootOrderFqddn attribute

Description	Specifies a list of FQDDs that has the boot list to apply on the next boot. In the attribute `SetBootOrderFqddn`, the value of `n` can be 1 to 16
Legal Values	String of UEFI boot devices
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.BiosBootSettings.SetLegacyHddOrderFqddn (Read or Write)

Table 818. Details of BIOS.BiosBootSettings.SetLegacyHddOrderFqddn attribute

Description	Specifies a list of FQDDs that has the legacy HDD list to apply on the next boot. In the attribute `SetLegacyHddOrderFqdd`, the value of `n` can be 1 to 16
Legal Values	String of UEFI boot devices
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.EmbServerMgmt

The objects in this group assist in embedded server management.

BIOS.EmbServerMgmt.FrontLcd (Read or Write)

Table 819. Details of BIOS.EmbServerMgmt.FrontLcd attribute

Description	Allows to display the default (Model name and number) or a user-defined string in the front-panel LCD. To modify the advanced features of the front-panel LCD, press F2 during boot to enter System Setup and then select iDRAC Settings.
Legal Values	• None • UserDefined • ModelNum • Advanced
Default Value	None
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.EmbServerMgmt.UserLcdStr (Read or Write)

Table 820. Details of BIOS.EmbServerMgmt.UserLcdStr attribute

Description	Allows you to view or enter the User-Defined String to display on the LCD.
Legal Values	String of up to 62 Characters
Default Value	Null
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices

You can use the objects in this group to manage the integrated devices such as internal NIC and integrated USB.

BIOS.IntegratedDevices.CurrentEmbVideoState (Read or Write)

Description	Read-only. Indicates the current state of the Embedded Video Controller. If the Embedded Video Controller is the only display capability in the system (that is, no add-in graphics card is installed), then the Embedded Video Controller is automatically used as the primary display even if the Embedded Video Controller setting is Disabled.
Legal Values	String from 0-9 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.EmbNic1 (Read or Write)

Table 821. Details of BIOS.IntegratedDevices.EmbNic1 attribute

Description	Enables or disables the operating system interface of the embedded NIC1.
Legal Values	• Enabled • EnabledPxe • EnablediScsi • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.EmbNic1Nic2 (Read or Write)

Table 822. Details of BIOS.IntegratedDevices.EmbNic1Nic2 attribute

Description	Enables or disables the operating system interface of the embedded NIC1 and NIC2 controllers.
Legal Values	• Enabled • Disabled OS • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.EmbNic2 (Read or Write)

Table 823. Details of BIOS.IntegratedDevices.EmbNic2 attribute

Description	Enables or disables the operating system interface of the embedded NIC2.
Legal Values	• Enabled • EnabledPxe • EnablediScsi • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.EmbNic3 (Read or Write)

Table 824. Details of BIOS.IntegratedDevices.EmbNic3 attribute

Description	Enables or disables the operating system interface of the embedded NIC3.
Legal Values	• Enabled • EnabledPxe • EnablediScsi • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.EmbNic3Nic4 (Read or Write)

Table 825. Details of BIOS.IntegratedDevices.EmbNic3Nic4 attribute

Description	Enables or disables the operating system interface of the embedded NIC3 and NIC4 controllers.
Legal Values	• Enabled • Disabled OS • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.EmbNic4 (Read or Write)

Table 826. Details of BIOS.IntegratedDevices.EmbNic4 attribute

Description	Enables or disables the operating system interface of the embedded NIC4.
Legal Values	• Enabled • EnabledPxe • EnablediScsi • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.EmbVideo (Read or Write)

Table 827. Details of IOS.IntegratedDevices.EmbVideo attribute

Description	Enables or disables the BIOS support for the embedded video controller.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.GlobalSlotDriverDisable

Table 828. Details of BIOS.IntegratedDevices.GlobalSlotDriverDisable attribute

Description	Controls the pre-boot driver on any slot.
Legal Values	• Enabled • Disabled
Default Value	NA
Write Privilege	Server control
License Required	RACADM
Dependency	None

BIOS.IntegratedDevices.IntegratedNetwork1 (Read or Write)

Table 829. Details of BIOS.IntegratedDevices.IntegratedNetwork1 attribute

Description	Enables or disables the Integrated Network Card 1.
Legal Values	• Enabled • Disabled OS
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.IntegratedNetwork2 (Read or Write)

Table 830. Details of BIOS.IntegratedDevices.IntegratedNetwork2 attribute

Description	Enables or disables the integrated network card 2.
Legal Values	• Enabled • DisabledOS
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.IntegratedRaid (Read or Write)

Table 831. Details of BIOS.IntegratedDevices.IntegratedRaid attribute

Description	Enables or disables the integrated RAID controller.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.IntegratedSas (Read or Write)

Table 832. Details of BIOS.IntegratedDevices.IntegratedSas attribute

Description	Enables or disables the integrated SAS controller.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.InternalSdCard (Read or Write)

Table 833. Details of BIOS.IntegratedDevices.InternalSdCard attribute

Description	Enables or disables the internal SD Card port.
Legal Values	• On • Off
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.InternalSdCardRedundancy (Read or Write)

Table 834. Details of BIOS.IntegratedDevices.InternalSdCardRedundancy attribute

Description	Sets the SD Card redundancy mode.
Legal Values	• Mirror • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if InternalSdCard is set to 'Off'.

BIOS.IntegratedDevices.InternalUsb (Read or Write)

Table 835. Details of BIOS.IntegratedDevices.InternalUsb attribute

Description	Enables or disables the internal USB port.
Legal Values	• On • Off
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.InternalUsb1 (Read or Write)

Table 836. Details of BIOS.IntegratedDevices.InternalUsb1 attribute

Description	Enables or disables the internal USB port 1.
Legal Values	• On • Off
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.InternalUsb2 (Read or Write)

Table 837. Details of BIOS.IntegratedDevices.InternalUsb2 attribute

Description	Enables or disables the internal USB port 2.
Legal Values	• On • Off
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.IONonPostedPrefetch

Table 838. Details of BIOS.IntegratedDevices.IONonPostedPrefetch attribute

Description	Enables or disables the PCI IO non-posted pre-fetch mode to control the PCIe throughput. When this option is enabled, the read operation from the PCI devices are optimized. However, performance is reduced for write operation from the PCI devices.
Legal Values	• Enabled • Disabled
Default Value	NA
Write Privilege	Server control
License Required	RACADM
Dependency	None

BIOS.IntegratedDevices.IoatEngine (Read or Write)

Table 839. Details of BIOS.IntegratedDevices.IoatEngine attribute

Description	Enables or disables the I/O Acceleration technology (I/OAT) option.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.IONonPostedPrefetch

Table 840. Details of BIOS.IntegratedDevices.IONonPostedPrefetch attribute

Description	Enables or disables the PCI IO non-posted pre-fetch mode to control the PCIe throughput. When this option is enabled, the read operation from the PCI devices are optimized. However, performance is reduced for write operation from the PCI devices.
Legal Values	• Enabled • Disabled
Default Value	NA
Write Privilege	Server control
License Required	RACADM
Dependency	None

BIOS.IntegratedDevices.MmioAbove4GB (Read or Write)

Table 841. Details of BIOS.IntegratedDevices.MmioAbove4GB attribute

Description	Enables or disables support for PCIe devices that require large amount of memory. Enable this option only for 64-bit operating systems.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.OsWatchdogTimer (Read or Write)

Table 842. Details of BIOS.IntegratedDevices.OsWatchdogTimer attribute

Description	Enables or disables timer initialization by the operating system.

Table 842. Details of BIOS.IntegratedDevices.OsWatchdogTimer attribute (continued)

Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.SriovGlobalEnable (Read or Write)

Table 843. Details of BIOS.IntegratedDevices.SriovGlobalEnable attribute

Description	Enables or disables BIOS configuration of Single Root I/O Virtualization (SR-IOV) devices.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.IntegratedDevices.Usb3Setting (Read or Write)

Description	Controls USB 3.0 support. When set to Disabled, BIOS disables USB 3.0 mode for all the USB3.0 ports. The USB devices operate at USB2.0 mode. When set to Enabled, BIOS operates all USB3.0 ports at USB2.0 mode during POST, and switches them to USB3.0 mode right after the operating system (OS) boots. You must select this option only if the operating system (such as. Windows Server 2012) has a native USB 3.0 driver. Otherwise none of the USB devices will work after boot. The Auto option is available only on workstation servers. If this option is selected, the BIOS leaves all USB 3.0 ports at USB 2.0 mode, and a special OS switching driver is required to set the USB3.0 port to USB3.0 mode. Microsoft Windows 7 has switching driver capability.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.UsbPorts (Read or Write)

Table 844. Details of BIOS.IntegratedDevices.UsbPorts attribute

Description	Sets the user accessible USB ports.

Table 844. Details of BIOS.IntegratedDevices.UsbPorts attribute (continued)

Legal Values	• All on • Only back ports on • All off
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings

To manage memory-related configuration settings, use the objects in this group.

BIOS.MemSettings.CorrEccSmi (Read or Write)

Description	Allows the system to log ECC corrected DRAM errors into the SEL log. Logging these rare errors can help identify marginal components; however the system will pause for a few milliseconds after an error while the log entry is created. Latency conscious customers may wish to disable the feature. Spare Mode, and Mirror mode require this feature to be enabled.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.MemLowPower (Read or Write)

Table 845. Details of BIOS.MemSettings.MemLowPower attribute

Description	Enables or disables the low-power mode of the memory.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings.MemOpMode (Read or Write)

Table 846. Details of BIOS.MemSettings.MemOpMode attribute

Description	Current memory operating mode.
Legal Values	• OptimizerMode • SpareMode • MirrorMode • AdvEccMode • SpareWithAdvEccMode
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings.MemOptimizer (Read or Write)

Table 847. Details of BIOS.MemSettings.MemOptimizer attribute

Description	Configure the memory optimizer setting.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings.MemOpVoltage (Read Only)

Table 848. Details of BIOS.MemSettings.MemOpVoltage attribute

Description	Operating voltage of memory.
Legal Values	• AutoVolt • Volt15V
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings.MemTest (Read or Write)

Table 849. Details of BIOS.MemSettings.MemTest attribute

Description	Specifies whether BIOS software-based system memory tests are conducted during POST.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings.NodeInterleave (Read or Write)

Table 850. Details of BIOS.MemSettings.NodeInterleave attribute

Description	If the system is configured with matching memory this field enables node interleaving.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings.RedundantMem (Read or Write)

Table 851. Details of BIOS.MemSettings.RedundantMem attribute

Description	Enables or disables the redundant memory feature.
Legal Values	• Disabled • Spare • Mirror • IntraNodeMirror • DimmSpare • Dddc
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings.RedundantMemCfgValid (Read or Write)

Table 852. Details of BIOS.MemSettings.RedundantMemCfgValid attribute

Description	Redundant Memory Configuration Valid
Legal Values	• Invalid • Valid
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings.RedundantMemInUse (Read Only)

Table 853. Details of BIOS.MemSettings.RedundantMemInUse attribute

Description	Display the current redundant memory setting in BIOS.
Legal Values	• NotInUse • InUse
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings.Serialdbgout (Read or Write)

Table 854. Details of BIOS.MemSettings.Serialdbgout attribute

Description	Enables or disables the Serial Debug Out option.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings.SnoopFilter (Read or Write)

Table 855. Details of BIOS.MemSettings.SnoopFilter attribute

Description	Enables or disables the snoop filter option.

Table 855. Details of BIOS.MemSettings.SnoopFilter attribute (continued)

	NOTE: This attribute is not supported for 13th generation servers.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings.SnoopMode (Read or Write)

Description	Allows tuning of memory performances under different memory bandwidths. The optimal Snoop Mode setting is highly dependent on workload type. Early Snoop is best used for latency sensitive workloads. This setting offers the best balance between workload effects. Home Snoop is best used for NUMA workloads that need maximum local and remote memory bandwidth. Cluster on Die is best used for highly NUMA optimized workloads. This setting offers the best case local memory latency, but worst case remote latency. Cluster On Die is only available when Node Interleaving is Disabled. Opportunistic Snoop Broadcast, available on select processor models, works well for workloads of mixed NUMA optimization. It offers a good balance of latency and bandwidth.
Legal Values	• EarlySnoop • HomeSnoop • ClusterOnDie
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SysMemSize (Read or Write)

Table 856. Details of BIOS.MemSettings.SysMemSize attribute

Description	Indicates the current amount of main memory in the system.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings.SysMemSpeed (Read or Write)

Table 857. Details of BIOS.MemSettings.SysMemSpeed attribute

Description	Indicates the current clock frequency of the main memory.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings.SysMemType (Read or Write)

Table 858. Details of BIOS.MemSettings.SysMemType attribute

Description	Indicates the current type of main memory installed in the system.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings.SysMemVolt (Read or Write)

Table 859. Details of BIOS.MemSettings.SysMemVolt attribute

Description	Displays the current operating voltage of main memory.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MemSettings.VideoMem (Read or Write)

Table 860. Details of BIOS.MemSettings.VideoMem attribute

Description	Indicates the total amount of video memory available to the embedded video controller.
Legal Values	None

Table 860. Details of BIOS.MemSettings.VideoMem attribute (continued)

Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MiscSettings

To manage the miscellaneous objects settings, use the object in this group.

BIOS.MiscSettings.AssetTag (Read or Write)

Table 861. Details of BIOS.MiscSettings.AssetTag attribute

Description	Displays the current asset tag and the asset tag can be modified.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MiscSettings.ErrPrompt (Read or Write)

Table 862. Details of BIOS.MiscSettings.ErrPrompt attribute

Description	Enables or disables the F1 and F2 prompt on error.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MiscSettings.InSystemCharacterization (Read or Write)

Table 863. Details of BIOS.MiscSettings.InSystemCharacterization attribute

Description	The ratio of power and performance of a system is optimized by ISC when it is enabled.
Legal Values	• Enabled • FastBoot

Table 863. Details of BIOS.MiscSettings.InSystemCharacterization attribute (continued)

	• Disabled
Default Value	Not Applicable
License Required	RACADM
Dependency	None

BIOS.MiscSettings.NumLock (Read or Write)

Table 864. Details of BIOS.MiscSettings.NumLock attribute

Description	Enable or disable the system boots with Num locks, not applicable for 84-key keyboards
Legal Values	• On • Off
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MiscSettings.ReportKbdErr (Read or Write)

Table 865. Details of BIOS.MiscSettings.ReportKbdErr attribute

Description	Enables or disables the keyboard-related error messages to be reported at system startup.
Legal Values	• Report • No report
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MiscSettings.SystemUefiShell (Read or Write)

Table 866. Details of BIOS.MiscSettings.SystemUefiShell attribute

Description	Enables or disables the System UEFI Shell as a UEFI boot option choice.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control

Table 866. Details of BIOS.MiscSettings.SystemUefiShell attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MiscSettings.SysMgmtNVByte1 (Read or Write)

Table 867. Details of attribute

Description	Indicates the system management NVRAM byte 1.
Legal Values	Integer
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MiscSettings.SysMgmtNVByte2 (Read or Write)

Table 868. Details of BIOS.MiscSettings.SysMgmtNVByte2 attribute

Description	Indicates the system management NVRAM byte 2.
Legal Values	Integer
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MiscSettings.SystemUefiShell (Read or Write)

Table 869. Details of BIOS.MiscSettings.SystemUefiShell attribute

Description	Enables or disables the system UEFI shell as UEFI boot option.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.MiscSettings.ForceInt10 (Read or Write)

Table 870. Details of BIOS.MiscSettings.ForceInt10 attribute

Description	Specifies if the system BIOS will load the legacy video (INT 10h) option ROM from the video controller.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.NetworkSettings

The objects in this group manage the iSCSI devices.

BIOS.NetworkSettings.PxeDevnEnDis (Read or Write)

Table 871. Details of BIOS.NetworkSettings.PxeDevnEnDis attribute

Description	Indicates if the PXE device is enabled or disabled. When enabled, a UEFI boot option is created for the PXE device. For the attribute `PxeDevnEnDis`, the value of `n` can be 2 — 4.
Legal Values	• Enabled • Disabled
Default Value	None
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.OneTimeBoot

You can manage the one time boot settings using the objects in this group.

BIOS.OneTimeBoot.OneTimeBootMode (Read or Write)

Table 872. Details of BIOS.OneTimeBoot.OneTimeBootMode attribute

Description	Configure the one time boot mode setting.
Legal Values	• Disabled • OneTimeBootSeq • OneTimeHddSeq • OneTimeUefiBootSeq
Default Value	Not Applicable

Table 872. Details of BIOS.OneTimeBoot.OneTimeBootMode attribute (continued)

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NOTE: On a Dell 13th generation of PowerEdge server, to set the value from `OneTimeBootMode` to `OneTimeUefiBootSeq`, you must boot the server in UEFI mode.

BIOS.OneTimeBoot.OneTimeBootSeqDev (Read or Write)

Table 873. Details of BIOS.OneTimeBoot.OneTimeBootSeqDev attribute

Description	Configure the one time boot sequence device in BIOS.
Legal Values	Hard Disk List
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if OneTimeBootMode is not set to `OneTimeBootSeq`.

BIOS.OneTimeBoot.OneTimeCustomBootStr (Read or Write)

Table 874. Details of BIOS.OneTimeBoot.OneTimeCustomBootStr attribute

Description	Configure the one time custom boot device.
Legal Values	Custom device list
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if `OneTimeBootMode` is set to `Disabled` or set to `OneTimeBootSeq`, `OneTimeHddSeq`, or `OneTimeUefiBootSeq`

BIOS.OneTimeBoot.OneTimeHddSeqDev (Read or Write)

Table 875. Details of BIOS.OneTimeBoot.OneTimeHddSeqDev attribute

Description	Configure the one time Hard Disk Drive (HDD) sequence for BIOS.
Legal Values	RAID FQDD
Default Value	Not Applicable
Write Privilege	Server Control

Table 875. Details of BIOS.OneTimeBoot.OneTimeHddSeqDev attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if `OneTimeBootMode` is not set to `OneTimeHddSeq`

BIOS.OneTimeBoot.OneTimeUefiBootSeqDev (Read or Write)

Table 876. Details of BIOS.OneTimeBoot.OneTimeUefiBootSeqDev attribute

Description	Configure the one time UEFI Boot Sequence device.
Legal Values	NIC or Optical Device list
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if `OneTimeBootMode` is not set to `OneTimeUefiBootSeq`

BIOS.ProcSettings

To configure the processor settings, use the objects in this group.

BIOS.ProcSettings.CorePerfBoost (Read or Write)

Table 877. Details of BIOS.ProcSettings.CorePerfBoost attribute

Description	Enables or disables CPU core performance booster.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.DataReuse (Read or Write)

Table 878. Details of BIOS.ProcSettings.DataReuse attribute

Description	Enables or disables data reuse in cache.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable

Table 878. Details of BIOS.ProcSettings.DataReuse attribute (continued)

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.DculpPrefetcher (Read or Write)

Table 879. Details of BIOS.ProcSettings.DculpPrefetcher attribute

Description	Enables or disables Data Cache Unit (DCU) IP Prefetcher.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.DcuStreamerPrefetcher (Read or Write)

Table 880. Details of BIOS.ProcSettings.DcuStreamerPrefetcher attribute

Description	Enables or disables Data Cache Unit (DCU) Streamer Prefetcher.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.DmaVirtualization (Read or Write)

Table 881. Details of BIOS.ProcSettings.DmaVirtualization attribute

Description	Enables or disables hardware capabilities for DMA remapping and virtualization are available.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Table 881. Details of BIOS.ProcSettings.DmaVirtualization attribute (continued)

Dependency	None

BIOS.ProcSettings.DynamicCoreAllocation (Read or Write)

Table 882. Details of BIOS.ProcSettings.DynamicCoreAllocation attribute

Description	Enables or disables the operating system capability to set the logical processors in idle state which helps to reduce power consumption.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.LogicalProc (Read or Write)

Table 883. Details of BIOS.ProcSettings.LogicalProc attribute

Description	To enable report all logical processors and to disable report one logical processor per core.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.PerfMonitorDevices (Read or Write)

Table 884. Details of BIOS.ProcSettings.PerfMonitorDevices attribute

Description	Allows to enable or disable the performance monitoring devices. When set to `Enabled`, the performance monitoring devices are visible to the operating system. **NOTE:** The Performance Monitor Devices field is set to `Disabled` by default.
Legal Values	• Enabled • Disabled
Default Value	
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc1Brand (Read or Write)

Table 885. Details of BIOS.ProcSettings.Proc1Brand attribute

Description	Provides the processor brand name.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc1ControlledTurbo (Read or Write)

Table 886. Details of BIOS.ProcSettings.Proc1ControlledTurbo attribute

Description	Controls the turbo engagement. **NOTE:** You can enable this option only when System Profile is set to Performance.
Legal Values	• Disabled • ControlledTurboLimit • ControlledTurboLimitMinus1 • ControlledTurboLimitMinus2 • ControlledTurboLimitMinus3
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc1Id (Read or Write)

Table 887. Details of BIOS.ProcSettings.Proc1Id attribute

Description	Provides the processor's family model and stepping values.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc1L2Cache (Read or Write)

Table 888. Details of BIOS.ProcSettings.Proc1L2Cache attribute

Description	Amount of memory in the corresponding processor cache.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc1L3Cache (Read or Write)

Table 889. Details of BIOS.ProcSettings.Proc1L3Cache attribute

Description	Amount of memory in the corresponding processor cache.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc1NumCores (Read or Write)

Table 890. Details of BIOS.ProcSettings.Proc1NumCores attribute

Description	Number of cores in the processor package.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc2Brand (Read or Write)

Table 891. Details of BIOS.ProcSettings.Proc2Brand attribute

Description	Provides the processor brand name.
Legal Values	None

Table 891. Details of BIOS.ProcSettings.Proc2Brand attribute (continued)

Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc2ControlledTurbo (Read or Write)

Table 892. Details of BIOS.ProcSettings.Proc2ControlledTurbo attribute

Description	Controls the turbo engagement. **NOTE:** You can enable this option only when System Profile is set to Performance.
Legal Values	• Disabled • ControlledTurboLimit • ControlledTurboLimitMinus1 • ControlledTurboLimitMinus2 • ControlledTurboLimitMinus3
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

BIOS.Procsettings.Proc2Cores

Table 893. Details of BIOS.Procsettings.Proc2Cores attribute

Description	Controls the number of enabled cores in each processor.
Legal Values	All, 1, 2, 4, 6, 8, 10, 12, 14, 16, 18, 20, 22, 24
Default Value	NA
Write Privilege	Server control
License Required	RACADM
Dependency	Requires the DPAT Pro license to make it visible. It can be edited only if the `Number of Cores per Processor` is set to `Custom`.

BIOS.ProcSettings.Proc2Id (Read or Write)

Table 894. Details of BIOS.ProcSettings.Proc2Id attribute

Description	Processor's family model and stepping values.
Legal Values	None
Default Value	Not Applicable

Table 894. Details of BIOS.ProcSettings.Proc2Id attribute (continued)

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc2L2Cache (Read or Write)

Table 895. Details of BIOS.ProcSettings.Proc2L2Cache attribute

Description	AmountBIOS.ProcSettings.Proc2L2Cache (Read Only) of memory in the corresponding processor cache.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc2L3Cache (Read or Write)

Table 896. Details of BIOS.ProcSettings.Proc2L3Cache attribute

Description	Amount of memory in the corresponding processor cache.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc2NumCores (Read or Write)

Table 897. Details of BIOS.ProcSettings.Proc2NumCores attribute

Description	Number of cores in the processor package.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc3Brand (Read or Write)

Table 898. Details of BIOS.ProcSettings.Proc3Brand attribute

Description	Brand text provided by the processor manufacturer.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc3ControlledTurbo (Read or Write)

Table 899. Details of BIOS.ProcSettings.Proc3ControlledTurbo attribute

Description	Controls the turbo engagement. **NOTE:** You can enable this option only when System Profile is set to Performance.
Legal Values	• Disabled • ControlledTurboLimit • ControlledTurboLimitMinus1 • ControlledTurboLimitMinus2 • ControlledTurboLimitMinus3
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.Procsettings.Proc3Cores

Table 900. Details of BIOS.Procsettings.Proc3Cores attribute

Description	Controls the number of enabled cores in each processor.
Legal Values	All, 1, 2, 4, 6, 8, 10, 12, 14, 16, 18, 20, 22, 24
Default Value	NA
Write Privilege	Server control
License Required	RACADM
Dependency	Requires the DPAT Pro license to make it visible. It can be edited only if the `Number of Cores per Processor` is set to `Custom`.

BIOS.ProcSettings.Proc3Id (Read or Write)

Table 901. Details of BIOS.ProcSettings.Proc3Id attribute

Description	Processor's family model and stepping values.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

c(Read or Write)

Table 902. Details of BIOS.ProcSettings.Proc3Id attribute

Description	Amount of memory in the corresponding processor cache.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc3L3Cache (Read or Write)

Table 903. Details of BIOS.ProcSettings.Proc3L3Cache attribute

Description	Amount of memory in the corresponding processor cache.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc3NumCores (Read or Write)

Table 904. Details of BIOS.ProcSettings.Proc3NumCores attribute

Description	Number of cores in the processor package.
Legal Values	None

Table 904. Details of BIOS.ProcSettings.Proc3NumCores attribute (continued)

Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc4Brand (Read or Write)

Table 905. Details of BIOS.ProcSettings.Proc4Brand attribute

Description	The processor manufacturer provides brand text
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc4ControlledTurbo (Read or Write)

Table 906. Details of BIOS.ProcSettings.Proc4ControlledTurbo attribute

Description	Controls the turbo engagement. **NOTE:** You can enable this option only when System Profile is set to Performance.
Legal Values	• Disabled • ControlledTurboLimit • ControlledTurboLimitMinus1 • ControlledTurboLimitMinus2 • ControlledTurboLimitMinus4
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

BIOS.Procsettings.Proc4Cores

Table 907. Details of BIOS.Procsettings.Proc4Cores attribute

Description	Controls the number of enabled cores in each processor.
Legal Values	All, 1, 2, 4, 6, 8, 10, 12, 14, 16, 18, 20, 22, 24
Default Value	NA

Table 907. Details of BIOS.Procsettings.Proc4Cores attribute (continued)

Write Privilege	Server control
License Required	RACADM
Dependency	Requires the DPAT Pro license to make it visible. It can be edited only if the `Number of Cores per Processor` is set to `Custom`.

BIOS.ProcSettings.Proc4Id (Read or Write)

Table 908. Details of BIOS.ProcSettings.Proc4Id attribute

Description	Processor's family model and stepping values.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc4L2Cache (Read or Write)

Table 909. Details of BIOS.ProcSettings.Proc4L2Cache attribute

Description	Amount of memory in the corresponding processor cache.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc4L3Cache (Read or Write)

Table 910. Details of BIOS.ProcSettings.Proc4L3Cache attribute

Description	Amount of memory in the corresponding processor cache.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc4NumCores (Read or Write)

Table 911. Details of BIOS.ProcSettings.Proc4NumCores attribute

Description	Number of cores in the processor package.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.Proc64bit (Read or Write)

Table 912. Details of BIOS.ProcSettings.Proc64bit attribute

Description	Specifies whether the installed processors support 64-bit extensions.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.ProcAdjCacheLine (Read or Write)

Table 913. Details of BIOS.ProcSettings.ProcAdjCacheLine attribute

Description	Enables or disables the system optimization for applications that require high utilization of sequential memory access.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.ProcBusSpeed (Read or Write)

Table 914. Details of BIOS.ProcSettings.ProcBusSpeed attribute

Description	Bus speed of the processor.

Table 914. Details of BIOS.ProcSettings.ProcBusSpeed attribute (continued)

Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.ProcConfigTdp (Read or Write)

Table 915. Details of BIOS.ProcSettings.ProcConfigTdp attribute

Description	Allows to re-configure the Thermal Design Power (TDP) to lower levels.
Legal Values	• Nominal • Level1 • Level2
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

BIOS.ProcSettings.ProcCores (Read or Write)

Table 916. Details of BIOS.ProcSettings.ProcCores attribute

Description	Controls the number of enabled cores in each processor.
Legal Values	• Single • All • 1 • 2 • 4 • 6 • 8 • 10 • 12 • 14 • 16
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.ProcCoreSpeed (Read or Write)

Table 917. Details of vattribute

Description	Clock speed of the processor.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.ProcDramPrefetcher (Read or Write)

Table 918. Details of BIOS.ProcSettings.ProcDramPrefetcher attribute

Description	Enable to turn on the DRAM prefetch unit in the Northbridge. Disable to prevent DRAM references from triggering DRAM prefetch requests.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.ProcExecuteDisable (Read or Write)

Table 919. Details of BIOS.ProcSettings.ProcExecuteDisable attribute

Description	Specifies whether Execute Disable Memory Protection Technology is enabled or disabled.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.ProcHpcMode (Read or Write)

Table 920. Details of BIOS.ProcSettings.ProcHpcMode attribute

Description	Configure processor's HPC mode.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.ProcHtAssist (Read or Write)

Table 921. Details of BIOS.ProcSettings.ProcHtAssist attribute

Description	When enabled it provides filtering of broadcast probes to improve HyperTransport I/O Link bandwidth and performance on multi-node systems.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.ProcHwPrefetcher (Read or Write)

Table 922. Details of BIOS.ProcSettings.ProcHwPrefetcher attribute

Description	When enabled, the processor is able to prefetch extra cache lines for every memory request.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.ProcHyperTransport (Read or Write)

Table 923. Details of BIOS.ProcSettings.ProcHyperTransport attribute

Description	Specifies the supported HyperTransport I/O Link Specification.
Legal Values	• HT1 • HT3
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.ProcSoftwarePrefetcher (Read or Write)

Table 924. Details of BIOS.ProcSettings.ProcSoftwarePrefetcher attribute

Description	Enables or disables the hardware prefetcher for considering software prefetches when detecting strides for prefetch requests.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.ProcVirtualization (Read or Write)

Table 925. Details of IOS.ProcSettings.ProcVirtualization attribute

Description	When enabled, the additional hardware capabilities provided by virtualization technology are available for use.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.ProcX2Apic (Read or Write)

Table 926. Details of BIOS.ProcSettings.ProcX2Apic attribute

Description	Enables or disables the X2APIC mode. **NOTE:** To enable `BIOS.ProcSettings.ProcX2Apic`, you must enable `BIOS.ProcSettings.ProcVirtualization`.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if the `ProcVirtualization` attribute is set to `Disabled`.

BIOS.ProcSettings.QpiBandwidthPriority (Read or Write)

Table 927. Details of BIOS.ProcSettings.QpiBandwidthPriority attribute

Description	Sets the bandwidth priority to compute (default) or I/O.
Legal Values	• InputOutput • Compute
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.QpiSpeed (Read or Write)

Table 928. Details of BIOS.ProcSettings.QpiSpeed attribute

Description	Controls QuickPath Interconnect data rate settings.
Legal Values	• MaxDataRate • 8 GTps • 7 GTps • 6 GTps
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProcSettings.RtidSetting (Read or Write)

Table 929. Details of BIOS.ProcSettings.RtidSetting attribute

Description	Allocates more RTIDs to the remote socket increasing cache performance between the sockets.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProxyAttributes

The objects in this group manage the legacy boot protocol of LOM.

BIOS.ProxyAttributes.EmbNicPortnBootproto (Read or Write)

Table 930. Details of BIOS.ProxyAttributes.EmbNicPortnBootproto attribute

Description	Controls the Legacy Boot Protocol of the LOM port specified by the Embedded NIC port. Assists in system management software and does not appear in system BIOS setup. The value of `n` can be 1–4. This attribute returns `Unknown` when read. The LOM port legacy boot protocol setting is not changed when `Unknown` is written. An error is displayed if written with a setting (None, PXE, or iSCSI) that is not supported by the LOM.
Legal Values	• Unknown • None • Pxe • Iscsi
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.ProxyAttributes.IntNic1PortnBootproto (Read or Write)

Table 931. Details ofBIOS.ProxyAttributes.IntNic1PortnBootproto attribute

Description	Controls the Legacy Boot Protocol of the LOM Port specified by the Embedded NIC port number Port. Assists for system management software use and does not appear in System BIOS Setup. For this attribute, the value of `n` can be 1–4. This attribute returns `Unknown` when read. The LOM port legacy boot protocol setting is not changed when `Unknown` is written. An error is returned if written with a setting (None, PXE, or iSCSI) that is not supported by the LOM.
Legal Values	• Unknown

Table 931. Details ofBIOS.ProxyAttributes.IntNic1PortnBootproto attribute (continued)

	• None • Pxe • Iscsi
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.PxeDev1Settings

The objects in this group manage the PXE device settings.

BIOS.PxeDev1Settings.PxeDevnInterface (Read or Write)

Table 932. Details of BIOS.PxeDev1Settings.PxeDevnInterface attribute

Description	Indicates the NIC Interface used for the specified PXE device. For the attribute `PxeDevnInterface`, the value of `n` can be 1 — 4.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.PxeDev1Settings.PxeDevnProtocol (Read or Write)

Table 933. Details of BIOS.PxeDev1Settings.PxeDevnProtocol attribute

Description	Controls the PXE protocol used for the specified PXE device. For the attribute `PxeDevnProtocol`, the value of `n` can be 1 — 4.
Legal Values	• IPv4 • IPv6
Default Value	None
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.PxeDev1Settings.PxeDevnVlanEnDis (Read or Write)

Table 934. Details of BIOS.PxeDev1Settings.PxeDevnVlanEnDis attribute

Description	Indicates if the VLAN is enabled or disabled for the specified PXE device. For the attribute `PxeDevnVlanEnDis`, the value of `n` can be 1 — 4.

Table 934. Details of BIOS.PxeDev1Settings.PxeDevnVlanEnDis attribute (continued)

Legal Values	• Enabled • Disabled
Default Value	None
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.PxeDev1Settings.PxeDevnVlanId (Read or Write)

Table 935. Details of BIOS.PxeDev1Settings.PxeDevnVlanId attribute

Description	Indicates the VLAN ID for the specified PXE device. For the attribute `PxeDevnVlanId`, the value of `n` can be 1 — 4.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.PxeDev1Settings.PxeDevnVlanPriority (Read or Write)

Table 936. Details of BIOS.PxeDev1Settings.PxeDevnVlanPriority attribute

Description	Indicates the VLAN priority for the specific PXE device. For the attribute `PxeDevnVlanPriority`, the value of `n` can be 1 — 4.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings

Use the objects in this group to configure the BIOS SATA settings.

BIOS.SataSettings.EmbSata (Read or Write)

Description Configures the embedded SATA to be set to Off, AHCI, or RAID Mode.

Legal Values
- AtaMode
- AhciMode
- RaidMode
- Off

Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.eSataPort1 (Read or Write)

Table 937. Details of IOS.SataSettings.eSataPort1 attribute

Description	Sets the drive type of the selected device.
Legal Values	• Off • Auto
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.eSataPort1Capacity (Read or Write)

Table 938. Details of BIOS.SataSettings.eSataPort1Capacity attribute

Description	Displays the total capacity of a hard-disk drive.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.eSataPort1DriveType (Read or Write)

Table 939. Details of BIOS.SataSettings.eSataPort1DriveType attribute

Description	Indicates type of device attached to this SATA port.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.eSataPort1Model (Read or Write)

Table 940. Details of BIOS.SataSettings.eSataPort1Model attribute

Description	Displays the drive model of the selected device.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortA (Read or Write)

Table 941. Details of BIOS.SataSettings.SataPortA attribute

Description	Sets the drive type of the selected device.
Legal Values	• Off • Auto
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if EmbSata is not set to `AtaMode`.

BIOS.SataSettings.SataPortACapacity (Read or Write)

Table 942. Details of IOS.SataSettings.SataPortACapacity attribute

Description	Displays the total capacity of a hard-disk drive.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortADriveType (Read or Write)

Table 943. Details of BIOS.SataSettings.SataPortADriveType attribute

Description	Indicates type of device attached to this SATA port.

Table 943. Details of BIOS.SataSettings.SataPortADriveType attribute (continued)

Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortAModel (Read or Write)

Table 944. Details of BIOS.SataSettings.SataPortAModel attribute

Description	Displays the drive model of the selected device.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortB (Read or Write)

Table 945. Details of BIOS.SataSettings.SataPortB attribute

Description	Sets the drive type of the selected device.
Legal Values	• Off • Auto
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if EmbSata is not set to `AtaMode`.

BIOS.SataSettings.SataPortBCapacity (Read or Write)

Table 946. Details of BIOS.SataSettings.SataPortBCapacity attribute

Description	Displays the total capacity of a hard-disk drive.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control

Table 946. Details of BIOS.SataSettings.SataPortBCapacity attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortBDriveType (Read or Write)

Table 947. Details of BIOS.SataSettings.SataPortBDriveType attribute

Description	Indicates type of device attached to this SATA port.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortBModel (Read or Write)

Table 948. Details of BIOS.SataSettings.SataPortBModel attribute

Description	Displays the drive model of the selected device.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortC (Read or Write)

Table 949. Details of BIOS.SataSettings.SataPortC attribute

Description	Sets the drive type of the selected device.
Legal Values	• Off • Auto
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if EmbSata is not set to `AtaMode`.

BIOS.SataSettings.SataPortCCapacity (Read or Write)

Table 950. Details of BIOS.SataSettings.SataPortCCapacity attribute

Description	Displays the total capacity of a hard-disk drive.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortCDriveType (Read or Write)

Table 951. Details of BIOS.SataSettings.SataPortCDriveType attribute

Description	Indicates type of device attached to this SATA port.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortCModel (Read or Write)

Table 952. Details of BIOS.SataSettings.SataPortCModel attribute

Description	Displays the drive model of the selected device.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortD (Read or Write)

Table 953. Details of BIOS.SataSettings.SataPortD attribute

Description	Sets the drive type of the selected device.
Legal Values	• Off

Table 953. Details of BIOS.SataSettings.SataPortD attribute (continued)

	• Auto
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if EmbSata is not set to `AtaMode`.

BIOS.SataSettings.SataPortDCapacity (Read or Write)

Table 954. Details of BIOS.SataSettings.SataPortDCapacity attribute

Description	Displays the total capacity of a hard-disk drive.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortDDriveType (Read or Write)

Table 955. Details of BIOS.SataSettings.SataPortDDriveType attribute

Description	Indicates type of device attached to this SATA port.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortDModel (Read or Write)

Table 956. Details of BIOS.SataSettings.SataPortDModel attribute

Description	Displays the drive model of the selected device.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Table 956. Details of BIOS.SataSettings.SataPortDModel attribute (continued)

Dependency	None

BIOS.SataSettings.SataPortE (Read or Write)

Table 957. Details of BIOS.SataSettings.SataPortE attribute

Description	Sets the drive type of the selected device.
Legal Values	• Off • Auto
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if EmbSata is not set to `AtaMode`.

BIOS.SataSettings.SataPortECapacity (Read or Write)

Table 958. Details of BIOS.SataSettings.SataPortECapacity attribute

Description	Displays the total capacity of a hard-disk drive.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortEDriveType (Read or Write)

Table 959. Details of BIOS.SataSettings.SataPortEDriveType attribute

Description	Indicates type of device attached to this SATA port.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortEModel (Read or Write)

Table 960. Details of BIOS.SataSettings.SataPortEModel attribute

Description	Displays the drive model of the selected device.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortF (Read or Write)

Table 961. Details of BIOS.SataSettings.SataPortF attribute

Description	Sets the drive type of the selected device.
Legal Values	• Off • Auto
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if EmbSata is not set to `AtaMode`.

BIOS.SataSettings.SataPortFCapacity (Read or Write)

Table 962. Details of BIOS.SataSettings.SataPortFCapacity attribute

Description	Displays the total capacity of a hard-disk drive.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortFDriveType (Read or Write)

Table 963. Details of BIOS.SataSettings.SataPortFDriveType attribute

Description	Indicates type of device attached to this SATA port.
Legal Values	None

Table 963. Details of BIOS.SataSettings.SataPortFDriveType attribute (continued)

Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortFModel (Read or Write)

Table 964. Details of BIOS.SataSettings.SataPortFModel attribute

Description	Displays the drive model of the selected device.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortG (Read or Write)

Table 965. Details of BIOS.SataSettings.SataPortG attribute

Description	Sets the drive type of the selected device.
Legal Values	• Off • Auto
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if EmbSata is not set to `AtaMode`.

BIOS.SataSettings.SataPortGCapacity (Read or Write)

Table 966. Details of BIOS.SataSettings.SataPortGCapacity attribute

Description	Displays the total capacity of a hard-disk drive.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortGDriveType (Read or Write)

Table 967. Details of BIOS.SataSettings.SataPortGDriveType attribute

Description	Indicates type of device attached to this SATA port.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortGModel (Read or Write)

Table 968. Details of IOS.SataSettings.SataPortGModel attribute

Description	Displays the drive model of the selected device.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortH (Read or Write)

Table 969. Details ofBIOS.SataSettings.SataPortH attribute

Description	Sets the drive type of the selected device.
Legal Values	• Off • Auto
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if EmbSata is not set to `AtaMode`.

BIOS.SataSettings.SataPortHCapacity (Read or Write)

Table 970. Details of BIOS.SataSettings.SataPortHCapacity attribute

Description	Displays the total capacity of a hard disk drive.

Table 970. Details of BIOS.SataSettings.SataPortHCapacity attribute (continued)

Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortHDriveType (Read or Write)

Table 971. Details of BIOS.SataSettings.SataPortHDriveType attribute

Description	Indicates type of device attached to this SATA port.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortHModel (Read Only)

Table 972. Details of BIOS.SataSettings.SataPortHModel attribute

Description	Displays the drive model of the selected device.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortI (Read or Write)

Table 973. Details of BIOS.SataSettings.SataPortI attribute

Description	Sets the drive type of the selected device. When the Embedded SATA setting is in: • ATA Mode, setting this attribute to `Auto` will enable the BIOS support for the device. Select `Off` to turn off the BIOS support for the device. • AHCI Mode or RAID Mode, the BIOS always enables support for the device.
Legal Values	• Off

Table 973. Details of BIOS.SataSettings.SataPortI attribute (continued)

	• Auto
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortICapacity (Read or Write)

Table 974. Details of BIOS.SataSettings.SataPortICapacity attribute

Description	Displays the total capacity of a hard-disk drive. This property is not defined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortIDriveType (Read or Write)

Table 975. Details of BIOS.SataSettings.SataPortIDriveType attribute

Description	Indicates the type of device attached to this SATA port.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortIModel (Read or Write)

Table 976. Details of BIOS.SataSettings.SataPortIModel attribute

Description	Displays the drive model of the selected device.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortJ (Read or Write)

Table 977. Details of BIOS.SataSettings.SataPortJ attribute

Description	Sets the drive type of the selected device. When the Embedded SATA setting is in: ● ATA Mode, set this property to `Auto` to enable the BIOS support for the device. Select `Off` to turn off the BIOS support for the device. ● AHCI Mode or RAID Mode, the BIOS always enables support for the device.
Legal Values	● Off ● Auto
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortJCapacity (Read or Write)

Table 978. Details of BIOS.SataSettings.SataPortJCapacity attribute

Description	Displays the total capacity of a hard-disk drive. This property is not defined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortJDriveType (Read or Write)

Table 979. Details of BIOS.SataSettings.SataPortJDriveType attribute

Description	Indicates the type of device attached to this SATA port.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SataPortJModel (Read or Write)

Table 980. Details of BIOS.SataSettings.SataPortJModel attribute

Description	Displays the drive model of the selected device.

Table 980. Details of BIOS.SataSettings.SataPortJModel attribute (continued)

Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.SecurityFreezeLock (Read or Write)

Table 981. Details of BIOS.SataSettings.SecurityFreezeLock attribute

Description	Directs the Security Freeze Lock command to the Embedded SATA drives during POST. This option is only applicable for ATA and AHCI mode, and not applicable for RAID mode.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SataSettings.WriteCache (Read or Write)

Description	Sends Enable or Disable Write Cache command to the Embedded SATA drives during POST. This option is only applicable to ATA, AHCI mode, and is not applicable to RAID mode.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SerialCommSettings

To manage the serial port settings, use the objects in the group.

BIOS.SerialCommSettings.ConTermType (Read or Write)

Table 982. Details of BIOS.SerialCommSettings.ConTermType attribute

Description	Configures the remote console's terminal type.
Legal Values	• Vt100Vt220 • Ansi
Default Value	Not Applicable

Table 982. Details of BIOS.SerialCommSettings.ConTermType attribute (continued)

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SerialCommSettings.ExtSerialConnector (Read or Write)

Table 983. Details of BIOS.SerialCommSettings.ExtSerialConnector attribute

Description	Associate the External Serial Connector to Serial 1 or Serial 2 or Remote Access Device.
Legal Values	• Serial1 • Serial2 • RemoteAccDevice
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SerialCommSettings.FailSafeBaud (Read or Write)

Table 984. Details of BIOS.SerialCommSettings.FailSafeBaud attribute

Description	BIOS attempts to determine the baud rate automatically. This fail-safe baud rate is used only if the attempt is unsuccessful.
Legal Values	• 115200 • 57600 • 19200 • 9600
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SerialCommSettings.RedirAfterBoot (Read or Write)

Table 985. Details of BIOS.SerialCommSettings.RedirAfterBoot attribute

Description	Enables or disables the BIOS console redirection when the operating system is loaded.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable

Table 985. Details of BIOS.SerialCommSettings.RedirAfterBoot attribute (continued)

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SerialCommSettings.SerialComm (Read or Write)

Table 986. Details of BIOS.SerialCommSettings.SerialComm attribute

Description	Controls the serial communication options.
Legal Values	• Off • OnNoConRedir • OnConRedirCom1 • OnConRedirCom2 • OnConRedir
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SerialCommSettings.SerialPortAddress (Read or Write)

Table 987. Details of BIOS.SerialCommSettings.SerialPortAddress attribute

Description	Port address for the Serial Devices. (COM1=0x3F8 COM2=0x2F8)
Legal Values	• Serial1Com1Serial2Com2 • Serial1Com2Serial2Com1 • Com1 • Com2
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SlotDisablement

To manage the slot disablement settings, use the objects in this group.

BIOS.SlotDisablement.Slot1 (Read or Write)

Table 988. Details of BIOS.SlotDisablement.Slot1 attribute

Description	Control the configuration of the card installed in slot1.
Legal Values	• Enabled • Disabled • BootDriverDisabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SlotDisablement.Slot2 (Read or Write)

Table 989. Details of BIOS.SlotDisablement.Slot2 attribute

Description	Control the configuration of the card installed in slot 2.
Legal Values	• Enabled • Disabled • BootDriverDisabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SlotDisablement.Slot3 (Read or Write)

Table 990. Details of attribute

Description	Control the configuration of the card installed in slot 3.
Legal Values	• Enabled • Disabled • BootDriverDisabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SlotDisablement.Slot4 (Read or Write)

Table 991. Details of BIOS.SlotDisablement.Slot4 attribute

Description	Control the configuration of the card installed in slot 4.
Legal Values	• Enabled • Disabled • BootDriverDisabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SlotDisablement.Slot5 (Read or Write)

Table 992. Details of IOS.SlotDisablement.Slot5 attribute

Description	Control the configuration of the card installed in slot 5.
Legal Values	• Enabled • Disabled • BootDriverDisabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SlotDisablement.Slot6 (Read or Write)

Table 993. Details of BIOS.SlotDisablement.Slot6 attribute

Description	Control the configuration of the card installed in slot 6.
Legal Values	• Enabled • Disabled • BootDriverDisabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SlotDisablement.Slot7 (Read or Write)

Table 994. Details of BIOS.SlotDisablement.Slot7 attribute

Description	Control the configuration of the card installed in slot 7.
Legal Values	• Enabled • Disabled • BootDriverDisabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SlotDisablement.Slot8 (Read or Write)

Table 995. Details of BIOS.SlotDisablement.Slot8 attribute

Description	Controls configuration of the card installed in this slot. You can set one of the following options for each card: • Enabled: The card is available during POST or to the operating system. • Disabled: The card is not available during POST or to the operating system. • Boot Driver Disabled: The Option ROM is not run during POST, the system cannot boot from the card, and the pre-boot services are not available. However, it is available to the operating system. This option is not available if the slot contains a Dell RAID card. **NOTE:** If multiple cards from the same manufacturer are managed using the same boot driver, select `BootDriverDisabled` option for all the cards from the same manufacturer so that the Option ROM is not run.
Legal Values	• Enabled • Disabled • BootDriverDisabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SlotDisablement.Slot9 (Read or Write)

Table 996. Details of BIOS.SlotDisablement.Slot9 attribute

Description	Controls the configuration of the card installed in this slot. You can set one of the following options for each card: • Enabled: The card is available during POST or to the operating system. • Disabled: The card is not available during POST or to the operating system. • Boot Driver Disabled: The Option ROM is not run during POST, the system cannot boot from the card, and the pre-boot services are not available. However, it is available to the operating system. This option is not available if the slot contains a Dell RAID card.

Table 996. Details of BIOS.SlotDisablement.Slot9 attribute (continued)

	NOTE: If multiple cards from the same manufacturer are managed using the same boot driver, select `BootDriverDisabled` for all the cards from the same manufacturer so that the Option ROM is not run.
Legal Values	• Enabled • Disabled • BootDriverDisabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SlotDisablement.Slot10 (Read or Write)

Table 997. Details of BIOS.SlotDisablement.Slot10 attribute

Description	Controls configuration of the card installed in this slot. You can set one of the following option for each card. • Enabled: The card is available during POST or to the operating system. • Disabled: The card is not available during POST or to the operating system. • Boot Driver Disabled: The Option ROM will not run during POST, the system cannot boot from the card, and the pre-boot services are not available. However, it is available to the operating system. **NOTE:** This option is not available if the slot contains a Dell RAID card. **NOTE:** If multiple cards from the same manufacturer are managed using the same boot driver, select `BootDriverDisabled` value for all the cards from the same manufacturer so that the Option ROM is not run.
Legal Values	• Enabled • Disabled • BootDriverDisabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysInformation

To view information about system configuration, use the objects in this group.

BIOS.SysInformation.SystemMeVersion (Read or Write)

Description	Indicates the current version of the Management Engine (ME) firmware.
Legal Values	String from 0 to 48 characters
Default Value	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysInformation.SysMfrContactInfo (Read or Write)

Table 998. Details of BIOS.SysInformation.SysMfrContactInfo attribute

Description	Provides information about the Original Equipment Manufacturer of this system.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysInformation.SystemBiosVersion (Read or Write)

Table 999. Details of BIOS.SysInformation.SystemBiosVersion attribute

Description	Provides the current revision of the system BIOS firmware.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysInformation.SystemCpldVersion (Read or Write)

Table 1000. Details of IOS.SysInformation.SystemCpldVersion attribute

Description	Displays the current revision of the system CPLD firmware.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysInformation.SystemManufacturer (Read or Write)

Table 1001. Details of BIOS.SysInformation.SystemManufacturer attribute

Description	Provides the name of the Original Equipment Manufacturer of this system.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysInformation.SystemModelName (Read or Write)

Table 1002. Details of BIOS.SysInformation.SystemModelName attribute

Description	Provides the product name of the system.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysInformation.SystemServiceTag (Read or Write)

Table 1003. Details of BIOS.SysInformation.SystemServiceTag attribute

Description	The Service Tag assigns the Original Equipment Manufacturer of this system.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency`	None

BIOS.SysInformation.UefiComplianceVersion (Read or Write)

Table 1004. Details of BIOS.SysInformation.UefiComplianceVersion attribute

Description	Displays the system firmware UEFI compliance level.
Legal Values	Not Applicable
Default Value	Not Applicable

Table 1004. Details of BIOS.SysInformation.UefiComplianceVersion attribute (continued)

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysProfileSettings

To manage the system profile settings, use the objects in this group.

BIOS.SysProfileSettings.CollaborativeCpuPerfCtrl (Read/Write)

Table 1005. Details of BIOS.SysProfileSettings.CollaborativeCpuPerfCtrl attribute

Description	Enables or disables the CPU power management control. When `ProcPwrPerf` is not set to `SysDbpm` in Custom mode, changing this setting does not affect system performance.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Enabled only when `SysProfileSettings.ProcPwrPerf` is set to `SysDbpm` in Custom mode.

BIOS.SysProfileSettings.EnergyEfficientTurbo (Read or Write)

Table 1006. Details of BIOS.SysProfileSettings.EnergyEfficientTurbo attribute

Description	Enables or disables the energy efficient turbo.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysProfileSettings.EnergyPerformanceBias (Read or Write)

Table 1007. Details of BIOS.SysProfileSettings.EnergyPerformanceBias attribute

Description	Indicates the energy performance settings.
Legal Values	• MaxPower • BalancedPerformance

Table 1007. Details of BIOS.SysProfileSettings.EnergyPerformanceBias attribute (continued)

	• BalancedEfficiency • LowPower
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysProfileSettings.MemFrequency (Read or Write)

Table 1008. Details of BIOS.SysProfileSettings.MemFrequency attribute

Description	Set the speed of the system memory to maximum performance, maximum reliability or a specific speed.
Legal Values	• MaxPerf • 1600MHz • 1333MHz • 1067MHz • 800MHz • MaxReliability
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if `SysProfileSettings.SysProfile` is not set to Custom mode.

BIOS.SysProfileSettings.MemPatrolScrub (Read or Write)

Table 1009. Details of BIOS.SysProfileSettings.MemPatrolScrub attribute

Description	Patrol scrubbing is a feature that searches the memory for errors and repairs correctable errors to prevent the accumulation of memory errors.
Legal Values	• Standard • Extended • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if `SysProfileSettings.SysProfile` is not set to Custom mode.

BIOS.SysProfileSettings.MemPwrMgmt (Read or Write)

Table 1010. Details of BIOS.SysProfileSettings.MemPwrMgmt attribute

Description	Enables or disables the memory to operate in power management mode.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysProfileSettings.MemRefreshRate (Read or Write)

Table 1011. Details of BIOS.SysProfileSettings.MemRefreshRate attribute

Description	Frequency at which memory is normally refreshed.
Legal Values	• 1x • 2x
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if `SysProfileSettings.SysProfile` is not set to Custom mode.

BIOS.SysProfileSettings.MemVolt (Read or Write)

Table 1012. Details of BIOS.SysProfileSettings.MemVolt attribute

Description	Sets the DIMM voltage selection.
Legal Values	• AutoVolt • Volt135V • Volt15V
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if `SysProfileSettings.SysProfile` is set to Custom mode.

BIOS.SysProfileSettings.MonitorMwait (Read or Write)

Table 1013. Details of BIOS.SysProfileSettings.MonitorMwait attribute

Description	Enables or disables Monitor or Mwait instructions. When C state is enabled in Custom mode, changing this setting does not affect system performance
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Disabled only when `SysProfileSettings.ProcCStates` state is disabled in Custom mode.

BIOS.SysProfileSettings.PowerDelivery (Read or Write)

Table 1014. Details of BIOS.SysProfileSettings.PowerDelivery attribute

Description	Sets the power delivery mode.
Legal Values	• MaxReliability • MinPwr
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysProfileSettings.Proc1TurboCoreNum (Read or Write)

Description	Controls the number of Turbo Boost enabled cores for processor 1. By reducing the number of cores enabled with Turbo Boost, the maximum turbo frequency on the cores with Turbo Boost may be higher. Read-only unless System Profile is set to Custom.
Legal Values	• All • 1 • 2 • 4 • 6
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.Proc2TurboCoreNum (Read or Write)

Description	Controls the number of Turbo Boost enabled cores for processor 2. By reducing the number of cores enabled with Turbo Boost, the maximum turbo frequency on the cores with Turbo Boost may be higher. Read-only unless System Profile is set to Custom.
Legal Values	• All • 1 • 2 • 4 • 6
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.ProcC1E (Read or Write)

Table 1015. Details of BIOS.SysProfileSettings.ProcC1E attribute

Description	When enabled, the processor is allowed to switch to minimum performance state when idle.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if `SysProfileSettings.SysProfile` is not set to Custom mode.

BIOS.SysProfileSettings.ProcCStates (Read or Write)

Table 1016. Details of BIOS.SysProfileSettings.ProcCStates attribute

Description	Enables or disables the processor C-States.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if `SysProfileSettings.SysProfile` is not set to Custom mode.

BIOS.SysProfileSettings.ProcPwrPerf (Read or Write)

Table 1017. Details of BIOS.SysProfileSettings.ProcPwrPerf attribute

Description	Sets CPU power management to maximum performance operating system DBPM or System DBPM (DAPC) mode.
Legal Values	• MaxPerf • MinPwr • SysDbpm • OsDbpm
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if `SysProfileSettings.SysProfile` is not set to Custom mode.

BIOS.SysProfileSettings.PowerSaver (Read or Write)

Table 1018. Details of BIOS.SysProfileSettings.PowerSaver attribute

Description	Enables or disables the enhanced System DBPM (DAPC) mode.
Legal Values	• Enabled • Disabled
Default value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if SysProfileSettings.SysProfile is not set to Custom mode.

BIOS.SysProfileSettings.ProcTurboMode (Read or Write)

Table 1019. Details of BIOS.SysProfileSettings.ProcTurboMode attribute

Description	When enabled, the processor can operate in Turbo Boost Mode.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if `SysProfileSettings.SysProfile` is not set to Custom mode.

BIOS.SysProfileSettings.SysProfile (Read or Write)

Table 1020. Details of BIOS.SysProfileSettings.SysProfile attribute

Description	Sets the System Profile to Performance Per Watt (DAPC), Performance Per Watt (OS) Performance Dense Configuration, or Custom mode.
Legal Values	• PerfPerWattOptimizedOs • PerfPerWattOptimizedDapc • PerfOptimized • Custom • DenseCfgOptimized
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysProfileSettings.TpmCommand (Read or Write)

Table 1021. Details of BIOS.SysProfileSettings.TpmCommand attribute

Description	Allows to control the Trusted Platform Module (TPM). This property is Read-Only when TPM Security is set to `Off` and the action requires a restart before the effect. When set to: • `None`, the command is not sent to the TPM. • `Activate`, the TPM is enabled and activated. • `Deactivate`, the TPM is disabled and deactivated. • `Clear`, all the contents of TPM is cleared. Clearing the TPM will cause loss of all keys in the TPM. **NOTE:** The clearing can affect starting the operating system..
Legal Values	• None • Activate • Deactivate • Clear
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysProfileSettings.UncoreFrequency (Read or Write)

Table 1022. Details of IOS.SysProfileSettings.UncoreFrequency attribute

Description	Selects the processor uncore frequency.
Legal Values	• DynamicUFS • MaxUFS • MinUFS
Default Value	Not Applicable
Write Privilege	Server Control

Table 1022. Details of IOS.SysProfileSettings.UncoreFrequency attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysProfileSettings.WorkloadProfile (Read or Write)

Description	Allows optimization of performance based on the workload type. The WorkloadProfile setting is not a 'state'. Setting a workload profile is a one-time action that in turns modifies various BIOS settings to be optimized for the requested workload type.
Legal Values	• NotAvailable • HpcProfile • LowLatencyOptimizedProfile
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.WriteDataCrc

Table 1023. Details of BIOS.SysProfileSettings.WriteDataCrc attribute

Description	Detects the DDR4 data bus issues and corrects during the write operation.
Legal Values	• Enabled • Disabled
Default Value	NA
Write Privilege	Server control
License Required	RACADM
Dependency	Read only if `SysProfileSettings.SysProfile` is not set to `Custom`.

BIOS.SysSecurity

To manage the system security properties of the BIOS, use the objects in this group.

NOTE: After modifying the IntelTxt attribute value, the pending flag is enabled for the dependent attributes such as TpmActivation, TpmClear, and TpmSecurity.

BIOS.SysSecurity.AcPwrRcvry (Read or Write)

Table 1024. Details of BIOS.SysSecurity.AcPwrRcvry attribute

Description	Specifies how the system responds after AC power is restored to the system. It is useful when the system is turned off with a power strip.
Legal Values	• On

Table 1024. Details of BIOS.SysSecurity.AcPwrRcvry attribute (continued)

	• Off • Last
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if `SysSecurity.AcPwrRcvry` is set to Off.

BIOS.SysSecurity.AcPwrRcvryDelay (Read or Write)

Table 1025. Details of BIOS.SysSecurity.AcPwrRcvryDelay attribute

Description	Specifies how the system supports the staggering of power-up after AC power has been restored to the system.
Legal Values	• Immediate • User • Random
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.AcPwrRcvryUserDelay (Read or Write)

Table 1026. Details of BIOS.SysSecurity.AcPwrRcvryUserDelay attribute

Description	Controls the user-defined AC Recovery Delay.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.Aesni (Read or Write)

Table 1027. Details of BIOS.SysSecurity.Aesni attribute

Description	Displays the status of Intel(R) Processor AES-NI feature.
Legal Values	• Enabled • Disabled

Table 1027. Details of BIOS.SysSecurity.Aesni attribute (continued)

Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.BiosUpdateControl (Read or Write)

Table 1028. Details of BIOS.SysSecurity.BiosUpdateControl attribute

Description	If this attribute is set to Unlocked, then all BIOS update is allowed. If set to Limited, then local BIOS updates from DOS or UEFI shell based flash utilities, or Lifecycle Controller user interface is disallowed.
Legal Values	• Unlocked • Limited • Locked
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.IntelTxt (Read or Write)

Table 1029. Details of BIOS.SysSecurity.IntelTxt attribute

Description	Enables or disables Trusted Execution technology. **NOTE:** When the IntelTxt value is set to 'on', then the following values are set: TpmActivation=NoChange (Pending Value=NoChange), TpmClear=No (Pending Value=No), TpmSecurity=OnPbm (Pending Value=OnPbm).
Legal Values	• On • Off
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if: • `ProcSettings.ProcVirtualization` is `Disabled` • `SysSecurity.TpmActivation` is `Deactivate` • `SysSecurity.TpmActivation` is `Yes` • `SysSecurity.TpmSecurity` is not set to `OnPbm`

BIOS.SysSecurity.NmiButton (Read or Write)

Table 1030. Details of BIOS.SysSecurity.NmiButton attribute

Description	Enables or disables the NMI button on the front panel.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.PasswordStatus (Read or Write)

Table 1031. Details of BIOS.SysSecurity.PasswordStatus attribute

Description	Locks the system password.
Legal Values	• Locked • Unlocked
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.PwrButton (Read or Write)

Table 1032. Details of BIOS.SysSecurity.PwrButton attribute

Description	Enables or disables the power button on the front panel.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.SecureBoot (Read or Write)

Table 1033. Details of BIOS.SysSecurity.SecureBoot attribute

Description	Enables or disables the SecureBoot option.

Table 1033. Details of BIOS.SysSecurity.SecureBoot attribute (continued)

	NOTE: `BiosBootSettings.Bootmode` must be set to `UEFI` and `MiscSettings.ForceInt10` must be `Disabled` to operate this property.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.SecureBootPolicy (Read or Write)

Description	Allows selecting the Secure Boot Policy. When set to Standard, the BIOS uses the key and certificates from the system manufacturer to authenticate pre-boot images. When set to Custom, the BIOS uses the user-customized key and certificates. Note: If Custom mode is selected, the Secure Boot Custom Policy Settings menu is displayed. Note: Changing the default security certificates may cause the system to fail booting from certain boot options.
Legal Values	• Standard • Custom
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.SetupPassword (Read or Write)

Table 1034. Details of IOS.SysSecurity.SetupPassword attribute

Description	Set up the system password. Optional parameter `-o <string>` is used with this object to provide old password as an authentication for changing the previously configured password to the new password. The password can include the following: • Up to 32 characters including whitespace. • Contain numbers 0 through 9. • Only lower case alphabets are accepted. • Special characters accepted are +, ",, — , ., /, ;, [, \,], `. To enable password modification, **J_EN_PASSWD** must be installed. To clear the already configured password, use the option available under F2 (system setup) during system start.
Legal Values	String of up to 22 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.SHA256SetupPassword (Read or Write)

Table 1035. Details of BIOS.SysSecurity.SHA256SetupPassword attribute

Description	Indicates the SHA256 hash of the setup password.
Legal Values	String of 64 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.SHA256SetupPasswordSalt (Read or Write)

Table 1036. Details of BIOS.SysSecurity.SHA256SetupPasswordSalt attribute

Description	Indicates the Salt string added to the setup password before hash.
Legal Values	String of 32 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.SignedFirmwareUpdate (Read or Write)

Table 1037. Details of BIOS.SysSecurity.SignedFirmwareUpdate attribute

Description	Enables the signed BIOS update feature. Once enabled, this attribute cannot be disabled. When you change the value from disabled to enabled, a warning message is displayed.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.SysPassword (Read or Write)

Table 1038. Details of BIOS.SysSecurity.SysPassword attribute

Description	Provides the system password. Optional parameter `-o <string>` is used with this object to provide old password as an authentication for changing the previously configured password to the new password. The password can include the following: • Up to 32 characters including whitespace. • Contain numbers 0 through 9.

Table 1038. Details of BIOS.SysSecurity.SysPassword attribute (continued)

	• Only lower case alphabets are accepted. • Special characters accepted are +, ", ,, -, ., /, :, [, \,], `. To enable password modification, **J_EN_PASSWD** must be installed. To clear the already configured password, use the option available under F2 (system setup) during system start.
Legal Values	String of up to 22 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.SHA256SystemPassword (Read or Write)

Table 1039. Details of BIOS.SysSecurity.SHA256SystemPassword attribute

Description	Indicates the SHA256 hash of the system password.
Legal Values	String of 64 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.SHA256SystemPasswordSalt (Read or Write)

Table 1040. Details of BIOS.SysSecurity.SHA256SystemPasswordSalt attribute

Description	Indicates the Salt string added to the system password before hash.
Legal Values	String of 32 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.TcmActivation (Read or Write)

Table 1041. Details of BIOS.SysSecurity.TcmActivation attribute

Description	Set the operational state of the Trusted Cryptography Module (TCM).
Legal Values	• No change • Activate • Deactivate

Table 1041. Details of BIOS.SysSecurity.TcmActivation attribute (continued)

Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.TcmClear (Read or Write)

Table 1042. Details of BIOS.SysSecurity.TcmClear attribute

Description	Warns that clearing the TPM causes loss of all keys in the TPM. It may affect starting the operating system.
Legal Values	• Yes • No
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.TcmSecurity (Read or Write)

Table 1043. Details of BIOS.SysSecurity.TcmSecurity attribute

Description	Controls the reporting of the Trusted Cryptography Module (TCM) in the system.
Legal Values	• Off • On
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.TpmActivation (Read or Write)

Table 1044. Details of BIOS.SysSecurity.TpmActivation attribute

Description	Specify the operational state of the Trusted Platform Module (TPM).
Legal Values	• NoChange • Activate • Deactivate
Default Value	Not Applicable

Table 1044. Details of BIOS.SysSecurity.TpmActivation attribute (continued)

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if `SysSecurity.TpmSecurity` is set to `Off`.

BIOS.SysSecurity.TpmClear (Read or Write)

Table 1045. Details of BIOS.SysSecurity.TpmClear attribute

Description	Warns that clearing the TPM causes loss of all keys in the TPM. It may affect starting the operating system.
Legal Values	• Yes • No
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Read Only if `SysSecurity.TpmSecurity` is set to `Off`.

BIOS.SysSecurity.TpmFirmware

Table 1046. Details of BIOS.SysSecurity.TpmFirmware attribute

Description	Displays the firmware version of the Trusted Platform Module (TPM).
Legal Values	NA
Default Value	NA
Write Privilege	Server control
License Required	RACADM
Dependency	None

BIOS.SysSecurity.TpmInfo (Read Only)

Description	Displays the TPM's type and TPM's firmware version.
Legal Values	String from 0 to 100 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.TpmPpiBypassClear

Table 1047. Details of BIOS.SysSecurity.TpmPpiBypassClear attribute

Description	Clears the Physical Presence Interface (PPI) Advanced Configuration and Power Interface (ACPI) and enables the operating system to by-pass the PPI-related prompts.
Legal Values	• Enabled • Disabled
Default Value	NA
Write Privilege	Server control
License Required	RACADM
Dependency	None

BIOS.SysSecurity.TpmPpiBypassProvision

Table 1048. Details of BIOS.SysSecurity.TpmPpiBypassProvision attribute

Description	Enables or disables the Physical Presence Interface (PPI) Advanced Configuration and Power Interface (ACPI) and this feature enables operating system to by-pass the PPI-related prompts.
Legal Values	• Enabled • Disabled
Default Value	NA
Write Privilege	Server control
License Required	RACADM
Dependency	None

BIOS.SysSecurity.TpmSecurity (Read or Write)

Table 1049. Details of BIOS.SysSecurity.TpmSecurity attribute

Description	Controls the reporting of the Trusted Platform Module (TPM) in the system.
Legal Values	• Off • OnPbm • OnNoPbm
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.TPMStatus (Read Only)

Table 1050. Details of BIOS.SysSecurity.TPMStatus attribute

Description	Displays the status of TPM.
Legal Values	String of up to 64 ASCII characters.
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.SysSecurity.UefiVariableAccess (Read or Write)

Description Provides varying degrees of securing UEFI variables. When set to Standard, UEFI variables are accessible and can be modified in the Operating System (OS) per the UEFI specification. When set to Controlled, select UEFI variables are protected and cannot be modified in an OS environment. New UEFI boot entries are forced to be at the end of the current boot order.

Legal Values
- Standard
- Controlled

Default Value Not Applicable

Write Privilege Server Control

License Required iDRAC Express or iDRAC Enterprise

Dependency Not applicable

BIOS.UefiBootSettings

The objects in this group manages the UEFI boot settings.

BIOS.UefiBootSettings.UefiBootSeq (Read or Write)

Table 1051. Details of BIOS.UefiBootSettings.UefiBootSeq attribute

Description	Controls the UEFI boot order. The first option in the list is tried first. If unsuccessful, the second option is tried and so on. This property is applied only when Boot Mode is `UEFI` and not `BIOS`.
Legal Values	Enum Values
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

BIOS.UefiBootSettings.UefiPxeIpVersion (Read or Write)

Table 1052. Details of BIOS.UefiBootSettings.UefiPxeIpVersion attribute

Description	Enables to select the IPv4 PXE booting (default) or IPv6 PXE booting when in UEFI boot mode. This property is disabled in BIOS boot mode. If this property is modified, the PXE options in the UEFI boot sequence is replaced on the next restart.
Legal Values	• IPv4 • IPv6
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

FC.FCDevice

The objects in this group manage the FC device.

FC.FCDevice.BusDeviceFunction (Read Only)

Table 1053. Details of FC.FCDevice.BusDeviceFunction attribute

Description	Indicates the enumerated PCI Bus, Device, and Function value as a single string.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.FCDevice.ChipMdl (Read Only)

Table 1054. Details of FC.FCDevice.ChipMdl attribute

Description	Indicates the PCI configuration space information.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.FCDevice.EFIVersion (Read Only)

Table 1055. Details of attribute

Description	Indicates the version of the EFI device driver.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.FCDevice.FamilyVersion (Read Only)

Table 1056. Details of FC.FCDevice.FamilyVersion attribute

Description	Indicates the firmware's family version.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.FCDevice.PCIDeviceID (Read Only)

Table 1057. Details of FC.FCDevice.PCIDeviceID attribute

Description	Indicates the device ID present in the PCI configuration space.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.FCTarget

The objects in this group manage the Fibre Channel target.

FC.FCTarget.BootScanSelection (Read or Write)

Table 1058. Details of FC.FCTarget.BootScanSelection attribute

Description	Sets the port's operation while starting the system from Fiber Channel target(s). Only operations supported by the option-ROM should be implemented.

Table 1058. Details of FC.FCTarget.BootScanSelection attribute (continued)

Legal Values	• Disabled • SpecifiedLUN • FirstLUN • FirstLUN0 • FirstNOTLUN0 • FabricDiscovered
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.FCTarget.FirstFCTargetLUN (Read or Write)

Table 1059. Details of FC.FCTarget.FirstFCTargetLUN attribute

Description	Specifies the LUN (Logical Unit Number) of the first Fibre Channel boot target.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.FCTarget.SecondFCTargetLUN (Read or Write)

Table 1060. Details of FC.FCTarget.SecondFCTargetLUN attribute

Description	Specifies the LUN of the second Fibre Channel boot target.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.FCTarget.FirstFCTargetWWPN (Read or Write)

Table 1061. Details of FC.FCTarget.FirstFCTargetWWPN attribute

Description	Specifies the World Wide Port Name of the first Fibre Channel boot target.
Legal Values	Not Applicable
Default Value	Not Applicable

Table 1061. Details of FC.FCTarget.FirstFCTargetWWPN attribute (continued)

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.FCTarget.SecondFCTargetWWPN (Read or Write)

Table 1062. Details of FC.FCTarget.SecondFCTargetWWPN attribute

Description	Specifies the World Wide Port Name (WWPN) of the second Fibre Channel boot target.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.HBAConfig

The objects in this group manage the Fibre Channel Host Bus Adapter (HBA).

FC.HBAConfig.FCTape (Read or Write)

Table 1063. Details of FC.HBAConfig.FCTape attribute

Description	Enables or disables Fibre Channel Tape support.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.HBAConfig.FabricLoginTimeout (Read or Write)

Table 1064. Details of FC.HBAConfig.FabricLoginTimeout attribute

Description	Sets the SAN Fabric login time out.
Legal Values	Not Applicable
Default Value	3000
Write Privilege	Server Control

Table 1064. Details of FC.HBAConfig.FabricLoginTimeout attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.HBAConfig.FabricLoginRetryCount (Read or Write)

Table 1065. Details of FC.HBAConfig.FabricLoginRetryCount attribute

Description	Sets the current SAN Fabric login retry count.
Legal Values	Not Applicable
Default Value	3
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.HBAConfig.FramePayloadSize (Read or Write)

Table 1066. Details of FC.HBAConfig.FramePayloadSize attribute

Description	Sets the Frame Payload Size to automatic or in bytes.
Legal Values	• Auto • 512 • 1024 • 2048 • 2112
Default Value	Auto
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.HBAConfig.HardZone (Read or Write)

Table 1067. Details of FC.HBAConfig.HardZone attribute

Description	Enables or disables the Fibre Channel hard zone.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Table 1067. Details of FC.HBAConfig.HardZone attribute (continued)

Dependency	Not Applicable

FC.HBAConfig.HardZoneAddress (Read or Write)

Table 1068. Details of FC.HBAConfig.HardZoneAddress attribute

Description	Sets the Hard Zone address.
Legal Values	Not Applicable
Default Value	0
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.HBAConfig.LinkDownTimeout (Read or Write)

Table 1069. Details of FC.HBAConfig.LinkDownTimeout attribute

Description	Sets the Link down time out.
Legal Values	Not Applicable
Default Value	3000
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.HBAConfig.LoopResetDelay (Read or Write)

Table 1070. Details of FC.HBAConfig.LoopResetDelay attribute

Description	Sets the arbitrated Loop Reset Delay for the port in seconds.
Legal Values	Not Applicable
Default Value	5
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.HBAConfig.PortDownRetryCount (Read or Write)

Table 1071. Details of FC.HBAConfig.PortDownRetryCount attribute

Description	Sets the target port down Input/Output retry count.
Legal Values	Not Applicable

Table 1071. Details of FC.HBAConfig.PortDownRetryCount attribute (continued)

Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.HBAConfig.PortDownTimeout (Read or Write)

Table 1072. Details of FC.HBAConfig.PortDownTimeout attribute

Description	Sets the target port down time out.
Legal Values	Not Applicable
Default Value	3000
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.HBAConfig.PortLoginRetryCount (Read or Write)

Table 1073. Details of FC.HBAConfig.PortLoginRetryCount attribute

Description	Sets the target Port login retry count.
Legal Values	Not Applicable
Default Value	3
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.HBAConfig.PortLoginTimeout (Read or Write)

Table 1074. Details of FC.HBAConfig.PortLoginTimeout attribute

Description	Sets the target port login time out.
Legal Values	Not Applicable
Default Value	3000
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.PortConfig

The objects in this group manage the Fiber Channel port configuration.

FC.PortConfig.DeviceName (Read Only)

Table 1075. Details of FC.PortConfig.DeviceName attribute

Description	Indicates the product name of the Fibre Channel host bus adapter.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.PortConfig.FCDevice (Read Only)

Table 1076. Details of FC.PortConfig.FCDevice attribute

Description	Displays the version of the device and firmware.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.PortConfig.FCTarget (Read Only)

Table 1077. Details of FC.PortConfig.FCTarget attribute

Description	Enables the connection, configure boot, and communication parameters for the Fibre Channel boot target(s).
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.PortConfig.HBAConfig (Read Only)

Table 1078. Details of FC.PortConfig.HBAConfig attribute

Description	Configures the advanced settings for adapter and port.

Table 1078. Details of FC.PortConfig.HBAConfig attribute (continued)

Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.PortConfig.PortNumber (Read Only)

Table 1079. Details of FC.PortConfig.PortNumber attribute

Description	Indicates the Fibre Channel Host Bus Adapter port number.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.PortConfig.PortSpeed (Read or Write)

Table 1080. Details of FC.PortConfig.PortSpeed attribute

Description	Specifies the data rate of the Fibre Channel Host Bus Adapter port. The value can be Automatic or specified in Gbps.
Legal Values	• Auto • 1G • 2G • 4G • 8G • 16G
Default Value	Auto
Write Privilege	Sever Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.PortConfig.VirtualWWN (Read or Write)

Table 1081. Details of FC.PortConfig.VirtualWWN attribute

Description	Indicates the virtual Fibre Channel World Wide Node Name (WWN).
Legal Values	Not Applicable

Table 1081. Details of FC.PortConfig.VirtualWWN attribute (continued)

Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.PortConfig.VirtualWWPN (Read or Write)

Table 1082. Details of FC.PortConfig.VirtualWWPN attribute

Description	Indicates the virtual Fibre Channel World Wide Port Name of the port.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.PortConfig.WWN (Read Only)

Table 1083. Details of FC.PortConfig.WWN attribute

Description	Indicates the permanent Fibre Channel World Wide Node name.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

FC.PortConfig.WWPN (Read Only)

Table 1084. Details of FC.PortConfig.WWPN attribute

Description	Indicates the permanent Fibre Channel World Wide Port Name assigned to the port.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.ConfigureFormn

The objects in this group manage.

NIC.ConfigureFormn.BusDeviceFunction (Read Only)

Table 1085. Details of NIC.ConfigureFormn.BusDeviceFunction attribute

Description	Indicates the value of the bus device function.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.ConfigureFormn.MacAddr (Read Only)

Table 1086. Details of NIC.ConfigureFormn.MacAddr attribute

Description	Indicates the permanent MAC address.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.ConfigureFormn.FIPMacAddr (Read Only)

Table 1087. Details of NIC.ConfigureFormn.FIPMacAddr attribute

Description	Indicates the permanent FIP-MAC address for FCoE.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.ConfigureFormn.IscsiMacAddr (Read Only)

Table 1088. Details of NIC.ConfigureFormn.IscsiMacAddr attribute

Description	Indicates the permanent MAC address for iSCSI off load.

Table 1088. Details of NIC.ConfigureFormn.IscsiMacAddr attribute (continued)

Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.ConfigureFormn.iScsiOffloadMode (Read or Write)

Table 1089. Details of NIC.ConfigureFormn.iScsiOffloadMode attribute

Description	Enables or disables the iSCSI off load on the partition.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.ConfigureFormn.FCoEOffloadMode (Read or Write)

Table 1090. Details of NIC.ConfigureFormn.FCoEOffloadMode attribute

Description	Enables or disables the FCoE on the partition.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.ConfigureFormn.NicMode (Read or Write)

Table 1091. Details of NIC.ConfigureFormn.NicMode attribute

Description	Enables or disables the NIC mode on the partition.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control

Table 1091. Details of NIC.ConfigureFormn.NicMode attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.ConfigureFormn.PCIDeviceID (Read Only)

Table 1092. Details of NIC.ConfigureFormn.PCIDeviceID attribute

Description	Indicates the PCI Device ID of the partition.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.ConfigureFormn.WWN (Read Only)

Table 1093. Details of NIC.ConfigureFormn.WWN attribute

Description	Indicates the Fibre Channel World Wide Node name identifier for FCoE.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.ConfigureFormn.WWPN (Read Only)

Table 1094. Details of NIC.ConfigureFormn.WWPN attribute

Description	Indicates the Fibre Channel World Wide Port Name identifier for FCoE.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC_ConfigureFormn.VirtWWN (Read or Write)

Table 1095. Details of attribute

Description	Sets the Fibre Channel World Wide Node Name identifier for partition FCoE.
Legal Values	Not Applicable
Default Value	00:00:00:00:00:00:00:00
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC_ConfigureFormn.VirtWWPN (Read or Write)

Table 1096. Details of NIC_ConfigureFormn.VirtWWPN attribute

Description	Assigns the Fibre Channel World Wide Port Name identifier for partition FCoE.
Legal Values	Not Applicable
Default Value	00:00:00:00:00:00:00:00
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC_ConfigureFormn.VirtMacAddr (Read or Write)

Table 1097. Details of NIC_ConfigureFormn.VirtMacAddr attribute

Description	Assigns MAC address for partition.
Legal Values	Not Applicable
Default Value	00:00:00:00:00:00
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC_ConfigureFormn.VirtIscsiMacAddr (Read or Write)

Table 1098. Details of attribute

Description	Assigns the MAC address for partition iSCSI off load.
Legal Values	Not Applicable
Default Value	00:00:00:00:00:00
Write Privilege	Server Control

Table 1098. Details of attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC_ConfigureFormn.VirtFIPMacAddr (Read or Write)

Table 1099. Details of NIC_ConfigureFormn.VirtFIPMacAddr attribute

Description	Assigns the FIP-MAC address for partition FCoE.
Legal Values	Not Applicable
Default Value	00:00:00:00:00:00
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.DCBSettings

The following section provides information about the objects in the `NIC.DCBSettings` group.

NIC.DCBSettings.CongestionNotification (Read Only)

Table 1100. Details of NIC.DCBSettings.CongestionNotification attribute

Description	Indicates whether Congestion Notification capability is supported.
Legal Values	• Available • Unavailable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.DCBSettings.DCBExchangeProtocol (Read Only)

Table 1101. Details of NIC.DCBSettings.DCBExchangeProtocol attribute

Description	Indicates whether Data Center Bridging (DCB) Exchange Protocol capability is supported.
Legal Values	• Available • Unavailable
Default Value	Not Applicable
Write Privilege	Not Applicable

Table 1101. Details of NIC.DCBSettings.DCBExchangeProtocol attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.DCBSettings.EnhancedTransmissionSelection (Read Only)

Table 1102. Details of NIC.DCBSettings.EnhancedTransmissionSelection attribute

Description	Indicates whether Enhanced Transmission Selection capability is supported.
Legal Values	• Available • Unavailable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.DCBSettings.PriorityFlowControl (Read Only)

Table 1103. Details of NIC.DCBSettings.PriorityFlowControl attribute

Description	Indicates whether Priority Flow Control capability is supported.
Legal Values	• Available • Unavailable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.DeviceLevelConfig

To manage the device level configurations, use the objects in this group.

NOTE: To get the actual supported values for BIOS, NIC, and FC components, query the help with an index. If you query without an index, the generic help is displayed.

NIC.DeviceLevelConfig.EVBModesSupport (Read Only)

Table 1104. Details of NIC.DeviceLevelConfig.EVBModesSupport attribute

Description	Indicates the type of EVB Modes supported.
Legal Values	• VEB

Table 1104. Details of NIC.DeviceLevelConfig.EVBModesSupport attribute (continued)

	• VEPA • PE • Multichannel
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.DeviceLevelConfig.FlowControlSetting (Read or Write)

Table 1105. Details of NIC.DeviceLevelConfig.FlowControlSetting attribute

Description	Configure type of Flow Control used.
Legal Values	• Auto • TX:Send Pause on RX Overflow • RX:Throttle TX on Pause Received • TX RX Flow Control
Default Value	Auto
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.DeviceLevelConfig.NParEP (Read or Write)

Table 1106. Details of attribute

Description	Controls the enablement of NParEP mode.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.DeviceLevelConfig.NumberVFSupported (Read Only)

Description	The total number of PCI Virtual Functions supported on this port (or device). Whether the number applies to the device as a whole, or to an individual port, is indicated by the value of the Virtual Function Allocation Basis.

Legal Values	None
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.SRIOVSupport (Read Only)

Table 1107. Details of NIC.DeviceLevelConfig.SRIOVSupport attribute

Description	Indicates whether SR-IOV capability is supported.
Legal Values	• Available • Unavailable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency`	None

NIC.DeviceLevelConfig.VFAllocBasis (Read Only)

Description	Defines the domain in which Virtual Functions are allocated; either Port or Device. Note: A device which implements less than 1 PF per physical port must use Device level VF allocation.
Legal Values	• Port • Device
Default Value	Port
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.VFAllocMult (Read Only)

Description	Defines the multiple (e.g. x1, x4, x8, etc.) in which VFs must be allocated to a PF.
Legal Values	Integral values from 0-256
Default Value	1
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.VirtualizationMode (Read or Write)

Table 1108. Details of NIC.DeviceLevelConfig.VirtualizationMode attribute

Description	Specifies the type of virtualization used by the controller on all ports.
Legal Values	• NONE • NPAR • SRIOV • NPARSRIOV
Default Value	None
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NOTE: For Emulex cards, the `VirtualizationMode` attribute is found under the `VndrConfigPage` group instead of the `DeviceLevelConfig` group.

NIC.FCOECapabilities

The following section provides information about the objects in the `NIC.FCOECapabilities` group.

NIC.FCOECapabilities.AddressingMode (Read Only)

Table 1109. Details of NIC.FCOECapabilities.AddressingMode attribute

Description	Indicates whether SPMA or FPMA addressing is used for FCoE transactions.
Legal Values	• SPMA • FPMA
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCOECapabilities.MaxFrameSize (Read Only)

Table 1110. Details of NIC.FCOECapabilities.MaxFrameSize attribute

Description	Indicates the maximum frame size for each FCoE frame.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable

Table 1110. Details of NIC.FCOECapabilities.MaxFrameSize attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCOECapabilities.MaxIOsPerSession (Read Only)

Table 1111. Details of NIC.FCOECapabilities.MaxIOsPerSession attribute

Description	Indicates the maximum number of IOs supported per session.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCOECapabilities.MaxNPIVPerPort (Read Only)

Table 1112. Details of NIC.FCOECapabilities.MaxNPIVPerPort attribute

Description	Indicates the maximum number of NPIV WWN per port.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCOECapabilities.MaxNumberExchanges (Read Only)

Table 1113. Details of NIC.FCOECapabilities.MaxNumberExchanges attribute

Description	Indicates the maximum number of exchanges supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCOECapabilities.MaxNumberLogins (Read Only)

Table 1114. Details of NIC.FCOECapabilities.MaxNumberLogins attribute

Description	Indicates the maximum number of logins supported per port.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCOECapabilities.MaxNumberOfFCTargets (Read Only)

Table 1115. Details of NIC.FCOECapabilities.MaxNumberOfFCTargets attribute

Description	Indicates the maximum number of FC targets supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCOECapabilities.MaxNumberOutStandingCommands (Read Only)

Table 1116. Details of NIC.FCOECapabilities.MaxNumberOutStandingCommands attribute

Description	Indicates the maximum number of outstanding commands supported across all sessions.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCOECapabilities.MTUReconfigurationSupport (Read Only)

Table 1117. Details of NIC.FCOECapabilities.MTUReconfigurationSupport attribute

Description	Indicates whether the MTU reconfiguration capability is supported.

Table 1117. Details of NIC.FCOECapabilities.MTUReconfigurationSupport attribute (continued)

Legal Values	• Available • Unavailable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCoEConfiguration

The following section provides information about the objects in the NIC.FCoEConfiguration group.

NIC.FCoEConfiguration.ConnectFirstFCoETarget (Read or Write)

Table 1118. Details of NIC.FCoEConfiguration.ConnectFirstFCoETarget attribute

Description	Specifies whether FCoE initiator is used to connect to the first FCoE storage target defined.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCoEConfiguration.BootOrderFirstFCoETarget (Read or Write)

Table 1119. Details of NIC.FCoEConfiguration.BootOrderFirstFCoETarget attribute

Description	Specifies the port's target in the FCoE boot order.
Legal Values	Not Applicable
Default Value	0
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.FCoEConfiguration.BootOrderSecondFCoETarget (Read or Write)

Table 1120. Details of NIC.FCoEConfiguration.BootOrderSecondFCoETarget attribute

Description	Specifies the port's second defined target in the FCoE boot.
Legal Values	Not Applicable
Default Value	0
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.FCoEConfiguration.BootOrderThirdFCoETarget (Read or Write)

Table 1121. Details of NIC.FCoEConfiguration.BootOrderThirdFCoETarget attribute

Description	Specifies the port's third defined target in the FCoE boot.
Legal Values	Not Applicable
Default Value	0
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.FCoEConfiguration.BootOrderFourthFCoETarget (Read or Write)

Table 1122. Details of NIC.FCoEConfiguration.BootOrderFourthFCoETarget attribute

Description	Specifies the port's fourth defined target in the FCoE boot.
Legal Values	Not Applicable
Default Value	0
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.FCoEConfiguration.FirstFCoEBootTargetLUN (Read or Write)

Table 1123. Details of NIC.FCoEConfiguration.FirstFCoEBootTargetLUN attribute

Description	LUN of the first FCoE storage target that the FCoE initiator will start the system from when Connect attribute is enabled.

Table 1123. Details of NIC.FCoEConfiguration.FirstFCoEBootTargetLUN attribute (continued)

Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Enable `FCoEConfiguration.ConnectFirstFCoETarget`

NIC.FCoEConfiguration.FirstFCoEFCFVLANID (Read or Write)

Table 1124. Details of NIC.FCoEConfiguration.FirstFCoEFCFVLANID attribute

Description	VLAN ID uses the first FC storage target to connect.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCoEConfiguration.FirstFCoEWWPNTarget (Read or Write)

Table 1125. Details of NIC.FCoEConfiguration.FirstFCoEWWPNTarget attribute

Description	World Wide Port Name (WWPN) of the first FCoE storage target.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCoEConfiguration.MTUParams (Read or Write)

Table 1126. Details of NIC.FCoEConfiguration.MTUParams attribute

Description	Configure the MTU setting.
Legal Values	• Global • Per DCB Priority • Per VLAN
Default Value	Not Applicable

Table 1126. Details of NIC.FCoEConfiguration.MTUParams attribute (continued)

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCoEGenParams

The following section provides information about the objects in the `NIC.FCoEGenParams` group.

NIC.FCoEGenParams.FCoEBootScanSelection (Read or Write)

Table 1127. Details of NIC.FCoEGenParams.FCoEBootScanSelection attribute

Description	Represents the adaptor behavior for starting the system from specified FCoE storage target or fabric discovered target.
Legal Values	• 0 — Disabled • 1 — First LUN • 2 — First LUN 0 • 3 — First LUN Not LUN 0 • 4 — Fabric Discovered LUN • 5 — Specified LUN
Default Value	0 — Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCoEGenParams.FCoEFabricDiscoveryRetryCnt (Read or Write)

Table 1128. Details of NIC.FCoEGenParams.FCoEFabricDiscoveryRetryCnt attribute

Description	Retry count for FCoE fabric discovery.
Legal Values	Values: 0–60
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCoEGenParams.FCoEFirstHddTarget (Read or Write)

Table 1129. Details of NIC.FCoEGenParams.FCoEFirstHddTarget attribute

Description	Specifies whether the FCoE target is represented as the first HDD to the system.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCoEGenParams.FCoELnkUpDelayTime (Read or Write)

Table 1130. Details of NIC.FCoEGenParams.FCoELnkUpDelayTime attribute

Description	Specifies the time FCoE Initiator waits after an Ethernet link is established before sending any data over the network. Units are in seconds.
Legal Values	Values: 0–255
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCoEGenParams.FCoELunBusyRetryCnt (Read or Write)

Table 1131. Details of NIC.FCoEGenParams.FCoELunBusyRetryCnt attribute

Description	Specifies the number of connection retries the FCoE boot initiator will attempt if the FCoE target LUN is busy.
Legal Values	Values: 0–60
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FCoEGenParams.FCoETgtBoot (Read or Write)

Table 1132. Details of NIC.FCoEGenParams.FCoETgtBoot attribute

Description	Enables the FCoE initiator to start system to the FCoE target.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FrmwImgMenu

The following section provides information about the objects in the `NIC.FrmwImgMenu` group.

NIC.FrmwImgMenu.ControllerBIOSVersion (Read Only)

Table 1133. Details of NIC.FrmwImgMenu.ControllerBIOSVersion attribute

Description	Indicates the controller BIOS version information.
Legal Values	String of up to 8 ASCII characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FrmwImgMenu.EFIVersion (Read Only)

Table 1134. Details of NIC.FrmwImgMenu.EFIVersion attribute

Description	Indicates the EFI device driver version information.
Legal Values	String of up to 8 ASCII characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.FrmwImgMenu.FamilyVersion (Read Only)

Table 1135. Details of IC.FrmwImgMenu.FamilyVersion attribute

Description	Indicates the firmware family version information.
Legal Values	String of up to 8 ASCII characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.GlobalBandwidthAllocation

The following section provides information about the objects in the `NIC.GlobalBandwidthAllocation` group.

NIC.GlobalBandwidthAllocation.MaxBandwidth (Read or Write)

Table 1136. Details of NIC.GlobalBandwidthAllocation.MaxBandwidth attribute

Description	Set the maximum percentage of port TX bandwidth allocated to partition.
Legal Values	Values from 0 to 100
Default Value	100
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.GlobalBandwidthAllocation.MinBandwidth (Read or Write)

Table 1137. Details of NIC.GlobalBandwidthAllocation.MinBandwidth attribute

Description	Set the minimum percentage of port TX bandwidth allocated to partition.
Legal Values	Values: 0–100
Default Value	25
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.IscsiFirstTgtParams

The following section provides information about the objects in the `NIC.IscsiFirstTgtParams` group.

NIC.IscsiFirstTgtParams.AddressingMode (Read or Write)

Table 1138. Details of NIC.IscsiFirstTgtParams.AddressingMode attribute

Description	Enables or disables the connection to the first iSCSI target.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.IscsiFirstTgtParams.ConnectFirstTgt (Read or Write)

Table 1139. Details of NIC.IscsiFirstTgtParams.ConnectFirstTgt attribute

Description	Enables or disables connecting to the first iSCSI target.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiFirstTgtParams.FirstTgtBootLun (Read or Write)

Table 1140. Details of NIC.IscsiFirstTgtParams.FirstTgtBootLun attribute

Description	Set the first iSCSI storage target boot Logical Unit Number (LUN).
Legal Values	Values: 0–18446744073709551615
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiFirstTgtParams.FirstTgtChapId (Read or Write)

Table 1141. Details of NIC.IscsiFirstTgtParams.FirstTgtChapId attribute

Description	Set the first iSCSI storage target Challenge-Handshake Authentication Protocol (CHAP) ID.
Legal Values	String of up to 128 ASCII characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiFirstTgtParams.FirstTgtChapPwd (Password)

Table 1142. Details of NIC.IscsiFirstTgtParams.FirstTgtChapPwd attribute

Description	Specifies the first iSCSI storage target Challenge-Handshake Authentication Protocol (CHAP) secret (target CHAP password).
Legal Values	String of up to 16 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiFirstTgtParams.FirstTgtIpAddress (Read or Write)

Table 1143. Details of NIC.IscsiFirstTgtParams.FirstTgtIpAddress attribute

Description	Set the IP address of the first iSCSI target.
Legal Values	Valid IPv4 or IPv6 address
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiFirstTgtParams.FirstTgtIpVer (Read or Write)

Table 1144. Details of NIC.IscsiFirstTgtParams.FirstTgtIpVer attribute

Description	Specifies whether or not IPv4 or IPv6 network address is used for first iSCSI target.

Table 1144. Details of NIC.IscsiFirstTgtParams.FirstTgtIpVer attribute (continued)

Legal Values	• IPv4 • IPv6
Default Value	IPv4
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.IscsiFirstTgtParams.FirstTgtIscsiName (Read or Write)

Table 1145. Details of NIC.IscsiFirstTgtParams.FirstTgtIscsiName attribute

Description	Set the iSCSI Qualified Name (IQN) of the first iSCSI storage target.
Legal Values	String of upto 223 ASCII characters **NOTE:** The legal value range may be smaller than the maximum size of 223, based on the vendor configuration of the NIC cards.
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiFirstTgtParams.FirstTgtTcpPort (Read or Write)

Table 1146. Details of NIC.IscsiFirstTgtParams.FirstTgtTcpPort attribute

Description	Set the TCP Port number of the first iSCSI target.
Legal Values	Values from 1 to 65535
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiGenParams

The following section provides information about the objects in the `NIC.IscsiGenParams` group.

NIC.IscsiGenParams.ChapAuthEnable (Read or Write)

Table 1147. Details of NIC.IscsiGenParams.ChapAuthEnable attribute

Description	To use CHAP authentication when connecting to the iSCSI target, enable or disable the ability of the initiator.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiGenParams.ChapMutualAuth (Read or Write)

Table 1148. Details of NIC.IscsiGenParams.ChapMutualAuth attribute

Description	Enables or disables mutual CHAP authentication between the iSCSI initiator and target.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.IscsiGenParams.DhcpVendId (Read or Write)

Table 1149. Details of NIC.IscsiGenParams.DhcpVendId attribute

Description	Control what Vendor ID is presented to the DHCP service.
Legal Values	String of upto 255 ASCII characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiGenParams.FirstHddTarget (Read or Write)

Table 1150. Details of NIC.IscsiGenParams.FirstHddTarget attribute

Description	Enables or disables to check if the iSCSI target appears as the first hard disk drive (HDD) in the system.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiGenParams.IpAutoConfig (Read or Write)

Table 1151. Details of NIC.IscsiGenParams.IpAutoConfig attribute

Description	Controls the source of the initiator IP address DHCP or static assignment. This option is specific to IPv6.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `IscsiGenParams.IpVer` is set to 'IPv4' and `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiGenParams.IpVer (Read or Write)

Table 1152. Details of NIC.IscsiGenParams.IpVer attribute

Description	Controls whether IPv4 or IPv6 network addressing is used for iSCSI initiator and targets.
Legal Values	• Ipv4 • Ipv6 • None
Default Value	Ipv4
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiGenParams.IscsiTgtBoot (Read or Write)

Table 1153. Details of NIC.IscsiGenParams.IscsiTgtBoot attribute

Description	Specifies whether or not the iSCSI initiator will boot to the specified iSCSI target after connection.
Legal Values	• Enabled • Disabled • OneTimeDisabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.IscsiGenParams.IscsiViaDHCP (Read or Write)

Table 1154. Details of NIC.IscsiGenParams.IscsiViaDHCP attribute

Description	Enables the acquisition of iSCSI target parameters from DHCP.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiGenParams.IscsiVLanId (Read or Write)

Table 1155. Details of NIC.IscsiGenParams.IscsiVLanId attribute

Description	Specifies the VLAN ID for iSCSI boot mode.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.IscsiGenParams.IscsiVLanMode (Read or Write)

Table 1156. Details of NIC.IscsiGenParams.IscsiVLanMode attribute

Description	Enables or disables the Virtual LAN mode for iSCSI boot.

Table 1156. Details of NIC.IscsiGenParams.IscsiVLanMode attribute (continued)

Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.IscsiGenParams.LnkUpDelayTime (Read or Write)

Table 1157. Details of NIC.IscsiGenParams.LnkUpDelayTime attribute

Description	Set the time to allow for link to establish before driver initialization.
Legal Values	Values from 0 to 255
Default Value	0
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiGenParams.LunBusyRetryCnt (Read or Write)

Table 1158. Details of NIC.IscsiGenParams.LunBusyRetryCnt attribute

Description	Specifies the number of connection attempts the iSCSI boot initiator will attempt if the iSCSI target LUN is busy.
Legal Values	Values: 0–60
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiGenParams.TcpIpViaDHCP (Read or Write)

Table 1159. Details of NIC.IscsiGenParams.TcpIpViaDHCP attribute

Description	Setting to enable acquisition of IPv4 TCP/IP parameters from DHCP.
Legal Values	• Enabled • Disabled
Default Value	Disabled

Table 1159. Details of NIC.IscsiGenParams.TcpIpViaDHCP attribute (continued)

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `IscsiGenParams.IpVer` is set to 'IPv6' and `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiGenParams.TcpTimestmp (Read or Write)

Table 1160. Details of NIC.IscsiGenParams.TcpTimestmp attribute

Description	Enables or disables use of TCP timestamps in network packets as defined in RFC 1323.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiGenParams.WinHbaBootMode (Read or Write)

Table 1161. Details of NIC.IscsiGenParams.WinHbaBootMode attribute

Description	When enabled, it enables iSCSI Offload HBA start mode and disables iSCSI software initiator boot.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.IscsiInitiatorParams

The following section provides information about the objects in the `NIC.IscsiInitiatorParams` group.

NIC.IscsiInitiatorParams.IscsiInitiatorChapId (Read or Write)

Table 1162. Details of NIC.IscsiInitiatorParams.IscsiInitiatorChapId attribute

Description	Set the iSCSI initiator Challenge-Handshake Authentication Protocol (CHAP) ID.

Table 1162. Details of NIC.IscsiInitiatorParams.IscsiInitiatorChapId attribute (continued)

Legal Values	String of up to 128 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiInitiatorParams.IscsiInitiatorChapPwd (Read or Write)

Table 1163. Details of NIC.IscsiInitiatorParams.IscsiInitiatorChapPwd attribute

Description	Set the iSCSI initiator Challenge-Handshake Authentication Protocol (CHAP) secret (password).
Legal Values	String of 12–16 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiInitiatorParams.IscsiInitiatorGateway (Read or Write)

Table 1164. Details of NIC.IscsiInitiatorParams.IscsiInitiatorGateway attribute

Description	Specifies the Default Gateway of the iSCSI initiator.
Legal Values	String of 2-39 characters (Ipv4 or Ipv6 gateway)
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Available if `VndrConfigGroup.iSCSIBootSupport` is Unavailable.

NIC.IscsiInitiatorParams.IscsiInitiatorIpAddr (Read or Write)

Table 1165. Details of NIC.IscsiInitiatorParams.IscsiInitiatorIpAddr attribute

Description	Specifies the IP address of the iSCSI initiator.
Legal Values	String of 2–39 characters (Ipv4 or Ipv6 address)
Default Value	Not Applicable
Write Privilege	Server Control

Table 1165. Details of NIC.IscsiInitiatorParams.IscsiInitiatorIpAddr attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiInitiatorParams.IscsiInitiatorName (Read or Write)

Table 1166. Details of NIC.IscsiInitiatorParams.IscsiInitiatorName attribute

Description	Specifies the initiator iSCSI Qualified Name (IQN).
Legal Values	String of upto 223 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiInitiatorParams.IscsiInitiatorPrimDns (Read or Write)

Table 1167. Details of NIC.IscsiInitiatorParams.IscsiInitiatorPrimDns attribute

Description	Specifies the Primary DNS IP address of the iSCSI initiator.
Legal Values	String of 2–39 characters (Ipv4 or Ipv6 gateway)
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiInitiatorParams.IscsiInitiatorSecDns (Read or Write)

Table 1168. Details of NIC.IscsiInitiatorParams.IscsiInitiatorSecDns attribute

Description	Specifies the Secondary DNS IP address of the iSCSI initiator.
Legal Values	String of 2–39 characters (Ipv4 or Ipv6 gateway)
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiInitiatorParams.IscsiInitiatorSubnet (Read or Write)

Table 1169. Details of NIC.IscsiInitiatorParams.IscsiInitiatorSubnet attribute

Description	Specifies the IPv4 Subnet Mask of the iSCSI initiator.
Legal Values	String of 7–15 characters (IPv4 Subnet)
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiInitiatorParams.IscsiInitiatorSubnetPrefix (Read or Write)

Table 1170. Details of NIC.IscsiInitiatorParams.IscsiInitiatorSubnetPrefix attribute

Description	Specifies the IPv6 Subnet Mask Prefix of the iSCSI initiator.
Legal Values	String of 2–39 characters (IPv6 Subnet)
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiSecondaryDeviceParams

The following section provides information about the objects in the `NIC.IscsiSecondaryDeviceParams` group.

NIC.IscsiSecondaryDeviceParams.SecondaryDeviceMacAddr (Read or Write)

Table 1171. Details of NIC.IscsiSecondaryDeviceParams.SecondaryDeviceMacAddr attribute

Description	Specifies the MAC address of a secondary iSCSI boot adapter for redundancy in case if start is unsuccessful.
Legal Values	String of up to 17 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiSecondaryDeviceParams.UseIndTgtName (Read or Write)

Table 1172. Details of NIC.IscsiSecondaryDeviceParams.UseIndTgtName attribute

Description	Specifies whether to use Independent Target Name when multipath I/O is enabled.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiSecondaryDeviceParams.UseIndTgtPortal (Read or Write)

Table 1173. Details of NIC.IscsiSecondaryDeviceParams.UseIndTgtPortal attribute

Description	Specifies whether to use Independent Target Portal when multipath I/O is enabled.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiSecondTgtParams

To configure the `iSCSIsecond` storage, use the objects in this group.

NIC.IscsiSecondTgtParams.ConnectSecondTgt (Read or Write)

Table 1174. Details of NIC.IscsiSecondTgtParams.ConnectSecondTgt attribute

Description	Enables connecting to the second iSCSI target.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiSecondTgtParams.SecondTgtBootLun (Read or Write)

Table 1175. Details of NIC.IscsiSecondTgtParams.SecondTgtBootLun attribute

Description	Specifies the second iSCSI storage target boot Logical Unit Number (LUN).
Legal Values	Values: 0–18446744073709551615
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiSecondTgtParams.SecondTgtChapId (Read or Write)

Table 1176. Details of NIC.IscsiSecondTgtParams.SecondTgtChapId attribute

Description	Specifies the second iSCSI storage target Challenge-Handshake Authentication Protocol (CHAP) ID
Legal Values	Values: 0–128.
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiSecondTgtParams.SecondTgtChapPwd (Read or Write)

Table 1177. Details of NIC.IscsiSecondTgtParams.SecondTgtChapPwd attribute

Description	Specifies the second iSCSI storage target Challenge-Handshake Authentication Protocol (CHAP) secret (target CHAP password).
Legal Values	String of 12–16 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiSecondTgtParams.SecondTgtIpAddress (Read or Write)

Table 1178. Details of NIC.IscsiSecondTgtParams.SecondTgtIpAddress attribute

Description	Specifies the IP address of the second iSCSI target.

Table 1178. Details of NIC.IscsiSecondTgtParams.SecondTgtIpAddress attribute (continued)

Legal Values	String of 2-39 characters (Ipv4 or Ipv6 address)
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiSecondTgtParams.SecondTgtIpVer (Read or Write)

Table 1179. Details of NIC.IscsiSecondTgtParams.SecondTgtIpVer attribute

Description	Specifies whether or not IPv4 or IPv4 network address is used for the second iSCSI target.
Legal Values	• IPv4 • IPv6
Default Value	IPv4
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.IscsiSecondTgtParams.SecondTgtIscsiName (Read or Write)

Table 1180. Details of NIC.IscsiSecondTgtParams.SecondTgtIscsiName attribute

Description	Specifies the iSCSI Qualified Name (IQN) of the second iSCSI storage target.
Legal Values	String of up to 223 characters **NOTE:** The legal value range may be smaller than the maximum size of 223, based on the vendor configuration of the NIC cards.
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.IscsiSecondTgtParams.SecondTgtTcpPort (Read or Write)

Table 1181. Details of NIC.IscsiSecondTgtParams.SecondTgtTcpPort attribute

Description	Specifies the TCP Port number of the second iSCSI target.
Legal Values	Values: 1–65535
Default Value	Not Applicable

Table 1181. Details of NIC.IscsiSecondTgtParams.SecondTgtTcpPort attribute (continued)

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not available if `VndrConfigGroup.iSCSIBootSupport` is unavailable.

NIC.NICConfig

To configure the `NICConfig` properties, use the objects in this group.

NIC.NICConfig.BannerMessageTimeout (Read or Write)

Table 1182. Details of NIC.NICConfig.BannerMessageTimeout attribute

Description	Specifies the number of seconds that the OptionROM banner is displayed during POST.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.NICConfig.BootOptionROM (Read or Write)

Table 1183. Details of NIC.NICConfig.BootOptionROM attribute

Description	Controls the enablement of legacy Boot Protocols in the Option ROM.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.NICConfig.BootRetryCnt (Read or Write)

Table 1184. Details of NIC.NICConfig.BootRetryCnt attribute

Description	Specifies the number of attempts when the start is unsuccessful.
Legal Values	• NoRetry • 1Retry • 2Retries

Table 1184. Details of NIC.NICConfig.BootRetryCnt attribute (continued)

	• 3Retries • 4Retries • 5Retries • 6Retries • IndefiniteRetries
Default Value	NoRetry
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.NICConfig.BootStrapType (Read or Write)

Table 1185. Details of NIC.NICConfig.BootStrapType attribute

Description	Specifies the boot strap method used to start the operating system.
Legal Values	• AutoDetect • BBS • Int18h • Int19h
Default Value	AutoDetect
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.NICConfig.HideSetupPrompt (Read or Write)

Table 1186. Details of NIC.NICConfig.HideSetupPrompt attribute

Description	Enables or disables the option ROM setup prompt during Power On Self Test (POST).
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.NICConfig.LegacyBootProto (Read or Write)

Table 1187. Details of NIC.NICConfig.LegacyBootProto attribute

Description	Select a non-UEFI network start protocol.
Legal Values	• PXE • iSCSI • FCoE • NONE • iSCSIPrimary • iSCSI Secondary
Default Value	None
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.NICConfig.LnkSpeed (Read or Write)

Table 1188. Details of NIC.NICConfig.LnkSpeed attribute

Description	Specifies the port speed used for the selected boot protocol.
Legal Values	• AutoNeg • 10 Mbps Half • 10 Mbps Full • 100 Mbps Half • 100 Mbps Full
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.NICConfig.NumberVFAdvertised (Read or Write)

Table 1189. Details of NIC.NICConfig.NumberVFAdvertised attribute

Description	Indicates the number of PCI Virtual Functions advertised on the port when SR-IOV is enabled.
Legal Values	Not Applicable
Default Value	0
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.NICConfig.VLanId (Read or Write)

Table 1190. Details of NIC.NICConfig.VLanId attribute

Description	Specifies the ID (tag) for the VLAN Mode.
Legal Values	Values: 1–4095
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	`VLanMode` must be enabled.

NIC.NICConfig.VLanMode (Read or Write)

Table 1191. Details of NIC.NICConfig.VLanMode attribute

Description	Virtual LAN mode enables use of a VLAN tag to use vendor-defined boot protocols.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.NICConfig.WakeOnLan (Read or Write)

Table 1192. Details of NIC.NICConfig.WakeOnLan attribute

Description	Enables the server to be powered on using an in-band magic packet.
Legal Values	• Enabled • Disabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.NICConfig.WakeOnLanLnkSpeed (Read or Write)

Table 1193. Details of NIC.NICConfig.WakeOnLanLnkSpeed attribute

Description	Select the port speed used for Wake on LAN mode.

Table 1193. Details of NIC.NICConfig.WakeOnLanLnkSpeed attribute (continued)

Legal Values	• AutoNeg • 10 Mbps Half • 10 Mbps Full • 100 Mbps Half • 100 Mbps Full
Default Value	AutoNeg
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.NICPartitioningConfig

To configure the `NICPartitioning` properties, use the objects in this group.

NIC.NICPartitioningConfig.NicPartitioning (Read or Write)

Table 1194. Details of NIC.NICPartitioningConfig.NicPartitioning attribute

Description	Enables or disables NIC partitioning for all device ports.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.NICPartitioningConfig.PartitionState (Read Only)

Table 1195. Details of NIC.NICPartitioningConfig.PartitionState attribute

Description	Indicates the current enablement state of the partition.
Legal Values	• Enabled • Disabled
Default Value	Enabled
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.NICPartitioningConfig.ConfigureFormn (Read Only)

Table 1196. Details of NIC.NICPartitioningConfig.ConfigureFormn attribute

Description	Configures the partition functionality and display the assigned address.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.NICPartitioningConfig.NumberPCIEFunctionsEnabled (Read Only)

Table 1197. Details of NIC.NICPartitioningConfig.NumberPCIEFunctionsEnabled attribute

Description	Indicates the number of physical PCIe functions currently enabled on this port.
Legal Values	Values: 1–65535
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.NICPartitioningConfig.NumberPCIEFunctionsSupported (Read Only)

Table 1198. Details of NIC.NICPartitioningConfig.NumberPCIEFunctionsSupported attribute

Description	Indicates the number of physical PCIe functions supported on this port.
Legal Values	Values: 1–65535
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup

The objects in this group manage the vendor configuration settings.

NIC.VndrConfigGroup.BusDeviceFunction (Read Only)

Table 1199. Details of NIC.VndrConfigGroup.BusDeviceFunction attribute

Description	Indicates the BIOS assigned PCIe.
Legal Values	String of up to 8 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.BlnkLeds (Read or Write)

Table 1200. Details of NIC.VndrConfigGroup.BlnkLeds attribute

Description	Identifies the physical network port by blinking the associated LED.
Legal Values	Values: 0–15
Default Value	15
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.ChipMdl (Read Only)

Table 1201. Details of NIC.VndrConfigGroup.ChipMdl attribute

Description	Indicates the chip type or revision.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.EnergyEfficientEthernet (Read Only)

Table 1202. Details of NIC.VndrConfigGroup.EnergyEfficientEthernet attribute

Description	Indicates whether Energy Efficient Ethernet capability is supported.
Legal Values	None

Table 1202. Details of NIC.VndrConfigGroup.EnergyEfficientEthernet attribute (continued)

Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.DCBXSupport (Read Only)

Table 1203. Details of NIC.VndrConfigGroup.DCBXSupport attribute

Description	Indicates whether Data Center Bridging (DCB) capability is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.DeviceName (Read Only)

Table 1204. Details of NIC.VndrConfigGroup.DeviceName attribute

Description	Official product name of the device.
Legal Values	Not Applicable
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not Applicable

NIC.VndrConfigGroup.FCoEBootSupport (Read Only)

Table 1205. Details of NIC.VndrConfigGroup.FCoEBootSupport attribute

Description	Indicates whether Fibre Channel over Ethernet Boot capability is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.FCoEOffloadMode (Read or Write)

Table 1206. Details of NIC.VndrConfigGroup.FCoEOffloadMode attribute

Description	Enables or disables FCoE personality on the port.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.FCoEOffloadSupport (Read Only)

Table 1207. Details of NIC.VndrConfigGroup.FCoEOffloadSupport attribute

Description	Indicates whether FCoE Offload capability is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.FeatureLicensingSupport (Read Only)

Table 1208. Details of NIC.VndrConfigGroup.FeatureLicensingSupport attribute

Description	Indicates whether Dell Feature Licensing capability is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.FIPMacAddr (Read Only)

Table 1209. Details of NIC.VndrConfigGroup.FIPMacAddr attribute

Description	Permanent FIP-MAC address for FCoE assigned during manufacturing.

Table 1209. Details of NIC.VndrConfigGroup.FIPMacAddr attribute (continued)

Legal Values	String of up to 17 characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.FlexAddressing (Read Only)

Table 1210. Details of NIC.VndrConfigGroup.FlexAddressing attribute

Description	Indicates whether Dell FlexAddressing feature is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.iSCSIBootSupport (Read Only)

Table 1211. Details of NIC.VndrConfigGroup.iSCSIBootSupport attribute

Description	Indicates whether iSCSI Boot capability is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.ISCSIMacAddr (Read Only)

Table 1212. Details of NIC.VndrConfigGroup.ISCSIMacAddr attribute

Description	Indicates the permanent MAC address for iSCSI offload assigned during manufacturing.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise

Table 1212. Details of NIC.VndrConfigGroup.ISCSIMacAddr attribute (continued)

Dependency	None

NIC.VndrConfigGroup.iSCSIOffloadMode (Read or Write)

Table 1213. Details of NIC.VndrConfigGroup.iSCSIOffloadMode attribute

Description	Enables or disables iSCSI offload personality on the port.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.iSCSIOffloadSupport (Read Only)

Table 1214. Details of NIC.VndrConfigGroup.iSCSIOffloadSupport attribute

Description	Indicates whether iSCSI Offload capability is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.LinkStatus (Read Only)

Table 1215. Details of NIC.VndrConfigGroup.LinkStatus attribute

Description	Indicates the physical network link status that reports the controller.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.MacAddr (Read Only)

Table 1216. Details of NIC.VndrConfigGroup.MacAddr attribute

Description	Indicates the permanent MAC address assigned during manufacturing.
Legal Values	String of up to 17 characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.NicMode (Read or Write)

Table 1217. Details of NIC.VndrConfigGroup.NicMode attribute

Description	Enables or disables NIC personality on the port.
Legal Values	• Enabled • Disabled
Default Value	Enabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.NicPartitioningSupport (Read Only)

Table 1218. Details of NIC.VndrConfigGroup.NicPartitioningSupport attribute

Description	Indicates whether NIC Partitioning capability is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.NWManagementPassThrough (Read Only)

Table 1219. Details of NIC.VndrConfigGroup.NWManagementPassThrough attribute

Description	Indicates whether the Network Management Pass-Through capability is supported.
Legal Values	None

Table 1219. Details of NIC.VndrConfigGroup.NWManagementPassThrough attribute (continued)

Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.OnChipThermalSensor (Read Only)

Table 1220. Details of NIC.VndrConfigGroup.OnChipThermalSensor attribute

Description	Indicates whether an on-chip thermal sensor is available.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.OSBMCManagementPassThrough (Read Only)

Table 1221. Details of NIC.VndrConfigGroup.OSBMCManagementPassThrough attribute

Description	Indicates whether OS-BMC Management Pass Through capability is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.PCIDeviceID (Read Only)

Table 1222. Details of NIC.VndrConfigGroup.PCIDeviceID attribute

Description	Indicates the PCI Device ID of the port.
Legal Values	String of up to 4 characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise

Table 1222. Details of NIC.VndrConfigGroup.PCIDeviceID attribute (continued)

Dependency	None

NIC.VndrConfigGroup.PXEBootSupport (Read Only)

Table 1223. Details of NIC.VndrConfigGroup.PXEBootSupport attribute

Description	Indicates whether PXE Boot capability is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.RemotePHY (Read Only)

Table 1224. Details of NIC.VndrConfigGroup.RemotePHY attribute

Description	Indicates whether RemotePHY capability is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.RXFlowControl (Read Only)

Table 1225. Details of NIC.VndrConfigGroup.RXFlowControl attribute

Description	Indicates whether Receive (RX) Flow control capability is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.TOESupport (Read Only)

Table 1226. Details of NIC.VndrConfigGroup.TOESupport attribute

Description	Indicates whether TCP/IP Offload Engine capability is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.TXBandwidthControlMaximum (Read Only)

Table 1227. Details of NIC.VndrConfigGroup.TXBandwidthControlMaximum attribute

Description	Indicates whether Transmit (TX) Bandwidth Control Maximum capability is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.TXBandwidthControlMinimum (Read Only)

Table 1228. Details of NIC.VndrConfigGroup.TXBandwidthControlMinimum attribute

Description	Indicates whether Transmit (TX) Bandwidth Control Minimum capability is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.TXFlowControl (Read Only)

Table 1229. Details of NIC.VndrConfigGroup.TXFlowControl attribute

Description	Indicates whether Transmit (TX) Flow Control capability is supported.
Legal Values	None
Default Value	Not Applicable

Table 1229. Details of NIC.VndrConfigGroup.TXFlowControl attribute (continued)

Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.VirtFIPMacAddr (Read or Write)

Table 1230. Details of NIC.VndrConfigGroup.VirtFIPMacAddr attribute

Description	Programmatically assignable FIP-MAC address for FCoE. Programmatic write for support of I/O Identity feature.
Legal Values	String of up to 17 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.VirtIscsiMacAddr (Read or Write)

Table 1231. Details of NIC.VndrConfigGroup.VirtIscsiMacAddr attribute

Description	Programmatically assignable MAC address for iSCSI offload. Programmatic write for support of I/O Identity feature.
Legal Values	String of up to 17 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.VirtMacAddr (Read or Write)

Table 1232. Details of NIC.VndrConfigGroup.VirtMacAddr attribute

Description	Programmatically assignable MAC address. Programmatic write for support of I/O Identity feature.
Legal Values	String of up to 17 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Table 1232. Details of NIC.VndrConfigGroup.VirtMacAddr attribute (continued)

Dependency	None

NIC.VndrConfigGroup.VirtualLinkControl (Read or Write)

Table 1233. Details of NIC.VndrConfigGroup.VirtualLinkControl attribute

Description	Indicates whether Virtual Link Control capability is supported.
Legal Values	None
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.VirtWWN (Read or Write)

Table 1234. Details of NIC.VndrConfigGroup.VirtWWN attribute

Description	Programmatically assignable Fibre Channel World Wide Node Name identifier for FCoE.
Legal Values	String of up to 23 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.VirtWWPN (Read or Write)

Table 1235. Details of NIC.VndrConfigGroup.VirtWWPN attribute

Description	Programmatically assignable Fibre Channel World Wide Port Name identifier for FCoE.
Legal Values	String of up to 23 characters
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.WWN (Read Only)

Table 1236. Details of NIC.VndrConfigGroup.WWN attribute

Description	Fibre Channel World Wide Node Name identifier for FCoE.
Legal Values	String of up to 23 characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigGroup.WWPN (Read Only)

Table 1237. Details of NIC.VndrConfigGroup.WWPN attribute

Description	Fibre Channel World Wide Port Name identifier for FCoE.
Legal Values	String of up to 23 characters
Default Value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

NIC.VndrConfigPage

The objects in this group manage the vendor configuration page settings.

NIC.VndrConfigPage.BlnkLeds (Read or Write)

Description	Blink LEDs for a duration of up to 15 seconds. Only valid for adapters with link LEDs.
Legal Values	String from 0-15 characters
Default Value	15
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.BusDeviceFunction (Read Only)

Description	The value of this attribute depends on the state of the NParEP Mode setting. If NParEP Mode is Disabled, the value is the BIOS assigned PCIe Bus:Device:Function identifier. If NParEP Mode is Enabled, the value is the BIOS assigned PCIe Bus:Function identifier.
Legal Values	String of up to 8 characters

Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.ChipMdl (Read Only)

Description	This attribute consists of the concatenation of 2 different elements, a vendor-defined silicon marketing name and the silicon revision information as specified in PCI configuration space, separated by space. For example: R720 B0.
Legal Values	None
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.DeviceName (Read Only)

Description	Official product name of the device.
Legal Values	None
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.FCoEBootSupport (Read Only)

Description	Indicates whether Fibre Channel over Ethernet Boot capability is supported.
Legal Values	• Available • Unavailable
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.FIPMacAddr (Read Only)

Description	Permanent FIP-MAC address for FCoE assigned during manufacturing. If supported, the current address value should be readable at all times, irrespective of feature enablement.
Legal Values	None
Default Value	None
Write Privilege	None

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.FlexAddressing (Read Only)

Description	Indicates whether the Dell FlexAddressing feature is supported.
Legal Values	• Available • Unavailable
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.iSCSIBootSupport (Read Only)

Description	Indicates whether iSCSI Boot is supported.
Legal Values	• Available • Unavailable
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.iSCSIDualIPVersionSupport (Read Only)

Description	Indicates support for simultaneous IPv4 and IPv6 configurations of the iSCSI initiator and iSCSI primary and secondary targets.
Legal Values	• Available • Unavailable
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.iScsiOffloadMode (Read or Write)

Description	Enable/Disable the iSCSI offload personality on the port. This setting is for when operating in non-NPar mode only.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

NIC.VndrConfigPage.iSCSIOffloadSupport (Read Only)

Description	Indicates whether the iSCSI Offload capability is supported.
Legal Values	• Available • Unavailable
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.LinkStatus (Read Only)

Description	Physical link status of the network port as reported by the controller.
Legal Values	• Connected • Disconnected
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.MacAddr (Read Only)

Description	The Permanent MAC address assigned during manufacturing.
Legal Values	String of up to 17 characters
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.NicPartitioningSupport (Read Only)

Description	Indicates whether the NIC Partitioning capability is supported.
Legal Values	• Available • Unavailable
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.PCIDeviceID (Read Only)

Description	PCI Device ID reported by the controller when operating in non-NPar mode only. The value of the attribute is undefined for controllers operating in NPar mode that change their device IDs or support multiple PCI Device IDs at the partition level.
Legal Values	String of up to 4 characters
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.PXEBootSupport (Read Only)

Description	Indicates whether the PXE Boot capability is supported.
Legal Values	• Available • Unavailable
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.TOESupport (Read Only)

Description	Indicates whether TCP/IP Offload Engine capability is supported
Legal Values	• Available • Unavailable
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.VirtFIPMacAddr (Read or Write)

Description	Programmatically assignable FIP-MAC address for FCoE. Virtual addresses written will also generate corresponding VWWNN and VWWPN addresses as defined in Y741D. The supported method of reverting to the permanent FIP-MAC address is by writing 0's as the virtual address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. If supported, the current address value should be readable at all times, irrespective of feature enablement.
Legal Values	String of upto 17 characters
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.VirtMacAddr (Read or Write)

Description	Programmatically assignable MAC address. Programmatic write for support of I/O Identity feature. The supported method of reverting to the permanent MAC address is by writing 0's to the virtual MAC. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. If supported, the current address value should be readable at all times, irrespective of feature enablement.
Legal Values	String of upto 17 characters
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.VirtWWN (Read or Write)

Description	Programmatically assignable Fibre Channel World Wide Node Name identifier for FCoE. Virtual addresses written will also be modified by subsequent writes to the VirtFIP-MAC addesss as defined in Y741D. The supported method of clearing this virtual address is by writing 0's as the address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's.
Legal Values	String of upto 23 characters
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.VirtWWPN (Read or Write)

Description	Programmatically assignable Fibre Channel World Wide Port Name identifier for FCoE. Virtual addresses written will also be modified by subsequent writes to the VirtFIP-MAC addesss as defined in Y741D The supported method of clearing this virtual address is by writing 0's as the address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. .
Legal Values	String of upto 23 characters
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.WWN (Read Only)

Description	Fibre Channel World Wide Node Name identifier for FCoE
Legal Values	String of upto 23 characters
Default Value	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

NIC.VndrConfigPage.WWPN (Read Only)

Description	Fibre Channel World Wide Port Name identifier for FCoE
Legal Values	String of upto 23 characters
Default Value	Not Applicable
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

Storage.Controller

The objects in this group manage storage controller attributes. This group is indexed.

The following sections provide information about the objects in this group.

Storage.Controller.BackgroundInitializationRate (Read or Write)

Table 1238. Details of Storage.Controller.BackgroundInitializationRate attribute

Description	The Background Initialization (BGI) rate is the percentage of the system's resources dedicated to perform the background initialization of a virtual disk after it is created.
Legal Values	Values: 0–100
Default value	100
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.Controller.BatteryLearnMode (Read Only)

Table 1239. Details of Storage.Controller.BatteryLearnMode attribute

Description	Battery Learn Mode controls a RAID controller's Battery Learn Cycle.
Legal Values	• Automatic • Warn • Disabled • Not Supported
Default value	None
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	A battery must be present on the controller.

Storage.Controller.CheckConsistencyMode (Read or Write)

Table 1240. Details of Storage.Controller.CheckConsistencyMode attribute

Description	Check Consistency feature is used to verify the accuracy of the redundant (parity) information.
Legal Values	• Normal • Stop On Error
Default value	Normal
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.Controller.CheckConsistencyRate (Read or Write)

Table 1241. Details of Storage.Controller.CheckConsistencyRate attribute

Description	The Check Consistency rate is the percentage of the system's resources dedicated to performing a check consistency on a redundant virtual disk.
Legal Values	Values: 0–100
Default value	100
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.Controller.ControllerBootMode (Read or Write)

Table 1242. Details of Storage.Controller.ControllerBootMode attribute

Description	This property indicates the Controller Boot Mode setting on the controller.
Legal Values	• User Mode • Continue Boot On Error • Headless Mode Continue On Error • Headless Safe Mode
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.Controller.CopybackMode (Read or Write)

Table 1243. Details of Storage.Controller.CopybackMode attribute

Description	This attribute represents the mode of restoring the configuration of a virtual disk when a failed physical disk drive is replaced in an array.
Legal Values	• On

Table 1243. Details of Storage.Controller.CopybackMode attribute (continued)

	• ON with SMART • Off
Default value	On
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.Controller.CurrentControllerMode (Read Only)

Table 1244. Details of Storage.Controller.CurrentControllerMode attribute

Description	Indicates the current personality mode of controllers.
Legal Values	• RAID • HBA
Default value	RAID
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.Controller.EnhancedAutoImportForeignConfig (Read or Write)

Table 1245. Details of Storage.Controller.EnhancedAutoImportForeignConfig attribute

Description	This property indicates the Enhanced Auto Import of Foreign Configuration setting on the controller.
Legal Values	• Disabled • Enabled
Default Value	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.Controller.PatrolReadMode (Read or Write)

Table 1246. Details of Storage.Controller.PatrolReadMode attribute

Description	Patrol Read is a feature for identifying disk errors to avoid disk failures and data loss or corruption. The Patrol Read only runs on the disks that are used in a virtual disk or that are hot-spare.
Legal Values	• Automatic • Manual • Disabled
Default value	Automatic
Write Privilege	Server Control

Table 1246. Details of Storage.Controller.PatrolReadMode attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.Controller.PatrolReadRate (Read or Write)

Table 1247. Details of Storage.Controller.PatrolReadRate attribute

Description	The Patrol Read Rate is the percentage of the system's resources dedicated to perform Patrol Read.
Legal Values	Values: 0–100
Default value	30
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.Controller.PatrolReadUnconfiguredArea (Read or Write)

Table 1248. Details of Storage.Controller.PatrolReadUnconfiguredArea attribute

Description	Enables or disables the patrol read in non-configured areas.
Legal Values	• Disabled • Enabled
Default value	Disabled
Write Privilege	Server Control
License Required	RACADM
Dependency	None

Storage.Controller.Persisthotspare(Read or Write)

Table 1249. Details of Storage.Controller.Persisthotspare attribute

Description	Enables or disables the persistent hot spare.
Legal Values	• Enabled • Disabled
Default Value	Disabled
Write Privilege	Server Control
License Required	RACADM
Dependency	None

Storage.Controller.PossibleloadBalancedMode (Read or Write)

Table 1250. Details of Storage.Controller.PossibleloadBalancedMode attribute

Description	This attribute represents the ability to automatically use both controller ports connected to the same enclosure to route I/O requests.
Legal Values	• Automatic • Disabled
Default value	Automatic
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.Controller.RebuildRate (Read or Write)

Table 1251. Details of Storage.Controller.RebuildRate attribute

Description	The Rebuild Rate is the percentage of the system's resources dedicated to rebuilding a failed disk when a rebuild is necessary.
Legal Values	Values: 0–100
Default value	100
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.Controller.ReconstructRate (Read or Write)

Table 1252. Details of Storage.Controller.ReconstructRate attribute

Description	The Reconstruct Rate is the percentage of the system's resources dedicated to reconstructing a disk group after adding a physical disk drive or changing the RAID level of a virtual disk residing on the disk group.
Legal Values	Values: 0–100
Default value	100
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.Controller.RequestedControllerMode (Read or Write)

Table 1253. Details of Storage.Controller.RequestedControllerMode attribute

Description	Modifies the controller mode to RAID or HBA.
Legal Values	• None • RAID

Table 1253. Details of Storage.Controller.RequestedControllerMode attribute (continued)

	• HBA • Not Supported
Default value	Not Applicable
Write Privilege	Server Control
License Required	RACADM
Dependency	None

Storage.Controller.SupportControllerBootMode (Read Only)

Table 1254. Details of Storage.Controller.SupportControllerBootMode attribute

Description	This is read only attribute. This property indicates if this controller supports setting of controller boot mode.
Legal Values	• Supported • Not Supported
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.Controller.SupportEnhancedAutoForeignImport (Read Only)

Table 1255. Details of Storage.Controller.SupportEnhancedAutoForeignImport attribute

Description	This is a read only attribute. This property indicates if this controller supports enhanced auto import of foreign configurations.
Legal Values	• Supported • Not Supported
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.Controller.SupportRAID10UnevenSpans (Read Only)

Table 1256. Details of Storage.Controller.SupportRAID10UnevenSpans attribute

Description	This is a read-only attribute. This property indicates if this controller supports uneven spans for RAID 10.
Legal Values	• Supported • Not Supported
Default value	
Write Privilege	Configure iDRAC

Table 1256. Details of Storage.Controller.SupportRAID10UnevenSpans attribute (continued)

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.Controller.T10PICapability (Read Only)

Table 1257. Details of Storage.Controller.T10PICapability attribute

Description	This is a read-only attribute. This property indicates if this controller supports T10 PI.
Legal Values	• Incapable • Capable
Default Value	Not Applicable
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.enclosure

The objects in this group manage the storage enclosure attributes. This group is indexed.

Storage.enclosure.BackplaneCurrentMode (Read Only)

Table 1258. Details of Storage.enclosure.BackplaneCurrentMode attribute

Description	Displays the current mode of the backplane.
Legal Values	• UnifiedMode • SplitMode • SplitMode–4:20 • SplitMode–8:16 • SplitMode–16:8 • SplitMode–20:4 • Not Applicable • None
Default Value	UnifiedMode
Write Privilege	Not Applicable
License Required	RACADM
Dependency	Backplane must support.

Storage.enclosure.BackplaneRequestedMode (Read or Write)

Table 1259. Details of Storage.enclosure.BackplaneRequestedMode attribute

Description	Configures the backplane mode.
Legal Values	• UnifiedMode • SplitMode

Table 1259. Details of Storage.enclosure.BackplaneRequestedMode attribute (continued)

	• SplitMode–4:20 • SplitMode–8:16 • SplitMode–16:8 • SplitMode–20:4 • Not Applicable • None
Default Value	UnifiedMode
Write Privilege	Server Control
License Required	RACADM
Dependency	Backplane must support.

Storage.enclosure.BackplaneType (Read Only)

Table 1260. Details of Storage.enclosure.BackplaneType attribute

Description	Indicates whether or not the backplane is shared.
Legal Values	• Shared • Non-Shared
Default Value	Non-Shared
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Backplane must support.

Storage.PhysicalDisk

The objects in this group manage storage physical disk drive attributes. This group is indexed.

The following section provides information about the objects in this group.

Storage.PhysicalDisk.BlockSizeInBytes (Read Only)

Table 1261. Details of Storage.PhysicalDisk.BlockSizeInBytes attribute

Description	This is a read-only attribute. This property indicates the logical block size of the physical drive that this virtual disk belongs to.
Legal Values	Values: 512 or 4096
Default value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.PhysicalDisk.MaxCapableSpeed (Read Only)

Table 1262. Details of Storage.PhysicalDisk.MaxCapableSpeed attribute

Description	This is a read-only attribute. The property represents the data transfer speed that the disk is capable of.
Legal Values	• Unknown • 1.5GBPS • 3GBPS • 6GBPS • 12GBPS
Default value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.PhysicalDisk.RaidNominalMediumRotationRate (Read Only)

Table 1263. Details of Storage.PhysicalDisk.RaidNominalMediumRotationRate attribute

Description	This is a read-only attribute and represents the nominal medium rotation speed of a physical disk drive.
Legal Values	Values: 2–4294967295
Default value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.PhysicalDisk.T10PICapability (Read Only)

Table 1264. Details of Storage.PhysicalDisk.T10PICapability attribute

Description	This is a read-only attribute. This property indicates if this physical disk drive supports T10 PI.
Legal Values	• Incapable • Capable
Default value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.VirtualDisk

The objects in this group manage storage virtual disk attributes. This group is indexed.

The following section provides information about the objects in this group.

Storage.VirtualDisk.BlockSizeInBytes (Read Only)

Table 1265. Details of Storage.VirtualDisk.BlockSizeInBytes attribute

Description	This is a read-only attribute. This property indicates the logical block size of the physical drive that this virtual disk belongs to.
Legal Values	Values: 512 or 4096
Default value	Not Applicable
Write Privilege	Not Applicable
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.VirtualDisk.DiskCachePolicy (Read or Write)

Table 1266. Details of Storage.VirtualDisk.DiskCachePolicy attribute

Description	Set the physical disk drive caching policy of all members of a Virtual Disk by enabling the Disk Cache Policy. When this feature is enabled, the physical disk drive writes data to the physical disk drive cache before writing it to the physical disk drive. Because it is faster to write data to the cache than to a disk, enabling this feature can improve system performance.
Legal Values	• Default • Enabled • Disabled
Default value	Default
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.VirtualDisk.ReadPolicy (Read or Write)

Table 1267. Details of the Storage.VirtualDisk.ReadPolicy attribute

Description	The read policies indicate whether or not the controller must read sequential sectors of the virtual disk when seeking data. **NOTE:** Storage.VirtualDisk.ReadPolicy attribute is read-only for few PERCs—for example, H330.
Legal Values	• No Read Ahead • Read Ahead **NOTE:** Previous generations of PERC controllers support read policy settings of No Read Ahead, Read Ahead, and Adaptive Read Ahead. With PERC 8 and PERC 9, the Read Ahead and Adaptive Read Ahead settings are functionally equivalent at the controller level. For backward compatibility purposes, some systems management interfaces and PERC 8 and 9 controllers still allow setting the read policy to Adaptive Read Ahead. While it is possible to set Read Ahead or Adaptive Read Ahead on PERC 8 or PERC 9, there is no functional difference.
Default value	Adaptive
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Table 1267. Details of the Storage.VirtualDisk.ReadPolicy attribute (continued)

Dependency	None

Storage.VirtualDisk.T10PIStatus (Read or Write)

Table 1268. Details of the Storage.VirtualDisk.T10PIStatus attribute

Description	This property indicates if T10 PI is enabled or disabled on this virtual disk. **NOTE:** Can be disabled only if the current value for this object is enabled.
Legal Values	• 0 — Disabled • 1 — Enabled
Default value	0 — Disabled
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

Storage.VirtualDisk.WritePolicy (Read or Write)

Table 1269. Details of the Storage.VirtualDisk.WritePolicy attribute

Description	The write policies specify whether or not the controller sends a write-request completion signal as soon as the data is in the cache or after it has been written to disk. **NOTE:** Storage.VirtualDisk.WritePolicy attribute is read-only for few PERCs—for example, H330.
Legal Values	• Write Through • Write Back • Force Write Back
Default value	WriteBack
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

A

Deprecated and New Subcommands

Table 1270. Details of deprecated and new subcommands

Deprecated Subcommands	New Subcommands
getconfig	get
config	set
getuscversion	getversion
raid	storage

NOTE: The following attributes are obsoleted and these attributes do not support the **ipBlocking** feature:

- ipBlockingEnabled
- ipBlockingFailCount
- ipBlockingFailWindow
- ipBlockingPenaltyTime

B

Legacy and New Groups and Objects

Table 1271. Details of legacy groups and objects

Legacy Groups and Objects	New Groups and Objects
idRacInfo	**iDRAC.Info**
idRacType	Type
idRacProductInfo	Product
idRacDescriptionInfo	Description
idRacVersionInfo	Version
idRacBuildInfo	Build
idRacName	Name
cfgActiveDirectory	**iDRAC.ActiveDirectory**
cfgADEnable	Enable
cfgADRacDomain	RacDomain
cfgADRacName	RacName
cfgADAuthTimeout	AuthTimeout
cfgADType	Schema
cfgADDomainController1	DomainController1
cfgADDomainController2	DomainController2
cfgADDomainController3	DomainController3
cfgADGlobalCatalog1	GlobalCatalog1
cfgADGlobalCatalog2	GlobalCatalog2
cfgADGlobalCatalog3	GlobalCatalog3
cfgADCertValidationEnable	CertValidationEnable
cfgADSSOEnable	SSOEnable
cfgADDcSRVLookupEnable	DCLookupEnable
cfgADDcSRVLookupbyUserdomain	DCLookupByUserDomain
cfgADDcSRVLookupDomainName	DCLookupDomainName
cfgADGcSRVLookupEnable	GCLookupEnable

Table 1271. Details of legacy groups and objects (continued)

Legacy Groups and Objects	New Groups and Objects
cfgADGcRootDomain	GCRootDomain
cfgLanNetworking	**iDRAC.Nic**
cfgNicEnable	Enable
cfgNicMacAddress	MACAddress
cfgDNSRacName	DNSRacName
cfgNicSelection	Selection
cfgNicFailoverNetwork	Failover
cfgDNSDomainName	DNSDomainName
cfgDNSDomainNameFromDHCP	DNSRacName
cfgDNSRegisterRac	DNSRegister
cfgNicVLanEnable	VLanEnable
cfgNicVLanID	VLanID
cfgNicVLanPriority	VLanPriority
	iDRAC.IPv4
cfgNicIPv4Enable	Enable
cfgNicIpAddress	Address
cfgNicNetmask	NetMask
cfgNicGateway	Gateway
cfgNicUseDhcp	DHCPEnable
cfgDNSServersFromDHCP	DNSFromDHCP
cfgDNSServer1	DNS1
cfgDNSServer2	DNS2
cfgIpv6LanNetworking	**iDRAC.IPv6**
cfgIPv6Enable	Enable
cfgIPv6Address1	Address1
cfgIPv6Gateway	Gateway
cfgIPv6PrefixLength	PrefixLength
cfgIPv6AutoConfig	AutoConfig
cfgIPv6LinkLocalAddress	LinkLocalAddress

Table 1271. Details of legacy groups and objects (continued)

Legacy Groups and Objects	New Groups and Objects
cfgIPv6Address2	Address2
cfgIPv6Address3	Address3
cfgIPv6Address4	Address4
cfgIPv6Address5	Address5
cfgIPv6Address6	Address6
cfgIPv6Address7	Address7
cfgIPv6Address8	Address8
cfgIPv6Address9	Address9
cfgIPv6Address10	Address10
cfgIPv6Address11	Address11
cfgIPv6Address12	Address12
cfgIPv6Address13	Address13
cfgIPv6Address14	Address14
cfgIPv6Address15	Address15
cfgIPv6DNSServersFromDHCP6	DNSFromDHCP6
cfgIPv6DNSServer1	DNS1
cfgIPv6DNSServer2	DNS2
cfgServerPower	**System.Power**
cfgServerPowerStatus	Status
cfgServerActualPowerConsumption	Realtime.Power
cfgServerMinPowerCapacity	Cap.MinThreshold
cfgServerMaxPowerCapacity	Cap.MaxThreshold
cfgServerPeakPowerConsumption	Max.Power
cfgServerPeakPowerConsumptionTimestamp	Max.Power.Timestamp
cfgServerPowerConsumptionClear	Max.PowerClear
cfgServerPowerCapWatts	Cap.Watts
cfgServerPowerCapBtuhr	Cap.BtuHr
cfgServerPowerCapPercent	Cap.Percent
cfgServerPowerCapEnable	Cap.Enable

Table 1271. Details of legacy groups and objects (continued)

Legacy Groups and Objects	New Groups and Objects
cfgServerPowerLastHourAvg	Avg.LastHour
cfgServerPowerLastDayAvg	Avg.LastDay
cfgServerPowerLastWeekAvg	Avg.LastWeek
cfgServerPowerLastHourMinPower	Min.LastHour
cfgServerPowerLastHourMinTime	Min.LastHour.Timestamp
cfgServerPowerLastHourMaxPower	Max.LastHour
cfgServerPowerLastHourMaxTime	Max.LastHour.Timestamp
cfgServerPowerLastDayMinPower	Min.LastDay
cfgServerPowerLastDayMinTime	Min.LastDay.Timestamp
cfgServerPowerLastDayMaxPower	Max.LastDay
cfgServerPowerLastDayMaxTime	Max.LastDay.Timestamp
cfgServerPowerLastWeekMinPower	Min.LastWeek
cfgServerPowerLastWeekMinTime	Min.LastWeek.Timestamp
cfgServerPowerLastWeekMaxPower	Max.LastWeek
cfgServerPowerLastWeekMaxTime	Max.LastWeek.Timestamp
cfgServerPowerInstHeadroom	Realtime.Headroom
cfgServerPowerPeakHeadroom	Max.Headroom
cfgServerActualAmperageConsumption	Realtime.Amps
cfgServerPeakAmperage	Max.Amps
cfgServerPeakAmperageTimeStamp	Max.Amps.Timestamp
cfgServerCumulativePowerConsumption	EnergyConsumption
cfgServerCumulativePowerConsumptionTimeStamp	EnergyConsumption.StarttimeStamp
cfgServerCumulativePowerClear	EnergyConsumption.Clear
cfgServerPowerPicEAllocation	PCIePowerAllocation
cfgServerPowerSupply	**System.Power.Supply**
cfgServerPowerSupplyIndex	Index
cfgServerPowerSupplyInputStatus	LineStatus
cfgServerPowerSupplyMaxInputPower	MaxInputPower
cfgServerPowerSupplyMaxOutputPower	MaxOutputPower

Table 1271. Details of legacy groups and objects (continued)

Legacy Groups and Objects	New Groups and Objects
cfgServerPowerSupplyOnlineStatus	Status
cfgServerPowerSupplyFwVer	FwVer
cfgServerPowerSupplyCurrentDraw	CurrentDraw
cfgServerPowerSupplyType	Type
cfgServerPowerBusMonitoring	PMBusMonitoring
cfgUserAdmin	**iDRAC.Users**
cfgUserAdminIndex	NA
cfgUserAdminUserName	UserName
cfgUserAdminPassword	Password
cfgUserAdminEnable	Enable
cfgUserAdminPrivilege	Privilege
cfgUserAdminIpmiLanPrivilege	IpmiLanPrivilege
cfgUserAdminIpmiSerialPrivilege	IpmiSerialPrivilege
cfgUserAdminSolEnable	SolEnable
cfgRemoteHosts	**iDRAC.SysLog**
cfgRhostsSyslogEnable	SysLogEnable
cfgRhostsSyslogServer1	Server1
cfgRhostsSyslogServer2	Server2
cfgRhostsSyslogServer3	Server3
cfgRhostsSyslogPort	Port
	iDRAC.Update
cfgRhostsFwUpdateTftpEnable	FwUpdateTFTPEnable
cfgRhostsFwUpdateIpAddr	FwUpdateIPAddr
cfgRhostsFwUpdatePath	FwUpdatePath
	[iDRAC.RemoteHosts]
cfgRhostsSmtpServerIpAddr	SMTPServerIPAddress
cfgEmailAlert	**iDRAC.EmailAlert**
cfgEmailAlertIndex	NA
cfgEmailAlertEnable	Enable

Table 1271. Details of legacy groups and objects (continued)

Legacy Groups and Objects	New Groups and Objects
cfgEmailAlertAddress	Address
cfgEmailAlertCustomMsg	CustomMsg
cfgSessionManagement	
cfgSsnMgtTelnetIdleTimeout	**iDRAC.Telnet**
	Enable
	Port
	Timeout
cfgSsnMgtSshIdleTimeout	**iDRAC.SSH**
	Enable
	Port
	Timeout
cfgSsnMgtRacadmTimeout	**iDRAC.Racadm**
	Enable
	Timeout
cfgSsnMgtConsRedirMaxSessions	**iDRAC.VirtualConsole**
	EncryptEnable
	Enable
	PluginType
	LocalVideo
	Port
	MaxSessions
	Timeout
	AccessPrivilege
cfgSsnMgtWebserverTimeout	**iDRAC.Webserver**
	Enable
	HttpPort
	Timeout
	HttpsPort
	LowerEncryptionBitLength

Table 1271. Details of legacy groups and objects (continued)

Legacy Groups and Objects	New Groups and Objects
[cfgSerial]	**iDRAC.Serial**
cfgSerialBaudRate	BaudRate
cfgSerialConsoleEnable	Enable
cfgSerialConsoleIdleTimeout	IdleTimeout
cfgSerialConsoleNoAuth	NoAuth
cfgSerialConsoleCommand	Command
cfgSerialHistorySize	HistorySize
	iDRAC.SerialRedirection
cfgSerialConsoleQuitKey	QuitKey
cfgSerialCom2RedirEnable	Enable
cfgSerialTelnetEnable	**iDRAC.Telnet**
cfgSerialSshEnable	**iDRAC.SSH**
[cfgOobSnmp]	**iDRAC.SNMP**
cfgOobSnmpAgentEnable	AgentEnable
cfgOobSnmpAgentCommunity	AgentCommunity
[cfgNetTuning]	
cfgNetTuningNic100MB	**iDRAC.Nic**
cfgNetTuningNicFullDuplex	**iDRAC.Nic**
cfgNetTuningNicMtu	**iDRAC.Nic**
cfgNetTuningNicAutoneg	**iDRAC.Nic**
[cfgRacTuning]	
cfgRacTuneRemoteRacadmEnable=1	**iDRAC.Racadm**
cfgRacTuneWebserverEnable=1	**iDRAC.Webserver**
cfgRacTuneHttpPort=80	**iDRAC.Webserver**
cfgRacTuneHttpsPort=443	**iDRAC.Webserver**
cfgRacTuneTelnetPort=23	**iDRAC.Telnet**
cfgRacTuneSshPort=22	**iDRAC.SSH**
cfgRacTuneConRedirEnable=1	**iDRAC.VirtualConsole**

Table 1271. Details of legacy groups and objects (continued)

Legacy Groups and Objects	New Groups and Objects
cfgRacTuneConRedirPort=5900	**iDRAC.VirtualConsole**
cfgRacTuneConRedirEncryptEnable=1	**iDRAC.VirtualConsole**
cfgRacTuneLocalServerVideo=1	**iDRAC.VirtualConsole**
	iDRAC.IPBlocking
cfgRacTuneIpRangeEnable=0	RangeEnable
cfgRacTuneIpRangeAddr=192.168.1.1	RangeAddr
cfgRacTuneIpRangeMask=255.255.255.0	RangeMask
	iDRAC.Time
cfgRacTuneTimezoneOffset=0	TimeZoneOffset
cfgRacTuneDaylightOffset=0	DaylightOffset
cfgRacTuneAsrEnable=1	TBD
cfgRacTunePlugintype=0	**iDRAC.VirtualConsole**
	iDRAC.LocalSecurity
cfgRacTuneCtrlEConfigDisable=0	PrebootConfig
cfgRacTuneLocalConfigDisable=0	LocalConfig
cfgRacTuneVirtualConsoleAuthorizeMultipleSessions=0	**iDRAC.VirtualConsole**
ifcRacManagedNodeOs	**System.ServerOS**
ifcRacMnOsHostname	HostName
ifcRacMnOsOsName	OSName
cfgRacSecurity	**iDRAC.Security**
cfgRacSecCsrKeySize	CsrKeySize
cfgRacSecCsrCommonName	CsrCommonName
cfgRacSecCsrOrganizationName	CsrOrganizationName
cfgRacSecCsrOrganizationUnit	CsrOrganizationUnit
cfgRacSecCsrLocalityName	CsrLocalityName
cfgRacSecCsrStateName	CsrStateName
cfgRacSecCsrCountryCode	CsrCountryCode
cfgRacSecCsrEmailAddr	CsrEmailAddr
cfgRacVirtual	**iDRAC.VirtualMedia**

Table 1271. Details of legacy groups and objects (continued)

Legacy Groups and Objects	New Groups and Objects
cfgVirMediaAttached	Attached
cfgVirtualBootOnce	BootOnce
cfgVirMediaFloppyEmulation	FloppyEmulation
cfgLDAP	**iDRAC.LDAP**
cfgLdapEnable	Enable
cfgLdapServer	Server
cfgLdapPort	Port
cfgLdapBaseDN	BaseDN
cfgLdapUserAttribute	UserAttribute
cfgLdapGroupAttribute	GroupAttribute
cfgLdapGroupAttributeIsDN	GroupAttributeIsDN
cfgLdapBindDN	BindDN
# cfgLdapBindPassword	BindPassword
cfgLdapSearchFilter	SearchFilter
cfgLdapCertValidationEnable	CertValidationEnable
cfgLdapRoleGroup	**iDRAC.LDApRole**
cfgLdapRoleGroupIndex	NA
cfgLdapRoleGroupDN	DN
cfgLdapRoleGroupPrivilege	Privilege
cfgStandardSchema	**iDRAC.ADGroup**
cfgSSADRoleGroupIndex	NA
cfgSSADRoleGroupName	Name
cfgSSADRoleGroupDomain	Domain
cfgSSADRoleGroupPrivilege	Privilege
cfgIpmiSerial	**iDRAC.IPMISerial**
cfgIpmiSerialConnectionMode	ConnectionMode
cfgIpmiSerialBaudRate	BaudRate
cfgIpmiSerialFlowControl	FlowControl
cfgIpmiSerialChanPrivLimit	ChanPrivLimit

Table 1271. Details of legacy groups and objects (continued)

Legacy Groups and Objects	New Groups and Objects
cfgIpmiSerialLineEdit	LineEdit
cfgIpmiSerialDeleteControl	DeleteControl
cfgIpmiSerialEchoControl	EchoControl
cfgIpmiSerialHandshakeControl	HandshakeControl
cfgIpmiSerialNewLineSequence	NewLineSeq
cfgIpmiSerialInputNewLineSequence	InputNewLineSeq
cfgIpmiSol	**iDRAC.IPMISol**
cfgIpmiSolEnable	Enable
cfgIpmiSolBaudRate	BaudRate
cfgIpmiSolMinPrivilege	MinPrivilege
cfgIpmiSolAccumulateInterval	AccumulateInterval
cfgIpmiSolSendThreshold	SendThreshold
cfgIpmiLan	**iDRAC.IPMILan**
cfgIpmiLanEnable	Enable
cfgIpmiLanPrivilegeLimit	PrivLimit
cfgIpmiLanAlertEnable	AlertEnable
cfgIpmiEncryptionKey	EncryptionKey
cfgIpmiPetCommunityName	CommunityName
cfgUserDomain	**iDRAC.UserDomain**
cfgUserDomainIndex	NA
cfgUserDomainName	Name
cfgSmartCard	**iDRAC.SmartCard**
cfgSmartCardLogonEnable	SmartCardLogonEnable
cfgSmartCardCRLEnable	SmartCardCRLEnable
[cfgIPv6URL]	
cfgIPv6URLString	NA
cfgVFlashSD	**iDRAC.vFlashSD**
cfgVFlashSDSize	Size

Table 1271. Details of legacy groups and objects (continued)

Legacy Groups and Objects	New Groups and Objects
cfgVFlashSDLicensed	Licensed
cfgVFlashSDAvailableSize	AvailableSize
cfgVFlashSDHealth	Health
cfgVFlashSDEnable	Enable
cfgVFlashSDWriteProtect	WriteProtect
cfgVFlashSDInitialized	Initialized
cfgVFlashPartition	**iDRAC.vFlashPartition**
cfgVFlashPartitionIndex	NA
cfgVFlashPartitionSize	Size
cfgVFlashPartitionEmulationType	EmulationType
cfgVFlashPartitionFlashOSVolLabel	VolumeLabel
cfgVFlashPartitionFormatType	FormatType
cfgVFlashPartitionAccessType	AccessType
cfgVFlashPartitionAttachState	AttachState
cfgServerInfo	**iDRAC.ServerBoot**
cfgServerBootOnce	BootOnce
cfgServerFirstBootDevice	FirstBootDevice
cfgLogging	**iDRAC.Logging**
cfgLoggingSELOEMEventFilterEnable	SELOEMEventFilterEnable
	iDRAC.SNMP.Alert
cfgIpmiPetAlertEnable	Enable
cfgIpmiPetAlertDestIpAddr	DestAddr

Topics:

- cfgSSADRoleGroupPrivilege (Read or Write)

cfgSSADRoleGroupPrivilege (Read or Write)

Table 1272. Details of cfgSSADRoleGroupPrivilege

Description	Use the bit mask numbers listed in the table below to set role-based authority privileges for a Role Group.
Legal Values	• For iDRAC: 0x00000000 to 0x000001ff • For CMC: 0x00000000 – 0x00000fff

Table 1272. Details of cfgSSADRoleGroupPrivilege (continued)

Default	<blank>

Table 1273. Example

Role Group Privilege	Bit Mask
Login to iDRAC	0x00000001
Configure iDRAC	0x00000002
Configure Users	0x00000004
Clear Logs	0x00000008
Execute Server Control Commands	0x00000010
Access Virtual Console	0x00000020
Access Virtual Media	0x00000040
Test Alerts	0x00000080
Execute Debug Commands	0x00000100