

Dell OptiPlex Micro Cable Cover

User Guide



Notes, cautions, and warnings

 | **NOTE:** A NOTE indicates important information that helps you make better use of your product.

 | **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 | **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

© 2018 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

Contents

1 Dell OptiPlex Micro Cable Cover.....	4
2 Getting help.....	8
Contacting Dell.....	8

Dell OptiPlex Micro Cable Cover

The cable cover for the Dell OptiPlex Micro system helps protect the ports and cables connected to the system. Follow these steps to install the cable cover.

NOTE: Images shown below may vary depending on your system configuration.

- 1 Route the cables through the slot at the bottom of the cable cover.



- 2 Connect the cables to their respective ports and turn the antenna (if available/applicable) outwards to pass through the antenna slot at the top of the cable cover.



3 Align the cable cover retaining hooks into their slots on the Dell OptiPlex Micro chassis.

⚠ CAUTION: Take care not to bend or break the delicate plastic hooks.



- 4 Gently press down on the cable cover (1) till it clicks into place and slide the latch (2) to lock the cable cover in place.



 **NOTE:** For added security, use the Noble Wedge slot to secure the system.

Getting help

Contacting Dell

NOTE: If you do not have an active Internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.

Dell provides several online and telephone-based support and service options. Availability varies by country and product, and some services may not be available in your area. To contact Dell for sales, technical support, or customer service issues:

- 1 Go to **Dell.com/support**.
- 2 Select your support category.
- 3 Verify your country or region in the **Choose a Country/Region** drop-down list at the bottom of the page.
- 4 Select the appropriate service or support link based on your need.