



Statement of Volatility – Dell OptiPlex XE2

△ CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

The Dell OptiPlex XE2 contains both volatile and non-volatile (NV) components. Volatile components lose their data immediately after power is removed from the component. Non-volatile (NV) components continue to retain their data even after power is removed from the component. The following NV components are present on the XE2's system board.

Table 1. List of Non-Volatile Components on System Board

Description	Reference Designator	Volatility Description	User Accessible for external data	Remedial Action (action necessary to prevent loss of data)
Embedded Flash memory in embedded controller SMSC SCH5555-NS	UO1	2K bytes of on-chip ROM and 256 bytes of on-chip RAM	No	N/A
System BIOS	SPI1/SPI3	Non-volatile memory, 32 Mbits/64 Mbits (4 MB/8 MB), System BIOS and Video BIOS for basic boot operation, (on board diagnostics.)	No	N/A
TPM ST ST33ZP24AR28PVSP	TPM	4K bytes non-volatile memory located in the TPM module.	No	N/A
System Memory – DDR3 DIMM memory	Connectors: DIMM1, DIMM2, DIMM3, DIMM4	Volatile memory in OFF state Note: See state definitions later in text. One to four modules will be populated. System memory size will depend on DIMM modules and will be between 4 GB to 64 GB.	Yes	Power off system.
System memory SPD EEPROM	On memory DIMM(s)	Non-volatile EEPROM memory. (256 bytes). One device present on each DIMM. Stores memory manufacturer data and timing information for correct operation of system memory.	No	N/A
RTC CMOS	BATTERY	Volatile battery back-backed CMOS memory 256 bytes. Stores CMOS information.	No	Removing the onboard Coin Cell battery.
Video memory – type – see the next column	UMA architecture-uses system memory.	Volatile memory in off state. UMA uses main system memory size allocated out of main memory.	No	Enter S3-S5 state.

Description	Reference Designator	Volatility Description	User Accessible for external data	Remedial Action (action necessary to prevent loss of data)
Hard drive	User replaceable	Non-volatile magnetic media, various sizes in GB.	Yes	Low level format.
CD-ROM/RW/ DVD/ DVD+RW/ Diskette Drives	User replaceable	Non-volatile optical/magnetic media.	Yes	Low level format/erase.

⚠ CAUTION: All other components on the system board lose data if power is removed from the system. Primary power loss (unplugging the power cord and removing the battery) destroys all user data on the memory (DDR4, 2400/2666 MHz). Secondary power loss (removing the on-board coin-cell battery) destroys system data on the system configuration and time-of-day information.

In addition, to clarify memory volatility and data retention in situations where the system is put in different ACPI power states the following is provided (those ACPI power states are S0, S1, S3, S4 and S5):

S0 state is the working state where the dynamic RAM is maintained and is read/write by the processor.

S1 state is a low wake-up latency sleeping state. In this state, no system context is lost (CPU or chip set) and hardware maintains all system contexts.

S3 is called “suspend to RAM” state or stand-by mode. In this state the dynamic RAM is maintained. Dell systems will be able to go to S3 if the OS and the peripherals used in the system supports S3 state. Win10 support S3 state.

S4 is called “suspend to disk” state or “hibernate” mode. There is no power. In this state, the dynamic RAM is not maintained. If the system has been commanded to enter S4, the OS will write the system context to a non-volatile storage file and leave appropriate context markers. When the system is coming back to the working state, a restore file from the nonvolatile storage can occur. The restore file must be valid. Dell systems will be able to go to S4 if the OS and the peripherals support S4 state. Win10 support S4 state.

S5 is the “soft” off state. There is no power. The OS does not save any context to wake up the system. No data will remain in any component on the system board, i.e. cache or memory. The system will require a complete boot when awakened. Since S5 is the shut off state, coming out of S5 requires power on which clears all registers.

The following table shows all the states supported by Dell Optiplex XE2

Model Number	S0	S1	S3	S4	S5
Dell Optiplex XE2	X		X	X	X

© 2019 Dell Inc.

Trademarks used in this text: Dell™, the DELL logo, Latitude™ are trademarks of Dell Inc. Intel®, Pentium®, Xeon®, Core™ and Celeron® are registered trademarks of Intel Corporation in the U.S. and other countries. Microsoft®, Windows® are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.