

Dell OptiPlex
FX130 & FX170

VESA Mount Manual



Notes, Cautions, and Warnings



NOTE: A NOTE indicates important information that helps you make better use of your thin client.



CAUTION: A CAUTION indicates potential damage to hardware or loss of data if instructions are not followed.



WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

Information in this document is subject to change without notice.

© 2011 Dell Inc. All rights reserved.

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.


Trademarks used in this text: Dell™, the DELL logo, and OptiPlex™.


Other trademarks and trade names may be used in this publication to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

March 2011

Rev. A00

Dell OptiPlex FX130 & FX170 VESA Mount Manual

 **WARNING:** Before beginning, turn off the thin client, disconnect the AC adapter from the electrical outlet and the thin client, and remove any other external cables from the thin client.

 **WARNING:** Before installing your thin client in an enclosure, read the safety instructions that shipped with your thin client.

VESA Mounting Materials




1 VESA Mounting Plate

2 VESA Mounting Bracket

3 Screws

VESA Bracket

- 1 Remove the middle button on of the side plate on your thin client that has three mounting holes.

 **NOTE:** Only one side plate has three mounting holes.




- 2 Place the VESA mounting plate on the thin client's side plate chassis and insert the screws to secure the mounting plate to the thin client.







- 3 Insert the screws to secure the VESA bracket.



 **NOTE:** The VESA mount above is secured to the back of a monitor. Make sure the mounting bracket is secured as shown above.

- 4 Slide the VESA mounting plate attached to your thin client onto the VESA mounting bracket.

Mounting the VESA Bracket to a Wall

-  **WARNING:** Before beginning, turn off the thin client, disconnect the AC adapter from the electrical outlet and the thin client, and remove any other external cables from the thin client.
 -  **WARNING:** Before installing your thin client in an enclosure, read the safety instructions that shipped with your thin client.
 -  **CAUTION:** Use a wall that supports at least 20 lbs. (9.1kg) of weight. Use appropriate mounting hardware depending on wall material (hardware not included).
- 1 Insert the screws to secure the VESA mounting bracket to the wall.
 - 2 Slide the VESA mounting plate attached to your thin client onto the VESA mounting bracket.
-  **WARNING:** Before mounting the chassis to the wall bracket ensure that none of the vents are blocked on the system.

Getting Help

Contacting Dell

For customers in the United States, call 800-WWW-DELL (800-999-3355).



NOTE: If you do not have an active Internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.

Dell provides several online and telephone-based support and service options. Availability varies by country and product, and some services may not be available in your area. To contact Dell for sales, technical support, or customer service issues:

- 1 Visit **support.dell.com** and verify your country or region in the “Choose a Country/Region” drop down menu at the bottom of the page.
- 2 Click “Contact Us” on the left side of the page. Then select the appropriate service or support link based on your needs.
- 3 Choose the method of contacting Dell that is convenient for you.



Printed in the U.S.A.

www.dell.com | support.dell.com