












Dell S2419H/S2419HN/S2419NX/S2719H/S2719HN/S2719NX



i



Dell.com/S2419H
Dell.com/S2419HN
Dell.com/S2419NX
Dell.com/S2719H
Dell.com/S2719HN
Dell.com/S2719NX