



Using Westtek® ClearVue™ with your Dell™ Axim™ X50v

This document helps you use the Westtek ClearVue Suite on your Axim X50v. Before installing the ClearVue Suite, you must establish an ActiveSync connection with your host PC. Use the host USB cable and the ActiveSync software that came with your Axim to complete this step.

For more information on installing and using ActiveSync, see the *Dell Axim X50 Owner's Manual*.

Installing Westtek ClearVue

Once you have established an ActiveSync *Guest* or *Partnership* connection with your Axim:

- 1 Insert the *Presentation Pack for Dell Axim X50v* CD into the CD or DVD drive on your host PC.
- 2 The ClearVue Suite installation wizard should launch automatically. If not, explore the CD using the Windows Explorer and double-click `WTCV241Setup_Ste.exe`.

October 2004



0C8908A01

- 3 Follow the on-screen instructions to install the software.
- 4 When prompted for a product serial number, enter the serial number on the CD sleeve.

When installation is complete, the ClearVue software icon will be displayed in the **Programs** folder on your Axim.

Installing the VGA Cable

Before using external video, make sure that the VGA cable is attached to your Axim. Options for using the *Presentation Pack* are available under the **External Video** menu option within ClearVue.

For more information on external video options, access the ClearVue online help by selecting **Start**→**Help** from the ClearVue application.

Enabling Mirror Mode with Windows Media Player

To play video with Windows Media Player 10 on both the PDA screen and an external monitor, enable Mirror Mode before playing the movie.

To enable Mirror Mode, check the option in **Start** →**Settings** →**System** →**Mirror Mode**.

If you have started the movie before enabling Mirror Mode, stop the movie by clicking **Menu** →**Stop** and then restart the movie.

Information in this document is subject to change without notice.

© 2004 Dell Inc. All rights reserved. Printed in Taiwan.

Reproduction in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: *Dell* the *DELL* logo, and Axim are trademarks of Dell Inc. Westtek is a registered trademark and ClearVue is a trademark of Westtek, LLC in the United States. Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

