

4220 SNMP Table

| Test Case | name | function | oid | value Type | Read /Write | Criteria |
|-----------|--------------------|-----------------------------------|----------------------------------|----------------|----------------|---|
| MP-001 | RFC1213-system | sysDescr | .1.3.6.1.2.1.1.1.0 | STRING | R | Dell 4220 |
| MP-002 | | sysObjectID | .1.3.6.1.2.1.1.2.0 | OID | R | .1.3.6.1.4.1.674.10901.200.10 |
| MP-003 | | sysUpTime | .1.3.6.1.2.1.1.3.0 | Timeticks | R | * hours * minutes * seconds |
| MP-004 | | sysContact | .1.3.6.1.2.1.1.4.0 | STRING | R/W | web management |
| MP-005 | | sysName | .1.3.6.1.2.1.1.5.0 | STRING | R/W | web management(Group Name + Projector Name) |
| MP-006 | | sysLocation | .1.3.6.1.2.1.1.6.0 | STRING | R/W | web management |
| MP-007 | | sysServices | .1.3.6.1.2.1.1.7.0 | INTEGER | R | DEFVAL { 72 } |
| MP-008 | RFC1213-interfaces | ifNumber | .1.3.6.1.2.1.2.1.0 | INTEGER | R | DEFVAL { 1 } |
| MP-009 | pdmGeneral | pdmGeneralProductName | 1.3.6.1.4.1.2699.2.4.1.2.1.0 | STRING | R | Dell 4220 |
| MP-010 | | pdmGeneralSerialNumber | 1.3.6.1.4.1.2699.2.4.1.2.2.0 | STRING | R | OSD上PPID最後七碼 |
| MP-011 | | pdmGeneralAssetTag | 1.3.6.1.4.1.2699.2.4.1.2.3.0 | STRING | R/W | (16byte) |
| MP-012 | | pdmGeneralHardwareVersion | 1.3.6.1.4.1.2699.2.4.1.2.4.0 | STRING | R | DEFVAL { " " } |
| MP-013 | | pdmGeneralServicePerson | 1.3.6.1.4.1.2699.2.4.1.2.5.0 | STRING | R/W | (22byte) |
| MP-014 | | pdmGeneralDeviceAge | 1.3.6.1.4.1.2699.2.4.1.2.6.0 | INTEGER | R | (display hour) |
| MP-015 | | pdmGeneralPowerOnCount | 1.3.6.1.4.1.2699.2.4.1.2.7.0 | INTEGER | R | Projector ON count |
| MP-016 | | pdmGeneralManufactureDate | 1.3.6.1.4.1.2699.2.4.1.2.8.0 | STRING | R | ManufactureDate |
| MP-017 | | pdmGeneralLanguageTagSNMP | 1.3.6.1.4.1.2699.2.4.1.2.9.0 | STRING | R | en-US |
| MP-018 | | pdmGeneralNtpServerAddress | 1.3.6.1.4.1.2699.2.4.1.2.10.0 | STRING | R | DEFVAL { "" } |
| MP-019 | PdmCtrl | pdmCtrlIndex | 1.3.6.1.4.1.2699.2.4.1.3.1.1.1.1 | INTEGER | not-accessible | 1 |
| MP-020 | | pdmCtrlDescription | 1.3.6.1.4.1.2699.2.4.1.3.1.1.2.1 | STRING | R | Reon VX-210 |
| MP-021 | | pdmCtrlHardwareVersion | 1.3.6.1.4.1.2699.2.4.1.3.1.1.3.1 | STRING | R | DEFVAL { "" } |
| MP-022 | | | 1.3.6.1.4.1.2699.2.4.1.3.1.1.4.1 | STRING | R | system version; network version |
| MP-023 | | pdmCtrlFirmwareVersion | | | | |
| MP-023 | | pdmCtrlFirmwareUpgradeable | 1.3.6.1.4.1.2699.2.4.1.3.1.1.5.1 | INTEGER | R | DEFVAL { 10 } |
| MP-024 | | pdmCtrlUpgrdeInstructions | 1.3.6.1.4.1.2699.2.4.1.3.1.1.6.1 | STRING | R | DEFVAL { " " } |
| MP-025 | | pdmCtrlPostStatus | 1.3.6.1.4.1.2699.2.4.1.3.1.1.7.1 | INTEGER | R | DEFVAL { 2 } |
| MP-026 | | pdmCtrlPostCode | 1.3.6.1.4.1.2699.2.4.1.3.1.1.8.1 | STRING | R | DEFVAL { " " } |
| MP-027 | | pdmCtrlPostStatusDefinitions | 1.3.6.1.4.1.2699.2.4.1.3.1.1.9.1 | STRING | R | DEFVAL { " " } |
| MP-028 | pdmPowerIndex | .1.3.6.1.4.1.2699.2.4.1.4.1.1.1.1 | INTEGER | not-accessible | 1 | |
| MP-029 | pdmPowerIndex | .1.3.6.1.4.1.2699.2.4.1.4.1.1.1.2 | INTEGER | not-accessible | 2 | |

| | | | | | | | |
|--------|----------|--------------------------|-----------------------------------|----------------------------------|----------------|--|---------------------|
| MP-030 | PdmPower | pdmPowerIndex | .1.3.6.1.4.1.2699.2.4.1.4.1.1.1.3 | INTEGER | not-accessible | 3 | |
| MP-031 | | pdmPowerIndex | .1.3.6.1.4.1.2699.2.4.1.4.1.1.1.4 | INTEGER | not-accessible | 4 | |
| MP-032 | | pdmPowerIndex | .1.3.6.1.4.1.2699.2.4.1.4.1.1.1.5 | INTEGER | not-accessible | 5 | |
| MP-033 | | pdmPowerIndex | .1.3.6.1.4.1.2699.2.4.1.4.1.1.1.6 | INTEGER | not-accessible | 6 | |
| MP-034 | | pdmPowerImplementedState | .1.3.6.1.4.1.2699.2.4.1.4.1.1.2.1 | INTEGER | R | 11 | |
| MP-035 | | pdmPowerImplementedState | .1.3.6.1.4.1.2699.2.4.1.4.1.1.2.2 | INTEGER | R | 7 | |
| MP-036 | | pdmPowerImplementedState | .1.3.6.1.4.1.2699.2.4.1.4.1.1.2.3 | INTEGER | R | 9 | |
| MP-037 | | pdmPowerImplementedState | .1.3.6.1.4.1.2699.2.4.1.4.1.1.2.4 | INTEGER | R | 8 | |
| MP-038 | | pdmPowerImplementedState | .1.3.6.1.4.1.2699.2.4.1.4.1.1.2.5 | INTEGER | R | 8 | |
| MP-039 | | pdmPowerImplementedState | .1.3.6.1.4.1.2699.2.4.1.4.1.1.2.6 | INTEGER | R | 10 | |
| MP-040 | | pdmPowerDescription | .1.3.6.1.4.1.2699.2.4.1.4.1.1.3.1 | STRING | R | Power On. | |
| MP-041 | | pdmPowerDescription | .1.3.6.1.4.1.2699.2.4.1.4.1.1.3.2 | STRING | R | Power Off. | |
| MP-042 | | pdmPowerDescription | .1.3.6.1.4.1.2699.2.4.1.4.1.1.3.3 | STRING | R | Projector is cooling down. | |
| MP-043 | | pdmPowerDescription | .1.3.6.1.4.1.2699.2.4.1.4.1.1.3.4 | STRING | R | Low power mode. | |
| MP-044 | | pdmPowerDescription | .1.3.6.1.4.1.2699.2.4.1.4.1.1.3.5 | STRING | R | Low power mode. | |
| MP-045 | | pdmPowerDescription | .1.3.6.1.4.1.2699.2.4.1.4.1.1.3.6 | STRING | R | Warming up. | |
| MP-046 | | pdmPowerMfrDescription | .1.3.6.1.4.1.2699.2.4.1.4.1.1.4.1 | STRING | R | Full power on, all components active. | |
| MP-047 | | pdmPowerMfrDescription | .1.3.6.1.4.1.2699.2.4.1.4.1.1.4.2 | STRING | R | Standby State. Only network electronics remain on. | |
| MP-048 | | pdmPowerMfrDescription | .1.3.6.1.4.1.2699.2.4.1.4.1.1.4.3 | STRING | R | Going down to standby mode. | |
| MP-049 | | pdmPowerMfrDescription | .1.3.6.1.4.1.2699.2.4.1.4.1.1.4.4 | STRING | R | Lamp off; fan on. | |
| MP-050 | | pdmPowerMfrDescription | .1.3.6.1.4.1.2699.2.4.1.4.1.1.4.5 | STRING | R | Lamp off; fan on. | |
| MP-051 | | pdmPowerMfrDescription | .1.3.6.1.4.1.2699.2.4.1.4.1.1.4.6 | STRING | R | Lamp warming up; fan on. | |
| MP-052 | | pdmPowerTargetState | .1.3.6.1.4.1.2699.2.4.1.4.1.1.5.1 | INTEGER | R | 7 | |
| MP-053 | | pdmPowerTargetState | .1.3.6.1.4.1.2699.2.4.1.4.1.1.5.2 | INTEGER | R | 11 | |
| MP-054 | | pdmPowerTargetState | .1.3.6.1.4.1.2699.2.4.1.4.1.1.5.3 | INTEGER | R | 3 | |
| MP-055 | | pdmPowerTargetState | .1.3.6.1.4.1.2699.2.4.1.4.1.1.5.4 | INTEGER | R | 7 | |
| MP-056 | | pdmPowerTargetState | .1.3.6.1.4.1.2699.2.4.1.4.1.1.5.5 | INTEGER | R | 11 | |
| MP-057 | | pdmPowerTargetState | .1.3.6.1.4.1.2699.2.4.1.4.1.1.5.6 | INTEGER | R | 3 | |
| MP-058 | | pdmPowerTransitionTime | .1.3.6.1.4.1.2699.2.4.1.4.1.1.6.1 | INTEGER | R | 120 | |
| MP-059 | | pdmPowerTransitionTime | .1.3.6.1.4.1.2699.2.4.1.4.1.1.6.2 | INTEGER | R | 30 | |
| MP-060 | | pdmPowerTransitionTime | .1.3.6.1.4.1.2699.2.4.1.4.1.1.6.3 | INTEGER | R | 0 | |
| MP-061 | | pdmPowerTransitionTime | .1.3.6.1.4.1.2699.2.4.1.4.1.1.6.4 | INTEGER | R | 120 | |
| MP-062 | | pdmPowerTransitionTime | .1.3.6.1.4.1.2699.2.4.1.4.1.1.6.5 | INTEGER | R | 20 | |
| MP-063 | | pdmPowerTransitionTime | .1.3.6.1.4.1.2699.2.4.1.4.1.1.6.6 | INTEGER | R | 0 | |
| MP-064 | | pdmPowerCommAvailable | .1.3.6.1.4.1.2699.2.4.1.4.1.1.7.1 | INTEGER | R | 3 | |
| MP-065 | | pdmPowerCommAvailable | .1.3.6.1.4.1.2699.2.4.1.4.1.1.7.2 | INTEGER | R | 4 | |
| MP-066 | | pdmPowerCommAvailable | .1.3.6.1.4.1.2699.2.4.1.4.1.1.7.3 | INTEGER | R | 4 | |
| MP-067 | | pdmPowerCommAvailable | .1.3.6.1.4.1.2699.2.4.1.4.1.1.7.4 | INTEGER | R | 3 | |
| MP-068 | | pdmPowerCommAvailable | .1.3.6.1.4.1.2699.2.4.1.4.1.1.7.5 | INTEGER | R | 3 | |
| MP-069 | | pdmPowerCommAvailable | .1.3.6.1.4.1.2699.2.4.1.4.1.1.7.6 | INTEGER | R | 4 | |
| MP-070 | | pdmPowerCurrentState | 1.3.6.1.4.1.2699.2.4.1.4.2.0 | INTEGER | R | projector State | |
| MP-071 | | pdmPowerRequestedState | 1.3.6.1.4.1.2699.2.4.1.4.3.0 | INTEGER | R/W | projector Requested State | |
| MP-072 | | pdmDisplayCap | pdmDisplayCapResolutionH | 1.3.6.1.4.1.2699.2.4.1.5.1.0 | INTEGER | R | 1600 |
| MP-073 | | | pdmDisplayCapResolutionV | 1.3.6.1.4.1.2699.2.4.1.5.2.0 | INTEGER | R | 1200 |
| MP-074 | | | pdmDisplayCapPhysSizeH | 1.3.6.1.4.1.2699.2.4.1.5.3.0 | STRING | R | DEFVAL { "" } |
| MP-075 | | | pdmDisplayCapPhysSizeV | 1.3.6.1.4.1.2699.2.4.1.5.4.0 | STRING | R | DEFVAL { "" } |
| MP-076 | | pdmDisplaySet | pdmDisplaySetIndex | 1.3.6.1.4.1.2699.2.4.1.6.1.1.1.1 | INTEGER | not-accessible | 1 |
| MP-077 | | | pdmDisplaySetAffectsAll | 1.3.6.1.4.1.2699.2.4.1.6.1.1.2.1 | INTEGER | R | DEFVAL { 1 } |
| MP-078 | | | pdmDisplaySetInputSource | 1.3.6.1.4.1.2699.2.4.1.6.1.1.3.1 | INTEGER | R/W | Correspond with OSD |
| MP-079 | | | pdmDisplaySetBrightness | 1.3.6.1.4.1.2699.2.4.1.6.1.1.4.1 | INTEGER | R/W | Brightness |
| MP-080 | | | pdmDisplaySetBrtnMax | 1.3.6.1.4.1.2699.2.4.1.6.1.1.5.1 | INTEGER | R | 100 |
| MP-081 | | | pdmDisplaySetContrast | 1.3.6.1.4.1.2699.2.4.1.6.1.1.6.1 | INTEGER | R/W | Contrast |
| MP-082 | | | pdmDisplaySetConMax | 1.3.6.1.4.1.2699.2.4.1.6.1.1.7.1 | INTEGER | R | 100 |

| | | | | | | | |
|--------|----------------------------|--------------------------|-----------------------------------|----------------------------------|---------|---|----------------------------|
| MP-083 | pdmDisplaySet | pdmDisplaySetRed | 1.3.6.1.4.1.2699.2.4.1.6.1.1.8.1 | INTEGER | R | DEFVAL { 0 } | |
| MP-084 | | pdmDisplaySetGreen | 1.3.6.1.4.1.2699.2.4.1.6.1.1.9.1 | INTEGER | R | DEFVAL { 0 } | |
| MP-085 | | pdmDisplaySetBlue | 1.3.6.1.4.1.2699.2.4.1.6.1.1.10.1 | INTEGER | R | DEFVAL { 0 } | |
| MP-086 | | pdmDisplaySetRGBMax | 1.3.6.1.4.1.2699.2.4.1.6.1.1.11.1 | INTEGER | R | DEFVAL { 100 } | |
| MP-087 | | pdmDisplaySetSaturation | 1.3.6.1.4.1.2699.2.4.1.6.1.1.12.1 | INTEGER | R/W | Saturation | |
| MP-088 | | pdmDisplaySetSatMax | 1.3.6.1.4.1.2699.2.4.1.6.1.1.13.1 | INTEGER | R | 100 | |
| MP-089 | | pdmDisplaySetHue | 1.3.6.1.4.1.2699.2.4.1.6.1.1.14.1 | INTEGER | R/W | Hue | |
| MP-090 | | pdmDisplaySetHueMax | 1.3.6.1.4.1.2699.2.4.1.6.1.1.15.1 | INTEGER | R | 100 | |
| MP-091 | | pdmDisplaySetSharpness | 1.3.6.1.4.1.2699.2.4.1.6.1.1.16.1 | INTEGER | R/W | Sharpness | |
| MP-092 | | pdmDisplaySetShpMax | 1.3.6.1.4.1.2699.2.4.1.6.1.1.17.1 | INTEGER | R | 31 | |
| MP-093 | | pdmDisplaySetColorTemp | 1.3.6.1.4.1.2699.2.4.1.6.1.1.18.1 | INTEGER | R/W | custom(3); low(4); mid(5); high(6) | |
| MP-094 | | pdmDisplaySetRedClrTmp | 1.3.6.1.4.1.2699.2.4.1.6.1.1.19.1 | INTEGER | R/W | DEFVAL { 50 } | |
| MP-095 | | pdmDisplaySetGreenClrTmp | 1.3.6.1.4.1.2699.2.4.1.6.1.1.20.1 | INTEGER | R/W | DEFVAL { 50 } | |
| MP-096 | | pdmDisplaySetBlueClrTmp | 1.3.6.1.4.1.2699.2.4.1.6.1.1.21.1 | INTEGER | R/W | DEFVAL { 50 } | |
| MP-097 | | pdmDisplaySetClrTmpMax | 1.3.6.1.4.1.2699.2.4.1.6.1.1.22.1 | INTEGER | R | DEFVAL { 0 } | |
| MP-098 | | pdmDisplaySetVideoMute | 1.3.6.1.4.1.2699.2.4.1.6.2.0 | INTEGER | R/W | muted(1); notMuted(2) | |
| MP-099 | | pdmDisplaySetDisplayMode | 1.3.6.1.4.1.2699.2.4.1.6.3.0 | INTEGER | R/W | 1:1-->zoom(3) ; 4:3-->window4x3(7) ; 16:10-->widescreen16x9(5) | |
| MP-100 | | pdmLightSource | pdmLightSourceIndex | 1.3.6.1.4.1.2699.2.4.1.7.1.1.1.1 | INTEGER | not-accessible | 1 |
| MP-101 | | | pdmLightSourceDescription | 1.3.6.1.4.1.2699.2.4.1.7.1.1.2.1 | STRING | R | Philips 300W E21.7 ARC 1.1 |
| MP-102 | | | pdmLightSourceStatus | 1.3.6.1.4.1.2699.2.4.1.7.1.1.3.1 | INTEGER | R | okay(3) ; failed(4) |
| MP-103 | pdmLightSourceEcoSetting | | 1.3.6.1.4.1.2699.2.4.1.7.1.1.4.1 | INTEGER | R/W | ECO Mode: Off-->normal(4) ; On-->low(5) | |
| MP-104 | pdmLightSourceAge | | 1.3.6.1.4.1.2699.2.4.1.7.1.1.5.1 | INTEGER | R | lamp hour | |
| MP-105 | pdmLightSourceErrorCounter | | 1.3.6.1.4.1.2699.2.4.1.7.1.1.6.1 | INTEGER | R | pdmLightSourceErrorCounter | |

| | | | | | | |
|--------|---------------|-----------------------------------|------------------------------------|---------|----------------|--|
| MP-106 | | pdmLightSourceReset | 1.3.6.1.4.1.2699.2.4.1.7.1.1.7.1 | INTEGER | R/W | DEFVAL { 1 } resetFRU(3) & resetCountersOnly(4)--> lamp hour & Error Counter reset to 0 |
| MP-107 | | pdmLightSourceReplacementCount | 1.3.6.1.4.1.2699.2.4.1.7.1.1.8.1 | STRING | R | DEFVAL { "" } |
| MP-108 | | pdmLightSourceReplacementTime | 1.3.6.1.4.1.2699.2.4.1.7.1.1.9.1 | STRING | R | DEFVAL { "1980-01-01T00:00:00" } |
| MP-109 | | pdmLightSourceReplacementInterval | 1.3.6.1.4.1.2699.2.4.1.7.1.1.10.1 | INTEGER | R | DEFVAL { 0 } |
| MP-110 | | pdmLightSourceReplacementPN | 1.3.6.1.4.1.2699.2.4.1.7.1.1.11.1 | STRING | R | DEFVAL { "" } |
| MP-111 | pdmFan | pdmFanIndex | 1.3.6.1.4.1.2699.2.4.1.8.1.1.1.1 | INTEGER | not-accessible | 1 |
| MP-112 | | pdmFanDescription | 1.3.6.1.4.1.2699.2.4.1.8.1.1.2.1 | STRING | R | System fan |
| MP-113 | | pdmFanStatus | 1.3.6.1.4.1.2699.2.4.1.8.1.1.3.1 | INTEGER | R | okay(3) ; warning(4) |
| MP-114 | | pdmFanSpeed | 1.3.6.1.4.1.2699.2.4.1.8.1.1.4.1 | INTEGER | R | DEFVAL { 0 } |
| MP-115 | | pdmFanErrorCounter | 1.3.6.1.4.1.2699.2.4.1.8.1.1.5.1 | INTEGER | R | pdmFanErrorCounter |
| MP-116 | | pdmFanReset | 1.3.6.1.4.1.2699.2.4.1.8.1.1.6.1 | INTEGER | R/W | DEFVAL { 1 } resetFRU(3) & resetCountersOnly(4)--> Error Counter reset to 0 |
| MP-117 | | pdmFanReplacementCount | 1.3.6.1.4.1.2699.2.4.1.8.1.1.7.1 | STRING | R | DEFVAL { "" } |
| MP-118 | | pdmFanReplacementTime | 1.3.6.1.4.1.2699.2.4.1.8.1.1.8.1 | STRING | R | DEFVAL { "1980-01-01T00:00:00" } |
| MP-119 | | pdmFanReplacementInterval | 1.3.6.1.4.1.2699.2.4.1.8.1.1.9.1 | INTEGER | R | DEFVAL { 0 } |
| MP-120 | | pdmFanReplacementPartNumber | 1.3.6.1.4.1.2699.2.4.1.8.1.1.10.1 | STRING | R | DEFVAL { "" } |
| MP-121 | pdmTempSensor | pdmTempSensorIndex | 1.3.6.1.4.1.2699.2.4.1.10.1.1.1.1 | INTEGER | not-accessible | 1 |
| MP-122 | | pdmTempSensorDescription | 1.3.6.1.4.1.2699.2.4.1.10.1.1.2.1 | STRING | R | Measure system internal temperature |
| MP-123 | | pdmTempSensorStatus | 1.3.6.1.4.1.2699.2.4.1.10.1.1.3.1 | INTEGER | R | DEFVAL { 2 } |
| MP-124 | | pdmTempSensorTemp | 1.3.6.1.4.1.2699.2.4.1.10.1.1.4.1 | INTEGER | R | Describes the temperature being measured by the thermal sensor in 10ths of a degree C. |
| MP-125 | | pdmTempSensorErrorCounter | 1.3.6.1.4.1.2699.2.4.1.10.1.1.5.1 | INTEGER | R | TempSensorErrorCounter |
| MP-126 | | pdmTempSensorReset | 1.3.6.1.4.1.2699.2.4.1.10.1.1.6.1 | INTEGER | R/W | DEFVAL { 1 } resetFRU(3) & resetCountersOnly(4)--> Error Counter reset to 0 |
| MP-127 | | pdmTempSensorReplaceCount | 1.3.6.1.4.1.2699.2.4.1.10.1.1.7.1 | STRING | R | DEFVAL { "" } |
| MP-128 | | pdmTempSensorReplaceTime | 1.3.6.1.4.1.2699.2.4.1.10.1.1.8.1 | STRING | R | DEFVAL { "1980-01-01T00:00:00" } |
| MP-129 | | pdmTempSensorReplaceInterval | 1.3.6.1.4.1.2699.2.4.1.10.1.1.9.1 | INTEGER | R | DEFVAL { 0 } |
| MP-130 | | pdmTempSensorReplacePN | 1.3.6.1.4.1.2699.2.4.1.10.1.1.10.1 | STRING | R | DEFVAL { "" } |
| MP-131 | pdmTempSwitch | pdmTempSwitchIndex | 1.3.6.1.4.1.2699.2.4.1.11.1.1.1.1 | INTEGER | not-accessible | 1 |
| MP-132 | | pdmTempSwitchDescription | 1.3.6.1.4.1.2699.2.4.1.11.1.1.2.1 | STRING | R | Avertronics INC. |
| MP-133 | | pdmTempSwitchStatus | 1.3.6.1.4.1.2699.2.4.1.11.1.1.3.1 | INTEGER | R | okay(3) ; fail(5) |
| MP-134 | | pdmTempSwitchErrorCounter | 1.3.6.1.4.1.2699.2.4.1.11.1.1.4.1 | INTEGER | R | TempSwitchErrorCounter |
| MP-135 | | pdmTempSwitchReset | 1.3.6.1.4.1.2699.2.4.1.11.1.1.5.1 | INTEGER | R/W | DEFVAL { 1 } resetFRU(3) & resetCountersOnly(4)--> Error Counter reset to 0 |
| MP-136 | | pdmTempSwitchReplaceCount | 1.3.6.1.4.1.2699.2.4.1.11.1.1.6.1 | STRING | R | DEFVAL { "" } |
| MP-137 | | pdmTempSwitchReplaceTime | 1.3.6.1.4.1.2699.2.4.1.11.1.1.7.1 | STRING | R | DEFVAL { "1980-01-01T00:00:00" } |
| MP-138 | | pdmTempSwitchReplacePN | 1.3.6.1.4.1.2699.2.4.1.11.1.1.8.1 | STRING | R | DEFVAL { "" } |
| MP-139 | | pdmConnectorIndex | 1.3.6.1.4.1.2699.2.4.1.12.1.1.1.1 | INTEGER | not-accessible | 1 |
| MP-140 | | pdmConnectorIndex | 1.3.6.1.4.1.2699.2.4.1.12.1.1.1.2 | INTEGER | not-accessible | 2 |
| MP-141 | | pdmConnectorIndex | 1.3.6.1.4.1.2699.2.4.1.12.1.1.1.3 | INTEGER | not-accessible | 3 |

| | | | | | | |
|--------|--------------|-------------------------|-------------------------------------|---------|----------------|------------------|
| MP-142 | | pdmConnectorIndex | .1.3.6.1.4.1.2699.2.4.1.12.1.1.1.4 | INTEGER | not-accessible | 4 |
| MP-143 | | pdmConnectorIndex | .1.3.6.1.4.1.2699.2.4.1.12.1.1.1.5 | INTEGER | not-accessible | 5 |
| MP-144 | | pdmConnectorIndex | .1.3.6.1.4.1.2699.2.4.1.12.1.1.1.6 | INTEGER | not-accessible | 6 |
| MP-145 | | pdmConnectorIndex | .1.3.6.1.4.1.2699.2.4.1.12.1.1.1.7 | INTEGER | not-accessible | 7 |
| MP-146 | | pdmConnectorIndex | .1.3.6.1.4.1.2699.2.4.1.12.1.1.1.8 | INTEGER | not-accessible | 8 |
| MP-147 | | pdmConnectorIndex | .1.3.6.1.4.1.2699.2.4.1.12.1.1.1.9 | INTEGER | not-accessible | 9 |
| MP-148 | | pdmConnectorIndex | .1.3.6.1.4.1.2699.2.4.1.12.1.1.1.10 | INTEGER | not-accessible | 10 |
| MP-149 | | pdmConnectorIndex | .1.3.6.1.4.1.2699.2.4.1.12.1.1.1.11 | INTEGER | not-accessible | 11 |
| MP-150 | | pdmConnectorDescription | .1.3.6.1.4.1.2699.2.4.1.12.1.1.2.1 | STRING | R | VGA-A |
| MP-151 | | pdmConnectorDescription | .1.3.6.1.4.1.2699.2.4.1.12.1.1.2.2 | STRING | R | VGA-B |
| MP-152 | | pdmConnectorDescription | .1.3.6.1.4.1.2699.2.4.1.12.1.1.2.3 | STRING | R | S-Video |
| MP-153 | | pdmConnectorDescription | .1.3.6.1.4.1.2699.2.4.1.12.1.1.2.4 | STRING | R | Composite Video |
| MP-154 | | pdmConnectorDescription | .1.3.6.1.4.1.2699.2.4.1.12.1.1.2.5 | STRING | R | HDMI |
| MP-155 | | pdmConnectorDescription | .1.3.6.1.4.1.2699.2.4.1.12.1.1.2.6 | STRING | R | Wireless Display |
| MP-156 | | pdmConnectorDescription | .1.3.6.1.4.1.2699.2.4.1.12.1.1.2.7 | STRING | R | USB Display |
| MP-157 | | pdmConnectorDescription | .1.3.6.1.4.1.2699.2.4.1.12.1.1.2.8 | STRING | R | USB Viewer |
| MP-158 | | pdmConnectorDescription | .1.3.6.1.4.1.2699.2.4.1.12.1.1.2.9 | STRING | R | Audio-A |
| MP-159 | | pdmConnectorDescription | .1.3.6.1.4.1.2699.2.4.1.12.1.1.2.10 | STRING | R | Audio-B |
| MP-160 | | pdmConnectorDescription | .1.3.6.1.4.1.2699.2.4.1.12.1.1.2.11 | STRING | R | Audio-C |
| MP-161 | | pdmConnectorType | .1.3.6.1.4.1.2699.2.4.1.12.1.1.3.1 | INTEGER | R | 3 |
| MP-162 | | pdmConnectorType | .1.3.6.1.4.1.2699.2.4.1.12.1.1.3.2 | INTEGER | R | 3 |
| MP-163 | | pdmConnectorType | .1.3.6.1.4.1.2699.2.4.1.12.1.1.3.3 | INTEGER | R | 10 |
| MP-164 | | pdmConnectorType | .1.3.6.1.4.1.2699.2.4.1.12.1.1.3.4 | INTEGER | R | 13 |
| MP-165 | | pdmConnectorType | .1.3.6.1.4.1.2699.2.4.1.12.1.1.3.5 | INTEGER | R | 6 |
| MP-166 | | pdmConnectorType | .1.3.6.1.4.1.2699.2.4.1.12.1.1.3.6 | INTEGER | R | 12 |
| MP-167 | | pdmConnectorType | .1.3.6.1.4.1.2699.2.4.1.12.1.1.3.7 | INTEGER | R | 16 |
| MP-168 | | pdmConnectorType | .1.3.6.1.4.1.2699.2.4.1.12.1.1.3.8 | INTEGER | R | 16 |
| MP-169 | | pdmConnectorType | .1.3.6.1.4.1.2699.2.4.1.12.1.1.3.9 | INTEGER | R | 16 |
| MP-170 | | pdmConnectorType | .1.3.6.1.4.1.2699.2.4.1.12.1.1.3.10 | INTEGER | R | 16 |
| MP-171 | | pdmConnectorType | .1.3.6.1.4.1.2699.2.4.1.12.1.1.3.11 | INTEGER | R | 16 |
| MP-172 | | pdmConnectorEnabled | .1.3.6.1.4.1.2699.2.4.1.12.1.1.4.1 | INTEGER | R | DEFVAL { 1 } |
| MP-173 | | pdmConnectorEnabled | .1.3.6.1.4.1.2699.2.4.1.12.1.1.4.2 | INTEGER | R | DEFVAL { 1 } |
| MP-174 | pdmConnector | pdmConnectorEnabled | .1.3.6.1.4.1.2699.2.4.1.12.1.1.4.3 | INTEGER | R | DEFVAL { 1 } |
| MP-175 | | pdmConnectorEnabled | .1.3.6.1.4.1.2699.2.4.1.12.1.1.4.4 | INTEGER | R | DEFVAL { 1 } |
| MP-176 | | pdmConnectorEnabled | .1.3.6.1.4.1.2699.2.4.1.12.1.1.4.5 | INTEGER | R | DEFVAL { 1 } |
| MP-177 | | pdmConnectorEnabled | .1.3.6.1.4.1.2699.2.4.1.12.1.1.4.6 | INTEGER | R | DEFVAL { 1 } |
| MP-178 | | pdmConnectorEnabled | .1.3.6.1.4.1.2699.2.4.1.12.1.1.4.7 | INTEGER | R | DEFVAL { 1 } |
| MP-179 | | pdmConnectorEnabled | .1.3.6.1.4.1.2699.2.4.1.12.1.1.4.8 | INTEGER | R | DEFVAL { 1 } |
| MP-180 | | pdmConnectorEnabled | .1.3.6.1.4.1.2699.2.4.1.12.1.1.4.9 | INTEGER | R | DEFVAL { 1 } |
| MP-181 | | pdmConnectorEnabled | .1.3.6.1.4.1.2699.2.4.1.12.1.1.4.10 | INTEGER | R | DEFVAL { 1 } |
| MP-182 | | pdmConnectorEnabled | .1.3.6.1.4.1.2699.2.4.1.12.1.1.4.11 | INTEGER | R | DEFVAL { 1 } |
| MP-183 | | pdmConnectorAudioAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.5.1 | INTEGER | R | DEFVAL { 0 } |
| MP-184 | | pdmConnectorAudioAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.5.2 | INTEGER | R | DEFVAL { 0 } |
| MP-185 | | pdmConnectorAudioAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.5.3 | INTEGER | R | DEFVAL { 0 } |
| MP-186 | | pdmConnectorAudioAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.5.4 | INTEGER | R | DEFVAL { 0 } |
| MP-187 | | pdmConnectorAudioAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.5.5 | INTEGER | R | DEFVAL { 0 } |
| MP-188 | | pdmConnectorAudioAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.5.6 | INTEGER | R | DEFVAL { 0 } |
| MP-189 | | pdmConnectorAudioAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.5.7 | INTEGER | R | DEFVAL { 0 } |
| MP-190 | | pdmConnectorAudioAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.5.8 | INTEGER | R | DEFVAL { 0 } |
| MP-191 | | pdmConnectorAudioAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.5.9 | INTEGER | R | DEFVAL { 0 } |
| MP-192 | | pdmConnectorAudioAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.5.10 | INTEGER | R | DEFVAL { 0 } |
| MP-193 | | pdmConnectorAudioAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.5.11 | INTEGER | R | DEFVAL { 0 } |
| MP-194 | | pdmConnectorVideoAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.6.1 | INTEGER | R | DEFVAL { 0 } |
| MP-195 | | pdmConnectorVideoAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.6.2 | INTEGER | R | DEFVAL { 0 } |
| MP-196 | | pdmConnectorVideoAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.6.3 | INTEGER | R | DEFVAL { 0 } |

| | | | | | | |
|--------|-------------------|-----------------------------|-------------------------------------|---------|----------------|--|
| MP-197 | | pdmConnectorVideoAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.6.4 | INTEGER | R | DEFVAL { 0 } |
| MP-198 | | pdmConnectorVideoAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.6.5 | INTEGER | R | DEFVAL { 0 } |
| MP-199 | | pdmConnectorVideoAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.6.6 | INTEGER | R | DEFVAL { 0 } |
| MP-200 | | pdmConnectorVideoAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.6.7 | INTEGER | R | DEFVAL { 0 } |
| MP-201 | | pdmConnectorVideoAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.6.8 | INTEGER | R | DEFVAL { 0 } |
| MP-202 | | pdmConnectorVideoAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.6.9 | INTEGER | R | DEFVAL { 0 } |
| MP-203 | | pdmConnectorVideoAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.6.10 | INTEGER | R | DEFVAL { 0 } |
| MP-204 | | pdmConnectorVideoAdjust | .1.3.6.1.4.1.2699.2.4.1.12.1.1.6.11 | INTEGER | R | DEFVAL { 0 } |
| MP-205 | | pdmConnectorVideoCurrInput | 1.3.6.1.4.1.2699.2.4.1.12.2.0 | INTEGER | R/W | Correspond with OSD |
| MP-206 | | pdmConnectorAudioCurrInput | 1.3.6.1.4.1.2699.2.4.1.12.3.0 | INTEGER | R/W | Correspond with OSD |
| MP-207 | | pdmInterlockIndex | 1.3.6.1.4.1.2699.2.4.1.13.1.1.1.1 | INTEGER | not-accessible | 1 |
| MP-208 | pdmInterlockTable | pdmInterlockDescription | 1.3.6.1.4.1.2699.2.4.1.13.1.1.2.1 | STRING | R | DEFVAL { "" } |
| MP-209 | | pdmInterlockStatus | 1.3.6.1.4.1.2699.2.4.1.13.1.1.3.1 | INTEGER | R | DEFVAL { 3 } |
| MP-210 | | pdmLocaleCharsetIndex | 1.3.6.1.4.1.2699.2.4.1.14.1.1.1.1 | INTEGER | not-accessible | 1 |
| MP-211 | pdmLocaleCharset | pdmLocaleCharsetEnum | 1.3.6.1.4.1.2699.2.4.1.14.1.1.2.1 | INTEGER | R | DEFVAL { 4 } |
| MP-212 | | pdmLocaleCharsetEnumEWS | 1.3.6.1.4.1.2699.2.4.1.14.2.0 | INTEGER | R/W | DEFVAL { 4 } |
| MP-213 | | pdmLocaleLanguageIndex | 1.3.6.1.4.1.2699.2.4.1.15.1.1.1.1 | INTEGER | not-accessible | 1 |
| MP-214 | | pdmLocaleLanguageTag | 1.3.6.1.4.1.2699.2.4.1.15.1.1.2.1 | STRING | R | DEFVAL { en-US } |
| MP-215 | pdmLocaleLanguage | pdmLocaleLanguageTagEWS | 1.3.6.1.4.1.2699.2.4.1.15.2.0 | STRING | R | DEFVAL { en-US } |
| MP-216 | | pdmLocaleLanguageTagOSD | 1.3.6.1.4.1.2699.2.4.1.15.3.0 | STRING | R | DEFVAL { en-US } |
| MP-217 | | pdmLocaleLanguageTagWSM | 1.3.6.1.4.1.2699.2.4.1.15.4.0 | STRING | R | DEFVAL { en-US } |
| MP-218 | | pdmAudioDescription | 1.3.6.1.4.1.2699.2.4.1.16.1.0 | STRING | R | DEFVAL { "" } |
| MP-219 | | pdmAudioVolume | 1.3.6.1.4.1.2699.2.4.1.16.2.0 | INTEGER | R/W | 0~1000 |
| MP-220 | pdmAudio | pdmAudioMute | 1.3.6.1.4.1.2699.2.4.1.16.3.0 | INTEGER | R/W | muted(1) ; notMuted(2) |
| MP-221 | | pdmAudioTreble | 1.3.6.1.4.1.2699.2.4.1.16.4.0 | INTEGER | R | DEFVAL { 0 } |
| MP-222 | | pdmAudioBass | 1.3.6.1.4.1.2699.2.4.1.16.5.0 | INTEGER | R | DEFVAL { 0 } |
| MP-223 | | pdmAudioBalance | 1.3.6.1.4.1.2699.2.4.1.16.6.0 | INTEGER | R | DEFVAL { 0 } |
| MP-224 | | pdmAlertIndex | 1.3.6.1.4.1.2699.2.4.1.18.1.1.1.1 | INTEGER | not-accessible | 1 |
| MP-225 | | pdmAlertGroupType | 1.3.6.1.4.1.2699.2.4.1.18.1.1.2.1 | STRING | R | See Note 1 |
| MP-226 | | pdmAlertGroupId | 1.3.6.1.4.1.2699.2.4.1.18.1.1.3.1 | STRING | R | See Note 1 |
| MP-227 | | pdmAlertCode | 1.3.6.1.4.1.2699.2.4.1.18.1.1.4.1 | STRING | R | DEFVAL { "" } |
| MP-228 | | pdmAlertDescription | 1.3.6.1.4.1.2699.2.4.1.18.1.1.5.1 | STRING | R | Alert's condition has lamp Fail, Lamp hours running out, Projector Overheating,Lamp Overheating and Fan Error. |
| MP-229 | | pdmAlertSeverityLevel | 1.3.6.1.4.1.2699.2.4.1.18.1.1.6.1 | INTEGER | R | See Note 1 |
| MP-230 | | pdmAlertTrainingLevel | 1.3.6.1.4.1.2699.2.4.1.18.1.1.7.1 | INTEGER | R | DEFVAL { 2 } |
| MP-231 | | pdmAlertDateTime | 1.3.6.1.4.1.2699.2.4.1.18.1.1.8.1 | STRING | R | DEFVAL { "1980-01-01T00:00:00" } |
| MP-232 | pdmAlert | pdmAlertPowerOnCount | 1.3.6.1.4.1.2699.2.4.1.18.1.1.9.1 | STRING | R | DEFVAL { "" } |
| MP-233 | | pdmAlertSysUptime | 1.3.6.1.4.1.2699.2.4.1.18.1.1.10.1 | STRING | R | DEFVAL { "" } |
| MP-234 | | pdmAlertCriticalAlertsCount | 1.3.6.1.4.1.2699.2.4.1.18.2.0 | INTEGER | R | CriticalAlertsCount= FanErrorCounter+TempSwitchErrorCounter+TempSensorErrorCounter+LightSourceErrorCounter |

| | | | | | | |
|--------|--|------------------------|-------------------------------|---------|---|--|
| MP-235 | | pdmAlertAllAlertsCount | 1.3.6.1.4.1.2699.2.4.1.18.3.0 | INTEGER | R | AllAlertsCount= FanErrorCounter+TempSwitchErrorCounter+TempSensorErrorCounter+LightSourceErrorCounter |
|--------|--|------------------------|-------------------------------|---------|---|--|

The rest Object will respond default.

c) If there is Lamp fail alert happen, the tables is shown below
pdmAlertGroupType = "Lamp"
pdmAlertGroupID= Lamp Fail
pdmAlertSeverity = Critical (3)
The rest Object will respond default.

d) If there is Lamp hours running out alert happen, the tables is shown below
pdmAlertGroupType = "Lamp"
pdmAlertGroupID= Lamp hours running out
pdmAlertSeverity = warning (4)
The rest Object will respond default

e) If there is Projector Over-heating alert, the tables is shown below
pdmAlertGroupType = "ThermalSensor"
pdmAlertGroupID= "Projector Overheating"
pdmAlertSeverity = warning (4)
The rest Object will respond default.

f) If there is Lamp Over-heating alert, the tables is shown below
pdmAlertGroupType = "ThermalSwitch"
pdmAlertGroupID= "Lamp Overheating"
pdmAlertSeverity = Critical (3)
The rest Object will respond default.