



Specifications

Copyright © 2015 Dell Inc. All rights reserved. This product is protected by U.S. and international copyright and intellectual property laws. Dell and the Dell logo are trademarks of Dell Inc. in the United States and/or other jurisdictions. All other marks and names mentioned herein may be trademarks of their respective companies.

2015-08 Rev. A01

Regulatory model: P20T | Type: P20T003

Computer model: Inspiron 11-3157

Front

Front

Left



Right



Base



Display



Modes

Power/Battery status light

Indicates the power state and battery state of the computer.

Solid white — Power adapter is connected to the computer and the battery is being charged.

Solid yellow — Battery charge is low or critical.

 ${\sf Off}-{\sf Power}$ adapter is connected to the computer and battery is fully charged or power adapter is not connected to the computer.



Front

Left



Right



Base




Display



Modes

Left



Power-adapter port

Connect a power adapter to provide power to your computer and charge the battery.

HDMI port

Connect a TV or another HDMI-in enabled device. Provides video and audio output.

USB 3.0 port with PowerShare

Connect peripherals such as storage devices, printers, and so on. Provides data transfer speeds up to 5 Gbps.

PowerShare allows you to charge your USB devices even when your computer is turned off.

NOTE: If your computer is turned off or in Hibernate state, you must connect the power adapter to charge your devices using the PowerShare port. You must enable this feature in the BIOS setup program.

NOTE: Certain USB devices may not charge when the computer is turned off or in the Sleep state. In such cases, turn on the computer to charge the device.

USB 3.0 port

Connect peripherals such as storage devices, printers, and so on. Provides data transfer speeds up to 5 Gbps.

Headset port

Connect a headphone, a microphone, or a headphone and microphone combo (headset).

6 Left speaker

Provides audio output from your computer.



Right

Front



Left



Right



Base



Display



Modes



Power button

Press to turn on the computer if it is turned off or in Sleep state.

Press to put the computer in Sleep state if it is turned on. Press and hold for 4 seconds to force shut-down the computer.

NOTE: You can customize the power-button behavior in Power Options. For more information, see Me and My Dell at www.dell.com/support/ manuals.

Volume-control buttons (2)

Press to increase or decrease the volume.

Right speaker

Provides audio output from your computer.

USB 2.0 port

Connect peripherals such as storage devices, printers, and so on. Provides data transfer speeds up to 480 Mbps.

Media-card reader

Reads from and writes to media cards.

Security-cable slot

Connect a Noble security-cable to prevent unauthorized movement of your computer.



Base

Front

Left



Right



Base



Display



Modes



Left-click area

Press to left click.

Touch pad

Move your finger on the touch pad to move the mouse pointer. Tap to left click.

Right-click area

Press to right click.



Front

Left



Right



Base




Display



Modes

Display



Left microphone

Provides high-quality digital sound input for audio recording, voice calls, and so on.

Ambient-light sensor

Detects the ambient light and automatically adjusts the display brightness.

Camera

Allows you to video chat, capture photos, and record videos.

Camera-status light

Turns on when the camera is in use.

5 **Right microphone**

Provides high-quality digital sound input for audio recording, voice calls, and so on.

6 Windows button

Press to go to the Start screen.





Modes

Front





Left



Right



Base



Display



Modes



Tablet Stand



Tablet



Tent





Dimensions and weight

Height	19 mm (0.75 in)
Width	300 mm (11.81 in)
Depth	201 mm (7.91 in)
Weight	1.39 kg (3.06 lb)
	NOTE : The weight of your laptop varies depending on the configuration ordered and the manufacturing variability.





































System information

Computer model	Inpiron 11-3157
Processor	Intel Celeron Dual Core
	Intel Pentium Quad Core
Chipset	Integrated in processor



















Audio



















Memory

Slot One SODIMM slot

Type DDR3L

Speed 1600 MHz

Configurations supported: 2 GB and 4 GB











Memory



Ports and connectors



Communications



Video



Audio



Storage



Media-card reader



Display



Camera



Touch pad












Ports and connectors

External:	
USB	One USB 2.0 portOne USB 3.0 port
	One USB 3.0 port with PowerShare
Audio/video	One HDMI portOne headphone and microphone combo (headset) port

Internal:

One M.2 slot for Wi-Fi and Bluetooth combo card M.2









Ports and Communications connectors









Audio





















Communications

Wireless

- Wi-Fi 802.11b/g/n
- Wi-Fi 802.11ac
- Bluetooth 4.0
- Intel WiDi (optional)





















Storage



















Video

Controller Intel HD Graphics

Memory Shared system memory





































Audio

Controller Realtek Al C3234 with Waves MaxxAudio

Speakers Two


Speaker output:

Average 2 W Peak 2.5 W

Microphone Digital-array microphones in camera assembly

Volume controls Media-control shortcut keys and volume-control buttons







information



Memory



Ports and connectors



Communications



Video



Audio



Storage



Media-card reader



Display



















Storage

Interface SATA 6 Gbps

Hard drive • One 2.5-inch drive

• One eMMC card



















Video



















Media-card reader

One 2-in-1 slot Type

Card supported SD card

















Memory

connectors









Media-card reader













Display

11.6-inch HD WI FD touch Type

Resolution (maximum) 1366 x 768

Dimensions:

144 mm (5.67 in) Height

Width 256.13 mm (10.08 in)

Diagonal 294.64 mm (11.60 in)

Refresh rate 60 Hz

Operating angle 0 degrees (closed) to 360 degrees

Pixel pitch 0.1875 mm

Controls Brightness can be controlled using shortcut keys.



Dimensions and weight



information



Memory



Ports and connectors



Communications



Video



Audio



Storage



Media-card reader



Keyboard







Touch pad



Power adapter



Computer environment



Keyboard

Type Chiclet keyboard Shortcut keys Some keys on your keyboard have two symbols on them. These keys can be used to type alternate characters or to perform secondary functions. To type the alternate character, press Shift and the desired key. To perform secondary functions, press Fn and the desired key.

> **NOTE**: You can change the behavior of the shortcut keys by pressing Fn+Esc or by changing **Function Key Behavior** in System Setup.

List of shortcut keys.



reader















environment

Ports and connectors




















Shortcut keys



Decrease volume

Increase volume

►/ II Play/Pause

P Open Search charm

Open Share charm

Open Devices charm


Open Settings charm

List recently-used apps

Display active app menu-bar

Decrease brightness

Increase brightness





Camera

Resolution:

Still image 0.92 megapixel

1280 x 720 (HD) at 30 fps (maximum) Video

Diagonal viewing angle 74 degrees























Audio





















Touch pad

Resolution:

Horizontal 1207 dpi Vertical 1702 dpi

Dimensions:

Width 105.20 mm (4.14 in)

Height 60.20 mm (2.37 in)







Memory













Audio





















Battery

3 cell Type

Dimensions:

Width 254 mm (10 in)

77.20 mm (3.04 in) Depth

6.80 mm (0.27 in) Height

Weight (maximum) 0.25 kg (0.55 lb)

11.4 VDC Voltage

Charging time when the

computer is off (approximate)

Operating time Varies depending on operating conditions and can significantly reduce under

Within 4 hours

certain power-intensive conditions.

Life span (approximate) 300 discharge/charge cycles

Temperature range:

0°C to 35°C (32°F to 95°F) Operating

Storage -40°C to 65°C (-40°F to 149°F)

Coin-cell battery CR-2032



Dimensions and weight



System information



Memory



Ports and connectors



Communications



Video



Audio



Storage



Media-card reader



Display



Camera





Touch pad











Power adapter

45 W Type

Input voltage 100 VAC-240 VAC

50 Hz-60 Hz Input frequency

1.30 A Input current

Output current 2.31 A

19.50 VDC Rated output voltage

Temperature range:

0°C to 40°C (32°F to 104°F) Operating

-40°C to 70°C (-40°F to 158°F) Storage



Dimensions and weight



information



Memory



Ports and connectors



Communications



Video



Audio



Storage



Media-card reader



Display



Keyboard



Camera



Touch pad





Computer Power adapter environment



Computer environment

Airborne contaminant level	G1 as defined by ISA-S71.04-1985		
	Operating	Storage	
Temperature range	0°C to 35°C (32°F to 95°F)	-40°C to 65°C (-40°F to 149°F)	
Relative humidity (maximum)	10% to 90% (non-condensing)	0% to 95% (non-condensing)	
Vibration (maximum)*	0.66 GRMS	1.30 GRMS	
Shock (maximum)	110 G [†]	160 G [‡]	
Altitude (maximum)	–15.2 m to 3048 m (–50 ft to 10,000 ft)	-15.2 m to 10,668 m (-50 ft to 35,000 ft)	

^{*} Measured using a random vibration spectrum that simulates user environment.





































[†] Measured using a 2 ms half-sine pulse when the hard drive is in use.

[‡] Measured using a 2 ms half-sine pulse when the hard-drive head is in parked position.