

Vostro 3578


Quick Start Guide

Vodnik za hitri začetek



1 Connect the power adapter and press the power button

Priključite napajalnik in pritisnite gumb za vklop/izklop



What's New

Novosti

- Supports Intel® Kaby lake Celeron UMA processors
- Supports Intel® Kaby lake Pentium UMA processors
- Podpira procesorje Intel® Kaby lake Celeron UMA
- Podpira procesorje Intel® Kaby lake Pentium UMA

Locate Dell apps in Windows 10

Poiščite aplikacije Dell v sistemu Windows 10



SupportAssist

Scan, optimize, update, and get support for your computer

Optično pregledajte, optimizirajte, posodobite in pridobite podporo za računalnik

Product support and manuals

Podpora in navodila za izdelke

Contact Dell

Stik z družbo Dell

Regulatory and safety

Zakonski predpisi in varnost

Regulatory model

Regulatorni način

Regulatory type

Regulativna vrsta

Computer model

Model računalnika

Dell.com/support

Dell.com/support/manuals

Dell.com/support/windows

Dell.com/contactdell

Dell.com/regulatory_compliance

P63F

P63F002

Vostro 3578

© 2017 Dell Inc. or its subsidiaries.

© 2017 Intel Corporation.





0H2FFJA00

2017-11

Features

Funkcije



- 1. Camera
- 2. Camera-status light
- 3. Microphone
- 4. Security-cable slot
- 5. Power button
- 6. Optical drive
- 7. USB 2.0 port
- 8. Headset port
- 9. Memory card reader
- 10. Fingerprint reader (optional)
- 11. Speaker
- 12. Power and battery-status light/hard-drive activity light
- 13. Touchpad
- 14. Speaker
- 15. USB 3.1 Gen 1 ports
- 16. HDMI port
- 17. VGA port
- 18. Network port
- 19. Power adapter
- 20. Battery
- 21. Battery release
- 22. Service Tag label

- 1. Kamera
- 2. Lučka za stanje kamere
- 3. Mikrofon
- 4. Reža za varnostni kabel
- 5. Gumb za vklop/izklop
- 6. Optični pogon
- 7. Vrata USB 2.0
- 8. Vrata za slušalke
- 9. Bralnik pomnilniških kartic
- 10. Bralnik prstnih odtisov (dodatna možnost)
- 11. Zvočnik
- 12. Lučka stanja napajanja in lučka stanja baterije/lučka dejavnosti trdega diska
- 13. Sledilna ploščica
- 14. Zvočnik
- 15. Vrata USB 3.1 1. generacije
- 16. Vrata HDMI
- 17. Vrata VGA
- 18. Omrežna vrata
- 19. Napajalnik
- 20. Baterija
- 21. Sprostitev baterije
- 22. Servisna oznaka