









7330 Mono Laser Printer Adding Memory


Ajout de mémoire • Aggiunta di memoria • Aufrüsten des Speichers • Adición de memoria




7



8



9



10

Confirm installation

Confirmez l'installation
 Confermare l'installazione
 Installation bestätigen
 Confirmar instalación

Print Configuration Page

Imprimez la page de configuration
 Stampare la pagina di configurazione
 Konfigurationsseite drucken
 Imprimir página de configuración

