

Dell PowerConnect W-AirWave Firmware Matrix

W-AirWave	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version	
Dell PowerConnect							
W Series: W-620, W-650, W-651 W-3200, W-3400, W-3600, W-AP68, W- AP92, W-AP93 W-AP105, W-AP124/5, W-AP134/5, W-AP175	5.0.1.x	●	--	●	Telnet/TFTP	7.1.0	
	5.0.3.x	●	●	●	Telnet/TFTP	7.1.0	
	5.0.3.0-1.1.0.1 (Instant only)	●	●	●	Telnet/TFTP	7.3.5	
	6.0.x	●	●	●	Telnet/TFTP	7.3.0	
	6.1.x	●	●	●	Telnet/TFTP	7.3.0	
3Com							
WX Series and APs	6.0.3.2	--	--	--	--	5.1.0	
	6.0.3.2	●	●	●	Telnet/TFTP/FTP	5.3.0	
	7.0.5.6	●	●	●	Telnet/TFTP/FTP	6.4.0	
Aruba							
200, 800, 6xx, 2400, 3x00, 5000, 6000 & APs	2.5.1.5	--	--	--	--	4.3.0	
	2.5.1.5	--	--	●	Telnet/TFTP	4.4.0	
	2.5.4.26	●	--	●	Telnet/TFTP	4.4.0	
	3.1.0	--	--	●	Telnet/TFTP	5.1.0	
	3.1.1	--	--	●	Telnet/TFTP	5.2.4	
	3.3.0	--	--	●	Telnet/TFTP	5.3.0	
	3.3.0	●	●	●	Telnet/TFTP	6.0.0	
	3.3.1.11	●	●	●	Telnet/TFTP	6.1.0	
	3.3.1.28	●	●	●	Telnet/TFTP	6.3.0	
	3.3.1.31	●	●	●	Telnet/TFTP	6.4.0	
	3.3.2.5	●	●	●	Telnet/TFTP	6.1.0	
	3.3.2.10	●	●	●	Telnet/TFTP	6.2.0	
	3.3.2.16	●	●	●	Telnet/TFTP	6.3.0	
	3.3.2.21	●	●	●	Telnet/TFTP	6.4.0	
	3.3.2.24	●	●	●	Telnet/TFTP	7.0.0	
	3.3.3.0	●	●	●	Telnet/TFTP	6.4.0	
	3.4.0.0	●	●	●	Telnet/TFTP	6.3.0	
	3.4.0.6	●	●	●	Telnet/TFTP	6.4.0	
	3.4.1.0	●	●	●	Telnet/TFTP	6.4.0	
	3.4.2.1	●	●	●	Telnet/TFTP	7.0.0	
	3.4.3.0	●	●	●	Telnet/TFTP	7.1.0	
	3.4.3.2	●	●	●	Telnet/TFTP	7.2.0	
	3.4.4.3	●	●	●	Telnet/TFTP	7.3.0	
	5.0.0.0	●	●	●	Telnet/TFTP	7.0.0	
	5.0.1.0	●	●	●	Telnet/TFTP	7.1.0	
	5.0.2.0	●	●	●	Telnet/TFTP	7.1.0	
	5.0.3.0	●	●	●	Telnet/TFTP	7.2.0	
	5.0.3.3	●	●	●	Telnet/TFTP	7.3.0	
	3x00, RAP-5WN,RAP-2WG	3.3.2.10-m-3.0.0	●	●	●	Telnet/TFTP	6.2.0
		3.3.2.14-m-3.1.0	●	●	●	Telnet/TFTP	6.3.0
		3.3.2.18-m-3.1.3	●	●	●	Telnet/TFTP	6.4.0
		3.3.2.24-m-3.1.7	●	●	●	Telnet/TFTP	7.0.0
3.3.2.24-m-3.1.12		●	●	●	Telnet/TFTP	7.1.0	
6xx, 3x00 & APs	6.0.0.0	●	●	●	Telnet/TFTP	7.1.0	
	6.0.0.1	●	●	●	Telnet/TFTP	7.2.0	
	6.0.1.2	●	●	●	Telnet/TFTP	7.3.0	
	6.1.1.0	●	●	●	Telnet/TFTP	7.3.0	
MSR2/4000 MST200 MSR1200	4.2	●	--	--	FTP/TFTP	7.3.0	
Instant	5.0.3.0-1.1.0.0	●	●	●	HTTPS	7.3.0	

Dell PowerConnect W-AirWave Firmware Matrix

W-AirWave	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version
Alcatel-Lucent						
OAW-43xx OAW-4x04 OAW-6000 & APs	2.5.1.5	--	--	●	Telnet/TFTP	6.1.0
	2.5.4.26	●	--	●	Telnet/TFTP	6.1.0
	3.1.0	--	--	●	Telnet/TFTP	6.1.0
	3.1.1	--	--	●	Telnet/TFTP	6.1.0
	3.3.0	●	●	●	Telnet/TFTP	6.1.0
	3.3.1.11	●	●	●	Telnet/TFTP	6.1.0
	3.3.1.28	●	●	●	Telnet/TFTP	6.3.0
	3.3.1.31	●	●	●	Telnet/TFTP	6.4.0
	3.3.2.5	●	●	●	Telnet/TFTP	6.1.0
	3.3.2.10	●	●	●	Telnet/TFTP	6.2.0
	3.3.2.16	●	●	●	Telnet/TFTP	6.3.0
	3.3.2.21	●	●	●	Telnet/TFTP	6.4.0
	3.3.2.24	●	●	●	Telnet/TFTP	7.0.0
	3.3.3.0	●	●	●	Telnet/TFTP	6.4.0
	3.4.0.6	●	●	●	Telnet/TFTP	6.4.0
	3.4.1.0	●	●	●	Telnet/TFTP	6.4.0
	3.4.2.1	●	●	●	Telnet/TFTP	7.0.0
	3.4.3.2	●	●	●	Telnet/TFTP	7.2.0
	3.4.4.3	●	●	●	Telnet/TFTP	7.3.0
	5.0.0.0	●	●	●	Telnet/TFTP	7.0.0
	5.0.1.0	●	●	●	Telnet/TFTP	7.1.0
	5.0.2.0	●	●	●	Telnet/TFTP	7.1.0
	5.0.3.0	●	●	●	Telnet/TFTP	7.2.0
5.0.3.3	●	●	●	Telnet/TFTP	7.3.0	
OAW-43xx, OAW-6xx & APs	6.0.0.0	●	●	●	Telnet/TFTP	7.2.0
	6.0.1.2	●	●	●	Telnet/TFTP	7.3.0
	6.1.1.0	●	●	●	Telnet/TFTP	7.3.0

Dell PowerConnect W-AirWave Firmware Matrix

W-AirWave	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version
Avaya						
AP-1/AP-2	3.95	●	●	●	SNMP/TFTP	2.2.0
AP-3	2.0	●	--	●	SNMP/TFTP	2.2.0
	2.3.3	●	--	●	SNMP/TFTP	2.3.0
	2.4.0	●	●	●	SNMP/TFTP	2.5.0
	2.4.3	●	●	●	SNMP/TFTP	2.5.0
	2.4.5	●	●	●	SNMP/TFTP	2.6.0
	2.4.11	●	●	●	SNMP/TFTP	2.8.0
	2.5.2	●	●	●	SNMP/TFTP	3.1.2
	2.5.3	●	●	●	SNMP/TFTP	3.1.3
AP-4 AP-5 AP-6	2.5.5	●	●	●	SNMP/TFTP	4.1.0
	2.3.1	●	--	●	SNMP/TFTP	2.11.0
	2.3.3	●	--	●	SNMP/TFTP	2.11.0
	2.4.3	●	●	●	SNMP/TFTP	2.11.0
	2.4.5	●	●	●	SNMP/TFTP	2.11.0
	2.4.11	●	●	●	SNMP/TFTP	2.11.0
	2.5.2	●	●	●	SNMP/TFTP	3.1.2
	2.5.3	●	●	●	SNMP/TFTP	3.1.3
AP-7	2.5.5	●	●	●	SNMP/TFTP	4.1.0
	2.5.2	●	●	●	SNMP/TFTP	3.2.1
	2.6.0	●	●	●	SNMP/TFTP	3.2.1
	3.1.0	●	●	●	SNMP/TFTP	3.3.3
	3.2.0	●	●	●	SNMP/TFTP	4.2.0
	3.2.1	●	●	●	SNMP/TFTP	4.3.0
	3.4.0	●	●	●	SNMP/TFTP	4.4.1
	2.4.5	●	●	●	SNMP/TFTP	2.11.0
AP-8	2.4.11	●	●	●	SNMP/TFTP	2.11.0
	2.4.12	●	●	●	SNMP/TFTP	3.0.2
	2.5.2	●	●	●	SNMP/TFTP	3.1.2
	2.6.0	●	●	●	SNMP/TFTP	3.1.2
	3.1.0	●	●	●	SNMP/TFTP	3.3.4
	3.2.0	●	●	●	SNMP/TFTP	4.2.0
	3.2.1	●	●	●	SNMP/TFTP	4.3.0
	3.4.0	●	●	●	SNMP/TFTP	4.4.1
Bel Air						
200	main.2005.03.29	--	--	--	--	4.0.2
Cisco Pre-VxWorks						
4800	8.65.2	--	--	--	--	3.2.2
Cisco VxWorks						
340 350	11.01	--	--	--	--	2.2.0
	11.03	--	--	--	--	2.2.0
	11.06A	--	--	--	--	2.2.0
	11.07A	--	--	--	--	2.2.0
	11.08T1	--	--	--	--	2.2.0
	11.10T	--	--	--	--	2.2.0
	11.21	--	--	--	--	2.2.0
	11.23T	--	--	--	--	2.2.0
	12.01T1	--	--	--	--	2.5.0
	12.02T1	--	--	--	--	2.7.0
	12.03T	--	--	--	--	2.8.0
	12.04	--	--	--	--	2.9.0
	12.05	--	--	--	--	3.0.4
1200	11.40T	--	--	--	--	2.2.0
	11.42T	--	--	--	--	2.2.0
	11.54T	--	--	--	--	2.2.0
	11.56	--	--	--	--	2.2.0
	12.01T1	--	--	--	--	2.5.0
	12.02T1	--	--	--	--	2.7.0
	12.03T	--	--	--	--	2.8.0
	12.04	--	--	--	--	2.9.0
12.05	--	--	--	--	3.0.4	

Dell PowerConnect W-AirWave Firmware Matrix

W-AirWave	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version
Cisco IOS						
350 1100 1200	12.2(4)JA	●	●	●	Telnet/TFTP	2.4.0
	12.2(8)JA	●	●	●	Telnet/TFTP	2.4.0
	12.2(11)JA1	●	●	●	Telnet/TFTP	2.4.0
	12.2(13)JA	●	●	●	Telnet/TFTP	2.6.0
	12.2(13)JA1	●	●	●	Telnet/TFTP	2.8.0
	12.2(13)JA3	●	●	●	Telnet/TFTP	2.11.0
	12.2(13)JA4	●	●	●	Telnet/TFTP	2.11.0
	12.2(15)JA	●	●	●	Telnet/TFTP	2.11.0
	12.2(15)XR	●	●	●	Telnet/TFTP	3.0.2
	12.2(15)XR2	●	●	●	Telnet/TFTP	3.0.2
	12.3(2)JA	●	●	●	Telnet/TFTP	3.1.3
	12.3(2)JA2	●	●	●	Telnet/TFTP	3.2.0
	12.3(4)JA	●	●	●	Telnet/TFTP	3.3.0
	12.3(7)JA	●	●	●	Telnet/TFTP	3.4.2
	12.3(7)JA1	●	●	●	Telnet/TFTP	4.0.2
	12.3(7)JA2	●	●	●	Telnet/TFTP	4.0.2
	12.3(8)JA	●	●	●	Telnet/TFTP	4.2.0
	12.3(8)JA2	●	●	●	Telnet/TFTP	4.3.0
	12.3(8)JEA	●	●	●	Telnet/TFTP	4.4.0
	12.3(11)JA	●	●	●	Telnet/TFTP	4.4.3
1130 1240	12.2(13)JA	●	●	●	Telnet/TFTP	3.2.1
	12.3(2)JA	●	●	●	Telnet/TFTP	3.2.1
	12.3(4)JA	●	●	●	Telnet/TFTP	3.3.0
	12.3(7)JA	●	●	●	Telnet/TFTP	3.4.2
	12.3(7)JA1	●	●	●	Telnet/TFTP	4.0.2
	12.3(7)JA2	●	●	●	Telnet/TFTP	4.0.2
	12.3(8)JA	●	●	●	Telnet/TFTP	4.2.0
	12.3(8)JA2	●	●	●	Telnet/TFTP	4.3.0
	12.3(8)JEA	●	●	●	Telnet/TFTP	4.4.0
	12.3(11)JEA	●	●	●	Telnet/TFTP	4.4.1
	12.4(3g)JA	●	●	●	Telnet/TFTP	5.2.5
	12.4(10b)JA	●	●	●	Telnet/TFTP	5.3.0
	12.4(10b)JDA	●	●	●	Telnet/SSH/TFTP/SCP	6.2.0
	12.4(10b)JDA3	●	●	●	Telnet/SSH/TFTP/SCP	6.4.0
	12.4(21a)JA1	●	●	●	Telnet/SSH/TFTP/SCP	6.4.0
1300	12.3(2)JA2	●	●	●	Telnet/TFTP	3.4.0
	12.3(4)JA	●	●	●	Telnet/TFTP	3.4.0
	12.3(7)JA	●	●	●	Telnet/TFTP	3.4.2
	12.3(7)JA1	●	●	●	Telnet/TFTP	4.0.2
	12.3(7)JA2	●	●	●	Telnet/TFTP	4.0.2
	12.3(8)JA	●	●	●	Telnet/TFTP	4.2.0
	12.3(8)JA2	●	●	●	Telnet/TFTP	4.3.0
	12.3(8)JEA	●	●	●	Telnet/TFTP	4.4.0
	12.4(3g)JA	●	●	●	Telnet/TFTP	5.2.5
	12.4(10b)JA	●	●	●	Telnet/TFTP	5.3.0
	12.4(10b)JDA	●	●	●	Telnet/SSH/TFTP/SCP	6.2.0
	12.4(10b)JDA3	●	●	●	Telnet/SSH/TFTP/SCP	6.4.0
1250	12.4(10b)JA	●	●	●	Telnet/TFTP	5.3.0
	12.4(10b)JDA	●	●	●	Telnet/SSH/TFTP/SCP	6.2.0
	12.4(10b)JDA3	●	●	●	Telnet/SSH/TFTP/SCP	6.4.0
	12.4(21a)JA1	●	●	●	Telnet/SSH/TFTP/SCP	6.4.0
1400	12.4(10b)JA3	●	●	●	Telnet/SSH/TFTP/SCP	6.0.0
	12.4(10b)JDA	●	●	●	Telnet/SSH/TFTP/SCP	6.2.0
	12.4(10b)JDA3	●	●	●	Telnet/SSH/TFTP/SCP	6.4.0
	12.4(21a)JA1	●	●	●	Telnet/SSH/TFTP/SCP	6.4.0
1140	12.4(21a)JA1	●	●	●	Telnet/SSH/TFTP/SCP	7.0.0
871w	12.4(4)T7	--	--	●	Telnet/SSH/TFTP/SCP	6.2.0

Dell PowerConnect W-AirWave Firmware Matrix

W-AirWave	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version	
Cisco WLC							
WLC 4012, 4100, 4400	2.2.127.4	●	--	●	--	3.2.4	
	3.1.111.0	●	--	●	--	4.0.2	
	3.2.78.0	●	--	●	--	4.2.3	
LWAPP 10x0, 1130, 1200	3.2.116.21	●	--	●	--	4.2.3	
	3.2.195.10	●	--	●	--	5.1.0	
	2.2.127.4	●	--	●	--	4.0.1	
WLC/IWLC 4400, 2x00, 5500	3.1.111.0	●	--	●	--	4.0.2	
	3.2.116.21	●	--	●	--	4.2.3	
	4.0.155.0	●	--	●	--	4.4.0	
	4.0.179.x	●	--	●	--	4.4.0	
	4.0.206.0	●	--	●	--	5.1.0	
	4.0.217.0	●	--	●	--	5.1.0	
	4.1.171.0	●	--	●	--	5.1.0	
	4.1.181.0	●	--	●	--	5.2.4	
	4.1.185.0	●	--	●	--	5.3.0	
	4.2.61.0	●	--	●	--	5.3.0	
	4.2.99.0	●	--	●	--	6.0.0	
	LWAPP 1130, 1140, 1240 1250, 1300, 1500	4.2.130.0	●	--	●	--	6.1.0
		4.2.207.0	●	--	●	--	7.0.0
		5.0.148.0	●	--	●	--	6.0.0
		5.1.151.0	●	--	●	--	6.2.0
		5.2.157.0	●	--	●	--	6.2.0
		5.2.178.0	●	--	●	--	6.3.0
		5.2.193.0	●	--	●	--	6.4.0
		6.0.182.0	●	--	●	--	6.4.0
	6.0.196.0	●	--	●	--	7.0.0	
7.0.98.0	●	--	●	--	7.1.0		
7.0.116.0	●	--	●	--	7.3.0		
Enterasys							
Roamabout 3000	1.3.1	--	--	--	--	3.0.4	
	2.1.0	--	--	--	--	3.0.4	
	2.1.1	--	--	--	--	3.0.4	
	2.1.2	--	--	--	--	3.0.4	
	2.6.6	--	--	--	--	3.0.5	
	3.1.0	--	--	--	--	3.3.1	
	3.1.20	--	--	--	--	4.3.0	
3.1.24	--	--	--	--	4.4.0		
Roamabout 4102	1.3.1	--	--	--	--	3.0.4	
	1.01.25	--	--	--	--	4.3.0	
	1.01.32	--	--	--	--	4.4.0	
RBT-8XX0 and APs	5.0.12.5	--	--	--	--	5.1.0	
	5.0.12.5	●	●	●	Telnet/TFTP/FTP	5.3.0	
Foundry							
IronPoint 200	2.01	--	--	--	SNMP	6.1.0	
	2.02	--	--	--	SNMP	6.1.0	
IronPoint 250	3.0	--	--	--	SNMP	6.2.0	
	3.1	--	--	--	SNMP	6.2.0	
	3.2	--	--	--	SNMP	6.2.0	
Hirschmann							
BAT-54	7.00.0070	--	--	--	--	5.0.0	
	7.10.0022	--	--	--	--	5.3.0	
	7.60.0165	--	--	--	--	7.0.0	
Intermec							
2100 / 2101 / 2102	1.94	--	--	●	SNMP/TFTP	4.0.2	
2106	1.90	--	--	●	SNMP/TFTP	4.0.2	
WA 21 / WA 22	2.30	--	--	●	SNMP/TFTP	4.0.2	
Juniper Netscreen							
Netscreen 5GT	5.0.0	--	--	●	SNMP/TFTP	3.4.2	
LANCOM							
L-54g L-54ag OAP-54 Lancom 3550	4.02.0003	--	--	--	--	3.2.4	
	5.02.0012	--	--	--	--	3.2.4	
	5.02.0018	--	--	--	--	3.2.4	
	5.02.0020	--	--	--	--	3.4.0	
	6.02.0008	--	--	--	--	4.2.0	
	6.10.0038	--	--	--	--	4.3.0	
	7.00.0070	--	--	--	--	5.0.0	
	7.22.0016	--	--	--	--	5.3.0	
7.26.0049	--	--	--	--	5.3.0		

Dell PowerConnect W-AirWave Firmware Matrix

W-AirWave	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version
Meru						
MC1000 & APs	3.3-118	--	--	--	--	5.1.0
	3.4.SR5-21	--	--	--	--	5.3.0
	3.5.Beta-29	--	--	--	--	6.0.0
	3.6	--	--	--	--	6.1.0
	3.6-124	--	--	--	--	6.3.0
	3.6-127	--	--	--	--	6.3.0
	3.6-270	--	--	--	--	6.4.0
	3.6.1-49	--	--	--	--	7.0.0
Nomadix						
HSG	2.3.234	--	--	--	--	3.1.1
	2.4.31	--	--	--	--	3.1.2
AG 2000	1.3.211	--	--	--	--	3.3.1
	1.4.129	--	--	--	--	4.0.2
AG 2100	11.4.138	--	--	--	--	4.0.2
AG 3000	21.4.139	--	--	--	--	4.0.2
AG 5000	5.4.113	--	--	--	--	4.0.2
Nortel						
WSS23x0 & APs	5.0.11.4	--	--	--	--	5.1.0
	5.0.11.4	●	●	●	Telnet/TFTP/FTP	5.3.0
	6.0.3.2	--	--	--	--	5.3.0
	6.0.3.2	●	●	●	Telnet/TFTP/FTP	5.3.0
	7.0.5.6	●	●	●	Telnet/TFTP/FTP	6.4.0
ProCurve Networking by HP						
420	2.0.38	--	--	--	--	3.0.5
	2.0.39	--	--	--	--	3.0.6
	2.1.0	--	--	--	--	3.3.2
	2.1.3	--	--	--	--	3.3.2
	2.1.5	--	--	--	--	4.3.0
	2.1.7	--	--	--	--	4.5.0
	2.2.0	--	--	--	--	5.1.6
	2.2.5	--	--	--	--	6.3.0
DWL-520	2.0	●	--	●	SNMP/TFTP	2.2.0
	2.3.3	●	--	●	SNMP/TFTP	2.3.0
	2.4.0	●	●	●	SNMP/TFTP	2.5.0
	2.4.3	●	●	●	SNMP/TFTP	2.5.0
	2.4.5	●	●	●	SNMP/TFTP	2.6.0
	2.5.2	●	●	●	SNMP/TFTP	3.1.2
530	WA.01.16	--	--	--	--	4.3.0
	WA.01.16	--	--	--	--	5.0.0
	WA.01.19	--	--	--	--	5.0.0
	WA.02.10	--	--	--	--	6.0.0
	WA.02.19	--	--	--	--	6.1.0
xl WESM & APs	WS.01.05	--	--	●	Telnet/TFTP	4.4.0
	WS.02.01	--	--	●	Telnet/TFTP	5.2.5
	WS.02.07	●	●	●	Telnet/SSH/TFTP	5.3.0
zl WESM & APs	WT.01.03	--	--	●	Telnet/SSH/TFTP	5.3.0
	WT.01.15	●	●	●	Telnet/SSH/TFTP	7.0.0
	WT.01.28	●	●	●	Telnet/SSH/TFTP	7.0.0
MSM7xx & APs	5.3.1.8-01-7189	--	--	--	--	6.4.0

Dell PowerConnect W-AirWave Firmware Matrix

W-AirWave	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version
Proxim						
AP 600	2.3.1	●	--	●	SNMP/TFTP	2.2.0
	2.3.3	●	--	●	SNMP/TFTP	2.3.0
	2.4.3	●	●	●	SNMP/TFTP	2.5.0
	2.4.5	●	●	●	SNMP/TFTP	2.6.0
	2.4.11	●	●	●	SNMP/TFTP	2.8.0
	2.5.2	●	●	●	SNMP/TFTP	3.1.2
	2.5.3	●	●	●	SNMP/TFTP	3.1.2
	2.5.4	●	●	●	SNMP/TFTP	4.1.0
AP 700	2.5.5	●	●	●	SNMP/TFTP	3.3.1
	2.5.2	●	●	●	SNMP/TFTP	3.2.1
	2.6.0	●	●	●	SNMP/TFTP	3.2.1
	3.1.0	●	●	●	SNMP/TFTP	3.4.2
	3.2.0	●	●	●	SNMP/TFTP	4.2.0
	3.2.1	●	●	●	SNMP/TFTP	4.3.4
	3.4.0	●	●	●	SNMP/TFTP	4.4.1
	3.6.2	●	●	●	SNMP/TFTP	5.3.0
AP 2000	3.7.0	●	●	●	SNMP/TFTP	6.1.0
	4.0.1	●	●	●	SNMP/TFTP	6.2.0
	4.0.2	●	●	●	SNMP/TFTP	6.3.0
	2.0	●	--	●	SNMP/TFTP	2.2.0
	2.3.3	●	--	●	--	2.3.0
	2.4.0	●	●	●	SNMP/TFTP	2.5.0
	2.4.3	●	●	●	SNMP/TFTP	2.5.0
	2.4.5	●	●	●	SNMP/TFTP	2.6.0
AP 4000	2.4.11	●	●	●	SNMP/TFTP	2.8.0
	2.5.2	●	●	●	SNMP/TFTP	3.1.2
	2.5.3	●	●	●	SNMP/TFTP	3.1.3
	2.5.4	●	●	●	SNMP/TFTP	3.3.1
	2.5.5	●	●	●	SNMP/TFTP	4.1.0
	2.4.5	●	●	●	SNMP/TFTP	2.11.0
	2.4.11	●	●	●	SNMP/TFTP	2.11.0
	2.4.12	●	●	●	SNMP/TFTP	3.0.2
AP 4000M AP 4900M	2.5.2	●	●	●	SNMP/TFTP	3.1.2
	2.6.0	●	●	●	SNMP/TFTP	3.1.3
	3.1.0	●	●	●	SNMP/TFTP	3.4.2
	3.2.0	●	●	●	SNMP/TFTP	4.2.0
	3.2.1	●	●	●	SNMP/TFTP	4.3.4
	3.4.0	●	●	●	SNMP/TFTP	4.4.1
	3.6.2	●	●	●	SNMP/TFTP	5.3.0
	3.7.0	●	●	●	SNMP/TFTP	6.1.0
Tsunami MP.11a	4.0.0	●	●	●	SNMP/TFTP	6.2.0
	4.0.2	●	●	●	SNMP/TFTP	6.3.0
	3.2.0	●	●	●	SNMP/TFTP	4.3.4
	3.2.1	●	●	●	SNMP/TFTP	4.3.4
	3.4.0	●	●	●	SNMP/TFTP	4.4.1
	3.6.2	●	●	●	SNMP/TFTP	5.3.0
Tsunami MP.11 5054,4954, 954, 2454, 5012	3.7.0	●	●	●	SNMP/TFTP	6.1.0
	4.0.0	●	●	●	SNMP/TFTP	6.2.0
	4.0.2	●	●	●	SNMP/TFTP	6.3.0
	2.0.1	●	●	●	SNMP/TFTP	3.2.4
Tsunami MP.11a	2.2.0	●	●	●	SNMP/TFTP	3.2.4
	2.2.2	●	●	●	SNMP/TFTP	3.2.4
	2.2.6	●	●	●	SNMP/TFTP	3.4.2
Tsunami MP.11 5054,4954, 954, 2454, 5012	2.3.0	●	●	●	SNMP/TFTP	5.2.0
	4.0.0	●	●	●	SNMP/TFTP	5.2.0

Dell PowerConnect W-AirWave Firmware Matrix

W-AirWave	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version
Symbol						
3021	04.01-23	●	●	●	SNMP/TFTP	4.0.1
	04.02-19	●	●	●	SNMP/TFTP	4.0.1
4121	3.52.13	●	--	●	SNMP/TFTP	2.2.0
	2.70.06	●	●	●	SNMP/TFTP	2.2.0
4131	3.51-20	●	--	●	SNMP/TFTP	2.2.0
	3.70-72	●	●	●	SNMP/TFTP	3.0.4
	3.92-29	●	●	●	SNMP/TFTP	3.0.7
	3.93-00	●	●	●	SNMP/TFTP	3.4.2
	3.94-15	●	●	●	SNMP/TFTP	4.3.0
	3.95-04	●	●	●	SNMP/TFTP	7.3.0
5131	1.1.0.0.045R	--	--	--	--	5.2.1
	1.1.0.0.045R	--	--	●	Telnet/TFTP	5.2.4
	2.0.0	●	●	●	Telnet/TFTP	6.1.0
	2.1.0	●	●	●	Telnet/TFTP	6.2.0
	2.2.0	●	●	●	Telnet/TFTP	6.3.0
	2.3.1.0	●	●	●	Telnet/TFTP	7.0.0
	2.4.1.0	●	●	●	Telnet/TFTP/FTP	7.1.0
7131	2.5.0.0	●	●	●	Telnet/TFTP/FTP	7.1.0
	3.2.2	●	●	●	Telnet/TFTP/FTP	7.1.0
	4.0.3	●	●	●	Telnet/TFTP/FTP	7.1.0
	4.1.0	●	●	●	Telnet/TFTP/FTP	7.1.0
5181	4.1.2	●	●	●	Telnet/TFTP/FTP	7.1.0
	1.1.2	●	●	●	Telnet/TFTP	6.2.0
WS5000 & APs	0.0-35R	--	--	--	--	4.3.0
	2.0.0	--	--	--	--	4.4.0
WS2000 & APs	0.0-35R	--	--	●	Telnet/TFTP	5.0.0
	2.2.3.0-020R	--	--	●	Telnet/TFTP	6.0.0
	2.2.3.0-020R	●	--	●	Telnet/TFTP	6.1.0
	2.3.2.0-003R	●	--	●	Telnet/TFTP	6.3.0
	2.4.0.0-023R	●	--	●	Telnet/TFTP	6.3.0
	2.4.1.0-005R	●	--	●	Telnet/TFTP	6.4.0
	2.4.4.0-001R	●	--	●	Telnet/TFTP	7.1.0
WS5100 & APs	2.4.5	●	--	●	Telnet/TFTP	7.3.0
	2.0.0	--	--	--	--	4.4.0
	3.0.0	--	--	●	Telnet/TFTP	5.0.0
	3.0.2	●	●	●	Telnet/TFTP	5.3.0
	3.0.3	●	●	●	Telnet/TFTP	5.3.0
	3.0.3	●	●	●	Telnet/SSH/TFTP	6.0.0
	3.1.0	●	●	●	Telnet/SSH/TFTP	6.1.0
	3.2.0	●	●	●	Telnet/SSH/TFTP	6.1.0
	3.3.1	●	●	●	Telnet/SSH/TFTP/FTP	6.3.0
	3.3.3	●	●	●	Telnet/SSH/TFTP/FTP	7.1.0
RFSx000 & APs	3.3.4	●	●	●	Telnet/SSH/TFTP/FTP	7.3.0
	1.0.0.0	●	--	●	Telnet/SSH/TFTP	6.0.0
	1.2.0.0	●	●	●	Telnet/SSH/TFTP/FTP	6.3.0
	3.2.0	●	●	●	Telnet/SSH/TFTP	6.2.0
	4.0.0.0	●	●	●	Telnet/SSH/TFTP/FTP	6.3.0
	4.1.0.0	●	●	●	Telnet/SSH/TFTP/FTP	7.1.0
	4.1.0.1	●	●	●	Telnet/SSH/TFTP/FTP	7.3.0
	4.2.1.0	●	●	●	Telnet/SSH/TFTP/FTP	7.1.0
Systemax	4.3.0.0	●	●	●	Telnet/SSH/TFTP/FTP	7.1.0
	4.3.3	●	●	●	Telnet/SSH/TFTP/FTP	7.3.0
Airspeed 542	2.4.5	●	●	●	SNMP/TFTP	3.2.0
	2.4.11	●	●	●	SNMP/TFTP	3.2.0
	2.4.12	●	●	●	SNMP/TFTP	3.2.0
	2.5.2	●	●	●	SNMP/TFTP	3.2.0
	2.6.0	●	●	●	SNMP/TFTP	3.2.0
Teklogix						
9150/9160	C234p	--	--	●	--	4.4.0

Dell PowerConnect W-AirWave Firmware Matrix

W-AirWave	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version
Trapeze						
MX Series & MPs	5.0.12.2	--	--	--	--	5.1.0
	5.0.12.2	●	●	●	Telnet/TFTP/FTP	5.3.0
	6.0.2.2	--	--	--	--	5.1.0
	6.0.2.2	●	●	●	Telnet/TFTP/FTP	5.3.0
	6.0.4.2	●	●	●	Telnet/TFTP/FTP	5.3.0
	7.0.5.6	●	●	●	Telnet/TFTP/FTP	6.4.0
Tropos						
4/5210, 5320, 9422, 9532	5.1.4.7	--	--	--	--	5.0.0
3/4/5210, 5320, 9422, 9532	5.1.4.7	--	--	--	--	5.3.0
	6.5.1.3	--	--	--	--	5.3.0
	6.6.0.0	--	--	--	--	5.3.0
	6.6.1.3	--	--	--	--	6.2.0
Vivato						
VP1200	1.3.1.r4	--	--	--	--	3.3.2
VA2200	1.1.r2	--	--	--	--	3.3.1
	2.2	--	--	--	--	3.4.2
VP2200	3.0.r9	--	--	--	--	5.2.4

© 2011 Aruba Networks, Inc. Aruba Networks trademarks include AirWave, Aruba Networks®, Aruba Wireless Networks®, the registered Aruba the Mobile Edge Company logo, and Aruba Mobility Management System®. Dell™, the DELL™ logo, and PowerConnect™ are trademarks of Dell Inc. All rights reserved. Specifications in this manual are subject to change without notice. Originated in the USA. All other trademarks are the property of their respective owners.