

## Dell PowerConnect W-AirWave Wireless Management Suite Firmware Matrix

W-AirWave Wireless Management Suite	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version
<b>Dell PowerConnect</b>						
W Series: W-620, W-650, W-651 W-3200, W-3400, W-3600	5.0.1.0	●	--	●	Telnet/TFTP	7.1.0
W-AP92, W-AP93 W-AP105 W-AP124, W-AP125	5.0.3.0	●	●	●	Telnet/TFTP	7.1.0
	6.0.0.0	●	●	●	Telnet/TFTP	7.2.0
<b>3Com</b>						
WX Series and APs	6.0.3.2	--	--	--	--	5.1.0
	6.0.3.2	●	●	●	Telnet/TFTP/FTP	5.3.0
	7.0.5.6	●	●	●	Telnet/TFTP/FTP	6.4.0
<b>Aruba</b>						
200, 800, 6xx, 2400, 3x00, 5000, 6000 & APs	2.5.1.5	--	--	--	--	4.3.0
	2.5.1.5	--	--	●	Telnet/TFTP	4.4.0
	2.5.4.26	●	--	●	Telnet/TFTP	4.4.0
	3.1.0	--	--	●	Telnet/TFTP	5.1.0
	3.1.1	--	--	●	Telnet/TFTP	5.2.4
	3.3.0	--	--	●	Telnet/TFTP	5.3.0
	3.3.0	●	●	●	Telnet/TFTP	6.0.0
	3.3.1.11	●	●	●	Telnet/TFTP	6.1.0
	3.3.1.28	●	●	●	Telnet/TFTP	6.3.0
	3.3.1.31	●	●	●	Telnet/TFTP	6.4.0
	3.3.2.5	●	●	●	Telnet/TFTP	6.1.0
	3.3.2.10	●	●	●	Telnet/TFTP	6.2.0
	3.3.2.16	●	●	●	Telnet/TFTP	6.3.0
	3.3.2.21	●	●	●	Telnet/TFTP	6.4.0
	3.3.2.24	●	●	●	Telnet/TFTP	7.0.0
	3.3.3.0	●	●	●	Telnet/TFTP	6.4.0
	3.4.0.0	●	●	●	Telnet/TFTP	6.3.0
	3.4.0.6	●	●	●	Telnet/TFTP	6.4.0
	3.4.1.0	●	●	●	Telnet/TFTP	6.4.0
	3.4.2.1	●	●	●	Telnet/TFTP	7.0.0
	3.4.3.0	●	●	●	Telnet/TFTP	7.1.0
	3.4.3.2	●	●	●	Telnet/TFTP	7.2.0
	5.0.0.0	●	●	●	Telnet/TFTP	7.0.0
	5.0.1.0	●	●	●	Telnet/TFTP	7.1.0
	5.0.2.0	●	●	●	Telnet/TFTP	7.1.0
	5.0.3.0	●	●	●	Telnet/TFTP	7.2.0
3x00, RAP-5WN,RAP-2WG	3.3.2.10-rn-3.0.0	●	●	●	Telnet/TFTP	6.2.0
	3.3.2.14-rn-3.1.0	●	●	●	Telnet/TFTP	6.3.0
	3.3.2.18-rn-3.1.3	●	●	●	Telnet/TFTP	6.4.0
	3.3.2.24-rn-3.1.7	●	●	●	Telnet/TFTP	7.0.0
	3.3.2.24-rn-3.1.12	●	●	●	Telnet/TFTP	7.1.0
6xx, 3x00 & APs		6.0.0.0	●	●	Telnet/TFTP	7.1.0
		6.0.0.1	●	●	Telnet/TFTP	7.2.0
<b>Alcatel-Lucent</b>						
OAW-43xx OAW-4x04 OAW-6000 & APs	2.5.1.5	--	--	●	Telnet/TFTP	6.1.0
	2.5.4.26	●	--	●	Telnet/TFTP	6.1.0
	3.1.0	--	--	●	Telnet/TFTP	6.1.0
	3.1.1	--	--	●	Telnet/TFTP	6.1.0
	3.3.0	●	●	●	Telnet/TFTP	6.1.0
	3.3.1.11	●	●	●	Telnet/TFTP	6.1.0
	3.3.1.28	●	●	●	Telnet/TFTP	6.3.0
	3.3.1.31	●	●	●	Telnet/TFTP	6.4.0
	3.3.2.5	●	●	●	Telnet/TFTP	6.1.0
	3.3.2.10	●	●	●	Telnet/TFTP	6.2.0
	3.3.2.16	●	●	●	Telnet/TFTP	6.3.0
	3.3.2.21	●	●	●	Telnet/TFTP	6.4.0
	3.3.2.24	●	●	●	Telnet/TFTP	7.0.0
	3.3.3.0	●	●	●	Telnet/TFTP	6.4.0
	3.4.0.6	●	●	●	Telnet/TFTP	6.4.0
	3.4.1.0	●	●	●	Telnet/TFTP	6.4.0
	3.4.2.1	●	●	●	Telnet/TFTP	7.0.0
	3.4.3.2	●	●	●	Telnet/TFTP	7.2.0
	5.0.0.0	●	●	●	Telnet/TFTP	7.0.0
	5.0.1.0	●	●	●	Telnet/TFTP	7.1.0
	5.0.2.0	●	●	●	Telnet/TFTP	7.1.0
	5.0.3.0	●	●	●	Telnet/TFTP	7.2.0
OAW-43/6xx & APs	6.0.0.0	●	●	●	Telnet/TFTP	7.2.0

## Dell PowerConnect W-AirWave Wireless Management Suite Firmware Matrix

W-AirWave Wireless Management Suite	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version
<b>Avaya</b>						
AP-1/AP-2	3.95	●	●	●	SNMP/TFTP	2.2.0
	2.0	●	--	●	SNMP/TFTP	2.2.0
	2.3.3	●	--	●	SNMP/TFTP	2.3.0
	2.4.0	●	●	●	SNMP/TFTP	2.5.0
	2.4.3	●	●	●	SNMP/TFTP	2.5.0
	2.4.5	●	●	●	SNMP/TFTP	2.6.0
	2.4.11	●	●	●	SNMP/TFTP	2.8.0
	2.5.2	●	●	●	SNMP/TFTP	3.1.2
	2.5.3	●	●	●	SNMP/TFTP	3.1.3
	2.5.5	●	●	●	SNMP/TFTP	4.1.0
AP-3	2.3.1	●	--	●	SNMP/TFTP	2.11.0
	2.3.3	●	--	●	SNMP/TFTP	2.11.0
	2.4.3	●	●	●	SNMP/TFTP	2.11.0
	2.4.5	●	●	●	SNMP/TFTP	2.11.0
	2.4.11	●	●	●	SNMP/TFTP	2.11.0
AP-4	2.5.2	●	●	●	SNMP/TFTP	3.1.2
	2.5.3	●	●	●	SNMP/TFTP	3.1.3
	2.5.5	●	●	●	SNMP/TFTP	4.1.0
	2.6.0	●	●	●	SNMP/TFTP	3.2.1
	3.1.0	●	●	●	SNMP/TFTP	3.3.3
AP-5	3.2.0	●	●	●	SNMP/TFTP	4.2.0
	3.2.1	●	●	●	SNMP/TFTP	4.3.0
	3.4.0	●	●	●	SNMP/TFTP	4.4.1
	2.4.5	●	●	●	SNMP/TFTP	2.11.0
	2.4.11	●	●	●	SNMP/TFTP	2.11.0
AP-6	2.4.12	●	●	●	SNMP/TFTP	3.0.2
	2.5.2	●	●	●	SNMP/TFTP	3.1.2
	2.6.0	●	●	●	SNMP/TFTP	3.1.2
	3.1.0	●	●	●	SNMP/TFTP	3.3.4
	3.2.0	●	●	●	SNMP/TFTP	4.2.0
AP-7	3.2.1	●	●	●	SNMP/TFTP	4.3.0
	3.4.0	●	●	●	SNMP/TFTP	4.4.1
	2.5.2	●	●	●	SNMP/TFTP	3.2.1
	2.6.0	●	●	●	SNMP/TFTP	3.2.1
	3.1.0	●	●	●	SNMP/TFTP	3.3.3
AP-8	3.2.0	●	●	●	SNMP/TFTP	4.2.0
	3.2.1	●	●	●	SNMP/TFTP	4.3.0
	3.4.0	●	●	●	SNMP/TFTP	4.4.1
	2.4.5	●	●	●	SNMP/TFTP	2.11.0
	2.4.11	●	●	●	SNMP/TFTP	2.11.0
<b>Bel Air</b>						
200	main.2005.03.29	--	--	--	--	4.0.2
<b>Cisco Pre-VxWorks</b>						
4800	8.65.2	--	--	--	--	3.2.2
<b>Cisco VxWorks</b>						
340	11.01	●	--	●	SNMP/TFTP	2.2.0
	11.03	●	--	●	SNMP/TFTP	2.2.0
	11.06A	●	--	●	SNMP/TFTP	2.2.0
	11.07A	●	--	●	SNMP/TFTP	2.2.0
	11.08T1	●	--	●	SNMP/TFTP	2.2.0
	11.10T	●	--	●	SNMP/TFTP	2.2.0
	11.21	●	●	●	SNMP/TFTP	2.2.0
	11.23T	●	●	●	SNMP/TFTP	2.2.0
	12.01T1	●	●	●	SNMP/TFTP	2.5.0
	12.02T1	●	●	●	SNMP/TFTP	2.7.0
350	12.03T	●	●	●	SNMP/TFTP	2.8.0
	12.04	●	●	●	SNMP/TFTP	2.9.0
	12.05	●	●	●	SNMP/TFTP	3.0.4
	11.40T	●	--	●	SNMP/TFTP	2.2.0
	11.42T	●	--	●	SNMP/TFTP	2.2.0
1200	11.54T	●	--	●	SNMP/TFTP	2.2.0
	11.56	●	●	●	SNMP/TFTP	2.2.0
	12.01T1	●	●	●	SNMP/TFTP	2.5.0
	12.02T1	●	●	●	SNMP/TFTP	2.7.0
	12.03T	●	●	●	SNMP/TFTP	2.8.0
	12.04	●	●	●	SNMP/TFTP	2.9.0
	12.05	●	●	●	SNMP/TFTP	3.0.4

## Dell PowerConnect W-AirWave Wireless Management Suite Firmware Matrix

W-AirWave Wireless Management Suite	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version
<b>Cisco IOS</b>						
350	12.2(4)JA	●	●	●	Telnet/TFTP	2.4.0
1100	12.2(8)JA	●	●	●	Telnet/TFTP	2.4.0
1200	12.2(11)JA1	●	●	●	Telnet/TFTP	2.4.0
	12.2(13)JA	●	●	●	Telnet/TFTP	2.6.0
	12.2(13)JA1	●	●	●	Telnet/TFTP	2.8.0
	12.2(13)JA3	●	●	●	Telnet/TFTP	2.11.0
	12.2(13)JA4	●	●	●	Telnet/TFTP	2.11.0
	12.2(15)JA	●	●	●	Telnet/TFTP	2.11.0
	12.2(15)XR	●	●	●	Telnet/TFTP	3.0.2
	12.2(15)XR2	●	●	●	Telnet/TFTP	3.0.2
	12.3(2)JA	●	●	●	Telnet/TFTP	3.1.3
	12.3(2)JA2	●	●	●	Telnet/TFTP	3.2.0
	12.3(4)JA	●	●	●	Telnet/TFTP	3.3.0
	12.3(7)JA	●	●	●	Telnet/TFTP	3.4.2
	12.3(7)JA1	●	●	●	Telnet/TFTP	4.0.2
	12.3(7)JA2	●	●	●	Telnet/TFTP	4.0.2
	12.3(8)JA	●	●	●	Telnet/TFTP	4.2.0
	12.3(8)JA2	●	●	●	Telnet/TFTP	4.3.0
	12.3(8)JEA	●	●	●	Telnet/TFTP	4.4.0
	12.3(11)JA	●	●	●	Telnet/TFTP	4.4.3
1130	12.2(13)JA	●	●	●	Telnet/TFTP	3.2.1
1240	12.3(2)JA	●	●	●	Telnet/TFTP	3.2.1
	12.3(4)JA	●	●	●	Telnet/TFTP	3.3.0
	12.3(7)JA	●	●	●	Telnet/TFTP	3.4.2
	12.3(7)JA1	●	●	●	Telnet/TFTP	4.0.2
	12.3(7)JA2	●	●	●	Telnet/TFTP	4.0.2
	12.3(8)JA	●	●	●	Telnet/TFTP	4.2.0
	12.3(8)JA2	●	●	●	Telnet/TFTP	4.3.0
	12.3(8)JEA	●	●	●	Telnet/TFTP	4.4.0
	12.3(11)JEA	●	●	●	Telnet/TFTP	4.4.1
	12.4(3g)JA	●	●	●	Telnet/TFTP	5.2.5
	12.4(10b)JA	●	●	●	Telnet/TFTP	5.3.0
	12.4(10b)JDA	●	●	●	Telnet/SSH/TFTP/SCP	6.2.0
	12.4(10b)JDA3	●	●	●	Telnet/SSH/TFTP/SCP	6.4.0
	12.4(21a)JA1	●	●	●	Telnet/SSH/TFTP/SCP	6.4.0
1300	12.3(2)JA2	●	●	●	Telnet/TFTP	3.4.0
	12.3(4)JA	●	●	●	Telnet/TFTP	3.4.0
	12.3(7)JA	●	●	●	Telnet/TFTP	3.4.2
	12.3(7)JA1	●	●	●	Telnet/TFTP	4.0.2
	12.3(7)JA2	●	●	●	Telnet/TFTP	4.0.2
	12.3(8)JA	●	●	●	Telnet/TFTP	4.2.0
	12.3(8)JA2	●	●	●	Telnet/TFTP	4.3.0
	12.3(8)JEA	●	●	●	Telnet/TFTP	4.4.0
	12.4(3g)JA	●	●	●	Telnet/TFTP	5.2.5
	12.4(10b)JA	●	●	●	Telnet/TFTP	5.3.0
	12.4(10b)JDA	●	●	●	Telnet/SSH/TFTP/SCP	6.2.0
	12.4(10b)JDA3	●	●	●	Telnet/SSH/TFTP/SCP	6.4.0
	12.4(21a)JA1	●	●	●	Telnet/SSH/TFTP/SCP	6.4.0
1250	12.4(10b)JA	●	●	●	Telnet/TFTP	5.3.0
	12.4(10b)JDA	●	●	●	Telnet/SSH/TFTP/SCP	6.2.0
	12.4(10b)JDA3	●	●	●	Telnet/SSH/TFTP/SCP	6.4.0
	12.4(21a)JA1	●	●	●	Telnet/SSH/TFTP/SCP	6.4.0
1400	12.4(10b)JA3	●	●	●	Telnet/SSH/TFTP/SCP	6.0.0
	12.4(10b)JDA	●	●	●	Telnet/SSH/TFTP/SCP	6.2.0
	12.4(10b)JDA3	●	●	●	Telnet/SSH/TFTP/SCP	6.4.0
	12.4(21a)JA1	●	●	●	Telnet/SSH/TFTP/SCP	6.4.0
1140	12.4(21a)JA1	●	●	●	Telnet/SSH/TFTP/SCP	7.0.0
871w	12.4(4)T7	--	--	●	Telnet/SSH/TFTP/SCP	6.2.0

## Dell PowerConnect W-AirWave Wireless Management Suite Firmware Matrix

W-AirWave Wireless Management Suite	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version
<b>Cisco WLC</b>						
WLC 4012, 4100, 4400	2.2.127.4	●	--	●	--	3.2.4
LWAPP 10x0, 1130, 1200	3.1.111.0	●	--	●	--	4.0.2
	3.2.78.0	●	--	●	--	4.2.3
	3.2.116.21	●	--	●	--	4.2.3
	3.2.195.10	●	--	●	--	5.1.0
WLC/IWLC 4400, 2x00, 5500	2.2.127.4	●	--	●	--	4.0.1
	3.1.111.0	●	--	●	--	4.0.2
	3.2.116.21	●	--	●	--	4.2.3
	4.0.155.0	●	--	●	--	4.4.0
	4.0.179.x	●	--	●	--	4.4.0
	4.0.206.0	●	--	●	--	5.1.0
	4.0.217.0	●	--	●	--	5.1.0
	4.1.171.0	●	--	●	--	5.1.0
	4.1.181.0	●	--	●	--	5.2.4
	4.1.185.0	●	--	●	--	5.3.0
	4.2.61.0	●	--	●	--	5.3.0
LWAPP 1130, 1140, 1240 1250, 1300, 1500	4.2.99.0	●	--	●	--	6.0.0
	4.2.130.0	●	--	●	--	6.1.0
	4.2.207.0	●	--	●	--	7.0.0
	5.0.148.0	●	--	●	--	6.0.0
	5.1.151.0	●	--	●	--	6.2.0
	5.2.157.0	●	--	●	--	6.2.0
	5.2.178.0	●	--	●	--	6.3.0
	5.2.193.0	●	--	●	--	6.4.0
	6.0.182.0	●	--	●	--	6.4.0
	6.0.196.0	●	--	●	--	7.0.0
	7.0.98.0	●	--	●	--	7.1.0
<b>Enterasys</b>						
Roamabout 3000	1.3.1	●	●	●	SNMP/TFTP	3.0.4
	2.1.0	●	●	●	SNMP/TFTP	3.0.4
	2.1.1	●	●	●	SNMP/TFTP	3.0.4
	2.1.2	●	●	●	SNMP/TFTP	3.0.4
	2.6.6	●	●	●	SNMP/TFTP	3.0.5
	3.1.0	●	●	●	SNMP/TFTP	3.3.1
	3.1.20	●	●	●	SNMP/TFTP	4.3.0
	3.1.24	●	●	●	SNMP/TFTP	4.4.0
	1.3.1	●	●	●	SNMP/TFTP	3.0.4
Roamabout 4102	1.01.25	●	●	●	SNMP/TFTP	4.3.0
	1.01.32	●	●	●	SNMP/TFTP	4.4.0
RBT-8XX0 and APs	5.0.12.5	--	--	--	--	5.1.0
	5.0.12.5	●	●	●	Telnet/TFTP/FTP	5.3.0
<b>Foundry</b>						
IronPoint 200	2.01	--	--	--	SNMP	6.1.0
	2.02	--	--	--	SNMP	6.1.0
IronPoint 250	3.0	--	--	--	SNMP	6.2.0
	3.1	--	--	--	SNMP	6.2.0
	3.2	--	--	--	SNMP	6.2.0
<b>Hirschmann</b>						
BAT-54	7.00.0070	--	--	--	--	5.0.0
	7.10.0022	--	--	--	--	5.3.0
	7.60.0165	--	--	--	--	7.0.0
<b>Intermec</b>						
2100 / 2101 / 2102	1.94	--	--	●	SNMP/TFTP	4.0.2
2106	1.90	--	--	●	SNMP/TFTP	4.0.2
WA 21 / WA 22	2.30	--	--	●	SNMP/TFTP	4.0.2
<b>Juniper Netscreen</b>						
Netscreen 5GT	5.0.0	--	--	●	SNMP/TFTP	3.4.2
<b>LANCOM</b>						
L-54g L-54ag OAP-54 Lancom 3550	4.02.0003	--	--	--	--	3.2.4
	5.02.0012	--	--	--	--	3.2.4
	5.02.0018	--	--	--	--	3.2.4
	5.02.0020	--	--	--	--	3.4.0
	6.02.0008	--	--	--	--	4.2.0
	6.10.0038	--	--	--	--	4.3.0
	7.00.0070	--	--	--	--	5.0.0
	7.22.0016	--	--	--	--	5.3.0
	7.26.0049	--	--	--	--	5.3.0

## Dell PowerConnect W-AirWave Wireless Management Suite Firmware Matrix

W-AirWave Wireless Management Suite	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version
<b>Meru</b>						
<b>MC1000 &amp; APs</b>	3.3-118	--	--	--	--	5.1.0
	3.4.SR5-21	--	--	--	--	5.3.0
	3.5.Beta-29	--	--	--	--	6.0.0
	3.6	--	--	--	--	6.1.0
	3.6-124	--	--	--	--	6.3.0
	3.6-127	--	--	--	--	6.3.0
	3.6-270	--	--	--	--	6.4.0
	3.6.1-49	--	--	--	--	7.0.0
<b>Nomadix</b>						
<b>HSG</b>	2.3.234	--	--	--	--	3.1.1
	2.4.31	--	--	--	--	3.1.2
<b>AG 2000</b>	1.3.211	--	--	--	--	3.3.1
	1.4.129	--	--	--	--	4.0.2
<b>AG 2100</b>	11.4.138	--	--	--	--	4.0.2
<b>AG 3000</b>	21.4.139	--	--	--	--	4.0.2
<b>AG 5000</b>	5.4.113	--	--	--	--	4.0.2
<b>Nortel</b>						
<b>WSS23x0 &amp; APs</b>	5.0.11.4	--	--	--	--	5.1.0
	5.0.11.4	●	●	●	Telnet/TFTP/FTP	5.3.0
	6.0.3.2	--	--	--	--	5.3.0
	6.0.3.2	●	●	●	Telnet/TFTP/FTP	5.3.0
	7.0.5.6	●	●	●	Telnet/TFTP/FTP	6.4.0
<b>ProCurve Networking by HP</b>						
<b>420</b>	2.0.38	●	●	●	Telnet/TFTP	3.0.5
	2.0.39	●	●	●	Telnet/TFTP	3.0.6
	2.1.0	●	●	●	Telnet/TFTP	3.3.2
	2.1.3	●	●	●	Telnet/TFTP	3.3.2
	2.1.5	●	●	●	Telnet/TFTP	4.3.0
	2.1.7	●	●	●	Telnet/TFTP	4.5.0
	2.2.0	●	●	●	Telnet/TFTP	5.1.6
	2.2.5	●	●	●	Telnet/TFTP	6.3.0
<b>DWL-520</b>	2.0	●	--	●	SNMP/TFTP	2.2.0
	2.3.3	●	--	●	SNMP/TFTP	2.3.0
	2.4.0	●	●	●	SNMP/TFTP	2.5.0
	2.4.3	●	●	●	SNMP/TFTP	2.5.0
	2.4.5	●	●	●	SNMP/TFTP	2.6.0
	2.5.2	●	●	●	SNMP/TFTP	3.1.2
<b>530</b>	WA.01.16	--	--	--	--	4.3.0
	WA.01.16	●	--	●	Telnet/TFTP	5.0.0
	WA.01.19	●	●	●	Telnet/TFTP	5.0.0
	WA.02.10	●	●	●	Telnet/TFTP	6.0.0
	WA.02.19	●	●	●	Telnet/TFTP	6.1.0
<b>xI WESM &amp; APs</b>	WS.01.05	--	--	●	Telnet/TFTP	4.4.0
	WS.02.01	--	--	●	Telnet/TFTP	5.2.5
	WS.02.07	●	●	●	Telnet/SSH/TFTP	5.3.0
<b>zI WESM &amp; APs</b>	WT.01.03	--	--	●	Telnet/SSH/TFTP	5.3.0
	WT.01.15	●	●	●	Telnet/SSH/TFTP	7.0.0
	WT.01.28	●	●	●	Telnet/SSH/TFTP	7.0.0
<b>MSM7xx &amp; APs</b>	5.3.1.8-01-7189	--	--	--	--	6.4.0

## Dell PowerConnect W-AirWave Wireless Management Suite Firmware Matrix

W-AirWave Wireless Management Suite	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version
<b>Proxim</b>						
	2.3.1	●	--	●	SNMP/TFTP	2.2.0
	2.3.3	●	--	●	SNMP/TFTP	2.3.0
	2.4.3	●	●	●	SNMP/TFTP	2.5.0
	2.4.5	●	●	●	SNMP/TFTP	2.6.0
AP 600	2.4.11	●	●	●	SNMP/TFTP	2.8.0
	2.5.2	●	●	●	SNMP/TFTP	3.1.2
	2.5.3	●	●	●	SNMP/TFTP	3.1.2
	2.5.4	●	●	●	SNMP/TFTP	4.1.0
	2.5.5	●	●	●	SNMP/TFTP	3.3.1
	2.5.2	●	●	●	SNMP/TFTP	3.2.1
	2.6.0	●	●	●	SNMP/TFTP	3.2.1
AP 700	3.1.0	●	●	●	SNMP/TFTP	3.4.2
	3.2.0	●	●	●	SNMP/TFTP	4.2.0
	3.2.1	●	●	●	SNMP/TFTP	4.3.4
	3.4.0	●	●	●	SNMP/TFTP	4.4.1
	3.6.2	●	●	●	SNMP/TFTP	5.3.0
	3.7.0	●	●	●	SNMP/TFTP	6.1.0
	4.0.1	●	●	●	SNMP/TFTP	6.2.0
	4.0.2	●	●	●	SNMP/TFTP	6.3.0
	2.0	●	--	●	SNMP/TFTP	2.2.0
	2.3.3	●	--	●		2.3.0
AP 2000	2.4.0	●	●	●	SNMP/TFTP	2.5.0
	2.4.3	●	●	●	SNMP/TFTP	2.5.0
	2.4.5	●	●	●	SNMP/TFTP	2.6.0
	2.4.11	●	●	●	SNMP/TFTP	2.8.0
	2.5.2	●	●	●	SNMP/TFTP	3.1.2
	2.5.3	●	●	●	SNMP/TFTP	3.1.3
	2.5.4	●	●	●	SNMP/TFTP	3.3.1
	2.5.5	●	●	●	SNMP/TFTP	4.1.0
	2.4.5	●	●	●	SNMP/TFTP	2.11.0
	2.4.11	●	●	●	SNMP/TFTP	2.11.0
AP 4000	2.4.12	●	●	●	SNMP/TFTP	3.0.2
	2.5.2	●	●	●	SNMP/TFTP	3.1.2
	2.6.0	●	●	●	SNMP/TFTP	3.1.3
	3.1.0	●	●	●	SNMP/TFTP	3.4.2
	3.2.0	●	●	●	SNMP/TFTP	4.2.0
	3.2.1	●	●	●	SNMP/TFTP	4.3.4
	3.4.0	●	●	●	SNMP/TFTP	4.4.1
	3.6.2	●	●	●	SNMP/TFTP	5.3.0
	3.7.0	●	●	●	SNMP/TFTP	6.1.0
	4.0.0	●	●	●	SNMP/TFTP	6.2.0
	4.0.2	●	●	●	SNMP/TFTP	6.3.0
AP 4000M AP 4900M	3.2.0	●	●	●	SNMP/TFTP	4.3.4
	3.2.1	●	●	●	SNMP/TFTP	4.3.4
	3.4.0	●	●	●	SNMP/TFTP	4.4.1
	3.6.2	●	●	●	SNMP/TFTP	5.3.0
	3.7.0	●	●	●	SNMP/TFTP	6.1.0
	4.0.0	●	●	●	SNMP/TFTP	6.2.0
	4.0.2	●	●	●	SNMP/TFTP	6.3.0
Tsunami MP.11a	2.0.1	●	●	●	SNMP/TFTP	3.2.4
	2.2.0	●	●	●	SNMP/TFTP	3.2.4
	2.2.2	●	●	●	SNMP/TFTP	3.2.4
	2.2.6	●	●	●	SNMP/TFTP	3.4.2
Tsunami MP.11 5054,4954, 954, 2454, 5012	2.3.0	●	●	●	SNMP/TFTP	5.2.0
	4.0.0	●	●	●	SNMP/TFTP	5.2.0

## Dell PowerConnect W-AirWave Wireless Management Suite Firmware Matrix

W-AirWave Wireless Management Suite	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version
<b>Symbol</b>						
3021	04.01-23	●	●	●	SNMP/TFTP	4.0.1
	04.02-19	●	●	●	SNMP/TFTP	4.0.1
4121	3.52.13	●	--	●	SNMP/TFTP	2.2.0
	2.70.06	●	●	●	SNMP/TFTP	2.2.0
4131	3.51-20	●	--	●	SNMP/TFTP	2.2.0
	3.70-72	●	●	●	SNMP/TFTP	3.0.4
	3.92-29	●	●	●	SNMP/TFTP	3.0.7
	3.93-00	●	●	●	SNMP/TFTP	3.4.2
	3.94-15	●	●	●	SNMP/TFTP	4.3.0
5131	1.1.0.0.045R	--	--	--	--	5.2.1
	1.1.0.0.045R	--	--	●	Telnet/TFTP	5.2.4
	2.0.0	●	--	●	Telnet/TFTP	6.1.0
	2.1.0	●	●	●	Telnet/TFTP	6.2.0
	2.2.0	●	●	●	Telnet/TFTP	6.3.0
	2.3.1.0	●	●	●	Telnet/TFTP	7.0.0
	2.4.1.0	●	●	●	Telnet/TFTP/FTP	7.1.0
	2.5.0.0	●	●	●	Telnet/TFTP/FTP	7.1.0
	3.2.2	●	●	●	Telnet/TFTP/FTP	7.1.0
	4.0.3	●	●	●	Telnet/TFTP/FTP	7.1.0
7131	4.1.0	●	●	●	Telnet/TFTP/FTP	7.1.0
	5181	1.1.2	●	●	Telnet/TFTP	6.2.0
WS5000 & APs	0.0-35R	--	--	--	--	4.3.0
	2.0.0	--	--	--	--	4.4.0
WS2000 & APs	0.0-35R	--	--	●	Telnet/TFTP	5.0.0
	2.2.3.0-020R	--	--	●	Telnet/TFTP	6.0.0
	2.2.3.0-020R	●	--	●	Telnet/TFTP	6.1.0
	2.3.2.0-003R	●	--	●	Telnet/TFTP	6.3.0
	2.4.0.0-023R	●	--	●	Telnet/TFTP	6.3.0
	2.4.1.0-005R	●	--	●	Telnet/TFTP	6.4.0
	2.4.4.0-001R	●	--	●	Telnet/TFTP	7.1.0
	2.0.0	--	--	--	--	4.4.0
	3.0.0	--	--	●	Telnet/TFTP	5.0.0
	3.0.2	●	●	●	Telnet/TFTP	5.3.0
WS5100 & APs	3.0.3	●	●	●	Telnet/TFTP	5.3.0
	3.0.3	●	●	●	Telnet/SSH/TFTP	6.0.0
	3.1.0	●	●	●	Telnet/SSH/TFTP	6.1.0
	3.2.0	●	●	●	Telnet/SSH/TFTP	6.1.0
	3.3.1	●	●	●	Telnet/SSH/TFTP/FTP	6.3.0
	3.3.3	●	●	●	Telnet/SSH/TFTP/FTP	7.1.0
	1.0.0.0	●	--	●	Telnet/SSH/TFTP	6.0.0
	1.2.0.0	●	●	●	Telnet/SSH/TFTP/FTP	6.3.0
	3.2.0	●	●	●	Telnet/SSH/TFTP	6.2.0
	4.0.0.0	●	●	●	Telnet/SSH/TFTP/FTP	6.3.0
RFSx000 & APs	4.1.0.0	●	●	●	Telnet/SSH/TFTP/FTP	7.1.0
	4.2.1.0	●	●	●	Telnet/SSH/TFTP/FTP	7.1.0
	4.3.0.0	●	●	●	Telnet/SSH/TFTP/FTP	7.1.0
<b>Systimax</b>						
Airspeed 542	2.4.5	●	●	●	SNMP/TFTP	3.2.0
	2.4.11	●	●	●	SNMP/TFTP	3.2.0
	2.4.12	●	●	●	SNMP/TFTP	3.2.0
	2.5.2	●	●	●	SNMP/TFTP	3.2.0
	2.6.0	●	●	●	SNMP/TFTP	3.2.0
<b>Teklogix</b>						
9150/9160	C234p	--	--	●	--	4.4.0

## Dell PowerConnect W-AirWave Wireless Management Suite Firmware Matrix

W-AirWave Wireless Management Suite	Firmware	Upgrade	Downgrade	Configuration	Protocol	Supported since Version
<b>Trapeze</b>						
MX Series & MPs	5.0.12.2	--	--	--	--	5.1.0
	5.0.12.2	●	●	●	Telnet/TFTP/FTP	5.3.0
	6.0.2.2	--	--	--	--	5.1.0
	6.0.2.2	●	●	●	Telnet/TFTP/FTP	5.3.0
	6.0.4.2	●	●	●	Telnet/TFTP/FTP	5.3.0
	7.0.5.6	●	●	●	Telnet/TFTP/FTP	6.4.0
<b>Tropos</b>						
4/5210, 5320, 9422, 9532  3/4/5210, 5320, 9422, 9532	5.1.4.7	--	--	--	--	5.0.0
	5.1.4.7	--	--	--	--	5.3.0
	6.5.1.3	--	--	--	--	5.3.0
	6.6.0.0	--	--	--	--	5.3.0
	6.6.1.3	--	--	--	--	6.2.0
<b>Vivato</b>						
VP1200	1.3.1.r4	--	--	--	--	3.3.2
VA2200	1.1.r2	--	--	--	--	3.3.1
	2.2	--	--	--	--	3.4.2
VP2200	3.0.r9	--	--	--	--	5.2.4

© 2011 Aruba Networks, Inc. AirWave®, Aruba Networks®, Aruba Mobility Management System®, and other registered marks are trademarks of Aruba Networks, Inc. Dell™, the DELL™ logo, and PowerConnect™ are trademarks of Dell Inc. All rights reserved. Specifications in this manual are subject to change without notice. Originated in the USA. Any other trademarks appearing in this manual are the property of their respective companies. Open Source Code - Certain Aruba products include Open Source software code developed by third parties, including software code subject to the GNU General Public License (GPL), GNU Lesser General Public License (LGPL), or other Open Source Licenses. The Open Source code used can be found at this site: [http://www.arubanetworks.com/open\\_source](http://www.arubanetworks.com/open_source). Legal Notice - The use of Aruba Networks, Inc. switching platforms and software, by all individuals or corporations, to terminate other vendors' VPN client devices constitutes complete acceptance of liability by that individual or corporation for this action and indemnifies, in full, Aruba Networks, Inc. from any and all legal actions that might be taken against it with respect to infringement of copyright on behalf of those vendors.