

Dell License Manager

Version 1.2

Release Notes



Release Notes

License Manager

Dell License Manager is a one-to-many license deployment and reporting tool for integrated Dell Remote Access Controller (iDRAC) and Dell chassis management controller (CMC) licenses. Dell License Manager can also inventory licensable systems to report the licensing status and currently enabled management controller feature level. Use Dell iDRAC licenses to enable server management capabilities such as the virtual media and remote console support currently available in the Enterprise iDRAC feature set. Use Dell CMC licenses to enable chassis management capabilities such as console integration, remote access, multi-chassis management, server cloning, and so on. To use the license manager, inventory licensable servers and deploy licenses obtained from the online licensing portal (<http://www.dell.com/support/retail/lkm>).

Version 1.2

Release Date: September 2014

Previous Version 1.1

Importance

OPTIONAL: Dell recommends the customer review specifics about the update to determine if it applies to your system. The update contains changes that impact only certain configurations, or provides new features that may/may not apply to your environment.

What's New

- Support for Dell 13th generation PowerEdge servers.
- Support for Dell OpenManage Essentials perpetual licenses.
- Support for management of up to 3500 licenses.
- Ability to filter the imported licenses based on matching systems.
- Ability to discover and inventory systems using a text file that contains IP addresses and/or host names.

Known Issues

Issue 1

Description:

The Dell License Manager help content cannot be viewed in some versions of Microsoft Internet Explorer.

Resolution:

Enable active scripting under security settings and then retry the operation.

1. In Internet Explorer, click **Tools** → **Internet Options**.
The **Internet Options** window is displayed.
2. Click the **Security** tab, and then click **Custom level**.
The **Security Settings** window is displayed.
3. In the **Settings** pane, scroll down until you find **Scripting and Active Scripting**.
4. Click **Enable**, and then click **OK**.
The **Security Settings** window is closed.
5. In the **Internet Options** window, click **OK**.

Installation Prerequisites

Microsoft .NET Framework 4.5

<http://www.microsoft.com/en-us/download/details.aspx?id=30653>

Windows Remote Management (WinRM) 2.0 or later

Part of Windows Management Framework Core package

<http://support.microsoft.com/kb/968930>

This functionality is included in Microsoft Windows 7 and Windows Server 2008 R2.

The WinRM prerequisites are also available through Microsoft Windows Update.

Hardware And Software Requirements

Disk Space

200 MB (minimum)

Memory (RAM)

2 GB (minimum)

Network

100 Mbps

Screen Resolution

1024 x 768

1600 x 1200 for German users

Operating System

Microsoft Windows 7

Windows Server 2008 R2

Windows Server 2008 (SP2 or later)

Windows Server 2012

Windows Server 2012 R2

Both 64-bit and 32-bit versions are supported.

Installation

To install Dell License Manager, download and run the installer. For more information on installing Dell License Manager, see the *Dell License Manager User Guide* at Dell.com/OpenManageManuals.

Uninstallation

Dell License Manger can be uninstalled from the Windows Control Panel, Programs and Features option.

Global Support

For technical support, see www.dell.com/support.

Copyright © 2014 Dell Inc. All rights reserved. This product is protected by U.S. and international copyright and intellectual property laws. Dell™ and the Dell logo are trademarks of Dell Inc. in the United States and/or other jurisdictions. All other marks and names mentioned herein may be trademarks of their respective companies.