



SoftBank 001DL

クイックスタートガイド

---

この文書の情報は、事前の通知なく変更されることがあります。

© 2010 すべての著作権は Dell Inc. にあります。

Dell および DELL のロゴは Dell Inc. の商標です。



2010 年 10 月

P/N 1F5NP


Rev. A00

## はじめに

### 背面カバーを取り外す



### SIM カードを挿入する



### 電池パックを取り付ける




## はじめに

### microSD カードを挿入する

1



2



### 背面カバーを取り付ける

1




2




背面カバーは隙間がないよう  
最後まで押し込んでください。

### 電池パックを充電する



## 各部の名称




1. 戻るボタン
2. メニューボタン
3. ホームボタン
4. マイク
5. 近接センサー

6. レシーバー
7. 前面カメラレンズ
8. 環境照明センサー
9. イヤホン端子
10. ボリュームダウンボタン

11. ボリュームアップボタン
12. 電源およびスリープ / ウェイクボタン
13. カメラボタン

## 各部の名称



1. カメラレンズ

2. カメラフラッシュ

3. 外部接続端子


4. スピーカ

## 電源を入れる



### 電源ボタンを押し続ける




メモ：デバイスがオンの時に背面カバーを外すと、デバイスは自動的にオフになります。



### Wi-Fi をオンにしてネットワークに接続

- 1 ホームボタン  → メニューボタン  → **設定** → **無線とネットワーク** → **Wi-Fi** とタッチして、Wi-Fi チェックボックスを選択します。デバイスが、利用できるワイヤレスネットワークをスキャンします。
- 2 **Wi-Fi 設定** をタッチします。検出された Wi-Fi ネットワークの名前およびセキュリティ設定が **Wi-Fi ネットワーク** リストに表示されます。
- 3 **Wi-Fi ネットワーク** リストをフリックし、接続したいネットワークの名前をタッチします。
- 4 パスワードを入力し（必要な場合）、**接続** をタッチして Wi-Fi ネットワークに接続します。




**メモ**：お使いのデバイスがワイヤレスネットワークに接続されると、シグナルの強度を示す Wi-Fi アイコン  がステータスバーに表示されます。



## マイクフォン付きイヤホンの接続


マイクフォン付きイヤホンをイヤホン端子に接続する



## コンピュータへの接続 (オプション)








### デバイスの microSD カードに音楽、写真、およびビデオファイルをコピーする

- 1 デバイスとコンピュータに USB ケーブルを接続します。コンピュータが自動的にドライバをインストールするのを待ちます。
- 2 インストールが完了したら、新しい「リムーバブルディスク」がコンピュータに表示されます。これで、コンピュータから microSD カードの内容を見ることができるようになります。
- 3 コンピュータから音楽、写真、またはビデオファイルを選択し、それらのファイルをリムーバブルディスクにある音楽、写真、ビデオフォルダにそれぞれコピーします。
- 4 コピーが完了したら、USB ケーブルを取り外します。












## 連絡先のロード

### SIM から連絡先をコピーする

- 1 ホームボタン  → ランチャーボタン  → **連絡先**  とタッチ、または電話ボタン  → **連絡先**  とタッチします。
- 2 メニューボタン  → **インポート / エクスポート** → **SIM カードからインポート** とタッチします。
- 3 連絡先をタッチしてデバイスに追加、またはメニューボタン  → **すべてをインポート** とタッチしてすべての連絡先をデバイスにコピーします。

### Gmail から連絡先を追加する

- 1 ホームボタン  → メニューボタン  → **設定** → **アカウント & 同期化** とタッチして、**アカウント & 同期化設定** メニューを開きます。
- 2 **アカウントの追加** → **Google** とタッチし、Google アカウントにサインインします。
- 3 戻るボタン  をタッチして **アカウント & 同期化設定** メニューに戻り、**自動同期化** をタッチします。
- 4 Gmail アカウントをタッチし、**連絡先の同期化** をタッチします。
- 5 ホームボタン  → ランチャーボタン  → **連絡先**  とタッチ、または電話ボタン  → **連絡先**  とタッチします。
- 6 メニューボタン  → **表示オプション** とタッチします。
- 7 Gmail アカウントをタッチし、連絡先グループリストをスクロールダウンして、**その他すべての連絡先** をタッチして選択します。

## 詳細情報

詳細に関しては、[support.jp.dell.com/manuals](http://support.jp.dell.com/manuals) で取扱説明書を参照してください。または、QuickOffice を起動し、**メモカード**を選択することで、お使いのデバイスで取扱説明書を表示することもできます。

ご利用いただけるサービスおよび詳細については、ソフトバンクモバイルホームページ (<http://www.softbank.jp/>) をご確認ください。

取扱説明書の最新版は、ソフトバンクモバイルのホームページよりダウンロードできます。

<http://www.softbank.jp/mb/r/support/001dl/>



SoftBank 001DL

## Quick Start Guide

---

**Information in this document is subject to change without notice.**



**© 2010 Dell Inc. All rights reserved.**

*Dell* and the *DELL* logo are trademarks of Dell Inc.



**October 2010    P/N 1F5NP    Rev. A00**

## Getting Started


### Remove the back cover



### Insert the SIM card



### Insert the battery




## Getting Started

### Insert the microSD card

1



2



### Replace the back cover


1



2




### Charge the battery





## Overview



1. Back button

2. Menu button

3. Home button

4. Microphone

5. Proximity sensors

6. Earpiece

7. Front-facing camera lens

8. Ambient light sensor

9. Headphone connector


10. Volume down button

11. Volume up button

12. Power and Sleep/Wake button

13. Camera button

## Overview



- 1. Camera lens
- 2. Camera flash


- 3. 30-pin connector
- 4. Speaker

## Turn On Your Device

### Press and hold the power button





**NOTE:** The device will turn off automatically if you remove the back cover while the device is on.




## Connect to a Network

### Turn on Wi-Fi and connect to a network


- 1 Touch the Home button  → Menu button  → **Settings** → **Wireless & networks** → **Wi-Fi** to select the Wi-Fi check box. The device scans for available wireless networks.
- 2 Touch **Wi-Fi settings**. The names and security settings of discovered Wi-Fi networks will be displayed in the **Wi-Fi networks** list.
- 3 Flick the **Wi-Fi networks** list and touch the name of the network that you would like to connect to.
- 4 Enter a password (if necessary), then touch **Connect** to connect to the Wi-Fi network.



**NOTE:** When your device is connected to a wireless network, the Wi-Fi icon  appears in the status bar to indicate the signal strength.

## Connect Headphones


Connect the 3.5 mm headphones to the headphone connector



## Connect to a Computer (Optional)








### Copying music, photo, and video files to the microSD card in your device

- 1 Connect the 30-pin-to-USB cable to your device and a computer. Wait for your computer to automatically install the driver.
- 2 Once the installation is complete, a new "Removable Disk" will become available on your computer. This will allow you to view the contents of the microSD card from your computer.
- 3 Select the music, photo, and/or video files from your computer, then copy them to the Music, Pictures, and Video folders (respectively) on the Removable Disk.
- 4 Once the copy is complete, disconnect the 30-pin-to-USB cable.












# Loading My Contacts

## Copying contacts from SIM

- 1 Touch the Home button  → the Launcher button  → **Contacts** , or touch the Phone button  → **Contacts** .
- 2 Touch the Menu button  → **Import/Export** → **Import from SIM card**.
- 3 Touch the contact to add to your device, or touch the Menu button  → **Import all** to copy all the contacts to your device.

## Adding contacts from Gmail

- 1 Touch the Home button  → Menu button  → **Settings** → **Accounts & sync** to open the **Accounts & sync settings** menu.
- 2 Touch **Add account** → **Google**, and sign in to your Google account.
- 3 Touch the Back button  to return to the **Accounts & sync settings** menu, and touch **Auto-sync**.
- 4 Touch your Gmail account, and touch **Sync Contacts**.
- 5 Touch the Home button  → the Launcher button  → **Contacts** , or touch the Phone button  → **Contacts** .
- 6 Touch the Menu button  → **Display options**.
- 7 Touch your Gmail account, scroll down the contact group list, and touch to select **All Other Contacts**. Your Gmail contacts will be added to your Contacts list.

## For More Information

For more information, see the User's Manual at [support.dell.com/manuals](https://support.dell.com/manuals). Or, you can view the User's Manual on your device by launching QuickOffice, then selecting **Memory card**.