


About Your Keyboard Dock

关于您的键盘扩展坞



- | | |
|----------------------------------|-----------------------------------|
| 1. Docking latch | 8. Windows key |
| 2. Release latch | 9. Caps-lock light |
| 3. Docking connector | 10. Battery/charging-status light |
| 4. Docking latch | 11. Power-adaptor port |
| 5. USB 2.0 port | 12. USB 2.0 port |
| 6. Mini-HDMI port | |
| 7. Touchpad and touchpad buttons | |

- | | |
|---------------|------------------|
| 1. 对接门锁 | 8. Windows 按键 |
| 2. 释放门锁 | 9. Caps-lock 指示灯 |
| 3. 对接连接器 | 10. 电池/充电状态指示灯 |
| 4. 对接门锁 | 11. 电源适配器端口 |
| 5. USB 2.0 端口 | 12. USB 2.0 端口 |
| 6. 微型 HDMI 端口 | |
| 7. 触摸板和触摸板按钮 | |

Keyboard Dock

键盘扩展坞

XPS


10



Docking Your Tablet 对接您的平板电脑


Remove docking-port covers from the tablet

从平板电脑上取下对接端口护盖



Insert tablet in the keyboard dock until it clicks in place

将平板电脑插入键盘扩展坞，直到其卡入到位




Connect the power adapter

连接电源适配器



Undocking Your Tablet 拔下您的平板电脑

拔下您的平板电脑



© 2012 Dell Inc.

Dell™, the DELL logo, and XPS™ are trademarks of Dell Inc.

© 2012 Dell Inc.

Dell™、DELL 徽标和 XPS™ 是 Dell Inc. 的商标。



05M92WA00

Printed in China.

2012 - 12