Inspiron 13 5000 2-in-1 Setup and Specifications



Notes, cautions, and warnings



NOTE: A NOTE indicates important information that helps you make better use of your product.



CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

Copyright © 2017 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

2017-02

Rev. A01

Contents

Set up your computer	5
Views	8
Front	8
Left	
Right	
Base	
Display	
Modes	
	12
	12
	13
Tent	13



Specifications	14
Dimensions and weight	14
System information	14
Memory	14
Ports and connectors	15
Communications	15
Video	15
Audio	16
Storage	16
Media-card reader	16
Keyboard	16
Camera	17
Touch pad	17
Power adapter	17
Battery	18
Display	18
Computer environment	19
Keyboard shortcuts	20
Getting help and contacting Dell	22
Self-help resources	
Contacting Dell	



Set up your computer

1 Connect the power adapter and press the power button.






2 Finish operating system setup.

For Windows:

a) Connect to a network.



b) Sign-in to your Microsoft account or create a new account.



For Ubuntu:

Follow the instructions on the screen to finish setup.



3 Locate Dell apps in Windows.



Register your computer

Dell Help & Support








SupportAssist—Check and update your computer



Views

Front



Power and battery-status light/hard-drive activity light

Indicates the battery-charge status or the hard-drive activity.



NOTE: Press Fn+H to toggle this light between power and batterystatus light and hard-drive activity light.

Hard-drive activity light

Turns on when the computer reads from or writes to the hard drive.

Power and battery-status light

Indicates the power and battery-charge status.


Solid white — Power adapter is connected and the battery has more than 5% charge.

Amber — Computer is running on battery and the battery has less than 5% charge.

Off

- Power adapter is connected and the battery is fully charged.
- Computer is running on battery and the battery has more than 5% charge.
- Computer is in sleep state, hibernation, or turned off

l eft





1 Power-adapter port

Connect a power adapter to provide power to your computer and charge the battery.

2 **HDMI** port

Connect a TV or another HDMI-in enabled device. Provides video and audio output.

3 **USB 3.0 port with PowerShare**

Connect peripherals such as storage devices, printers, and so on. Provides data transfer speeds up to 5 Gbps.

PowerShare allows you to charge your USB devices even when your computer is turned off.



NOTE: If your computer is powered off or in hibernate state, you must connect the power adapter to charge your devices using the PowerShare port. You must enable this feature in the BIOS setup program.



NOTE: Certain USB devices may not charge when the computer is powered off or in sleep state. In such cases, turn on the computer to charge the device.

4 USB 3.0 port

Connect peripherals such as storage devices, printers, and so on. Provides data transfer speeds up to 5 Gbps.

5 Headset port

Connect a headphone, a microphone, or a headset (headphone and microphone combo).

Right



Power button

Press to turn on the computer if it is turned off or in sleep state.

Press to put the computer in sleep state if it is turned on.



Press and hold for 4 seconds to force shut-down the computer.



NOTE: You can customize the power-button behavior in Power Options. For more information, see *Me and My Dell* at www.dell.com/support/manuals.

2 Volume-control buttons (2)

Press to increase or decrease the volume.

3 Media-card reader

Reads from and writes to media cards.

4 USB 2.0 port

Connect peripherals such as storage devices, printers, and so on. Provides data transfer speeds up to 480 Mbps.

5 Security-cable slot

Connect a security cable to prevent unauthorized movement of your computer.

Base



1 Left-click area

Press to left-click.

2 Touch pad

D&LL

Move your finger on the touch pad to move the mouse pointer. Tap to left-click and two finger tap to right-click.

3 Right-click area

Press to right-click.

Display



1 Left microphone

Provides digital sound input for audio recording, voice calls, and so on.

2 Infrared emitter (optional)

Emits infrared light, which allows the infrared camera to sense depth and track motion.

3 Infrared camera (optional)

Allows you to video chat, capture photos, and record videos. Depth-sensing feature of the camera enhances security when paired with Windows Hello.

4 Camera

Allows you to video chat, capture photos, and record videos.



5 Camera-status light

Turns on when the camera is in use.

6 Right microphone

Provides digital sound input for audio recording, voice calls, and so on.

7 Service tag location

The service tag is a unique alphanumeric identifier that allows Dell service technicians to identify the hardware components in your computer and access warranty information.

Modes

Notebook



Tablet





Stand



Tent





Specifications

Dimensions and weight

 Height
 19.50 mm (0.77 in)

 Width
 324 mm (12.76 in)

 Depth
 224.70 mm (8.85 in)

 Weight (maximum)
 1.68 kg (3.70 lb)



NOTE: The weight of your computer varies depending on the configuration ordered and the manufacturing variability.

System information

Computer model Inspiron 13-5378

Processor . 7th Generation Intel Core i3/i5/i7

Intel Celeron Dual CoreIntel Pentium Dual Core

Chipset Integrated in the processor

Memory

Slots Two SODIMM slots

Type Dual-channel DDR4

Speed 2133 MHz

Configurations supported 4 GB, 8 GB, 12 GB, and 16 GB



Ports and connectors

· One USB 3.0 port
One USB 2.0 port
 One USB 3.0 port with PowerShare
· One HDMI port
One headset (headphone and microphone combo) port
· · · · · · · · · · · · · · · · · · ·

One M.2 slot for Wi-Fi and Bluetooth

Communications

\	
Wireless	 Wi-Fi 802.11 ac
	· Bluetooth 4.0
	· Bluetooth 4.1 (optional)
	 Miracast
	 Wi-Fi Display Support (Wi-Fi Alliance)

combo card

Video

M.2 Card

Controller	
Controller	 Intel HD Graphics 610 - Intel Celeron and Pentium
	 Intel HD Graphics 620 - Intel Core i3/i5/i7
	· Intel Iris Graphics 640 - Intel Core i7
Memory	Shared system memory



Audio

Controller Realtek ALC3253 with Waves

MaxxAudio Pro

Speakers Two

Speaker Output • Average – 2 W

· Peak - 2.5 W

Microphone Digital-array microphones in camera

assembly

Volume controls Media-control shortcut keys and volume-

control buttons

Storage

Interface SATA 6 Gbps

Hard drive One 2.5-inch drive

Solid-state drive One 2.5-inch drive

Media-card reader

Type One SD card slot

Cards supported SD card

Keyboard

Type . Backlit keyboard

· Non-Backlit keyboard

Shortcut keys Some keys on your keyboard have two

symbols on them. These keys can be used to type alternate characters or to



perform secondary functions. To type the alternate character, press Shift and the desired key. To perform secondary functions, press Fn and the desired key.



NOTE: You can define the primary behavior of the function keys (F1-F12) by changing Function Key Behavior in BIOS setup program.

Keyboard shorcuts

Camera

Resolution • Still image: 0.92 megapixel

Video: 1280 x 720 (HD) at 30 fps

(maximum)

Diagonal viewing angle 74 degrees

Touch pad

Resolution . Horizontal: 1260

· Vertical: 960

Dimensions • Height: 65 mm (2.56 in)

• Width: 105 mm (4.13 in)

Power adapter

Type 45 W

Input voltage 100 VAC-240 VAC

Input frequency 50 Hz-60 Hz

Input current (maximum) 1.30 A

Output current (continuous) 2.31 A



Rated output voltage 19.50 VDC

Temperature range: Operating 0°C to 40°C (32°F to 104°F)

Temperature range: Storage -40°C to 70°C (-40°F to 158°F)

Battery

Type 3-cell "smart" lithium-ion (42 WHr)

Weight (maximum) 0.2 kg (0.44 lb)

Voltage 11.40 VDC

Charging time

(approximate)

4 hours (when the computer is off)

Operating time Varies depending on operating conditions and can

significantly reduce under certain power-intensive

conditions.

Life span (approximate) 300 discharge/charge cycles

Temperature range:

Operating

0°C to 35°C (32°F to 95°F)

Temperature range:

Storage

-40°C to 65°C (-40°F to 149°F)

Coin-cell battery CR-2032

Height 5.90 mm (0.23 in)
Width 97.15 mm (3.82 in)

Depth 184. 15 mm (7.25 in)

Display

Type 13.3-inch HD WLED touch 13.3-inch Full HD WLED

screen touch screen

Resolution (maximum) 1366 x 768 1920 x 1080

Viewing angle 120 degrees 160 degrees

Pixel pitch 0.2148 mm 0.1529 mm



Height	164.97 mm (6.49 in)	165.10 mm (6.50 in)
Width	293.42 mm (11.55 in)	293.60 mm (11.56 in)
Diagonal	337.82 mm (13.30 in)	337.82 mm (13.30 in)
Refresh rate	60 Hz	
Operating angle	0 degree (closed) to 360 de	grees
Controls	Brightness can be controlled	d using shortcut keys

Computer environment

Airborne contaminant level: G1 as defined by ISA-S71.04-1985

	Operating	Storage
Temperature range	0°C to 35°C (32°F to 95°F)	-40°C to 65°C (-40°F to 149°F)
Relative humidity (maximum)	10% to 90% (non- condensing)	0% to 95% (non- condensing)
Vibration (maximum)*	0.66 GRMS	1.30 GRMS
Shock (maximum)	110 G [†]	160 G [‡]
Altitude (maximum)	-15.2 m to 3048 m (-50 ft to 10,000 ft)	-15.2 m to 10,668 m (-50 ft to 35,000 ft)

^{*} Measured using a random vibration spectrum that simulates user environment.



[†] Measured using a 2 ms half-sine pulse when the hard drive is in use.

[‡] Measured using a 2 ms half-sine pulse when the hard-drive head is in parked position.

Keyboard shortcuts

Keys	Description
F1 « x	Mute audio
F2 •	Decrease volume
F3 (4)	Increase volume
F4	Play previous track/chapter
F5 ▶II	Play/Pause
F6 ▶H	Play next track/chapter
F8 2	Switch to external display
F ⁹ ρ	Search
F10	Toggle keyboard backlight
F11	Decrease brightness
F12	Increase brightness
Fn + PrtScr	Turn off/on wireless
Fn + B	Pause/Break
Fn + Insert	Sleep
Fn + S	Toggle scroll lock



Keys	Description
Fn + H	Toggle between power and battery- status light/hard-drive activity light
Fn + R	System request
Fn + Ctrl	Open application menu
Fn + Esc	Toggle Fn-key lock
Fn + End →	End
Fn + ←Home	Home
Fn + + PgDn	Page down
Fn + PgUp	Page up



Getting help and contacting Dell

Self-help resources

You can get information and help on Dell products and services using these self-help resources:

Table 1. Self-help resources

Information about Dell products and

services

Dell Help & Support app

www.dell.com



Get started app



Accessing help In Windows search, type Help and

Support, and press Enter.

Online help for operating system <u>www.dell.com/support/windows</u>

www.dell.com/support/linux

www.dell.com/support

Troubleshooting information, user manuals, setup instructions, product specifications, technical help blogs, drivers, software updates, and so on.

Learn about your operating system, See *Me and My L* setting up and using your computer, data support/manuals. backup, diagnostics, and so on.

See Me and My Dell at www.dell.com/

Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see www.dell.com/contactdell.



