Inspiron 17 5000 Setup and Specifications



Notes, cautions, and warnings



NOTE: A NOTE indicates important information that helps you make better use of your computer.



CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

© 2016 Dell Inc. All rights reserved. This product is protected by U.S. and international copyright and intellectual property laws. Dell and the Dell logo are trademarks of Dell Inc. in the United States and/or other jurisdictions. All other marks and names mentioned herein may be trademarks of their respective companies.

2016-06

Rev. A00

Contents

Set up your computer	5
Views	8
Front	
Left	
Right	
Base	
Display	
Specifications	12
Dimensions and weight	
System information	12
Memory	
Ports and connectors	13
Communications	13
Video	13
Audio	14
Storage	14
Media-card reader	15
Keyboard	15
Camera	15
Touch pad	16
Power adapter	16
Battery	16
Display	17
Computer environment	17
Keyboard shortcuts	19

Getting help and contacting Dell	21
Self-help resources	21
Contacting Dell	22

Set up your computer

1 Connect the power adapter and press the power button.



2 Finish operating system setup.

For Windows:

a) Connect to your network.



b) Sign in to your Microsoft account or create a local account.



For Ubuntu:

Follow the instructions on the screen to finish setup.

3 Locate Dell apps.



Register your computer

Dell Help & Support








SupportAssist — Check and update your computer

Views

Front



1 Power and battery-status light/hard-drive activity light

Indicates the battery-charge status or the hard-drive activity.



NOTE: Press Fn+H to toggle this light between power and battery-status light and hard-drive activity light.

Hard-drive activity light

Turns on when the computer reads from or writes to the hard drive.

Power and battery-status light

Indicates the power and battery-charge status.


Solid white — Power adapter is connected and the battery has more than 5% charge.

Amber — Computer is running on battery and the battery has less than 5% charge.

Off

- Power adapter is connected and the battery is fully charged.
- Computer is running on battery and the battery has more than 5% charge.
- Computer is in sleep state, hibernation, or turned off.

Left



1 Power-adapter port

Connect a power adapter to provide power to your computer and charge the battery.

2 Network port

Connect an Ethernet (RJ45) cable from a router or a broadband modem for network or internet access

3 HDMI port

Connect a TV or another HDMI-in enabled device. Provides video and audio output.

4 USB 3.0 ports (2)

Connect peripherals such as storage devices and printers. Provides data transfer speeds up to 5 Gbps.

5 Headset port

Connect a headphone or a headset (headphone and microphone combo).

Right



1 SD-card slot

Reads from and writes to the SD card.

2 USB 2.0 port

Connect peripherals such as storage devices and printers. Provides data transfer speeds up to 480 Mbps.

3 Optical drive

Reads from and writes to CDs and DVDs.

4 Security-cable slot

Connect a security cable to prevent unauthorized movement of your computer.

Base



1 Touch pad

Move your finger on the touch pad to move the mouse pointer. Tap to left-click and two finger tap to right-click.

2 Left-click area

Press to left-click.

3 Right-click area

Press to right-click.

4 Power button

Press to turn on the computer if it is turned off, in sleep state, or in hibernate state.


Press to put the computer in sleep state if it is turned on.

Press and hold for 4 seconds to force shut-down the computer.



NOTE: You can customize the power-button behavior in Power Options. For more information, see Me and My Dell at www.dell.com/support/manuals.

Display



1 Left microphone

Provides digital sound input for audio recording and voice calls.

2 Camera

Enables you to video chat, capture photos, and record videos.

3 Camera-status light

Turns on when the camera is in use.

4 Right microphone

Provides digital sound input for audio recording and voice calls.

5 Service Tag label

The Service Tag is a unique alphanumeric identifier that enables Dell service technicians to identify the hardware components in your computer and access warranty information.

Specifications

Dimensions and weight

 Height
 25.30 mm (1 in)

 Width
 424 mm (16.69 in)

 Depth
 280 mm (11.02 in)

 Weight (maximum)
 3.09 kg (6.81 lb)



NOTE: The weight of your computer varies depending on the configuration ordered and the manufacturing variability.

System information

Computer model Inspiron 17-5765

Processor • AMD FX-9800P

AMD A12-9700PAMD A10-9600PAMD A9-9400

Chipset Integrated in the processor

Memory

Slots Two SODIMM slots

Type Single or Dual-channel DDR4

Speed Up to 1866 MHz

Configurations

supported

4 GB, 6 GB, 8 GB, 12 GB, and 16 GB

Ports and connectors

External:		
Network	One RJ45 port	
USB	Two USB 3.0 portsOne USB 2.0 port	
Audio/Video	 One HDMI port One headset (headphone and microphone combo) port 	
Internal:		
M.2 slot	One M.2 slot for WiFi and Bluetooth combo card	

Communications

Ethernet	10/100 Mbps Ethernet controller integrated on system board
Wireless	• WiFi 802.11ac
	 WiFi 802.11b/g/n
	 Bluetooth 4.2
	Bluetooth 4.0

Video

	Integrated	Discrete
Controller	7th generation AMD APU Radeon Graphics	 AMD Radeon R5 M435 Graphics AMD Radeon R7 M445 Graphics AMD Radeon R7 M445DX Dual Graphics

	Integrated	Discrete
		NOTE: AMD Radeon M445DX Dual graphics is supported on computers with AMD A10-9600P processor, AMD A12-9700P processor, or AMD FX-9800P processor with R7 M445 discrete graphics.
Memory	Shared system memory	Up to 4 GB GDDR5

Audio

ridaio	
Controller	Realtek ALC3234 with Waves MaxxAudio Pro
Speakers	Two
Speaker output	Average – 2 WPeak – 2.5 W
Microphone	Digital-array microphones
Volume controls	Media-control shortcut keys

Storage



NOTE: The computer is shipped with either hard drive or solid-state drive, depending on the configuration ordered.

Interface	 SATA 6 Gbps for hard drive and solid- state drive SATA 1.5 Gbps for optical drive
Hard drive	One 2.5-inch drive
Solid-state drive	One 2.5-inch drive
Optical drive	One 9.5 mm DVD+/-RW drive

Media-card reader

Type One SD-card slot

SD card

SD High Capacity (SDHC) card SD Extended Capacity (SDXC)

card

Keyboard

Cards supported

Type Standard keyboard

Backlit keyboard (optional)

Shortcut keys Some keys on your keyboard have

two symbols on them. These keys can be used to type alternate characters or to perform secondary functions. To type the alternate character, press Shift and the desired key. To perform secondary functions, press Fn and the desired key.

NOTE: You can define the primary behavior of the shortcut keys by pressing Fn+Esc or by changing Function Key **Behavior** in System Setup.

Keyboard shortcuts

Camera

Resolution Still image: 0.92 megapixel

Video: 1280 x 720 (HD) at 30 fps

(maximum)

Diagonal viewing angle 74 degrees

Touch pad

Resolution • Horizontal: 1228 dpi

Vertical: 928 dpi

Dimensions

• Height: 80 mm (3.15 in)

• Width: 105 mm (4.13 in)

Power adapter

Type • 45 W

• 65 W

Input voltage 100 VAC-240 VAC

Input frequency 50 Hz-60 Hz

Input current (maximum) 1.30 A/1.60 A/1.70 A

Output current (continuous) 2.31 A/3.34 A
Rated output voltage 19.50 VDC

Temperature range: Operating 0°C to 40°C (32°F to 104°F)

Temperature range: Storage -40°C to 70°C (-40°F to 158°F)

Battery

Type 3-cell 42 WHr smart lithium ion

Dimensions:

Width 97.15 mm (3.82 in)

Depth 184.15 mm (7.25 in)

Height 5.90 mm (0.23 in)

Weight (maximum) 0.2 kg (0.44 lb)

Voltage 11.40 VDC

Operating time Varies depending on operating conditions and can

significantly reduce under certain power-intensive

conditions.

Life span (approximate) 300 discharge/charge cycles

Temperature range:

0°C to 35°C (32°F to 95°F)

Operating

Temperature range:

-40°C to 65°C (-40°F to 149°F)

Storage

Coin-cell battery CR-2032

Display

	HD+	FHD
Туре		17.3 inch
Resolution (maximum)	1600 x 900	1920 x 1080
Pixel pitch	0.2388 mm	0.1989 mm
Refresh rate		60 Hz
Operating angle	0 degrees (closed) to 135 degrees	
Controls	Brightness car	n be controlled using shortcut keys
Dimensions:		
Height (including bezel)		279.54 mm (11.01 in)
Width (including bezel)		422.95 mm (16.65 in)
Diagonal (excluding bezel)		438.38 mm (17.26 in)

Computer environment

Airborne contaminant level: G1 as defined by ISA-S71.04-1985

	Operating	Storage
Temperature range	0°C to 35°C (32°F to 95°F)	-40°C to 65°C (-40°F to 149°F)
Relative humidity (maximum)	10% to 90% (non- condensing)	0% to 95% (non- condensing)
Vibration (maximum)*	0.66 GRMS	1.30 GRMS
Shock (maximum)	110 G [†]	160 G [‡]
Altitude (maximum)	-15.2 m to 3048 m (-50 ft to 10,000 ft)	-15.2 m to 10,668 m (- 50 ft to 35,000 ft)

^{*} Measured using a random vibration spectrum that simulates user environment.

[†] Measured using a 2 ms half-sine pulse when the hard drive is in use.

[‡] Measured using a 2 ms half-sine pulse when the hard-drive head is in parked position.

Keyboard shortcuts

Keys	Description
F1	Mute audio
F2 📦	Decrease volume
F3 🐠	Increase volume
F4 •••	Play previous track/chapter
F5 ▶Ⅱ	Play/Pause
F6 ▶₩	Play next track/chapter
F8 🚉	Switch to external display
F9 ρ	Search
F10	Toggle keyboard backlight (optional)
(F11 ∰	Decrease brightness
F12 ★	Increase brightness
	Turn off/on wireless
Fn + B	Pause/Break
Fn + Insert	Sleep
Fn + S	Toggle scroll lock
Fn + H	Toggle between power and battery- status light/hard-drive activity light

Keys	Description
Fn + R	System request
Fn + Ctrl	Open application menu
Fn + Esc	Toggle Fn-key lock
Fn + End →	End
Fn + ←Home	Home
Fn + PgDn	Page down
Fn + PgUp	Page up

Getting help and contacting Dell

Self-help resources

You can get information and help on Dell products and services using these self-help resources:

Information about Dell products and

Windows 8.1 and Windows 10

www.dell.com

services

Dell Help & Support app



Windows 10

Get started app



Windows 8.1

Help + Tips app



Accessing help in Windows 8, Windows 8.1, and Windows 10

In Windows search, type Help and Support, and press Enter.

Accessing help in Windows 7

Click Start → Help and Support.

Online help for operating system

www.dell.com/support/windows www.dell.com/support/linux

Troubleshooting information, user manuals, setup instructions, product specifications, technical help blogs, drivers, software updates, and so on.

www.dell.com/support

Learn about your operating system, setting up and using your computer, data backup, diagnostics, and so on.

See *Me and My Dell* at www.dell.com/support/manuals.

Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see www.dell.com/contactdell.



NOTE: Availability varies by country and product, and some services may not be available in your country.



NOTE: If you do not have an active internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.