

Dell Online Diagnostics
Version 2.19.2

Readme



Dell Online Diagnostics, a stand-alone suite of diagnostic programs or test modules allows you to run diagnostic tests on Dell systems in a production environment and helps you ensure maximum uptime of your Dell systems.

What's New

New major features

- Support for the following systems:
 - R320
 - R420
 - R520
 - M420
 - M520

New Operating Systems support

Linux:

- Centos 5.5 (x86_64)

VMWare:

- ESX 4.1 Server Update 2

Virtualization:

- Citrix XenServer 6.0

New hardware support

- Dell PowerEdge Systems: R320, R420, R520, M420, and M520

Hardware and Software Requirements

Hardware Requirements

The following hardware supports Dell Online Diagnostics:

Tape Drives

- Dell PowerVault 110T/114T LTO-3 - 060
- Dell PowerVault LTO-4-120

Tape Arrays, Autoloaders, and Libraries

- Dell PowerVault ML6000-LTO-4
- Dell PowerVault TL2000-LTO-4
- Dell PowerVault TL4000-LTO-4

External Storage Enclosures

- Dell PowerVault MD1200
- Dell PowerVault MD1220

Removable Disk Drives

- Dell PowerVault RD1000 Internal SATA Drive

Diagnostics for RAID Controllers, SAS Controllers, SCSI Controllers, and the following Attached Hard Drives

- PERC H200 Adapter
- SAS 6Gbps HBA
- PERC H310 Adapter, Mini Blade, Mini Monolithic, and Embedded
- PERC H710P Adapter, Mini Blade, and Mini Monolithic
- PERC H710 Adapter, Mini Blade, and Mini Monolithic
- PERC H810 Adapter
- PERC S110

Diagnostics for Fibre Channel Controllers

- Qlogic QME8142 10G FCoE Mezzanine card
- Emulex OCm10102-FM CNA Dual port Mezzanine card
- Emulex LPe1205-M Dual port FC8 HBAs Mezzanine card
- Emulex LPe1150, 4Gb, Optical, Host Bus Adapter
- Emulex LPe12002 Dual Channel 8Gb, Optional, Host Bus Adapter
- Emulex LPe12000 Single Channel 8Gb, Optional, Host Bus Adapter
- Emulex LPe11002 Dual Channel 4Gb, Optional, Host Bus Adapter

Software Requirements

Dell Online Diagnostics runs on the following Operating Systems:

Microsoft Windows

- Microsoft Windows Server 2008 Standard, Enterprise, and Datacenter (x86_64) R2 editions
- Microsoft Windows Server 2008 Core Standard, Enterprise, and Datacenter (x86_64) R2 editions
- Microsoft Windows Server 2008 Web, Standard, and Enterprise (x86) SP2 editions
- Microsoft Windows Server 2008 Core Standard and Enterprise (x86) SP2 editions

- Microsoft Windows Server 2008 Standard, Enterprise, and Datacenter (x86_64) SP2 editions
- Microsoft Windows Server 2008 Core Standard, Enterprise, and Datacenter (x86_64) SP2 editions
- Microsoft Windows Storage Server 2008 Express, Workgroup, Standard, and Enterprise editions
- Microsoft Windows Small Business Server 2008 Standard and Premium editions
- Microsoft Windows Server 2008 Standard, Enterprise, and Datacenter (x86_64) R2 SP1 editions
- Microsoft Windows Essential Business Server 2008 (x86_64)
- Microsoft Windows 2011 Small Business Server (x86_64)

GNU/Linux

- SUSE Linux Enterprise Server 11 with SP1 (x86_64)
- Red Hat Enterprise Linux 5.7 Server (x86)
- Red Hat Enterprise Linux 5.7 Server (x86_64)
- Red Hat Enterprise Linux 6.1 Server (x86_64)
- Red Hat Enterprise Linux 6.1 Server for HPC (x86_64)
- SUSE Linux Enterprise Server 10 with SP4 (x86_64)
- SUSE Linux Enterprise Server 11 SP2 (x86_64)

Installation

To install Dell online diagnostics, you need to be an administrator or have administrator rights.

Prerequisites

- Dell Online Diagnostics installation requires a minimum free space of 40 MB on your system drive. Uninstallation requires a minimum free space of 40 KB on your system drive (C: on Windows or /opt on Linux).
- Compatibility Arch Support packages on Red Hat Enterprise Linux 64-bit systems are required as the Online Diagnostics GUI is a 32-bit application.

NOTE: If Compatibility Arch Support packages are missing when Dell Online Diagnostics launches on your Red Hat Enterprise Linux x86_64 system, the following message displays: Compatibility Arch Support package(s) [gtk, pango, and redhat-artwork] is not installed on this system.

If the Compatibility Arch Support packages are missing, install the packages using the following steps:

1. Run Red Hat Package Management Utility (redhat-config-packages).
2. Select the Compatibility Arch Support checkbox in the Package Management window and click Details. The Compatibility Arch Support Details window displays. Ensure that the following packages: gtk, pango, and redhat-artwork are selected for installation from the new window.
3. Click Close in the Compatibility Arch Support Details window.
4. Click Update in the Package Management window.

See the Dell Systems Management Tools and Documentation DVD for more information.

Installation

On Microsoft Windows Operating Systems

To install Dell Online Diagnostics on Windows Operating Systems, do the following:

1. Download the **.exe** file from support.dell.com or from the *Dell Systems Management Tools and Documentation* DVD.
2. Launch this application.
3. Choose a directory on your system where you want the extracted files to reside.
4. To use the GUI, run the tool from the Windows **Start** menu.
5. To use the CLI on Windows, click **Start -> Programs -> Online Diagnostics 2.19.2 -> Online Diagnostics CLI**.

On Enterprise Linux (RedHat, SUSE and CentOS) and virtual(VmWare and Citrix) Operating Systems

To install Dell Online Diagnostics on Enterprise Linux Operating Systems do the following:

1. Unzip the **tar.gz** file to a desired location. The extracted files contain an install script: **install.sh**, and some Red Hat Package Manager (RPM) packages.
2. Install the RPM packages using **install.sh**. All the files needed to run Dell Online Diagnostics are extracted to the default installation directory **/opt/dell/onlinediags**.
3. Go to the **onlinediags** directory and run **startDiags.sh** from an X session to launch the GUI application.
4. To use the CLI on Linux, run **pediags** from **/oldiags/bin** in the installation directory.

NOTE: srvadmin-hapi component fails to install if your system does not have the minimum version of OpenIPMI required by srvadmin-hapi. In this case, if IPMI is supported on your system, download OpenIPMI from support.dell.com or install OpenIPMI from the Dell Systems Management Tools and Documentation DVD by running **./srvadmin-openipmi.sh** from the **srvadmin/linux/supportscripts** directory.

Upgrade/Downgrade

To upgrade or downgrade Dell Online Diagnostics, first uninstall all existing versions.

Uninstallation

From Windows Operating Systems

To uninstall Dell Online Diagnostics from Windows Operating Systems, use one of the options below:

- Go to **Start -> Programs-> Online Diagnostics 2.x.y -> Uninstall**.
- Run the **Uninst.exe** from **X:\<Install_directory>\online_diagnostics**, where X is the system drive where the files are installed.

From Enterprise Linux Operating Systems: RedHat, SUSE, and VMWare

To uninstall Dell Online Diagnostics from Enterprise Linux Operating Systems (Red Hat, SUSE, or VMware), run **uninstall.sh** from the **install** directory.

Notes

- Do not update the NIC drivers when you run tests. The tests may produce unexpected results.
- During the Autoloader Self Test, the Tape Device Self Test displays a warning Data on the media will be destroyed! message at the start.
NOTE: This message applies specifically to tape drives and is not valid for Autoloaders.
- Start a fresh session of Dell Online Diagnostics after installing the Dell components required by Dell Online Diagnostics, so as to benefit from the newly installed components.

Open Issues and Resolutions

On All Operating Systems

- You may get unexpected results on disconnecting the USB cable while running a diskette test on a USB diskette drive. On systems running Red Hat Enterprise Linux products, the operating system may stop responding. On systems running Windows, the test may never complete.
- Running NIC diagnostics which disconnect the network may also cause a Server Administrator user session to be logged out and disruption of applications that require or use a network connection.
- Running multiple NIC diagnostics together on a NIC may result in the failure of the NIC Communication Test.
Resolution: Select and run NIC Communication Tests individually to obtain accurate results.
- Running diagnostic tests on unsupported tape devices on PowerEdge systems might produce unexpected or erroneous results.
NOTE: See the *ReadMe* for a list of supported tape drives for Dell servers.
- In the Command Line Interface (CLI), if you abort a diagnostic test, the test results may not display in some scenarios.
Resolution: Ensure Tests complete so that test results display.
- The Disk Self Test may fail if you remove the hard disk while the test is running. The test may also fail the first time it is run after re-inserting the disk.
Resolution: Rerun the test again.
- When Picker is loaded with a media and Tape Device Self Test is run on an auto-loader (Dell PowerVault 124T), the following warning message may display: The tape device appears to have encountered an error while running its built-in Self Test. Switch the tape device off and on and try the test again. If this error persists, it indicates a hardware problem.
Resolution: Unload the Picker and run the test again.
- When a defective media is inserted in a LTO4 drive, the following message displays in English, Incompatible or corrupt media in the drive or media not present. Load a compatible media and run the test again. For non-English systems the following message displays Media is not present in the drive or incompatible media. Load a compatible cartridge before running this test.
- SAS PHY Integrity Test fails when run simultaneously on a MD1000 connected to a PERC card and an Internal Backplane connected to a non-PERC card. This failure does not indicate any hardware error.
Resolution: Run the test separately.
- When you save test results or configuration using the **Save Results** or **Save Configuration** menu options, with a file name that has double-byte characters (Japanese or Simplified Chinese languages), the resulting **.zip** file is created without an HTML file.
Resolution: Create the file using ASCII characters to avoid this error situation.
- On R420, R520, R320, M520 and M420 network vendor tests from Broadcom and Intel are not supported.

On Windows Operating Systems

- On Windows Small Business Server systems, network administrator is not a full privileged Administrator to run Dell Online Diagnostics
Resolution: To run Dell Online Diagnostics on these systems, do the following:
 1. Click **Start-> Programs-> Online Diagnostics 2.19.2**
 2. Right click **Dell Online Diagnostics GUI** or **Dell Online Diagnostics CLI**
 3. Select **Run as Administrator**
- After running Dell Online Diagnostics, the following errors are logged in the Event Viewer System Log by the Removable Storage Service.
Type: Error, Source: DCOM
Type: Error, Source: Removable Storage Service
These entries are logged because Dell Online Diagnostics stops the Removable Storage Service in order to scan the system for those tape devices on which diagnostics are to be done. After performing the scan, the Removable Storage Service restarts.
- CLI commands used while installing Dell Online Diagnostics do not work if the application install path contains special characters like # or % in the folder path.
- If you start Dell Online Diagnostics immediately after installing a driver, the tests may not be available in the Select Test(s) to Run tree as it takes some time for the driver to get installed completely.
Resolution: Wait for some time before starting Dell Online Diagnostics.
- If the floppy media is ejected while executing diagnostic tests on a USB floppy drive, you may not be able to stop the drive, using the Safely Remove Hardware feature from the Windows system tray.
- On Japanese or Chinese Microsoft Windows operating systems, the device description of external USB devices may contain junk characters. If it is a non-Dell device, Dell recommends that the device is disconnected before you start Dell Online Diagnostics.
- In Windows Server 2008 systems with UAC on, users without administrative privileges are prompted for the administrator password. With UAC off, users with administrative privileges only can run Dell Online Diagnostics.
- On Windows Server 2008 systems, Floppy tests might take a longer time to complete as compared to the previous versions of Windows.
- CD/DVD Read Exerciser Test fails on Microsoft Windows Server 2008 Core operating systems as the dependent Windows API command fails to execute.
- On Windows Server 2008 Server Core operating systems, you may not be able to save test results or configuration using the GUI menu.
Resolution: You can access the test configuration and results files that Dell Online Diagnostics stores automatically at the **X:\dell\diagnostics\log** directory, where X is the system drive.
- On Windows operating systems, when you run diagnostic tests on multiple Broadcom Network Interface Controllers (NICs) at the same time, some tests may fail. Also, a warning sign may be noted in Device Manager for some NICs.
Resolution: Run one diagnostic test on one NIC at a time for accurate results.
- For operating systems released prior to Microsoft Windows Server 2008, the SATA CD-DVD attached to the NVIDIA SATA controller is displayed under System in the tree view.
- NIC Communication Test may fail if IPv6 is enabled.
- On USB Hub test result tab, Device, Test, and Result Details are not available.
- On some Western Digital hard drives, Disk Self test hangs at 90 percent.
- Interrupt test might fail intermittently when run multiple times.
Resolution: Re-run the test.
- Dell Online Diagnostics Application may crash intermittently in quick mode when more than 50 tests are executed in parallel.
Resolution: The same tests can be executed in CLI mode.

On Enterprise Linux and ESX Operating Systems

- Running the CD/DVD Read Exerciser test on corrupt CD media or on a faulty drive may cause the test to run for a longer duration, and Dell Online Diagnostics may appear to hang.
Resolution: Terminate Dell Online Diagnostics and try running the test again in the Quick Test mode.
- Serial port tests are not enumerated on Red Hat Enterprise Linux Version 5 Update 3 with XEN kernel because XEN kernel uses the serial port during system boot up and the operating system fails to load the serial port driver.
- Intel Offline Test fails when the network services are stopped, if the adapter is not configured for Wake-on-LAN (WOL) or Manageability and the PHY is powered off. However, as the test powers on the PHY and enables WOL, the test passes from the next time onward.
- Connecting or removing USB or CD/DVD devices from Red Hat Enterprise Linux systems, while the enumeration is in progress, may cause the system to hang.
Resolution: Wait for enumeration to complete, before connection or removing USB or CD/DVD devices from Red Hat Enterprise Linux systems.
- If tapeware is installed, Dell Online Diagnostics may fail to start.
Resolution: Delete the softlink entry `/lib/libstdc++-libc6.2-2.so.3` and restart Dell Online Diagnostics. If there are still issues, contact the Tapeware support team for help.
- ICH7R IDE controllers are not supported. Running tests on this controller or the devices connected to it may cause unexpected behavior.
- When you run a SCSI Communication test on a channel that has an LTO3 tape drive connected to it and perform a backup simultaneously using tar commands, the backup operation may fail.
Resolution: Ensure that backup or restore operations are not in progress before running the SCSI Communication test.
- When the Yosemite backup software is installed on a system that has a tape changer, SCSI Communication tests and tape tests may fail.
Resolution: Ensure that the Yosemite backup software service is stopped before running these tests.
- The Tape Self Test writes to and advances the tape media during execution. Manual erase operations using the Linux command `mt -f/dev/stX erase`, if executed immediately after the Tape Self Test execution, will fail with an I/O error.
Resolution: Avoid this error condition by always rewinding the tape media after running the Tape Self Test.
- When a non-root user uses `su` to become a superuser (root), some tests may not work in the CLI, when the `pediags` command is run.
Resolution: Users should use `su -` to become a super user to run the `pediags` command.
- On SUSE Enterprise Server 10, with ArpArmor enabled and when you run network diagnostics on a console, warning messages display indicating a violation of policy.
- Multiple USB devices, when connected to a deep hierarchy of bus powered USB Hubs, cause the Linux USB device driver sub-system to become unresponsive. This prevents Dell Online Diagnostics from launching in the GUI mode.
Resolution: Follow the steps below if faced with this issue:
 1. Disconnect the top-level hub connected to the system.
 2. Connect external power supply (if supported) to this hub.
 3. Disconnect all the devices from the hub.
 4. Reconnect the hub to the server.
 5. Reconnect the devices on server ports (if available) and to other higher level hub ports having external power supply, if required.
- If the SCIM RPM is installed, keyboard navigation may not function correctly while selecting the Selection Options.
- POST Result test will not be available on systems running on Linux operating systems and having an IDE Virtual CD Drive with `ide-cd` driver module.
Resolution: Refer to the PSQN No. F25CF0642DD7B211E030030ABD6273EA.

- The onboard SATA disks diagnostic tests are not supported. In the Dell Online Diagnostics GUI, the controller and the tests are disabled and the message Diagnostic tests are not supported on the device displays in the Configuration tab. On VMWare, running the `pediags idedevdiag --show` command does not enumerate the SATA disks.
- NIC Communication Test may fail if IPv6 is enabled.
- If the memory and DRAC tests get disabled in Dell Online Diagnostics, restart the Systems Management Device Driver service (`instsvcdrv`) to enable the memory and DRAC tests.
- USB controllers are not supported on VMware ESX 4.1 Update 2.
- On SLES 10 SP4 and RHEL 5.7 x64 systems, memory and serial port diagnostics are not available if OpenManage version 6.3 or later is installed.

Resolution: Uninstall OpenManage and reinstall Dell Online Diagnostics.

- On VMware ESX 4.1 Update 2 and Citrix 6.0, the NIC Communication test is not available for paravirtualized devices, such as `vswif` (Service Console).
- On VMware ESX Classic, if USB DVDROM is removed while running the tests, the behavior of Dell Online Diagnostics is unexpected and the tests do not complete. In this situation, the Abort functionality does not work.
- Fibre Channel Adapters are not supported on VMware ESX 4.1 Update 2 and 64-bit Linux operating systems, because the required drivers or utilities are unavailable.
- On RHEL 6.1 network vendor tests from Broadcom and Intel are not supported.
- For all Blade servers (PowerEdge M-series) diagnostics for serial port are not supported on Linux operating systems.

Global Support

For information on technical support, visit www.dell.com/contactus.

For issues, mail to Support_OnlineDiagnostics@dell.com

For information on documentation support, visit support.dell.com/manuals. On the **Manuals** page, click **Software ->Serviceability Tools**. Click on the specific product on the right-side to access the documents.

Information in this document is subject to change without notice.

© 2012 Dell Inc. All rights reserved.

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: Dell™, the DELL logo, PowerEdge™, and PowerVault™ are trademarks of Dell Inc. Intel®, Core™ are registered trademarks of Intel Corporation in the U.S. and other countries. Microsoft®, Windows®, and Windows Server® are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries. Red Hat Enterprise Linux® and Enterprise Linux® are registered trademarks of Red Hat, Inc. in the United States and/or other countries. SUSE™ is a trademark of Novell Inc. in the United States and other countries. Xen®, and XenServer® are either registered trademarks or trademarks of Citrix Systems, Inc. in the United States and/or other countries. VMware® is a registered trademark of VMWare, Inc. in the United States or other countries.

Other trademarks and trade names may be used in this publication to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

2012 – 5

Rev. A00