

# Dell EMC OpenManage Deployment Toolkit 6.2 for Microsoft Windows Preinstallation Environment Release Notes

## Topics:

- Release Type and Definition
- DTK Deprecation Message
- Importance
- Platforms Affected
- What Is Supported
- What's New
- Important Notes
- Known Issues
- Installation Prerequisites
- Upgrading From Previous Versions
- Contacting Dell

This document describes the new features, enhancements, and fixed issues in Dell Openmanage Deployment Toolkit 6.2 for Microsoft Windows Preinstallation Environment

## Release Type and Definition

## Deployment ToolKit

The Dell OpenManage Deployment Toolkit (DTK) includes a set of utilities, scripts, and sample configuration files that to deploy and your Dell system. You can use DTK to build script-based and RPM-based installation for deploying large number of systems on a pre-operating system environment in a reliable way, without changing their current deployment processes.

In addition to the command line utilities used to configure various system features, DTK also provides sample scripts and configuration files to perform common deployment tasks and documentation.

## Version

6.2

## Release Date

November 2018

## Previous Version

6.1

# DTK Deprecation Message

The OpenManage Deployment Toolkit (DTK) along with the associated tools and capabilities will be deprecated for version 6.1 and later:

- Redundant Array of Independent Disks Configuration (RAIDCFG) Utility
- System Configuration (SYSCFG) Utility
- ELI tool
- Utility Partition (UPINIT)

It is recommended to use the RACADM Command Line (CLI) as a replacement for the RAIDCFG and SYSCFG utilities. For more information on downloading RACADM, see [www.dell.com/Support/Home](http://www.dell.com/Support/Home).

**i NOTE: DTK will continue to support any new hardware or operating system for the 14th generation of PowerEdge servers. However, support for later generations of PowerEdge servers will be deprecated. For more information about features supported by DTK, see the latest User's Guide available at [www.dell.com/OpenManageManuals](http://www.dell.com/OpenManageManuals).**

## Importance

**RECOMMENDED:** Dell recommends applying this update during your next scheduled update cycle. The update contains feature enhancements or changes that will help keep your system software current and compatible with other system modules (firmware, BIOS, drivers and software).

## Platforms Affected

For a complete list of supported Dell PowerEdge systems and supported Operating systems, see the *Dell Systems Software Support Matrix* available in the required version of OpenManage Software at [dell.com/openmanagemanuals](http://dell.com/openmanagemanuals).

## What Is Supported

## Hardware and Software Requirements

Before beginning the deployment process, ensure that you have the following tools, software, and information ready to use:

- Advanced knowledge of Windows.
- Windows Assessment and Deployment Kit (ADK) to build Windows PE.
- Working knowledge of Microsoft Remote Installation Services (RIS) and Automated Deployment Services (ADS) (including setting up of RIS and ADS environments), or any other third-party deployment system or tool.
- Working knowledge of Windows Deployment Services (WDS) or any other third-party deployment system or tool for Windows PE.
- A workstation with the following capabilities:
  - A writable CD/DVD drive and CD/DVD writing software
  - Network access
- A target system with a CD/DVD drive if you are performing a local deployment or network access if you are performing a network deployment.
- All Deployment Toolkit utilities, sample scripts, and sample configuration files.
- All required Windows PE drivers, operating system drivers, and the Dell utility partition image file.
- A minimum BIOS version is recommended on some of the platforms for all the DTK options to work correctly. In general, it is good practice to use the latest ("n") version of BIOS firmware or the "n-1" version that is available on "dell.com/support." For more information see the Dell Systems Software Support Matrix available in the required version of OpenManage Software at [dell.com/openmanagemanuals](http://dell.com/openmanagemanuals).

## Operating Systems Requirements

DTK Utilities (SYSCFG and RAIDCFG) and scripts (sample) supports Windows PE 5.1 and Windows PE 10.0.

For Microsoft WinPE and OS deployment support limitations refer to <http://technet.microsoft.com/en-us/library/hh824993.aspx>.

DTK helps deploy the following Microsoft Windows Server Operating Systems:

- Microsoft Windows Server 2012 R2 Foundation, Essentials, Standard, and Datacenter editions
- Microsoft Windows Server 2016 Essentials, Standard, and Datacenter editions

## What's New

The new features for this release include:

- Support for the following network cards:
  - QLogic 10GE 4P QL41164HxRJ-DE Adapter.
  - QLogic 10GE 4P QL41164HxRJ-DE Adapter.
  - QL41262HMKR-DE 25 Gigabit Ethernet.
  - QLogic FastLinQ 41262 Dual Port 25GbE SFP28 rNDC.
  - QLogic 2x25GE QL41262HMCU CAN.
  - Intel(R) Ethernet 25G 2P XXV710 Adapter.
  - Intel(R) Ethernet 10G 2P X550-t Adapter.
  - Intel(R) Gigabit 4P I350-t Adapter.
  - Intel(R) 10GbE 4P X710-t Adapter.
  - Intel(R) 4P X550 rNDC.
  - ConnectX-5 Dual Port 100 GbE QSFP Network Adapter.
  - ConnectX-4 Dual Port 100 GbE QSFP Network Adapter.
  - ConnectX-5 Single Port VPI EDR QSFP28 Adapter.
- Added support for the following Dell PowerEdge servers:
  - PowerEdge R240
  - PowerEdge R340
  - PowerEdge T140
  - PowerEdge T340
  - PowerEdge R740xd2

 **NOTE:** For the list of supported operating systems and Dell servers, see the *Dell Systems Software Support Matrix* at [dell.com/openmanagemanuals](http://dell.com/openmanagemanuals).

## Important Notes

This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>).

### DTK operating system deployment limitation:

DTK does not support operating system deployment, when multiple boot VDs exist on a single controller or when the server has multiple boot controllers. If multiple boot controllers exist on the server, the boot VD must be created on any one of the controllers, and the boot VD must be set as first boot device in system BIOS.

On debranded or rebranded servers, Deployment toolkit is not supported.

 **NOTE:** During booting WInPE ISO image for Windows PE 5.1 and Windows PE 10.0 user will not be prompted for entering any key to continue.

## SYSCFG

- Some options may not be present on all systems, which may be due to the BIOS version or hardware feature set. The usage information generated by running **SYSCFG** without arguments shows only those options that are valid for your system.
- The **--devseq** option is present only if you have an available, bootable hard-disk partition. If this option is present in the configuration file, but not present on your system, you will receive a usage error.
- It is required to perform a warm reboot after applying the SYSCFG settings changes on Dell PowerEdge 12th generation of PowerEdge systems.
- If you perform operations that change the "--redmem" option, reboot your system immediately. It is applicable to both command line and "--infile" usage.

***(i) NOTE:*** Additionally, the **--redmem** option should not be issued with any other command and should be immediately followed by a system reboot. This is important when you develop scripts that can alter the **--redmem** setting.

- For options that use text strings such as username, password, hostname, and community string, using characters such as <space>, "<," ">," "|," "=" on the command line can be misinterpreted by the command line parser and may cause errors. To avoid such errors, use only alphanumeric characters.
- If you set the username using syscfg username option, Serial over LAN (SOL) access for the corresponding user will be enabled by default. You can disable SOL access for a user using **syscfg solaction --userid=<userid> --action=disable** command.

## RAIDCFG

- When creating virtual disks, the chunk (stripe) size is always in KBs. Do not specify any units of measure for the chunk size.
- When providing multiple physical disks for the "create virtual disk" command, do not separate the disks with spaces. For example, "-ad=1:4, 1:5" causes an error. The correct way to input multiple physical disks is "-ad=1:4,1:5,1:6" or "-ad=1:4:0,1:5:0,1:6:0".
- If you change the controller mode from SCSI to RAID mode, data loss may occur. Back up any data you require before changing the modes.
- For creating RAID0 on any SWRAID controller minimum two hard-disks to be connected.
- SwRAID does not support blink/unblink operation.
- RAIDCFG operations can not be performed on HBA330 and AHCI non-raid mode.

**Table 1. Support Matrix for controller cards**

| Controller type   | OSD support with PowerEdge MX740c and PowerEdge MX840c | OSD support with MX5016s | Virtual disk, Physical disk support with Compute backplanes | Virtual disk, Physical disk support using MX5016s HDDs |
|-------------------|--|--------------------------|---|--|
| H745P MX          | YES  | NO                       | YES   | YES  |
| H730P MX          | YES  | N/A                      | YES   | N/A  |
| HBA330 MX         | YES  | N/A                      | PD = YES ; VD = NO  | N/A  |
| S140 (SATA)       | YES  | YES                      | N/A   | YES  |
| HBA330 MMZ        | NO   | NO                       | PD = YES ; VD = NO  | PD = YES ; VD = NO                                     |
| S140 + NVMe disks | NO   | N/A                      | YES   | N/A  |

## Known Issues

### SYSCFG Issues

- In DRAC , the **--virtualmedia** and **--vflash** options do not work if there is an active virtual media session. Disconnect the virtual media using the DRAC GUI. Log into DRAC. **Click Media > Virtual Media > Disconnect**.
- The syscfg --bootseq command detects CD-ROM with SAS/SATA controllers as unknown.unknown.n-1.
- On R815, syscfg power --profile option allows to set apc. Though apc is not supported on R815, syscfg does not throw an error message.
- The legacy attribute values enable and disable are also supported for 12G systems for backward compatibility. In future releases, these arguments might be deprecated. Try to use the values shown in help message for BIOS options for 12G server.
- Some options may not be present on all systems, which may be due to the BIOS version or hardware feature set. The usage information generated by running SYSCFG without arguments shows only those options that are valid for your system.
- The option for **powerctl**, which is **softshutdown**, does not work on Windows PE.
- The **--solbitrate** option in **solcfgparams** and the **--mgscommbitrate** option in **serialcfgparams** accept a baud rate of 57600, but tools such as "ipmish" and "solproxy" do not function at that baud rate for PowerEdge systems.
- Intel(R) Gigabit 4P I350-t rNDC card x32 driver shows the following warning message "Windows cannot verify the publisher of this driver software" on Win7 x32, while injecting due to expired certificate.

## RAIDCFG Issues

- If both the software and hardware RAID is enabled, raidcfg will show the same controller ID for both the controllers. Disable either software raid or insert the hardware raid other than PCIe slot 0 in the server.
- You can assign up to 10 Global hot spares using Raidcfg. Use the Dell OpenManage Server Administrator Storage Management for assigning more than 10 Global hot spares.
- Raidcfg does not support Non RAID (Volume) mode on S140 controller.
- On Software RAID Controller, NVMe PCIe-SSD add-on card is not supported.
- Lockdown Mode enabled will not impact with Raidcfg functionality.
- On Dell PERC H740 controllers, conversion of a RAID Capable Disk to Non-RAID disk and vice versa is not supported using RAIDCFG.

## RACADM Issues

- If you use virtual media to boot into Windows PE, executing certain RACADM commands may cause Windows PE to crash.
- After generating the rac configuration file using the `racadm getconfig -f <file_name>` command, comment out the following properties in the configuration file before you update a configuration using the `racadm config -f <file_name>` command:
  - `#cfgRacTuneCtrlEConfigDisable=0`
  - `#cfgRacTuneLocalConfigDisable=0`
- VLAN objects (cfgNicVLanEnable, cfgNicVLanId, and cfgNicVLanPriority) displayed using the local RACADM command `racadm getconfig -g cfgLanNetworking` or VLAN objects generated in the configuration file using the local RACADM command `racadm getconfig -f <file name>` do not contain the leading "#" symbol, which indicates that they are read-only.

## Windows PE Issues

- Running partcfg.bat may fail when virtual media is enabled. For the hard disk, partcfg.bat uses the driver letter "c:". When virtual media is enabled, sometimes, the virtual device gets assigned with the drive letter "c:" And, partcfg.bat execution fails. To run partcfg.bat successfully, either disable the virtual media or use the diskpart command to assign a free driver letter for partcfg.bat.
- Software RAID S140 supported only on Windows 64-bit operating system.

## Installation Prerequisites

Before extracting Deployment Toolkit components, ensure that you have:

- Download the DTK ISO from [dell.com/support](http://dell.com/support)
- A workstation that has 512 MB RAM
- A writable CD drive and CD-writing software (optional)
- Network access
- A minimum BIOS version is recommended on some of the platforms for all the DTK options to work properly. In general, it is a good practice to use the latest ("n") version of BIOS firmware or the "n-1" version that is available on "dell.com/support."

## Installation Procedure

For complete installation and deployment instructions, see the *Dell OpenManage Deployment Toolkit User's Guide* and the *Dell OpenManage Deployment Toolkit Installation Guide* available at [dell.com/openmanagemanuals](http://dell.com/openmanagemanuals).

## Installation and Configuration Notes

- The sample scripts are provided as examples for customers who want to develop their own deployment process. Some customers may find that the scripts work well in their environment, while some customers may need to develop their own scripts entirely from scratch. Customers deploying multiple systems to provide unique information for each server when appropriate. For example, system host names, IP addresses, and BIOS asset tags need to be unique for each system. Modify the shell scripts and configuration files to reflect the unique information for each system being deployed. Many options are available to optimize this process.
- Installation of Dell utility partition is no longer supported on Windows PE.

# Upgrading From Previous Versions

When upgrading from a previous release of the DTK, ensure that you create environment for the new DTK version separately from the previous version of DTK. This step is necessary because the environments and requirements for the new DTK versions are completely different.

## Contacting Dell

 **NOTE:** If you do not have an active Internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.

Dell provides several online and telephone-based support and service options. Availability varies by country and product, and some services may not be available in your area. To contact Dell for sales, technical support, or customer service issues:

Go to [dell.com/contactdell](http://dell.com/contactdell).

**© 2018 - 2019 Dell Inc. or its subsidiaries. All rights reserved.** Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

## Notes, cautions, and warnings

 **NOTE:** A NOTE indicates important information that helps you make better use of your product.

 **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

**© 2018 - 2019 Dell Inc. or its subsidiaries. All rights reserved.** Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.