

Dell™ OpenManage™
Server Administrator

Messages Reference Guide

Notes and Cautions



NOTE: A NOTE indicates important information that helps you make better use of your computer.



CAUTION: A CAUTION indicates potential damage to hardware or loss of data if instructions are not followed.

Information in this document is subject to change without notice.

© 2009 Dell Inc. All rights reserved.

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: *Dell*, the *DELL* logo and *Dell OpenManage* are trademarks of Dell Inc.; *VMware* is registered trademark or trademark of *VMware, Inc.* in the United States and/or other countries; *Microsoft*, *Windows*, and *Windows Server* are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries; *Red Hat* and *Red Hat Enterprise Linux* are registered trademark of Red Hat, Inc. in the United States and/or other countries; *SUSE* is a registered trademark of Novell, Inc. in the United States and other countries.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

January 2009

Contents

1	Introduction	7
	What's New in this Release	7
	Messages Not Described in This Guide	8
	Understanding Event Messages	8
	Sample Event Message Text	10
	Viewing Alerts and Event Messages	10
	Logging Messages to a Unicode Text File	11
	Viewing Events in Windows 2000 Advanced Server and Windows Server 2003	11
	Viewing Events in Red Hat Enterprise Linux and SUSE Linux Enterprise Server	12
	Viewing the Event Information	13
	Understanding the Event Description	13
2	Event Message Reference	17
	Miscellaneous Messages	17
	Temperature Sensor Messages	20
	Cooling Device Messages	23
	Voltage Sensor Messages	25
	Current Sensor Messages	28
	Chassis Intrusion Messages	31

	Redundancy Unit Messages	34
	Power Supply Messages	36
	Memory Device Messages	40
	Fan Enclosure Messages	41
	AC Power Cord Messages	43
	Hardware Log Sensor Messages	44
	Processor Sensor Messages	46
	Pluggable Device Messages	49
	Battery Sensor Messages	51
	Chassis Management Controller Messages	53
3	System Event Log Messages for IPMI Systems	55
	Temperature Sensor Events	55
	Voltage Sensor Events	56
	Fan Sensor Events	57
	Processor Status Events	59
	Power Supply Events	60
	Memory ECC Events	62
	BMC Watchdog Events	62
	Memory Events	63
	Hardware Log Sensor Events	64

	Drive Events	65
	Intrusion Events	66
	BIOS Generated System Events	67
	R2 Generated System Events	73
	Cable Interconnect Events	74
	Battery Events	74
	Power And Performance Events	75
	Entity Presence Events	75
4	Storage Management Message Reference	77
	Alert Monitoring and Logging	77
	Alert Message Format with Substitution Variables	78
	Alert Message Change History	81
	Alert Descriptions and Corrective Actions	82
	Index	219

Introduction

Dell™ OpenManage™ Server Administrator produces event messages stored primarily in the operating system or Server Administrator event logs and sometimes in SNMP traps. This document describes the event messages created by Server Administrator version 6.0.1 and displayed in the Server Administrator Alert log.

Server Administrator creates events in response to sensor status changes and other monitored parameters. The Server Administrator event monitor uses these status change events to add descriptive messages to the operating system event log or the Server Administrator Alert log.

Each event message that Server Administrator adds to the Alert log consists of a unique identifier called the event ID for a specific event source category and a descriptive message. The event message includes the severity, cause of the event, and other relevant information, such as the event location and the monitored item's previous state.

Tables provided in this guide list all Server Administrator event IDs in numeric order. Each entry includes the event ID's corresponding description, severity level, and cause. Message text in angle brackets (for example, *<State>*) describes the event-specific information provided by the Server Administrator.

What's New in this Release

The following changes have been made for this release:

- Added a new alert in the “Understanding Event Messages” section.
- Added a new alert (Event ID 1013) in the “Miscellaneous Messages” section.
- Added the “POST Code Errors” table in the “BIOS Generated System Events” section.
- Added a new alert (Event ID 2382) in the “Storage Management Message Reference” section.

Messages Not Described in This Guide




This guide describes only event messages created by Server Administrator and displayed in the Server Administrator Alert log. For information on other messages produced by your system, consult one of the following sources:

- Your system's *Installation and Troubleshooting Guide*
- Operating system documentation
- Application program documentation

Understanding Event Messages

This section describes the various types of event messages generated by the Server Administrator. When an event occurs on your system, Server Administrator sends information about one of the following event types to the systems management console:

Table 1-1. Understanding Event Messages

Icon	Alert Severity	Component Status
	OK/Normal / Informational	An event that describes the successful operation of a unit. The alert is provided for informational purposes and does not indicate an error condition. For example, the alert may indicate the normal start or stop of an operation, such as power supply or a sensor reading returning to normal.
	Warning / Non-critical	An event that is not necessarily significant, but may indicate a possible future problem. For example, a Warning/Non-critical alert may indicate that a component (such as a temperature probe in an enclosure) has crossed a warning threshold.
	Critical / Failure / Error	A significant event that indicates actual or imminent loss of data or loss of function. For example, crossing a failure threshold or a hardware failure such as an array disk.

Server Administrator generates events based on status changes in the following sensors:

- **Temperature Sensor** — Helps protect critical components by alerting the systems management console when temperatures become too high inside a chassis; also monitors a variety of locations in the chassis and in any attached systems.
- **Fan Sensor** — Monitors fans in various locations in the chassis and in any attached systems.
- **Voltage Sensor** — Monitors voltages across critical components in various chassis locations and in any attached systems.
- **Current Sensor** — Monitors the current (or amperage) output from the power supply (or supplies) in the chassis and in any attached systems.
- **Chassis Intrusion Sensor** — Monitors intrusion into the chassis and any attached systems.
- **Redundancy Unit Sensor** — Monitors redundant units (critical units such as fans, AC power cords, or power supplies) within the chassis; also monitors the chassis and any attached systems. For example, redundancy allows a second or n th fan to keep the chassis components at a safe temperature when another fan has failed. Redundancy is normal when the intended number of critical components are operating. Redundancy is degraded when a component fails, but others are still operating. Redundancy is lost when there is one less critical redundancy device than required.
- **Power Supply Sensor** — Monitors power supplies in the chassis and in any attached systems.
- **Memory Prefailure Sensor** — Monitors memory modules by counting the number of Error Correction Code (ECC) memory corrections.
- **Fan Enclosure Sensor** — Monitors protective fan enclosures by detecting their removal from and insertion into the system, and by measuring how long a fan enclosure is absent from the chassis. This sensor monitors the chassis and any attached systems.
- **AC Power Cord Sensor** — Monitors the presence of AC power for an AC power cord.
- **Hardware Log Sensor** — Monitors the size of a hardware log.

- **Processor Sensor** — Monitors the processor status in the system.
- **Pluggable Device Sensor** — Monitors the addition, removal, or configuration errors for some pluggable devices, such as memory cards.
- **Battery Sensor** — Monitors the status of one or more batteries in the system.

Sample Event Message Text

The following example shows the format of the event messages logged by Server Administrator.

```
EventID: 1000
Source: Server Administrator
Category: Instrumentation Service
Type: Information
Date and Time: Mon Oct 21 10:38:00 2002
Computer: <computer name>
Description:
Server Administrator starting
Data: Bytes in Hex
```

Viewing Alerts and Event Messages

An event log is used to record information about important events.

Server Administrator generates alerts that are added to the operating system event log and to the Server Administrator Alert log. To view these alerts in Server Administrator:

- 1 Select the **System** object in the tree view.
- 2 Select the **Logs** tab.
- 3 Select the **Alert** subtab.

You can also view the event log using your operating system's event viewer. Each operating system's event viewer accesses the applicable operating system event log.

The location of the event log file depends on the operating system you are using.

- In the Microsoft® Windows® 2000 Advanced Server and Windows Server® 2003 operating systems, messages are logged to the system event log and optionally to a Unicode text file, `dcsys32.log` (viewable using Notepad), that is located in the `install_path\omsa\log` directory. The default `install_path` is `C:\Program Files\Dell\SysMgt`.
- In the Red Hat® Enterprise Linux® and SUSE® Linux Enterprise Server operating systems, messages are logged to the system log file. The default name of the system log file is `/var/log/messages`. You can view the messages file using a text editor such as `vi` or `emacs`.

Logging Messages to a Unicode Text File

Logging messages to a Unicode text file is optional. By default, the feature is disabled. To enable this feature, modify the **Event Manager** section of the `dcemdy32.ini` file as follows:

- In Windows, locate the file at `<install_path>\dataeng\ini` and set `UnitextLog.enabled=True`. The default `install_path` is `C:\Program Files\Dell\SysMgt`. Restart the **DSM SA Event Manager** service.
- In Red Hat Enterprise Linux and SUSE Linux Enterprise Server, locate the file at `<install_path>/dataeng/ini` and set `UnitextLog.enabled=True`. The default `install_path` is `/opt/dell/srvadmin`. Issue the `"/etc/init.d/dataeng restart"` command to restart the Server Administrator event manager service. This will also restart the Server Administrator data manager and SNMP services.

The following subsections explain how to open the Windows 2000 Advanced Server, Windows Server 2003, Red Hat Enterprise Linux, and SUSE Linux Enterprise Server event viewers.

Viewing Events in Windows 2000 Advanced Server and Windows Server 2003

- 1 Click the **Start** button, point to **Settings**, and click **Control Panel**.
- 2 Double-click **Administrative Tools**, and then double-click **Event Viewer**.

3 In the Event Viewer window, click the Tree tab and then click System Log. The System Log window displays a list of recently logged events.

4 To view the details of an event, double-click one of the event items.



NOTE: You can also look up the `dcsys32.log` file, in the `install_path\omsa\log` directory, to view the separate event log file. The default `install_path` is `C:\Program Files\Dell\SysMgt`.

Viewing Events in Red Hat Enterprise Linux and SUSE Linux Enterprise Server

1 Log in as root.

2 Use a text editor such as vi or emacs to view the file named `/var/log/messages`.

The following example shows the Red Hat Enterprise Linux and SUSE Linux Enterprise Server message log, `/var/log/messages`. The text in boldface type indicates the message text.



NOTE: These messages are typically displayed as one long line. In the following example, the message is displayed using line breaks to help you see the message text more clearly.

...

```
Feb 6 14:20:51 server01 Server Administrator:  
Instrumentation Service EventID: 1000  
Server Administrator starting
```

```
Feb 6 14:20:51 server01 Server Administrator:  
Instrumentation Service EventID: 1001  
Server Administrator startup complete
```

```
Feb 6 14:21:21 server01 Server Administrator:  
Instrumentation Service EventID: 1254 Chassis  
intrusion detected Sensor location: Main chassis  
intrusion Chassis location: Main System Chassis  
Previous state was: OK (Normal) Chassis intrusion  
state: Open
```

```
Feb 6 14:21:51 server01 Server Administrator:  
Instrumentation Service EventID: 1252 Chassis  
intrusion returned to normal Sensor location: Main
```

```
chassis intrusion Chassis location: Main System
Chassis Previous state was: Critical (Failed) Chassis
intrusion state: Closed
```

Viewing the Event Information

The event log for each operating system contains some or all of the following information:

- **Date** — The date the event occurred.
- **Time** — The local time the event occurred.
- **Type** — A classification of the event severity: Information, Warning, or Error.
- **User** — The name of the user on whose behalf the event occurred.
- **Computer** — The name of the system where the event occurred.
- **Source** — The software that logged the event.
- **Category** — The classification of the event by the event source.
- **Event ID** — The number identifying the particular event type.
- **Description** — A description of the event. The format and contents of the event description vary, depending on the event type.

Understanding the Event Description

Table 1-2 lists in alphabetical order each line item that may appear in the event description.

Table 1-2. Event Description Reference

Description Line Item	Explanation
Action performed was: <i><Action></i>	Specifies the action that was performed, for example: Action performed was: Power cycle
Action requested was: <i><Action></i>	Specifies the action that was requested, for example: Action requested was: Reboot, shutdown OS first
Additional Details: <i><Additional details for the event></i>	Specifies additional details available for the hot plug event, for example: Memory device: DIMM1_A Serial number: FFFF30B1

Table 1-2. Event Description Reference (continued)

Description Line Item	Explanation
<i><Additional power supply status information></i>	Specifies information pertaining to the event, for example: Power supply input AC is off, Power supply POK (power OK) signal is not normal, Power supply is turned off
Chassis intrusion state: <i><Intrusion state></i>	Specifies the chassis intrusion state (open or closed), for example: Chassis intrusion state: Open
Chassis location: <i><Name of chassis></i>	Specifies name of the chassis that generated the message, for example: Chassis location: Main System Chassis
Configuration error type: <i><type of configuration error></i>	Specifies the type of configuration error that occurred, for example: Configuration error type: Revision mismatch
Current sensor value (in Amps): <i><Reading></i>	Specifies the current sensor value in amps, for example: Current sensor value (in Amps): 7.853
Date and time of action: <i><Date and time></i>	Specifies the date and time the action was performed, for example: Date and time of action: Sat Jun 12 16:20:33 2004
Device location: <i><Location in chassis></i>	Specifies the location of the device in the specified chassis, for example: Device location: Memory Card A
Discrete current state: <i><State></i>	Specifies the state of the current sensor, for example: Discrete current state: Good
Discrete temperature state: <i><State></i>	Specifies the state of the temperature sensor, for example: Discrete temperature state: Good

Table 1-2. Event Description Reference (continued)

Description Line Item	Explanation
Discrete voltage state: <State>	Specifies the state of the voltage sensor, for example: Discrete voltage state: Good
Fan sensor value: <Reading>	Specifies the fan speed in revolutions per minute (RPM) or On/Off, for example: Fan sensor value (in RPM): 2600 Fan sensor value: Off
Log type: <Log type>	Specifies the type of hardware log, for example: Log type: ESM
Memory device bank location: <Bank name in chassis>	Specifies the name of the memory bank in the system that generated the message, for example: Memory device bank location: Bank_1
Memory device location: <Device name in chassis>	Specifies the location of the memory module in the chassis, for example: Memory device location: DIMM_A
Number of devices required for full redundancy: <Number>	Specifies the number of power supply or cooling devices required to achieve full redundancy, for example: Number of devices required for full redundancy: 4
Peak value (in Watts): <Reading>	Specifies the peak value in Watts, for example: Peak value (in Watts): 1.693
Possible memory module event cause: <list of causes>	Specifies a list of possible causes for the memory module event, for example: Possible memory module event cause: Single bit warning error rate exceeded Single bit error logging disabled
Power Supply type: <type of power supply>	Specifies the type of power supply, for example: Power Supply type: VRM

Table 1-2. Event Description Reference (continued)

Description Line Item	Explanation
Previous redundancy state was: <i><State></i>	Specifies the status of the previous redundancy message, for example: Previous redundancy state was: Lost
Previous state was: <i><State></i>	Specifies the previous state of the sensor, for example: Previous state was: OK (Normal)
Processor sensor status: <i><status></i>	Specifies the status of the processor sensor, for example: Processor sensor status: Configuration error
Redundancy unit: <i><Redundancy location in chassis></i>	Specifies the location of the redundant power supply or cooling unit in the chassis, for example: Redundancy unit: Fan Enclosure
Sensor location: <i><Location in chassis></i>	Specifies the location of the sensor in the specified chassis, for example: Sensor location: CPU1
Temperature sensor value: <i><Reading></i>	Specifies the temperature in degrees Celsius, for example: Temperature sensor value (in degrees Celsius): 30
Voltage sensor value (in Volts): <i><Reading></i>	Specifies the voltage sensor value in volts, for example: Voltage sensor value (in Volts): 1.693

Event Message Reference

The following tables lists in numerical order each event ID and its corresponding description, along with its severity and cause.



NOTE: For corrective actions, see the appropriate documentation.

Miscellaneous Messages

Miscellaneous messages in Table 2-1 indicate that certain alert systems are up and working.

Table 2-1. Miscellaneous Messages

Event ID	Description	Severity	Cause
0000	Log was cleared	Information	User cleared the log from Server Administrator.
0001	Log backup created	Information	The log was full, copied to backup, and cleared.
1000	Server Administrator starting	Information	Server Administrator is beginning to initialize.
1001	Server Administrator startup complete	Information	Server Administrator completed its initialization.
1002	A system BIOS update has been scheduled for the next reboot	Information	The user has chosen to update the flash basic input/output system (BIOS).
1003	A previously scheduled system BIOS update has been canceled	Information	The user decides to cancel the flash BIOS update, or an error occurs during the flash.

Table 2-1. Miscellaneous Messages (continued)

Event ID	Description	Severity	Cause
1004	Thermal shutdown protection has been initiated	Error	This message is generated when a system is configured for thermal shutdown due to an error event. If a temperature sensor reading exceeds the error threshold for which the system is configured, the operating system shuts down and the system powers off. This event may also be initiated on certain systems when a fan enclosure is removed from the system for an extended period of time.
1005	SMBIOS data is absent	Error	The system does not contain the required systems management BIOS version 2.2 or higher, or the BIOS is corrupted.
1006	Automatic System Recovery (ASR) action was performed Action performed was: <Action> Date and time of action: <Date and time>	Error	This message is generated when an automatic system recovery action is performed due to a hung operating system. The action performed and the time of action are provided.
1007	User initiated host system control action Action requested was: <Action>	Information	User requested a host system control action to reboot, power off, or power cycle the system. Alternatively, the user had indicated protective measures to be initiated in the event of a thermal shutdown.

Table 2-1. Miscellaneous Messages (continued)

Event ID	Description	Severity	Cause
1008	Systems Management Data Manager Started	Information	Systems Management Data Manager services were started.
1009	Systems Management Data Manager Stopped	Information	Systems Management Data Manager services were stopped.
1011	RCI table is corrupt	Error	This message is generated when the BIOS Remote Configuration Interface (RCI) table is corrupted or cannot be read by the systems management software.
1012	IPMI Status <i>Interface: <the IPMI interface being used>, <additional information if available and applicable></i>	Information	This message is generated to indicate the Intelligent Platform Management Interface (IPMI) status of the system. Additional information, when available, includes Baseboard Management Controller (BMC) not present, BMC not responding, System Event Log (SEL) not present, and SEL Data Record (SDR) not present.
1013	System Peak Power detected new peak value Peak value (in Watts):<Reading>	Information	The system peak power sensor detected a new peak value in power consumption. The new peak value in Watts is provided.

Temperature Sensor Messages

Temperature sensors listed in Table 2-2 help protect critical components by alerting the systems management console when temperatures become too high inside a chassis. The temperature sensor messages use additional variables: sensor location, chassis location, previous state, and temperature sensor value or state.

Table 2-2. Temperature Sensor Messages

Event ID	Description	Severity	Cause
1050	Temperature sensor has failed Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> If sensor type is not discrete: Temperature sensor value (in degrees Celsius): <Reading> If sensor type is discrete: Discrete temperature state: <State>	Error	A temperature sensor on the backplane board, system board, or the carrier in the specified system failed. The sensor location, chassis location, previous state, and temperature sensor value are provided.
1051	Temperature sensor value unknown Sensor location: <Location in chassis> Chassis location: <Name of chassis> If sensor type is not discrete: Temperature sensor value (in degrees Celsius): <Reading> If sensor type is discrete: Discrete temperature state: <State>	Information	A temperature sensor on the backplane board, system board, or drive carrier in the specified system could not obtain a reading. The sensor location, chassis location, previous state, and a nominal temperature sensor value are provided.

Table 2-2. Temperature Sensor Messages (continued)

Event ID	Description	Severity	Cause
1052	Temperature sensor returned to a normal value Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> If sensor type is not discrete: Temperature sensor value (in degrees Celsius): <Reading> If sensor type is discrete: Discrete temperature state: <State>	Information	A temperature sensor on the backplane board, system board, or drive carrier in the specified system returned to a valid range after crossing a failure threshold. The sensor location, chassis location, previous state, and temperature sensor value are provided.
1053	Temperature sensor detected a warning value Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> If sensor type is not discrete: Temperature sensor value (in degrees Celsius): <Reading> If sensor type is discrete: Discrete temperature state: <State>	Warning	A temperature sensor on the backplane board, system board, CPU, or drive carrier in the specified system exceeded its warning threshold. The sensor location, chassis location, previous state, and temperature sensor value are provided.

Table 2-2. Temperature Sensor Messages (continued)

Event ID	Description	Severity	Cause
1054	<p>Temperature sensor detected a failure value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Temperature sensor value (in degrees Celsius): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete temperature state: <State></p>	Error	<p>A temperature sensor on the backplane board, system board, or drive carrier in the specified system exceeded its failure threshold. The sensor location, chassis location, previous state, and temperature sensor value are provided.</p>
1055	<p>Temperature sensor detected a non-recoverable value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Temperature sensor value (in degrees Celsius): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete temperature state: <State></p>	Error	<p>A temperature sensor on the backplane board, system board, or drive carrier in the specified system detected an error from which it cannot recover. The sensor location, chassis location, previous state, and temperature sensor value are provided.</p>

Cooling Device Messages

Cooling device sensors listed in Table 2-3 monitor how well a fan is functioning. Cooling device messages provide status and warning information for fans in a particular chassis.

Table 2-3. Cooling Device Messages

Event ID	Description	Severity	Cause
1100	Fan sensor has failed Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Fan sensor value: <Reading>	Error	A fan sensor in the specified system is not functioning. The sensor location, chassis location, previous state, and fan sensor value are provided.
1101	Fan sensor value unknown Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Fan sensor value: <Reading>	Error	A fan sensor in the specified system could not obtain a reading. The sensor location, chassis location, previous state, and a nominal fan sensor value are provided.
1102	Fan sensor returned to a normal value Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Fan sensor value: <Reading>	Information	A fan sensor reading on the specified system returned to a valid range after crossing a warning threshold. The sensor location, chassis location, previous state, and fan sensor value are provided.

Table 2-3. Cooling Device Messages (continued)

Event ID	Description	Severity	Cause
1103	Fan sensor detected a warning value Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Fan sensor value: <Reading>	Warning	A fan sensor reading in the specified system exceeded a warning threshold. The sensor location, chassis location, previous state, and fan sensor value are provided.
1104	Fan sensor detected a failure value Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Fan sensor value: <Reading>	Error	A fan sensor in the specified system detected the failure of one or more fans. The sensor location, chassis location, previous state, and fan sensor value are provided.
1105	Fan sensor detected a non-recoverable value Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Fan sensor value: <Reading>	Error	A fan sensor detected an error from which it cannot recover. The sensor location, chassis location, previous state, and fan sensor value are provided.

Voltage Sensor Messages

Voltage sensors listed in Table 2-4 monitor the number of volts across critical components. Voltage sensor messages provide status and warning information for voltage sensors in a particular chassis.

Table 2-4. Voltage Sensor Messages

Event ID	Description	Severity	Cause
1150	Voltage sensor has failed Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> If sensor type is not discrete: Voltage sensor value (in Volts): <Reading> If sensor type is discrete: Discrete voltage state: <State>	Error	A voltage sensor in the specified system failed. The sensor location, chassis location, previous state, and voltage sensor value are provided.
1151	Voltage sensor value unknown Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> If sensor type is not discrete: Voltage sensor value (in Volts): <Reading> If sensor type is discrete: Discrete voltage state: <State>	Warning	A voltage sensor in the specified system could not obtain a reading. The sensor location, chassis location, previous state, and a nominal voltage sensor value are provided.

Table 2-4. Voltage Sensor Messages (continued)

Event ID	Description	Severity	Cause
1152	<p>Voltage sensor returned to a normal value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Voltage sensor value (in Volts): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete voltage state: <State></p>	Information	A voltage sensor in the specified system returned to a valid range after crossing a failure threshold. The sensor location, chassis location, previous state, and voltage sensor value are provided.
1153	<p>Voltage sensor detected a warning value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Voltage sensor value (in Volts): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete voltage state: <State></p>	Warning	A voltage sensor in the specified system exceeded its warning threshold. The sensor location, chassis location, previous state, and voltage sensor value are provided.

Table 2-4. Voltage Sensor Messages (continued)

Event ID	Description	Severity	Cause
1154	Voltage sensor detected a failure value Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> If sensor type is not discrete: Voltage sensor value (in Volts): <Reading> If sensor type is discrete: Discrete voltage state: <State>	Error	A voltage sensor in the specified system exceeded its failure threshold. The sensor location, chassis location, previous state, and voltage sensor value are provided.
1155	Voltage sensor detected a non-recoverable value Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> If sensor type is not discrete: Voltage sensor value (in Volts): <Reading> If sensor type is discrete: Discrete voltage state: <State>	Error	A voltage sensor in the specified system detected an error from which it cannot recover. The sensor location, chassis location, previous state, and voltage sensor value are provided.

Current Sensor Messages

Current sensors listed in Table 2-5 measure the amount of current (in amperes) that is traversing critical components. Current sensor messages provide status and warning information for current sensors in a particular chassis.

Table 2-5. Current Sensor Messages

Event ID	Description	Severity	Cause
1200	Current sensor has failed Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> If sensor type is not discrete: Current sensor value (in Amps): <Reading> OR Current sensor value (in Watts): <Reading> If sensor type is discrete: Discrete current state: <State>	Error	A current sensor in the specified system failed. The sensor location, chassis location, previous state, and current sensor value are provided.

Table 2-5. Current Sensor Messages (continued)

Event ID	Description	Severity	Cause
1201	Current sensor value unknown Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> If sensor type is not discrete: Current sensor value (in Amps): <Reading> OR Current sensor value (in Watts): <Reading> If sensor type is discrete: Discrete current state: <State>	Error	A current sensor in the specified system could not obtain a reading. The sensor location, chassis location, previous state, and a nominal current sensor value are provided.
1202	Current sensor returned to a normal value Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> If sensor type is not discrete: Current sensor value (in Amps): <Reading> OR Current sensor value (in Watts): <Reading> If sensor type is discrete: Discrete current state: <State>	Information	A current sensor in the specified system returned to a valid range after crossing a failure threshold. The sensor location, chassis location, previous state, and current sensor value are provided.

Table 2-5. Current Sensor Messages (continued)

Event ID	Description	Severity	Cause
1203	<p>Current sensor detected a warning value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Current sensor value (in Amps): <Reading> OR</p> <p>Current sensor value (in Watts): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete current state: <State></p>	Warning	<p>A current sensor in the specified system exceeded its warning threshold.</p> <p>The sensor location, chassis location, previous state, and current sensor value are provided.</p>
1204	<p>Current sensor detected a failure value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Current sensor value (in Amps): <Reading> OR</p> <p>Current sensor value (in Watts): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete current state: <State></p>	Error	<p>A current sensor in the specified system exceeded its failure threshold.</p> <p>The sensor location, chassis location, previous state, and current sensor value are provided.</p>

Table 2-5. Current Sensor Messages (continued)

Event ID	Description	Severity	Cause
1205	<p>Current sensor detected a non-recoverable value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>If sensor type is not discrete:</p> <p>Current sensor value (in Amps): <Reading> OR</p> <p>Current sensor value (in Watts): <Reading></p> <p>If sensor type is discrete:</p> <p>Discrete current state: <State></p>	Error	<p>A current sensor in the specified system detected an error from which it cannot recover. The sensor location, chassis location, previous state, and current sensor value are provided.</p>

Chassis Intrusion Messages

Chassis intrusion messages listed in Table 2-6 are a security measure. Chassis intrusion means that someone is opening the cover to a system's chassis. Alerts are sent to prevent unauthorized removal of parts from a chassis.

Table 2-6. Chassis Intrusion Messages

Event ID	Description	Severity	Cause
1250	Chassis intrusion sensor has failed Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Chassis intrusion state: <Intrusion state>	Error	A chassis intrusion sensor in the specified system failed. The sensor location, chassis location, previous state, and chassis intrusion state are provided.
1251	Chassis intrusion sensor value unknown Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Chassis intrusion state: <Intrusion state>	Error	A chassis intrusion sensor in the specified system could not obtain a reading. The sensor location, chassis location, previous state, and chassis intrusion state are provided.
1252	Chassis intrusion returned to normal Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Chassis intrusion state: <Intrusion state>	Information	A chassis intrusion sensor in the specified system detected that a cover was opened while the system was operating but has since been replaced. The sensor location, chassis location, previous state, and chassis intrusion state are provided.

Table 2-6. Chassis Intrusion Messages (continued)

Event ID	Description	Severity	Cause
1253	Chassis intrusion in progress Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Chassis intrusion state: <Intrusion state>	Warning	A chassis intrusion sensor in the specified system detected that a system cover is currently being opened and the system is operating. The sensor location, chassis location, previous state, and chassis intrusion state are provided.
1254	Chassis intrusion detected Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Chassis intrusion state: <Intrusion state>	Warning	A chassis intrusion sensor in the specified system detected that the system cover was opened while the system was operating. The sensor location, chassis location, previous state, and chassis intrusion state are provided.
1255	Chassis intrusion sensor detected a non-recoverable value Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Chassis intrusion state: <Intrusion state>	Error	A chassis intrusion sensor in the specified system detected an error from which it cannot recover. The sensor location, chassis location, previous state, and chassis intrusion state are provided.

Redundancy Unit Messages

Redundancy means that a system chassis has more than one of certain critical components. Fans and power supplies, for example, are so important for preventing damage or disruption of a computer system that a chassis may have “extra” fans or power supplies installed. Redundancy allows a second or *n*th fan to keep the chassis components at a safe temperature when the primary fan has failed. Redundancy is normal when the intended number of critical components are operating. Redundancy is degraded when a component fails but others are still operating. Redundancy is lost when the number of components functioning falls below the redundancy threshold. Table 2-7 lists the redundancy unit messages.

The number of devices required for full redundancy is provided as part of the message, when applicable, for the redundancy unit and the platform. For details on redundancy computation, see the respective platform documentation.

Table 2-7. Redundancy Unit Messages

Event ID	Description	Severity	Cause
1300	<p>Redundancy sensor has failed</p> <p>Redundancy unit: <i><Redundancy location in chassis></i></p> <p>Chassis location: <i><Name of chassis></i></p> <p>Previous redundancy state was: <i><State></i></p>	Warning	A redundancy sensor in the specified system failed. The redundancy unit location, chassis location, previous redundancy state, and the number of devices required for full redundancy are provided.
1301	<p>Redundancy sensor value unknown</p> <p>Redundancy unit: <i><Redundancy location in chassis></i></p> <p>Chassis location: <i><Name of chassis></i></p> <p>Previous redundancy state was: <i><State></i></p>	Warning	A redundancy sensor in the specified system could not obtain a reading. The redundancy unit location, chassis location, previous redundancy state, and the number of devices required for full redundancy are provided.

Table 2-7. Redundancy Unit Messages (continued)

Event Description ID	Severity	Cause
1302 Redundancy not applicable Redundancy unit: <Redundancy location in chassis> Chassis location: <Name of chassis> Previous redundancy state was: <State>	Information	A redundancy sensor in the specified system detected that a unit was not redundant. The redundancy location, chassis location, previous redundancy state, and the number of devices required for full redundancy are provided.
1303 Redundancy is offline Redundancy unit: <Redundancy location in chassis> Chassis location: <Name of chassis> Previous redundancy state was: <State>	Information	A redundancy sensor in the specified system detected that a redundant unit is offline. The redundancy unit location, chassis location, previous redundancy state, and the number of devices required for full redundancy are provided.
1304 Redundancy regained Redundancy unit: <Redundancy location in chassis> Chassis location: <Name of chassis> Previous redundancy state was: <State>	Information	A redundancy sensor in the specified system detected that a “lost” redundancy device has been reconnected or replaced; full redundancy is in effect. The redundancy unit location, chassis location, previous redundancy state, and the number of devices required for full redundancy are provided.

Table 2-7. Redundancy Unit Messages (continued)

Event ID	Description	Severity	Cause
1305	Redundancy degraded Redundancy unit: <Redundancy location in chassis> Chassis location: <Name of chassis> Previous redundancy state was: <State>	Warning	A redundancy sensor in the specified system detected that one of the components of the redundancy unit has failed but the unit is still redundant. The redundancy unit location, chassis location, previous redundancy state, and the number of devices required for full redundancy are provided.
1306	Redundancy lost Redundancy unit: <Redundancy location in chassis> Chassis location: <Name of chassis> Previous redundancy state was: <State>	Error	A redundancy sensor in the specified system detected that one of the components in the redundant unit has been disconnected, has failed, or is not present. The redundancy unit location, chassis location, previous redundancy state, and the number of devices required for full redundancy are provided.

Power Supply Messages

Power supply sensors monitor how well a power supply is functioning. Power supply messages listed in Table 2-8 provide status and warning information for power supplies present in a particular chassis.

Table 2-8. Power Supply Messages

Event ID	Description	Severity	Cause
1350	<p>Power supply sensor has failed Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Power Supply type: <type of power supply></p> <p><Additional power supply status information></p> <p>If in configuration error state:</p> <p>Configuration error type: <type of configuration error></p>	Error	A power supply sensor in the specified system failed. The sensor location, chassis location, previous state, and additional power supply status information are provided.
1351	<p>Power supply sensor value unknown</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Power Supply type: <type of power supply></p> <p><Additional power supply status information></p> <p>If in configuration error state:</p> <p>Configuration error type: <type of configuration error></p>	Warning	A power supply sensor in the specified system could not obtain a reading. The sensor location, chassis location, previous state, and additional power supply status information are provided.

Table 2-8. Power Supply Messages (continued)


Event ID	Description	Severity	Cause
1352	Power supply returned to normal Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Power Supply type: <type of power supply> <Additional power supply status information> If in configuration error state: Configuration error type: <type of configuration error>	Information	A power supply has been reconnected or replaced. The sensor location, chassis location, previous state, and additional power supply status information are provided.
1353	Power supply detected a warning Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Power Supply type: <type of power supply> <Additional power supply status information> If in configuration error state: Configuration error type: <type of configuration error>	Warning	A power supply sensor reading in the specified system exceeded a user-definable warning threshold. The sensor location, chassis location, previous state, and additional power supply status information are provided.

Table 2-8. Power Supply Messages (continued)

Event ID	Description	Severity	Cause
1354	<p>Power supply detected a failure</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Power Supply type: <type of power supply></p> <p><i><Additional power supply status information></i></p> <p>If in configuration error state:</p> <p>Configuration error type: <type of configuration error></p>	Error	A power supply has been disconnected or has failed. The sensor location, chassis location, previous state, and additional power supply status information are provided.
1355	<p>Power supply sensor detected a non-recoverable value</p> <p>Sensor location: <Location in chassis></p> <p>Chassis location: <Name of chassis></p> <p>Previous state was: <State></p> <p>Power Supply type: <type of power supply></p> <p><i><Additional power supply status information></i></p> <p>If in configuration error state:</p> <p>Configuration error type: <type of configuration error></p>	Error	A power supply sensor in the specified system detected an error from which it cannot recover. The sensor location, chassis location, previous state, and additional power supply status information are provided.

Memory Device Messages

Memory device messages listed in Table 2-9 provide status and warning information for memory modules present in a particular system. Memory devices determine health status by monitoring the ECC memory correction rate and the type of memory events that have occurred.

 **NOTE:** A critical status does not always indicate a system failure or loss of data. In some instances, the system has exceeded the ECC correction rate. Although the system continues to function, you should perform system maintenance as described in Table 2-9.


 **NOTE:** In Table 2-9, *<status>* can be either *critical* or *non-critical*.

Table 2-9. Memory Device Messages

Event ID	Description	Severity	Cause
1403	Memory device status is <i><status></i> Memory device location: <i><location in chassis></i> Possible memory module event cause: <i><list of causes></i>	Warning	A memory device correction rate exceeded an acceptable value. The memory device status and location are provided.
1404	Memory device status is <i><status></i> Memory device location: <i><location in chassis></i> Possible memory module event cause: <i><list of causes></i>	Error	A memory device correction rate exceeded an acceptable value, a memory spare bank was activated, or a multibit ECC error occurred. The system continues to function normally (except for a multibit error). Replace the memory module identified in the message during the system's next scheduled maintenance. Clear the memory error on multibit ECC error. The memory device status and location are provided.

Fan Enclosure Messages

Some systems are equipped with a protective enclosure for fans. Fan enclosure messages listed in Table 2-10 monitor whether foreign objects are present in an enclosure and how long a fan enclosure is missing from a chassis.

Table 2-10. Fan Enclosure Messages

Event ID	Description	Severity	Cause
1450	Fan enclosure sensor has failed Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Critical/ Failure / Error	The fan enclosure sensor in the specified system failed. The sensor location and chassis location are provided.
1451	Fan enclosure sensor value unknown Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Warning	The fan enclosure sensor in the specified system could not obtain a reading. The sensor location and chassis location are provided.
1452	Fan enclosure inserted into system Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Information	A fan enclosure has been inserted into the specified system. The sensor location and chassis location are provided.
1453	Fan enclosure removed from system Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Warning	A fan enclosure has been removed from the specified system. The sensor location and chassis location are provided.

Table 2-10. Fan Enclosure Messages (continued)

Event ID	Description	Severity	Cause
1454	Fan enclosure removed from system for an extended amount of time Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Error	A fan enclosure has been removed from the specified system for a user-definable length of time. The sensor location and chassis location are provided.
1455	Fan enclosure sensor detected a non-recoverable value Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Error	A fan enclosure sensor in the specified system detected an error from which it cannot recover. The sensor location and chassis location are provided.

AC Power Cord Messages

AC power cord messages listed in Table 2-11 provide status and warning information for power cords that are part of an AC power switch, if your system supports AC switching.

Table 2-11. AC Power Cord Messages

Event ID	Description	Severity	Cause
1500	AC power cord sensor has failed Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Critical/ Failure/ Error	An AC power cord sensor in the specified system failed. The AC power cord status cannot be monitored. The sensor location and chassis location information are provided.
1501	AC power cord is not being monitored Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Information	The AC power cord status is not being monitored. This occurs when a system's expected AC power configuration is set to nonredundant . The sensor location and chassis location information are provided.
1502	AC power has been restored Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Information	An AC power cord that did not have AC power has had the power restored. The sensor location and chassis location information are provided.

Table 2-11. AC Power Cord Messages (continued)

Event ID	Description	Severity	Cause
1503	AC power has been lost Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Critical/ Failure/ Error	An AC power cord has lost its power, but there is sufficient redundancy to classify this as a warning. The sensor location and chassis location information are provided.
1504	AC power has been lost Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Error	An AC power cord has lost its power, and lack of redundancy requires this to be classified as an error. The sensor location and chassis location information are provided.
1505	AC power has been lost Sensor location: <Location in chassis> Chassis location: <Name of chassis>	Error	An AC power cord sensor in the specified system failed. The AC power cord status cannot be monitored. The sensor location and chassis location information are provided.

Hardware Log Sensor Messages

Hardware logs provide hardware status messages to systems management software. On certain systems, the hardware log is implemented as a circular queue. When the log becomes full, the oldest status messages are overwritten when new status messages are logged. On some systems, the log is not circular. On these systems, when the log becomes full, subsequent hardware status messages are lost. Hardware log sensor messages listed in Table 2-12 provide status and warning information about the noncircular logs that may fill up, resulting in lost status messages.

Table 2-12. Hardware Log Sensor Messages

Event ID	Description	Severity	Cause
1550	Log monitoring has been disabled Log type: <Log type>	Warning	A hardware log sensor in the specified system is disabled. The log type information is provided.
1551	Log status is unknown Log type: <Log type>	Information	A hardware log sensor in the specified system could not obtain a reading. The log type information is provided.
1552	Log size is no longer near or at capacity Log type: <Log type>	Information	The hardware log on the specified system is no longer near or at its capacity, usually as the result of clearing the log. The log type information is provided.
1553	Log size is near capacity Log type: <Log type>	Warning	The size of a hardware log on the specified system is near or at the capacity of the hardware log. The log type information is provided.
1554	Log size is full Log type: <Log type>	Error	The size of a hardware log on the specified system is full. The log type information is provided.
1555	Log sensor has failed Log type: <Log type>	Error	A hardware log sensor in the specified system failed. The hardware log status cannot be monitored. The log type information is provided.

Processor Sensor Messages

Processor sensors monitor how well a processor is functioning. Processor messages listed in Table 2-13 provide status and warning information for processors in a particular chassis.

Table 2-13. Processor Sensor Messages

Event ID	Description	Severity	Cause
1600	Processor sensor has failed Sensor Location: <i><Location in chassis></i> Chassis Location: <i><Name of chassis></i> Previous state was: <i><State></i> Processor sensor status: <i><status></i>	Critical/ Failure/ Error	A processor sensor in the specified system is not functioning. The sensor location, chassis location, previous state and processor sensor status are provided.
1601	Processor sensor value unknown Sensor Location: <i><Location in chassis></i> Chassis Location: <i><Name of chassis></i> Previous state was: <i><State></i> Processor sensor status: <i><status></i>	Critical/ Failure/ Error	A processor sensor in the specified system could not obtain a reading. The sensor location, chassis location, previous state and processor sensor status are provided.

Table 2-13. Processor Sensor Messages (continued)

Event ID	Description	Severity	Cause
1602	Processor sensor returned to a normal value Sensor Location: <Location in chassis> Chassis Location: <Name of chassis> Previous state was: <State> Processor sensor status: <status>	Information	A processor sensor in the specified system transitioned back to a normal state. The sensor location, chassis location, previous state and processor sensor status are provided.
1603	Processor sensor detected a warning value Sensor Location: <Location in chassis> Chassis Location: <Name of chassis> Previous state was: <State> Processor sensor status: <status>	Warning	A processor sensor in the specified system is in a throttled state. The sensor location, chassis location, previous state and processor sensor status are provided.

Table 2-13. Processor Sensor Messages (continued)

Event ID	Description	Severity	Cause
1604	Processor sensor detected a failure value Sensor Location: <Location in chassis> Chassis Location: <Name of chassis> Previous state was: <State> Processor sensor status: <status>	Error	A processor sensor in the specified system is disabled, has a configuration error, or experienced a thermal trip. The sensor location, chassis location, previous state and processor sensor status are provided.
1605	Processor sensor detected a non-recoverable value Sensor Location: <Location in chassis> Chassis Location: <Name of chassis> Previous state was: <State> Processor sensor status: <status>	Error	A processor sensor in the specified system has failed. The sensor location, chassis location, previous state and processor sensor status are provided.

Pluggable Device Messages

The pluggable device messages listed in Table 2-14 provide status and error information when some devices, such as memory cards, are added or removed.

Table 2-14. Pluggable Device Messages

Event ID	Description	Severity	Cause
1650	<Device plug event type unknown> Device location: <Location in chassis, if available> Chassis location: <Name of chassis, if available> Additional details: <Additional details for the events, if available>	Information	A pluggable device event message of unknown type was received. The device location, chassis location, and additional event details, if available, are provided.
1651	Device added to system Device location: <Location in chassis> Chassis location: <Name of chassis> Additional details: <Additional details for the events>	Information	A device was added in the specified system. The device location, chassis location, and additional event details, if available, are provided.

Table 2-14. Pluggable Device Messages (continued)

Event ID	Description	Severity	Cause
1652	Device removed from system Device location: <Location in chassis> Chassis location: <Name of chassis> Additional details: <Additional details for the events>	Information	A device was removed from the specified system. The device location, chassis location, and additional event details, if available, are provided.
1653	Device configuration error detected Device location: <Location in chassis> Chassis location: <Name of chassis> Additional details: <Additional details for the events>	Error	A configuration error was detected for a pluggable device in the specified system. The device may have been added to the system incorrectly.

Battery Sensor Messages

Battery sensors monitor how well a battery is functioning. Battery messages listed in Table 2-15 provide status and warning information for batteries in a particular chassis.

Table 2-15. Battery Sensor Messages

Event ID	Description	Severity	Cause
1700	Battery sensor has failed Sensor location: <Location in chassis> Chassis location: <Name of chassis> Previous state was: <State> Battery sensor status: <status>	Critical/ Failure/ Error	A battery sensor in the specified system is not functioning. The sensor location, chassis location, previous state, and battery sensor status are provided.
1701	Battery sensor value unknown Sensor Location: <Location in chassis> Chassis Location: <Name of chassis> Previous state was: <State> Battery sensor status: <status>	Warning	A battery sensor in the specified system could not retrieve a reading. The sensor location, chassis location, previous state, and battery sensor status are provided.
1702	Battery sensor returned to a normal value Sensor Location: <Location in chassis> Chassis Location: <Name of chassis> Previous state was: <State> Battery sensor status: <status>	Information	A battery sensor in the specified system detected that a battery transitioned back to a normal state. The sensor location, chassis location, previous state, and battery sensor status are provided.

Table 2-15. Battery Sensor Messages (continued)

Event ID	Description	Severity	Cause
1703	Battery sensor detected a warning value Sensor Location: <Location in chassis> Chassis Location: <Name of chassis> Previous state was: <State> Battery sensor status: <status>	Warning	A battery sensor in the specified system detected that a battery is in a predictive failure state. The sensor location, chassis location, previous state, and battery sensor status are provided.
1704	Battery sensor detected a failure value Sensor Location: <Location in chassis> Chassis Location: <Name of chassis> Previous state was: <State> Battery sensor status: <status>	Error	A battery sensor in the specified system detected that a battery has failed. The sensor location, chassis location, previous state, and battery sensor status are provided.
1705	Battery sensor detected a non-recoverable value Sensor Location: <Location in chassis> Chassis Location: <Name of chassis> Previous state was: <State> Battery sensor status: <status>	Error	A battery sensor in the specified system detected that a battery has failed. The sensor location, chassis location, previous state, and battery sensor status are provided.

Chassis Management Controller Messages

Alerts sent by Dell™ M1000e Chassis Management Controller (CMC) are organized by severity. That is, the event ID of the CMC trap indicates the severity (informational, warning, critical, or non-recoverable) of the alert. Each CMC alert includes the originating system name, location, and event message text. The alert message text matches the corresponding Chassis Event Log message text that is logged by the sending CMC for that event.

Table 2-16. Chassis Management Controller Messages

EventID	Description	Severity	Cause
2000	CMC generated a test trap	Informational	A user-initiated test trap was issued, through the CMC GUI or RACADM CLI.
2002	CMC reported a return-to-normal or informational	Informational	CMC informational event, as described in the drsCAMessage variable binding supplied with the alert.
2003	CMC reported a warning	Warning	CMC warning event, as described in the drsCAMessage variable supplied with the alert.
2004	CMC reported a critical event	Critical	CMC critical event, as described in the drsCAMessage variable binding supplied with the alert.
2005	CMC reported a non-recoverable event	Non-Recoverable	CMC non-recoverable event, as described in the drsCAMessage variable binding supplied with the alert.

System Event Log Messages for IPMI Systems

The tables in this chapter list the system event log (SEL) messages, their severity, and cause.



NOTE: For corrective actions, see the appropriate documentation.

Temperature Sensor Events

The temperature sensor event messages help protect critical components by alerting the systems management console when the temperature rises inside the chassis. These event messages use additional variables, such as sensor location, chassis location, previous state, and temperature sensor value or state.

Table 3-1. Temperature Sensor Events

Event Message	Severity	Cause
<p><i><Sensor Name/Location></i> temperature sensor detected a failure <i><Reading></i> where <i><Sensor Name/Location></i> is the entity that this sensor is monitoring. For example, "PROC Temp" or "Planar Temp."</p> <p>Reading is specified in degree Celsius. For example 100 C.</p>	Critical	Temperature of the backplane board, system board, or the carrier in the specified system <i><Sensor Name/Location></i> exceeded the critical threshold.
<p><i><Sensor Name/Location></i> temperature sensor detected a warning <i><Reading></i>.</p>	Warning	Temperature of the backplane board, system board, or the carrier in the specified system <i><Sensor Name/Location></i> exceeded the non-critical threshold.

Table 3-1. Temperature Sensor Events (continued)

Event Message	Severity	Cause
<i><Sensor Name/Location> temperature sensor returned to warning state <Reading>.</i>	Warning	Temperature of the backplane board, system board, or the carrier in the specified system <i><Sensor Name/Location></i> returned from critical state to non-critical state.
<i><Sensor Name/Location> temperature sensor returned to normal state <Reading>.</i>	Information	Temperature of the backplane board, system board, or the carrier in the specified system <i><Sensor Name/Location></i> returned to normal operating range.

Voltage Sensor Events

The voltage sensor event messages monitor the number of volts across critical components. These messages provide status and warning information for voltage sensors for a particular chassis.

Table 3-2. Voltage Sensor Events

Event Message	Severity	Cause
<i><Sensor Name/Location> voltage sensor detected a failure <Reading> where <Sensor Name/Location> is the entity that this sensor is monitoring. Reading is specified in volts. For example, 3.860 V.</i>	Critical	The voltage of the monitored device has exceeded the critical threshold.
<i><Sensor Name/Location> voltage sensor state asserted.</i>	Critical	The voltage specified by <i><Sensor Name/Location></i> is in critical state.
<i><Sensor Name/Location> voltage sensor state de-asserted.</i>	Information	The voltage of a previously reported <i><Sensor Name/Location></i> is returned to normal state.

Table 3-2. Voltage Sensor Events (continued)

Event Message	Severity	Cause
<i><Sensor Name/Location> voltage sensor detected a warning <Reading>.</i>	Warning	Voltage of the monitored entity <i><Sensor Name/Location></i> exceeded the warning threshold.
<i><Sensor Name/Location> voltage sensor returned to normal <Reading>.</i>	Information	The voltage of a previously reported <i><Sensor Name/Location></i> is returned to normal state.

Fan Sensor Events

The cooling device sensors monitor how well a fan is functioning. These messages provide status warning and failure messages for fans for a particular chassis.

Table 3-3. Fan Sensor Events

Event Message	Severity	Cause
<i><Sensor Name/Location> Fan sensor detected a failure <Reading> where <Sensor Name/Location> is the entity that this sensor is monitoring. For example "BMC Back Fan" or "BMC Front Fan."</i> <i>Reading is specified in RPM. For example, 100 RPM.</i>	Critical	The speed of the specified <i><Sensor Name/Location></i> fan is not sufficient to provide enough cooling to the system.
<i><Sensor Name/Location> Fan sensor returned to normal state <Reading>.</i>	Information	The fan specified by <i><Sensor Name/Location></i> has returned to its normal operating speed.

Table 3-3. Fan Sensor Events (continued)

Event Message	Severity	Cause
<Sensor Name/Location> Fan sensor detected a warning <Reading>.	Warning	The speed of the specified <Sensor Name/Location> fan may not be sufficient to provide enough cooling to the system.
<Sensor Name/Location> Fan Redundancy sensor redundancy degraded.	Information	The fan specified by <Sensor Name/Location> may have failed and hence, the redundancy has been degraded.
<Sensor Name/Location> Fan Redundancy sensor redundancy lost.	Critical	The fan specified by <Sensor Name/Location> may have failed and hence, the redundancy that was degraded previously has been lost.
<Sensor Name/Location> Fan Redundancy sensor redundancy regained	Information	The fan specified by <Sensor Name/Location> may have started functioning again and hence, the redundancy has been regained.

Processor Status Events

The processor status messages monitor the functionality of the processors in a system. These messages provide processor health and warning information of a system.

Table 3-4. Processor Status Events

Event Message	Severity	Cause
<Processor Entity> status processor sensor IERR, where <Processor Entity> is the processor that generated the event. For example, PROC for a single processor system and PROC # for multiprocessor system.	Critical	IERR internal error generated by the <Processor Entity>. This event is generated due to processor internal error.
<Processor Entity> status processor sensor Thermal Trip.	Critical	The processor generates this event before it shuts down because of excessive heat caused by lack of cooling or heat synchronization.
<Processor Entity> status processor sensor recovered from IERR.	Information	This event is generated when a processor recovers from the internal error.
<Processor Entity> status processor sensor disabled.	Warning	This event is generated for all processors that are disabled.
<Processor Entity> status processor sensor terminator not present.	Information	This event is generated if the terminator is missing on an empty processor slot.
< Processor Entity> presence was deasserted.	Critical	This event is generated when the system could not detect the processor.
<Processor Entity> presence was asserted.	Information	This event is generated when the earlier processor detection error was corrected.

Table 3-4. Processor Status Events (continued)

Event Message	Severity	Cause
<i><Processor Entity></i> thermal tripped was deasserted.	Information	This event is generated when the processor has recovered from an earlier thermal condition.
<i><Processor Entity></i> configuration error was asserted.	Critical	This event is generated when the processor configuration is incorrect.
<i><Processor Entity></i> configuration error was deasserted.	Information	This event is generated when the earlier processor configuration error was corrected.
<i><Processor Entity></i> throttled was asserted.	Warning	This event is generated when the processor slows down to prevent overheating.
<i><Processor Entity></i> throttled was deasserted.	Information	This event is generated when the earlier processor throttled event was corrected.

Power Supply Events

The power supply sensors monitor the functionality of the power supplies. These messages provide status and warning information for power supplies for a particular system.

Table 3-5. Power Supply Events

Event Message	Severity	Cause
<i><Power Supply Sensor Name></i> power supply sensor removed.	Critical	This event is generated when the power supply sensor is removed.
<i><Power Supply Sensor Name></i> power supply sensor AC recovered.	Information	This event is generated when the power supply has been replaced.
<i><Power Supply Sensor Name></i> power supply sensor returned to normal state.	Information	This event is generated when the power supply that failed or removed was replaced and the state has returned to normal.

Table 3-5. Power Supply Events (continued)

Event Message	Severity	Cause
<i><Entity Name> PS Redundancy sensor redundancy degraded.</i>	Information	Power supply redundancy is degraded if one of the power supply sources is removed or failed.
<i><Entity Name> PS Redundancy sensor redundancy lost.</i>	Critical	Power supply redundancy is lost if only one power supply is functional.
<i><Entity Name> PS Redundancy sensor redundancy regained.</i>	Information	This event is generated if the power supply has been reconnected or replaced.
<i><Power Supply Sensor Name> predictive failure was asserted</i>	Critical	This event is generated when the power supply is about to fail.
<i><Power Supply Sensor Name> input lost was asserted</i>	Critical	This event is generated when the power supply is unplugged.
<i><Power Supply Sensor Name> predictive failure was deasserted</i>	Information	This event is generated when the power supply has recovered from an earlier predictive failure event.
<i><Power Supply Sensor Name> input lost was deasserted</i>	Information	This event is generated when the power supply is plugged in.

Memory ECC Events

The memory ECC event messages monitor the memory modules in a system. These messages monitor the ECC memory correction rate and the type of memory events that occurred.

Table 3-6. Memory ECC Events

Event Message	Severity	Cause
<i>ECC error correction detected on Bank # DIMM [A/B].</i>	Information	This event is generated when there is a memory error correction on a particular Dual Inline Memory Module (DIMM).
<i>ECC uncorrectable error detected on Bank # [DIMM].</i>	Critical	This event is generated when the chipset is unable to correct the memory errors. Usually, a bank number is provided and DIMM may or may not be identifiable, depending on the error.
<i>Correctable memory error logging disabled.</i>	Critical	This event is generated when the chipset in the ECC error correction rate exceeds a predefined limit.

BMC Watchdog Events

The BMC watchdog operations are performed when the system hangs or crashes. These messages monitor the status and occurrence of these events in a system.

Table 3-7. BMC Watchdog Events

Event Message	Severity	Cause
BMC OS Watchdog timer expired.	Information	This event is generated when the BMC watchdog timer expires and no action is set.
BMC OS Watchdog performed system reboot.	Critical	This event is generated when the BMC watchdog detects that the system has crashed (timer expired because no response was received from Host) and the action is set to reboot.

Table 3-7. BMC Watchdog Events (continued)

Event Message	Severity	Cause
BMC OS Watchdog performed system power off.	Critical	This event is generated when the BMC watchdog detects that the system has crashed (timer expired because no response was received from Host) and the action is set to power off.
BMC OS Watchdog performed system power cycle.	Critical	This event is generated when the BMC watchdog detects that the system has crashed (timer expired because no response was received from Host) and the action is set to power cycle.

Memory Events

The memory modules can be configured in different ways in particular systems. These messages monitor the status, warning, and configuration information about the memory modules in the system.

Table 3-8. Memory Events

Event Message	Severity	Cause
Memory RAID redundancy degraded.	Warning	This event is generated when there is a memory failure in a RAID-configured memory configuration.
<i>Memory RAID redundancy lost.</i>	Critical	This event is generated when redundancy is lost in a RAID-configured memory configuration.
Memory RAID redundancy regained	Information	This event is generated when the redundancy lost or degraded earlier is regained in a RAID-configured memory configuration.
Memory Mirrored redundancy degraded.	Warning	This event is generated when there is a memory failure in a mirrored memory configuration.

Table 3-8. Memory Events (continued)

Event Message	Severity	Cause
Memory Mirrored redundancy lost.	Critical	This event is generated when redundancy is lost in a mirrored memory configuration.
Memory Mirrored redundancy regained.	Information	This event is generated when the redundancy lost or degraded earlier is regained in a mirrored memory configuration.
Memory Spared redundancy degraded.	Warning	This event is generated when there is a memory failure in a spared memory configuration.
Memory Spared redundancy lost.	Critical	This event is generated when redundancy is lost in a spared memory configuration.
Memory Spared redundancy regained.	Information	This event is generated when the redundancy lost or degraded earlier is regained in a spared memory configuration.

Hardware Log Sensor Events

The hardware logs provide hardware status messages to the system management software. On particular systems, the subsequent hardware messages are not displayed when the log is full. These messages provide status and warning messages when the logs are full.

Table 3-9. Hardware Log Sensor Events

Event Message	Severity	Cause
Log full detected.	Critical	This event is generated when the SEL device detects that only one entry can be added to the SEL before it is full.
Log cleared.	Information	This event is generated when the SEL is cleared.

Drive Events

The drive event messages monitor the health of the drives in a system. These events are generated when there is a fault in the drives indicated.

Table 3-10. Drive Events

Event Message	Severity	Cause
Drive <Drive #> asserted fault state.	Critical	This event is generated when the specified drive in the array is faulty.
Drive <Drive #> de-asserted fault state.	Information	This event is generated when the specified drive recovers from a faulty condition.
Drive <Drive #> drive presence was asserted	Informational	This event is generated when the drive is installed.
Drive <Drive #> predictive failure was asserted	Warning	This event is generated when the drive is about to fail.
Drive <Drive #> predictive failure was deasserted	Informational	This event is generated when the drive from earlier predictive failure is corrected.
Drive <Drive #> hot spare was asserted	Warning	This event is generated when the drive is placed in a hot spare.
Drive <Drive #> hot spare was deasserted	Informational	This event is generated when the drive is taken out of hot spare.
Drive <Drive #> consistency check in progress was asserted	Warning	This event is generated when the drive is placed in consistency check.
Drive <Drive #> consistency check in progress was deasserted	Informational	This event is generated when the consistency check of the drive is completed.

Table 3-10. Drive Events (continued)

Event Message	Severity	Cause
Drive <Drive #> in critical array was asserted	Critical	This event is generated when the drive is placed in critical array.
Drive <Drive #> in critical array was deasserted	Informational	This event is generated when the drive is removed from critical array.
Drive <Drive #> in failed array was asserted	Critical	This event is generated when the drive is placed in the fail array.
Drive <Drive #> in failed array was deasserted	Informational	This event is generated when the drive is removed from the fail array.
Drive <Drive #> rebuild in progress was asserted	Informational	This event is generated when the drive is rebuilding.
Drive <Drive #> rebuild aborted was asserted	Warning	This event is generated when the drive rebuilding process is aborted.

Intrusion Events

The chassis intrusion messages are a security measure. Chassis intrusion alerts are generated when the system's chassis is opened. Alerts are sent to prevent unauthorized removal of parts from the chassis.

Table 3-11. Intrusion Events

Event Message	Severity	Cause
<Intrusion sensor Name> sensor detected an intrusion.	Critical	This event is generated when the intrusion sensor detects an intrusion.
<Intrusion sensor Name> sensor returned to normal state.	Information	This event is generated when the earlier intrusion has been corrected.

Table 3-11. Intrusion Events

Event Message	Severity	Cause
<i><Intrusion sensor Name> sensor intrusion was asserted while system was ON</i>	Critical	This event is generated when the intrusion sensor detects an intrusion while the system is on.
<i><Intrusion sensor Name> sensor intrusion was asserted while system was OFF</i>	Critical	This event is generated when the intrusion sensor detects an intrusion while the system is off.

BIOS Generated System Events

The BIOS-generated messages monitor the health and functionality of the chipsets, I/O channels, and other BIOS-related functions.

Table 3-12. BIOS Generated System Events

Event Message	Severity	Cause
<i>System Event I/O channel chk.</i>	Critical	This event is generated when a critical interrupt is generated in the I/O Channel.
<i>System Event PCI Parity Err.</i>	Critical	This event is generated when a parity error is detected on the PCI bus.
<i>System Event Chipset Err.</i>	Critical	This event is generated when a chip error is detected.
<i>System Event PCI System Err.</i>	Information	This event indicates historical data, and is generated when the system has crashed and recovered.
<i>System Event PCI Fatal Err.</i>	Critical	This error is generated when a fatal error is detected on the PCI bus.

Table 3-12. BIOS Generated System Events (continued)

Event Message	Severity	Cause
<i>System Event PCIE Fatal Err.</i>	Critical	This error is generated when a fatal error is detected on the PCIE bus.
POST Err	Critical	This event is generated when an error occurs during system boot. See the system documentation for more information on the error code.
POST fatal error #<number> or <error description>	Critical	This event is generated when a fatal error occurs during system boot. See “Table 3-13” for more information.
Memory Spared redundancy lost	Critical	This event is generated when memory spare is no longer redundant.
Memory Mirrored redundancy lost	Critical	This event is generated when memory mirroring is no longer redundant.
Memory RAID redundancy lost	Critical	This event is generated when memory RAID is no longer redundant.
Err Reg Pointer OEM Diagnostic data event was asserted	Information	This event is generated when an OEM event occurs. OEM events can be used by Dell™ service team to better understand the cause of the failure.
System Board PFault Fail Safe state asserted	Critical	This event is generated when the system board voltages are not at normal levels.
System Board PFault Fail Safe state deasserted	Information	This event is generated when earlier PFault Fail Safe system voltages return to a normal level.

Table 3-12. BIOS Generated System Events (continued)

Event Message	Severity	Cause
Memory Add (BANK# DIMM#) presence was asserted	Information	This event is generated when memory is added to the system.
Memory Removed (BANK# DIMM#) presence was asserted	Information	This event is generated when memory is removed from the system.
Memory Cfg Err configuration error (BANK# DIMM#) was asserted	Critical	This event is generated when memory configuration is incorrect for the system.
Mem Redun Gain redundancy regained	Information	This event is generated when memory redundancy is regained.
Mem ECC Warning transition to non-critical from OK	Warning	This event is generated when correctable ECC errors have increased from a normal rate.
Mem ECC Warning transition to critical from less severe	Critical	This event is generated when correctable ECC errors reach a critical rate.
Mem CRC Err transition to non-recoverable	Critical	This event is generated when CRC errors enter a non-recoverable state.
Mem Fatal SB CRC uncorrectable ECC was asserted	Critical	This event is generated when CRC errors occur while storing to memory.
Mem Fatal NB CRC uncorrectable ECC was asserted	Critical	This event is generated when CRC errors occur while removing from memory.
Mem Overtemp critical over temperature was asserted	Critical	This event is generated when system memory reaches critical temperature.

Table 3-12. BIOS Generated System Events (continued)

Event Message	Severity	Cause
USB Over-current transition to non-recoverable	Critical	This event is generated when the USB exceeds a predefined current level.
Hdwr version err hardware incompatibility (BMC/iDRAC Firmware and CPU mismatch) was asserted	Critical	This event is generated when there is a mismatch between the BMC and iDRAC firmware and the processor in use or vice versa.
Hdwr version err hardware incompatibility(BMC /iDRAC Firmware and CPU mismatch) was deasserted	Information	This event is generated when the earlier mismatch between the BMC and iDRAC firmware and the processor is corrected.
SBE Log Disabled correctable memory error logging disabled was asserted	Critical	This event is generated when the ECC single bit error rate is exceeded.
CPU Protocol Err transition to non-recoverable	Critical	This event is generated when the processor protocol enters a non-recoverable state.
CPU Bus PERR transition to non-recoverable	Critical	This event is generated when the processor bus PERR enters a non-recoverable state.
CPU Init Err transition to non-recoverable	Critical	This event is generated when the processor initialization enters a non-recoverable state.
CPU Machine Chk transition to non-recoverable	Critical	This event is generated when the processor machine check enters a non-recoverable state.
Logging Disabled all event logging disabled was asserted	Critical	This event is generated when all event logging is disabled.

Table 3-12. BIOS Generated System Events (continued)

Event Message	Severity	Cause
LinkT/FlexAddr: Link Tuning sensor, device option ROM failed to support link tuning or flex address (Mezz XX) was asserted	Critical	This event is generated when the PCI device option ROM for a NIC does not support link tuning or the Flex addressing feature.
LinkT/FlexAddr: Link Tuning sensor, failed to program virtual MAC address (<location>) was asserted.	Critical	This event is generated when BIOS fails to program virtual MAC address on the given NIC device.
PCIE NonFatal Er: Non Fatal IO Group sensor, PCIE error(<location>)	Warning	This event is generated in association with a CPU IERR.
I/O Fatal Err: Fatal IO Group sensor, fatal IO error (<location>)	Critical	This event is generated in association with a CPU IERR and indicates the PCI/PCIE device that caused the CPU IERR.
Unknown system event sensor unknown system hardware failure was asserted	Critical	This event is generated when an unknown hardware failure is detected.

POST Code Table

Table 3-13 lists the POST Code errors that are generated when a fatal error occurs during system boot.

Table 3-13. POST Code Errors

Fatal Error Code	Description	Cause
80	No memory detected	This error code implies that no memory is installed.
81	Memory detected but is not configurable	This error code indicates memory configuration error that could be result of bad memory, mismatched memory or bad socket.
82	Memory configured but not usable.	This error code indicates memory sub-system failure.
83	System BIOS shadow failure	This error code indicates system BIOS shadow failure.
84	CMOS failure	This error code indicates that CMOS RAM is not working.
85	DMA controller failure	This error code indicates DMA controller failure.
86	Interrupt controller failure	This error code indicates interrupt controller failure.
87	Timer refresh failure	This error code indicates timer refresh failure.
88	Programmable interval timer error	This error code indicates a programmable interval timer error.
89	Parity error	This error code indicates a parity error.
8A	SIO failure	This error code indicates SIO failure.
8B	Keyboard controller failure	This error code indicates keyboard controller failure.
8C	SMI initialization failure	This error code indicates SMI initialization failure.

Table 3-13. POST Code Errors (continued)

Fatal Error Code	Description	Cause
C0	Shutdown test failure	This error code indicates a shutdown test failure.
C1	POST Memory test failure	This error code indicates bad memory detection.
C2	RAC configuration failure	Check screen for the actual error message
C3	CPU configuration failure	Check screen for the actual error message
C4	Incorrect memory configuration	Memory population order not correct.
FE	General failure after video	Check screen for the actual error message

R2 Generated System Events

Table 3-14. R2 Generated Events

Description	Severity	Cause
System Event: OS stop event OS graceful shutdown detected	Information	The OS was shutdown/restarted normally.
OEM Event data record (after OS graceful shutdown/restart event)	Information	Comment string accompanying an OS shutdown/restart.
System Event: OS stop event runtime critical stop	Critical	The OS encountered a critical error and was stopped abnormally.
OEM Event data record (after OS bugcheck event)	Information	OS bugcheck code and parameters.

Cable Interconnect Events

The cable interconnect messages are used for detecting errors in the hardware cabling.

Table 3-15. Cable Interconnect Events

Description	Severity	Cause
<i>Cable sensor <Name/Location></i> Configuration error was asserted.	Critical	This event is generated when the cable is not connected or is incorrectly connected.
<i>Cable sensor <Name/Location></i> Connection was asserted.	Information	This event is generated when the earlier cable connection error was corrected.

Battery Events

Table 3-16. Battery Events

Description	Severity	Cause
<i><Battery sensor Name/Location></i> Failed was asserted	Critical	This event is generated when the sensor detects a failed or missing battery.
<i><Battery sensor Name/Location></i> Failed was deasserted	Information	This event is generated when the earlier failed battery was corrected.
<i><Battery sensor Name/Location></i> is low was asserted	Warning	This event is generated when the sensor detects a low battery condition.
<i><Battery sensor Name/Location></i> is low was deasserted	Information	This event is generated when the earlier low battery condition was corrected.

Power And Performance Events

The power and performance events are used to detect degradation in system performance with change in power supply.

Table 3-17. Power And Performance Events

Description	Severity	Cause
System Board Power Optimized: Performance status sensor for System Board, degraded, <description of why> was deasserted	Normal	This event is generated when system performance was restored.
System Board Power Optimized: Performance status sensor for System Board, degraded, <description of why> was asserted	Warning	This event is generated when change in power supply degrades system performance.

Entity Presence Events

The entity presence messages are used for detecting different hardware devices.

Table 3-18. Entity Presence Events

Description	Severity	Cause
<Device Name> presence was asserted	Information	This event is generated when the device was detected.
<Device Name> absent was asserted	Critical	This event is generated when the device was not detected.

Storage Management Message Reference

The Dell™ OpenManage™ Server Administrator Storage Management's alert or event management features let you monitor the health of storage resources such as controllers, enclosures, physical disks, and virtual disks.

Alert Monitoring and Logging

The Storage Management Service performs alert monitoring and logging. By default, the Storage Management Service starts when the managed system starts up. If you stop the Storage Management Service, then alert monitoring and logging stops. Alert monitoring does the following:

- Updates the status of the storage object that generated the alert.
- Propagates the storage object's status to all the related higher objects in the storage hierarchy. For example, the status of a lower-level object will be propagated up to the status displayed on the **Health** tab for the top-level **Storage** object.
- Logs an alert in the Alert log and the operating system (OS) application log.
- Sends an SNMP trap if the operating system's SNMP service is installed and enabled.



NOTE: Dell OpenManage Server Administrator Storage Management does not log alerts regarding the data I/O path. These alerts are logged by the respective RAID drivers in the system alert log.

See the *Storage Management Online Help* for updated information.

Alert Message Format with Substitution Variables

When you view an alert in the Server Administrator alert log, the alert identifies the specific components such as the controller name or the virtual disk name to which the alert applies. In an actual operating environment, a storage system can have many combinations of controllers and disks as well as user-defined names for virtual disks and other components. Because each environment is unique in its storage configuration and user-defined names, an accurate alert message requires that the Storage Management Service be able to insert the environment-specific names of storage components into an alert message.

This environment-specific information is inserted after the alert message text as shown for alert 2127 in Table 4-1.

For other alerts, the alert message text is constructed from information passed directly from the controller (or another storage component) to the Alert Log. In these cases, the variable information is represented with a % (percent sign) in the Storage Management documentation. An example of such an alert is shown in Table 4-1.

Table 4-1. Alert Message Format

Alert ID	Message Text Displayed in the Storage Management Service Documentation	Message Text Displayed in the Alert Log with Variable Information Supplied
2127	Background Initialization started	Background Initialization started: Virtual Disk 3 (Virtual Disk 3) Controller 1 (PERC 5/E Adapter)
2334	Controller event log%	Controller event log: Current capacity of the battery is above threshold.: Controller 1 (PERC 5/E Adapter)

The variables required to complete the message vary depending on the type of storage object and whether the storage object is in a SCSI or SAS configuration. The following table identifies the possible variables used to identify each storage object.



NOTE: Some alert messages relating to an enclosure or an enclosure component, such as a fan or EMM, are generated by the controller when the enclosure or enclosure component ID cannot be determined.

Table 4-2. Message Format with Variables for Each Storage Object



Storage Object	Message Variables
Controller	<p data-bbox="330 391 711 422">Message Format: Controller A (Name)</p> <p data-bbox="330 430 632 462">Message Format: Controller A</p> <p data-bbox="330 470 912 534">Example: 2326 A foreign configuration has been detected.: Controller 1 (PERC 5/E Adapter)</p> <p data-bbox="330 542 1002 582"> NOTE: The controller name is not always displayed.</p>
Battery	<p data-bbox="330 590 733 622">Message Format: Battery X Controller A</p> <p data-bbox="330 630 991 686">Example: 2174 The controller battery has been removed: Battery 0 Controller 1</p>
SCSI Physical Disk	<p data-bbox="330 694 952 726">Message Format: Physical Disk X:Y Controller A, Connector B</p> <p data-bbox="330 734 1002 798">Example: 2049 Physical disk removed: Physical Disk 0:14 Controller 1, Connector 0</p>
SAS Physical Disk	<p data-bbox="330 805 968 837">Message Format: Physical Disk X:Y:Z Controller A, Connector B</p> <p data-bbox="330 845 912 909">Example: 2049 Physical disk removed: Physical Disk 0:0:14 Controller 1, Connector 0</p>
Virtual Disk	<p data-bbox="330 917 946 949">Message Format: Virtual Disk X (Name) Controller A (Name)</p> <p data-bbox="330 957 778 989">Message Format: Virtual Disk X Controller A</p> <p data-bbox="330 997 946 1061">Example: 2057 Virtual disk degraded: Virtual Disk 11 (Virtual Disk 11) Controller 1 (PERC 5/E Adapter)</p> <p data-bbox="330 1069 1002 1141"> NOTE: The virtual disk and controller names are not always displayed.</p>
Enclosure:	<p data-bbox="330 1149 918 1181">Message Format: Enclosure X:Y Controller A, Connector B</p> <p data-bbox="330 1189 968 1248">Example: 2112 Enclosure shutdown: Enclosure 0:2 Controller 1, Connector 0</p>

Table 4-2. Message Format with Variables for Each Storage Object (continued)

Storage Object	Message Variables
SCSI Power Supply	A, B, C and X, Y, Z in the following examples are variables representing the storage object name or number.
	Message Format: Power Supply X Controller A, Connector B, Target ID C where "C" is the SCSI ID number of the enclosure management module (EMM) managing the power supply. Example: 2122 Redundancy degraded: Power Supply 1, Controller 1, Connector 0, Target ID 6
SAS Power Supply	Message Format: Power Supply X Controller A, Connector B, Enclosure C
	Example: 2312 A power supply in the enclosure has an AC failure.: Power Supply 1, Controller 1, Connector 0, Enclosure 2
SCSI Temperature Probe	Message Format: Temperature Probe X Controller A, Connector B, Target ID C
	where "C" is the SCSI ID number of the EMM managing the temperature probe. Example: 2101 Temperature dropped below the minimum warning threshold: Temperature Probe 1, Controller 1, Connector 0, Target ID 6
SAS Temperature Probe	Message Format: Temperature Probe X Controller A, Connector B, Enclosure C
	Example: 2101 Temperature dropped below the minimum warning threshold: Temperature Probe 1, Controller 1, Connector 0, Enclosure 2
SCSI Fan	Message Format: Fan X Controller A, Connector B, Target ID C where "C" is the SCSI ID number of the EMM managing the fan.
	Example: 2121 Device returned to normal: Fan 1, Controller 1, Connector 0, Target ID 6
SAS Fan	Message Format: Fan X Controller A, Connector B, Enclosure C
	Example: 2121 Device returned to normal: Fan 1, Controller 1, Connector 0, Enclosure 2

Table 4-2. Message Format with Variables for Each Storage Object (continued)

Storage Object	Message Variables
	A, B, C and X, Y, Z in the following examples are variables representing the storage object name or number.
SCSI EMM	Message Format: EMM X Controller A, Connector B, Target ID C where "C" is the SCSI ID number of the EMM. Example: 2121 Device returned to normal: EMM 1, Controller 1, Connector 0, Target ID 6
SAS EMM	Message Format: EMM X Controller A, Connector B, Enclosure C Example: 2121 Device returned to normal: EMM 1, Controller 1, Connector 0, Enclosure 2

Alert Message Change History

The following table describes the changes made to the Storage Management alerts from the previous release of Storage Management to the current release.

Table 4-3. Alert Message Change History

Alert Message Change History	
Storage Management 3.0.2	Comments
Product Versions to which Changes Apply	Storage Management 3.0.2 Server Administrator 6.0.1 Dell OpenManage 6.0.1
New Alerts	2382
Storage Management 3.0	Comments
Product Versions to which Changes Apply	Storage Management 3.0 Server Administrator 5.5 Dell OpenManage 5.5

Table 4-3. Alert Message Change History (continued)

Alert Message Change History		
New Alerts	2060, 2075, 2087, 2125, 2183, 2184, 2185, 2190, 2197, 2198, 2200, 2210, 2216, 2217, 2218, 2219, 2220, 2221, 2222, 2223, 2224, 2225, 2226, 2227, 2228, 2229, 2230, 2231, 2236, 2237, 2257, 2258, 2381	
Modified Alerts	2060, 2075, 2087	The alert numbers were re-used and the trap numbers were changed accordingly. As a result the alert descriptions were updated and the SNMP trap number was changed to 1201.
Documentation Change	Documentation updated to reflect change in SNMP trap number and description text. 2060, 2075, 2087	The alert numbers were re-used and the trap numbers were changed accordingly. As a result the alert descriptions were updated and the SNMP trap number was changed to 1201.

Alert Descriptions and Corrective Actions

The following sections describe alerts generated by the RAID or SCSI controllers supported by Storage Management. The alerts are displayed in the Server Administrator Alert subtab or through Windows Event Viewer. These alerts can also be forwarded as SNMP traps to other applications.

SNMP traps are generated for the alerts listed in the following sections. These traps are included in the Dell OpenManage Server Administrator Storage Management management information base (MIB). The SNMP traps for these alerts use all of the SNMP trap variables. For more information on SNMP support and the MIB, see the *Dell OpenManage SNMP Reference Guide*.

To locate an alert, scroll through the following table to find the alert number displayed on the Server Administrator Alert tab or search this file for the alert message text or number. See "Understanding Event Messages" for more information on severity levels.

For more information regarding alert descriptions and the appropriate corrective actions, see the online help.

Table 4-4. Storage Management Messages

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2048	Device failed	Critical / Failure / Error	<p>Cause: A storage component such as a physical disk or an enclosure has failed. The failed component may have been identified by the controller while performing a task such as a rescan or a check consistency.</p> <p>Action: Replace the failed component. You can identify which disk has failed by locating the disk that has a red “X” for its status. Perform a rescan after replacing the failed component.</p>	<p>Clear Alert Number: 2121.</p> <p>Related Alert Number: 2095, 2201, 2203</p> <p>LRA Number: 2051, 2061, 2071, 2081, 2091, 2101</p>	<p>754</p> <p>804</p> <p>854</p> <p>904</p> <p>954</p> <p>1004</p> <p>1054</p> <p>1104</p> <p>1154</p> <p>1204</p>

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2049	Physical disk removed	Warning / Non-critical	<p>Cause: A physical disk has been removed from the disk group. This alert can also be caused by loose or defective cables or by problems with the enclosure.</p> <p>Action: If a physical disk was removed from the disk group, either replace the disk or restore the original disk. On some controllers, a removed disk has a red "X" for its status. On other controllers, a removed disk may have an <code>Offline</code> status or is not displayed on the user interface. Perform a rescan after replacing or restoring the disk. If a disk has not been removed from the disk group, then check for problems with the cables. See the online help for more information on checking the cables. Make sure that the enclosure is powered on. If the problem persists, check the enclosure documentation for further diagnostic information.</p>	<p>Clear Alert Number: 2052.</p> <p>Related Alert Number: 2054, 2057, 2056, 2076, 2079, 2081, 2083, 2129, 2202, 2204, 2270, 2292, 2299, 2369</p> <p>LRA Number: 2070</p>	903

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2050	Physical disk offline	Warning / Non-critical	<p>Cause: A physical disk in the disk group is offline. The user may have manually put the physical disk offline.</p> <p>Action: Perform a rescan. You can also select the offline disk and perform a Make Online operation.</p>	<p>Clear Alert Number: 2158.</p> <p>Related Alert Number: 2099, 2196</p> <p>LRA Number: 2070</p>	903
2051	Physical disk degraded	Warning / Non-critical	<p>Cause: A physical disk has reported an error condition and may be degraded. The physical disk may have reported the error condition in response to a consistency check or other operation.</p> <p>Action: Replace the degraded physical disk. You can identify which disk is degraded by locating the disk that has a red "X" for its status. Perform a rescan after replacing the disk.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2070</p> <p>LRA Number: None.</p>	903
2052	Physical disk inserted	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2065, 2305, 2367</p> <p>LRA Number: None.</p>	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2053	Virtual disk created	OK/Normal/Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201
2054	Virtual disk deleted	Warning/Non-critical	<p>Cause: A virtual disk has been deleted. Performing a Reset Configuration may detect that a virtual disk has been deleted and generate this alert.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2080</p>	1203
2055	Virtual disk configuration changed	OK/Normal/Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2056	Virtual disk failed	Critical / Failure / Error	<p>Cause: One or more physical disks included in the virtual disk have failed. If the virtual disk is non-redundant (does not use mirrored or parity data), then the failure of a single physical disk can cause the virtual disk to fail. If the virtual disk is redundant, then more physical disks have failed than can be rebuilt using mirrored or parity information.</p> <p>Action: Create a new virtual disk and restore from a backup.</p> <p>The disk controller rebuilds the virtual disk by first configuring a hot spare for the disk, and then initiating a write operation to the disk. The write operation will initiate a rebuild of the disk.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2048, 2049, 2050, 2076, 2079, 2081, 2129, 2346</p> <p>LRA Number: 2081</p>	1204

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2057	Virtual disk degraded	Warning / Non-critical	<p>Cause 1: This alert message occurs when a physical disk included in a redundant virtual disk fails. Because the virtual disk is redundant (uses mirrored or parity information) and only one physical disk has failed, the virtual disk can be rebuilt.</p> <p>Action 1: Configure a hot spare for the virtual disk if one is not already configured. Rebuild the virtual disk. When using an Expandable RAID Controller (PERC) PERC 3/SC, 3/DCL, 3/DC, 3/QC, 4/SC, 4/DC, 4e/DC, 4/Di, CERC ATA100/4ch, PERC 5/E, PERC 5/i or a Serial Attached SCSI (SAS) 5/iR controller, rebuild the virtual disk by first configuring a hot spare for the disk, and then initiating a write operation to the disk. The write operation will initiate a rebuild of the disk.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2048, 2049, 2050, 2076, 2079, 2081, 2123, 2129, 2346</p> <p>LRA Number: 2080</p>	1203

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2057 contd.			<p>Cause 2: A physical disk in the disk group has been removed.</p> <p>Action 2: If a physical disk was removed from the disk group, either replace the disk or restore the original disk. You can identify which disk has been removed by locating the disk that has a red “X” for its status. Perform a rescan after replacing the disk.</p>		
2058	Virtual disk check consistency started	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: 2085.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201
2059	Virtual disk format started	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: 2086.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2060	Copy of data started on physical disk 1 from physical disk 2.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: 2075 LRA Number: None.	1201
2061	Virtual disk initialization started	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: 2088. Related Alert Number: None. LRA Number: None.	1201
2062	Physical disk initialization started	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None.	Clear Alert Number: 2089. Related Alert Number: None. LRA Number: None.	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2063	Virtual disk reconfiguration started	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: 2090. Related Alert Number: None. LRA Number: None.	1201
2064	Virtual disk rebuild started	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: 2091. Related Alert Number: None. LRA Number: None.	1201
2065	Physical disk rebuild started	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: 2092. Related Alert Number: 2099, 2121, 2196 LRA Number: None.	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2067	Virtual disk check consistency cancelled	OK/Normal/Informational	<p>Cause: The check consistency operation was cancelled because a physical disk in the array has failed or because a user cancelled the check consistency operation.</p> <p>Action: If the physical disk failed, then replace the physical disk. You can identify which disk failed by locating the disk that has a red “X” for its status. Perform a rescan after replacing the disk. When performing a consistency check, be aware that the consistency check can take a long time. The time it takes depends on the size of the physical disk or the virtual disk.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2070	Virtual disk initialization cancelled	OK / Normal / Informational	<p>Cause: The virtual disk initialization cancelled because a physical disk included in the virtual disk has failed or because a user cancelled the virtual disk initialization.</p> <p>Action: If a physical disk failed, then replace the physical disk. You can identify which disk has failed by locating the disk that has a red “X” for its status. Perform a rescan after replacing the disk. Restart the format physical disk operation. Restart the virtual disk initialization.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201
2074	Physical disk rebuild cancelled	OK / Normal / Informational	<p>Cause: The user has cancelled the rebuild operation.</p> <p>Action: Restart the rebuild operation.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2075	Copy of data completed on physical disk %2 from physical disk %1	OK / Normal / Informational	<p>Cause: This alert is provided for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2060.</p> <p>LRA Number: None</p>	1201
2076	Virtual disk Check Consist-ency failed	Critical / Failure / Error	<p>Cause: A physical disk included in the virtual disk failed or there is an error in the parity information. A failed physical disk can cause errors in parity information.</p> <p>Action: Replace the failed physical disk. You can identify which disk has failed by locating the disk that has a red “X” for its status. Rebuild the physical disk. When finished, restart the check consistency operation.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2081</p>	1204

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2077	Virtual disk format failed	Critical / Failure / Error	Cause: A physical disk included in the virtual disk failed. Action: Replace the failed physical disk. You can identify which physical disk has failed by locating the disk that has a red "X" for its status. Rebuild the physical disk. When finished, restart the virtual disk format operation.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2081	1204
2079	Virtual disk initial-ization failed	Critical / Failure / Error	Cause: A physical disk included in the virtual disk has failed or a user has cancelled the initialization. Action: If a physical disk has failed, then replace the physical disk.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2081	1204
2080	Physical disk initial-ization failed	Critical / Failure / Error	Cause: The physical disk has failed or is corrupt. Action: Replace the failed or corrupt disk. You can identify a disk that has failed by locating the disk that has a red "X" for its status. Restart the initialization.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2071	904

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2081	Virtual disk reconfiguration failed	Critical / Failure / Error	<p>Cause: A physical disk included in the virtual disk has failed or is corrupt. A user may also have cancelled the reconfiguration.</p> <p>Action: Replace the failed or corrupt disk. You can identify a disk that has failed by locating the disk that has a red “X” for its status.</p> <p>If the physical disk is part of a redundant array, then rebuild the physical disk. When finished, restart the reconfiguration.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2081</p>	1204
2082	Virtual disk rebuild failed	Critical / Failure / Error	<p>Cause: A physical disk included in the virtual disk has failed or is corrupt. A user may also have cancelled the rebuild.</p> <p>Action: Replace the failed or corrupt disk. You can identify a disk that has failed by locating the disk that has a red “X” for its status. Restart the virtual disk rebuild.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2048</p> <p>LRA Number: 2081</p>	1204

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2083	Physical disk rebuild failed	Critical / Failure / Error	Cause: A physical disk included in the virtual disk has failed or is corrupt. A user may also have cancelled the rebuild. Action: Replace the failed or corrupt disk. You can identify a disk that has failed by locating the disk that has a red “X” for its status. Rebuild the virtual disk rebuild.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2071	904
2085	Virtual disk check consistency completed	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Status: Alert 2085 is a clear alert for alert 2058. Related Alert Number: None. LRA Number: None.	1201
2086	Virtual disk format completed	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Status: Alert 2086 is a clear alert for alert 2059. Related Alert Number: None. LRA Number: None.	1201

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2087	Copy of data resumed from physical disk %2 to physical disk %1	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Status: None Related Alert Number: 260. LRA Number: None.	1201
2088	Virtual disk initializ-ation completed	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Status: Alert 2088 is a clear alert for alerts 2061 and 2136. Related Alert Number: None. LRA Number: None.	1201
2089	Physical disk initial-ization completed	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Status: Alert 2089 is a clear alert for alert 2062. Related Alert Number: None. LRA Number: None.	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2090	Virtual disk reconfiguration completed	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Status: Alert 2090 is a clear alert for alert 2063. Related Alert Number: None. LRA Number: None.	1201
2091	Virtual disk rebuild completed	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Status: Alert 2091 is a clear alert for alert 2064. Related Alert Number: None. LRA Number: None.	1201
2092	Physical disk rebuild completed	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Status: Alert 2092 is a clear alert for alert 2065. Related Alert Number: None. LRA Number: None.	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2094	Predictive Failure reported.	Warning / Non-critical	<p>Cause: The physical disk is predicted to fail. Many physical disks contain Self Monitoring Analysis and Reporting Technology (SMART). When enabled, SMART monitors the health of the disk based on indications such as the number of write operations that have been performed on the disk.</p> <p>Action: Replace the physical disk. Even though the disk may not have failed yet, it is strongly recommended that you replace the disk.</p> <p>If this disk is part of a redundant virtual disk, perform the Offline task on the disk; replace the disk; and then assign a hot spare and the rebuild will start automatically.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2070</p>	903

Table 4-4. Storage Management Messages (continued)


Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2094 cond.			<p>If this disk is a hot spare, then unassign the hot spare; perform the Prepare to Remove task on the disk; replace the disk; and assign the new disk as a hot spare.</p> <p> CAUTION: If this disk is part of a nonredundant disk, back up your data immediately. If the disk fails, you will not be able to recover the data.</p>		
2095	SCSI sense data.	OK / Normal / Informational	<p>Cause: A SCSI device experienced an error, but may have recovered.</p> <p>Action: None.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2273</p> <p>LRA Number: None.</p>	751,851, 901
2098	Global hot spare assigned	OK / Normal / Informational	<p>Cause: A user has assigned a physical disk as a global hot spare. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2277</p> <p>LRA Number: None.</p>	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2099	Global hot spare unassigned	OK / Normal / Informational	<p>Cause: A user has unassigned a physical disk as a global hot spare. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	901
2100	Temperature exceeded the maximum warning threshold	Warning / Non-critical	<p>Cause: The physical disk enclosure is too hot. A variety of factors can cause the excessive temperature. For example, a fan may have failed, the thermostat may be set too high, or the room temperature may be too hot.</p> <p>Action: Check for factors that may cause overheating. For example, verify that the enclosure fan is working. You should also check the thermostat settings and examine whether the enclosure is located near a heat source. Make sure the enclosure has enough ventilation and that the room temperature is not too hot. See the physical disk enclosure documentation for more diagnostic information.</p>	<p>Clear Alert Number: 2353.</p> <p>Related Alert Number: 2112</p> <p>LRA Number: 2090</p>	1053

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2101	Temp-erature dropped below the minimum warning threshold	Warning / Non-critical	<p>Cause: The physical disk enclosure is too cool.</p> <p>Action: Check if the thermostat setting is too low and if the room temperature is too cool.</p>	<p>Clear Alert Number: 2353.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2090</p>	1053
2102	Temp-erature exceeded the maximum failure threshold	Critical / Failure / Error	<p>Cause: The physical disk enclosure is too hot. A variety of factors can cause the excessive temperature. For example, a fan may have failed, the thermostat may be set too high, or the room temperature may be too hot.</p> <p>Action: Check for factors that may cause overheating. For example, verify that the enclosure fan is working. You should also check the thermostat settings and examine whether the enclosure is located near a heat source. Make sure the enclosure has enough ventilation and that the room temperature is not too hot. See the physical disk enclosure documentation for more diagnostic information.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2091</p>	1054

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2103	Temperature dropped below the minimum failure threshold	Critical / Failure / Error	<p>Cause: The physical disk enclosure is too cool.</p> <p>Action: Check if the thermostat setting is too low and if the room temperature is too cool.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2112</p> <p>LRA Number: 2091</p>	1054
2104	Controller battery is reconditioning	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: 2105.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1151
2105	Controller battery recondition is completed	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Status: Alert 2105 is a clear alert for alert 2104.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1151

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2106	Smart FPT exceeded	Warning / Non-critical	<p>Cause: A disk on the specified controller has received a SMART alert (predictive failure) indicating that the disk is likely to fail in the near future.</p> <p>Action: Replace the disk that has received the SMART alert. If the physical disk is a member of a non-redundant virtual disk, then back up the data before replacing the disk.</p> <p>⚠ CAUTION: Removing a physical disk that is included in a non-redundant virtual disk will cause the virtual disk to fail and may cause data loss.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2070</p>	903

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2107	Smart configuration change	Critical / Failure / Error	<p>Cause: A disk has received a SMART alert (predictive failure) after a configuration change. The disk is likely to fail in the near future.</p> <p>Action: Replace the disk that has received the SMART alert. If the physical disk is a member of a non-redundant virtual disk, then back up the data before replacing the disk.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2071</p>	904

⚠ CAUTION: Removing a physical disk that is included in a non-redundant virtual disk will cause the virtual disk to fail and may cause data loss.

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2108	Smart warning	Warning / Non-critical	<p>Cause: A disk has received a SMART alert (predictive failure). The disk is likely to fail in the near future.</p> <p>Action: Replace the disk that has received the SMART alert. If the physical disk is a member of a non-redundant virtual disk, then back up the data before replacing the disk.</p> <p>△ CAUTION: Removing a physical disk that is included in a non-redundant virtual disk will cause the virtual disk to fail and may cause data loss.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2070</p>	903

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2109	SMART warning temperature	Warning / Non-critical	<p>Cause: A disk has reached an unacceptable temperature and received a SMART alert (predictive failure). The disk is likely to fail in the near future.</p> <p>Action 1: Determine why the physical disk has reached an unacceptable temperature. A variety of factors can cause the excessive temperature. For example, a fan may have failed, the thermostat may be set too high, or the room temperature may be too hot or cold. Verify that the fans in the server or enclosure are working. If the physical disk is in an enclosure, you should check the thermostat settings and examine whether the enclosure is located near a heat source.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2070</p>	903

Table 4-4. Storage Management Messages (continued)


Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2109 contd			<p>Make sure the enclosure has enough ventilation and that the room temperature is not too hot. See the physical disk enclosure documentation for more diagnostic information.</p> <p>Action 2: If you cannot identify why the disk has reached an unacceptable temperature, then replace the disk. If the physical disk is a member of a non-redundant virtual disk, then back up the data before replacing the disk.</p>		
			<p> CAUTION: Removing a physical disk that is included in a non-redundant virtual disk will cause the virtual disk to fail and may cause data loss.</p>		

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2110	SMART warning degraded	Warning / Non-critical	<p>Cause: A disk is degraded and has received a SMART alert (predictive failure). The disk is likely to fail in the near future.</p> <p>Action: Replace the disk that has received the SMART alert. If the physical disk is a member of a non-redundant virtual disk, then back up the data before replacing the disk.</p> <p>⚠ CAUTION: Removing a physical disk that is included in a non-redundant virtual disk will cause the virtual disk to fail and may cause data loss.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2070</p>	903
2111	Failure prediction threshold exceeded due to test	Warning / Non-critical	<p>Cause: A disk has received a SMART alert (predictive failure) due to test conditions.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2070</p>	903

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2112	Enclosure was shut down	Critical / Failure / Error	<p>Cause: The physical disk enclosure is either hotter or cooler than the maximum or minimum allowable temperature range.</p> <p>Action: Check for factors that may cause overheating or excessive cooling. For example, verify that the enclosure fan is working. You should also check the thermostat settings and examine whether the enclosure is located near a heat source. Make sure the enclosure has enough ventilation and that the room temperature is not too hot or too cold. See the enclosure documentation for more diagnostic information.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2091</p>	854
2114	A consistency check on a virtual disk has been paused (suspend-ed)	OK / Normal / Informational	<p>Cause: The check consistency operation on a virtual disk was paused by a user.</p> <p>Action: To resume the check consistency operation, right-click the virtual disk in the tree view and select Resume Check Consistency.</p>	<p>Clear Alert Number: 2115.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2115	A consistency check on a virtual disk has been resumed	OK/Normal/Informational	<p>Cause: The check consistency operation on a virtual disk has resumed processing after being paused by a user. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Status: Alert 2115 is a clear alert for alert 2114.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201
2116	A virtual disk and its mirror have been split	OK/Normal/Informational	<p>Cause: A user has caused a mirrored virtual disk to be split. When a virtual disk is mirrored, its data is copied to another virtual disk in order to maintain redundancy. After being split, both virtual disks retain a copy of the data, although because the mirror is no longer intact, updates to the data are no longer copied to the mirror. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2117	A mirrored virtual disk has been unmirrored	OK / Normal / Informational	Cause: A user has caused a mirrored virtual disk to be unmirrored. When a virtual disk is mirrored, its data is copied to another virtual disk in order to maintain redundancy. After being unmirrored, the disk formerly used as the mirror returns to being a physical disk and becomes available for inclusion in another virtual disk. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	1201
2118	Change write policy	OK / Normal / Informational	Cause: A user has changed the write policy for a virtual disk. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	1201

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2120	Enclosure firmware mismatch	Warning / Non-critical	<p>Cause: The firmware on the EMM is not the same version. It is required that both modules have the same version of the firmware. This alert may be caused when a user attempts to insert an EMM module that has a different firmware version than an existing module.</p> <p>Action: Download the same version of the firmware to both EMM modules.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2090</p>	853
2121	Device returned to normal	OK / Normal / Informational	<p>Cause: A device that was previously in an error state has returned to a normal state. For example, if an enclosure became too hot and subsequently cooled down, then you may receive this alert. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Status: Alert 2121 is a clear alert for alert 2048.</p> <p>Related Alert Number: 2050, 2065, 2158</p> <p>LRA Number: None.</p>	752 802 852 902 952 1002 1052 1102 1152 1202

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2122	Redundancy degraded	Warning / Non-critical	<p>Cause: One or more of the enclosure components has failed.</p> <p>For example, a fan or power supply may have failed. Although the enclosure is currently operational, the failure of additional components could cause the enclosure to fail.</p> <p>Action: Identify and replace the failed component. To identify the failed component, select the enclosure in the tree view and click the Health subtab. Any failed component will be identified with a red "X" on the enclosure's Health subtab. Alternatively, you can select the Storage object and click the Health subtab.</p> <p>The controller status displayed on the Health subtab indicates whether a controller has a failed or degraded component.</p> <p>See the enclosure documentation for information on replacing enclosure components and for other diagnostic information.</p>	<p>Clear Alert Status: 2124.</p> <p>Related Alert Number: 2048</p> <p>LRA Number: 2090</p>	1305

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2123	Redund-ancy lost	Warning / Non-critical	<p>Cause: A virtual disk or an enclosure has lost data redundancy. In the case of a virtual disk, one or more physical disks included in the virtual disk have failed. Due to the failed physical disk or disks, the virtual disk is no longer maintaining redundant (mirrored or parity) data. The failure of an additional physical disk will result in lost data. In the case of an enclosure, more than one enclosure component has failed. For example, the enclosure may have suffered the loss of all fans or all power supplies.</p> <p>Action: Identify and replace the failed components. To identify the failed component, select the Storage object and click the Health subtab.</p>	<p>Clear Alert Number: 2124.</p> <p>Related Alert Number: 2048, 2049, 2057</p> <p>LRA Number: 2080, 2090</p>	1306

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2123 contd.			<p>The controller status displayed on the Health subtab indicates whether a controller has a failed or degraded component.</p> <p>Click the controller that displays a Warning or Failed status. This action displays the controller Health subtab which displays the status of the individual controller components. Continue clicking the components with a Warning or Health status until you identify the failed component.</p> <p>See the online help for more information. See the enclosure documentation for information on replacing enclosure components and for other diagnostic information.</p>		

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2124	Redund-ancy normal	OK/Normal/Informational	<p>Cause: Data redundancy has been restored to a virtual disk or an enclosure that previously suffered a loss of redundancy. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: Alert 2124 is a clear alert for alerts 2122 and 2123.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1304
2125	Controller cache preserved for missing or offline virtual disk	Warning/Non-critical	<p>Cause: Virtual disk controller was disconnected, during IO operation.</p> <p>Action: Import foreign disks, if any. Check if the enclosure containing the virtual disk is disconnected from the controller.</p>	<p>Clear Alert Number: No</p> <p>Related Alert Number: No</p> <p>LRA Number: No</p>	753

Table 4-4. Storage Management Messages (continued)



Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2126	SCSI sense sector reassign	Warning / Non-critical	<p>Cause: A sector of the physical disk is corrupted and data cannot be maintained on this portion of the disk. This alert is for informational purposes.</p> <p> CAUTION: Any data residing on the corrupt portion of the disk may be lost and you may need to restore your data from backup.</p> <p>Action: If the physical disk is part of a non-redundant virtual disk, then back up the data and replace the physical disk.</p> <p> CAUTION: Removing a physical disk that is included in a non-redundant virtual disk will cause the virtual disk to fail and may cause data loss.</p> <p>If the disk is part of a redundant virtual disk, then any data residing on the corrupt portion of the disk will be reallocated elsewhere in the virtual disk.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	903

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2127	Back-ground initialization (BGI) started	OK / Normal / Informational	<p>Cause: BGI of a virtual disk has started. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Status: 2130.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201
2128	BGI cancelled	OK / Normal / Informational	<p>Cause: BGI of a virtual disk has been cancelled. A user or the firmware may have stopped BGI.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201
2129	BGI failed	Critical / Failure / Error	<p>Cause: BGI of a virtual disk has failed.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2340</p> <p>LRA Number: 2081</p>	1204

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2130	BGI completed	OK/Normal/ Informational	<p>Cause: BGI of a virtual disk has completed. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: Alert 2130 is a clear alert for alert 2127.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201
2131	Firmware version mismatch	Warning/ Non-critical	<p>Cause: The firmware on the controller is not a supported version.</p> <p>Action: Install a supported version of the firmware. If you do not have a supported version of the firmware available, you can download it from the Dell Support site at support.dell.com or check with your support provider for information on how to obtain the most current firmware.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2060</p>	753

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2132	Driver version mismatch	Warning / Non-critical	<p>Cause: The controller driver is not a supported version.</p> <p>Action: Install a supported version of the driver. If you do not have a supported driver version available, you can download it from the Dell Support site at support.dell.com or you can check with your support provider for information on how to obtain the most current driver.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2060</p>	753
2135	<p>Array Manager is installed on the system</p> <p>NOTE: This is not supported on Dell OpenManage Server Administrator version 6.0.1.</p>	Warning / Non-critical	<p>Cause: Storage Management has been installed on a system that has an Array Manager installation.</p> <p>Action: Installing Storage Management and Array Manager on the same system is not a supported configuration. Uninstall either Storage Management or Array Manager.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2050</p>	103

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2136	Virtual disk initialization	OK/Normal/Informational	<p>Cause: Virtual disk initialization is in progress. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: 2088.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201
2137	Communication timeout	Warning/Non-critical	<p>Cause: The controller is unable to communicate with an enclosure. There are several reasons why communication may be lost. For example, there may be a bad or loose cable. An unusual amount of I/O may also interrupt communication with the enclosure. In addition, communication loss may be caused by software, hardware, or firmware problems, bad or failed power supplies, and enclosure shutdown.</p> <p>When viewed in the Alert Log, the description for this event displays several variables. These variables are: controller and enclosure names, type of communication problem, return code, and SCSI status.</p>	<p>Clear Alert Number: 2162.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2090</p>	853

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2137 contd.			<p>Action: Check for problems with the cables. See the online help for more information on checking the cables. You should also check to see if the enclosure has degraded or failed components. To do so, select the enclosure object in the tree view and click the Health subtab. The Health subtab displays the status of the enclosure components. Verify that the controller has supported driver and firmware versions installed and that the EMMs are each running the same version of supported firmware.</p>		
2138	Enclosure alarm enabled	OK/Normal/Informational	<p>Cause: A user has enabled the enclosure alarm. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	851

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2139	Enclosure alarm disabled	OK / Normal / Informational	Cause: A user has disabled the enclosure alarm. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	851
2140	Dead disk segments restored	OK / Normal / Informational	Cause: Disk space that was formerly “dead” or inaccessible to a redundant virtual disk has been restored. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	1201
2141	Physical disk dead segments recovered	OK / Normal / Informational	Cause: Portions of the physical disk were formerly inaccessible. The disk space from these dead segments has been recovered and is now usable. Any data residing on these dead segments has been lost. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2142	Controller rebuild rate has changed	OK/Normal/Informational	<p>Cause: A user has changed the controller rebuild rate. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751
2143	Controller alarm enabled	OK/Normal/Informational	<p>Cause: A user has enabled the controller alarm. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751
2144	Controller alarm disabled	OK/Normal/Informational	<p>Cause: A user has disabled the controller alarm. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2145	Controller battery low	Warning / Non-critical	Cause: The controller battery charge is low. Action: Recondition the battery. See the online help for more information.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2100	1153
2146	Bad block replacement error	Warning / Non-critical	Cause: A portion of a physical disk is damaged. Action: See the <i>Dell OpenManage Server Administrator Storage Management</i> online help for more information.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2060	753
2147	Bad block sense error	Warning / Non-critical	Cause: A portion of a physical disk is damaged. Action: See the <i>Dell OpenManage Server Administrator Storage Management</i> online help for more information.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2060	753

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2148	Bad block medium error	Warning / Non-critical	<p>Cause: A portion of a physical disk is damaged.</p> <p>Action: See the <i>Dell OpenManage Server Administrator Storage Management</i> online help for more information.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2060</p>	753
2149	Bad block extended sense error	Warning / Non-critical	<p>Cause: A portion of a physical disk is damaged.</p> <p>Action: See the <i>Dell OpenManage Server Administrator Storage Management</i> online help for more information.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2060</p>	753
2150	Bad block extended medium error	Warning / Non-critical	<p>Cause: A portion of a physical disk is damaged.</p> <p>Action: See the <i>Dell OpenManage Server Administrator Storage Management</i> online help for more information.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2060</p>	753

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2151	Enclosure asset tag changed	OK / Normal / Informational	Cause: A user has changed the enclosure asset tag. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	851
2152	Enclosure asset name changed	OK / Normal / Informational	Cause: A user has changed the enclosure asset name. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	851
2153	Service tag changed	OK / Normal / Informational	Cause: An enclosure service tag was changed. In most circumstances, this service tag should only be changed by Dell support or your service provider. Action: Ensure that the tag was changed under authorized circumstances.	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	851

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2154	Maximum temperature probe warning threshold value changed	OK/Normal/Informational	<p>Cause: A user has changed the value for the maximum temperature probe warning threshold. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1051
2155	Minimum temperature probe warning threshold value changed	OK/Normal/Informational	<p>Cause: A user has changed the value for the minimum temperature probe warning threshold. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1051
2156	Controller alarm has been tested	OK/Normal/Informational	<p>Cause: The controller alarm test has run successfully. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2157	Controller configuration has been reset	OK / Normal / Informational	<p>Cause: A user has reset the controller configuration. See the online help for more information. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751
2158	Physical disk online	OK / Normal / Informational	<p>Cause: An offline physical disk has been made online. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Status: Alert 2158 is a clear alert for alert 2050.</p> <p>Related Alert Number: 2048, 2050, 2065, 2099, 2121, 2196, 2201, 2203</p> <p>LRA Number: None.</p>	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2159	Virtual disk renamed	OK / Normal / Informational	<p>Cause: A user has renamed a virtual disk.</p> <p>When renaming a virtual disk on a PERC 3/SC, 3/DCL, 3/DC, 3/QC, 4/SC, 4/DC, 4e/DC, 4/Di, CERC ATA100/4ch, PERC 5/E, PERC 5/i or SAS 5/iR controller, this alert displays the new virtual disk name.</p> <p>On the PERC 3/SC, 3/DCL, 3/DC, 3/QC, 4/SC, 4/DC, 4e/DC, 4/Di, 4/IM, 4e/Si, 4e/Di, and CERC ATA 100/4ch controllers, this alert displays the original virtual disk name. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201
2162	Communication regained	OK / Normal / Informational	<p>Cause: Communication with an enclosure has been restored. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Status: Alert 2162 is a clear alert for alerts 2137 and 2292.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	851

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2163	Rebuild completed with errors	Critical / Failure / Error	Cause: You might be attempting a RAID configuration that is not supported by the controller. Action: See the Storage Management online help for more information.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2071	904
2164	See the Readme file for a list of validated controller driver versions	OK / Normal / Informational	Cause: Storage Management is unable to determine whether the system has the minimum required versions of the RAID controller drivers. This alert is for informational purposes. Action: See the Readme file for driver and firmware requirements. In particular, if Storage Management experiences performance problems, you should verify that you have the minimum supported versions of the drivers and firmware installed.	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	101

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2165	The RAID controller firmware and driver validation was not performed. The configuration file cannot be opened.	Warning / Non-critical	<p>Cause: Storage Management is unable to determine whether the system has the minimum required versions of the RAID controller firmware and drivers. This situation may occur for a variety of reasons. For example, the installation directory path to the configuration file may not be correct. The configuration file may also have been removed or renamed.</p> <p>Action: Reinstall Storage Management</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2060</p>	753
2166	The RAID controller firmware and driver validation was not performed. The configuration file is out of date or corrupted.	Warning / Non-critical	<p>Cause: Storage Management is unable to determine whether the system has the minimum required versions of the RAID controller firmware and drivers. This situation has occurred because a configuration file is unreadable or missing data. The configuration file may be corrupted.</p> <p>Action: Reinstall Storage Management.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2060</p>	753

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2167	The current kernel version and the non-RAID SCSI driver version are older than the minimum required levels. See readme.txt for a list of validated kernel and driver versions.	Warning / Non-critical	<p>Cause: The version of the kernel and the driver do not meet the minimum requirements. Storage Management may not be able to display the storage or perform storage management functions until you have updated the system to meet the minimum requirements.</p> <p>Action: See the Readme file for a list of validated kernel and driver versions. Update the system to meet the minimum requirements and then reinstall Storage Management.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2050</p>	103
2168	The non-RAID SCSI driver version is older than the minimum required level. See readme.txt for the validated driver version.	Warning / Non-critical	<p>Cause: The version of the driver does not meet the minimum requirements. Storage Management may not be able to display the storage or perform storage management functions until you have updated the system to meet the minimum requirements.</p> <p>Action: See the Readme file for the validated driver version. Update the system to meet the minimum requirements and then reinstall Storage Management.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2050</p>	103

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2169	The controller battery needs to be replaced.	Critical / Failure / Error	<p>Cause: The controller battery cannot recharge. The battery may be old or it may have been already recharged the maximum number of times. In addition, the battery charger may not be working.</p> <p>Action: Replace the battery pack.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2118</p> <p>LRA Number: 2101</p>	1154
2170	The controller battery charge level is normal.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1151

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2171	The controller battery temperature is above normal.	Warning / Non-critical	Cause: The battery may be recharging, the room temperature may be too hot, or the fan in the system may be degraded or failed. Action: If this alert was generated due to a battery recharge, the situation will correct when the recharge is complete. You should also check if the room temperature is normal and that the system components are functioning properly.	Clear Alert Number: 2172. Related Alert Number: None. LRA Number: 2100	1153
2172	The controller battery temperature is normal.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Status: Alert 2172 is a clear alert for alert 2171. Related Alert Number: None. LRA Number: None.	1151

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2173	Un-supported configuration detected. The SCSI rate of the enclosure management modules (EMMs) is not the same. EMM0 %1 EMM1 %2	Warning / Non-critical	<p>Cause: The EMMs in the enclosure have a different SCSI rate. This is an unsupported configuration. All EMMs in the enclosure should have the same SCSI rate. The % (percent sign) indicates a substitution variable. The text for this substitution variable is displayed with the alert in the Alert Log and can vary depending on the situation.</p> <p>Action: No action required.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2090</p>	853
2174	The controller battery has been removed.	Warning / Non-critical	<p>Cause: The controller cannot communicate with the battery, the battery may be removed, or the contact point between the controller and the battery may be burnt or corroded.</p> <p>Action: Replace the battery if it has been removed. If the contact point between the battery and the controller is burnt or corroded, you will need to replace either the battery or the controller, or both. See the hardware documentation for information on how to safely access, remove, and replace the battery.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2188, 2318</p> <p>LRA Number: 2100</p>	1153

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2175	The controller battery has been replaced.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	1151
2176	The controller battery Learn cycle has started.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: 2177. Related Alert Number: None. LRA Number: None.	1151
2177	The controller battery Learn cycle has completed.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Status: Alert 2177 is a clear alert for alert 2176. Related Alert Number: None. LRA Number: None.	1151

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2178	The controller battery Learn cycle has timed out.	Warning / Non-critical	<p>Cause: The controller battery must be fully charged before the Learn cycle can begin. The battery may be unable to maintain a full charge causing the Learn cycle to timeout. Additionally, the battery must be able to maintain cached data for a specified period of time in the event of a power loss. For example, some batteries maintain cached data for 24 hours. If the battery is unable to maintain cached data for the required period of time, then the Learn cycle will timeout.</p> <p>Action: Replace the battery pack as the battery is unable to maintain a full charge.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2100</p>	1153
2179	The controller battery Learn cycle has been postponed.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1151

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2180	The controller battery Learn cycle will start in %1 days.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes. The %1 indicates a substitution variable. The text for this substitution variable is displayed with the alert in the Alert Log and can vary depending on the situation.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1151
2181	The controller battery Learn cycle will start in %1 hours.	OK / Normal / Informational	<p>Cause: The %1 indicates a substitution variable. The text for this substitution variable is displayed with the alert in the Alert Log and can vary depending on the situation. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1151
2182	An invalid SAS configuration has been detected.	Critical / Failure / Error	<p>Cause: The controller and attached enclosures are not cabled correctly.</p> <p>Action: See the hardware documentation for information on correct cabling configurations.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2061</p>	754

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2183	Replace member operation failed on physical disk %1	Critical / Failure / Error	Cause: The physical disk being replaced has failed. Action: None	Clear Alert Number: None. Related Alert Number: 2060. LRA Number: None	904
2184	Replace member operation cancelled on physical disk	OK / Normal / Informational	Cause: User cancelled the replace member operation. Action: None	Clear Alert Number: None Related Alert Number: 2060 LRA Number: None	901
2185	Replace member operation stopped for rebuild of hot spare on physical disk	Warning / Non-critical	Cause: This alert is provided for informational purposes Action: None	Clear Alert Number: None Related Alert Number: 2060 LRA Number: None	903

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2186	The controller cache has been discarded.	Warning / Non-critical	Cause: The controller has flushed the cache and any data in the cache has been lost. This may happen if the system has memory or battery problems that cause the controller to distrust the cache. Although user data may have been lost, this alert does not always indicate that relevant or user data has been lost. Action: Verify that the battery and memory are functioning properly.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2060	753
2187	Single-bit ECC error limit exceeded.	Warning / Non-critical	Cause: The system memory is malfunctioning. Action: Replace the battery pack.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2060	753

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2188	The controller write policy has been changed to Write Through.	OK/Normal/Informational	<p>Cause: The controller battery is unable to maintain cached data for the required period of time. For example, if the required period of time is 24 hours, the battery is unable to maintain cached data for 24 hours. It is normal to receive this alert during the battery Learn cycle as the Learn cycle discharges the battery before recharging it. When discharged, the battery cannot maintain cached data.</p> <p>Action: Check the health of the battery. If the battery is weak, replace the battery pack.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1151
2189	The controller write policy has been changed to Write Back.	OK/Normal/Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1151

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2190	The controller has detected a hot-plugged enclosure.	OK / Normal / Informational	Cause: The SAS controller with firmware version 6.1 or later has detected a hot-plugged enclosure. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2191	Multiple enclosures are attached to the controller. This is an unsupported configuration.	Critical / Failure / Error	Cause: There are too many enclosures attached to the controller port. When the enclosure limit is exceeded, the controller loses contact with all enclosures attached to the port. Action: Remove the last enclosure. You must remove the enclosure that has been added last and is causing the enclosure limit to exceed.	Clear Alert Number: None. Related Alert Number: 2211 LRA Number: 2091	854

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2192	The virtual disk Check Consistency has made corrections and completed.	OK/Normal/Informational	<p>Cause: The virtual disk Check Consistency has identified errors and made corrections. For example, the Check Consistency may have encountered a bad disk block and remapped the disk block to restore data consistency. This alert is for informational purposes.</p> <p>Action: This alert is for informational purposes only and no additional action is required. As a precaution, monitor the Alert Log for other errors related to this virtual disk. If problems persist, contact Dell Technical Support.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1203
2193	The virtual disk reconfiguration has resumed.	OK/Normal/Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2194	The virtual disk Read policy has changed.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	1201
2195	Dedicated hot spare assigned. Physical disk %1	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None.	Clear Alert Number: 2196. Related Alert Number: None. LRA Number: None.	1201
2196	Dedicated hot spare unassigned. Physical disk %1	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None.	Clear Alert Status: Alert 2196 is a clear alert for alert 2195. Related Alert Number: None. LRA Number: None.	1201

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2197	Replace member operation has stopped for rebuild.	OK/Normal/Informational	<p>Cause: This alert is provided for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None</p> <p>Related Alert Number: 260.</p> <p>LRA Number: None.</p>	903
2198	The physical disk is too small to be used for Replace member operation	OK/Normal/Informational	<p>Cause: Replace member operation cannot be performed on the physical disk as the target disk is smaller for than the source disk. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None</p> <p>Related Alert Number: None</p> <p>LRA Number: None</p>	903
2199	The virtual disk cache policy has changed.	OK/Normal/Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2200	Replace member operation is not possible as combination of SAS and SATA physical disks is not supported in the same virtual disk.	Warning/ Noncritical	<p>Cause: Replace member operation cannot be performed because the target physical disk is of a different type (SAS/SATA) from the rest of the virtual disk. SAS and SATA are not supported on the same virtual disk. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	903
2201	A global hot spare failed.	Warning / Non-critical	<p>Cause: The controller is not able to communicate with a disk that is assigned as a dedicated hot spare. The disk may have been removed. There may also be a bad or loose cable.</p> <p>Action: Check if the disk is healthy and that it has not been removed. Check the cables. If necessary, replace the disk and reassign the hot spare.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2048</p> <p>LRA Number: 2070</p>	903

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2202	A global hot spare has been removed.	OK/Normal/Informational	<p>Cause: The controller is unable to communicate with a disk that is assigned as a global hot spare. The disk may have been removed. There may also be a bad or loose cable.</p> <p>Action: Check if the disk is healthy and that it has not been removed. Check the cables. If necessary, replace the disk and reassign the hot spare.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	901
2203	A dedicated hot spare failed.	Warning/Non-critical	<p>Cause: The controller is unable to communicate with a disk that is assigned as a dedicated hot spare. The disk may have failed or been removed. There may also be a bad or loose cable.</p> <p>Action: Check if the disk is healthy and that it has not been removed. Check the cables. If necessary, replace the disk and reassign the hot spare.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2048</p> <p>LRA Number: 2070</p>	903

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2204	A dedicated hot spare has been removed.	OK / Normal / Informational	<p>Cause: The controller is unable to communicate with a disk that is assigned as a dedicated hot spare. The disk may have been removed. There may also be a bad or loose cable.</p> <p>Action: Check if the disk is healthy and that it has not been removed. Check the cables. If necessary, replace the disk and reassign the hot spare.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	901
2205	A dedicated hot spare has been automatically unassigned.	OK / Normal / Informational	<p>Cause: The hot spare is no longer required because the virtual disk it was assigned to has been deleted.</p> <p>Action: None.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2098, 2161, 2196</p> <p>LRA Number: None.</p>	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2206	The only hot spare available is a SATA disk. SATA disks cannot replace SAS disks.	Warning / Non-critical	<p>Cause: The only physical disk available to be assigned as a hot spare is using SATA technology. The physical disks in the virtual disk are using SAS technology. Because of this difference in technology, the hot spare cannot rebuild data if one of the physical disks in the virtual disk fails.</p> <p>Action: Add a SAS disk that is large enough to be used as the hot spare and assign the new disk as a hot spare.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2070</p>	903
2207	The only hot spare available is a SAS disk. SAS disks cannot replace SATA disks.	Warning / Non-critical	<p>Cause: The only physical disk available to be assigned as a hot spare is using SAS technology. The physical disks in the virtual disk are using SATA technology. Because of this difference in technology, the hot spare cannot rebuild data if one of the physical disks in the virtual disk fails.</p> <p>Action: Add a SATA disk that is large enough to be used as the hot spare and assign the new disk as a hot spare.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2070</p>	903

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2210	Battery requires reconditioning. Initiate the battery learn cycle.	Warning / Non-critical	Cause: Battery requires reconditioning. Action: Initiate the battery learn cycle.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2070	1153
2211	The physical disk is not supported.	Warning / Non-critical	Cause: The physical disk may not have a supported version of the firmware or the disk may not be supported by Dell. Action: If the disk is supported by Dell, update the firmware to a supported version. If the disk is not supported by Dell, replace the disk with one that is supported.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2070	903
2212	The controller battery temperature is above normal.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	1151

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2213	Recharge count maximum exceeded	Warning / Non-critical	<p>Cause: The battery has been recharged more times than the battery recharge limit allows.</p> <p>Action: Replace the battery pack.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2100</p>	1153
2214	Battery charge in progress	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1151
2215	Battery charge process interrupted	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1151

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2216	The battery learn mode has changed to auto.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	1151
2217	The battery learn mode has changed to warn.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	1151
2218	None of the Controller Property are changed.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: You should change at least one controller property and run the command again.	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2219	Abort Check Consist-ency on Error, Allow Reversible Hot Spare and Replace Member, Auto Replace Member on Predictive Failure, and Load balance changed.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2220	Allow Reversible Hot Spare and Replace Member, Auto Replace Member operation on Predictive Failure, and Load balance changed.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2221	Auto Replace Member operation on Predictive Failure, Abort Check Consist-ency on Error, and Load balance changed.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2222	Load balance and Auto Replace Member operation on Predictive Failure changed.	OK / Normal / Informational	Cause: This alert is generated due to user initiated change in controller properties. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2223	Abort Check Consist-ency on Error, Allow Reversible Hot Spare and Replace Member, and Load balance changed.	OK / Normal / Informational	Cause: This alert is generated due to user initiated change in controller properties. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2224	Allow Reversible Hot Spare and Replace Member and Load balance changed.	OK / Normal / Informational	Cause: This alert is generated due to user initiated change in controller properties. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2225	Abort Check Consist-ency on Error and Load balance changed.	OK/Normal/Informational	<p>Cause: This alert is generated due to user initiated change in controller properties. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751
2226	Load balance changed	OK/Normal/Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751
2227	Abort Check Consist-ency on Error, Allow Revertible Hot Spare and Replace Member, and Auto Replace Member Operation on Predictive Failure changed.	OK/Normal/Informational	<p>Cause: This alert is generated due to user initiated change in controller properties. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2228	Allow Reversible Hot Spare and Replace Member and Auto Replace Member operation on Predictive Failure changed.	OK / Normal / Informational	Cause: This alert is generated due to user initiated change in controller properties. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2229	Abort Check Consist-ency on Error and Auto Replace Member operation on Predictive Failure changed.	OK / Normal / Informational	Cause: This alert is generated due to user initiated change in controller properties. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2230	Auto Replace Member operation on Predictive Failure changed.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2231	Allow Revertible Hot Spare and Replace Member and Abort Check Consist-ency on Error changed.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2232	The controller alarm is silenced.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2233	The Background initialization (BGI) rate has changed.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2234	The Patrol Read rate has changed.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2235	The Check Consist-ency rate has changed.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2236	Allow Revertible Hot Spare and Replace Member property changed.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2237	Abort Check Consistency on Error modified.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2238	The controller debug log file has been exported.	OK/Normal/Informational	Cause: The user has attempted to export the controller debug log. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2239	A foreign configuration has been cleared.	OK/Normal/Informational	Cause: The user has attempted to clear a foreign configuration. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2240	A foreign configuration has been imported.	OK / Normal / Informational	Cause: The user has attempted to import a foreign configuration. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2241	The Patrol Read mode has changed.	OK / Normal / Informational	Cause: The controller has changed the petrol read mode. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2242	The Patrol Read has started.	OK / Normal / Informational	Cause: The controller has started the Petrol Read operation. This alert is for informational purposes. Action: None	Clear Alert Number: 2243. Related Alert Number: None. LRA Number: None.	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2243	The Patrol Read has stopped.	OK/Normal/Informational	<p>Cause: The controller has stopped the Petrol Read operation. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Status: Alert 2243 is a clear alert for alert 2242.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751
2244	A virtual disk blink has been initiated.	OK/Normal/Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201
2245	A virtual disk blink has ceased.	OK/Normal/Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2246	The controller battery is degraded.	Warning / Non-critical	<p>Cause: The controller battery charge is weak.</p> <p>Action: As the charge weakens, the charger should automatically recharge the battery. If the battery has reached its recharge limit, replace the battery pack. Monitor the battery to make sure that it recharges successfully. If the battery does not recharge, replace the battery pack.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2100</p>	1153
2247	The controller battery is charging.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: 2358.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1151
2248	The controller battery is executing a Learn cycle.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1151

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2249	The physical disk Clear operation has started.	OK/Normal/Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	901
2250	Redundant Path is broken	Warning/Non-critical	<p>Cause: This alert is provided for informational purposes.</p> <p>Action: Check the connection to the enclosure, which is degraded.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>Local Response Agent (LRA) Alert Number: None.</p>	751
2251	The physical disk blink has initiated.	OK/Normal/Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2252	The physical disk blink has ceased.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	901
2253	Redundant path restored	OK/Normal/Informational	Cause: This alert is provided for informational purposes. Action: None.	Clear Alert Number: None. Related Alert Number: None. Local Response Agent (LRA) Alert Number: None.	751
2254	The Clear operation has cancelled.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2255	The physical disk has been started.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: 2048, 2050, 2065, 2099, 2121, 2196, 2201, 2203 LRA Number: None.	901
2257	Controller preserved cache is discarded	Warning / Non-critical	Cause: The controller cache is discarded by the user. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	753
2258	Controller has preserved cache	Warning / Non-critical	Cause: IO interrupted for a virtual disk which is connected to the controller. Action: Check for foreign configuration and import if any. Check for cable fault. Recover any virtual disk lost by the controller.	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	753

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2259	An enclosure blink operation has initiated.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: 2260. Related Alert Number: None. LRA Number: None.	851
2260	An enclosure blink has ceased	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None.	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	851
2261	A global rescan has initiated.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	None	101
2262	SMART thermal shutdown is enabled.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	101

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2263	SMART thermal shutdown is disabled.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	101
2264	A device is missing.	Warning / Non-critical	<p>Cause: The controller cannot communicate with a device. The device may be removed. There may also be a bad or loose cable.</p> <p>Action: Check if the device is in and not removed. If it is in, check the cables. You should also check the connection to the controller battery and the battery health. A battery with a weak or depleted charge may cause this alert.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2050, 2060, 2070, 2080, 2090, 2100</p>	753 803 853 903 953 1003 1053 1103 1153 1203

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2265	A device is in an unknown state.	Warning / Non-critical	<p>Cause: The controller cannot communicate with a device. The state of the device cannot be determined. There may be a bad or loose cable. The system may also be experiencing problems with the application programming interface (API). There could also be a problem with the driver or firmware.</p> <p>Action: Check the cables. Check if the controller has a supported version of the driver and firmware. You can download the most current version of the driver and firmware from support.dell.com. Rebooting the system may also resolve this problem.</p>	<p>Clear Alert Number: 803</p> <p>None.</p> <p>Related Alert Number: 2048, 2050</p> <p>LRA Number: 2050, 2060, 2070, 2080, 2090, 2100</p>	<p>753</p> <p>803</p> <p>853</p> <p>903</p> <p>953</p> <p>1003</p> <p>1053</p> <p>1103</p> <p>1153</p> <p>1203</p>
2266	Controller log file entry: %1	OK / Normal / Informational	<p>Cause: The %1 indicates a substitution variable. The text for this substitution variable is generated by the controller and is displayed with the alert in the Alert Log. This text can vary depending on the situation. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: 751, 801, 851, 901, None.</p> <p>Related Alert Number: 1001, 1051, None.</p> <p>LRA Number: 1151, 1201</p> <p>None.</p>	<p>751, 801, 851, 901, 951, 1001, 1051, 1101, 1151, 1201</p>

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2267	The controller reconstruct rate has changed.	OK/Normal/Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751
2268	%1, Storage Management has lost communication with the controller. An immediate reboot is strongly recommended to avoid further problems. If the reboot does not restore communication, then contact technical support for more information.	Critical/Failure/Error	<p>Cause: Storage Management has lost communication with a controller. This may occur if the controller driver or firmware is experiencing a problem. The %1 indicates a substitution variable. The text for this substitution variable is displayed with the alert in the Alert Log and can vary depending on the situation.</p> <p>Action: Reboot the system. If the problem is not resolved, contact technical support. See your system documentation for information about contacting technical support by using telephone, fax, and Internet services.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2051</p>	104

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2269	The physical disk Clear operation has completed.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	901
2270	The physical disk Clear operation failed.	Critical / Failure / Error	Cause: A Clear task was being performed on a physical disk but the task was interrupted and did not complete successfully. The controller may have lost communication with the disk. The disk may have been removed or the cables may be loose or defective. Action: Verify that the disk is present and not in a Failed state. Make sure the cables are attached securely. See the online help for more information on checking the cables. Restart the Clear task.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2071	904

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2271	The Patrol Read corrected a media error.	OK / Normal / Informational	Cause: The Patrol Read task has encountered an error such as a bad disk block that cannot be remapped. This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	901
2272	Patrol Read found an uncorrectable media error.	Critical / Failure / Error	Cause: The Patrol Read task has encountered an error that cannot be corrected. There may be a bad disk block that cannot be remapped. Action: Back up your data. If you are able to back up the data successfully, then fully initialize the disk and then restore from back up.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2071	904

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2273	A block on the physical disk has been punctured by the controller.	Critical / Failure / Error	<p>Cause: The controller encountered an unrecoverable medium error when attempting to read a block on the physical disk and marked that block as invalid. If the controller encountered the unrecoverable medium error on a source physical disk during a rebuild or reconfigure operation, it will also puncture the corresponding block on the target physical disk. The invalid block will be cleared on a write operation.</p> <p>Action: Back up your data. If you are able to back up the data successfully, then fully initialize the disk and then restore from back up.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2071</p>	904
2274	The physical disk rebuild has resumed.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2276	The dedicated hot spare is too small.	Warning / Non-critical	<p>Cause: The dedicated hot spare is not large enough to protect all virtual disks that reside on the disk group.</p> <p>Action: Assign a larger disk as the dedicated hot spare.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2070</p>	903
2277	The global hot spare is too small.	Warning / Non-critical	<p>Cause: The global hot spare is not large enough to protect all virtual disks that reside on the controller.</p> <p>Action: Assign a larger disk as the global hot spare.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2070</p>	903

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2278	The controller battery charge level is below a normal threshold.	OK / Normal / Informational	<p>Cause: The battery is discharging. A battery discharge is a normal activity during the battery Learn cycle. Before completing, the battery Learn cycle recharges the battery. You should receive alert 2179 when the recharge occurs.</p> <p>Action1: Check if the battery Learn cycle is in progress. Alert 2176 indicates that the battery Learn cycle has initiated. The battery also displays the Learn state while the Learn cycle is in progress.</p> <p>Action2: If a Learn cycle is not in progress, replace the battery pack.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2199</p> <p>LRA Number: None.</p>	1154
2279	The controller battery charge level is operating within normal limits.	OK / Normal / Informational	<p>Cause: This alert indicates that the battery is recharging during the battery Learn cycle. This alert is provided for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1151

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2280	A disk media error has been corrected.	OK/Normal/Informational	<p>Cause: A disk media error was detected while the controller was completing a background task. A bad disk block was identified. The disk block has been remapped.</p> <p>Action: Consider replacing the disk. If you receive this alert frequently, be sure to replace the disk. You should also routinely back up your data.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201
2281	Virtual disk has inconsistent data.	OK/Normal/Informational	<p>Cause: The virtual disk has inconsistent data. This may be caused when a power loss or system shutdown occurs while data is being written to the virtual disk. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2127</p> <p>LRA Number: None.</p>	1201

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2282	Hot spare SMART polling failed.	Critical / Failure / Error	<p>Cause: The controller firmware attempted a SMART polling on the hot spare but was unable to complete it. The controller has lost communication with the hot spare.</p> <p>Action: Check the health of the disk assigned as a hot spare. You may need to replace the disk and reassign the hot spare. Make sure the cables are attached securely. See the <i>Dell OpenManage Server Administrator Storage Management User's Guide</i> for more information on checking the cables.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2071</p>	904
2285	A disk media error was corrected during recovery.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2286	A Learn cycle start is pending while the battery charges.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	1151
2287	The Patrol Read is paused.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: 2288. Related Alert Number: None. LRA Number: None.	751
2288	The patrol read has resumed.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Status: Alert 2288 is a clear alert for alert 2287. Related Alert Number: None. LRA Number: None.	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2289	Multi-bit ECC error.	Critical / Failure / Error	<p>Cause: An error involving multiple bits has been encountered during a read or write operation. The error correction algorithm recalculates parity data during read and write operations. If an error involves only a single bit, it may be possible for the error correction algorithm to correct the error and maintain parity data. An error involving multiple bits, however, usually indicates data loss. In some cases, if the multi-bit error occurs during a read operation, the data on the disk may be correct/valid. If the multi-bit error occurs during a write operation, data loss has occurred.</p> <p>Action: Replace the dual in-line memory module (DIMM). The DIMM is a part of the controller battery pack. See your hardware documentation for information on replacing the DIMM. You may need to restore data from backup.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2061</p>	754

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2290	Single-bit ECC error.	Warning / Non-critical	<p>Cause: An error involving a single bit has been encountered during a read or write operation. The error correction algorithm has corrected this error.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2060</p>	753
2291	An EMM has been discovered.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	851
2292	Communication with the enclosure has been lost.	Critical / Failure / Error	<p>Cause: The controller has lost communication with an EMM. The cables may be loose or defective.</p> <p>Action: Make sure the cables are attached securely. Reboot the system.</p>	<p>Clear Alert Number: 2162.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2091</p>	854

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2293	The EMM has failed.	Critical / Failure / Error	<p>Cause: The failure may be caused by a loss of power to the EMM. The EMM self test may also have identified a failure. There could also be a firmware problem or a multi-bit error.</p> <p>Action: Replace the EMM. See the hardware documentation for information on replacing the EMM.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2091</p>	854 and 954
2294	A device has been inserted.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	851, 1101 and 1001
2295	A device has been removed.	Critical / Failure / Error	<p>Cause: A device has been removed and the system is no longer functioning in optimal condition.</p> <p>Action: Replace the device.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2091</p>	854, 1004 and 1104

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2296	An EMM has been inserted.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	951
2297	An EMM has been removed.	Critical / Failure / Error	<p>Cause: An EMM has been removed.</p> <p>Action: Reinsert the EMM. See the hardware documentation for information on replacing the EMM.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2091</p>	954
2298	There is a bad sensor on an enclosure.	Warning / Non-critical	<p>Cause: The enclosure has a bad sensor. The enclosure sensors monitor the fan speeds, temperature probes, etc. The % indicates a substitution variable. The text for this substitution variable is displayed with the alerts in the Alert Log and can vary depending on the situation.</p> <p>Action: See the hardware documentation for more information.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2090</p>	853

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2299	Bad PHY %1	Critical / Failure / Error	<p>Cause: There is a problem with a physical connection or PHY. The %1 indicates a substitution variable. The text for this substitution variable is displayed with the alert in the Alert Log and can vary depending on the situation.</p> <p>Action: Contact Dell technical support.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2091</p>	854
2300	The enclosure is unstable.	Critical / Failure / Error	<p>Cause: The controller is not receiving a consistent response from the enclosure. There could be a firmware problem or an invalid cabling configuration. If the cables are too long, they will degrade the signal.</p> <p>Action: Power down all enclosures attached to the system and reboot the system. If the problem persists, upgrade the firmware to the latest supported version. You can download the most current version of the driver and firmware from support.dell.com. Make sure the cable configuration is valid. See the hardware documentation for valid cabling configurations.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2091</p>	854

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2301	The enclosure has a hardware error.	Critical / Failure / Error	<p>Cause: The enclosure or an enclosure component is in a Failed or Degraded state.</p> <p>Action: Check the health of the enclosure and its components. Replace any hardware that is in a Failed state. See the hardware documentation for more information.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2091</p>	854
2302	The enclosure is not responding.	Critical / Failure / Error	<p>Cause: The enclosure or an enclosure component is in a Failed or Degraded state.</p> <p>Action: Check the health of the enclosure and its components. Replace any hardware that is in a Failed state. See the hardware documentation for more information.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2091</p>	854
2303	The enclosure cannot support both SAS and SATA physical disks. Physical disks may be disabled.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	851

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2304	An attempt to hot plug an EMM has been detected. This type of hot plug is not supported.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: 2211 LRA Number: None.	751
2305	The physical disk is too small to be used for a rebuild.	Warning / Non-critical	Cause: The physical disk is too small to rebuild the data. Action: Remove the physical disk and insert a new physical disk that is the same size or larger than the disk that is being rebuilt. The new physical disk must also use the same technology (for example, SAS or SATA) as the disk being rebuilt. If the rebuild does not start automatically after you have inserted a suitable physical disk, then run the Rebuild task. See the <i>Dell OpenManage Server Administrator Storage Management User's Guide</i> for more information.	Clear Alert Number: None. Related Alert Number: 2326 LRA Number: 2070	903

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2306	Bad block table is 80% full.	Warning / Non-critical	<p>Cause: The bad block table is used for remapping bad disk blocks. This table fills, as bad disk blocks are remapped. When the table is full, bad disk blocks can no longer be remapped, and disk errors can no longer be corrected. At this point, data loss can occur. The bad block table is now 80% full.</p> <p>Action: Back up your data. Replace the disk generating this alert and restore from back up.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2307</p> <p>LRA Number: 2070</p>	903
2307	Bad block table is full. Unable to log block %1	Critical / Failure / Error	<p>Cause: The bad block table is used for remapping bad disk blocks. This table fills, as bad disk blocks are remapped. When the table is full, bad disk blocks can no longer be remapped and disk errors can no longer be corrected. At this point, data loss can occur. The %1 indicates a substitution variable. The text for this substitution variable is displayed with the alert in the Alert Log and can vary depending on the situation.</p> <p>Action: Replace the disk generating this alert. If necessary, restore your data from backup.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2048</p> <p>LRA Number: 2071</p>	904

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2309	A physical disk is incompatible.	Warning / Non-critical	<p>Cause: You have attempted to replace a disk with another disk that is using an incompatible technology. For example, you may have replaced one side of a mirror with a SAS disk when the other side of the mirror is using SATA technology.</p> <p>Action: See the hardware documentation for information on replacing disks.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2070</p>	903
2310	A virtual disk is permanently degraded.	Critical / Failure / Error	<p>Cause: A redundant virtual disk has lost redundancy. This may occur when the virtual disk suffers the failure of multiple physical disks. In this case, both the source physical disk and the target disk with redundant data have failed. A rebuild is not possible because there is no redundancy.</p> <p>Action: Replace the failed disks and restore from backup.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2081</p>	1204

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2311	The firmware on the EMMs is not the same version. EMM0 %1 EMM1 %2	Warning / Non-critical	<p>Cause: The firmware on the EMM modules is not the same version. It is required that both modules have the same version of the firmware. This alert may be caused if you attempt to insert an EMM module that has a different firmware version than an existing module. The %1 and %2 indicate a substitution variable. The text for these substitution variables is displayed with the alert in the Alert Log and can vary depending on the situation.</p> <p>Action: Upgrade to the same version of the firmware on both EMM modules.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2090</p>	853
2312	A power supply in the enclosure has an AC failure.	Warning / Non-critical	<p>Cause: The power supply has an AC failure.</p> <p>Action: Replace the power supply.</p>	<p>Clear Alert Number: 2325.</p> <p>Related Alert Number: 2122, 2324.</p> <p>LRA Number: 2090</p>	1003

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2313	A power supply in the enclosure has a DC failure.	Warning / Non-critical	Cause: The power supply has a DC failure. Action: Replace the power supply.	Clear Alert Number: 2323. Related Alert Number: 2122, 2322. LRA Number: 2090	1003
2314	The initialization sequence of SAS components failed during system startup. SAS management and monitoring is not possible.	Critical / Failure / Error	Cause: Storage Management is unable to monitor or manage SAS devices. Action: Reboot the system. If problem persists, make sure you have supported versions of the drivers and firmware. Also, you may need to reinstall Storage Management or Server Administrator because of some missing installation components.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2051	104

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2315	Diagnostic message %1	OK/Normal/Informational	<p>Cause: The %1 indicates a substitution variable. The text for this substitution variable is generated by the utility that ran the diagnostics and is displayed with the alert in the Alert Log. This text can vary depending on the situation. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751
2316	Diagnostic message %1	Critical/Failure/Error	<p>Cause: A diagnostics test failed. The %1 indicates a substitution variable. The text for this substitution variable is generated by the utility that ran the diagnostics and is displayed with the alert in the Alert Log. This text can vary depending on the situation.</p> <p>Action: See the documentation for the utility that ran the diagnostics for more information.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2061</p>	754

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2318	Problems with the battery or the battery charger have been detected. The battery health is poor.	Warning / Non-critical	Cause: The battery or the battery charger is not functioning properly. Action: Replace the battery pack.	Clear Alert Number: None. Related Alert Number: 2188 LRA Number: 2100	1154
2319	Single-bit ECC error. The DIMM is degrading.	Warning / Non-critical	Cause: The DIMM is beginning to malfunction. Action: Replace the DIMM to avoid data loss or data corruption. The DIMM is a part of the controller battery pack. See your hardware documentation for information on replacing the DIMM or contact technical support.	Clear Alert Number: None. Related Alert Number: 2320 LRA Number: 2060	753

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2320	Single-bit ECC error. The DIMM is critically degraded.	Critical / Failure / Error	<p>Cause: The DIMM is malfunctioning. Data loss or data corruption may be imminent.</p> <p>Action: Replace the DIMM immediately to avoid data loss or data corruption. The DIMM is a part of the controller battery pack. See your hardware documentation for information on replacing the DIMM or contact technical support.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2321</p> <p>LRA Number: 2061</p>	754
2321	Single-bit ECC error. The DIMM is critically degraded. There will be no further reporting.	Critical / Failure / Error	<p>Cause: The DIMM is malfunctioning. Data loss or data corruption is imminent. The DIMM must be replaced immediately. No further alerts will be generated.</p> <p>Action: Replace the DIMM immediately. The DIMM is a part of the controller battery pack. See your hardware documentation for information on replacing the DIMM.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2061</p>	754

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2322	The DC power supply is switched off.	Critical / Failure / Error	Cause: The power supply unit is switched off. Either a user switched off the power supply unit or it is defective. Action: Check if the power switch is turned off. If it is turned off, turn it on. If the problem persists, check if the power cord is attached and functional. If the problem is still not corrected or if the power switch is already turned on, replace the power supply unit.	Clear Alert Number: 2323. Related Alert Number: None. LRA Number: 2091	1004
2323	The power supply is switched on.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Status: Alert 2323 is a clear alert for alerts 2313 and 2322. Related Alert Number: None. LRA Number: None.	1001

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2324	The AC power supply cable has been removed.	Critical / Failure / Error	<p>Cause: The power cable may be pulled out or removed. The power cable may also have overheated and become warped and nonfunctional.</p> <p>Action: Replace the power cable.</p>	<p>Clear Alert Number: 2325.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2091</p>	1004
2325	The power supply cable has been inserted.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Status: Alert 2325 is a clear alert for alerts 2324 and 2312.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1001

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2326	A foreign configuration has been detected.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes. The controller has physical disks that were moved from another controller. These physical disks contain virtual disks that were created on the other controller. See the Import Foreign Configuration and Clear Foreign Configuration section in the <i>Dell OpenManage Server Administrator Storage Management User's Guide</i> for more information.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751
2327	The NVRAM has corrupted data. The controller is reinitializing the NVRAM.	Warning / Non-critical	<p>Cause: The NVRAM has corrupted data. This may occur after a power surge, a battery failure, or for other reasons. The controller is reinitializing the NVRAM.</p> <p>Action: None. The controller is taking the required corrective action. If this alert is generated often (such as during each reboot), replace the controller.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2266</p> <p>LRA Number: 2060</p>	753

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2328	The NVRAM has corrupt data.	Warning / Non-critical	<p>Cause: The NVRAM has corrupt data. The controller is unable to correct the situation.</p> <p>Action: Replace the controller.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2060</p>	753
2329	SAS port report: %1	Warning / Non-critical	<p>Cause: The text for this alert is generated by the controller and can vary depending on the situation. The %1 indicates a substitution variable. The text for this substitution variable is generated by the controller and is displayed with the alert in the Alert Log. This text can vary depending on the situation.</p> <p>Action: Run the PHY integrity test diagnostic. Make sure the cables are attached securely. If the problem persists, replace the cable with a valid cable according to SAS specifications. If the problem still persists, you may need to replace some devices such as the controller or EMM. See the hardware documentation for more information.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2060</p>	753

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2330	SAS port report: %1	OK / Normal / Informational	<p>Cause: The %1 indicates a substitution variable. The text for this substitution variable is generated by the controller and is displayed with the alert in the Alert Log. This text can vary depending on the situation. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751
2331	A bad disk block has been reassigned.	OK / Normal / Informational	<p>Cause: The disk has a bad block. Data has been readdressed to another disk block and no data loss has occurred.</p> <p>Action: Monitor the disk for other alerts or indications of poor health. For example, you may receive alert 2306. Replace the disk if you suspect there is a problem.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2332	A controller hot plug has been detected.	OK/Normal/Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751
2334	Controller event log: %1	OK/Normal/Informational	<p>Cause: The %1 indicates a substitution variable. The text for this substitution variable is generated by the controller and is displayed with the alert in the Alert Log. This text is from events in the controller event log that were generated while Storage Management was not running. This text can vary depending on the situation. This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2335	Controller event log: %1	Warning / Non-critical	<p>Cause: The %1 indicates a substitution variable. The text for this substitution variable is generated by the controller and is displayed with the alert in the Alert Log. This text is from events in the controller event log that were generated while Storage Management was not running. This text can vary depending on the situation.</p> <p>Action: If there is a problem, review the controller event log and the Server Administrator Alert Log for significant events or alerts that may assist in diagnosing the problem. Check the health of the storage components. See the hardware documentation for more information.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2060</p>	753

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2336	Controller event log: %1	Critical / Failure / Error	<p>Cause: The %1 indicates a substitution variable. The text for this substitution variable is generated by the controller and is displayed with the alert in the Alert Log. This text is from events in the controller event log that were generated while Storage Management was not running. This text can vary depending on the situation.</p> <p>Action: See the hardware documentation for more information.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2061</p>	754
2337	The controller is unable to recover cached data from the battery backup unit (BBU).	Critical / Failure / Error	<p>Cause: The controller was unable to recover data from the cache. This may occur when the system is without power for an extended period of time when the battery is discharged.</p> <p>Action: Check if the battery is charged and in good health. When the battery charge is unacceptably low, it cannot maintain cached data. Check if the battery has reached its recharge limit. The battery may need to be recharged or replaced.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2101</p>	1154

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2338	The controller has recovered cached data from the BBU.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	1151
2339	The factory default settings have been restored.	OK / Normal / Informational	Cause: This alert is for informational purposes. Action: None	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2340	The BGI completed with uncorrectable errors.	Critical / Failure / Error	<p>Cause: The BGI task encountered errors that cannot be corrected. The virtual disk contains physical disks that have unusable disk space or disk errors that cannot be corrected.</p> <p>Action: Replace the physical disk that contains the disk errors. Review other alert messages to identify the physical disk that has errors. If the virtual disk is redundant, you can replace the physical disk and continue using the virtual disk. If the virtual disk is non-redundant, you may need to recreate the virtual disk after replacing the physical disk. After replacing the physical disk, run Check Consistency to check the data.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2081</p>	1204
2341	The Check Consistency made corrections and completed.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1201

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2342	The Check Consistency found inconsistent parity data. Data redundancy may be lost.	Warning / Non-critical	Cause: The data on a source disk and the redundant data on a target disk is inconsistent. Action: Restart the Check Consistency task. If you receive this alert again, check the health of the physical disks included in the virtual disk. Review the alert messages for significant alerts related to the physical disks. If you suspect that a physical disk has a problem, replace it and restore from backup.	Clear Alert Number: None. Related Alert Number: 2341, 2343 LRA Number: 2080	1203
2343	The Check Consistency logging of inconsistent parity data is disabled.	Warning / Non-critical	Cause: The Check Consistency can no longer report errors in the parity data. Action: See the hardware documentation for more information.	Clear Alert Number: None. Related Alert Number: None. LRA Number: 2080	1203

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2346	Error occurred: %1	Warning / Non-critical	<p>Cause: A physical device may have an error. The %1 indicates a substitution variable. The text for this substitution variable is generated by the firmware and is displayed with the alert in the Alert Log. This text can vary depending on the situation.</p> <p>Action: Verify the health of attached devices. Review the Alert Log for significant events. Run the PHY integrity diagnostic tests. You may need to replace faulty hardware. Make sure the cables are attached securely. See the hardware documentation for more information.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2048, 2050, 2056, 2057, 2076, 2079, 2081, 2083, 2095, 2129, 2201, 2203, 2270, 2282, 2369</p> <p>LRA Number: 2070</p>	903
2347	The rebuild failed due to errors on the source physical disk.	Critical / Failure / Error	<p>Cause: You are attempting to rebuild data that resides on a defective disk.</p> <p>Action: Replace the source disk and restore from backup.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2195, 2346</p> <p>LRA Number: 2071</p>	904

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2348	The rebuild failed due to errors on the target physical disk.	Critical / Failure / Error	Cause: You are attempting to rebuild data on a disk that is defective. Action: Replace the target disk. If a rebuild does not automatically start after replacing the disk, initiate the Rebuild task. You may need to assign the new disk as a hot spare to initiate the rebuild.	Clear Alert Number: None. Related Alert Number: 2195, 2346 LRA Number: 2071	904
2349	A bad disk block could not be reassigned during a write operation.	Critical / Failure / Error	Cause: A write operation could not complete because the disk contains bad disk blocks that could not be reassigned. Data loss may have occurred and data redundancy may also be lost. Action: Replace the disk.	Clear Alert Number: None. Related Alert Number: 2346 LRA Number: 2071	904
2350	There was an unrecoverable disk media error during the rebuild.	Critical / Failure / Error	Cause: The rebuild encountered an unrecoverable disk media error. Action: Replace the disk.	Clear Alert Number: None. Related Alert Number: 2095, 2273 LRA Number: 2071	904

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2351	A physical disk is marked as missing.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None.	Clear Alert Number: 2352. Related Alert Number: None. LRA Number: None.	901
2352	A physical disk that was marked as missing has been replaced.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None.	Clear Alert Status: Alert 2352 is a clear alert for alert 2351. Related Alert Number: None. LRA Number: None.	901
2353	The enclosure temperature has returned to normal.	OK/Normal/Informational	Cause: This alert is for informational purposes. Action: None.	Clear Alert Status: Alert 2353 is a clear alert for alerts 2100 and 2101. Related Alert Number: None. LRA Number: None.	851

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2356	SAS SMP communications error %1.	Critical / Failure / Error	<p>Cause: The %1 indicates a substitution variable. The text for this substitution variable is generated by the firmware and is displayed with the alert in the Alert Log. This text can vary depending on the situation. The reference to SMP in this text refers to SAS Management Protocol.</p> <p>Action: There may be a SAS topology error. See the hardware documentation for information on correct SAS topology configurations. There may be problems with the cables such as a loose connection or an invalid cabling configuration. See the hardware documentation for information on correct cabling configurations. Check if the firmware is a supported version.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2061</p>	754

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2357	SAS expander error: %1	Critical / Failure / Error	<p>Cause: The %1 indicates a substitution variable. The text for this substitution variable is generated by the firmware and is displayed with the alert in the Alert Log. This text can vary depending on the situation.</p> <p>Action: There may be a problem with the enclosure. Check the health of the enclosure and its components, by selecting the enclosure object in the tree view. The Health subtab displays a red "X" or yellow exclamation point for enclosure components that are failed or degraded. See the enclosure documentation for more information.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2061</p>	754
2358	The battery charge cycle is complete.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	1151

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2359	The physical disk is not certified.	Warning / Non-critical	<p>Cause: The physical disk does not comply with the standards set by Dell and is not supported.</p> <p>Action: Replace the physical disk with a physical disk that is supported.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: 2070</p>	903
2360	A user has discarded data from the controller cache.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751
2361	Physical disk(s) that are part of a virtual disk have been removed while the system was shut down. This removal was discovered during system startup.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2362	Physical disk(s) have been removed from a virtual disk. The virtual disk will be in Failed state during the next system reboot.	OK/Normal / Informational	Cause: This alert is for informational purposes. Action: None.	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2364	All virtual disks are missing from the controller. This situation was discovered during system start-up.	OK/Normal / Informational	Cause: This alert is for informational purposes. Action: None.	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	751
2366	Dedicated spare imported as global due to missing arrays	OK/Normal / Informational	Cause: This alert is for informational purposes. Action: None.	Clear Alert Number: None. Related Alert Number: None. LRA Number: None.	901

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2367	Rebuild not possible as SAS/SATA is not supported in the same virtual disk.	Warning / Non-critical	<p>Cause: The physical disk is using an incompatible technology.</p> <p>Action: All physical disks in the virtual disk must use the same technology. You cannot use both SAS and SATA physical disks in the same virtual disk. Remove the physical disk and insert a new physical disk that uses the correct technology. If the rebuild does not start automatically after you have inserted a suitable physical disk, then run the Rebuild task.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2326</p> <p>LRA Number: 2070</p>	903
2368	The SCSI Enclosure Processor (SEP) has been rebooted as part of the firmware download operation and will be unavailable until the operation completes.	OK / Normal / Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: 2049, 2052, 2162, 2292</p> <p>LRA Number: None.</p>	851

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2369	Virtual Disk Re-dundancy has been degraded.	OK/Normal/Informational	<p>Cause: A physical disk in a RAID 6 virtual disk has either failed or been removed.</p> <p>Action: Replace the missing or failed physical disk.</p>	<p>Clear Alert Number: 2121.</p> <p>Related Alert Number: 2048, 2049, 2050, 2076, 2346</p> <p>LRA Number: None.</p>	1201
2371	Attempted import of Unsupported Virtual Disk type RAID%1	OK/Normal/Informational	<p>Cause: This alert is for informational purposes.</p> <p>Action: None.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Number: None.</p>	751
2372	Attempted import of Virtual Disk exceeding the limit supported on the controller.	OK/Normal/Informational	<p>Cause: This alert is provided for informational purposes.</p> <p>Action: None.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Alert Number: None.</p>	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2373	Attempted import of unsupported Virtual Disk type RAID %1	OK / Normal / Informational	Cause: This alert is provided for informational purposes. User is attempting to import a foreign virtual disk with unsupported RAID level on the controller Action: None.	Clear Alert Number: None. Related Alert Number: None. LRA Alert Number: None.	751
2374	Attempted import of Virtual Disk with missing span	OK / Normal / Informational	Cause: This alert is provided for informational purposes. User is attempting to import a foreign virtual disk with a missing span. Action: None.	Clear Alert Number: None. Related Alert Number: None. LRA Alert Number: None.	751
2375	Attempted import of Virtual Disk with missing physical disk	OK / Normal / Informational	Cause: User is attempting to import a foreign virtual disk with a missing physical disk. This alert is provided for informational purposes. Action: None.	Clear Alert Number: None. Related Alert Number: None. LRA Alert Number: None.	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2376	Attempted import of Virtual Disk with stale physical disk	OK/Normal/Informational	Cause: User is attempting to import a foreign virtual disk with a stale physical disk. This alert is provided for informational purposes. Action: None.	Clear Alert Number: None. Related Alert Number: None. LRA Alert Number: None.	751
2377	Attempted import of an orphan drive	OK/Normal/Informational	Cause: User is attempting to import an orphan drive. This alert is provided for informational purposes. Action: None.	Clear Alert Number: None. Related Alert Number: None. LRA Alert Number: None.	751
2378	Attempted import of an incompatible physical drive	OK/Normal/Informational	Cause: User is attempting to import an incompatible physical drive. This alert is provided for informational purposes. Action: None.	Clear Alert Number: None. Related Alert Number: None. LRA Alert Number: None.	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2379	An overflow of the foreign configuration has occurred. You can import the foreign configuration in multiple attempts	OK / Normal / Informational	Cause: This alert is provided for informational purposes. Action: None.	Clear Alert Number: None. Related Alert Number: None. LRA Alert Number: None.	751
2380	Foreign configuration has been partially imported. Some configuration failed to import.	OK / Normal / Informational	Cause: This alert is provided for informational purposes. Action: None.	Clear Alert Number: None. Related Alert Number: None. LRA Alert Number: None.	751

Table 4-4. Storage Management Messages (continued)

Event ID	Description	Severity	Cause and Action	Related Alert Information	SNMP Trap Numbers
2381	Controller preserved cache is recovered.	OK/Normal/Informational	<p>Cause: This alert is provided for informational purposes.</p> <p>Action: None</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Alert Number: None.</p>	751
2382	<p>An unsupported configuration was detected. The controller does not support physical disks of type SSD:</p> <p><Physical DiskID>,<controllerID>,<connector ID></p>	Warning / Non-critical	<p>Cause: A physical disk of media type SSD is attached to a controller that does not support SSD disks.</p> <p>Action: Replace the unsupported physical disk with a physical disk of media type HDD.</p>	<p>Clear Alert Number: None.</p> <p>Related Alert Number: None.</p> <p>LRA Alert Number: None.</p>	903

Index

Symbols	1050, 20
%1, Storage Management has lost communication with this RAID controller and attached storage. An immediate reboot is strongly recommended to avoid further problems. If the reboot does not restore communication, there may be a hardware failure., 172	1051, 20 1052, 21 1053, 21 1054, 22 1055, 22 1100, 23 1101, 23 1102, 23 1103, 24 1104, 24 1105, 24 1150, 25 1151, 25 1152, 26 1153, 26 1154, 27 1155, 27 1200, 28 1201, 29 1202, 29 1203, 30 1204, 30 1205, 31
Numerics	
0001, 17	
1000, 17	
1001, 17	
1002, 17	
1003, 17	
1004, 18	
1005, 18	
1006, 18	
1007, 18	
1008, 19	
1009, 19	
1011, 19	
1012, 19	

1250, 32	1500, 43
1251, 32	1501, 43
1252, 32	1502, 43
1253, 33	1503, 44
1254, 33	1504, 44
1255, 33	1505, 44
1300, 34	1550, 45
1301, 34	1551, 45
1302, 35	1552, 45
1303, 35	1553, 45
1304, 35	1554, 45
1305, 36	1555, 45
1306, 36	1600, 46
1350, 37	1601, 46
1351, 37	1602, 47
1352, 38	1603, 47
1353, 38	1604, 48
1354, 39	1605, 48
1355, 39	1650, 49
1403, 40	1651, 49
1404, 40	1652, 50
1450, 41	1653, 50
1451, 41	1700, 51
1452, 41	1701, 51
1453, 41	1702, 51
1454, 42	1703, 52
1455, 42	1704, 52

1705, 52
2000, 53
2002, 53
2003, 53
2004, 53
2005, 53
2048, 83
2049, 84
2050, 85
2051, 85
2052, 85
2053, 86
2054, 86
2055, 86
2056, 87
2057, 88
2058, 89
2059, 89
2060, 90
2061, 90
2062, 90
2063, 91
2064, 91
2065, 91
2067, 92
2070, 93
2074, 93
2075, 94
2076, 94
2077, 95
2079, 95
2080, 95
2081, 96
2082, 96
2083, 97
2085, 97
2086, 97
2087, 98
2088, 98
2089, 98
2090, 99
2091, 99
2092, 99
2094, 100
2095, 101
2098, 101
2099, 102
2100, 102
2101, 103
2102, 103
2103, 104
2104, 104
2105, 104
2106, 105

2107, 106
2108, 107
2109, 108
2110, 110
2111, 110
2112, 111
2114, 111
2115, 112
2116, 112
2117, 113
2118, 113
2120, 114
2121, 114
2122, 115
2123, 116
2124, 118
2125, 118
2126, 119
2127, 120
2128, 120
2129, 120
2130, 121
2131, 121
2132, 122
2135, 122
2136, 123
2137, 123
2138, 124
2139, 125
2140, 125
2141, 125
2142, 126
2143, 126
2144, 126
2145, 127
2146, 127
2147, 127
2148, 128
2149, 128
2150, 128
2151, 129
2152, 129
2153, 129
2154, 130
2155, 130
2156, 130
2157, 131
2158, 131
2159, 132
2162, 132
2163, 133
2164, 133
2165, 134
2166, 134

2167, 135
2168, 135
2169, 136
2170, 136
2171, 137
2173, 138
2174, 138
2175, 139
2176, 139
2177, 139
2178, 140
2179, 140
2180, 141
2181, 141
2182, 141
2183, 142
2184, 142
2185, 142
2186, 143
2187, 143
2188, 144
2189, 144
2190, 145
2191, 145
2192, 146
2193, 146
2194, 147
2195, 147
2196, 147
2197, 148
2198, 148
2199, 148
2200, 149
2201, 149
2202, 150
2203, 150
2204, 151
2205, 151
2206, 152
2207, 152
2210, 153
2211, 153
2212, 153
2213, 154
2214, 154
2215, 154
2216, 155
2217, 155
2218, 155
2219, 156
2220, 156
2221, 156
2222, 157
2223, 157

2224, 157	2254, 167
2226, 158	2255, 168
2227, 158	2257, 168
2228, 159	2258, 168
2229, 159	2259, 169
2230, 159	2260, 169
2231, 160	2261, 169
2232, 160	2262, 169
2233, 160	2263, 170
2234, 161	2264, 170
2235, 161	2265, 171
2236, 161	2266, 171
2237, 162	2267, 172
2238, 162	2268, 172
2239, 162	2269, 173
2240, 163	2270, 173
2241, 163	2271, 174
2242, 163	2272, 174
2243, 164	2273, 175
2244, 164	2274, 175
2245, 164	2276, 176
2246, 165	2277, 176
2247, 165	2278, 177
2248, 165	2279, 177
2249, 166	2280, 178
2251, 166	2281, 178
2252, 167	2282, 179

2285, 179	2313, 191
2286, 180	2314, 191
2287, 180	2315, 192
2288, 180	2316, 192
2289, 181	2318, 193
2290, 182	2319, 193
2291, 182	2320, 194
2292, 182	2321, 194
2293, 183	2322, 195
2294, 183	2323, 195
2295, 183	2324, 196
2296, 184	2325, 196
2297, 184	2326, 197
2298, 184	2327, 197
2299, 185	2328, 198
2300, 185	2329, 198
2301, 186	2330, 199
2302, 186	2331, 199
2303, 186	2332, 200
2304, 187	2334, 200
2305, 187	2335, 201
2306, 188	2336, 202
2307, 188	2337, 202
2309, 189	2338, 203
2310, 189	2339, 203
2311, 190	2340, 204
2312, 190	2341, 204

2342, 205
2343, 205
2346, 206
2347, 206
2348, 207
2349, 207
2350, 207
2351, 208
2352, 208
2353, 208
2356, 209
2357, 210
2358, 210
2359, 211
2360, 211
2361, 211
2362, 212
2364, 212
2366, 212
2367, 213
2368, 213
2369, 214
2371, 214
2372, 214
2373, 215
2374, 215
2375, 215

2376, 216
2377, 216
2378, 216
2379, 217
2380, 217
2381, 218
2382, 218

A

A bad disk block could not be
reassigned during a write
operation., 207
A bad disk block has been
reassigned., 199
A block on the physical disk has
been punctured by the
controller., 175
A consistency check on a virtual
disk has been paused
(suspended), 111
A consistency check on a virtual
disk has been resumed, 112
A controller hot plug has been
detected., 200
A controller rescan has been
initiated., 162
A dedicated hot spare
failed., 150
A dedicated hot spare has been
automatically
unassigned., 151

- A dedicated hot spare has been removed., 151
- A device has been inserted., 183
- A device has been removed., 183
- A device is in an unknown state., 171
- A device is missing., 170
- A disk media error has been corrected., 178
- A disk media error was corrected during recovery., 179
- A foreign configuration has been cleared., 162
- A foreign configuration has been detected., 197
- A foreign configuration has been imported., 163
- A global hot spare failed., 149
- A global hot spare has been removed., 150
- A global rescan has initiated., 169
- A Learn cycle start is pending while the battery charges., 180
- A mirrored virtual disk has been unmirrored, 113
- A physical disk is incompatible., 189
- A physical disk is marked as missing., 208
- A physical disk that was marked as missing has been replaced., 208
- A power supply in the enclosure has a DC failure., 191
- A power supply in the enclosure has an AC failure., 190
- A previously scheduled system BIOS update has been canceled, 17
- A system BIOS update has been scheduled for the next reboot, 17
- A user has discarded data from the controller cache., 211
- A virtual disk and its mirror have been split, 112
- A virtual disk blink has been initiated., 164
- A virtual disk blink has ceased., 164
- A virtual disk is permanently degraded., 189
- AC power cord is not being monitored, 43
- AC power cord messages, 43
- AC power cord sensor, 9
- AC power cord sensor has failed, 43, 65
- AC power has been lost, 44
- AC power has been restored, 43

All virtual disks are missing from the controller. This situation was discovered during system start-up., 212

An attempt to hot plug an EMM has been detected. This type of hot plug is not supported., 187

An EMM has been discovered., 182

An EMM has been inserted., 184

An EMM has been removed., 184

An enclosure blink has ceased, 169

An enclosure blink operation has initiated., 169

An invalid SAS configuration has been detected., 141

Array Manager is installed on the system, 122

Asset name changed, 129

Asset tag changed, 129

Automatic System Recovery (ASR) action was performed, 18

B

Background initialization cancelled, 120

Background initialization completed, 121

Background initialization failed, 120

Background initialization started, 120

Bad block extended medium error, 128

Bad block extended sense error, 128

Bad block medium error, 128

Bad block replacement error, 127

Bad block sense error, 127

Bad block table is 80% full., 188

Bad block table is full. Unable to log block %1, 188

Bad PHY %1, 185

Battery charge in progress, 154

Battery charge process interrupted, 154

battery messages, 74

BIOS Generated System Events, 67

bios generated system messages, 67

BMC Watchdog Events, 62

BMC watchdog messages, 62

C

cable interconnect messages, 74

Change write policy, 113

- Chassis intrusion detected, 33, 61
 - Chassis intrusion in progress, 33, 61
 - chassis intrusion messages, 31
 - Chassis intrusion returned to normal, 32
 - chassis intrusion sensor, 9
 - Chassis intrusion sensor detected a non-recoverable value, 33, 61
 - Chassis intrusion sensor has failed, 32
 - Chassis intrusion sensor value unknown, 32, 60
 - Chassis Management Controller Messages, 34
 - Communication regained, 132
 - Communication timeout, 123
 - Communication with the enclosure has been lost., 182
 - Controller alarm disabled, 126
 - Controller alarm enabled, 126
 - Controller alarm has been tested, 130
 - Controller battery is reconditioning, 104
 - Controller battery low, 127
 - Controller battery recondition is completed, 104
 - Controller configuration has been reset, 131
 - Controller event log %1, 200-202
 - Controller log file entry %1, 171
 - Controller rebuild rate has changed, 126
 - cooling device messages, 23
 - current sensor, 9
 - Current sensor detected a failure value, 30
 - Current sensor detected a non-recoverable value, 31
 - Current sensor detected a warning value, 30
 - Current sensor has failed, 28, 59
 - current sensor messages, 28
 - Current sensor returned to a normal value, 29, 59
 - Current sensor value unknown, 29
- D**
- Dead disk segments restored, 125
 - Dedicated hot spare assigned. Physical disk %1, 147
 - Dedicated hot spare unassigned. Physical disk %1, 147

Dedicated spare imported as global due to missing arrays, 212
Device failed, 83
Device returned to normal, 114
Diagnostic message %1, 192
Drive Events, 65
Driver version mismatch, 122
drives messages, 65

E

Enclosure alarm disabled, 125
Enclosure alarm enabled, 124
Enclosure firmware mismatch, 114
Enclosure was shut down, 111
entity presence messages, 75
Error occurred
 %1, 206
event description reference, 13

F

Failure prediction threshold exceeded due to test, 110
Fan enclosure inserted into system, 41
fan enclosure messages, 41

Fan enclosure removed from system, 41
Fan enclosure removed from system for an extended amount of time, 42
fan enclosure sensor, 9
Fan enclosure sensor detected a non-recoverable value, 42
Fan enclosure sensor has failed, 41
Fan enclosure sensor value unknown, 41
fan sensor, 9
Fan sensor detected a failure value, 24
Fan sensor detected a non-recoverable value, 24
Fan sensor detected a warning value, 24
Fan Sensor Events, 57
Fan sensor has failed, 23, 56
fan sensor messages, 57
Fan sensor returned to a normal value, 23
Fan sensor value unknown, 23, 56
Firmware version mismatch, 121

G

Global hot spare assigned, 101

Global hot spare unassigned, 102

H

hardware log sensor, 9

Hardware Log Sensor Events, 64

hardware log sensor messages, 64

Hot spare SMART polling
failed., 179

I

Intrusion Events, 66

intrusion messages, 66

L

Log backup created, 17

Log monitoring has been
disabled, 45, 66

Log size is near or at capacity, 45

Log size returned to a normal
level, 45

Log status is unknown, 45, 66

Log was cleared, 17

M

Maximum temperature probe
warning threshold value
changed, 130

Memory device ECC Correctable
error count crossed a warning
threshold, 40

Memory device ECC Correctable
error count sensor crossed a
failure threshold, 40

memory device messages, 40

Memory device monitoring has
been disabled, 40

Memory ECC Events, 62

memory ecc messages, 62

Memory Events, 63

memory modules messages, 63

memory prefailure sensor, 9

messages

AC power cord, 43, 65

battery, 74

battery sensor, 51

bios generated system, 67

BMC watchdog, 62

cable interconnect, 74

chassis intrusion, 31

cooling device, 23

current sensor, 28

drives, 65

entity presence, 75

fan enclosure, 41

fan sensor, 57

hardware log sensor, 64

intrusion, 66

memory device, 40

memory ecc, 62

memory modules, 63

- miscellaneous, 17
- pluggable device, 49, 67
- power supply, 36, 60
- processor sensor, 46
- processor status, 59
- r2 generated system, 72
- redundancy unit, 34
- storage management, 83
- temperature sensor, 20, 55
- voltage sensor, 25, 56

Minimum temperature probe
warning threshold value
changed, 130

Multi-bit ECC error., 181

Multiple enclosures are attached
to the controller. This is an
unsupported
configuration., 145

P

Patrol Read found an
uncorrectable media
error., 174

Physical disk dead segments
recovered, 125

Physical disk degraded, 85

Physical disk initialization
started, 90

Physical disk initialize
completed, 98

Physical disk initialize failed, 95

Physical disk inserted, 85

Physical disk offline, 85

Physical disk online, 131

Physical disk rebuild
cancelled, 93

Physical disk rebuild
completed, 99

Physical disk rebuild failed, 97

Physical disk rebuild started, 91

Physical disk removed, 84

Physical disk(s) have been
removed from a virtual disk.
The virtual disk will be in
Failed state during the next
system reboot., 212

Physical disk(s) that are part of a
virtual disk have been
removed while the system
was shut down. This removal
was discovered during
system start-up., 211

pluggable device sensor, 10

Power And Performance
Events, 75

Power supply detected a
failure, 39

Power supply detected a
warning, 38, 63

Power Supply Events, 60

power supply messages, 36, 60

Power supply returned to
normal, 38, 63

power supply sensor, 9

Power supply sensor detected a non-recoverable value, 39

Power supply sensor has failed, 37

Power supply sensor value unknown, 37

Predictive Failure reported, 100

Problems with the battery or the battery charger have been detected. The battery health is poor., 193

processor sensor, 10

Processor sensor detected a failure value, 48, 67

Processor sensor detected a non-recoverable value, 48

Processor sensor detected a warning value, 47, 67

Processor sensor has failed, 46, 67

Processor sensor returned to a normal state, 47, 67

Processor sensor value unknown, 46, 67

Processor Status Events, 59

processor status messages, 59

R

r2 generated system messages, 72

Rebuild completed with errors, 133

Rebuild not possible as SAS/SATA is not supported in the same virtual disk., 213

Recharge count maximum exceeded, 154

Redundancy degraded, 36, 115

Redundancy is offline, 35

Redundancy lost, 36, 116

Redundancy normal, 118

Redundancy not applicable, 35, 62

Redundancy regained, 35

Redundancy sensor has failed, 34

Redundancy sensor value unknown, 34, 62

redundancy unit messages, 34

redundancy unit sensor, 9

S

SAS expander error %1, 210

SAS port report %1, 198-199

SAS SMP communications error %1., 209

SCSI sense data, 101

SCSI sense sector reassign, 119

See the Readme file for a list of validated controller driver versions, 133

sensor

- AC power cord, 9
- chassis intrusion, 9
- current, 9
- fan, 9
- fan enclosure, 9
- hardware log, 9
- memory prefailure, 9
- power supply, 9
- processor, 10, 46
- redundancy unit, 9
- temperature, 9
- voltage, 9

Server Administrator starting, 17

Server Administrator startup complete, 17

Service tag changed, 129

Single-bit ECC error limit exceeded., 143

Single-bit ECC error., 182

Single-bit ECC error. The DIMM is critically degraded., 194

Single-bit ECC error. The DIMM is critically degraded. There will be no further reporting., 194

Single-bit ECC error. The DIMM is degrading., 193

Smart configuration change, 106

Smart FPT exceeded, 105

SMART thermal shutdown is disabled., 170

SMART thermal shutdown is enabled., 169

Smart warning, 107

Smart warning degraded, 110

Smart warning temperature, 108

SMBIOS data is absent, 18

System Event Log Messages, 55

system management data manager started, 19

system management data manager stopped, 19

T

Temperature dropped below the minimum failure threshold, 104

Temperature dropped below the minimum warning threshold, 103

Temperature exceeded the maximum failure threshold, 103

Temperature exceeded the maximum warning threshold, 102

temperature sensor, 9

Temperature sensor detected a failure value, 22

- Temperature sensor detected a non-recoverable value, 22
- Temperature sensor detected a warning value, 21
- Temperature Sensor Events, 55
- Temperature sensor has failed, 20, 55
- temperature sensor messages, 20, 55
- Temperature sensor returned to a normal value, 21, 56
- Temperature sensor value unknown, 20, 55
- The AC power supply cable has been removed., 196
- The background initialization (BGI) rate has changed., 160
- The battery charge cycle is complete., 210
- The BGI completed with uncorrectable errors., 204
- The Check Consistency found inconsistent parity data. Data redundancy may be lost., 205
- The Check Consistency logging of inconsistent parity data is disabled., 205
- The Check Consistency made corrections and completed., 204
- The Check Consistency rate has changed., 161
- The Clear operation has cancelled., 167
- The controller alarm is silenced., 160
- The controller battery charge level is below a normal threshold., 177
- The controller battery charge level is normal., 136
- The controller battery charge level is operating within normal limits., 177
- The controller battery has been removed., 138
- The controller battery has been replaced., 139
- The controller battery is charging., 165
- The controller battery is degraded., 165
- The controller battery is executing a Learn cycle., 165
- The controller battery Learn cycle has been postponed., 140
- The controller battery Learn cycle has completed., 139
- The controller battery Learn cycle has started., 139
- The controller battery Learn cycle has timed out., 140

- The controller battery Learn cycle will start in % days., 141
- The controller battery needs to be replaced., 136
- The controller battery temperature is above normal., 137
- The controller battery temperature is above normal., 153
- The controller battery temperature is normal., 137
- The controller cache has been discarded., 143
- The controller debug log file has been exported., 162
- The controller has recovered cached data from the BBU., 203
- The controller is unable to recover cached data from the battery backup unit (BBU)., 202
- The controller reconstruct rate has changed., 172
- The controller write policy has been changed to Write Back., 144
- The controller write policy has been changed to Write Through., 144
- The current kernel version and the non-RAID SCSI driver version are older than the minimum required levels. See the Readme file for a list of validated kernel and driver versions., 135
- The DC power supply is switched off., 195
- The dedicated hot spare is too small., 176
- The EMM has failed., 183
- The enclosure cannot support both SAS and SATA physical disks. Physical disks may be disabled., 186
- The enclosure has a hardware error., 186
- The enclosure is not responding., 186
- The enclosure is unstable., 185
- The enclosure temperature has returned to normal., 208
- The factory default settings have been restored., 203
- The firmware on the EMMs is not the same version. EMM0 %1 EMM1 %2, 190
- The global hot spare is too small., 176

- The initialization sequence of SAS components failed during system startup. SAS management and monitoring is not possible., 191
- The non-RAID SCSI driver version is older than the minimum required level. See the Readme file for the validated driver version., 135
- The NVRAM has corrupt data., 198
- The NVRAM has corrupted data. The controller is reinitializing the NVRAM., 197
- The only hot spare available is a SAS disk. SAS disks cannot replace SATA disks., 152
- The only hot spare available is a SATA disk. SATA disks cannot replace SAS disks., 152
- The Patrol Read corrected a media error., 174
- The patrol read has resumed., 180
- The Patrol Read has started., 163
- The Patrol Read has stopped., 164
- The Patrol Read is paused., 180
- The Patrol Read mode has changed., 163
- The Patrol Read rate has changed., 161
- The physical disk blink has ceased., 167
- The physical disk blink has initiated., 166
- The physical disk Clear operation failed., 173
- The physical disk Clear operation has completed., 173
- The physical disk Clear operation has started., 166
- The physical disk has been started., 168
- The physical disk is not certified., 211
- The physical disk is not supported., 153
- The physical disk is too small to be used for a rebuild., 187
- The physical disk rebuild has resumed., 175
- The power supply cable has been inserted., 196
- The power supply is switched on., 195
- The RAID controller firmware and driver validation was not performed. The configuration file cannot be opened., 134

The RAID controller firmware and driver validation was not performed. The configuration file is out of date or corrupted., 134

The rebuild failed due to errors on the source physical disk., 206

The rebuild failed due to errors on the target physical disk., 207

The SCSI Enclosure Processor (SEP) has been rebooted as part of the firmware download operation and will be unavailable until the operation completes., 213

The virtual disk cache policy has changed., 148

The virtual disk Check Consistency has made corrections and completed., 146

The virtual disk Read policy has changed., 147

The virtual disk reconfiguration has resumed., 146

There is a bad sensor on an enclosure., 184

There was an unrecoverable disk media error during the rebuild., 207

Thermal shutdown protection has been initiated, 18

U

understanding
event description, 13

Unsupported configuration detected. The SCSI rate of the enclosure management modules (EMMs) is not the same. EMM0 %1 EMM1 %2, 138

User initiated host system reset, 18

V

viewing
event information, 13
event messages, 10
events in Red Hat Linux, 12
events in SUSE Linux Enterprise Server, 12
events in Windows 2000, 11

Virtual disk check consistency cancelled, 92

Virtual disk check consistency completed, 97

Virtual disk check consistency failed, 94

Virtual disk check consistency started, 89

Virtual disk configuration changed, 86

Virtual disk created, 86

Virtual disk degraded, 88

- Virtual disk deleted, 86
- Virtual disk failed, 87
- Virtual disk format changed, 95
- Virtual disk format completed, 97
- Virtual disk format started, 89
- Virtual disk has inconsistent data., 178
- Virtual disk initialization, 123
- Virtual disk initialization cancelled, 93
- Virtual disk initialization completed, 98
- Virtual disk initialization failed, 95
- Virtual disk initialization started, 90
- Virtual disk rebuild completed, 99
- Virtual disk rebuild failed, 96
- Virtual disk rebuild started, 91
- Virtual disk reconfiguration completed, 99
- Virtual disk reconfiguration failed, 96
- Virtual disk reconfiguration started, 91
- Virtual Disk Redundancy has been degraded., 214
- Virtual disk renamed, 132
- voltage sensor, 9
 - Voltage sensor detected a failure value, 27, 58
 - Voltage sensor detected a non-recoverable value, 27
 - Voltage sensor detected a warning value, 26
 - Voltage Sensor Events, 56
 - Voltage sensor has failed, 25, 57
 - voltage sensor messages, 25, 56
 - Voltage sensor returned to a normal value, 26
 - Voltage sensor value unknown, 25, 57

