

Dell OpenManage
Server Administrator
Version 6.3

CIM Reference Guide



Notes



NOTE: A NOTE indicates important information that helps you make better use of your computer.

**Information in this publication is subject to change without notice.
© 2010 Dell Inc. All rights reserved.**

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: Dell™, the DELL logo, and OpenManage™ are trademarks of Dell Inc.; Microsoft® and Windows NT® are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries; Intel®, Pentium®, Xeon®, Itanium®, i860®, i960®, and Celeron® are registered trademarks and MMX™, i386™, i486™, SpeedStep™, and Core™ are trademarks of Intel Corporation in the United States and/or other countries; AMD™, AMD Athlon™, AMD Duron™, AMD-K5™, AMD-K6™, Opteron™, Sempron™, Phenom™ and Turion™ are trademarks and AMD-K6-2® and AMD-K6-III® are registered trademarks of Advanced Micro Devices, Inc. in the United States and/or other countries; Crusoe™ and Efficeon™ are trademarks of Transmeta Corporation in the United States and/or other countries.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

July 2010

Contents

1	Introduction	9
	Server Administrator	9
	What's New in this Release	9
	Documenting CIM Classes and Their Properties	10
	Base Classes	11
	Parent Classes	12
	Classes That Describe Relationships	12
	Dell-Defined Classes	12
	Common Properties of Classes	12
	Other Documents You May Need	15
	Typographical Conventions	16
2	CIM_PhysicalElement	17
	CIM_PhysicalElement	17
	CIM_PhysicalPackage	19
	CIM_PhysicalFrame	20
	CIM_Chassis	21
	DELL_Chassis	22
	CIM_PhysicalComponent	24

	CIM_Chip	24
	CIM_PhysicalMemory	26
	CIM_PhysicalConnector	28
	CIM_Slot	31
3	CIM_LogicalElement	35
	CIM_LogicalElement	36
	CIM_System	37
	CIM_ComputerSystem	38
	DELL_System	38
	CIM_LogicalDevice	39
	CIM_FRU	40
	CIM_LogicalPort	41
	CIM_NetworkPort	42
	DELL_ManagedSystemServicesDevice	43
	DELL_NetworkPort	44
	CIM_Sensor	47
	CIM_DiscreteSensor	49
	CIM_NumericSensor	49
	CIM_TemperatureSensor	52
	CIM_CurrentSensor	53
	CIM_VoltageSensor	54

CIM_Tachometer	55
CIM_WatchDog	56
CIM_CoolingDevice	57
CIM_Fan	58
CIM_UserDevice	59
CIM_PointingDevice	59
CIM_Keyboard	61
CIM_PowerSupply	62
CIM_Controller	64
CIM_ParallelController	65
CIM_SerialController	66
CIM_PCIBridge	67
CIM_PCIDevice	68
CIM_PCIBridge	69
CIM_Processor	70
CIM_StorageExtent	80
CIM_Memory	81
CIM_CacheMemory	81
CIM_SoftwareElement	83
CIM_BIOSElement	86
CIM_SoftwareFeature	87

DELL_SoftwareFeature	88
CIM_SystemResource	88
CIM_IRQ	89
CIM_MemoryMappedIO	91
CIM_DMA	92
CIM_RedundancyGroup	93
CIM_ExtraCapacityGroup	94
DELL_PSRedundancyGroup	95
DELL_FanRedundancyGroup	96
CIM_EnabledLogicalElement Group	96
CIM_ServiceAccessPoint	97
CIM_RemoteServiceAccessPoint	97
DELL_RemoteServiceAccessPort	99
DCIM_OEM_DataAccessModule	100
DCIM_RegisteredProfile	101
4 Dell-Defined Classes	103
DELL_EsmLog	103
DELL_PostLog	104
DELL_CMAApplication	104
DELL_CMDevice	105
DELL_CMDeviceApplication	106

	DELL_CMInventory	107
	DELL_CMOS	107
	DELL_CMPProductInfo	108
	DELL_BIOSExtensions	109
	Management Object File For Change Management	110
	Classes for Power Management	115
5	CIM_Dependency	135
	DELL_FanSensor	136
	CIM_PackageTempSensor	136
	CIM_PackageVoltSensor	137
	CIM_PackageCurrentSensor	138
	CIM_PackageFanSensor	138
	CIM_PackagePowerSupplySensor	139
	DELL_PackagePSRedundancy	140
	DELL_PSRRedundancy	140
	Index	143

Introduction

This reference guide documents the Dell OpenManage Server Administrator Common Information Model (CIM) provider contained in the Management Object File (MOF) `dccim32.mof`.

CIM provides a conceptual model for describing manageable objects in a systems management environment. CIM is a modeling tool rather than a programming language. CIM provides the structure for organizing objects into a model of a managed environment. For modeling a managed environment, CIM makes available a set of abstract and concrete classes of objects. These classes model the basic characteristics of systems, networks, and applications, as well as groupings of management-related data.

For more information about CIM, see the Distributed Management Task Force (DMTF) website at www.dmtf.org and the Microsoft website at www.microsoft.com.

Server Administrator

Server Administrator provides a suite of systems management information for keeping track of your networked systems. In addition to providing systems management agents that are independent of the management console, Server Administrator supports these systems management standards: CIM and Simple Network Management Protocol (SNMP).

In addition to supporting systems management industry standards, Server Administrator provides additional systems management information about the specific components of your Dell system.

What's New in this Release

These are the additions to this guide:

- Added new properties to `Dell_SDCardDevice`
- Added new processor families enumeration values

Documenting CIM Classes and Their Properties

The Dell CIM provider extends support to Dell-specific software and hardware components. The Dell MOF defines the classes for the Dell CIM provider. All of the supported classes and properties in the MOF are documented in this guide.

The following subsections define some of the basic building blocks of CIM classes that are used in describing the dccim32 provider name. These subsections also explain how the elements used in describing these classes are organized. This section does not document the entire CIM schema, but only those classes and properties supported by the dccim32 provider. The list of properties for each supported class varies greatly.

The property values being presented could be NULL or empty string on some systems, although in general, some non-empty values can be expected. Key properties (listed below) will always carry non-empty values. It is recommended that you use only the following properties as key attributes:

- `CIM_PhysicalElement`: CreationClassName, Tag
- `CIM_System`: CreationClassName, Name
- `CIM_LogicalDevice`: SystemCreationClassName, SystemName, CreationClassName, DeviceID
- `CIM_Dependency`: Antecedent, Dependent
- `CIM_SoftwareElement`: Name, Version, SoftwareElementState, SoftwareElementID, TargetOperatingSystem
- `CIM_SoftwareFeature`: IdentifyingNumber, ProductName, Vendor, Version, Name
- `CIM_IRQ`: CSCreationClassName, CSName, CreationClassName, IRQNumber
- `CIM_MemoryMappedIO`: CSCreationClassName, CSName, CreationClassName, StartingAddress
- `CIM_DMA`: CSCreationClassName, CSName, CreationClassName, DMAChannel
- `CIM_RedundancyGroup`: CreationClassName, Name
- `DELL_EsmLog`: RecordNumber
- `DELL_PostLog`: RecordNumber

- `DELL_BIOSExtensions`: `systemBIOSCharacteristics`
- `DELL_BIOSSettings`: `DisplayName`
- `CIM_ServiceAccessPoint`: `SystemCreationClassName`, `SystemName`, `CreationClassName`, `Name`

Base Classes

The classes listed in the Server Administrator CIM provider class hierarchy do not have a parent property. These base classes do not derive from another class. The base classes are:

- `CIM_ManagedSystemElement`
- `CIM_Dependency`
- `DELL_EsmLog`
- `DELL_PostLog`
- `DELL_CMApplication`
- `DELL_CMDevice`
- `DELL_CMDeviceApplications`
- `DELL_CMInventory`
- `DELL_CMOS`
- `DELL_CMProductInfo`

The `CIM_ManagedSystemElement` class is the base class for the system element hierarchy from which all other CIM classes are derived. As a result, `CIM_ManagedSystemElement` has no parent. Examples of managed system elements include software components such as files, devices such as hard drives and controllers, and physical subcomponents of devices such as chip sets and cards. For the `CIM_ManagedSystemElement` properties, see **Caption**, **CreationClassName**, **Description**, **Name**, and **Status** in Table 1-1

The Dell-defined classes are not defined in the official schema by the DMTF, the industry group that defines the standards for CIM, and hence do not have parent classes. `CIM_Dependency` does not have a parent class because it is a relationship or association between two managed system elements.

Parent Classes

Most classes in the dccim32 provider document both a **Class Name** and a **Parent Class** property. The parent class is the class from which any given class inherits its core properties. For example, the `CIM_Controller` class has the `CIM_LogicalDevice` class as its parent, and has various types of controllers (`CIM_ParallelController`, `CIM_SerialController`) as its children.


Classes That Describe Relationships

Classes that derive from `CIM_Dependency` have `CIM_Dependency` as their parent class, but they are documented in terms of *antecedent* and *dependent* elements in a relationship rather than in terms of common properties. Consider the following relationship between two `CIM_ManagedSystemElements`:

Antecedent	<code>CIM_PackageCurrentSensor</code>
Dependent	<code>CIM_PhysicalPackage</code>

The `CIM_PackageCurrentSensor` class monitors an entire physical package, such as all the components contained in a given system chassis. The `CIM_PhysicalPackage` class is dependent on the `CIM_PackageCurrentSensor` class for this monitoring function.

Dell-Defined Classes

Server Administrator has extended some CIM classes and has created new classes to assist in managing systems and their components. In the diagrams that appear in the documentation for each class, those classes created and populated by Dell are designated by the gold (lighter gray) triangle  icon.

Common Properties of Classes

Many classes have properties such as **Caption**, **Description**, and **CreationClassName**. Table 1-1 defines properties that have the same meaning in every class that has this property and are defined more than once in this guide.

Table 1-1. Common Properties of Classes

Property	Description	Data Type
Caption	Describes the object using a short textual description (one-line string).	string
CreationClassName	Indicates the name of the class or the subclass used in the creation of an instance. When used with the other key properties of this class, this property allows all instances of this class and its subclasses to be uniquely identified.	string
CSCreationClassName	Indicates the computer system's creation class name.	string
CSName	Indicates the computer system's name.	string
CurrentReading	Indicates the actual current value indicated by the sensor in amperes.	sint32
Description	Provides a textual description of the object.	string
LowerThresholdNonCritical	If current reading is between lower threshold noncritical and upper threshold noncritical, the current state is normal. See Figure 3-2.	sint32
LowerThresholdCritical	If the current reading is between upper threshold critical and upper threshold fatal, the current state is critical. See Figure 3-2.	sint32
IsLinear	Indicates that the sensor is linear over its dynamic range.	Boolean
Manufacturer	Provides the name of the organization responsible for producing the CIM_PhysicalElement or CIM_SoftwareElement. This may be the entity from whom the element is purchased, but not necessarily. Purchase information is contained in the Vendor property of CIM_Product.	string

Table 1-1. Common Properties of Classes (continued)

Property	Description	Data Type
Name	Defines the label by which the object is known. When subclassed, the Name property can be overridden to be a Key property.	string
Status	<p>Provides a string indicating the status of the component. Status values include:</p> <p>Operational Status Values:</p> <p>OK indicates that the object is functioning normally.</p> <p>Degraded means that the item is functioning, but not optimally.</p> <p>Stressed indicates that the element is functioning, but needs attention. Examples of Stressed states are overloaded, overheated, and so on.</p> <p>Nonoperational Status Values:</p> <p>Non-recover means that a nonrecoverable error has occurred.</p> <p>Error means that an element has encountered an operational condition that is severe as compared to its normal mode of operation.</p>	string
SystemCreationClassName	Indicates the system's creation class name.	string
UnitModifier	Provides the unit multiplier for the values returned by this sensor. All the values returned by this sensor are represented in units of 10 raised to the power of the unit modifier. If the unit modifier is -6, then the units of the values returned are microvolts. The units apply to all numeric properties of the sensor, unless explicitly overridden by the units' qualifier.	sint32
UpperThresholdCritical	If the current reading is between upper threshold critical and upper threshold fatal, the current status is critical. See Figure 3-2.	sint32

Table 1-1. Common Properties of Classes (continued)

Property	Description	Data Type
UpperThresholdNonCritical	If the current reading is between lower threshold noncritical and lower threshold critical, the current status is noncritical. See Figure 3-2.	sint32
Version	Version should be in the form <major>.<minor>.<revision> or <major>.<minor><letter><revision>; for example, 1.2.3 or 1.2a3.	string

Other Documents You May Need

Besides this *Dell OpenManage Server Administrator CIM Reference Guide*, you can find the following documents on the Dell Support website at support.dell.com/manuals:

- *Dell OpenManage Server Administrator User's Guide* documents the features, installation, and uninstallation of Server Administrator.
- *Dell OpenManage Server Administrator Installation Guide* contains instructions to help you install Dell OpenManage Server Administrator.
- *Dell OpenManage Management Station Software Installation Guide* contains instructions to help you install Dell OpenManage management station software that includes Baseboard Management Utility, DRAC Tools, and Active Directory Snap-In.
- *Dell OpenManage Server Administrator Command Line Interface User's Guide* explains how to perform tasks using the text-based command line interface.
- *Dell OpenManage Server Administrator Messages Reference Guide* lists the messages that you can receive on your systems management console or on your operating system's event viewer. This guide explains the text, severity, and cause of each message that the Server Administrator issues.
- *Dell OpenManage Server Administrator SNMP Reference Guide* documents the SNMP management information base (MIB). The SNMP MIB defines variables that cover the capabilities of Server Administrator systems management agents.
- The *Glossary* for information on terms used in this document.

Typographical Conventions

The following example shows how most of the classes in the Dell CIM provider are documented. Table 1-2 shows a partial class description for the `DELL_DMA` class. (For a full class description, see Table 3-42)

Class Name appears in `Courier` typeface and provides the string that names the class in the MOF.

Parent Class appears in `Courier` typeface and provides the name of the class from which the present class is derived.

Property denotes the name of the attribute that is being defined for this class.

Description includes text that defines the property.

Data Type stipulates the format that the values of this property must take. Common data types include Boolean, string, and various types of integer. Boolean indicates that the property must be expressed as one of two alternatives.


Table 1-2. CIM_DMA Properties

Class Name:	<code>CIM_DMA</code>	
Parent Class:	<code>CIM_SystemResource</code>	
Property	Description	Data Type
DMACHannel	A part of the object's key value, the DMA channel number.	uint32
Availability	Availability of the DMA. Availability values are defined as follows: 1 - Other 2 - Unknown 3 - Available 4 - In Use/Not Available 5 - In Use and Available/Shareable	uint16


CIM_PhysicalElement

CIM_PhysicalElement is a CIM-defined class. The CIM_PhysicalElement class contains the subclasses shown in Figure 2-1.

Figure 2-1. CIM_PhysicalElement Class Structure



CIM_PhysicalElement




Subclasses of the CIM_PhysicalElement class listed in Table 2-1 define any component of a system that has a distinct physical identity. Physical elements are tangible managed system elements (usually actual hardware items) that have a physical manifestation of some sort. By contrast, processes, files, and logical devices are not classified as physical elements. A managed system element is not necessarily a discrete component. A single card (which is a type of physical element) can host more than one logical device.

One card, for example, could implement both a modem and a local area network (LAN) adapter. In this case, the card would be represented by a single physical element associated with multiple logical devices.

Table 2-1. CIM_PhysicalElement Properties

Class Name:	CIM_PhysicalElement	
Parent Class:	CIM_ManagedSystemElement	
Property	Description	Data Type
CreationClassName	See Table 1-1.	
Manufacturer	See Table 1-1.	
Model	The name by which the physical element is generally known.	string
SerialNumber	A manufacturer-allocated number used to identify the physical element.	string
Tag	Uniquely identifies the physical element and serves as the element's key. The Tag property can contain information such as asset tag or serial number data. The key for physical element is placed very high in the object hierarchy in order to identify the hardware/entity independently, regardless of physical placement in or on cabinets, adapters, and so on. For example, a hot-swappable or removable component can be taken from its containing (scoping) package and temporarily unused. The object still continues to exist and may even be inserted into a different scoping container. Therefore, the key for physical element is an arbitrary string that is defined independently of any placement or location-oriented hierarchy.	string

CIM_PhysicalPackage




The `CIM_PhysicalPackage` class listed in Table 2-2 represents physical elements that contain or host other components. Examples are a rack enclosure or an adapter card with multiple functions.

Table 2-2. CIM_PhysicalPackage Properties

Class Name:	CIM_PhysicalPackage	
Parent Class:	CIM_PhysicalElement	
Property	Description	Data Type
Removable	A <code>CIM_PhysicalPackage</code> is removable if it is designed to be taken in and out of the physical container in which it is normally found without impairing the function of the overall package.	Boolean
Replaceable	A <code>CIM_PhysicalPackage</code> is replaceable if it is possible to substitute a physically different element for the original element, as in a field replaceable unit (FRU). For example, some computer systems allow the microprocessor to be upgraded to one of a higher clock rating. In this case, the microprocessor is said to be replaceable.	Boolean

CIM_PhysicalFrame




The `CIM_PhysicalFrame` class described in Table 2-3 contains other frame enclosures such as racks and chassis. Properties like **VisibleAlarm** or **AudibleAlarm**, and data related to security breaches are also members of this class.

Table 2-3. CIM_Physical Frame Properties

Class Name:	<code>CIM_PhysicalFrame</code>	
Parent Class:	<code>CIM_PhysicalPackage</code>	
Property	Description	Data Type
<code>LockPresent</code>	Indicates whether the frame is protected with a lock.	Boolean
<code>AudibleAlarm</code>	Indicates whether the frame is equipped with an audible alarm.	Boolean
<code>VisibleAlarm</code>	Indicates that the equipment includes a visible alarm.	Boolean
<code>SecurityBreach</code>	An enumerated, integer-valued property indicating that a physical breach of the frame is in progress. Values for the SecurityBreach property are: 1 - Other 2 - Unknown 3 - No breach 4 - Breach attempted 5 - Breach successful	uint16
<code>IsLocked</code>	Indicates that the frame is currently locked.	Boolean

CIM_Chassis




The `CIM_Chassis` class described in Table 2-4 represents the physical elements that enclose physical elements such as power supplies, fans, and processors.

Table 2-4. CIM_Chassis Parent Properties

Class Name:	<code>CIM_Chassis</code>	
Parent Class:	<code>CIM_PhysicalFrame</code>	
Property	Description	Data Type
<code>ChassisTypes</code>	Values for the <code>ChassisTypes</code> property are: 1 - Other 2 - Unknown 3 - Mini-tower 4 - Tower 5 - Space-saving 6 - Main system chassis 7 - Expansion chassis 8 - Subchassis 9 - Space-saving 10 - Main system chassis 11 - Expansion chassis 12 - Subchassis 13 - Bus expansion chassis 14 - Peripheral chassis 15 - Storage chassis 16 - Rack-mount chassis	<code>uint16</code>

DELL_Chassis



The `DELL_Chassis` class explained in Table 2-5 defines the identifying and status properties of the chassis. `DELL_Chassis` inherits from CIM-defined classes, but is populated by Dell properties.


Table 2-5. DELL_Chassis Properties

Class Name:	<code>DELL_Chassis</code>	
Parent Class:	<code>CIM_Chassis</code>	
Property	Description	Data Type
<code>AssetTag</code>	Indicates the container <code>AssetTag</code> string. This asset tag string is writable by the system administrator.	string
<code>SystemClass</code>	Refers to the system type that is installed and running the instrumentation. Values for the <code>SystemClass</code> property are: 1 - Other 2 - Unknown 3 - Workstation 4 - Server 5 - Desktop 6 - Portable 7 - Net PC	uint16
<code>SystemID</code>	Indicates the system identifier code.	uint16

Table 2-5. DELL_Chassis Properties (continued)

Class Name:	DELL_Chassis	
Parent Class:	CIM_Chassis	
Property	Description	Data Type
LogFormat	Defines whether the event log data is unicode formatted or binary (raw). Values for the event LogFormat property are: 1 - Formatted (event log only) 2 - Unformatted 3 - Events_and_POST_Formatted (both the event log and the power-on self-test (POST) log are unicode for matted)	uint16
FanStatus	Indicates the global status of fan sensors.	string
TempStatus	Indicates the global status of temperature sensors.	string
VoltStatus	Indicates the global status of voltage sensors.	string
AmpStatus	Indicates the global status of current sensors.	string
PsStatus	Indicates the global status of power supplies.	string
MemStatus	Indicates the global status of memory devices.	string
ProcStatus	Indicates the global status of processor devices.	string
FanRedStatus	Indicates the global status of the cooling unit.	string
PsRedStatus	Indicates the global status of the power unit.	string
IsDefaultThrSupported	Indicates whether resetting default thresholds are supported.	Boolean
ChassisSystemProperties	Indicates chassis characteristics, such as energy smart etc.	uint16
ChassisSystemRevision	Indicates the chassis revision.	uint16
EsmLogStatus	Indicates the global status of ESM log.	string
MemoryRedStatus	Indicates the global status of memory redundancy.	string

CIM_PhysicalComponent




The `CIM_PhysicalComponent` class listed in Table 2-6 represents any low-level or basic component within a package. A component object either cannot or does not need to be broken down into its constituent parts. For example, an application specific integrated circuit (ASIC) cannot be broken down into smaller discrete parts.

Table 2-6. CIM_PhysicalComponent Properties

Class Name:	<code>CIM_PhysicalComponent</code>
Parent Class:	<code>CIM_PhysicalElement</code>

CIM_Chip




The `CIM_Chip` class listed in Table 2-7 represents any type of integrated circuit hardware, including ASICs, processors, memory chips, and so on.

Table 2-7. CIM_Chip Properties

Class Name:	CIM_Chip	
Parent Class:	CIM_PhysicalComponent	
Property	Description	Data Type
FormFactor	0 - Unknown 1 - Other 2 - SIP 3 - DIP 4 - ZIP 5 - SOJ 6 - Proprietary 7 - SIMM 8 - DIMM 9 - TSOP 10 - PGA 11 - RIMM 12 - SODIMM 13 - SRIMM 14 - SMD 15 - SSMP 16 - QFP 17 - TQFP 18 - SOIC 19 - LCC 20 - PLCC 21 - BGA 22 - FPBGA 23 - LGA 24 - FB-DIMM	uint16

CIM_PhysicalMemory



The `CIM_PhysicalMemory` class described in Table 2-8 is a subclass of `CIM_Chip`, representing low-level memory devices, such as SIMMS, DIMMs, and so on.

Table 2-8. CIM_PhysicalMemory Properties

Class Name:	<code>CIM_PhysicalMemory</code>	
Parent Class:	<code>CIM_Chip</code>	
Property	Description	Data Type
FormFactor	See Table 2-7.	uint16
MemoryType	Indicates the type of physical memory. Values for the <code>MemoryType</code> property are: 0 - Unknown 1 - Other 2 - DRAM 3 - Synchronous DRAM 4 - Cache DRAM 5 - EDO 6 - EDRAM 7 - VRAM 8 - SRAM 9 - RAM 10 - ROM	uint16


Table 2-8. CIM_PhysicalMemory Properties (continued)

Class Name:	CIM_PhysicalMemory	
Parent Class:	CIM_Chip	
Property	Description	Data Type
MemoryType (continued)	11 - Flash 12 - EEPROM 13 - FEPRM 14 - EPROM 15 - CDRAM 16 - 3DRAM 17 - SDRAM 18 - SGRAM 19 - RDRAM 20 - DDR 21 - DDR2 22 - DDR2 FB-DIMM 24 - DDR3 25 - FBD2	
TotalWidth	Indicates the total width, in bits, of the physical memory, including check or error correction bits. If there are no error correction bits, the value in this property should match that specified for the DataWidth property.	uint16
DataWidth	Indicates the data width, in bits, of the physical memory. A data width of 0 and a total width of 8 would indicate that the memory is solely used to provide error correction bits.	uint16
Speed	Indicates the speed of the physical memory, in nanoseconds.	uint32
SpeedAsString	Indicates the accurate speed of the physical memory, in string format (with units).	string
Capacity	Indicates the total capacity of this physical memory, in bytes.	uint64

Table 2-8. CIM_PhysicalMemory Properties (continued)

Class Name:	CIM_PhysicalMemory	
Parent Class:	CIM_Chip	
Property	Description	Data Type
BankLabel	A string identifying the physically labeled bank where the memory is located, for example, "Bank 0" or "Bank A."	string
PositionInRow	Specifies the position of the physical memory in a "row." For example, if it takes two 8-bit memory devices to form a 16-bit row, then a value of 2 means that this memory is the second device. 0 is an invalid value for this property.	uint32
InterleavePosition	Indicates the position of this physical memory in an interleave. 0 indicates noninterleaved. 1 indicates the first position, 2 the second position, and so on. For example, in a 2:1 interleave, a value of 1 indicates that the memory is in the "even" position.	uint32

CIM_PhysicalConnector



The `CIM_PhysicalConnector` class explained in Table 2-9 includes physical elements such as plugs, jacks, or buses that connect physical elements. Any object that can be used to connect and transmit signals or power between two or more physical elements is a member of this class. For example, slots and D-shell connectors are types of physical connectors. See Table 2-10 for a list of valid connector type values.

Table 2-9. CIM_PhysicalConnector Properties

Class Name:	CIM_PhysicalConnector	
Parent Class:	CIM_PhysicalElement	
Property	Description	Data Type
ConnectorPinout	A free-form string describing the pin configuration and signal usage of a physical connector.	string
ConnectorType	An array of integers defining the type of physical connector. An array is specified to allow the description of “combinations” of connector information. For example, one array entry could specify RS-232, another DB-25, and a third entry could define the connector as male. See Table 2-10 for the values of the ConnectorType property.	uint16


Table 2-10. Connector Type Values

0 - Unknown	30 - <i>unused</i>	60 - Micro-DIN	90 - On Board IDE Connector
1 - Other	31 - <i>unused</i>	61 - PS/2	91 - On Board Floppy Connector
2 - Male	32 - IEEE-48	62 - Infrared	92 - 9 Pin Dual Inline
3 - Female	33 - AUI	63 - <i>unused</i>	93 - 25 Pin Dual Inline
4 - Shielded	34 - UTP Category 3	64 - Access. bus	94 - 50 Pin Dual Inline
5 - Unshielded	35 - UTP Category 4	65 - <i>unused</i>	95 - 68 Pin Dual Inline
6 - SCSI (A) High-Density (50 pins)	36 - UTP Category 5	66 - Centronics	96 - On Board Sound Connector
7 - SCSI (A) Low-Density (50 pins)	37 - BNC	67 - Mini-Centronics	97 - Mini-jack
8 - SCSI (P) High-Density (68 pins)	38 - RJ11	68 - Mini-Centronics Type-14	98 - PCI-X
9 - SCSI SCA-I (80 pins)	39 - RJ45	69 - Mini-Centronics Type-20	99 - Sbus IEEE 1396-1993 32-bit
10 - SCSI SCA-II (80 pins)	40 - Fiber MIC	70 - Mini-Centronics Type-26	100 - Sbus IEEE 1396-1993 64-bit

Table 2-10. Connector Type Values (continued)

11 - Fibre Channel (DB-9 Copper)	41 - <i>unused</i>	71 - Bus Mouse	101 - <i>unused</i>
12 - Fibre Channel (Fiber Optical)	42 - <i>unused</i>	72 - ADB	102 - GIO
13 - Fibre Channel SCA-II (40 pins)	43 - PCI	73 - AGP	103 - XIO
14 - Fibre Channel SCA-II (20 pins)	44 - ISA	74 - VME Bus	104 - HIO
15 - Fibre Channel BNC	45 - <i>unused</i>	75 - VME64	105 - NGIO
16 - ATA 3-1/2 Inch (40 pins)	46 - VESA	76 - Proprietary	106 - PMC
17 - ATA 2-1/2 Inch (44 pins)	47 - <i>unused</i>	77 - Proprietary Processor Card Slot	107 - MTRJ
18 - ATA-2	48 - <i>unused</i>	78 - Proprietary Memory Card Slot	108 - VF-45
19 - ATA-3	49 - <i>unused</i>	79 - Proprietary I/O Riser Slot	109 - Future I/O
20 - ATA/66	50 - <i>unused</i>	80 - PCI-66 MHz	110 - SC
21 - DB-9	51 - <i>unused</i>	81 - AGP2X	111 - SG
22 - DB-15	52 - <i>unused</i>	82 - AGP4X	112 - Electrical
23 - DB-25	53 - USB	83 - PC-98	113 - Optical
24 - DB-36	54 - IEEE 1394	84 - PC-98-Hireso	114 - Ribbon
25 - RS-232C	55 - HIPPI	85 - PC-H98	115 - GLM
26 - RS-422	56 - HSSDC (6 pins)	86 - PC-98Note	116 - 1x9
27 - RS-423	57 - GBIC	87 - PC-98Full	117 - Mini SG
28 - RS-485	58 - DIN	88 - SSA SCSI	118 - LC
29 - RS-449	59 - Mini-DIN	89 - Circular	119 - HSSC

CIM_Slot



The `CIM_Slot` class described in Table 2-11 represents connectors into which packages are inserted. For example, a physical package that is a hard drive can be inserted into a small computer system interface-single connector attachment (SCSI-SCA) slot. As another example, a card can be inserted into a 16-, 32-, or 64-bit expansion slot on a host board.

Table 2-11. CIM_Slot Properties

Class Name:	class <code>CIM_Slot</code>	
Parent Class:	<code>CIM_PhysicalConnector</code>	
Property	Description	Data Type
ConnectorType	See Table 2-10.	uint16
SupportsHotPlug	Indicates whether the slot supports hot-plug adapter cards.	Boolean
MaxDataWidth	Indicates the maximum bus width in bits of adapter cards that can be inserted into this slot. Values for the <code>MaxDataWidth</code> property are as follows: 0 - Unknown 1 - Other 8 - Bits 16 - Bits 32 - Bits 64 - Bits 128 - Bits	uint16

Table 2-11. CIM_Slot Properties (continued)

Class Name:	class CIM_Slot	
Parent Class:	CIM_PhysicalConnector	
Property	Description	Data Type
SystemSlotType	Indicates the type of system slot. Values for the SystemSlotType property are as follows: 1 - Other 2 - Unknown 3 - ISA 4 - MCA 5 - EISA 6 - PCI 7 - PCMCIA 8 - VL-VESA 9 - Proprietary 10 - Processor Card Slot 11 - Proprietary Memory Card Slot 12 - I/O Riser Card Slot 13 - NuBus 14 - PCI - 66MHz Capable 15 - AGP 16 - AGP 2X 17 - AGP 4X 18 - PCI-X 19 - AGP 8X 160 - PC-98/C20 161 - PC-98/C24	


Table 2-11. CIM_Slot Properties (continued)


Class Name:	class CIM_Slot	
Parent Class:	CIM_PhysicalConnector	
Property	Description	Data Type
Contd.	162 - PC-98/E	
	163 - PC-98/Local Bus	
	164 - PC-98/Card	
	165 - PCI Express	
	166 - PCI Express x1	
	167 - PCI Express x2	
	168 - PCI Express x4	
	169 - PCI Express x8	
	170 - PCI Express x16	
	171 - PCI Express Gen 2	
	172 - PCI Express Gen 2 x1	
	173 - PCI Express Gen 2 x2	
	174 - PCI Express Gen 2 x4	
	175 - PCI Express Gen 2 x8	
	176 - PCI Express Gen 2 x16	

CIM_LogicalElement

CIM_LogicalElement is a CIM-defined class containing the subclasses shown in Figure 3-1.

Figure 3-1. CIM_LogicalElement Class Structure





CIM_LogicalElement





Table 3-1 lists the following characteristics for members of the `CIM_LogicalElement` class:

- Represent abstractions used to manage and coordinate aspects of a physical environment such as files, processes, systems, system capabilities, and network components in the form of logical devices
- Represent devices, where devices are abstractions of hardware entities that may or may not be realized in physical hardware

Table 3-1. CIM_LogicalElement Properties

Class Name:	<code>CIM_LogicalElement</code>
Parent Class:	<code>CIM_ManagedSystemElement</code>

CIM_System




The `CIM_System` class shown in Table 3-2 defines a collection of managed system elements that operates as a functional whole. An instance of the `CIM_System` class contains a well-defined list of components that work together to perform a specific function.

Table 3-2. CIM_System Properties

Class Name:	<code>CIM_System</code>	
Parent Class:	<code>CIM_LogicalElement</code>	
Property	Description	Data Type
<code>CreationClassName</code>	See Table 1-1.	string
<code>Name</code>	Indicates the name of a specific system, such as a particular storage system or server.	string
<code>PrimaryOwnerContact</code>	Provides information on how the primary system owner can be reached, for example, a phone number or e-mail address.	string
<code>PrimaryOwnerName</code>	Indicates the name of the primary system owner.	string
<code>Roles</code>	An array of strings that specifies the roles this system plays in the IT environment. For example, for an instance of a network system, the Roles property might contain the string "storage system."	string

CIM_ComputerSystem




The CIM_ComputerSystem class listed in Table 3-3 contains some or all of the following CIM_ManagedSystemElements: file system, operating system, processor, and memory (volatile and/or nonvolatile storage). For properties, see Table 3-2.

Table 3-3. CIM_ComputerSystem Properties

Class Name:	CIM_ComputerSystem
Parent Class:	CIM_System

DELL_System




The DELL_System class listed in Table 3-4 is the set of all Dell instrumented systems, including server, and storage systems. For properties, see Table 3-2.

Table 3-4. DELL_System Properties

Class Name:	DELL_System
Parent Class:	CIM_ComputerSystem

CIM_LogicalDevice




The `CIM_LogicalDevice` class described in Table 3-5 models a hardware entity that may be realized in physical hardware. `CIM_LogicalDevice` includes any characteristics of a logical device that manages its operation or configuration. An example of a logical device is a temperature sensor’s reading of actual temperature.

Table 3-5. CIM_Logical Device Properties

Class Name:	<code>CIM_LogicalDevice</code>	
Parent Class:	<code>CIM_LogicalElement</code>	
Property	Description	Data Type
<code>SystemCreationClassName</code>	See Table 1-1.	string
<code>SystemName</code>	Indicates the scoping system’s name.	string
<code>CreationClassName</code>	See Table 1-1.	string
<code>DeviceID</code>	Identifies an address or other identifying information to uniquely name the logical device.	string

CIM_FRU




The `CIM_FRU` class described in Table 3-6 contains manufacturing information related to the Field Replaceable Units (FRU) of a system such as a system planar or I/O riser card.

Table 3-6. CIM_FRU Properties

Class Name:	CIM_FRU	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
FRUInformationState	Indicates the state and availability of FRU information.	uint 16
FRUDeviceName	Indicates the device name of the FRU	string
FRUManufacturingDateName	Indicates the manufacturing date of the FRU in ticks.	datetime
FRUManufacturerName	Indicates the name of the manufacturer.	string
FRUPartNumberName	Indicates the FRU part number.	string
FRUSerialNumberName	Indicates the FRU serial number.	string
FRURevisionName	Indicates the FRU Revision number.	string

CIM_LogicalPort




The `CIM_LogicalPort` class listed in Table 3-7 represents the abstraction of a port or connection point of a device. For example, a USB port can be abstracted to represent a port. This feature is used when the abstracted port has independent management characteristics from the device that includes it.

Table 3-7. CIM_LogicalPort Properties

Class Name:	CIM_LogicalPort	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
Speed	Indicates the bandwidth of the port in bits per second.	uint64
MaxSpeed	Indicates the maximum bandwidth of the port in bits per second.	uint64
RequestedSpeed	Indicates the requested bandwidth of the port in bits per second.	uint64
UsageRestriction	Indicates usage parameters for the port. For example, a storage array may have back end ports to communicate with disk drives and front end ports to communicate with hosts.	uint16

CIM_NetworkPort



The `CIM_NetworkPort` class listed in Table 3-8 describes the logical representation of a network.


Table 3-8. CIM_NetworkPort Properties

Class Name:	<code>CIM_NetworkPort</code>	
Parent Class:	<code>CIM_LogicalPort</code>	
Property	Description	Data Type
Speed	Indicates the bandwidth of the port in bits per second.	uint64
PortType	Identifies port type and whether it is DMTF reserved or vendor reserved. When this property is set to 1 (Other), the OtherPropertyType property contains a string description of the port type.	uint16
OtherPortType	When used in conjunction with PortType, this property identifies port type.	string
LinkTechnology	Enumerates the types of links to the device. When this property is set to 1, the OtherLinktechnology property displays relevant links to the device.	uint16
OtherLinkTechnology	When used in conjunction with Link Technology, this property displays relevant links to the device.	string
PermanentAddress	Defines the network address hardcoded into a port.	string
NetworkAddresses	Indicates the network addresses for a port.	string

Table 3-8. CIM_NetworkPort Properties (continued)

Class Name:	CIM_NetworkPort	
Parent Class:	CIM_LogicalPort	
Property	Description	Data Type
FullDuplex	Indicates whether the port is operating in a full duplex mode.	Boolean
AutoSense	Indicates whether the Network Port is capable of automatically determining the speed or other characteristics of network attached media.	Boolean
SupportedMaximumTransmissionUnit	Indicates the maximum transmission unit supported.	uint64
ActiveMaximumTransmissionUnit	Indicates the active or negotiated maximum transmission unit supported.	uint64

DELL_ManagedSystemServicesDevice




The DELL_ManagedSystemServicesDevice class listed in Table 3-9 defines the type, size of storage devices in MB, and related information.

Table 3-9. DELL_ManagedSystemServicesDevice properties

Class Name:	DELL_ManagedSystemServicesDevice	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
deviceType	Defines the type of storage device. The values for this property can be: 0 - Base managed device 1 - Optional managed device	uint8
storagePresent	Defines the storage device present on the card.	boolean
deviceSize	Indicates the size of storage device in MB.	uint32

DELL_NetworkPort



The DELL_NetworkPort class listed in Table 3-10 represents the abstraction of a port or connection point of a device. For example, a USB port can be abstracted to represent a port. This feature is used when the abstracted port has independent management characteristics from the device that includes it.

Table 3-10. DELL_NetworkPort Properties

Class Name:	Dell_NetworkPort	
Parent Class:	CIM_NetworkPort	
Property	Description	Data Type
NicTOECapability	<p>Defines NIC TCP Offload Engine (TOE) capability. The following values, with explanations, are possible for this property:</p> <ul style="list-style-type: none">0 - NIC/driver does not support querying for capability.1 - NIC/driver supports querying for capability but query returned an error.2 - NIC/driver supports querying for capability and query says it is capable.4 - NIC/driver supports querying for capability and query says it is not capable.8 - NIC/driver supports querying for capability but error prevented querying NIC/driver.16 - NIC/driver supports querying for capability but NIC/driver did not respond to query.	uint32
NicRDMACapability	<p>Defines NIC Remote Direct Memory Access (RDMA) capability. The following values, with explanations, are possible for this property:</p> <ul style="list-style-type: none">0 - NIC/driver does not support querying for capability.1 - NIC/driver supports querying for capability but query returned an error.2 - NIC/driver supports querying for capability and query says it is capable.4 - NIC/driver supports querying for capability and query says it is not capable.8 - NIC/driver supports querying for capability but error prevented querying NIC/driver.16 - NIC/driver supports querying for capability but NIC/driver did not respond to query.	uint32


Table 3-10. DELL_NetworkPort Properties (continued)

Class Name:	Dell_NetworkPort	
Parent Class:	CIM_NetworkPort	
Property	Description	Data Type
NiciSCSICapability	<p>Defines NIC Internet Small Computer System Interface (iSCSI) Capability. The following values, with explanations, are possible for this property:</p> <p>0 - NIC/driver does not support querying for capability.</p> <p>1 - NIC/driver supports querying for capability but query returned an error.</p> <p>2 - NIC/driver supports querying for capability and query says it is capable.</p> <p>4 - NIC/driver supports querying for capability and query says it is not capable.</p> <p>8 - NIC/driver supports querying for capability but error prevented querying NIC/driver.</p> <p>16 - NIC/driver supports querying for capability but NIC/driver did not respond to query.</p>	uint32
IsTOEEnable	Indicates whether TOE is enabled.	Boolean
IsRDMAEnable	Indicates whether RDMA is enabled.	Boolean
IsiSCSIEnable	Indicates whether SCSI is enabled.	Boolean
NicStatus	<p>Indicates NIC /driver status. The following values are possible:</p> <p>0 - Unknown</p> <p>1 - Connected</p> <p>2 - Disconnected</p> <p>3 - Driver Bad</p> <p>4 - Driver Disabled</p> <p>10 - Hardware initializing</p> <p>11 - Hardware resetting</p> <p>12 - Hardware closing</p> <p>13 - Hardware not ready</p>	uint32

Table 3-10. DELL_NetworkPort Properties (continued)

Class Name:	Dell_NetworkPort	
Parent Class:	CIM_NetworkPort	
Property	Description	Data Type
BusNumber	Indicates the PCI bus number.	uint8
FunctionNumber	Indicates the PCI Function number.	uint8
Driver version	Indicates the NIC driver version.	string
IPAddress	Indicates the NIC IP Address.	string
SubnetMask	Indicates the NIC subnet mask.	string
DHCPServer	Indicates the NIC DHCP Server.	string
DefaultGateway	Indicates the NIC default gateway.	string
CurrentMACAddress	Indicates the NIC current MAC address.	string
OSAdapterDescription	Describes the OS Adapter.	string
OSAdapterVendor	Provides OS Adapter vendor details.	string
OSAdapterProductName	Identifies the OS Adapter name.	string
ServiceName	Identifies the Service Name.	string

CIM_Sensor




The `CIM_Sensor` class explained in Table 3-11 contains hardware devices capable of measuring the characteristics of some physical property, for example, the temperature or voltage characteristics of a computer system.

Table 3-11. CIM_Sensor Properties

Class Name:	CIM_Sensor	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
SensorType	<p>The type of the sensor, for example, voltage or temperature sensor.</p> <p>Values for the SensorType property are:</p> <ul style="list-style-type: none">0 - Unknown1 - Other2 - Temperature sensors measure the environmental temperature.3 - Voltage sensors measure electrical voltage.4 - Current sensors measure current readings.5 - Tachometers measure speed/revolutions of a device. For example, a fan device can have an associated tachometer that measures its speed.6 - Batteries maintain the time and date and save the system's BIOS configuration when the system is switched off.	uint16
OtherSensorTypeDescription	The type of sensor when the SensorType property is set to Other.	string
PossibleStates	Enumerates the string outputs of the sensor. For example, a NumericSensor can report states based on threshold readings.	string
CurrentState	Indicates the current state of the sensor. This value is always one of the Possible States.	string
PollingInterval	Indicates the polling interval, in nanoseconds, that the sensor hardware or instrumentation uses to determine the current state of the sensor.	uint64

CIM_DiscreteSensor




The CIM_DiscreteSensor class described in Table 3-12 has a set of legal string values that it can report. The CIM_DiscreteSensor will always have a "current reading" that corresponds to one of the enumerated values.

Table 3-12. CIM_DiscreteSensor Properties

Class Name:	CIM_DiscreteSensor	
Parent Class:	CIM_Sensor	
Property	Description	Data Type
CurrentReading	See Table 1-1.	sint32
PossibleValues	Enumerates the string outputs that can be reported by the sensor.	sint32

CIM_NumericSensor



The CIM_NumericSensor class described in Table 3-13 returns numeric settings and may also support threshold settings. Figure 3-2 shows the relationship among upper and lower critical and upper and lower non-critical threshold values. The normal range falls between upper and lower non-critical thresholds.

Figure 3-2. Ranges for Threshold Values




Table 3-13 provides definitions for NumericSensor properties.


Table 3-13. CIM_NumericSensor Properties

Class Name:	CIM_NumericSensor	
Parent Class:	CIM_Sensor	
Property	Description	Data Type
UnitModifier	See Table 1-1.	sint32
CurrentReading	See Table 1-1.	sint32
IsLinear	See Table 1-1.	Boolean
LowerThresholdNonCritical	See Table 1-1.	sint32

Table 3-13. CIM_NumericSensor Properties (continued)

Class Name:	CIM_NumericSensor	
Parent Class:	CIM_Sensor	
Property	Description	Data Type
UpperThresholdNonCritical	See Table 1-1.	sint32
LowerThresholdCritical	See Table 1-1.	sint32
UpperThresholdCritical	See Table 1-1.	sint32
SupportedThresholds	An array representing the thresholds supported by this sensor. The supported values are as follows: 1 - LowerThresholdNonCritical 2 - UpperThresholdNonCritical 3 - LowerThresholdCritical 4 - UpperThresholdCritical	uint16
EnabledThresholds	An array representing the thresholds that are currently enabled for this sensor. Enabled threshold values are as follows: 1 - LowerThresholdNonCritical 2 - UpperThresholdNonCritical 3 - LowerThresholdCritical 4 - UpperThresholdCritical	uint16
SettableThresholds	An array representing the writable thresholds supported by sensor. Settable threshold values are: 1 - LowerThresholdNonCritical 2 - UpperThresholdNonCritical	uint16

CIM_TemperatureSensor




The CIM_TemperatureSensor class listed in Table 3-14 contains sensors that sample ambient temperature and return a value in degrees Celsius.

Table 3-14. CIM_TemperatureSensor Properties

Class Name:	CIM_TemperatureSensor	
Parent Class:	CIM_NumericSensor	
Property	Description	Data Type
UnitModifier	See Table 1-1.	sint32
CurrentReading	See Table 1-1.	sint32
IsLinear	See Table 1-1.	Boolean
LowerThresholdNonCritical	See Table 1-1.	sint32
UpperThresholdNonCritical	See Table 1-1.	sint32
LowerThresholdCritical	See Table 1-1.	sint32
UpperThresholdCritical	See Table 1-1.	sint32

CIM_CurrentSensor




The CIM_CurrentSensor class listed in Table 3-15 contains sensors that measure amperage and returns a value in amperes and watts.

Table 3-15. CIM_CurrentSensor Properties

Class Name:	CIM_CurrentSensor	
Parent Class:	CIM_NumericSensor	
Property	Description	Data Type
UnitModifier	See Table 1-1.	sint32
CurrentReading	See Table 1-1.	sint32
IsLinear	See Table 1-1.	Boolean
LowerThresholdNonCritical	See Table 1-1.	sint32
UpperThresholdNonCritical	See Table 1-1.	sint32
LowerThresholdCritical	See Table 1-1.	sint32
UpperThresholdCritical	See Table 1-1.	sint32

CIM_VoltageSensor




The `CIM_VoltageSensor` class shown in Table 3-16 contains sensors that measure voltage and return a value in volts.

Table 3-16. CIM_VoltageSensor Properties

Class Name:	CIM_VoltageSensor	
Parent Class:	CIM_NumericSensor	
Property	Description	Data Type
UnitModifier	See Table 1-1.	sint32
CurrentReading	See Table 1-1.	sint32
IsLinear	See Table 1-1.	Boolean
LowerThresholdNonCritical	See Table 1-1.	sint32
UpperThresholdNonCritical	See Table 1-1.	sint32
LowerThresholdCritical	See Table 1-1.	sint32
UpperThresholdCritical	See Table 1-1.	sint32

CIM_Tachometer




The `CIM_Tachometer` class listed in Table 3-17 contains devices that measure revolutions per minute (RPM) of a fan and return the value in RPMs.

Table 3-17. CIM_Tachometer Properties

Class Name:	<code>CIM_Tachometer</code>	
Parent Class:	<code>CIM_NumericSensor</code>	
Property	Description	Data Type
<code>SensorType</code>	See Table 1-1.	<code>uint16</code>
<code>UnitModifier</code>	See Table 1-1.	<code>sint32</code>
<code>CurrentReading</code>	See Table 1-1.	<code>sint32</code>
<code>IsLinear</code>	See Table 1-1.	<code>Boolean</code>
<code>LowerThresholdNonCritical</code>	See Table 1-1.	<code>sint32</code>
<code>UpperThresholdNonCritical</code>	See Table 1-1.	<code>sint32</code>

CIM_WatchDog



The `CIM_WatchDog` class described in Table 3-18 represents a timer that is implemented in system hardware. The watchdog feature allows the hardware to monitor the state of the operating system, BIOS, or a software component installed on the system. If the monitored component fails to rearm the timer before its expiration, the hardware assumes that the system is in a critical state and could reset the system. This feature can also be used as an application watchdog timer for a mission-critical application. In this case, the application would assume responsibility for rearming the timer before expiration.


Table 3-18. CIM_WatchDog Properties

Class Name:	<code>CIM_WatchDog</code>	
Parent Class:	<code>CIM_LogicalDevice</code>	
Property	Description	Data Type
<code>MonitoredEntity</code>	Indicates the entity that is currently being monitored by the watchdog feature. This property is used to identify the module that is responsible for rearming the watchdog at periodic intervals. Values for the <code>MonitoredEntity</code> property are: 1 - Unknown 2 - Other 3 - Operating System	<code>uint16</code>
<code>MonitoredEntityDescription</code>	A string describing additional textual information about the monitored entity.	<code>string</code>

Table 3-18. CIM_WatchDog Properties (continued)

Class Name:	CIM_WatchDog	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
TimeoutInterval	Indicates the time-out interval used by the watchdog, in microseconds.	uint32
TimerResolution	Indicates the resolution of the watchdog timer. For example, if this value is 100, then the timer can expire anytime between -100 microseconds and +100 microseconds.	uint32

CIM_CoolingDevice




The CIM_CoolingDevice class described in Table 3-19 contains a set of devices that work to keep the ambient internal temperature of the system at a safe value.

Table 3-19. CIM_CoolingDevice Properties

Class Name:	CIM_CoolingDevice	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
ActiveCooling	Specifies whether the device provides active (as opposed to passive) cooling.	Boolean

CIM_Fan




The CIM_Fan class explained in Table 3-20 contains a set of devices that work to keep the ambient internal temperature of the system at a safe value by circulating air.

Table 3-20. CIM_Fan Properties

Class Name:	CIM_Fan	
Parent Class:	CIM_CoolingDevice	
Property	Description	Data Type
VariableSpeed	Specifies whether the fan supports variable speeds.	Boolean
DesiredSpeed	Indicates the currently requested fan speed, defined in RPM. When the value = TRUE, the fan supports variable speeds. When a variable speed fan is supported (VariableSpeed Boolean = TRUE), the actual speed is determined using a sensor (CIM_Tachometer) that is associated with the fan.	uint64

CIM_UserDevice




The `CIM_UserDevice` class shown in Table 3-21 contains logical devices that allow a computer system’s users to input, view, or hear data. Classes derived from `CIM_UserDevice` include `CIM_Keyboard` and `CIM_PointingDevice`.

Table 3-21. CIM_UserDevice Properties

Class Name:	<code>CIM_UserDevice</code>	
Parent Class:	<code>CIM_LogicalDevice</code>	
Property	Description	Data Type
<code>IsLocked</code>	Indicates whether the device is locked, preventing user input or output.	Boolean

CIM_PointingDevice




The `CIM_PointingDevice` class described in Table 3-22 includes those devices used to point to regions of a display. Examples are a mouse or a trackball.

Table 3-22. CIM_PointingDevice Properties

Class Name:	CIM_PointingDevice	
Parent Class:	CIM_UserDevice	
Property	Description	Data Type
PointingType	Indicates the type of pointing device. Values for the PointingType property are: 1 - Other 2 - Unknown 3 - Mouse 4 - Trackball 5 - Trackpoint 6 - Glidepoint 7 - Touch pad 8 - Touch screen 9 - Mouse—optical sensor	uint16
NumberOfButtons	Indicates the number of buttons. If the CIM_PointingDevice has no buttons, a value of 0 is returned.	uint8
Handedness	Integer indicating whether the CIM_PointingDevice is configured for right- or left-handed operation. Values for the Handedness property are as follows: 0 - Unknown 1 - Not applicable 2 - Right-handed operation 3 - Left-handed operation	uint16

CIM_Keyboard




The `CIM_Keyboard` class explained in Table 3-23 includes devices that allow users to enter data.

Table 3-23. CIM_Keyboard Properties

Class Name:	CIM_Keyboard	
Parent Class:	CIM_UserDevice	
Property	Description	Data Type
NumberOfFunctionKeys	Indicates the number of function keys on the keyboard.	uint16
Layout	A free-form string indicating the format and layout of the keyboard.	string
Password	An integer indicating whether a hardware-level password is enabled at the keyboard, preventing local input. Values for the Password property are: 1 - Other 2 - Unknown 3 - Disabled 4 - Enabled 5 - Not implemented	uint16

CIM_PowerSupply



The `CIM_PowerSupply` class described in Table 3-24 contains devices that provide current and voltage for the operation of the system and its components.


Table 3-24. CIM_PowerSupply Properties

Class Name:	<code>CIM_PowerSupply</code>	
Parent Class:	<code>CIM_LogicalDevice</code>	
Property	Description	Data Type
<code>IsSwitchingSupply</code>	Indicates that the power supply is a switching power supply and not a linear power supply.	Boolean
<code>Range1InputVoltageLow</code>	Indicates the low voltage in millivolts of input voltage range 1 for this power supply. A value of 0 denotes unknown.	uint32
<code>Range1InputVoltageHigh</code>	Indicates the high voltage in millivolts of input voltage range 1 for this power supply. A value of 0 denotes unknown.	uint32

Table 3-24. CIM_PowerSupply Properties (continued)

Class Name:	CIM_PowerSupply	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
ActiveInputVoltage	Indicates which input voltage range is currently in use. Range 1, 2, or both can be specified using the values 3, 4, or 5, respectively. If the supply is not drawing power, a value of 6 (neither) can be specified. This information is necessary in the case of an uninterruptible power supply (UPS), a subclass of power supply. Values for the ActiveInputVoltage property are: 1 - Other 2 - Unknown 3 - Range 1 4 - Range 2 5 - Both range 1 and range 2 6 - Neither range 1 nor range 2	uint16
TotalOutputPower	Represents the total output power of the power supply in milliwatts. A value of 0 denotes that the power output is unknown.	uint32
PMCapable	Indicates the Power Monitoring capability.	Boolean

CIM_Controller




The `CIM_Controller` class shown in Table 3-25 groups miscellaneous control-related devices. Examples of controllers are small computer system interface (SCSI) controllers, Universal Serial Bus (USB) controllers, and serial controllers.

Table 3-25. CIM_Controller Properties

Class Name:	<code>CIM_Controller</code>	
Parent Class:	<code>CIM_LogicalDevice</code>	
Property	Description	Data Type
<code>ProtocolSupported</code>	The protocol used by the controller to access controlled devices. Values for the ProtocolSupported property are: 1 - Other 2 - Unknown 3 - PCI 4 - Parallel protocol	<code>uint16</code>

CIM_ParallelController




The `CIM_ParallelController` class identified in Table 3-26 contains a set of objects that control parallel devices. Parallel controllers transfer 8 or 16 bits of data at a time to the devices they control, for example, a parallel port controlling a printer.

Table 3-26. CIM_ParallelController Properties

Class Name:	<code>CIM_ParallelController</code>	
Parent Class:	<code>CIM_Controller</code>	
Property	Description	Data Type
<code>DMASupport</code>	Set to TRUE if the parallel controller supports DMA.	Boolean
<code>Security</code>	An enumeration indicating the operational security for the controller. Values for the <code>Security</code> property are: 1 - Other 2 - Unknown 3 - None 4 - External interface locked out 5 - External interface enabled 6 - Boot bypass	uint16

CIM_SerialController




The `CIM_SerialController` class explained in Table 3-27 contains controllers that transfer data one bit at a time to the devices they control, for example, a serial port controlling a modem.

Table 3-27. CIM_SerialController Properties

Class Name:	<code>CIM_SerialController</code>	
Parent Class:	<code>CIM_Controller</code>	
Property	Description	Data Type
MaxBaudRate	Indicates the maximum baud rate in bits per second supported by the serial controller.	uint32
Security	An enumeration indicating the operational security for the controller. Values for the Security property are: 1 - Other 2 - Unknown 3 - None 4 - External interface locked out 5 - External interface enabled 6 - Boot bypass	uint16

CIM_PCIController



The `CIM_PCIController` class listed in Table 3-28 contains a set of devices that follow the Peripheral Component Interconnect (PCI) protocol defined by the Personal Computer Memory Card International Association (PCMCIA). The PCI protocol defines how data is transferred between devices. The `CIM_PCIController` class contains PCI adapters and bridges.


Table 3-28. CIM_PCIController Properties

Class Name:	<code>CIM_PCIController</code>	
Parent Class:	<code>CIM_Controller</code>	
Property	Description	Data Type
<code>CommandRegister</code>	The current contents of the register that provide basic control over the device's ability to respond to, and/or perform PCI accesses. The data in the capabilities array is gathered from the PCI status register and the PCI capabilities list as defined in the PCI specification.	<code>uint16</code>

Table 3-28. CIM_PCIController Properties (continued)

Class Name:	CIM_PCIController	
Parent Class:	CIM_Controller	
Property	Description	Data Type
	Values for the CommandRegister property are:	
	0 - Unknown	
	1 - Other	
	2 - Supports 66 MHz	
	3 - Supports user-definable features	
	4 - Supports fast back-to-back transactions	
	5 - PCI-X capable	
	6 - PCI power management supported	
	7 - Message signaled interrupts supported	
	8 - Parity error recovery capable	
	9 - AGP supported	
	10 - Vital product data supported	
	11 - Provides slot identification	
	12 - Hot swap supported	

CIM_PCIDevice




The `CIM_PCIDevice` class shown in Table 3-29 describes the capabilities and management of a PCI device controller on an adapter card.

Table 3-29. CIM_PCIDevice Properties

Class Name:	CIM_PCIDevice	
Parent Class:	CIM_PCIController	
Property	Description	Data Type
BaseAddress	Identifies an array of up to six double-word base memory addresses.	uint32
SubsystemID	Identifies a subsystem identifier code.	uint16
SubsystemVendorID	Identifies a subsystem vendor ID. ID information is reported from a PCI device via protocol-specific requests. This information is also present in the CIM_PhysicalElement class (the manufacturer property) for hardware, and the CIM_Product class (the vendor property) for information related to product acquisition.	uint16
ExpansionROMBaseAddress	Identifies a double-word expansion ROM base memory address.	uint32

CIM_PCIBridge




The CIM_PCIBridge class shown in Table 3-30 describes the capabilities and management of a PCI controller providing bridge-to-bridge capability. An example is a PCI to Industry-Standard Architecture (ISA) bus bridge.

Table 3-30. CIM_PCIBridge Properties

Class Name:	CIM_PCIBridge	
Parent Class:	CIM_PCIController	
Property	Description	Data Type
BaseAddress	Identifies an array of double-word base memory addresses.	uint32
BridgeType	Indicates the type of bridge. A bridge is PCI to <value>, except for the Host, which is a host-to-PCI bridge. Values for the BridgeType property are as follows: 0 - Host 1 - ISA 128 - Other	uint16
BaseAddress	Identifies an array of double-word base memory addresses.	uint32

CIM_Processor



The `CIM_Processor` class described in Table 3-31 contains devices that interpret and execute commands, for example, the Intel Xeon microprocessor.

Table 3-31. CIM_Processor Properties

Class Name:	CIM_Processor	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
Role	A string describing the role of the microprocessor, for example, central microprocessor or math processor.	string
UpgradeMethod	<p>Provides microprocessor socket information including data on how this microprocessor can be upgraded (if upgrades are supported). This property is an integer enumeration. Values for the UpgradeMethod property are as follows:</p> <ul style="list-style-type: none"> 1 - Other 2 - Unknown 3 - Daughter board 4 - ZIF socket 5 - Replacement/piggy back 6 - None 7 - LIF socket 8 - Slot 1 9 - Slot 2 10 - 370-pin socket 19 - Socket mPGA604 20 - Socket LGA771 21 - Socket LGA775 22 - Socket S1 23 - Socket AM2 24- Socket F (1207) 25- Socket LGA1366 	uint16
MaxClockSpeed	Indicates the maximum speed (in MHz) of this microprocessor.	uint32
Core count	Indicates the number of core processors detected.	uint16
CoreEnabledCount	Indicates the number of core processors enabled.	uint16

Table 3-31. CIM_Processor Properties (continued)

Class Name:	CIM_Processor	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
CurrentClockSpeed	Indicates the current speed (in MHz) of this microprocessor.	uint32
DataWidth	Indicates the processor data width in bits.	uint16
AddressWidth	Indicates the processor address width in bits.	uint16
Stepping	Indicates the revision level of the processor within the microprocessor family.	string
UniqueID	Identifies a globally unique identifier for the microprocessor. This identifier may only be unique within a microprocessor family.	string
Brand	Indicates the brand name of the processor.	string
Model	Indicates the model name of the processor.	string
ExtendedCharacteristics	Indicates the extended capabilities of the processor. This attribute is a bit field. The following are the definitions of a bit when set to one: Bit 0 — Virtualization Technology (VT) supported Bit 1 — Demand-Based Switching (DBS) supported Bit 2 — eXecute Disable (XD) supported Bit 3 — Hyper Threading (HT) supported	uint16

Table 3-31. CIM_Processor Properties (continued)

Class Name:	CIM_Processor	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
ExtendedStates	Indicates the setting of the extended capabilities of the processor. This attribute is a bit field. The following are the definitions of a bit when set to one: Bit 0 — Virtualization Technology (VT) enabled Bit 1 — Demand-Based Switching (DBS) enabled Bit 2 — eXecute Disable (XD) enabled Bit 3 — Hyper Threading (HT) enabled	uint16
CPUStatus	Indicates the current status of the microprocessor. For example, it may be disabled by the user through the BIOS or disabled due to a POST error. Values for the CPUStatus property are as follows: 0 - Unknown 1 - Microprocessor enabled 2 - Microprocessor disabled by user via BIOS setup 3 - Microprocessor disabled by BIOS (POST error) 4 - Microprocessor is idle 5 - Other	uint16

Table 3-31. CIM_Processor Properties (continued)

Class Name:	CIM_Processor	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
Family	Refers to the processor family type. Values for the Family property are as follows: 1 - Other 2 - Unknown 3 - 8086 4 - 80286 5 - 80386 6 - 80486 7 - 8087 8 - 80287 9 - 80387 10 - 80487 11 - Pentium Brand 12 - Pentium Pro 13 - Pentium II 14 - Pentium processor with MMX technology 15 - Celeron 16 - Pentium II Xeon 17 - Pentium III 18 - M1 family 19 - M2 family 24 - AMD Duron Processor 25 - K5 family 26 - K6 family 27 - K6-2 28 - K6-3	uint16

Table 3-31. CIM_Processor Properties (continued)

Class Name:	CIM_Processor	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
Family (continued)	29 - AMD Athlon Processor Family	
	30 - AMD29000 Family	
	31 - K6-2+	
	32 - Power PC Family	
	33 - Power PC 601	
	34 - Power PC 603	
	35 - Power PC 603+	
	36 - Power PC 604	
	37 - Power PC 620	
	38 - Power PC X704	
	39 - Power PC 750	
	40 - Intel Core Duo processor	
	41 - Intel Core Duo mobile processor	
	42 - Intel Core Solo mobile processor	
	43 - Intel Atom processor	
	48 - Alpha Family	
	49 - Alpha 21064	
	50 - Alpha 21066	
	51 - Alpha 21164	
	52 - Alpha 21164PC	
	53 - Alpha 21164a	
	54 - Alpha 21264	
	55 - Alpha 21364	
	60 - AMD Opteron 4100 Series Processor	
	64 - MIPS Family	
	65 - MIPS R4000	
	66 - MIPS R4200	
	67 - MIPS R4400	
	68 - MIPS R4600	

Table 3-31. CIM_Processor Properties (continued)

Class Name:	CIM_Processor	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
Family (continued)	69 - MIPS R10000	
	80 - SPARC Family	
	81 - SuperSPARC	
	82 - microSPARC II	
	83 - microSPARC IIep	
	84 - UltraSPARC	
	85 - UltraSPARC II	
	86 - UltraSPARC IIi	
	87 - UltraSPARC III	
	88 - UltraSPARC IIIi	
	96 - 68040	
	97 - 68xxx Family	
	98 - 68000	
	99 - 68010	
	100 - 68020	
	101 - 68030	
	112 - Hobbit family	
	120 - Crusoe 5000 Family	
	121 - Crusoe 3000 Family	
	122 - Efficeon 8000 Family	
	128 - Weitek	
	130 - Itanium Processor	
	131 - AMD Athlon 64 Processor Family	
	132 - AMD Opteron Processor Family	
	133 - AMD Sempron Processor Family	
	134 - AMD Turion 64 Mobile Technology	
	135 - Dual-Core AMD Opteron Processor family	
	136 - AMD Athlon 64 X2 Dual-Core Processor family	

Table 3-31. CIM_Processor Properties (continued)

Class Name:	CIM_Processor	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
Family (continued)	137 - AMD Turion 64 X2 Mobile Technology	
	138 - Quad-Core AMD Opteron Processor Family	
	139 - Third-Generation AMD Opteron Processor Family	
	140 - AMD Phenom FX Quad-Core Processor Family	
	141 - AMD Phenom X4 Quad-Core Processor Family	
	142 - AMD Phenom X2 Dual-Core Processor Family	
	143 - AMD Athlon X2 Dual-Core Processor Family	
	144 - PA-RISC family	
	145 - PA-RISC 8500	
	146 - PA-RISC 8000	
	147 - PA-RISC 7300LC	
	148 - PA-RISC 7200	
	149 - PA-RISC 7100LC	
	150 - PA-RISC 7100	
	160 - V30 family	
	161 - Quad-Core Intel Xeon processor 3200 Series	
	162 - Dual-Core Intel Xeon processor 3000 Series	
	163 - Quad-Core Intel Xeon processor 5300 Series	
	164 - Dual-Core Intel Xeon processor 5100 Series	
	165 - Dual-Core Intel Xeon processor 5000 Series	
	166 - Dual-Core Intel Xeon processor LV	
	167 - Dual-Core Intel Xeon processor ULV	
	168 - Dual-Core Intel Xeon processor 7100 Series	
	169 - Quad-Core Intel Xeon processor 5400 Series	
	170 - Quad-Core Intel Xeon processor	
	171- Dual-Core Intel Xeon processor 5200 Series	
	172- Dual-Core Intel Xeon processor 7200 Series	
	173- Quad-Core Intel Xeon processor 7300 Series	

Table 3-31. CIM_Processor Properties (continued)

Class Name:	CIM_Processor	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
Family (continued)	174- Quad-Core Intel Xeon processor 7400 Series	
	175- Multi-Core Intel Xeon processor 7400 Series	
	176 - Pentium III Xeon	
	177 - Pentium III Processor with Intel SpeedStep	
	178 - Technology	
	179 - Pentium 4	
	180 - Intel Xeon	
	181 - AS400 Family	
	182 - Intel Xeon Processor MP	
	183 - AMD Athlon XP family	
	184 - AMD Athlon MP family	
	185 - Intel Itanium 2	
	186 - Intel Pentium M processor	
	187 - Intel Celeron D Processor	
	188 - Intel Pentium D Processor	
	189 - Intel Pentium Extreme Edition processor	
	190 - Intel Core 2 processor	
	192 - Intel Core 2 Solo processor	
	193 - Intel Core 2 Extreme processor	
	194 - Intel Core 2 Quad processor	
	195 - Intel Core 2 Extreme mobile processor	
	196 - Intel Core 2 Duo mobile processor	
	197 - Intel Core 2 Solo mobile processor	
	198 - Intel Core i7 Processor	
	199 - Dual-Core Intel Celeron Processor	
	200 - S/390 and zSeries family	
	201 - ESA/390 G4	
	202 - ESA/390 G5	


Table 3-31. CIM_Processor Properties (continued)

Class Name:	CIM_Processor	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
Family (continued)	203 - ESA/390 G6	
	204 - z/Architecture base	
	206 - CEh 206 Intel Core i3 processor	
	214 - Multi-Core Intel Xeon processor	
	215 - Dual-Core Intel Xeon processor 3xxx Series	
	216 - Quad-Core Intel Xeon processor 3xxx Series	
	217 - D9h 217 VIA Nano Processor Family	
	218 - Dual-Core Intel Xeon processor 5xxx Series	
	219 - Quad-Core Intel Xeon processor 5xxx Series	
	221 - Dual-Core Intel Xeon processor 7xxx Series	
	222 - Quad-Core Intel Xeon processor 7xxx Series	
	223 - Multi-Core Intel Xeon processor 7xxx Series	
	224 - E0h 224 Multi-Core Intel Xeon processor 3400 Series	
	230 - Embedded AMD Opteron Quad-Core Processor Family	
	231 - AMD Phenom Triple-Core Processor Family	
	232 - AMD Turion Ultra Dual-Core Mobile Processor Family	
	233 - AMD Turion Dual-Core Mobile Processor Family	
	234 - AMD Athlon Dual-Core Processor Family	
	235 - AMD Sempron SI Processor Family	
	238 - AMD Opteron Six-Core Processor Family	
	250 - i860	
	251 - i960	
	260 - SH-3	
	261 - SH-4	
	280 - ARM	
	281 - StrongARM	

Table 3-31. CIM_Processor Properties (continued)

Class Name:	CIM_Processor	
Parent Class:	CIM_LogicalDevice	
Property	Description	Data Type
Family (continued)	300 - 6x86	
	301 - MediaGX	
	302 - MII	
	320 - WinChip	
	350 - DSP	
	500 - Video processor	

CIM_StorageExtent




CIM_StorageExtent identified in Table 3-32 contains devices that manage data storage, for example, hard drives or microprocessor memory.

Table 3-32. CIM_StorageExtent Properties

Class Name:	CIM_StorageExtent
Parent Class:	CIM_LogicalDevice

CIM_Memory




The CIM_Memory class identified in Table 3-33 describes the capabilities and management of storage extent devices, for example, cache memory or system memory.

Table 3-33. CIM_Memory Properties

Class Name:	CIM_Memory
Parent Class:	CIM_StorageExtent

CIM_CacheMemory



The CIM_CacheMemory class explained in Table 3-34 describes the capabilities and management of cache memory. Cache memory allows a microprocessor to access data and instructions faster than normal system memory.


Table 3-34. CIM_CacheMemory Properties

Class Name: CIM_CacheMemory		
Parent Class: CIM_Memory		
Property	Description	Data Type
Level	Defines whether this is the primary, secondary, or tertiary cache. Values for the Level property are as follows: 1 - Other 2 - Unknown 3 - Primary 4 - Secondary 5 - Tertiary 6 - Not applicable	uint16
WritePolicy	Either defines whether this cache is a write-back or write-through cache or whether this information varies with address or is defined individually for each input/output (I/O). Values for the WritePolicy property are as follows: 1 - Other 2 - Unknown 3 - Write-back 4 - Write-through 5 - Varies with address 6 - Determination per I/O	uint16
CacheType	Defines whether this cache is for instruction caching, data caching, or both (unified). Values for the CacheType property are as follows: 1 - Other 2 - Unknown 3 - Instruction 4 - Data 5 - Unified	uint16

Table 3-34. CIM_CacheMemory Properties (continued)

Class Name:	CIM_CacheMemory	
Parent Class:	CIM_Memory	
Property	Description	Data Type
LineSize	Indicates the size, in bytes, of a single cache bucket or line.	uint32
ReadPolicy	Defines the policy used by the cache for handling read requests. Values for the ReadPolicy property are as follows: 1 - Other 2 - Unknown 3 - Read 4 - Read-ahead 5 - Read and read-ahead 6 - Determination per I/O	uint16

CIM_SoftwareElement



The `CIM_SoftwareElement` class described in Table 3-35 is used to define `CIM_SoftwareFeature`. The `CIM_SoftwareElement` class consists of individually manageable or deployable parts for a particular platform. A software element's platform is uniquely identified by its underlying hardware architecture and operating system (for example, a system running Microsoft Windows NT on an Intel microprocessor). A software element's implementation on a particular platform depends on the platform's operating system.


Table 3-35. CIM_SoftwareElement Properties

Class Name:	CIM_SoftwareElement	
Parent Class:	CIM_LogicalElement	
Property	Description	Data Type
Name	Indicates the name that identifies this software element.	string
Version	Provides the version in the form <major>.<minor>.<revision> or <major>.<minor><letter><revision>; for example, 1.2.3 or 1.2a3.	string
Manufacturer	See Table 1-1.	string
BuildNumber	Indicates the internal identifier for this build of the software element.	string
IdentificationCode	Provides the manufacturer's identifier for this software element. Often this will be a stock keeping unit (SKU) or a part number.	string

Table 3-35. CIM_SoftwareElement Properties (continued)

Class Name:	CIM_SoftwareElement	
Parent Class:	CIM_LogicalElement	
Property	Description	Data Type
SoftwareElementType	Indicates the type of software element. Values for SoftwareElementType are: 1 - Other 2 - Unknown 3 - BIOS 4 - ESM 5 - PSPB 6 - System Backplane 7 - Hendrix (PV20x) Kernel 8 - Hendrix (PV20x) Application 9 - Front Panel 10 - BMC 11 - Hot Plug PCI 12 - SDR 13 - Peripheral Bay Backplane 14 - Slimfast Secondary Backplane 15 - Generic Secondary Backplane (ESM 3&4) 16 - RAC4 17 - iDRAC	uint16

CIM_BIOSElement




The CIM_BIOSElement class listed in Table 3-36 describes the BIOS for the system. The BIOS controls the following:

- Communications between the microprocessor and peripheral devices, such as the keyboard and the video adapter
- Miscellaneous functions, such as system messages

Table 3-36. CIM_BIOSElement Properties

Class Name:	CIM_BIOSElement	
Parent Class:	CIM_SoftwareElement	
Property	Description	Data Type
Version	Provides the product version information.	string
Manufacturer	See Table 1-1	string
PrimaryBIOS	Specifies whether a given BIOS is the primary BIOS for the system. When the value = TRUE, the BIOS is the primary BIOS.	Boolean

CIM_SoftwareFeature




The `CIM_SoftwareFeature` class shown in Table 3-37 defines a particular function or capability of a product or application system. This class is intended to be meaningful to a consumer, or user of a product, rather than to explain how the product is built or packaged. When a software feature can exist on multiple platforms or operating systems (for example, a client component of a three-tiered client/server application might run on Windows NT), a software feature is a collection of all the software elements for these different platforms. The users of the model must be aware of this situation because typically they will be interested in a sub-collection of the software elements required for a particular platform.

Table 3-37. CIM_SoftwareFeature Properties

Class Name:	<code>CIM_SoftwareFeature</code>	
Parent Class:	<code>CIM_LogicalElement</code>	
Property	Description	Data Type
<code>IdentifyingNumber</code>	Provides product identification such as a serial number on software.	string
<code>ProductName</code>	Identifies the commonly used product name.	string
<code>Vendor</code>	Identifies the name of the product's supplier. Corresponds to the vendor property in the product object in the DMTF solution exchange standard.	string
<code>Version</code>	Identifies the product version information. Corresponds to the version property in the product object in the DMTF solution exchange standard.	string
<code>Name</code>	Defines the label by which the object is known to the users. This label is a user-defined name that uniquely identifies the element.	string

DELL_SoftwareFeature




DELL_SoftwareFeature described in Table 3-38 defines the universal resource locator (URL) of the systems management software and the language in which systems management information displays. Defining these properties enables users to manage a system using an Internet browser. You can access Server Administrator using the secure hypertext transfer protocol (https) and a preassigned port number of 1311, or you can specify a port number of your own choice.

Table 3-38. DELL_SoftwareFeature Properties

Class Name:	DELL_SoftwareFeature	
Parent Class:	CIM_SoftwareFeature	
Property	Description	Data Type
OmsaURL	Defines the URL for Server Administrator.	string
Language	Sets the language for systems management information.	string
AgentVersion	Defines the version information of local CIM agent (same as ISVC version.)	string

CIM_SystemResource




The `CIM_SystemResource` class listed in Table 3-39 provides access to system resources from an operating system. SystemResources consist of interrupt requests (IRQs) and direct memory access (DMA) capabilities.

Table 3-39. CIM_SystemResource Properties

Class Name:	<code>CIM_SystemResource</code>
Parent Class:	<code>CIM_LogicalElement</code>

CIM_IRQ



The `CIM_IRQ` class described in Table 3-40 contains IRQ information. An IRQ is a signal that data is about to be sent to or received by a peripheral device. The signal travels by an IRQ line to the microprocessor. Each peripheral connection must be assigned an IRQ number. For example, the first serial port in your computer (COM1) is assigned to IRQ4 by default.

Table 3-40. CIM_IRQ Properties

Class Name:	<code>CIM_IRQ</code>	
Parent Class:	<code>CIM_SystemResource</code>	
Property	Description	Data Type
<code>CSCreationClassName</code>	See Table 1-1.	string
<code>CSName</code>	See Table 1-1.	string
<code>CreationClassName</code>	See Table 1-1.	string
<code>IRQNumber</code>	Identifies the interrupt request number.	uint32


Table 3-40. CIM_IRQ Properties (continued)

Class Name:	CIM_IRQ	
Parent Class:	CIM_SystemResource	
Property	Description	Data Type
Availability	Indicates the availability of the IRQ. Values for the Availability property are as follows: 1 - Other 2 - Unknown 3 - Available 4 - In use/not available 5 - In use and available	uint16
TriggerLevel	Indicates whether the interrupt is triggered by the hardware signal going high or low. Values for the TriggerLevel property are as follows: 1 - Other 2 - Unknown 3 - Active low 4 - Active high	uint16
TriggerType	Indicates whether edge (value=4) or level triggered (value=3) interrupts occur. 1 - Other 2 - Unknown 3 - Level 4 - Edge	uint16

Table 3-40. CIM_IRQ Properties (continued)

Class Name:	CIM_IRQ	
Parent Class:	CIM_SystemResource	
Property	Description	Data Type
Shareable	Indicates whether the IRQ can be shared. A value of TRUE indicates that the IRQ can be shared.	Boolean
Hardware	Indicates whether the interrupt is hardware- or software-based. (A value of TRUE indicates that the interrupt is hardware based.) On a personal computer, a hardware IRQ is a physical wire to a programmable interrupt controller (PIC) chip set through which the microprocessor can be notified of time critical events. Some IRQ lines are reserved for standard devices such as the keyboard, diskette drive, and the system clock. A software interrupt is a programmatic mechanism to allow an application to get the attention of the processor.	Boolean

CIM_MemoryMappedIO




The CIM_MemoryMappedIO class explained in Table 3-41 addresses both memory and port I/O resources for personal computer architecture memory mapped I/O.

Table 3-41. CIM_MemoryMappedIO Properties

Class Name:	CIM_MemoryMappedIO	
Parent Class:	CIM_SystemResource	
Property	Description	Data Type
CSCreationClassName	See Table 1-1.	string
CSName	See Table 1-1.	string
CreationClassName	See Table 1-1.	string
StartingAddress	Identifies the starting address of memory mapped I/O.	uint64
EndingAddress	Identifies the ending address of memory mapped I/O.	uint64
MappedResource	Indicates the type of memory mapped I/O. MappedResource defines whether memory or I/O is mapped, and for I/O, whether the mapping is to a memory or a port space. Memory mapped I/O values are as follows: 1 - Other 2 - Mapped memory 3 - I/O mapped to memory space 4 - I/O mapped to port space	uint16

CIM_DMA




The CIM_DMA class explained in Table 3-42 contains DMA information. A DMA channel allows certain types of data transfer between RAM and a device to bypass the microprocessor.

Table 3-42. CIM_DMA Properties

Class Name:	CIM_DMA	
Parent Class:	CIM_SystemResource	
Property	Description	Data Type
CSCreationClassName	See Table 1-1.	string
CSName	See Table 1-1.	string
CreationClassName	See Table 1-1.	string
DMACHannel	Identifies a part of the object's key value, the DMA channel number.	uint32
Availability	Indicates the availability of the DMA. Values for the Availability property are as follows: 1 - Other 2 - Unknown 3 - Available 4 - In use/not available 5 - In use and available/shareable	uint16

CIM_RedundancyGroup




The `CIM_RedundancyGroup` class explained in Table 3-43 is a set of components that provide more instances of a critical component than are required for the system's operation. The extra components are used in case of critical component failure. For example, multiple power supplies allow a working power supply to take over when another power supply has failed.

Table 3-43. CIM_RedundancyGroup Properties

Class Name:	CIM_RedundancyGroup	
Parent Class:	CIM_LogicalElement	
Property	Description	Data Type
CreationClassName	See Table 1-1	string
Name	Serves as the key for the redundancy group's instance in an enterprise environment.	string
RedundancyStatus	Provides information on the state of the redundancy group. Values for the RedundancyStatus property are as follows: 0 - Unknown 1 - Other 2 - Fully redundant. Fully redundant means that all of the configured redundancy is still available. 3 - Degraded redundancy. Degraded redundancy means that some failures have been experienced but some reduced amount of redundancy is still available. 4 - Redundancy lost. Redundancy lost means that a sufficient number of failures have occurred so that no redundancy is available and the next failure experienced will cause overall failure.	uint16

CIM_ExtraCapacityGroup




The `CIM_ExtraCapacityGroup` class explained in Table 3-44 applies to systems that have more capability and components than are required for normal operation, for example, systems that have extra fans or power supplies.

Table 3-44. CIM_ExtraCapacityGroup Properties

Class Name:	CIM_ExtraCapacityGroup	
Parent Class:	CIM_RedundancyGroup	
Property	Description	Data Type
MinNumberNeeded	Specifies the smallest number of elements that must be operational in order to have redundancy. For example, in an N+1 redundancy relationship, the MinNumberNeeded property should be set to N.	uint32

DELL_PSRedundancyGroup




The DELL_PSRedundancyGroup described in Table 3-45 is a Dell-specific extension of the CIM_PowerSupply class. The DELL_PSRedundancyGroup class defines what constitutes power supply redundancy in a system.

Table 3-45. DELL_PSRedundancyGroup Properties

Class Name:	DELL_PSRedundancyGroup
Parent Class:	CIM_ExtraCapacityGroup

DELL_FanRedundancyGroup




The DELL_FanRedundancyGroup described in Table 3-46 defines what constitutes fan redundancy in a system.

Table 3-46. DELL_FanRedundancyGroup Properties

Class Name:	DELL_FanRedundancyGroup
Parent Class:	CIM_ExtraCapacityGroup

CIM_EnabledLogicalElement Group




The CIM_EnabledLogicalElementGroup class described in Table 3-47 extends the CIM_LogicalElementGroup class to abstract the concept of an element that is enabled or disabled, such as a LogicalDevice or ServiceAccessPoint.

Table 3-47. CIM_EnabledLogicalElementGroup Properties

Class Name:	CIM_EnabledLogicalElementGroup
Parent Class:	CIM_LogicalElementGroup

CIM_ServiceAccessPoint




The CIM_ServiceAccessPointGroup class described in Table 3-48 represents the ability to utilize or invoke a service. Access points indicate that a service is available to other entities for use.

Table 3-48. CIM_ServiceAccessPointGroup Properties

Class Name:	CIM_ServiceAccessPointGroup
Parent Class:	CIM_EnabledLogicalElement

CIM_RemoteServiceAccessPoint




The CIM_RemoteServiceAccessPointGroup class identified in Table 3-49 describes the accessing and addressing of information for a remote connection that is known to a *local* network element. This information is contained in the *local* network element since this is the context in which it is *remote*. The relevance of the remote service access point and information on its use are described by subclassing or associating to the CIM_RemoteServiceAccessPointGroup class.

Table 3-49. CIM_RemoteServiceAccessPointGroup Properties

Class Name:	CIM_RemoteServiceAccessPointGroup	
Parent Class:	CIM_ServiceAccessPointGroup	
Property	Description	Data Type
AccessInfo	Describes accessing or addressing of information for a remote connection. This can be a host name, network address, and other similar information.	string
InfoFormat	Indicates an enumerated integer describing the format and interpretation of the AccessInfo property. This property can have the following values: 1 - Other 2 - Host Name 3 - Ipv4 Address 4 - Ipv6 Address 5 - IPX Address 6 - DECnet Address 7 - SNA Address 8 - Autonomous System Number 9 - MPLS Label 10..99 - DMTF Reserved 100 - Dial String 101 - Ethernet Address 102 - Token Ring Address 103 - ATM Address 104 - Frame Relay Address 105..199 - DMTF Reserved 200 - URL 32768..65535 - Vendor Specific	uint16

DELL_RemoteServiceAccessPort



The `DELL_RemoteServiceAccessPortGroup` class described in Table 3-50 is an extended class of the `CIM_RemoteServiceAccessPointGroup` class. The `DELL_RemoteServiceAccessPortGroup` class provides information about Dell implementation-specific attributes.

Table 3-50. DELL_RemoteServiceAccessPortGroup Properties

Class Name:	<code>DELL_RemoteServiceAccessPortGroup</code>	
Parent Class:	<code>CIM_RemoteServiceAccessPointGroup</code>	
Property	Description	Data Type
PortName	Displays the name of the service access port.	string
VersionString	Indicates the version of the access point service.	string
RemoteAccessType	Indicated the type of remote access service. This property can have the following values: 0 - BMC 8 - IMC 9 - CMC 10 - iDRAC6 11 - iDRAC6 for modular systems 13 - BMC	uint16

DCIM_OEM_DataAccessModule

The `DCIM_OEM_DataAccessModule` class is derived from the `CIM_ManagedElement` class. This class models hardware information in a proprietary format.





Table 3-51. DCIM_OEM_DataAccessModule Properties

Class Name: <code>DCIM_OEM_DataAccessModule</code>		
Parent Class: <code>CIM_ManagedElement</code>		
Property	Description	Data Type
InstanceID	Identifies the instance.	string
GlobalStatus	Represents the global health status of the system. This property can have the following values: 0 - Other 1 - Unknown 2 - OK 3 - Warning / Non-Critical 4 - Critical 5 - Non-Recoverable .. - Reserved	sint32
SendCmd	The SendCmd method is used to invoke proprietary hardware management operation.	string

DCIM_RegisteredProfile



The `DCIM_RegisteredProfile` class is derived from the `CIM_RegisteredProfile` class. This class advertises the capabilities of `DCIM_OEM_DataAccessModule`.

Dell-Defined Classes

The Dell-defined classes are defined and populated by Dell rather than by CIM. None of these classes have a parent class and are on the same level as `CIM_ManagedSystemElement`. For information on how the logs are formatted, see Table 2-5.

Figure 4-1. Dell_EsmLog




The `DELL_EsmLog` class described in Table 4-1 records failure threshold violations collected by Server Administrator's embedded server management (ESM) capabilities.

Table 4-1. DELL_EsmLog Properties

Class Name:	DELL_EsmLog	
Parent Class:	None	
Property	Description	Data Type
recordNumber	Provides an index to the ESM table.	uint32
logRecord	Provides the ESM message content.	string
eventTime	Indicates the time that the message is generated.	datetime
status	Indicates the severity of the event that caused the log to be generated.	string

DELL_PostLog





The `DELL_PostLog` identified in Table 4-2 is a record of the system’s power-on self-test (POST). When you turn on a system, the POST tests various system components, such as random-access memory (RAM), the hard drives, and the keyboard.

Table 4-2. DELL_PostLog Properties

Class Name:	<code>DELL_PostLog</code>
Parent Class:	None

DELL_CMAApplication

 **NOTE:** Dell-updateable components, such as BIOS and firmware, are considered applications.




The `DELL_CMAApplication` class identified in Table 4-3 contains information related to the Dell change management applications.

Table 4-3. DELL_CMApplication Properties

Class Name:	DELL_CMApplication	
Parent Class:	None	
Property	Description	Data Type
componentType	Defines the application type	string
subComponentID	Defines an application string	string
version	Indicates the current version of the application	string
name	Indicates the name of the application	string
deviceKey	Indicates the device key of the application	string

DELL_CMDevice



The `DELL_CMDevice` identified in Table 4-4 contains information related to the Dell change management device.

Table 4-4. DELL_CMDevice Properties

Class Name:	DELL_CMDevice	
Parent Class:	None	
Property	Description	Data Type
componentID	Defines a component string	string
name	Indicates the name of the device	string
vendorID	Defines an ID for vendor supplying the device	string

Table 4-4. DELL_CMDevice Properties (continued)

Class Name:	DELL_CMDevice	
Parent Class:	None	
Property	Description	Data Type
subVendorID	Defines an ID for an additional vendor supplying the device	string
deviceID	Indicates the ID of the device	string
subDeviceID	Indicates the ID for additional device	string
bus	Indicates the PCI bus number	string
device	Indicates the PCI device number	string
function	Indicates the PCI Function number	string

DELL_CMDeviceApplication




The DELL_CMDeviceApplication class identified in Table 4-5 contains information related to the Dell change management association between the device and application.

Table 4-5. DELL_CMDeviceApplication Properties

Class Name:	DELL_CMDeviceApplication	
Parent Class:	None	
Property	Description	Data Type
antecedent	Refers to the device	string
dependent	Refers to the application	string

DELL_CMInventory




The DELL_CMInventory identified in Table 4-6 contains information related to the Dell Change Management inventory.

Table 4-6. DELL_CMInventory Properties

Class Name:	DELL_CMInventory	
Parent Class:	None	
Property	Description	Data Type
local	Indicates the locale of the system	string
schemaVersion	Indicates the Inventory schema implemented by the system	string
systemID	Defines the System ID	string

DELL_CMOS




The DELL_CMOS class identified in Table 4-7 contains information related to the Dell change management operating system.

Table 4-7. DELL_CMOS Properties

Class Name:	DELL_CMOS	
Parent Class:	None	
Property	Description	Data Type
architecture	Indicates the architecture of the operating system	string
vendor	Indicates the vendor of the operating system	string
majorVersion	Indicates the major version of the operating system	string
minorVersion	Indicates the minor version of the operating system	string
spMajorVersion	Indicates the current service pack number for the operating system's major version	string
spMinorVersion	Indicates the current service pack number for the operating system's minor version	string

DELL_CMProductInfo



The `DELL_CMProductInfo` identified in Table 4-8 contains information related to the Dell change management product.

Table 4-8. DELL_CMProductInfo Properties

Class Name:	DELL_CMProductInfo	
Parent Class:	None	
Property	Description	Data Type
name	Indicates the name of the product	string
description	Provides a short description of the product	string
vendor	Indicates the name of the product manufacturer	string
version	Indicates the current version number of the product	string

DELL_BIOSExtensions

The `DELL_BIOSExtensions` identified in Table 4-9 contains information related to the specific extension of the data attributes on your system.

Table 4-9. DELL_BIOSExtensions Properties

Class Name:	DELL_BIOSExtensions	
Parent Class:	CIM_ManagedSystemElement	
Property	Description	Data Type
systemBIOSCharacteristics	Indicates the characteristics of BIOS on your system	uint64
systemBIOSCharacteristicsExt1	Indicates the specific extension of the data attributes on your system	uint8
systemBIOSCharacteristicsExt2	Indicates the specific extension of the data attributes on your system	uint8

Management Object File For Change Management

This section shows the Management Object File (MOF) `invcim.mof`.

```
#pragma classflags("forceupdate")
#pragma namespace("\\\\.\\Root\\CIMV2")
[Locale(1033) : ToInstance]
Instance of __Namespace
{
    Name = "Dell";
};
#pragma namespace ("\\.\\Root\\CIMV2\\Dell")
//*****
//***Registers omprov Win32 Provider ***
//*****
instance of __Win32Provider as $P
{
    Name = "omprov";
    ClsId = "{EF6540AC-870F-445c-9401-10AAADB45CCF}";
    HostingModel = "NetworkServiceHost";
};
instance of __InstanceProviderRegistration
{
    Provider = $P;
    SupportsGet = "TRUE";
    SupportsPut = "FALSE";
    SupportsDelete = "FALSE";
```

```

        SupportsEnumeration = "TRUE";
};
instance of __MethodProviderRegistration
{
    Provider = $P;
};
//core.mof
//=====
// Using my own MOF instead of inheriting from existing MOFs, for rapid
// prototyping.
//=====
[Dynamic, Provider ("omprov"),
Description("The Dell_CMDevice class contains all the information
related to the Dell Change Management Device.")
]
class Dell_CMDevice
{
    [write (true), key: ToSubClass]
    string componentID;
    [write (true), key: ToSubClass]
    string name;
    [write (true), key: ToSubClass]
    string vendorID;
    [write (true), key: ToSubClass]
    string deviceID;
    [write (true), key: ToSubClass]
    string subDeviceID;
};

```

```

[write (true), key: ToSubClass]
string subVendorID;
[write (true), key: ToSubClass]
string bus;
[write (true), key: ToSubClass]
string device;
[write (true), key: ToSubClass]
string function;
};
[Dynamic, Provider ("omprov"),
Description("The Dell_CMInventory class contains all the information
related to the Dell Change Management Inventory.")
]
class Dell_CMInventory
{
[write (true), key: ToSubClass]
string local;
[write (true), key: ToSubClass]
string schemaVersion;
[write (true), key: ToSubClass]
string systemID;
};
[Dynamic, Provider ("omprov"),
Description("The Dell_CMProductInfo class contains all the
information related to the Dell Change Management Product.")
]
class Dell_CMProductInfo

```



```

{
  [write (true), key: ToSubClass]
  string name;
  [write (true), key: ToSubClass]
  string description;
  [write (true), key: ToSubClass]
  string vendor;
  [write (true), key: ToSubClass]
  string version;
};

[Dynamic, Provider ("omprov"),
Description("The Dell_CMOS class contains all the information related to
the Dell Change Management operating system.")
]
class Dell_CMOS
{
  [write (true), key: ToSubClass]
  string vendor;
  [write (true), key: ToSubClass]
  string majorVersion;
  [write (true), key: ToSubClass]
  string minorVersion;
  [write (true), key: ToSubClass]
  string spMajorVersion;
  [write (true), key: ToSubClass]
  string spMinorVersion;
  [write (true), key: ToSubClass]
  string architecture;
}

```

```

};
[Dynamic, Provider ("omprov"),
Description("The Dell_CMApplication class contains all the
information related to the Dell Change Management Application.")
]
class Dell_CMApplication
{
[write (true), key: ToSubClass]
string componentType;
[write (true), key: ToSubClass]
string subComponentID;
[write (true), key: ToSubClass]
string version;
[write (true), key: ToSubClass]
string name;
[write (true), key: ToSubClass]
string deviceKey;
};
[Association, Dynamic, Provider ("omprov"),
Description("The Dell_CMDeviceApplication class contains all the
information related to the Dell Change Management association between the
device and the application (1:n).")
]
class Dell_CMDeviceApplication
{
    [key, Override ("Antecedent"),
    Description ("The Device.")
]
}

```

```

Dell_CMDevice REF Antecedent;
    [key, Override ("Dependent"),
     Description ("The Application")
    ]
Dell_CMApplication REF Dependent;
};
// =====
// end of file
// =====

```

Classes for Power Management

The new classes introduced for power management are:

```

// =====
// DELL_PowerConsumptionAmpsSensor
// =====
[Dynamic, Provider ("dccim32"),
Description (
    "Monitors the power consumption")
]
class DELL_PowerConsumptionAmpsSensor :
CIM_NumericSensor
{
    [Override("SensorType") ]
uint16 SensorType = 4;

    [Override("BaseUnits") ]
uint16 BaseUnits = 6;
}

```

```

        [Override("UnitModifier") ]
sint32 UnitModifier = -1;

        [Override("RateUnits") ]
uint16 RateUnits = 0;

        [Override ("CurrentReading"),
// Override is used to define the MappingString
qualifier
        MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.5"}
        ]
sint32 CurrentReading;

        [Override ("NominalReading"),
        MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.6"}
        ]
sint32 NominalReading;

        [Override ("NormalMax"),
        MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.7"}
        ]
sint32 NormalMax;

```

```
        [Override ("NormalMin"),
          MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.8"}
        ]
sint32 NormalMin;
```

```
        [Override ("MaxReadable"),
          MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.9"}
        ]
sint32 MaxReadable;
```

```
        [Override ("MinReadable"),
          MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.10"}
        ]
sint32 MinReadable;
```

```
        [Override ("Resolution"),
          Units ("Tenths of MilliAmps"),
          MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.17"}
        ]
uint32 Resolution;
```

```
        [Override ("Tolerance"),
          MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.18"}
        ]
```

```

    ]
sint32 Tolerance;

    [Override ("Accuracy"),
    MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.19"}
    ]
sint32 Accuracy;

    [read, write,MappingStrings
{"MIF.DMTF|Electrical Current Probe|001.11"}
    ]
sint32 LowerThresholdNonCritical;

    [read, write,MappingStrings
{"MIF.DMTF|Electrical Current Probe|001.12"}
    ]
sint32 UpperThresholdNonCritical;

    [read,MappingStrings {"MIF.DMTF|Electrical
Current Probe|001.13"}
    ]
sint32 LowerThresholdCritical;

    [Override ("UpperThresholdCritical"),
    MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.14"}
    ]

```

```

sint32 UpperThresholdCritical;

    [Override ("LowerThresholdFatal"),
     MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.15"}
    ]
sint32 LowerThresholdFatal;

    [Override ("UpperThresholdFatal"),
     MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.16"}
    ]
sint32 UpperThresholdFatal;
};

// =====
// DELL_PowerConsumptionWattsSensor
// =====
[Dynamic, Provider ("dccim32"),
Description (
    "Monitors the power consumption")
]
class DELL_PowerConsumptionWattsSensor :
CIM_NumericSensor
{
    [Override ("SensorType") ]
uint16 SensorType = 4;

```

```

        [Override("BaseUnits") ]
uint16 BaseUnits = 7;

        [Override("UnitModifier") ]
sint32 UnitModifier = 0;

        [Override("RateUnits") ]
uint16 RateUnits = 0;

        [Override ("CurrentReading"),
// Override is used to define the MappingString
qualifier
        MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.5"}
        ]
sint32 CurrentReading;

        [Override ("NominalReading"),
        MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.6"}
        ]
sint32 NominalReading;

        [Override ("NormalMax"),
        MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.7"}

```



```

    ]
sint32 NormalMax;

    [Override ("NormalMin"),
    MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.8"}
    ]
sint32 NormalMin;

    [Override ("MaxReadable"),
    MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.9"}
    ]
sint32 MaxReadable;

    [Override ("MinReadable"),
    MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.10"}
    ]
sint32 MinReadable;

    [Override ("Resolution"),
    Units ("Tenths of MilliAmps"),
    MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.17"}
    ]
uint32 Resolution;

```

```
        [Override ("Tolerance"),
          MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.18"}
        ]
sint32 Tolerance;
```

```
        [Override ("Accuracy"),
          MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.19"}
        ]
sint32 Accuracy;
```

```
        [read, write, MappingStrings
{"MIF.DMTF|Electrical Current Probe|001.11"}
        ]
sint32 LowerThresholdNonCritical;
```

```
        [read, write, MappingStrings
{"MIF.DMTF|Electrical Current Probe|001.12"}
        ]
sint32 UpperThresholdNonCritical;
```

```
        [read, MappingStrings {"MIF.DMTF|Electrical
Current Probe|001.13"}
        ]
sint32 LowerThresholdCritical;
```

```

        [Override ("UpperThresholdCritical"),
          MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.14"}
        ]
sint32 UpperThresholdCritical;

        [Override ("LowerThresholdFatal"),
          MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.15"}
        ]
sint32 LowerThresholdFatal;

        [Override ("UpperThresholdFatal"),
          MappingStrings {"MIF.DMTF|Electrical Current
Probe|001.16"}
        ]
sint32 UpperThresholdFatal;
};

// =====
// DELL_PowerConsumptionData
// =====

[Dynamic, Provider ("dccim32"), Description (
"Dell Power Consumption Data includes, but is not
limited to Cumulative power consumption from a start
time, and peak values registered during a time period.
")
]

```

```

class DELL_PowerConsumptionData : CIM_LogicalDevice
{
[Description (
    "total power consumed from a start time")
]
uint32 cumulativePowerReading;

[Description (
    "The time from which the power reading is
accumulated")
]
datetime cprStartTime;

[Description (
    "Peak amperage reading")
]
uint16 peakAmpReading;

[Description (
    "The time from which the peak amp reading is being
monitored")
]
datetime parStartTime;

[Description (
    "The time of the peak amp reading")
]

```

```

datetime parTime;

[Description (
    "Peak wattage reading")
]
uint16 peakWattReading;

[Description (
    "The time from which the peak watt reading is
being monitored")
]
datetime pwrStartTime;

[Description (
    "The time of the peak watt reading")
]
datetime pwrTime;

[Description (
    "function to be used to reset the peak readings")
]
uint32 ResetCounters([IN]sint32 counter);
};
uint16 powerCapCapabilities;

[Description (

```

```

        "User configured power setting")
    ]
uint16 powerCapSetting;

[Description (
    "Instantaneous headroom")
]
uint32 instHeadRoom;

[Description (
    "Peak headroom")
]
uint32 peakHeadRoom;

[Description (
    "function to be used to set the power budget")
]
// =====
// DELL_AssociatedSupplyPCamps
// =====
[Association,
    Description (
        "A PowerConsumptionAmpsSensor associated with a
        CIM_PowerSupply which is defined by this class.")
    ]
class DELL_AssociatedSupplyPCamps : CIM_Dependency

```

```

{
    [Override ("Antecedent"),
        Description ("The PowerSupply instance.")
    ]
CIM_PowerSupply REF Antecedent;

    [Override ("Dependent"),
        Description (
            "The PowerConsumptionAmpsSensor associated with the
            CIM_PowerSupply.")
        ]
DELL_PowerConsumptionAmpsSensor REF Dependent;
};

// =====
// DELL_AssociatedSystemPCWatts
// =====
[Association,
    Description (
        "A PowerConsumptionWattsSensor associated with
        a DELL_System which is defined by this class.")
    ]
class DELL_AssociatedSystemPCWatts: CIM_Dependency
{
    [Override ("Antecedent"),
        Description ("The DELL_System instance.")
    ]

```

```

DELL_System REF Antecedent;

    [Override ("Dependent"),
      Description (
        "The PowerConsumptionWattsSensor associated with the
        system.")
    ]
DELL_PowerConsumptionWattsSensor REF Dependent;
};

```

```

// =====
// AssociatedSystemPCData
// =====
[Association,
Description (
    "A PowerConsumptionData associated with a
    DELL_System which is defined by this class.")
]
class DELL_AssociatedSystemPCData: CIM_Dependency
{
    [Override ("Antecedent"),
      Description ("The DELL_System instance.")
    ]
DELL_System REF Antecedent;

```

```

    [Override ("Dependent"),
      Description (

```



```

    "The PowerConsumptionData associated with the
    PowerSupply.")
    ]
DELL_PowerConsumptionData REF Dependent;
};

// =====
//     DELL_BIOSSettings
// =====
[Dynamic, Provider("dccim32"): ToInstance,
Description (
    "This class defines properties used for setting
    parameters in the DellSystem Management BIOS."),
DisplayName("BIOS Settings")]
class DELL_BIOSSettings : CIM_ManagedSystemElement
{
    [key, read, Description(
        "This property defines the instance ID of this
        class."),
    DisplayName("Dell Instance ID")]
        uint32 DellInstanceID;

    [read, Description (
        "Enables or Disables the Trusted Platform Module
        (TPM)."),
    DisplayName("TPM Security"),
    ValueMap{"0", "1", "2", "3", "4"},
    Values{"Other", "Unsupported", "Off", "On with BIOS
    Measurement",
        "On without BIOS Measurement" }]

```

```

uint8 TrustedPlatformModule;
};
// =====
// DELL_SDCardDevice
// =====
[Dynamic, Provider("dccim32"): ToInstance,
Description (
"This class defines the management SD card devices,
and relative info.")]
class DELL_SDCardDevice : CIM_LogicalDevice
{
[Description ("The enumeration of storage device
type"),
ValueMap {"1", "2", "3", "4"},
Values {"Other", "Unknown", "Hypervisor SD",
"Virtual Flash SD"}]
uint8 sdType;

[Description ("The licensing info of SD media"),
ValueMap {"0", "1", "2"},
Values {"Unknown", "Unlicensed", "Licensed"}]
uint8 sdCertified;

[Description ("Boolean value to determine the SD
device presence or not")]
boolean isSDCardPresent;

```

```

[Description ("Size of storage device, in MB")]
uint32 sdCardSizeMB;

[Description ("Available size of SD media, in MB")]
uint32 sdCardFreeSizeMB;

[Description ("state value of SD card, bit 0 for
present, bit 1 "
"and 2 reserved, bit 3 for offline detected, bit 4 for
"
"failed detected, bit 5 for active, bit 6 for
bootable, "
"and bit 7 for write protected. Rest of the bits
reserved.") ]
uint32 sdCardState;
};

// =====
DELL_PowerProfileData
// =====
[Dynamic, Provider("dccim32"): ToInstance,
Description (
"This class defines the power profiling and power knob
data.")
]
class DELL_PowerProfileData : CIM_LogicalDevice
{
[Description ("Chassis index for this power profile")]

```

```
uint8 chassisIndex;
```

```
[Description ("Supported profiles")]
```

```
uint16 supportedProfile;
```

```
[Description ("Profile setting")]
```

```
uint16 profileSetting;
```

```
[Description ("Custom Profile CPU management  
capability")]
```

```
uint16 customCPUCaps;
```

```
[Description ("Custom Profile CPU management  
setting")]
```

```
uint16 customCPUSettings;
```

```
[Description ("Custom Profile memory management  
capability")]
```

```
uint16 customMemCaps;
```

```
[Description ("Custom Profile memory management  
setting")]
```

```
uint16 customMemSettings;
```

```
[Description ("Custom Profile fan management  
capability")]
```


```
uint16 customFanCaps;
```

```
[Description ("Custom Profile fan management  
setting")]  
uint16 customFanSettings;  
};
```


CIM_Dependency

The `CIM_Dependency` class is an association used to establish dependency relationships between two managed system elements. `CIM_Dependency` shown in Figure 5-1 does not have a parent class because it is a relationship or association between two elements.

Figure 5-1. CIM_Dependency Class Structure



Each class derived from `CIM_Dependency` has an element called an antecedent that represents the independent object in this association, and another element called a dependent that represents the object that is dependent on the antecedent. For example, consider two managed system elements: `Chassis1` and `PowerSupply3`. `Chassis1` is the antecedent element because a managed power supply would always be either contained in, or grouped with, a chassis.

DELL_FanSensor




The `DELL_FanSensor` class described in Table 5-1 defines a Dell-specific association between a fan and a sensor. The `CIM_PackageFanSensor` class contains fans that assist in cooling the entire package as opposed to a fan dedicated to cooling only some of the components in the package.

Table 5-1. DELL_FanSensor Properties

Class Name:	DELL_FanSensor
Parent Class:	CIM_Dependency
Element	Description
Antecedent	CIM_Tachometer refers to the tachometer (fan sensor) that measures the RPM of the fan.
Dependent	CIM_Fan refers to the fan whose revolutions are measured by the tachometer.

CIM_PackageTempSensor




The `CIM_PackageTempSensor` class listed in Table 5-2 contains temperature sensors that are often installed in a package such as a chassis or a rack to assist in the monitoring of the package in general. This relationship is described by the `CIM_PackageTempSensor` association.

Table 5-2. CIM_PackageTempSensor Properties

Class Name:	CIM_PackageTempSensor
Parent Class:	CIM_Dependency
Element	Description
Antecedent	CIM_TempSensor refers to the temperature sensor for the package.
Dependent	CIM_PhysicalPackage refers to the physical package whose environment is being monitored.

CIM_PackageVoltSensor




The `CIM_PackageVoltSensor` identified in Table 5-3 contains voltage sensors that are often installed in a package such as a chassis or a rack to assist in the monitoring of the package in general. This relationship is described by the `CIM_PackageVoltSensor` association.

Table 5-3. CIM_PackageVoltage Properties

Class Name:	CIM_PackageVoltSensor
Parent Class:	CIM_Dependency
Element	Description
Antecedent	CIM_PackageVoltSensor refers to the voltage sensor for the package.
Dependent	CIM_PhysicalPackage refers to the physical package whose voltages are being monitored.

CIM_PackageCurrentSensor



The `CIM_PackageCurrentSensor` shown in Table 5-4 contains amperage sensors that are often installed in a package such as a chassis or a rack to assist in the monitoring of the package in general. This relationship is described by the `CIM_PackageCurrentSensor` association.

Table 5-4. CIM_PackageCurrentSensor Properties

Class Name:	<code>CIM_PackageCurrentSensor</code>
Parent Class:	<code>CIM_Dependency</code>
Element	Description
Antecedent	<code>CIM_CurrentSensor</code> refers to the amperage sensor for the package.
Dependent	<code>CIM_PhysicalPackage</code> refers to the physical package whose amperage is being monitored.

CIM_PackageFanSensor



The `CIM_PackageFanSensor` class described in Table 5-5 contains fan sensors that monitor the whole package.

Table 5-5. CIM_PackageFanSensor Properties

Class Name:	CIM_PackageFanSensor
Parent Class:	CIM_Dependency
Element	Description
Antecedent	CIM_Fan refers to the cooling device for the package.
Dependent	CIM_PhysicalPackage refers to the physical package whose environment is being monitored.

CIM_PackagePowerSupplySensor




The CIM_PackagePowerSupplySensor class described in Table 5-6 contains power supplies that provide power to the whole package.

Table 5-6. CIM_PackagePowerSupplySensor Properties

Class Name:	CIM_PackagePowerSupplySensor
Parent Class:	CIM_Dependency
Element	Description
Antecedent	CIM_PowerSupplySensor refers to the power supply sensor that monitors wattage for the entire package.
Dependent	CIM_PhysicalPackage refers to the package whose wattage is being monitored.

DELL_PackagePSRedundancy



The DELL_PackagePSRedundancy class listed in Table 5-7 defines what constitutes power supply redundancy for an entire package.

Table 5-7. DELL_PackagePSRedundancy Properties

Class Name:	DELL_PackagePSRedundancy
Parent Class:	CIM_Dependency
Element	Description
Antecedent	DELL_PSRedundancyGroup refers to power supplies that deliver wattage for the entire package.
Dependent	CIM_PhysicalPackage refers to the package to which the wattage is being supplied.

DELL_PSRedundancy



The DELL_PSRedundancy class shown in Table 5-8 defines what constitutes power supply redundancy for Dell systems.

Table 5-8. DELL_PSRedundancy Properties

Class Name:	DELL_PSRedundancy
Parent Class:	CIM_Dependency
Element	Description
Antecedent	CIM_PowerSupplySensor refers to the power supply sensor that monitors wattage for the entire package.
Dependent	CIM_PhysicalPackage refers to the package whose wattage is being monitored.

Index

C

CIM classes and properties, 10
 base classes, 11
 classes that describe
 relationships, 12
 common properties of classes, 12
 conventions, 12
 parent classes, 12

CIM_Chip, 24

CIM_Dependency

 CIM_PackageCurrentSensor, 138

 CIM_PackageFanSensor, 138

 CIM_PackagePowerSupplySensor,
 139

 CIM_PackageTempSensor, 136

 CIM_PackageVoltSensor, 137

 DELL_FanSensor, 136

 DELL_PackagePSRedundancy, 1
 40

 DELL_PSRedundancy, 140

CIM_LogicalElement

 CIM_BIOSElement, 83

 CIM_CacheMemory, 81

 CIM_ComputerSystem, 38

 CIM_Controller, 64

 CIM_CoolingDevice, 57

 CIM_CurrentSensor, 53

 CIM_DiscreteSensor, 49

 CIM_DMA, 92

 CIM_ExtraCapacityGroup, 94

 CIM_Fan, 58

 CIM_FRU, 40

 CIM_IRQ, 89

 CIM_Keyboard, 61

 CIM_LogicalDevice, 39

 CIM_LogicalPort, 41

 CIM_Memory, 81

 CIM_MemoryMappedIO, 91

 CIM_NumericSensor, 49

 CIM_ParallelController, 65

 CIM_PCIBridge, 69

 CIM_PCIBridge, 67

 CIM_PointingDevice, 59

 CIM_PowerSupply, 62

 CIM_Processor, 70

 CIM_RedundancyGroup, 93

 CIM_Sensor, 40, 47

 CIM_SerialController, 66

 CIM_SoftwareElement, 83

 CIM_SoftwareFeature, 87-88

 CIM_System, 37

 CIM_SystemResource, 88

 CIM_Tachometer, 55

 CIM_TemperatureSensor, 52

 CIM_UserDevice, 59

 CIM_VoltageSensor, 54

 CIM_Watchdog, 56

 DELL_FanExtraCapacityGroup,
 96

 DELL_NetworkPort, 43

 DELL_PSRedundancyGroup, 95

 DELL_System, 38

- CIM_PhysicalComponent, 24
- CIM_PhysicalElement
 - CIM_PhysicalConnector, 28
 - CIM_PhysicalMemory, 26
- CIM_PhysicalElement, 17
 - CIM_Chassis, 21
 - CIM_Chip, 24
 - CIM_PhysicalComponent, 24
 - CIM_PhysicalFrame, 20
 - CIM_PhysicalPackage, 19
 - CIM_Slot, 31
 - DELL_Chassis, 22
 - structure of, 17
- CIM_PhysicalElementClass
 - structure of, 17
- CIM_SoftwareElement, 83
 - class name, 16
 - common properties of classes, 12
 - current reading, 13

D

- data type, 16
- DCIM_OEM_DataAccessModule, 100
- DCIM_RegisteredProfile, 101
- Dell OpenManage Server Agent, 9
- DELL_CMAApplication, 104
- DELL_CMDevice, 105

- DELL_CMDeviceApplication, 106
- DELL_CMInventory, 107
- DELL_CMOS, 107
- DELL_CMProductInfo, 108
- DELL_EsmLog, 103
- DELL_ManagedSystemServices Device, 43
- DELL_PostLog, 104
- DELL_PSRRedundancy, 140
- description, 16

P

- parent class, 16
- property, 16

S

- Server Administrator 1.0, 9

V

- version, 15