

Dell OpenManage Server Update Utility
Version 14.07.00



Notes, Cautions, and Warnings

 **NOTE:** A NOTE indicates important information that helps you make better use of your computer.

 **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

Copyright © 2014 Dell Inc. All rights reserved. This product is protected by U.S. and international copyright and intellectual property laws. Dell™ and the Dell logo are trademarks of Dell Inc. in the United States and/or other jurisdictions. All other marks and names mentioned herein may be trademarks of their respective companies.

2014 - 07

Rev. A00

Contents

1 About Dell OpenManage Server Update Utility.....	5
Key Features and Functionalities.....	5
What's New in This Release.....	6
Supported Operating Systems.....	6
Accessing Documents From Dell Support Site.....	6
2 About Graphical User Interface Mode.....	8
Launching SUU in a GUI Mode.....	8
Prerequisite Failure Messages.....	8
Software Prerequisite Failure MessageHardware Prerequisite Failure MessageSoftware and Hardware Prerequisite Failure Message.....	8
Fixing the Software Prerequisite Failure.....	9
Fixing the Hardware Prerequisite Failure.....	9
Creating a Prerequisites Media.....	9
Comparison Report.....	10
Criticality Levels.....	10
Comparison Report Features.....	11
Upgrading System Components.....	12
Downgrading System Components.....	12
Updating System Components.....	12
Updating Failures.....	13
3 About Command Line Interface Mode.....	14
Launching SUU in a CLI Mode.....	14
List of CLI Commands.....	14
4 Integrating Server Update Utility With Other Components.....	16
Integrating SUU With OpenManage Essentials.....	16
Selecting a Catalog Source Using SUU.....	16
Creating A Custom SUU Using Dell Repository Manager.....	16
Exporting as a SUU.....	17
5 Known Issues and Frequently Asked Questions.....	19
Known Issues.....	19
Timeout due to USB Arbitration Service.....	19
Inventory Failure on Microsoft Windows Small Business Server 2008 Operating System.....	19
DUP Fails on 64-bit Red Hat Enterprise Linux Operating System.....	20
Enabling Operating System Devices.....	20


Linux Systems Require the libstdc++-libc6.2-2.so.5 and libstdc++- libc6.2-2.so.3 Library to run SUU.....	20
Running Linux Updates.....	20
Running SUU With the Progress Option.....	20
Updating Multiple Devices.....	20
Updating PERC Firmware.....	21
Restarting the System Inventory in the Same Session.....	21
Running SUU Over a Network.....	21
Deleting the Temporary Folder.....	21
Updating the H661 Firmware.....	21
Using the Remote Access Controller Virtual Media.....	22
Using Special Characters in the SUU Directory Name.....	22
Running RAC DUP Packages.....	22
Frequently Asked Questions.....	22
Why do I get a pop-up dialog box saying, "There is no disk in the drive. Please insert a disk into drive"?	22
When I run suu -c on a Linux system, I get an error saying, "Problem executing Inventory Collector." What causes this error and how can I fix it?.....	22
Why do get a pop-up box titled "Unsafe Removal of Device"?	22
When using the SUU GUI to perform an update, a message is displayed asking me to see the User's Guide for information on possible causes of why a server object is not displayed in the tree.....	22
When I run SUU, I do not see the Comparison Report? and I cannot update the system?.....	23
Why do I get a message saying, "Inventory operation exceeded specified time-out" when I try to run a Dell Update Package and SUU concurrently?.....	23
I cannot start SUU. The "Another instance of SUU is already running" message is displayed even though no other instances of SUU is running on the system.....	23
I cannot start Server Administrator after updating using SUU.....	23
I cannot update BIOS versions using SUU.....	23
I cannot run SUU, the "SUU Logging System has failed: There is not enough space on the disk" message is displayed.....	23

About Dell OpenManage Server Update Utility

Dell OpenManage Server Update Utility (SUU) is a DVD-based application for identifying and applying updates to the system.

You can use SUU to update the Dell PowerEdge system or to view the updates available for systems supported by SUU. SUU compares the versions of components currently installed on the system with the versions of the components packaged on the *Dell PowerEdge Server Update Utility* media.

SUU displays a comparison report of the versions and provides various options for updating the components.

 **NOTE:** Only users with administrator (Microsoft Windows) or root (Linux) privileges can perform updates using SUU.

Key Features and Functionalities

This section describes key features and functionalities of Dell OpenManage Server Update Utility (SUU).

Table 1. Features and Functionalities

Feature	Description
Prerequisite Failure Messages	List of error messages displayed when the prerequisite conditions are not met. For more information, see Prerequisite Failure Messages .
Fixing Prerequisite Failures	Allows you to fix the hardware or software prerequisite failures. For more information, see Fixing the Software Prerequisite Failure and Fixing the Hardware Prerequisite Failure .
Comparison Report	Displays a list of component versions installed on the system that do not match the versions on the repository. For more information, see Comparison Report .
Upgrading or Downgrading or Updating System Components	Allows you to upgrade, downgrade, or update the system components if the versions vary from the repository version. For more information, see Upgrading System Components , Downgrading System Components , and Updating System Component .
Launching SUU in a GUI mode or from Network Location	Enables you to run SUU, upgrade, downgrade, update components on multiple systems. For more information, see Launching SUU in a GUI mode or from a Network Location .

Feature	Description
CLI Commands	Displays the list of commands to perform comparisons and updates in the CLI mode. For more information, see List of CLI Command .
Dependency	Feature which provides information about the available updates for a device. SUU enables certain tools and applications to determine if a set of conditions or requirements are met. These conditions or requirements are called dependencies. Following are the types of dependency: Pre-requisites and Co-requisites. For more information, see Comparison Report .

What's New in This Release

SUU supports Dell PowerEdge R920 and R220.

Supported Operating Systems

For Windows:

- Microsoft Windows Server 2012 R2
- Microsoft Windows Server 2012, Essentials, Enterprise, Datacenter, and Foundation x64 editions
- Microsoft Windows Server 2008 R2 Foundation, Standard, Enterprise, and Datacenter editions with SP1
- Microsoft Windows Server 2008 SP2 Foundation, Standard, Enterprise, Datacenter and Web x86 (64-bit) editions with SP2

For Linux:

- SUSE Linux Enterprise Server 11 SP3 (64-bit)
- Red Hat Enterprise Linux 5 update 9 (32 and 64-bit)
- Red Hat Enterprise Linux 6 update 5 (64-bit)
- VMware ESX 4.1 U3
- Citrix XenServer 6.2

For detailed information on various Dell systems and operating systems on which SUU is supported, see the *Dell Systems Software Support Matrix* at dell.com/openmanagemanuals.

Accessing Documents From Dell Support Site

You can access the required documents in one of the following ways:

- Using the following links:
 - For all Systems Management documents — dell.com/softwaresecuritymanuals
 - For Remote Enterprise Systems Management documents — dell.com/esmmanuals
 - For Enterprise Systems Management documents — dell.com/openmanagemanuals
 - For Client Systems Management documents — dell.com/OMConnectionsClient
 - For Serviceability Tools documents — dell.com/serviceabilitytools
 - For OpenManage Connections Enterprise Systems Management documents — dell.com/OMConnectionsEnterpriseSystemsManagement

- For OpenManage Connections Client Systems Management documents — dell.com/OMConnectionsClient
- From the Dell Support site:
 - a. Go to dell.com/support/manuals.
 - b. Under **General support** section, click **Software & Security**.
 - c. In the **Software & Security** group box, click the required link from the following:
 - **Serviceability Tools**
 - **Enterprise System Management**
 - **Client System Management**
 - **Remote Enterprise System Management**
 - d. To view a document, click the required product version.
- Using search engines:
 - Type the name and version of the document in the **Search** box.

About Graphical User Interface Mode



The Graphical User Interface (GUI) provides an interactive approach to perform comparisons and updates.

You can use the GUI to:

- View the system comparison report, which displays the system inventoried device versions, applicable Dell update package (DUP) versions, and the devices that require an update.
- Perform an upgrade, downgrade, or a system set update.
- Browse the repository to view the supported components of all the platforms in the SUU DVD.

Launching SUU in a GUI Mode

You can run SUU from a network location or from the location where the SUU DVD is mounted. To update components on multiple systems:

1. Access the system on the network on which SUU is installed or choose the path where the DVD is mounted.
2. To launch the SUU GUI, double-click the **suulauncher.exe** file.
The components that need to be updated are displayed in the **Comparison Report**.
 **NOTE:** The **suulauncher.exe** file is applicable only for systems running Windows.
3. Click **Update**, **Upgrade**, or **Downgrade**.
 **NOTE:** To update all the components in a single session, select **Enable System Set Update** before clicking **Update**
4. Click **Yes** to continue or **No** to cancel.
If you click **Yes**, SUU displays the **Update** dialog box that displays the progress of the update, upgrade, or downgrade.
5. Click **OK** when the update, upgrade, or downgrade is complete.
The updates are reflected in the **Comparison Report**.

Prerequisite Failure Messages

The failure messages and their respective fixes displayed as follows:

Software Prerequisite Failure Message

Prerequisite Failure Message:

Your system does not meet the required prerequisites for installing the Dell OpenManage software component. Therefore, the row for the software component is

disabled in the Comparison Report. Click Continue to update the applicable hardware components.

Hardware Prerequisite Failure Message

Prerequisite Failure Message:

Your system does not meet the required prerequisites for some of the hardware component(s). Therefore, all the rows for the hardware component(s) are disabled in the Comparison Report. Click Continue to update the applicable Dell OpenManage software component.

Software and Hardware Prerequisite Failure Message

Prerequisite Failure Message:

Your system does not meet the required prerequisites for some of the hardware component(s) and for installing the Dell OpenManage software component. Therefore, all the rows will be disabled in the Comparison Report.

Fixing the Software Prerequisite Failure



When you launch Dell OpenManage Server Update Utility (SUU) in the GUI mode and the prerequisite check fails, perform the following:

1. Install the Dell OpenManage SUU version 7.0 or later.
2. Proceed with the [Upgrade](#), [Downgrade](#), or [Update](#) of the components.

Fixing the Hardware Prerequisite Failure

When you launch Dell OpenManage Server Update Utility (SUU) in the GUI mode and the prerequisites check for the hardware component fails, install the hardware prerequisites before proceeding with the upgrade, downgrade, or update of the components. Dell DUP HDD firmware update utility, related to system memory utilization, requires minimum of 8GB to 16GB RAM in the server.

To install the hardware prerequisites:

1. Use the Prerequisites media to bring the system up to meet the prerequisite levels.
 -  **NOTE:** Set the boot order in the system BIOS such that the media drive is placed ahead of the system hard-drive.
2. If the system fails to meet the prerequisites, restart the system with the Prerequisites media.
 -  **NOTE:** An additional restart may be required to complete the prerequisite update. Do not remove the media until the information on the screen prompts you to do so.
3. When prompted, replace the Prerequisites media with the Dell Server Updates media and restart the system.

Creating a Prerequisites Media


To create the Prerequisites media:

1. Go to dell.com/support.
2. Under **Support**.
 - a. Under the **Choose by Service Tag** section, click **Enter a Service Tag**.

3. Click **Drivers & Downloads**.
4. From the **Select the Product Family** list, select **Servers, Storage, Networking**.
5. From the **Select the Product Line** list, select **PowerEdge Server**.
6. From the **Select the Product Model** list, select the PowerEdge system, and click **Confirm**.
7. From the **Operating System** and **Driver Language** drop-down lists, select the appropriate operating system and language for the system.
8. From the **Category** drop-down list, select **Systems Management**.
9. From the table of results displayed, click **CD ISO - PowerEdge Updates Prerequisites v1.0** in the **File Title(s)** column.
10. Click **Download Now** to save the **PE Updates prereq cd.iso** file on the system. Copy this file to a system that has a media-burning program and create a bootable media from the provided .iso file. This bootable media is the Prerequisites media.

Comparison Report

SUU compares the version of the component installed on the system with the versions available in the repository and displays the results in a **Comparison Report**. The following are the fields that are displayed in the **Comparison Report**:

- **Select** — Select a component.
 - **Status** — Displays the status as icons, where each of the icons represents different status: upgrade, downgrade, only pre-requisites update, both pre-requisites and co-requisites updates, only co-requisites.
 - **Criticality** — Denotes the importance of the update.
 - **Package Name** — Displays the package name from the inventory.
 - **Component** — Displays the name of the component.
 - **Type** — Displays the type of devices listed from the inventory.
 - **Current version** — Displays the current version of the systems.
 - **Latest version** — Displays the latest available version to be updated in the repository.
 - **Pre-requisites** — Displays the list of pre-requisites that must be applied.
 - **Co-requisites** — Displays the list of co-requisites to be applied for the device, which are optional.
-  **NOTE:** If you select the **Apply Corequisites** check box, then the listed co-requisites are applied.

Criticality Levels

The **Criticality** column in the **Comparison Report** denotes the importance of applying the update. For more information on the criticality levels and their corresponding status, see the table below.

Table 2. Criticality Levels



Criticality Level	Status
Urgent	The update contains changes to improve the reliability and availability of the Dell system.

Criticality Level	Status
	It is recommended that you apply this update immediately.
Recommended	The update contains feature enhancements or changes that keeps the system software current and compatible with other system modules (firmware, BIOS, drivers, and application). It is recommended that you apply this update during the next scheduled update cycle.
Optional	The update contains changes that impact only certain configurations, or provides new features that may/may not apply to the environment. It is recommended that you review the update specifications to determine if it applies to the system.
Inapplicable	The update is not applicable on the system. The component version on the system is the same as the repository version and hence, no update is required.

Comparison Report Features

You can view, sort or export the **Comparison Report**.

Table 3. Comparison Report Features

Tasks	Action
Viewing Report	To view the report, in the left pane, click the system's host name.
Sorting Columns	To sort columns, click the column names.  NOTE: The columns are sorted in the ascending or descending order.
Exporting Report	To export the report, click Export Report .  NOTE: You can save the report in a .csv, .html, or .xml format on the system. For systems running Windows operating system, make sure the name of the report or the path does not exceed 260 characters. For systems running Linux operating system, make sure the name of the report does not exceed 255 characters or the path does not exceed 4096 characters.


Upgrading System Components

SUU compares the version of the components installed on the system with the versions available in the repository. If the system component versions are earlier than the repository version, SUU enables the **Upgrade** button on the upper right corner of the **Comparison Report**.

To upgrade the repository components:

1. Select the components that you want to upgrade.
2. Click **Upgrade** to apply the components that you have selected.
3. In the **Confirm Update** dialog box, click **Yes** to confirm and continue or **No** to cancel.
While upgrading the components, SUU displays an update report. After completion, SUU displays an **Update Complete** dialog box.
4. Click **OK**.

The status of the upgrade is reflected in the Comparison Report.

 **NOTE:** When you perform an upgrade, SUU copies all the update packages into a temporary directory on the system: <%systemdrive%>:\dell\suu , on systems running Microsoft Windows operating system and /var/log/dell/suu , on systems running Linux operating systems. SUU deletes this temporary directory after the upgrade process is complete. If a restart is required to complete the upgrade process, the directory is saved until the restart process is complete.

 **CAUTION:** Do not remove the Dell Server Updates DVD from the DVD drive when you are running SUU.

Downgrading System Components

SUU compares the components installed on the system with the component versions available in the repository. If the system component versions later than the repository versions, SUU enables the **Enable Downgrade** button on the upper right corner of the Comparison Report.

To downgrade the repository components:

1. Select **Enable Downgrade**.
SUU disables **Enable System Set Update** and selects only those component versions that are later than the repository version to downgrade.
2. Select **Downgrade**. All downgradeable components are automatically selected.
3. In the **Confirm Update** dialog box, click **Yes** to confirm and continue or **No** to cancel.
While downgrading the components, SUU displays an update report. After completion, SUU displays an **Update Complete** dialog box.
4. Click **OK**.
The status of the downgrade is reflected in the **Comparison Report**.

Updating System Components


SUU compares the version of the components installed on the system with the versions available in the repository. If system component versions are later than the repository version and vice versa, SUU enables the **Update** button on the upper right corner of the Comparison Report.

To upgrade and downgrade components in a single session:

1. Select **Enable System Set Update**.
SUU disables **Enable Downgrade** and **Upgrade changes to Update**. All the components that can be updated are selected in the Comparison Report.
2. Click the **Update** button.
The **Confirm Update** dialog box with a list of components to be updated is displayed.
3. Click **Yes** to proceed with the update or **No** to cancel the update.
If you click **Yes**, SUU displays the **Update** dialog box that shows the progress of the update.
4. Click **OK** when the update is complete.
The status of the update is reflected in the **Comparison Report**.

Updating Failures

While updating the system components, if a particular component update is unsuccessful, you can choose to continue or stop updating the other components. If you select **Stop on Update Failures**, SUU stops updating the other components.

 **NOTE: Stop on Update Failures** is enabled only if you have selected more than one component for an update.

About Command Line Interface Mode

The Command Line Interface (CLI) mode allows you to run commands from a command prompt to perform comparisons and updates.

Run SUU in CLI mode, in the Dell Server Updates DVD root directory. If you are running SUU from a network share, copy the Dell Server Updates DVD contents to a shared directory and run the CLI from the shared directory.

You can use the CLI to:

- To perform comparisons and updates. For list of commands, see [List of CLI Commands](#).
- View the progress of the update.


Launching SUU in a CLI Mode


You can run SUU from the directory where the SUU DVD is mounted. To update components on multiple systems in the CLI mode:

1. Access the system on which SUU is installed or choose the path where the DVD is loaded.
2. Run commands **suu - c** or **suu - u**, displays the comparison report and updates all the components.

List of CLI Commands

Table 4. CLI Commands List

CLI Command Syntax	Command Description
- ? - h - help	Displays the help message.
- g - gui	Launches the SUU Graphical user Interface.  NOTE: On systems running Linux operating systems this option can be used only from the X Window system.
- u - update	Update the system components to the repository level. Components in your system that are of a higher version than the components in the repository are downgraded without prompting you for confirmation. Not recommended always.
- e - upgradeonly	Upgrades all components repository versions that are greater than the current versions installed on the system. You cannot upgrade individual components using CLI. To do this, use the GUI.

CLI Command Syntax	Command Description
– n – downgradeonly	Downgrades all the system components greater than the repository components to the repository versions.  NOTE: SUU does not allow you to downgrade individual components.
– p – progress	Shows the progress of the upgrade or downgrade.
– c – comparison	Compares the current component.
– d – directory	Directs the event logs to a different directory than the default location.
– s – stoponfail	Stops the update if a failure occurs during the update of the first component.
– iprog – inventoryprogress	Shows the progress (in percentage) of the comparison between the components in the system and the components in the repository.
– nc – nocoreq	Filters the corequisites applicable on the system.

Integrating Server Update Utility With Other Components

The different possibilities of integrating SUU with other components are:

- [Integrating SUU with OpenManage Essentials](#)
- [Creating a custom SUU using Dell Repository Manager](#)
- [Exporting as a SUU](#)

Integrating SUU With OpenManage Essentials

OpenManage Essentials is a hardware management application that provides a comprehensive view of Dell systems, devices, and components in the enterprise's network. With OpenManage Essentials, a web-based and one-to-many systems management application for Dell systems and other devices, you can:

- Discover and inventory the systems.
- Monitor systems health.
- View and manage system alerts.
- Perform system updates.
- View hardware inventory and compliance reports.

Selecting a Catalog Source Using SUU

1. Launch **OpenManage Essentials**.
2. Click **Manage** → **System Update** → **Select a Catalog Source**.
3. Click **Use file System source (SUU)**.
4. Click **Browse** and select either the **catalog.xml** or **catalog.cab** file.
5. Click **Import now**.



Creating A Custom SUU Using Dell Repository Manager

You can create a custom SUU for the system using Dell Repository Manager (DRM).

1. Launch DRM.
2. Create or open a repository.
3. Select the bundles you want to export. From the list of displayed bundles, click **Export**.
4. In the **Export Bundles** dialog box, click **Next**.

5. In the Export Destination dialog box, select **Export as SUU to ISO** and click **Next**.
 **NOTE:** If you select **Export as SUU to directory**, the output package creates the SUU contents in the form of a directory.

Checking to see if the required plugin is installed... is displayed.

-  **NOTE:** If the system does not have the required plugin **Click here to install the Plugin** link is displayed.
6. To install the required plug-ins, Click the **Click here to install the Plugin** link.
The dialog box displayed is **Please wait...** with progress bar.
7. After the plug-in is downloaded, the **Report** dialog box is displayed. **Close** the dialog box.
8. After the latest plug-in is installed, the version of the installed Plugin is displayed. Click **Next**.
9. From the **Browse For Folder** dialog box, navigate to the folder on the local drive, where you want to save the ISO file, and then click **OK**.
10. Click **Finish**.
The dialog box displayed is **Please wait ...** with the progress of ISO Creation.
11. Click **Accept** the Security Warning download the files successfully.
 **NOTE:** When you attempt to download from another website or web page, and if security warning is displayed accept the files. The **Name**, **Publisher**, **Certificate Type**, and **Expiration Date** of the file appears in the window to ensure the authenticity.
12. After the SUU ISO is created, the **Report** dialog box is displayed. **Close** the report dialog box.
13. Burn the bootable ISO CD or DVD using the appropriate software.

To access the ISO file navigate to the predefined location where the bootable ISO is created.

Exporting as a SUU

You can export a selected Dell-recommended or a custom bundle as a fully-functional SUU.

To export a Dell-recommended or a custom bundle as a functional SUU:

1. Open a repository from **My Repositories** or import a repository from **Application**.
2. Click the **Bundles** tab.
3. Select the bundle that you want to export from the list of displayed bundle, and click **Export**.

4. In the **Export Bundle(s)** window, select **Export as SUU**, and select one of the following.

- **Export as SUU to Directory** to create a SUU pack in the provided directory.
- **Export as SUU to ISO** to create an ISO image of the SUU pack.

The system checks for availability of the latest SUU plug-in. If a plug-in is available, the version number of the plug-in displays and the application prompts you to proceed with the exporting process.

For more information on the usage of SUU on Windows and Linux servers, see the *Dell OpenManage Server Update Utility User's Guide* at dell.com/openmanagemanuals.

- While Repository Manager checks for availability of the required SUU plug-ins, the **Checking to see if the required plug-in is installed...** dialog box is displayed.
- If the latest plug-in is already downloaded the following message displays: Required plug-in found
The version number of the plug-in found is also displayed.
- When ftp.dell.com is accessible and, latest plug-ins exist on your system, the **Update plug-in** link displays. When you click the link, the plug-ins from the system are updated.
- If you attempt installing plug-ins by clicking the Click here to install the plug-in, when ftp.dell.com is not accessible and plug-ins do not exist on your system, the following error message is displayed: Plug-in file not found in configured location. Press "OK" to open Plug-in update settings.



NOTE: Ensure the system connects to the Internet and the ftp.dell.com is accessible.

5. Click **Next**.

6. From the **Browse For Folder** window, navigate to the folder on the local drive, where you want to export the SUU, and click **OK** Once you click **OK**.

7. If **Export SUU** job goes to the **Jobs Queue**. You can see the **Status** and **Progress** under the **Jobs Queue** list.

8. In the **Export Summary** window, click **Errors/Warnings** to check for errors or warnings.

The following are the different errors:

- If the file type of a component does not match with the bundle it belongs to. For example, a Linux DUP displays in a Windows bundle.
- If the supported platforms of a component does not match the bundle supported list. For example a PowerEdge R210 BIOS shows displaying in a T710 bundle.
- If the operating system supported for the bundle is Windows or Linux. For example, export M1000e bundle to a SUU. Other operating systems are considered as errors.

The following is considered a warning:

If multiple update components are applicable to the same device within a bundle, Repository Manager preserves only the latest version of the component in a custom SUU. All the other duplicated components are removed from the bundle.

9. Click **Finish**.

Known Issues and Frequently Asked Questions

This section describes some known issues and frequently asked questions for Dell OpenManage Server Update Utility (SUU).


Known Issues

The following are some known issues with Dell OpenManage Server Update Utility (SUU).

Timeout due to USB Arbitration Service

While USB arbitration service is running, if you run SUU or manually run the Inventory Collector on a managed node running the VMware ESX 4.1 operating system, a timeout occurs. When you manually run the DUP, an error message is displayed and the utility exits. To fix the issue, stop the USB arbitration service. as follows:


1. Check if the USB arbitration service is running with the **ps aux|grep usb** command to prevent the USB arbitration service during system start.
2. Run the **chkconfig usbarbitrator off** command.
3. After you stop the USB arbitration, restart the server to allow the DUPs and/or the Inventory Collector to run.

 **NOTE:** If you require the USB arbitration service manually, enable it after the update is complete. To enable the USB arbitration service, run the **chkconfig usbarbitrator** command.

Inventory Failure on Microsoft Windows Small Business Server 2008 Operating System

If you login to a system running Microsoft Windows Small Business Server 2008 operating system, you are logged in as a regular user even though you have Administrator rights.

 **NOTE:** An in-built feature called User Account Control (UAC) automatically reduces the potential of security breaches for a system running Windows operating system.

 **NOTE:** Before you run SUU or DUPs on the system, change the security options in Group Policy Editor.

To change the security options:

1. Click **Start Run** and then type **gpedit.esc** or **gpmc.msc**.
The **Group Policy Editor** window is displayed.
2. Browse to **Security Options**.
The **Policy** window is displayed
3. Navigate to **User Account Control: Behavior of the elevation prompt for administrators in Admin Approval Mode**.

4. Right-click and select **Elevate without prompt**.

DUP Fails on 64-bit Red Hat Enterprise Linux Operating System

If DUP fails to run on a 64-bit Red Hat Enterprise Linux operating system, manually install the following RPMs:

- `compat-libstdc++-33.i686`
- `libstdc++-4.4.4-13.el6.i686`
- `libxml2.i686`
- `libXp.i686`
- `libXtst.i686`
- `nss-softokn-freebl-3.12.9-11.el6.i686`



NOTE: The RPMs are available on the Red Hat Enterprise Linux 6 x64 media.

Enabling Operating System Devices

SUU does not inventory or update devices that are disabled in the operating system, though these devices may be displayed in the **Comparison Report**. To update the disabled devices, make the appropriate changes in the operating system and restart SUU.

Linux Systems Require the `libstdc++-libc6.2-2.so.5` and `libstdc++-libc6.2-2.so.3` Library to run SUU

On Linux systems, `libstdc++-libc6.2-2.so.5` and `libstdc++-libc6.2-2.so.3` libraries are required to run SUU. These libraries are available only if you have installed Red Hat Enterprise Linux on the system. If the system does not have these libraries and if you are running a supported version of Red Hat Enterprise Linux, install the **compat-libstdc++** RPM from **RedHat.com** or from the Red Hat CD.

Running Linux Updates

SUU uses the Dell Update Packages (DUP) to update the various system components. During a Linux update, the DUP creates the `.spsetup` file using the Linux lockfile utility at `/var/lock`. This file is created when one of the following situations occur:

- A kernel panic
- A system restart command during a DUP procedure, preventing a TERM signal from interrupting or stopping a running process

If one of these conditions occur, a `/var/lock/.spsetup` file is created, causing SUU to report a successful update and prompt the user to restart the system. When you run SUU again and run the Comparison Report, the comparison procedure reports no change in device status. If this situation occurs and if you are not running an update, delete the `/var/lock/.spsetup` file.

Running SUU With the Progress Option

While running SUU with the `-p` (progress) option, the SUU current instance log location is reported and not the SUU update log location.

Updating Multiple Devices

When updating multiple, identical devices on the same system, SUU applies the update to all instances of all devices. For example, if your system is configured with three controllers running firmware or driver

versions 1.1, 1.2, and 1.3, and the repository contains version 1.2, the update applies firmware version 1.2 to all devices.

Updating PERC Firmware

If you have multiple PowerEdge Expandable RAID Controller (PERC) cards installed on a system, you have to run the SUU update more than once to update the firmware of all PERC cards. This procedure ensures that all the PERC cards are updated even if the cards failed to update during the initial SUU update.

PERC update packages may fail if other processes, such as a consistency check or background initialization (BGI) are running on the controller. Ensure that such processes are not in progress before running the update package.

Restarting the System Inventory in the Same Session

If there is insufficient space in the **var** or **tmp** folder SUU does not allow you to restart the system inventory in the same session.

In Linux, if the space is not enough in the **var** or **tmp** folder, SUU displays the following error message: `:Not enough space available in /var or /tmp folder. Make sure you have at least 100MB.`

Ensure that you have sufficient space in the **var** or **tmp** folder and restart SUU to start the system inventory.

Running SUU Over a Network

- When SUU is running over a network and is performing a system inventory, if the system gets disconnected from the network, SUU displays a blank **Comparison Report**. To view the contents of the **Comparison Report**, ensure that you are connected to the network and restart SUU.
- When SUU is running over a network and the **Comparison Report** is displayed, if the system gets disconnected from the network and then if you click the **Update** button, SUU does not update any components. To update the components, ensure that you are connected to the network and restart SUU.

Deleting the Temporary Folder

When you run SUU over a network, JRE creates temporary files in the `<%systemdrive%>:\Documents and Settings\<%user%>\Local Settings\Temp\hsperfdata_<%user%>` directory on systems running Microsoft Windows (W2ks systems) and in the `/var` folder on systems running Linux. Delete these temporary files.

For the W2k8 systems the files are created at `<%systemdrive%>:\users\ <%user%>\AppData\Local\Temp\<number>\hsperfdata_<%user%>`.

Updating the H661 Firmware

On 9G servers and 10G servers, if the CERC ATA RAID controllers are configured with the H661 firmware, SUU cannot update the firmware to the latest version. To update the firmware, use the **-force** option to manually apply the DUP with the latest firmware version.

Using the Remote Access Controller Virtual Media

Do not use the Virtual Media to remotely run the SUU on a system. This procedure disconnects the Virtual Media connection, interrupting the SUU update procedure.

Using Special Characters in the SUU Directory Name

SUU does not run from a directory that contains special characters such as ", :, /, \, \$, and so on. For example, when a USB DVD-ROM or USB disk is attached to the system running SUSE Linux Enterprise Server operating system, by default it gets mounted to a directory name that contains special characters. For example, /media/USB:1:2/.

It is recommended to use a directory name without any special characters while running SUU.

Running RAC DUP Packages

On 9G servers and 10G servers, if you launch SUU when a Remote Access Controller (RAC) DUP package (RAC 4/P or RAC 4/i) is running, the DUP package update stops. To resolve this issue, run SUU only after the RAC DUP package update is complete.

Frequently Asked Questions

Why do I get a pop-up dialog box saying, "There is no disk in the drive. Please insert a disk into drive"?

The Dell Server Updates DVD was ejected from the DVD drive while SUU was running. SUU requires the DVD during the update.

When I run `suu -c` on a Linux system, I get an error saying, "Problem executing Inventory Collector." What causes this error and how can I fix it?

The Inventory Collector subcomponent of SUU requires the `libstdc++-libc6.2-2.so.3` shared library on the system. Install the `compat-libstdc++ RPM` from RedHat.com or from the Red Hat CD, if you are running a supported version of Red Hat Enterprise Linux or from the SUSE Linux Enterprise Server CD, if you are running SUSE Linux Enterprise Server on the system.

Why do get a pop-up box titled "Unsafe Removal of Device"?

A part of the SUU update requires updating the backplane firmware. If the operating system queries the backplane during a flash update and the backplane does not respond, the operating system receives an indication that the device was removed unsafely. After the backplane firmware is updated, you can see a message displaying that a new device was added.

When using the SUU GUI to perform an update, a message is displayed asking me to see the User's Guide for information on possible causes of why a server object is not displayed in the tree.

To perform updates, you must be running SUU on a supported system and must have the correct user access rights. For systems running Windows you must have administrator rights and for systems running

Linux you must have root rights. For the list of supported servers and operating systems, see the *Dell Systems Software Support Matrix* at dell.com/openmanagemanuals.

When I run SUU, I do not see the Comparison Report? and I cannot update the system?

You must have local administrator to run SUU on systems running Windows operating systems. To obtain local administrator rights, you must either belong to the local administrators group or use the local administrator account. On systems running Linux, only root (user id 0) users can see the Comparison Report and perform updates.

Why do I get a message saying, "Inventory operation exceeded specified time-out" when I try to run a Dell Update Package and SUU concurrently?

Running SUU and a separate DUP concurrently gives unexpected results. SUU runs DUPs in the background. Therefore, you must not run DUPs separately. Either run SUU or DUP; do not run both at the same time.

I cannot start SUU. The "Another instance of SUU is already running" message is displayed even though no other instances of SUU is running on the system.

On systems running Windows operating systems, open the Windows Task Manager, click the **Applications** tab, and check if SUU is running. On systems running Linux operating systems, open a terminal and type the **ps -eaf | grep suu** command to find out if SUU is running. If SUU is running, close the application, and restart SUU. If no other instances of SUU is running, then SUU may have encountered an abrupt shutdown for some reason. This results in the creation of lock files. To delete these lock files on systems running Windows operating system, navigate to the `<%systemdrive%>\dell\suu` directory and delete the **suu.lck** file. To delete the lock files on systems running Linux operating system, run the: **chattr -i suu.lck rm -f suu.lck**. This removes the lock file from the log directory located at `/var/log/dell/suu`.


I cannot start Server Administrator after updating using SUU.

After updating Server Administrator using SUU, some of the Server Administrator services may not run. Restart the system and start Server Administrator.

I cannot update BIOS versions using SUU.

For systems with a TCG 1.2 compliant Trusted Platform Module (TPM) chip, you cannot update BIOS using SUU and DUPs if:

- The Microsoft Windows BitLocker Drive Encryption feature is enabled.
- The Trusted Platform Module feature is set (using BIOS) to **ON** with Pre-boot Measurement.

 **NOTE:** For information about TPM security settings, see the *Dell OpenManage Server Administrator Online Help* or the *Dell OpenManage Server Administrator User's Guide* at dell.com/openmanagemanuals.

I cannot run SUU, the "SUU Logging System has failed: There is not enough space on the disk" message is displayed.

While running SUU, make sure that the log directory at `<%systemdrive%>\dell\suu` (on systems running Windows operating systems) and `/var/log/dell/suu` (on systems running Linux operating systems)

contains at least 10 MB of free space. You can also save the log files in a different directory. For more information, see the SUU command line options.