

Dell EMC Systems Management Tools And Documentation Installation Guide

Version 9.2.1

Notes, cautions, and warnings

 **NOTE:** A NOTE indicates important information that helps you make better use of your product.

 **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

© 2019 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

Contents

1 About.....	4
Systems Management software.....	4
Managed system and management station.....	4
Systems Management Tools and Documentation software.....	4
Managed system software.....	5
Management station software.....	5
DTK Deprecation Message.....	7
2 Installing management station software on Microsoft Windows.....	8
Installing management station software on Microsoft Windows Server and Hyper-V Server.....	8
Installing management station software using the CLI mode.....	8
Uninstalling management station software using the CLI mode.....	9

About

The Systems Management Tools and Documentation Installation Guide provides an overview of the management station software and installation instructions for the same. For information on installing Server Administrator, see the *Dell EMC Server Administrator Installation Guide* in the *Dell EMC Systems Management Tools and Documentation* software.

Systems Management software

The systems management image comprises of the three software's mentioned below:

- Systems Management Tools and Documentation
- Server Updates
- Management Console

You can download the free ISO image of the software's from www.dell.com/Support/Home.

For information on systems that support systems management software, supported operating systems, and components, see *Dell EMC OpenManage Systems Software Support Matrix* at www.dell.com/OpenManageManuals

Topics:

- [Managed system and management station](#)
- [Systems Management Tools and Documentation software](#)

Managed system and management station

Depending on the way you use the systems management tools, you can classify the systems as:

- Managed System
A managed system is any system that is monitored and managed using Server Administrator or Management Console. A Server Administrator is one of the systems management tools on the *Systems Management Tools and Documentation* software. You can manage systems running Server Administrator locally or remotely through a supported web browser. For more information on Server Administrator, see the *Server Administrator User's Guide* on the *Systems Management Tools and Documentation* software.
- Management Station
A management station is a laptop, desktop, or server that you use to remotely manage one or more managed systems from a central location. You can use tools such as:
 - Intelligent Platform Management Interface (IPMI) Utilities
 - Remote Access Controller (RAC) tools
 - Dell OpenManage Essentials or Server Administrator Web Server

Systems Management Tools and Documentation software

The *Systems Management Tools and Documentation* software contains the systems management software. The systems management software helps you to manage the systems by monitoring the system components, diagnosing issues, notifying through alerts, and troubleshooting remotely. Systems management software is classified into managed system software and management station software.

Managed system software

The following applications include the managed system software:

- Server Administrator
Server Administrator provides comprehensive one-to-one in-band server managements solutions to manage a server locally and remotely using a web browser-based Graphical User Interface (GUI) and Command Line Interface (CLI). Server Administrator installs server-specific Remote Access Card (RAC) and network interface management components.

NOTE: When you perform a fresh installation on a system running a 64-bit operating system, a 64-bit version of the Server Administrator is used for the installation. If you want to upgrade Server Administrator, a 32-bit version of the Server Administrator is used for the upgrade.

- Local Remote Access Controller
Local Remote Access Controller enables the system to receive email alerts for warnings or errors related to voltage, temperature, and fan speed. Remote Access Controller also logs event data and the most recent crash screen (available only on systems running Microsoft Windows operating system) to help you diagnose the probable cause of a system crash.

Management station software

The following applications include the management station software that you can install using the *Systems Management Tools and Documentation* software:

- Active Directory Snap-In
The Active Directory (AD) Snap-In utility provides an extension snap-in to the Microsoft Active Directory to manage AD objects specific to products on this software.
- BMC/IPMI Utilities
BMC Management Utility (BMU) is a utility that provides remote management and configuration of systems equipped with a Baseboard Management Controller (BMC) or iDRAC using the IPMI protocol. IPMI utilities are CLI-based management station software.

For more information on BMU, see the *Baseboard Management Controller Utilities User's Guide*

NOTE: Only 32-bit installer is available.

- RAC Tools
The RAC console is a management station software designed to provide remote management capabilities for the systems. You can remotely connect to the RAC hardware and access the RAC features either by using a web browser or the RACADM Command Line Interface (CLI). RACADM CLI is the command-line user interface to the RAC.

You can install RAC either on the managed system or on the management station.

For information on installing RAC on the managed system, see the *Server Administrator Installation Guide*. For information on installing on the management station, see [Installing Management Station Software on Windows](#). For more information on RAC, see the *Remote Access Controller User's Guide*.

- Dell Lifecycle Controller
Dell recommends using the Embedded Management, Integrated Dell Remote Access Controller 8 (iDRAC8) with Lifecycle Controller instead of Dell Systems Build and Update Utility (SBUU). SBUU is replaced with Lifecycle Controller on Dell's 13th generation of PowerEdge servers. iDRAC with Lifecycle Controller is an Embedded Systems Management application for operating system deployment and lifecycle management of PowerEdge servers. You can access Dell Lifecycle Controller by pressing **<F10>** during system boot up. The local GUI of iDRAC8 with Lifecycle Controller allows you to do the following in a pre-OS environment:
 - Hardware configuration
 - Operating system and hypervisor deployments

- Hardware updates
- Hardware diagnostics
- Easy maintenance of PowerEdge servers

The Lifecycle Controller is embedded on all Dell's 11th generation and later PowerEdge servers. No tools or downloads are required to use the capabilities of Lifecycle Controller.

For more information, see the following documents available at www.dell.com/OpenManageManuals:

- *Dell Lifecycle Controller Version <Version Number> User's Guide*
- *Dell Lifecycle Controller Remote Services Version <Version Number> Quick Start Guide*
- *Dell Lifecycle Controller Web Services Interface Guide*
- *Lifecycle Controller Integration Best Practices*

- Dell OpenManage Essentials

Dell recommends using Dell OpenManage Essentials as replacement for IT Assistant. Dell OpenManage Essentials (OME) provide improved capabilities such as:

- Discovering and inventorying the systems.
- Monitoring systems' health.
- Viewing and managing system alerts.
- Performing system updates.
- Viewing hardware inventory and compliance reports.

For more information regarding Dell OpenManage Essentials, contact service provider.

- iDRAC Service Module

The iDRAC Service Module is a lightweight optional software application that can be installed on a Dell's 12th generation and later PowerEdge servers. Using the iDRAC Service Module you can configure the features on the supported operating system. The iDRAC Service Module provides additional Server Management data to iDRAC and presents one-to-many consoles with access to Systems Management data through OS interfaces.

The iDRAC Service Module also complements the iDRAC interfaces such as the GUI, RACADM CLI, and WSMAN with additional monitoring features. For more information, see *iDRAC Service Module <Version Number> Installation Guide* available at www.dell.com/Support/Home.

- Dell OpenManage Deployment Toolkit (DTK)

The Dell OpenManage Deployment Toolkit (DTK) includes a set of utilities, sample scripts, and sample configuration files that you can use to deploy and configure the Dell systems. You can use DTK to build script-based and RPM-based installation for deploying large number of systems on a pre-operating system environment in a reliable way, without changing their current deployment processes. Using DTK you can install operating systems on Dell systems in BIOS or Unified Extensible Firmware Interface (UEFI) mode.

In addition to the command-line utilities used to configure various system features, DTK also provides sample scripts and configuration files to perform common deployment tasks and documentation. These files and scripts describe the use of the DTK in Microsoft Windows Pre-installation Environment (Windows PE) and Linux environments. For more information, see the following documents available at www.dell.com/OpenManageManuals:

- *Dell OpenManage Deployment Toolkit Version <Version Number> User's Guide*
- *Dell OpenManage Deployment Toolkit Version <Version Number> Command Line Interface Reference Guide*
- *Dell OpenManage Deployment Toolkit Version <Version Number> Installation Guide*

DTK Deprecation Message

The OpenManage Deployment Toolkit (DTK) along with the associated tools and capabilities will be deprecated for version 6.1 and later:

- Redundant Array of Independent Disks Configuration (RAIDCFG) Utility
- System Configuration (SYSCFG) Utility
- ELI tool
- Utility Partition (UPINIT)

It is recommended to use the RACADM Command Line (CLI) as a replacement for the RAIDCFG and SYSCFG utilities. For more information on downloading RACADM, see www.dell.com/Support/Home.

NOTE: DTK will continue to support any new hardware or operating system for the 14th generation of PowerEdge servers. However, support for later generations of PowerEdge servers will be deprecated. For more information about features supported by DTK, see the latest User's Guide available at www.dell.com/OpenManageManuals.

Installing management station software on Microsoft Windows

- 1 Log on with administrator privileges to the system on which you want to install the management station applications.
- 2 Download the web installer.

NOTE: You can download the web installer from www.dell.com/Support/Home.

- 3 Run **autorun.exe**.
- 4 Follow the instructions in the Install Wizard.

Installing management station software on Microsoft Windows Server and Hyper-V Server

Windows Server or Hyper-V Server operating system does not support a graphical user interface (GUI) based installation of the software components. Install the software in CLI mode on Server Core. For more information on Server Core, see the Microsoft website.

NOTE: Log in as a built-in Administrator to install systems management software on Windows Server and Windows client operating system. For more information on built-in Administrator account, see the Windows Server Help.

Installing management station software using the CLI mode

NOTE: Run the Command Prompt as an administrator to successfully perform tasks using the CLI mode.

To install the RAC Tools, launch the MSI file using the command:

```
· msixexec /i RACTools_x64.msi
```

NOTE: On the *Systems Management Tools and Documentation* software:

- The **RACTools_x64.msi** file is located at **SYSMGMT\ManagementStation\windows\DRACx64**
- DRAC tools provide local and remote management capabilities for system equipped with iDRAC.

NOTE:

The DRAC tools upgrade fails when you try to upgrade to 9.1.2 from any previous versions. However, the DRAC tools upgrade to 9.1.3 is supported. Therefore, it is recommended to upgrade to 9.1.3 from any previous versions. You can also uninstall the previous version and can do a fresh install of DRAC tools 9.1.2.

To install BMU, launch the MSI file using the command:

```
msiexec /i BMC.msi
```

NOTE: Only 32-bit installer is available.

NOTE: The **BMC.msi** file is located at **SYSMGMT\ManagementStation\windows\BMC** on the *Systems Management Tools and Documentation* software.

To install Active Directory Snap-In, launch the MSI file using the command:

· `msiexec /i ADSnapIn_x64.msi`

NOTE: On the *Systems Management Tools and Documentation* software:

· The `ADSNapIn_x64.msi` file is located at `SYSMGMT\ManagementStation\windows\ADSNapInx64`

To install the localized version of the management station software, at the command prompt type the following: `msiexec /I <management_station_software>.msi TRANSFORMS= <language_transform>.mst`

NOTE: Replace `<language_transform>.mst` with the appropriate language file:

- 1031.mst (German)
- 1034.mst (Spanish)
- 1036.mst (French)
- 1041.mst (Japanese)
- 2052.mst (Simplified Chinese)

Uninstalling management station software using the CLI mode

To uninstall management station software, run the commands as listed in the following table:

Table 1. Commands to uninstall management station software

Management Station Software	Command
RAC Tools	<code>msiexec /x RACTools_x64.msi</code> (or) <code>msiexec /x {70A4F030-7431-453D-9AF9-CFC1CEB25B08}</code>
BMC (32 bit)	<code>msiexec /x BMC.msi</code> (or) <code>msiexec /x {93B961A4-A775-49CE-BFD9-001E21F1E4B0}</code>
Systems Management	<code>msiexec /x SysMgmtx64.msi</code> (or) <code>msiexec /x {27C3216A-EF5E-463D-AFCB-08B34C10AA14}</code>