Inspiron 15 5000 Gaming Setup and Specifications



Notes, cautions, and warnings



NOTE: A NOTE indicates important information that helps you make better use of your product.



CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

© 2017-2018 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

2018 - 11

Rev. A03

Contents

Set up your computer	5
Views	8
Front	
Left	8
Right	9
Base	10
Display	11
Bottom	12
Specifications	13
Dimensions and weight	13
System information	13
Memory	13
Ports and connectors	14
Communications	14
Audio	15
Storage	15
Media-card reader	16
Keyboard	16
Camera	16
Touch pad	
Power adapter	17
Battery	17
Display	18
Video	19
Computer environment	19

Keyboard shortcuts	20
Getting help and contacting Dell	22
Self-help resources	
Contacting Dell	23

Set up your computer


1 Connect the power adapter, and press the power button.



- **2** Finish operating system setup.
 - a) Connect to a network.



b) Sign-in to your Microsoft account or create a new account.



Locate Dell apps in Windows. 3

Table 1. Locate Dell apps



Register your computer







SupportAssist — Check and update your computer

Views

Front



Power and battery-status light/hard-drive activity light

Indicates the battery-charge status or the hard-drive activity.



NOTE: Press Fn+H to toggle this light between power and batterystatus light and hard-drive activity light.

Hard-drive activity light

Turns on when the computer reads from or writes to the hard drive.

Power and battery-status light

Indicates the power and battery-charge status.


Solid white — Power adapter is connected and the battery has more than 5% charge.

Amber — Computer is running on battery and the battery has less than 5% charge.

Off

- Power adapter is connected and the battery is fully charged.
- Computer is running on battery and the battery has more than 5% charge.
- Computer is in sleep state, hibernation, or turned off.

Left



1 Power-adapter port

Connect a power adapter to provide power to your computer and charge the battery.


2 USB 3.0 ports (2)

Connect peripherals such as storage devices and printers. Provides data transfer speeds up to 5 Gbps.

3 Headset port

Connect a headphone or a headset (headphone and microphone combo).

Right



Media-card reader 1

Reads from and writes to media cards.

2 USB 3.0 port with PowerShare

Connect peripherals such as storage devices and printers.

Provides data transfer speeds up to 5 Gbps. PowerShare enables you to charge your USB devices even when your computer is turned off.



NOTE: If your computer is turned off or in hibernate state, you must connect the power adapter to charge your devices using the PowerShare port. You must enable this feature in the BIOS setup program.



NOTE: Certain USB devices may not charge when the computer is turned off or in sleep state. In such cases, turn on the computer to charge the device.

3 **HDMI** port

Connect a TV or another HDMI-in enabled device. Provides video and audio output.

Network port 4

Connect an Ethernet (RJ45) cable from a router or a broadband modem for network or internet access.

5 Security-cable slot

Connect a security cable to prevent unauthorized movement of your computer.

Base



1 Left-click area

Press to left-click.

2 Touch pad

Move your finger on the touch pad to move the mouse pointer. Tap to left-click and two finger tap to right-click.

3 Right-click area

Press to right-click.

4 Power button

Press to turn on the computer if it is turned off, in sleep state, or in hibernate state.

Press to put the computer in sleep state if it is turned on.

Press and hold for 4 seconds to force shut-down the computer.



NOTE: You can customize the power-button behavior in Power Options. For more information, see Me and My Dell at www.dell.com/ support/manuals.

Display



1 Left microphone

Provides digital sound input for audio recording and voice calls.

2 Camera-status light

Turns on when the camera is in use.


3 Camera

Enables you to video chat, capture photos, and record videos.

4 Right microphone

Provides digital sound input for audio recording and voice calls.

Bottom



1 Service Tag label

The Service Tag is a unique alphanumeric identifier that enables Dell service technicians to identify the hardware components in your computer and access warranty information.

2 Subwoofer

A speaker unit that is designed to produce low frequency bass sounds.

Specifications

Dimensions and weight

Table 2. Dimensions and weight

Height 25.3 mm (0.99 in) Width 383 mm (15.07 in) Depth 265 mm (10.43 in) Weight (maximum) 2.57 kg (5.66 lb)



NOTE: The weight of your computer varies depending on the configuration ordered and the manufacturing variability.

System information

Table 3. System information

Computer model Inspiron 15-5576

Processor 7th generation AMD FX 9830P Quad

7th generation AMD A10 9630P Quad

Chipset Integrated in the processor

Memory

Table 4. Memory specifications

Slots Two SODIMM slots Type Dual-channel DDR4

Speed 2400 MHz

Ports and connectors

Table 5. Ports and connectors specifications

External:	
Network	One RJ-45 port
USB	One USB 3.0 port with PowerShareTwo USB 3.0 ports
Audio/Video	One HDMI portOne headset (headphone and microphone combo) port

Table 6. Ports and connectors specifications

Internal:	
M.2 Card	One M.2 slot for SSD card (SATA)
	 One M.2 slot for WiFi/Bluetooth

Communications

Table 7. Communication specifications

Ethernet	10/100/1000 Mbps Ethernet controller integrated on system board
Wireless (with Antenna Diversity)	Wi-Fi 802.11acBluetooth 4.1

Audio

Table 8. Audio specifications

Controller Realtek ALC3246 with Waves

MaxxAudio Pro

Speakers Two

Speaker output Average: 2 W

Peak: 2.5 W

Subwoofer One

Digital-array microphones Microphone

Volume controls Media-control shortcut keys

Storage

Table 9. Storage specifications

Interface SATA 6 Gbps

Hard drive One 2.5-inch drive (SATA)

Solid-state drive (SSD) One M.2 drive (SATA)

Capacity

Hard drive Up to 1 TB (hard-drive only

configuration)

Up to 1 TB hard drive + up to 256 GB SSD (dual drive configuration)



NOTE: You can purchase up to 512 GB SSD separately and upgrade later.

SSD Up to 512 GB (PCle NVMe SSD only

configuration)

Media-card reader

Table 10. Media-card reader specifications

Type One 2-in-1 slot

Cards supported . SD card

MultiMedia Card (MMC)

Keyboard

Table 11. Keyboard specifications

Type

Standard keyboard

· Backlit keyboard (optional)

Shortcut keys Some keys on your keyboard have two

symbols on them. These keys can be used to type alternate characters or to perform secondary functions. To type the alternate character, press Shift and the desired key. To perform secondary functions, press Fn and the desired key.



NOTE: You can define the primary behavior of the function keys (F1-F12) by changing Function Key Behavior in BIOS setup program.

Keyboard shortcuts

Camera

Table 12. Camera specifications

Resolution Still image: 1 megapixel

 Video: 1280 x 720 (HD) at 30 fps (maximum)

Diagonal viewing angle 74 degrees

Touch pad

Table 13. Touch pad

Resolution . Horizontal: 800

· Vertical: 800

Dimensions • Height: 80 mm (3.14 in)

· Width: 105 mm (4.13 in)

Power adapter

Table 14. Power adapter specifications

Type 130 W

Input voltage 100 VAC-240 VAC

Input frequency 50 Hz-60 Hz

Input current (maximum) 1.80 A

Output current (continuous) 6.70 A

Rated output voltage 19.50 VDC

Temperature range: Operating 0°C to 40°C (32°F to 104°F)

Temperature range: Storage -40°C to 70°C (-40°F to 158°F)

Battery

Table 15. Battery specifications

Type 6-cell "smart" lithium ion (74 WHr)

Dimensions:

Width 177.80 mm (7 in)

Depth 87.85 mm (3.45 in)

Height 11.30 mm (0.44 in)

Weight (maximum) 0.35 kg (0.77 lb)

Voltage 11.10 VDC

Charging time (approximate) 4 hours (when the computer is off)

Operating time Varies depending on operating conditions

and can significantly reduce under certain power-intensive conditions.

Life span (approximate) 300 discharge/charge cycles

Temperature range • Operating: 0°C to 35°C (32°F to

95°F)

· Storage: -40°C to 65°C (-40°F to

149°F)

Coin-cell battery CR-2032

Display

Table 16. Display specifications

Type 15.6-inch FHD non-touch screen

Resolution (maximum) 1920 x 1080

Viewing angle (Left/Right/Up/Down) . 40/40/10/30

. 80/80/80/80

Pixel pitch 0.179 mm

Height (excluding bezel) 193.59 mm (7.62 in)
Width (excluding bezel) 344.16 mm (13.55 in)
Diagonal (excluding bezel) 394.87 mm (15.60 in)

Refresh rate 60 Hz

Operating angle 0 degrees (closed) to 135 degrees

Video

Table 17. Video specifications

	Integrated	Discrete
Controller	AMD Radeon R5/R7	AMD Radeon RX560
Memory	Shared system memory	4 GB GDDR5

Computer environment

Airborne contaminant level: G1 as defined by ISA-S71.04-1985

Table 18. Computer environment

	Operating	Storage
Temperature range	0°C to 35°C (32°F to 95°F)	-40°C to 65°C (-40°F to 149°F)
Relative humidity (maximum)	10% to 90% (non-condensing)	0% to 95% (non-condensing)
Vibration (maximum)*	0.66 GRMS	1.30 GRMS
Shock (maximum)	110 G [†]	160 G [‡]
Altitude (maximum)	-15.2 m to 3048 m (-50 ft to 10,000 ft)	-15.2 m to 10,668 m (-50 ft to 35,000 ft)

^{*} Measured using a random vibration spectrum that simulates user environment.

[†] Measured using a 2 ms half-sine pulse when the hard drive is in use.

[‡] Measured using a 2 ms half-sine pulse when the hard-drive head is in parked position.

Keyboard shortcuts

Table 19. List of keyboard shortcuts

Keys	Description
F1 ■×	Mute audio
F2 🐠	Decrease volume
F3 ● 0)	Increase volume
F4	Play previous track/chapter
F5 ▶II	Play/Pause
F6 ▶₩	Play next track/chapter
F8 🚉	Switch to external display
F ⁹ ρ	Search
F10	Toggle keyboard backlight
(F11	Decrease brightness
F12	Increase brightness
Fn + PrtScr	Turn off/on wireless
Fn + B	Pause/Break
Fn + Insert	Sleep
Fn + S	Toggle scroll lock

Keys	Description
Fn + Ctrl	Open application menu
Fn + H	Toggle between power and battery- status light/hard-drive activity light
Fn + Esc na	Toggle Fn-key lock

Getting help and contacting Dell

Self-help resources

You can get information and help on Dell products and services using these self-help resources:

Table 20. Self-help resources

Self-help resources	Resource location
Information about Dell products and services	www.dell.com
Dell Help & Support app	1 to
Accessing help	In Windows search, type Help and Support, and press Enter.
Online help for operating system	www.dell.com/support/windows
Troubleshooting information, user manuals, setup instructions, product specifications, technical help blogs, drivers, software updates, and so on.	www.dell.com/support
Dell knowledge base articles for a variety of computer concerns.	 Go to www.dell.com/support. Type the subject or keyword in the Search box. Click Search to retrieve the related articles.
Learn and know the following information about your product:	See Me and My Dell at www.dell.com/

information about your product:

- Product specifications
- Operating system
- Setting up and using your product
- Data backup

To locate the Me and My Dell relevant to your product, identify your product through one of the following:

Select **Detect Product**.

Self-help resources

- · Troubleshooting and diagnostics
- · Factory and system restore
- · BIOS information

Resource location

- Locate your product through the drop-down menu under **View Products**.
- Enter the **Service Tag number** or **Product ID** in the search bar.

Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see www.dell.com/contactdell.



NOTE: Availability varies by country and product, and some services may not be available in your country.



NOTE: If you do not have an active internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.