

Dell™ Systems Software Support Matrix 5.3

- [Introduction](#)
 - [Supported Dell OpenManage Systems Management Software](#)
 - [Supported Dell OpenManage Change Management Software](#)
 - [Supported Dell OpenManage Systems Management Consoles](#)
 - [Supported Remote Access Controllers and Solutions](#)
 - [RAID Controller Supported Servers, Operating Systems, Firmware, and Driver Version](#)
 - [Supported Browsers](#)
-

Notes and Notices

 **NOTE:** A NOTE indicates important information that helps you make better use of your system.

 **NOTICE:** A NOTICE indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

Information in this document is subject to change without notice.
© 2007 Dell Inc. All rights reserved.

Reproduction in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: *Dell*, the *DELL* logo, *OpenManage*, *PowerVault* and *PowerEdge* are trademarks of Dell Inc.; *Microsoft*, *Windows*, *Windows Server*, *Internet Explorer*, and *Active Directory* are registered trademarks of Microsoft Corporation; *Windows Vista* is a trademark of Microsoft Corporation; *Red Hat* and *Red Hat Enterprise Linux* are registered trademarks of Red Hat, Inc.; *SUSE* and *Novell NetWare* are registered trademarks of Novell, Inc. in the United States and other countries; *Intel* is a registered trademark of Intel Corporation; *VMware* is a registered trademark of VMware, Inc.; *Firefox* is a registered trademark of Mozilla.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

November 2007

[Back to Contents Page](#)

RAID Controller Supported Servers, Operating Systems, Firmware, and Driver Versions

Dell™ Systems Software Support Matrix 5.3

- [Overview](#)
- [PERC 4/DC](#)
- [PERC 4e/DC](#)
- [PERC 3/DC](#)
- [PERC 3/QC](#)
- [PERC 4/DI](#)
- [CERC ATA 100 4/CH](#)
- [PERC 3/DI](#)
- [PERC 4/IM](#)
- [PERC 4/SC](#)
- [CERC SATA 1.5/6 Channel](#)
- [PERC 4e/DI](#)
- [PERC 4e/Si](#)

- [PERC 5/E Adapter](#)
- [PERC 5/i Adapter](#)
- [PERC 5/i Integrated](#)
- [SAS 5/IR Adapter](#)
- [SAS 5/IR Integrated](#)
- [SAS 5/I Integrated](#)
- [SAS 5/E Adapter](#)
- [PERC 6/I Integrated and Adapter](#)
- [PERC 6/E Adapter](#)
- [SAS 6/IR Integrated and Adapter](#)
- [LSI Logic 1020/1030 Ultra320 SCSI Adapter](#)
- [CERC SATA 1.5/2S](#)
- [LSI 1020/1030 Embedded SCSI Controller](#)

Overview

Starting with Dell™ OpenManage™ Server Administrator version 5.0, only the enhanced Storage Management Service will be supported. The Storage Management Service allows you to configure and manage your storage devices from within Server Administrator.

 **NOTE:** The Storage Management Service mentioned in this guide refers to the enhanced Storage Management Service. Server Administrator no longer supports the basic Storage Management Service (also known as Array Manager).

 **NOTE:** Starting with Dell OpenManage version 5.3, Dell OpenManage Server Administrator is available on the *Dell Systems Console and Agent CD* and the *Dell Systems Management Tools and Documentation DVD*.

Most versions of the *Systems Management CD* support management of RAID controllers in the form of PERC cards, and some systems management releases also support CERC IDE and SATA controllers. System administrators responsible for monitoring the compatibility of their systems' storage devices need a clear matrix that shows the elements that are compatible with a particular storage controller. Each storage controller version in turn supports a specific array of elements, including:

- ı Version of the Storage Management Service
- ı Dell system
- ı Firmware version number required for a particular controller
- ı Supported operating systems, where each operating system requires a specific driver

For more information on Storage Management Services see the *Dell OpenManage Server Administrator User's Guide* and the *Dell OpenManage Storage Management User's Guide* either on the Dell Support website at support.dell.com, on the *Dell Systems Documentation CD*, or on the *Dell Systems Management Tools and Documentation DVD*.

Five types of controllers are included in this section:

- ı The RAID controller card group contains the following controllers: PERC 3/DC, PERC 3/SC, PERC 3/QC, PERC 4/SC, PERC 4/DC, PERC 4e/DC, PERC 5/E, PERC 5/i Adapter, PERC 5/i Integrated, SAS 5/IR Adapter, SAS 6/IR Integrated, PERC 6/E, PERC 6/I Adapter, PERC 6/i Integrated, SAS 6/IR Adapter, CERC ATA 100/4 Channel, and CERC SATA 1.5/6 Channel.
- ı The RAID on motherboard (ROMB) group includes the following controllers: PERC 3/DI, PERC 4/DI, PERC 4e/DI, PERC 4e/Si, CERC SATA 1.5/2S, and SAS 5/IR Integrated.
- ı The internal mirroring group, provided through the system BIOS, includes the PERC 4/IM controller.
- ı The LSI 1020/1030 embedded SCSI controller.
- ı The SAS 5/I Integrated and SAS 5/E controller.

 **NOTE:** The firmware and drivers listed in this section refer to the minimum supported version as of the publication date of this document. Later versions of the firmware and drivers may also be supported or required. For the most recent driver and firmware requirements, see the Dell Support website at support.dell.com for the Storage Management Service.

Key to Table Footnotes

Some drivers in the following tables are marked with an asterisk. You can refer to the following paragraph for more information:

Linux Driver Included in RPM*

The 1.1.4 Linux driver is included in RPM 2302 (Red Hat® Package Manager 2302).

PERC 4/DC

The PERC 4/DC supports the following Dell systems: 650, 750, 1650, 1750, 1800, 1850, 2600, 2650, 2800, 2850, 4600, 6600, 6650, 6800, and 6850.

[Table 6-1](#) shows the other elements supported by the PERC 4/DC.

Table 6-1. Storage Management Service Supported Elements: PERC 4/DC

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Microsoft® Windows® 2000 Driver	Windows Server® 2003 Driver	Red Hat Enterprise Linux® 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE® Linux Enterprise Server (versions 9 and 10)
1.1	4.3	3500	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.2	4.4	351Q	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.7	2.20.4.4	NA	NA
2.0	5.0	351X (32-bit) 351S (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.1	5.1	351X (32-bit) 351S (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.2	5.2	351S (64-bit)	NA	6.46.3.64	NA	NA	NA	NA
2.3	5.3	352D (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA

PERC 4e/DC

The PERC 4e/DC supports the following Dell systems: 800, 830, 850, 1800, 1850, 1900, 1950, 2800, 2850, 2900, 2950, 2970, 6800, and 6850.

[Table 6-2](#) shows the other elements supported by the PERC 4e/DC.

Table 6-2. Storage Management Service Supported Elements: PERC 4/e DC

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
1.1	4.3	513T	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.2	4.4	521Q	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.7	2.20.4.4	NA	NA
2.0	5.0	521X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.1	5.1	521X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.2	5.2	522A	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.3	5.3	522D	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9.

PERC 3/DC

The PERC 3/DC supports the following Dell systems: 1650, 2600, 2650, 4600, 6600, and 6650.

[Table 6-3](#) shows the other elements supported by the PERC 3/DC.

Table 6-3. Storage Management Service Supported Elements: PERC 3/DC

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
1.1	4.3	1970	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.2	4.4	198Q	5.48	6.46.2.32 (32-bit) 6.41.2.64 (64-bit)	2.10.7	2.20.4.4	NA	NA
2.0	5.0	198X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.1	5.1	198X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.2	5.2	199A	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA	2.20.4.4	NA	NA
2.3	5.3	199D	5.48	6.46.2.32(32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9.

PERC 3/QC

The PERC 3/QC supports the following Dell systems: 2600, 2650, 4600, 6600, and 6650.

[Table 6-4](#) shows the other elements supported by the PERC 3/QC.

Table 6-4. Storage Management Service Supported Elements: PERC 3/QC

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
1.1	4.3	1970	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.2	4.4	198Q	5.48	6.46.2.32 (32-bit) 6.41.2.64 (64-bit)	2.10.7	2.20.4.4	NA	NA
2.0	5.0	198X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.1	5.1	198X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.2	5.2	199A	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA	2.20.4.4	NA	NA
2.3	5.3	199D	5.48	6.46.2.32(32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA

PERC 4/Di

The PERC 4/Di supports the following Dell systems: 1750 and 2600.

[Table 6-5](#) shows the other elements supported by the PERC 4/Di.

Table 6-5. Storage Management Service Supported Elements: PERC 4/Di

--	--	--	--	--	--	--	--	--

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
1.1 on a PowerEdge 1750	4.3	4130	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.1 on a PowerEdge 2600	4.3	2.500	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.2 on a PowerEdge 1750	4.4	421Q	5.48	6.46.2.32 (32-bit) 6.41.2.32 (64-bit)	2.10.7	2.20.4.4	NA	NA
1.2 on a PowerEdge 2600	4.4	251Q	5.48	6.46.2.32 (32-bit) 6.41.2.32 (64-bit)	2.10.7	2.20.4.4	NA	NA
2.0 on a PowerEdge 1750	5.0	421W	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.0 on a PowerEdge 2600	5.0	251X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.1 on a PowerEdge 1750	5.1	421W	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.1 on a PowerEdge 2600	5.1	251X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.2 on a PowerEdge 2600	5.2	252A	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA	2.20.4.4	NA	NA
2.2 on a PowerEdge 1750	5.2	422A	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA	2.20.4.4	NA	NA
2.3 on a PowerEdge 2600	5.2	252D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.3 on a PowerEdge 1750	5.2	422D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA

CERC ATA 100 4/CH

The CERC ATA 100 4/CH supports the following Dell systems: 600SC, 650, and 1600SC.

[Table 6-6](#) shows the other elements supported by the CERC ATA 100 4/CH.

Table 6-6. Storage Management Service Supported Elements: CERC ATA 100 4/CH

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
1.1	4.3	6.62	5.46	6.41.2.32	Native	NA	NA	NA
1.2	4.4	6.62	5.46	6.41.2.32	2.10.1	2.10.1	NA	NA
2.0	5.0	6.62	5.46	6.41.2.32	2.10.1	2.10.1	NA	NA
2.1	5.1	6.62	5.46	6.41.2.32	2.10.1	2.10.1	NA	NA
2.2	5.2	6.62	NA	6.41.2.32	NA	2.10.1	NA	NA
2.3	5.3	6.62	NA	6.41.2.32	NA	2.10.1	NA	NA

PERC 3/Di

The PERC 3/Di supports the following Dell systems: 1650, 2650, and 4600.

[Table 6-7](#) and [Table 6-8](#) show the other elements supported by the PERC 3/Di.

Table 6-7. Storage Management Service Supported Elements: PERC 3/Di

Storage Management Service*	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server® 2008
1.1 on a PowerEdge 1650	4.3	2.8.0.6092	2.8.0.6085	2.8.0.6085	NA
1.1 on a PowerEdge 2650	4.3	2.8.0.6092	2.8.0.6085*	2.8.0.6085*	NA
1.1 on a PowerEdge 4600	4.3	2.8.0.6092	2.8.0.6085*	2.8.0.6085*	NA
1.2 on a PowerEdge 1650	4.4	2.8.0.6092	2.8.0.6085*	2.8.0.6085	NA
1.2 on a PowerEdge 2650	4.4	2.8.0.6092	2.8.0.6085*	2.8.0.6085*	NA
1.2 on a PowerEdge 4600	4.4	2.8.0.6092	2.8.0.6085*	2.8.0.6085*	NA
2.0 on a PowerEdge 1650	5.0	2.8.0.6098	2.8.0.6085*	2.8.0.6085*	NA
2.0 on a PowerEdge 2650	5.0	2.8.0.6098	2.8.0.6085*	2.8.0.6085*	NA
2.0 on a PowerEdge 4600	5.0	2.8.0.6098	2.8.0.6085*	2.8.0.6085*	NA
2.1 on a PowerEdge 1650	5.1	2.8.0.6098	2.8.0.6085*	2.8.0.6085*	NA
2.1 on a PowerEdge 2650	5.1	2.8.0.6098	2.8.0.6085*	2.8.0.6085*	NA
2.1 on a PowerEdge 4600	5.1	2.8.0.6098	2.8.0.6085*	2.8.0.6085*	NA
2.2 on a PowerEdge 1650	5.2	2.8.1-6098	NA	2.8.0.6084	NA
2.2 on a PowerEdge 2650	5.2	2.8.1-6098	NA	2.8.0.6084	NA
2.2 on a PowerEdge 4600	5.2	2.8.1-6098	NA	2.8.0.6084	NA
2.3 on a PowerEdge 1650	5.3	2.8.1-7692	NA	2.8.0.6084	2.8.1.7691
2.3 on a PowerEdge 2650	5.3	2.8.1-7692	NA	2.8.0.6084	2.8.1.7691
2.3 on a PowerEdge 4600	5.3	2.8.1-7692	NA	2.8.0.6084	2.8.1.7691

* The 1.1.4 Linux driver is included in the Red Hat Package Manager (RPM) 2302.

 **NOTE:** Microsoft Windows Server 2008 is scheduled to be available in the first half of 2008. For latest information, see <http://www.microsoft.com/windowsserver2008/default.mspx>.

Table 6-8. Storage Management Service Supported Elements: PERC 3/Di

Storage Management Service*	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
1.1 on a PowerEdge 1650	4.3	2.8.0.6092	1.1.4*	NA	NA	NA
1.1 on a PowerEdge 2650	4.3	2.8.0.6092	1.1.4*	NA	NA	NA
1.1 on a PowerEdge 4600	4.3	2.8.0.6092	1.1.4*	NA	NA	NA
1.2 on a PowerEdge 1650	4.4	2.8.0.6092	1.1.4*	1.1.5.2372	NA	NA
1.2 on a PowerEdge 2650	4.4	2.8.0.6092	1.1.4*	1.1.5.2372	NA	NA
1.2 on a PowerEdge 4600	4.4	2.8.0.6092	1.1.4*	1.1.5.2372	NA	NA
2.0 on a PowerEdge 1650	5.0	2.8.0.6098	1.1.4*	1.1.5.2392	NA	NA
2.0 on a PowerEdge 2650	5.0	2.8.0.6098	1.1.4*	1.1.5.2392	NA	NA
2.0 on a PowerEdge 4600	5.0	2.8.0.6098	1.1.4*	1.1.5.2392	NA	NA
2.1 on a PowerEdge 1650	5.1	2.8.0.6098	1.1.4*	1.1.5.2392	NA	NA
2.1 on a PowerEdge 2650	5.1	2.8.0.6098	1.1.4*	1.1.5.2392	NA	NA
2.1 on a PowerEdge 4600	5.1	2.8.0.6098	1.1.4*	1.1.5.2392	NA	NA
2.2 on a PowerEdge 1650	5.2	2.8.1-6098	NA	1.1.5.2372.1	NA	NA
2.2 on a PowerEdge 2650	5.2	2.8.1-6098	NA	1.1.5.2372.1	NA	NA
2.2 on a PowerEdge 4600	5.2	2.8.1-6098	NA	1.1.5.2372.1	NA	NA
2.3 on a PowerEdge 1650	5.3	2.8.1-7692	NA	1.1.5.2372.1	NA	NA

2.3 on a PowerEdge 2650	5.3	2.8.1-7692	NA	1.1.5.2372.1	NA	NA
2.3 on a PowerEdge 4600	5.3	2.8.1-7692	NA	1.1.5.2372.1	NA	NA
* The 1.1.4 Linux driver is included in the Red Hat Package Manager (RPM) 2302.						

PERC 4/IM

The PERC 4/IM supports the following Dell systems: 1655MC and 1855.

[Table 6-9](#) and [Table 6-10](#) show the other elements supported by the PERC 4/IM.

Table 6-9. Storage Management Service Supported Elements: PERC 4/IM

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
1.1 on PowerEdge 1655MC	4.3	1.00.12.00 1.00.0c.00 Hex	1.08.06	1.08.18 (Native)	NA
1.0.1 on PowerEdge 1855	4.1.4	1.03.23.90	1.09.11	1.09.11	NA
1.2 on PowerEdge 1655MC	4.4	1.00.12.00 1.00.0c.00 Hex	1.08.06	1.08.18 (Native)	NA
1.2 on PowerEdge 1855	4.4	1.03.23.90	1.09.11	1.09.11	NA
2.0 on PowerEdge 1655MC	5.0	1.03.23.90	1.08.06	Native	NA
2.0 on PowerEdge 1855	5.0	1.03.23.90	1.09.11	1.09.11	NA
2.1 on PowerEdge 1655MC	5.1	1.03.23.90	1.08.06	Native	NA
2.1 on PowerEdge 1855	5.1	1.03.23.90	1.09.11	1.09.11	NA
2.2 on PowerEdge 1655MC	5.2	1.03.23.90	NA	Native	NA
2.2 on PowerEdge 1855	5.2	1.03.23.90	NA	1.09.11	NA
2.3 on PowerEdge 1655MC	5.3	1.00.12.00	1.08.06	Native	NA
2.3 on PowerEdge 1855	5.3	1.03.23.90	1.09.11	1.09.11	Native

Table 6-10. Storage Management Service Supported Elements: PERC 4/IM

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
1.1 on PowerEdge 1655MC	4.3	1.00.12.00 1.00.0c.00 Hex	NA	NA	NA	NA
1.0.1 on PowerEdge 1855	4.1.4	1.03.23.90	Native	NA	NA	NA
1.2 on PowerEdge 1655MC	4.4	1.00.12.00 1.00.0c.00 Hex	NA	NA	NA	NA
1.2 on PowerEdge 1855	4.4	1.03.23.90	Native	Native	NA	NA
2.0 on PowerEdge 1655MC	5.0	1.03.23.90	NA	NA	NA	NA
2.0 on PowerEdge 1855	5.0	1.03.23.90	Native	Native	NA	NA
2.1 on PowerEdge 1655MC	5.1	1.03.23.90	NA	NA	NA	NA
2.1 on PowerEdge 1855	5.1	1.03.23.90	Native	Native	NA	NA
2.2 on PowerEdge 1655MC	5.2	1.03.23.90	NA	NA	NA	NA
2.2 on PowerEdge 1855	5.2	1.03.23.90	NA	Native	NA	NA
2.3 on PowerEdge 1655MC	5.3	1.00.12.00	NA	NA	NA	NA
2.3 on PowerEdge 1855	5.3	1.03.23.90	2.05.16	Native	NA	NA

PERC 4/SC

The PERC 4/SC supports the following Dell systems: 600SC, 650, 700, 750, 800, 830, 850, 1600SC, 1800, and 1850.

[Table 6-11](#) shows the other elements supported by the PERC 4/SC.

Table 6-11. Storage Management Service Supported Elements: PERC 4/SC

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
1.1	4.3	3500	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.2	4.4	351Q	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.7	2.20.4.4	NA	NA
2.0	5.0	351X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.1	5.1	351X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.2	5.2	352B	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA	2.20.4.4	NA	NA
2.3	5.3	352D (64-bit)	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA

CERC SATA 1.5/6 Channel

The CERC SATA 1.5/6 Channel supports the following Dell systems: 700, 750, 800, 830, 850, and 1800.

[Table 6-12](#) and [Table 6-13](#) show the other elements supported by the CERC SATA 1.5/6 Channel.

**Table 6-12. Storage Management Service Supported Elements:
CERC SATA 1.5/6 Channel**

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
1.1	4.3	2.8.0.7403	2.8.0.7010	2.8.0.7010	NA
1.2	4.4	4.1.0.7406	4.1.0.7010	4.1.0.7010 (32-bit) 4.1.1.7035 (64-bit)	NA
2.0	5.0	4.1.0.7417	4.1.0.7010	4.1.0.7010 (32-bit) 4.1.1.7038 (64-bit)	NA
2.1	5.1	4.1.0.7417	4.1.0.7010	4.1.0.7010 (32-bit) 4.1.1.7038 (64-bit)	NA
2.2	5.2	4.1.0.7417	NA	4.1.0.7010 (32-bit) 4.1.1.7038 (64-bit)	NA
2.3	5.3	4.1.0.7419	4.1.1.7040	4.1.1.7040	4.1.1.7040

* The 1.1.4 Linux driver is included in the Red Hat Package Manager (RPM) 2302.

Table 6-13. Storage Management Service Supported Elements: CERC SATA 1.5/6 Channel

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
1.1	4.3	2.8.0.7403	1.1.4*	NA	NA	NA
1.2	4.4	4.1.0.7406	1.1.4*	NA	NA	NA
2.0	5.0	4.1.0.7417	1.1.4*	1.1.5-2372	NA	NA
2.1	5.1	4.1.0.7417	1.1.4*	1.1.5-2372	NA	NA
2.2	5.2	4.1.0.7417	NA	1.1.5-2392	NA	NA
2.3	5.3	4.1.0.7419	NA	1.1.5-2392	NA	NA

* The 1.1.4 Linux driver is included in the Red Hat Package Manager (RPM) 2302.

PERC 4e/Di

The PERC 4e/Di supports the following Dell systems: 2800, 2850, 6800, and 6850.

[Table 6-14](#) shows the other elements supported by the PERC 4e/Di.

Table 6-14. Storage Management Service Supported Elements: PERC 4e/Di

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
1.1	4.3	5130	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.2	4.4	521Q	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.7	2.20.4.4	NA	NA
2.0	5.0	521X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.1	5.1	521X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.2	5.2	522A	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA	2.20.4.4	NA	2.20.4.7
2.3 on PowerEdge 2850	5.3	522D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7
2.3 on PowerEdge 6850	5.3	522D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7

Dell OpenManage version 5.3 supports only SP3 for SUSE Linux Enterprise Server version 9.

PERC 4e/Si

The PERC 4e/Si supports the following Dell system: 1850.

[Table 6-15](#) show the other elements supported by the PERC 4e/Si.

Table 6-15. Storage Management Service Supported Elements: PERC 4e/Si

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
1.1	4.3	5130	5.46	6.41.2.32	2.10.7	NA	NA	NA
1.2	4.4	521Q	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.7	2.20.4.4	NA	NA
2.0	5.0	521X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.1	5.1	521X	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	NA
2.2	5.2	522A	NA	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	NA	2.20.4.4	NA	NA
2.3	5.3	522D	5.48	6.46.2.32 (32-bit) 6.46.3.64 (64-bit)	2.10.10.1	2.20.4.4	NA	2.20.4.7

			(64-bit)			
Dell OpenManage version 5.3 supports only SP3 for SUSE Linux Enterprise Server version 9.						

PERC 5/E Adapter

The PERC 5/E Adapter supports the following Dell systems: 840, 860, 1850, 1900, 1950, 2850, 2900, 2950, 2970, 6800, 6850, 6950, R900, and R805.

 **NOTE:** All references made to PowerEdge 840, 2950, and 2900 also apply to PowerVault 100, PowerVault 500 and PowerVault 600 respectively.

[Table 6-16](#) and [Table 6-17](#) show the other elements supported by the PERC 5/E Adapter.

 **NOTE:** The RAID cards support both 32- and 64-bit versions of Red Hat Enterprise Linux operating systems and only 64-bit versions of the SUSE Linux Enterprise Server operating systems. However, ia64 versions of any operating system are not supported.

 **NOTE:** All references made to PowerEdge 840, 2950, and 2900 also apply to PowerVault 100, PowerVault 500 and PowerVault 600 respectively.

Table 6-16. Storage Management Service Supported Elements:

PERC 5/E Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
1.4	4.5.1	5.0.1	1.18.00.32	1.18.0.32 (32-bit) 1.18.0.64 (64-bit)	NA
2.0	5.0	5.0.1	1.18.00.32	1.18.0.32 (32-bit) 1.18.0.64 (64-bit)	NA
2.1	5.1	5.0.1	1.18.00.32	1.18.0.32 (32-bit) 1.18.0.64 (64-bit)	NA
2.2	5.2	5.1.1	2.8.0.32	2.8.0.32 (32-bit) 2.8.0.64 (64-bit)	NA
2.3	5.3	5.2.1-0060	2.14.0.32	2.14.0.32 (32-bit) 2.14.0.64 (64-bit) 2.13.0.32 (32-bit) 2.13.0.64 (64-bit)	

Table 6-17. Storage Management Service Supported Elements: PERC 5/E Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
2.0	5.0	5.0.1	00.00.02.03	00.00.02.03	NA	00.00.02.05
2.1	5.1	5.0.1	00.00.02.03	00.00.02.03	NA	00.00.02.05
2.2	5.2	5.1.1	NA	00.00.03.06	00.00.03.06	00.00.03.06
2.3	5.3	5.2.1-0060	NA	00.00.03.13	00.00.03.13	00.00.03.13

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9.

PERC 5/i Adapter

The PERC 5/i Adapter supports the following Dell systems: 840, 6850, 6950, and 1430SC.

 **NOTE:** All references made to PowerEdge 840 also apply to PowerVault 100.

[Table 6-18](#) and [Table 6-19](#) show the other elements supported by the PERC 5/i Adapter.

Table 6-18. Storage Management Service Supported Elements: PERC 5/i Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
2.0	5.0	5.0.1	1.18.00.32	1.18.0.32 (32-bit) 1.18.0.64 (64-bit)	NA
2.1	5.1	5.0.1	1.18.00.32	1.18.0.32	NA

				(32-bit) 1.18.0.64 (64-bit)	
2.2	5.2	5.1.1	2.8.0.32	2.8.0.32 (32-bit) 2.8.0.64 (64-bit)	NA
2.3	5.3	5.2.1-0060	2.14.0.32	2.14.0.32 (32-bit) 2.14.0.64 (64-bit)	2.13.0.32 (32-bit) 2.13.0.64 (64-bit)

Table 6-19. Storage Management Service Supported Elements: PERC 5/i Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
2.0	5.0	5.0.1	00.00.02.03	00.00.02.03	NA	00.00.02.05
2.1	5.1	5.0.1	00.00.02.03	00.00.02.03	NA	00.00.02.05
2.2	5.2	5.1.1	NA	00.00.03.06	00.00.03.06	00.00.03.06
2.3	5.3	5.2.1-0060	NA	00.00.03.13	00.00.03.13	00.00.03.13

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9.

PERC 5/i Integrated

The PERC 5/i Integrated supports the following Dell systems: 1900, 1950, 2900, 2950, and 2970.

[Table 6-20](#) and [Table 6-21](#) show the other elements supported by the PERC 5/i Integrated.

Table 6-20. Storage Management Service Supported Elements:
PERC 5/i Integrated

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Serer 2008
2.0	5.0	5.0.1	1.18.00.32	1.18.0.32 (32-bit) 1.18.0.64 (64-bit)	NA
2.1	5.1	5.0.1	1.18.00.32	1.18.0.32 (32-bit) 1.18.0.64 (64-bit)	NA
2.2	5.2	5.1.1	2.8.0.32	2.8.0.32 (32-bit) 2.8.0.64 (64-bit)	NA
2.3	5.3	5.2.1-0060	2.14.0.32	2.14.0.32 (32-bit) 2.14.0.64 (64-bit)	2.13.0.32 (32-bit) 2.13.0.64 (64-bit)

Table 6-21. Storage Management Service Supported Elements:
PERC 5/i Integrated

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
2.0	5.0	5.0.1	00.00.02.03	00.00.02.03	NA	00.00.02.05
2.1	5.1	5.0.1	00.00.02.03	00.00.02.03	NA	00.00.02.05
2.2	5.2	5.1.1	NA	00.00.03.06	00.00.03.06	00.00.03.06
2.3	5.3	5.2.1-0060	NA	00.00.03.13	00.00.03.13	00.00.03.13

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9.

SAS 5/iR Adapter

The SAS 5/iR Adapter supports the following Dell systems: 440SC, 1435SC, 1430SC, 840, 860, 1900, and 6950.

 **NOTE:** All references made to PowerEdge 840 also apply to PowerVault 100.

[Table 6-22](#) and [Table 6-23](#) show the other elements supported by the SAS 5/iR Adapter.

Table 6-22. Storage Management Service Supported Elements: SAS 5/iR Adapter

Storage Management Service	Dell OpenManage Version	SAS Firmware/BIOS Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
2.0	5.0	00.06.50.00/ 06.06.00.02	1.21.08.00	1.21.08.00	NA
2.1	5.1	00.06.50.00/ 06.06.00.02	1.21.08.00	1.21.08.00	NA
2.2	5.2	00.10.47.00/ 06.12.02.00	1.24.0.2	1.24.0.2	NA
2.3	5.3	00.10.51.00.06.12.04.00	1.24.4.0	1.24.04.00	1.25.06.22

Table 6-23. Storage Management Service Supported Elements: SAS 5/iR Adapter

Storage Management Service	Dell OpenManage Version	SAS Firmware/BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
2.0	5.0	00.06.50.00/ 06.06.00.02	02.06.32	03.02.63	NA	03.02.63
2.1	5.1	00.06.50.00/ 06.06.00.02	02.06.32	03.02.63	NA	03.02.63
2.2	5.2	00.10.47.00/ 06.12.02.00	NA	03.02.83.12	4.00.00.00	03.02.83.12 (version 9) 4.00.00.00 (version 10)
2.3	5.3	00.10.51.00.06.12.04.00	NA	3.02.83.12-7	4.00.07.00-2	3.02.83.12-7 (version 9) 4.00.07.00-2 (version 10)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9.

SAS 5/iR Integrated

The SAS 5/iR Integrated supports the following Dell system: 1955.

[Table 6-24](#) and [Table 6-25](#) show the other elements supported by the SAS 5/iR Integrated.

Table 6-24. Storage Management Service Supported Elements: SAS 5/iR Integrated

Storage Management Service	Dell OpenManage Version	SAS Firmware/BIOS Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
2.0	5.0	00.06.50.00/ 06.06.00.02	1.21.08.00	1.21.08.00	NA
2.1	5.1	00.06.50.00/ 06.06.00.02	1.21.08.00	1.21.08.00	NA
2.2	5.2	00.10.47.00.06.12.02.00	1.24.0.2	1.24.0.2	NA
2.3	5.3	00.10.51.00.06.12.04.00	1.24.04.00	1.24.04.00	1.25.06.22

Table 6-25. Storage Management Service Supported Elements: SAS 5/iR Integrated

Storage Management Service	Dell OpenManage Version	SAS Firmware/BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
2.0	5.0	00.06.50.00/ 06.06.00.02	2.06.32	3.02.63	NA	3.02.63
2.1	5.1	00.06.50.00/ 06.06.00.02	2.06.32	3.02.63	NA	3.02.63

2.2	5.2	00.10.47.00.06.12.02.00	NA	3.02.83.12	4.00.00.00	03.02.83.12 (version 9) 4.00.00.00 (version 10)
2.3	5.3	00.10.51.00.06.12.04.00	NA	3.02.83.12-7	4.00.07.00-2	3.02.83.12-7 (version 9) 4.00.07.00-2 (version 10)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9.

SAS 5/i Integrated

The SAS 5/i Integrated controller supports the following Dell systems: 1950, 2900, 2950, and 2970.

[Table 6-26](#) and [Table 6-27](#) show the other elements supported by the SAS 5/i Integrated controller.

Table 6-26. Storage Management Service Supported Elements: SAS 5/i Integrated

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
2.0	5.0	00.06.40.00/06.06.00.01	1.21.08.00	1.21.08.00	NA
2.1	5.1	00.06.40.00/06.06.00.01	1.21.08.00	1.21.08.00	NA
2.2	5.2	00.10.47.00.06.12.02.00	1.24.0.2	1.24.0.2	NA
2.3	5.3	00.10.51.00.06.12.04.00	1.24.04.00	1.24.04.00	1.25.06.22

Table 6-27. Storage Management Service Supported Elements: SAS 5/i Integrated

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
2.0	5.0	00.06.40.00/06.06.00.01	02.06.32	03.02.63	NA	03.02.63
2.1	5.1	00.06.40.00/06.06.00.01	02.06.32	03.02.63	NA	03.02.63
2.2	5.2	00.10.47.00.06.12.02.00	NA	03.02.83.12	4.00.00.00	03.02.83.12 (version 9) 4.00.00.00 (version 10)
2.3	5.3	00.10.51.00.06.12.04.00	2.06.48.02-2	3.02.83.12-7	4.00.07.00-2	3.02.83.12-7 (version 9) 4.00.07.00-2 (version 10)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9.

SAS 5/E Adapter

The SAS 5/E Adapter supports the following Dell systems: 1800, 1850, 1900, 1950, 2800, 2850, 2900, 2950, 2970, 6800, 6850, 6950, R900, and R805.

[Table 6-28](#) and [Table 6-29](#) show the other elements supported by the SAS 5/E Adapter.

Table 6-28. Storage Management Service Supported Elements: SAS 5/E Adapter

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Windows 2000 Driver	Windows Server 2003 Driver	Windows Server 2008
2.0	5.0	00.06.40.00/06.06.00.01	1.21.08.00	1.21.08.00	NA
2.1	5.1	00.06.40.00/06.06.00.01	1.21.08.00	1.21.08.00	NA
2.2	5.2	00.10.47.00.06.12.02.00	1.24.0.2	1.24.0.2	NA
2.3	5.3	00.10.51.00.06.12.04.00	1.24.04.00	1.24.04.00	1.25.06.22

Table 6-29. Storage Management Service Supported Elements: SAS 5/E Adapter

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
----------------------------	-------------------------	-------------------------------	-----------------------------------	-----------------------------------	--	--

2.0	5.0	00.06.40.00/ 06.06.00.01	02.06.32	03.02.63	NA	03.02.63
2.1	5.1	00.06.40.00/ 06.06.00.01	02.06.32	03.02.63	NA	03.02.63
2.2	5.2	00.10.47.00.06.12.02.00	NA	03.02.83.12	4.00.00.00	03.02.83.12 (version 9) 4.00.00.00 (version 10)
2.3	5.3	00.10.51.00.06.12.04.00	2.06.48.02-2	3.02.83.12-7	4.00.07.00-2	3.02.83.12-7 (version 9) 4.00.07.00-2 (version 10)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9.

PERC 6/i Integrated and Adapter

The PERC 6/i Integrated and Adapter supports the following Dell systems: 1950, 1955, 2900, 2950, 2970, R900, and R805.

[Table 6-30](#) and [Table 6-31](#) show the other elements supported by the PERC 6/i Integrated and Adapter.

Table 6-30. Storage Management Service Supported Elements:

PERC 6/i Integrated and Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware	Windows Server 2003 Driver	Windows Server 2008
2.3	5.3	6.0.1-0072	2.14.0.32 (32-bit) 2.14.0.64 (64-bit)	2.13.0.32 (32-bit) 2.13.0.64 (64-bit)

Table 6-31. Storage Management Service Supported Elements:
PERC 6/i Integrated and Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware	Red Hat Enterprise Linux 4.5 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (version 10)
2.3	5.3	6.0.1-0072	00.00.03.13	00.00.03.13	00.00.03.13

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9.

PERC 6/E Adapter

The PERC 6/E Adapter supports the following Dell systems: 840, 860, 1950, 1955, 2900, 2950, 2970, 6950, R200, R900, and R805.

 **NOTE:** All references made to PowerEdge 840, 2950, and 2900 also apply to PowerVault 100, PowerVault 500, and PowerVault 600 respectively.

[Table 6-32](#) and [Table 6-33](#) show the other elements supported by the PERC 6/E Adapter.

Table 6-32. Storage Management Service Supported Elements: PERC 6/E Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware	Windows Server 2003 Driver	Windows Server 2008
2.3	5.3	6.0.1-0072	2.14.0.32 (32-bit) 2.14.0.64 (64-bit)	2.13.0.32 (32-bit) 2.13.0.64 (64-bit)

Table 6-33. Storage Management Service Supported Elements: PERC 6/E Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware	Red Hat Enterprise Linux 4.5 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (version 10)
2.3	5.3	6.0.1-0072	00.00.03.13	00.00.03.13	00.00.03.13

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9.

SAS 6/iR Integrated and Adapter

The SAS 6/iR Integrated supports the following Dell non-modular systems: 1950, 2900, 2950, 2970, R900, and R805.

The SAS 6/iR Integrated also supports the following Dell modular systems: M600 and M605.

 **NOTE:** R805, M600, and M605 are scheduled to be available in Q4 CY07 - Q1 CY08.

The SAS 6/iR Adapter supports the following Dell systems: SC460, R900, and R805.

[Table 6-34](#) shows the other elements supported by the SAS 6/iR Integrated and Adapter.

**Table 6-34. Storage Management Service Supported Elements:
SAS 6/iR Integrated and Adapter**

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Windows Server 2003 Driver	Windows Server 2008
2.3	5.3	00.20.43.00.06.14.08.00	1.24.04.00	1.25.06.22

**Table 6-35. Storage Management Service Supported Elements:
SAS 6/iR Integrated and Adapter**

Storage Management Service	Dell OpenManage Version	SAS Firmware/ BIOS Version	Red Hat Enterprise Linux 4.5 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
2.3	5.3	00.20.43.00.06.14.08.00	3.02.83.12-7	4.00.07.00-2	3.03.83.12-7 (version 9) 4.00.07.00-2 (version 10)

Dell OpenManage version 5.3 supports only Update 5 of Red Hat Enterprise Linux version 4 and only SP3 for SUSE Linux Enterprise Server version 9.

LSI Logic 1020/1030 Ultra320 SCSI Adapter

LSI Logic 1020/1030 Ultra320 SCSI adapter supports the following Dell system: 2970

[Table 6-36](#) and [Table 6-37](#) show the other elements supported by LSI Logic 1020/1030 Ultra320 SCSI adapter.

Table 6-36. Storage Management Service Supported Elements: LSI Logic 1020/1030 Ultra320 SCSI Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware/ BIOS Version	Windows 2000 Driver	Windows Server 2003 Driver
2.2	5.2	NOTE: See the appropriate readme file for the latest information.	1.21.25.00	1.21.25.00
2.3	5.3	1.03.27.00.5.10.08.00.12	1.21.25.00	1.21.25.00

Table 6-37. Storage Management Service Supported Elements: LSI Logic 1020/1030 Ultra320 SCSI Adapter

Storage Management Service	Dell OpenManage Version	PERC Firmware/ BIOS Version	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
2.2	5.2	NOTE: See the appropriate readme file for the latest information.	NA	3.02.83.01	NA	3.02.83.01 (version 9) 3.03.15 (version 10)
2.3	5.3	1.03.27.00.5.10.08.00.12	NA	3.02.83.12-5	NA	3.02.83.12-5 (version 9 only)

Dell OpenManage version 5.3 supports only SP3 for SUSE Linux Enterprise Server version 9.

CERC SATA 1.5/2S

The CERC SATA 1.5/2s supports the following Dell systems: 800 and 1800.

[Table 6-38](#) show the other elements supported by the CERC SATA 1.5/2S.

**Table 6-38. Storage Management Service Supported Elements:
CERC SATA 1.5/2S**

Storage Management Service*	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (versions 9 and 10)
1.1	4.3	NA	6.00.048	6.00.048	NA	NA	NA	NA
1.2	4.4	NA	6.00.050	6.00.050	NA	NA	NA	NA
2.0	5.0	NA	6.00.050	6.00.050	NA	NA	NA	NA
2.1	5.1	NA	6.00.050	6.00.050	NA	NA	NA	NA
2.2	5.2	NA	NA	6.0.50.5 (32-bit) 6.0.3643.4 (64-bit)	NA	NA	NA	NA
2.3	5.3	NA	NA	6.0.50.5 (32-bit) 6.0.3643.4 (64-bit)	NA	NA	NA	NA

* The 1.1.4 Linux driver is included in the Red Hat Package Manager (RPM) 2302.

LSI 1020/1030 Embedded SCSI Controller

This embedded SCSI controller is an onboard chip. It supports the following systems: 1600SC, 1750, 1800, 1850, 2600, 2650, 2800, 2850, 6800, 6850, and 7250.

[Table 6-39](#) and [Table 6-40](#) show the other elements supported by the LSI 1020/1030.

Table 6-39. Storage Management Service Supported Elements: LSI 1020

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (version 9 and 10)
1.1 on a PowerEdge 1600SC	4.3	1.03.04.00	1.08.19	1.08.18 (Native)	NA	NA	NA	NA
1.2 on a PowerEdge 1600SC	4.4	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
2.0 on a PowerEdge 1600SC	5.0	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
2.1 on a PowerEdge 1600SC	5.1	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
2.2 on a PowerEdge 1600SC	5.2	1.03.23	NA	Native	NA	Native	NA	NA
2.3 on a PowerEdge 1600SC	5.3	1.03.23	NA	Native	NA	Native	NA	NA

Table 6-40. Storage Management Service Supported Elements: LSI 1030

Storage Management Service	Dell OpenManage Version	PERC Firmware Version	Windows 2000 Driver	Windows Server 2003 Driver	Red Hat Enterprise Linux 3 Driver	Red Hat Enterprise Linux 4 Driver	Red Hat Enterprise Linux Server 5 Driver	SUSE Linux Enterprise Server (version 9 and 10)
1.1 on PowerEdge 1750	4.3	1.01.61.00	1.08.19	1.08.18 (Native)	NA	NA	NA	NA
1.1 on PowerEdge 2600	4.3	1.01.61.00	1.08.19	1.08.18 (Native)	NA	NA	NA	NA

1.2 on a PowerEdge 1750	4.4	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
1.2 on a PowerEdge 2600	4.4	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
2.0 on a PowerEdge 1750	5.0	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
2.0 on a PowerEdge 2600	5.0	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
2.1 on a PowerEdge 1750	5.1	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
2.1 on a PowerEdge 2600	5.1	1.03.23	1.09.11	1.09.11 (Native)	2.05.11.03	Native	NA	NA
2.2 on a PowerEdge 1750	5.2	1.01.61.00	NA	Native	NA	NA	NA	NA
2.2 on a PowerEdge 2600	5.2	1.01.61.00	NA	Native	NA	NA	NA	NA
2.3 on a PowerEdge 1750	5.3	1.01.61.00	NA	Native	NA	NA	NA	NA
2.3 on a PowerEdge 2600	5.3	1.01.61.00	NA	Native	NA	NA	NA	NA

[Back to Contents Page](#)

[Back to Contents Page](#)

Supported Browsers

Dell™ Systems Software Support Matrix 5.3

[Table A-1](#) lists the browsers that support Dell™ OpenManage™ in Dell systems.

Table A-1. Supported Browsers

Operating System	Windows® 2000	Windows 2003	Windows XP	Windows Server 2008	Windows Vista	SUSE® Linux Enterprise Server 9	SUSE Linux Enterprise Server 10	Red Hat® Enterprise Linux® 4.5	Red Hat Enterprise Linux Server 5
Browser	Microsoft® Internet Explorer® 6.0 SP2	Internet Explorer 7.0 Internet Explorer 6.0 SP2 Firefox® 2.0	Internet Explorer 6.0 SP2 Firefox 2.0	Internet Explorer 7.0 Firefox 2.0	Internet Explorer 7.0 Firefox 2.0	Firefox 1.5	Firefox 1.5 Firefox 2.0	Firefox 1.5	Firefox 1.5

 **NOTE:** Microsoft Windows Server 2008 is scheduled to be available in the first half of 2008. For latest information, see <http://www.microsoft.com/windowsserver2008/default.mspx>.

 **NOTE:** IT Assistant is not supported on Firefox 2.0 on Microsoft Windows Server 2008.

 **NOTE:** IT Assistant is not supported on Microsoft Windows 2000 Professional, Windows Small Business Server 2003, and Windows Server 2008 Server Core.

 **NOTE:** DRAC 5 on Firefox 1.5 is supported only on the SUSE Linux Enterprise Server 10 operating system.

 **NOTE:** On Microsoft Windows operating systems, DRAC 5 is not supported on Firefox.

[Back to Contents Page](#)

[Back to Contents Page](#)

Supported Dell OpenManage Change Management Software

Dell™ Systems Software Support Matrix 5.3

- [Supported Change Management Software on Microsoft Windows Operating Systems](#)
- [Supported Change Management Software on Linux Operating Systems](#)

Dell™ OpenManage™ change management software is a set of tools that provides an easy way to update Dell systems. It is also an efficient way to manage hardware, software, and operating system updates.

Dell OpenManage change management software comprises:

- I Dell Update Packages

A Dell Update Package (DUP) is a self-contained executable in a standard package format. Each Update Package is designed to update a single software component on a Dell system.

Dell Update Packages allow administrators to update a wide range of system components simultaneously and apply scripts to similar sets of Dell systems to bring system software components up to the same version levels.

For more information on DUPs, see the *Dell Update Packages User's Guide* available on the Dell Support website at [support.dell.com](#). This guide is also available on the *Dell Server Updates* DVD.

- I Server Update Utility

Dell OpenManage Server Update Utility (SUU) is a DVD-based application for identifying and applying updates to a Dell system. You can use SUU to update your Dell system or to view the updates available for any system supported by SUU.

SUU compares the versions of components currently installed on your system with update components packaged on the *Dell Server Updates* DVD. SUU then displays a comparison report of the versions and provides the option of updating the components.

For more information on SUU, see the *Dell OpenManage Server Update Utility User's Guide* available on the Dell Support website at [support.dell.com](#). This guide is also available on the *Dell Server Updates* DVD.

Supported Change Management Software on Microsoft Windows Operating Systems

[Table 3-1](#) lists the supported Dell OpenManage 5.3 change management software on systems running a supported Microsoft® Windows® operating system.

- I A D in the intersection of the operating system and the Dell system columns indicates support for Dell Update Packages.
- I An S in the intersection of the operating system and the Dell system columns indicates support for Server Update Utility.

 **NOTE:** Microsoft Windows Server 2008 is scheduled to be available in the first half of 2008. For latest information, see <http://www.microsoft.com/windowsserver2008/default.mspx>.

 **NOTE:** Server Update Utility is used for server updates and may not work on newly released Dell systems that do not receive any server updates.

Table 3-1. Supported Dell OpenManage Change Management Software on Systems Running Microsoft Windows Operating Systems

Dell System	Windows 2000	Windows Small Business Server 2003	Windows Server® 2003 x86	Windows Server 2003 x64	Windows Storage Server 2003 R2 x64	Windows Server 2008 x86	Windows Server 2008 x64	Windows Unified DataStorage Server x64										
Edition	Server	Advanced Server	Standard	Premium	Web	Standard	Enterprise	Standard	Express	Workgroup	Standard	Enterprise	Web	Standard	Enterprise	Standard	Datacenter	Standard + Enterprise
Service Pack	SP4	SP4	R2-SP2	R2-SP2	SP2	R2-SP2	R2-SP2	R2-SP2	SP2	R2 - SP2	R2 - SP2	R2 - SP2	R2 - SP2	Gold	Gold	Gold	Gold	Gold
M600					D	D	D	D	D					D	D	D	D	
M605					D	D	D	D	D					D	D	D	D	
R805					D	D	D	D	D					D	D	D	D	
R900					D	D	D	D	D					D	D	D	D	

Supported Change Management Software on Linux Operating Systems

[Table 3-2](#) lists the supported Dell OpenManage 5.3 change management software on systems running a supported Linux operating system.

- An A in the intersection of the operating system and the Dell system columns indicates support for Dell Update Packages.
 - An S in the intersection of the operating system and the Dell system columns indicates support for Server Update Utility.



NOTE: Server Update Utility is used for server updates and may not work on newly released Dell systems that do not receive any server updates.

Table 3-2. Supported Dell OpenManage Change Management Software on Systems Running Linux Operating Systems

	Service Pack	SP3	Gold	U5	Gold	Gold						
M600		D	D		D	D		D	D			D
M605		D	D		D	D		D	D			D
R805		D	D		D	D		D	D			D
R900		D	D		D	D		D	D			D
R200		D, S	D, S		D, S	D, S		D, S	D, S			D, S
6950		D, S	D, S			D, S			D, S			D, S
6850		D, S	D, S			D, S			D, S			D, S
6800		D, S	D, S			D, S			D, S			D, S
6650						D, S						D, S
6600						D, S						D, S
4600						D, S	D, S					D, S
2970		D, S	D, S		D, S	D, S		D, S	D, S			D, S
2950		D, S	D, S		D, S	D, S		D, S	D, S			D, S
2900		D, S	D, S		D, S	D, S		D, S	D, S			D, S
2850					D, S	D, S		D, S	D, S			D, S
2800					D, S	D, S		D, S	D, S			D, S
2650					D, S	D, S						D, S
2600					D, S	D, S						D, S
1955		D, S	D, S		D, S			D, S				
1950		D, S	D, S		D, S			D, S				
1900		D, S	D, S		D, S	D, S		D, S	D, S			D, S
1855					D, S			D, S				
1850					D, S			D, S				
1800					D, S			D, S				
1750					D, S	D, S						D, S
1655MC												
1650					D, S	D, S						
860		D	D, S		D, S	D, S		D, S	D, S			D, S
850					D, S	D, S		D, S	D, S			D, S
840		D	D, S		D, S	D, S		D, S	D, S			D, S
830					D, S	D, S		D, S	D, S			D, S
800					D, S	D, S		D, S	D, S			D, S
750					D, S	D, S						D, S
700					D, S	D, S						D, S
PowerEdge SC systems												
SC1435			D, S	D, S	D, S		D, S	D, S				D, S
SC1425				D, S	D, S		D, S	D, S	D, S			D, S

[Back to Contents Page](#)

[Back to Contents Page](#)

Supported Dell OpenManage Systems Management Software

Dell™ Systems Software Support Matrix 5.3

- [Supported Dell OpenManage Systems Management Software on Microsoft Windows Operating Systems](#)
- [Supported Dell OpenManage Systems Management Software on Linux Operating Systems](#)
- [Supported Dell OpenManage Software on Other Operating Systems](#)

Dell™ OpenManage™ systems management software is a suite of application programs for Dell systems. This software allows you to manage your system with proactive monitoring, notification, and remote access.

Dell OpenManage systems management software can be divided into:

- ı Dell OpenManage Server Administrator

Dell OpenManage Server Administrator is a comprehensive, one-to-one systems management solution, designed for system administrators, to manage systems locally and remotely on a network.

Server Administrator comprises the following services:

- ı Instrumentation Service
- ı Remote Access Service
- ı Storage Management Service

For more information about Dell OpenManage Server Administrator, see the *Dell OpenManage Server Administrator User's Guide*. This guide is available on the Dell Support website at [support.dell.com](#), on the *Dell Systems Documentation CD*, or on the *Dell Systems Management Tools and Documentation DVD*.

- ı Dell Systems Build and Update Utility

Dell Systems Build and Update Utility is designed to speed up the setup and performance of Dell systems. Dell Systems Build and Update Utility provides a series of intuitive and easy-to-follow interview screens that help guide you through the server installation process.

For more information about Systems Build and Update Utility, see the *Systems Build and Update Utility Readme* available on the *Dell Systems Build and Update Utility CD*.

Documentation Conventions for Dell Systems

[Table 2-1](#) lists all the Dell systems that belong to the x6xx, x7xx, x8xx, x9xx, xx0x groups.

Table 2-1. Documentation Conventions for Dell Systems

x6xx	x7xx	x8xx	x9xx	xx0x
1600SC	700	800	1900	T105
1650	750	830	1950	R200
1655MC	1750	840	1955	M600
2600		850	2900	M605
2650		860	2950	R805
4600		1800	2970	R900
6600		1850	6950	
6650		1855		
		2800		
		2850		
		6800		
		6850		

 **NOTE:** R805, M600, and M605 are scheduled to be available in Q4 CY07 - Q1 CY08.

Supported Dell OpenManage Systems Management Software on Microsoft Windows Operating Systems

[Table 2-2](#) lists the supported Dell OpenManage 5.3 installation and systems management software on systems running a supported Microsoft® Windows® operating system.

- ı An X in the intersection of the operating system and the Dell system columns indicates that Server Administrator and Dell Systems Build and Update Utility are supported on that operating system for the corresponding system.
- ı An A in the intersection of the operating system and the Dell system columns indicates systems that support Dell Systems Build and Update Utility but not Server Administrator.

- An asterisk (*) in the intersection of the operating system and the Dell system columns indicates operating system support for Dell systems that do not support Dell OpenManage software.

 **NOTE:** Microsoft Windows Server 2008 is scheduled to be available in the first half of 2008. For latest information, see <http://www.microsoft.com/windowsserver2008/default.mspx>.

Table 2-2. Supported Dell OpenManage Systems Management Software on Systems Running Microsoft Windows Operating Systems

Dell System	Windows 2000		Windows Small Business Server 2003		Windows Server® 2003 x86		Windows Server 2003 IA64	Windows Server 2003 x64	Windows Storage Server 2003 R2 x64		Windows Server 2008 x86		Windows Server 2008 x64		Windows Unified DataStorage Server x64							
	Edition	Server	Advanced Server	Standard	Premium	Web	Standard	Enterprise	Enterprise	Standard	Enterprise	Datacenter	Express	Workgroup	Standard	Enterprise	Web	Standard	Enterprise	Standard	Datacenter	Standard and Enterprise
	Service Pack	SP4	SP4	R2-SP2	R2-SP2	SP2	R2-SP2	R2-SP2	R2-SP2	R2-SP2	R2-SP2	R2-SP2	R2-SP2	R2-SP2	R2-SP2	R2-SP2	Gold	Gold	Gold	Gold	Gold	
M600						X X		X X X									X X X X					
M605						X X		X X X									X X X X					
R805						X X		X X X									X X X X					
R900						X X		X X X									X X X X					
R200			X X		X			X									X X					
6950						X X		X X X									X X X X					
6850		X X				X X		X X									X X X					
6800		X X				X X		X X									X X X					
6650		X X				X X											X X					
6600		X X				X X											X X					
4600		X X	X		X X												X X					
2970						X X X		X X X									X X X X					
2950		X X				X X X		X X X									X X X X					
2900		X X X X	X X			X X X		X X X									X X X X					
2850		X X				X X X		X X X									X X X X					
2800		X X X X	X X		X X			X X									X X X X					
2650		X X				X X X											X X X					
2600		X X X X	X X		X X												X X					
1955		X X				X X		X X									X X X					
1950		X X X X	X X X X	X X X X	X X X X			X X X X									X X X X	X				
1900		X X X X X	X X X X X	X X X X X	X X X X X			X X X X X									X X X X					
1855		X X				X X		X X									X X X					
1850		X X				X X X		X X X									X X X X					
1800		X X X X	X X X X	X X X X	X X X X			X X X X									X X X X					
1750		X X				X X X		X X X									X X X					
1655MC		X X				X X X		X X X														
1650		X X				X X X		X X X														
1600SC		X	X X	X X	X X																	
860		X	X X X X	X X X X	X X X X					X							X X	X X		X		
850		X				X X		X X		X							X X	X X		X		
840		X	X X X	X X X	X X X			X X X		X X X							X X	X X		X		
830		X	X X X	X X X	X X X			X X X		X X X							X X	X X		X		
800		X	X X X	X X X	X X X			X X X									X			X		
750		X				X X		X X									X X			X		
700		X	X X X	X X X	X X X			X X X									X X			X		
650		X				X X		X X									X X					

600SC		X		X	X	X																			
PowerVault™ systems																									
100														X	X										
500															X	X	X								
600															X	X									
64-bit systems																									
7250								X										X	X				X		
7150								X																X	
3250							X																		X
PowerEdge SC systems																									
SC0400	*		*	*	*	*																			
SC1420			*	*	*	*							*												
SC1425				*	*	*							*		*										
SC420			*	*	*	*																			
SC430			*	*	*	*						*													
SC1430			*	*	*	*					*								*	*	*				
SC440			*	*	*	*					*								*	*	*				
SC1435				*	*	*					*							*	*	*	*				
T105			*	*	*	*					*								*		*				

Supported Dell OpenManage Systems Management Software on Linux Operating Systems

[Table 2-3](#) lists the supported Dell OpenManage 5.3 installation and systems management software on systems running a supported Linux operating system.

- 1 An X in the intersection of the operating system and the Dell system columns indicates that Server Administrator and Dell Systems Build and Update Utility are supported on that operating system for the corresponding Dell system.
- 1 An A in the intersection of the operating system and the Dell system columns indicates systems that support Dell Systems Build and Update Utility but not Server Administrator.
- 1 An asterisk (*) in the intersection of the operating system and the Dell system columns indicates operating system support for Dell systems that do not support Dell OpenManage software.

Table 2-3. Supported Dell OpenManage Systems Management Software on Systems Running Linux Operating Systems

Dell System	Edition	SUSE® Linux Enterprise Server 9 (x86_64)	SUSE Linux Enterprise Server 10 (x86_64)	Red Hat® Enterprise Linux® 4.5 (x86_32)			Red Hat Enterprise Linux 4.5 (x86_64)			Red Hat Enterprise Linux 4.5 (ia64)			Red Hat Enterprise Linux Server 5 (x86_32)			Red Hat Enterprise Linux Server 5 (x86_64)
	Service Pack	SP3	Gold	WS	ES	AS	WS	ES	AS	WS	ES	AS	WS	ES	AS	Gold
M600	X	X		X	X		X	X					X			X
M605	X	X		X	X		X	X					X			X
R805	X	X		X	X		X	X					X			X
R900	X	X		X	X		X	X					X			X
R200	X	X		X	X		X	X					X			X
6950	X	X			X			X					X			X
6850	X	X			X			X					X			X
6800	X	X			X			X					X			X
6650					X								X			
6600					X								X			

4600				x	x				x		
2970	x	x		x	x	x	x		x	x	
2950	x	x		x	x	x	x		x	x	
2900	x	x		x	x	x	x		x	x	
2850				x	x	x	x		x	x	
2800				x	x	x	x		x	x	
2650				x	x				x		
2600				x	x				x		
1955	x	x	x	x	x	x	x		x	x	
1950	x	x	x	x	x	x	x		x	x	
1900	x	x		x	x	x	x		x	x	
1855			x	x	x	x	x		x	x	
1850			x	x	x	x	x		x	x	
1800			x	x	x	x	x		x	x	
1750				x	x				x		
1655MC											
1650				x	x						
860	x	x		x	x	x	x		x	x	
850				x	x	x	x		x	x	
840	x	x		x	x	x	x		x	x	
830				x	x	x	x		x	x	
800				x	x	x	x		x	x	
750				x	x				x		
700				x	x				x		

64-bit systems

7250									x		
3250								x	x		

PowerEdge SC systems

SC1420				*		*	*		*	*	
SC1425				A	A	A	A	A	A	A	
SC420				*					*	*	
SC430				*		*			*	*	
SC1430		*		*		*			*	*	
SC440		*		*		*			*	*	
SC1435		A		A	A	A	A		A	A	
T105	*	*	*						*	*	

Supported Dell OpenManage Software on Other Operating Systems

The following notes pertain to Dell OpenManage support on Novell NetWare and Red Hat Enterprise Linux 3 operating systems:

 **NOTE:** Dell OpenManage 5.3 is not supported on Novell® NetWare®. Dell OpenManage 4.5 was the last version to be supported on the Novell NetWare operating system. However, there are some Dell systems that support the Novell NetWare 6.5 Support Pack 5 operating system. For a list of these systems, see the Dell Support website at support.dell.com.

 **NOTE:** Dell OpenManage 5.3 is not supported on Red Hat Enterprise Linux 3. Dell OpenManage 5.1 was the last version to be supported on Red Hat Enterprise Linux 3. However, there are some Dell systems that support the Red Hat Enterprise Linux 3 operating system. For a list of these systems, see the Dell Support website at support.dell.com.

[Back to Contents Page](#)

Introduction

Dell™ Systems Software Support Matrix 5.3

- [What's New for 5.3](#)
- [Structure of This Guide](#)
- [Supported Operating Systems](#)

The Dell™ Systems Software Support Matrix helps identify Dell OpenManage™ software and other Dell components supported on various Dell systems.

This guide is intended for system administrators and technicians who want to obtain information about the various Dell systems available, the operating systems supported by these systems, and the Dell OpenManage components that can be installed on these systems.

What's New for 5.3

The following are the changes in Dell OpenManage version 5.3:

- ı Support for Red Hat® Enterprise Linux® Server 4.5 (x86_32), (x86_64), and (IA-64).
- ı Support for Microsoft® Windows Server® 2008 Web, Standard, and Enterprise Edition for 32 bit x86.
- ı Support for Microsoft Windows Server 2008 Core Standard, and Enterprise Edition for 32 bit x86.
- ı Support for Microsoft Windows Server 2008 Standard and DataCenter Edition for x64.
- ı Support for Microsoft Windows Vista® Business and Enterprise Edition.
- ı Support for Microsoft Windows Server 2008 Core Standard and Datacenter (x64) Editions

 **NOTE:** Microsoft Windows Server 2008 is scheduled to be available in the first half of 2008. For latest information, see <http://www.microsoft.com/windowsserver2008/default.mspx>.

- ı Added support for the following Dell systems: T105, M600, R805, R200, R900, and M605.

 **NOTE:** R805, M600, and M605 are scheduled to be available in Q4 CY07 - Q1 CY08.

- ı Added support for the following Dell PowerVault™ systems: 100, 500, and 600.
-

Structure of This Guide

This guide is organized on the basis of the Dell OpenManage suite of products and the operating systems on which these products are supported.

This guide contains the following chapters:

[Supported Dell OpenManage Systems Management Software](#)

This chapter contains information about Dell OpenManage systems management software on Dell systems running supported operating systems. Dell OpenManage systems management software includes:

- ı Dell OpenManage Server Administrator
- ı Dell Systems Build and Update Utility

[Supported Dell OpenManage Change Management Software](#)

This chapter contains information about Dell OpenManage change management software on Dell systems running supported operating systems. Dell OpenManage change management software includes:

- ı Dell Update Packages
- ı Server Update Utility

[Supported Dell OpenManage Systems Management Consoles](#)

This chapter contains information about Dell OpenManage systems management consoles on Dell systems running supported operating systems. Dell OpenManage systems management consoles include:

- ı Dell OpenManage IT Assistant

- | DRAC tools that include RACADM
- | BMC Management Utility (BMU) and IPMItool out-of-band
- | IPMItool in-band

Supported Remote Access Controllers and Solutions

This chapter contains information about Dell Remote Access Controllers (DRAC) and Integrated Dell Remote Access Controllers (iDRAC) versions and firmware, as well as supported Baseboard Management Controllers (BMC) and Chassis Management Controllers (CMC) IPMI protocol versions.

Supported Browsers

This appendix lists supported browsers on various operating systems for Dell systems.

Supported Operating Systems

This Software Support Matrix offers support information for the following operating systems:

Microsoft Windows Operating Systems

- | Microsoft® Windows Server® 2008 Web, Standard, and Enterprise (32-bit x86) Editions
- | Microsoft Windows Server 2008 Core Standard and Enterprise (32-bit x86) Editions
- | Microsoft Windows Server 2008 Standard and DataCenter (x64) Editions
- | Microsoft Windows Server 2008 Core Standard and Datacenter (x64) Editions
- | Microsoft Windows Server 2003 Web, Standard and Enterprise (32-bit x86) Editions with SP2
- | Microsoft Windows Server 2003 Standard, Enterprise, and DataCenter (x64) Editions with SP2
- | Microsoft Windows Server 2003 Enterprise (IA-64) Editions with SP2
- | Microsoft Windows Server 2003 R2 Standard and Enterprise (32-bit x86) Editions with SP2
- | Microsoft Windows Server 2003 R2 Standard, Enterprise, and DataCenter (x64) Editions with SP2
- | Microsoft Windows Server 2003 Enterprise Edition with SP2 for Itanium®-based Systems
- | Microsoft Windows 2000 Server and Advanced Server with SP4
- | Microsoft Windows Small Business Server 2003 R2 Standard and Premium Editions with SP1 and SP2
- | Microsoft Windows Storage Server 2003 R2 Express, Workgroup, Standard, and Enterprise x64 Editions with SP2
- | Microsoft Windows Unified Data Storage Server 2003 Standard and Enterprise x64 Editions
- | Microsoft Windows XP Professional with SP2 (32-bit x86)

Linux Operating Systems

- | SUSE® Linux Enterprise Server 10 (x86_64)
- | SUSE Linux Enterprise Server 9 with SP3 (x86_64)
- | Red Hat Enterprise Linux Server 5 (x86_32)
- | Red Hat Enterprise Linux Server 5 (x86_64)
- | Red Hat Enterprise Linux WS, ES, and AS (Version 4.5) (x86_32)
- | Red Hat Enterprise Linux WS, ES, and AS (Version 4.5) (x86_64)
- | Red Hat Enterprise Linux WS and AS (Version 4.5) (IA-64)

 **NOTE:** For Dell OpenManage information specific to VMware®, see the latest Installation Guide, Release Notes, and the Dell–VMware Compatibility Matrix under the **Resources → Support Documents** section at www.dell.com/vmware.

[Back to Contents Page](#)

[Back to Contents Page](#)

Supported Dell OpenManage Systems Management Consoles

Dell™ Systems Software Support Matrix 5.3

- [Supported Systems for Dell OpenManage IT Assistant](#)
- [Supported Systems for RACADM](#)
- [Supported Systems for BMU and IPMItool Out-of-Band](#)
- [Supported Systems for IPMItool In-Band](#)

Dell™ OpenManage™ systems management consoles provide the necessary tools for remote or one-to-many group system management. These tools also consolidate the management applications used on management workstations.

Dell OpenManage systems management consoles tools and applications include:

- 1 Dell OpenManage IT Assistant
- 1 DRAC tools that include remote RACADM
- 1 BMC Management Utility and IPMItool out-of-band
- 1 IPMItool In-Band

Supported Systems for Dell OpenManage IT Assistant

Dell OpenManage IT Assistant provides a central point of access to monitor and manage systems on a local area network (LAN) or wide area network (WAN). By allowing an administrator a comprehensive view across the enterprise, IT Assistant can increase system uptime, automate repetitive tasks, and prevent interruption in critical business operations.

For more information on IT Assistant, see the *Dell OpenManage IT Assistant User's Guide* available on the Dell Support website at [support.dell.com](#), on the *Dell Systems Documentation* CD, or on the *Dell Systems Management Tools and Documentation* DVD.

Supported Microsoft Windows Operating Systems for IT Assistant

[Table 4-1](#) shows supported Microsoft Windows® operating systems for IT Assistant. An X in the operating system column indicates IT Assistant support.



NOTE: Microsoft Windows Server 2008 is scheduled to be available in the first half of 2008. For latest information, see <http://www.microsoft.com/windowsserver2008/default.mspx>.

Table 4-1. Supported Microsoft Windows Operating Systems for IT Assistant

	Windows 2000		Windows Server 2003 x86			Windows Server 2003 x64			Windows Storage Server 2003 R2 x64				Windows Server 2008 x86			Windows Server 2008 x64		Windows XP Professional x86	Windows Vista	
	Edition	Server	Advanced Server	Web	Standard	Enterprise	Standard	Enterprise	Datacenter	Express	Workgroup	Standard	Enterprise	Standard+ Enterprise	Web	Standard	Enterprise	Standard	Datacenter	Business/ Enterprise
Service Pack	SP4	SP4	R2-SP2	R2-SP2	R2-SP2	R2-SP2	R2-SP2	R2-SP2	R2-SP2	R2-SP2	R2-SP2	R2-SP2	R2-SP2	Gold	Gold	Gold	Gold	Gold	SP2	Gold
IT Assistant	X	X	X	X	X									X	X	X			X	X

Supported Linux Operating Systems for IT Assistant

IT Assistant cannot be installed on Dell systems running Red Hat® Enterprise Linux™ or SUSE® Linux Enterprise Server operating systems. These systems can, however, launch IT Assistant through supported browsers (Firefox® version 1.5). For more information on supported browsers, see [Supported Browsers](#).

Supported Systems for RACADM

RACADM is a command-line utility that enables administrators to configure and replicate settings across multiple Dell remote access controllers (RACs). The RACADM utility supports operations through the use of command-line parameters, switches, and a configuration file that contains all data required to configure a RAC.

For more information on the RACADM utility, see the *Dell Remote Access Controller Racadm User's Guide* available on the Dell Support website at support.dell.com, on the *Dell Systems Documentation* CD, or on the *Dell Systems Management Tools and Documentation* DVD.

Supported Microsoft Windows Operating Systems for the RACADM Utility

[Table 4-2](#) shows supported Microsoft Windows operating systems for the RACADM utility. An X in the operating system column indicates support for the RACADM utility.

Table 4-2. Supported Microsoft Windows Operating Systems for RACADM

	Windows 2000		Windows Server 2003 x86		Windows Server 2003 x64		Windows Storage Server 2003 R2 x64				Windows Server 2008 x86			Windows Server 2008 x64		Windows XP Professional x86		Windows Vista
	Edition	Service Pack	Server	Advanced Server	Web	Standard	Enterprise	Datacenter	Express	Workgroup	Standard	Enterprise	Standard + Enterprise	Web	Standard	Enterprise	Datacenter	Business/Enterprise
SP4	SP4	SP4	SP2	SP2	SP2	SP2	SP2	SP2	R2-SP2	R2-SP2	R2-SP2	R2-SP2	Gold	Gold	Gold	Gold	Gold	
Remote RACADM	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	

Supported Linux Operating Systems for the RACADM Utility

[Table 4-3](#) shows supported Linux operating systems for the RACADM utility. An X in the operating system column indicates support for the RACADM utility.

Table 4-3. Supported Linux Operating Systems for RACADM

	SUSE Linux Enterprise Server 9 (x86_64)		SUSE Linux Enterprise Server 10 (x86_64)		Red Hat Enterprise Linux 4.5 (x86_32)			Red Hat Enterprise Linux 4.5 (x86_64)			Red Hat Enterprise Linux Server 5 (x86_32)			Red Hat Enterprise Linux Server 5 (x86_64)		
	Edition	Service Pack			WS	ES	AS	WS	ES	AS	WS	ES	AS	Gold	Gold	
SP3			Gold		U5	U5	U5	U5	U5	U5	U5	U5	U5	Gold	Gold	
Remote RACADM	X		X		X	X	X	X	X	X	X	X	X	X	X	X

Supported Systems for BMU and IPMI tool Out-of-Band

BMC Management Utility (BMU) is a utility to access Baseboard Management Controller (BMC) and perform management activities. BMU allows remote, out-of-band LAN and/or serial port power control, event log access, and console redirection.

IPMItool is a CLI utility that helps in configuring and managing devices using the IPMI version 1.5 and later protocol. IPMItool supports out-of-band (OOB) access (over a LAN or through the serial port) to a single system at a time. IPMItool also supports in-band access.

For more information on BMU and IPMItool out-of-band, see the *Dell OpenManage Baseboard Management Controller Utilities User's Guide* available on the Dell Support website at support.dell.com, on the Dell Systems Documentation CD, or on the *Dell Systems Management Tools and Documentation DVD*.

Supported Microsoft Windows Operating Systems for BMU and IPMItool Out-of-Band

[Table 4-4](#) shows supported Microsoft Windows operating systems for BMU IPMItool out-of-band. An X in the operating system column indicates BMU and IPMItool out-of-band support.

Table 4-4. Supported Microsoft Windows Operating Systems for BMU and IPMI tool out-of-band

Supported Linux Operating Systems for BMU and IPMI tool Out-of-Band

[Table 4-5](#) shows supported Linux operating systems for BMU and IPMItool out-of-band. An X in the operating system column indicates BMU and IPMItool out-of-band support.

Table 4-5. Supported Linux Operating Systems for BMU and IPMI tool Out-of-Band

Supported Systems for IPMI tool In-Band

IPMItool in-band also helps in configuring and managing devices.

For more information on IPMItool, see the *Dell OpenManage Baseboard Management Controller Utilities User's Guide* available on the Dell Support website at support.dell.com, on the *Dell Systems Documentation* CD, or on the *Dell Systems Management Tools and Documentation* DVD.

 **NOTE:** The operating systems supported by IPMItool out-of-band are the same as those supported by BMU. For more information on supported operating systems for BMU and IPMItool out-of-band, see "[Supported Systems for BMU and IPMItool Out-of-Band](#)".

Supported Microsoft Windows Operating Systems for IPMI tool In-Band

[Table 4-6](#) shows supported Microsoft Windows operating systems for IPMItool in-band. An X in the operating system column indicates IPMItool in-band support.

Table 4-6. Supported Microsoft Windows Operating Systems for IPMI tool In-Band

	Windows Server 2003 x86			Windows Server 2003 x64			Windows Storage Server 2003 R2 x64			Windows Server 2008 x86			Windows Server 2008 x64	
Edition	Web	Standard	Enterprise	Standard	Enterprise	Datacenter	Express	Workgroup	Standard	Enterprise	Standard	Enterprise	Standard	Datacenter
Service Pack	SP2	SP2	SP2	SP2	SP2	SP2	R2-SP2	R2-SP2	R2-SP2	Gold	Gold	Gold	Gold	Gold
IPMI tool in-band	X	X	X	X	X		X	X	X	X	X	X	X	X

Supported Linux Operating Systems for IPMI tool In-Band

[Table 4-7](#) shows supported Linux operating systems for IPMItool in-band. An X in the operating system column indicates IPMItool in-band support.

Table 4-7. Supported Linux Operating Systems for IPMI tool In-Band

	SUSE Linux Enterprise Server 9 (x86_64)	SUSE Linux Enterprise Server 10 (x86_64)	Red Hat Enterprise Linux 4.5 (x86_32)			Red Hat Enterprise Linux 4.5 (x86_64)			Red Hat Enterprise Linux Server 5 (x86_32)			Red Hat Enterprise Linux Server 5 (x86_64)	
Edition			WS	ES	AS	WS	ES	AS					
Service Pack	SP3	Gold	U5	U5	U5	U5	U5	U5				Gold	Gold
IPMI tool in-band	X	X	X	X	X	X	X	X	X	X	X	X	X

[Back to Contents Page](#)

Supported Remote Access Controllers and Solutions

Dell™ Systems Software Support Matrix 5.3

Dell™ Remote Access Controller (DRAC) is a systems management hardware and software solution designed to provide remote management capabilities, crashed system recovery, and power control functions.

By communicating with the system's Baseboard Management Controller (BMC), DRAC (when installed) can be configured to send e-mail alerts for warnings or errors related to voltages, temperatures, intrusion, and fan speeds. DRAC also logs event data and the most recent crash screen (for systems running the Microsoft Windows operating system only) to help diagnose the probable cause of a system crash.

For more information on DRAC, see the *Remote Access Controller User's Guide* available on the Dell Support website at support.dell.com, on the *Dell Systems Documentation* CD, or on the *Dell Systems Management Tools and Documentation* DVD.

Supported Remote Access Controller versions and firmware, as well as supported BMC IPMI protocol versions, are listed in [Table 5-1](#). [Table 5-1](#) lists the following RAC types:

- ı Integrated Dell Remote Access Controller (iDRAC)
- ı Dell Remote Access Controller 5 (DRAC 5)
- ı Dell Remote Access Controller/Modular Computer (DRAC/MC)
- ı Dell Remote Access Controller 4 (DRAC 4)
- ı Dell Remote Access Controller III/XT (DRAC III/XT)
- ı Dell Embedded Remote Access/Modular Computer (ERA/MC) controller
- ı Dell Embedded Remote Access/Option (ERA/O) controller
- ı Dell Embedded Remote Access (ERA) controller
- ı Dell Remote Access Card III (DRAC III)

Table 5-1. Supported Remote Access Controllers and Solutions

Dell System	Remote Access Controllers (RACs)		Baseboard Management Controller (BMC)		
	RAC Type	Supported RAC Firmware Version	Integrated BMC	BMC Firmware Version	Supported IPMI Protocol Versions
M600	IDRAC	1.0	X (CMC)	1.29 or later	2.0
R805	DRAC 5	1.3.0	X	1.29 or later	2.0
R900	DRAC 5	1.3.0	X	1.29 or later	2.0
M605	IDRAC	1.0	X (CMC)	1.29 or later	2.0
R200	DRAC 4	1.6.0	X	1.29 or later	2.0
6950*	DRAC 5	1.3.0	X	1.29 or later	2.0
2970*	DRAC 5	1.3.0	X	1.29 or later	2.0
2950*	DRAC 5	1.3.0	X	1.29 or later	2.0
2900*	DRAC 5	1.3.0	X	1.29 or later	2.0
1955	DRAC/MC	1.5.0	X	1.10 or later	2.0
1950*	DRAC 5	1.3.0	X	1.29 or later	2.0
1900*	DRAC 5	1.3.0	X	1.29 or later	2.0
6850	DRAC 4	1.6.0	X	1.40 or later	1.5
6800	DRAC 4	1.6.0	X	1.40 or later	1.5
2850	DRAC 4	1.6.0	X	1.23 or later	1.5
2800	DRAC 4	1.6.0	X	1.23 or later	1.5
1855	DRAC/MC	1.5.0	X	1.01 or later	1.5
1850	DRAC 4	1.6.0	X	1.23 or later	1.5
1800	DRAC 4	1.6.0	X	1.23 or later	1.5
860	DRAC 4	1.6.0	X	1.67 or later	1.5
850	DRAC 4	1.6.0	X	1.44 or later	1.5
840	DRAC 4	1.6.0	X	1.67 or later	1.5
830	DRAC 4	1.6.0	X	1.44 or later	1.5
800	DRAC 4	1.6.0	X	1.30 or later	1.5
1750	ERA/O	3.3.5			
750	DRAC III/XT	3.3.5			
700	DRAC III/XT	3.3.5			

6650	DRAC III	3.3.5			
6600	DRAC III	3.3.5			
4600	DRAC III	3.3.5			
2650	ERA	3.3.5			
2600	ERA/O	3.3.5			
1655MC	ERA/MC	1.4.4			
1650	ERA/O	3.3.5			
1600SC	ERA	3.3.5			
650	DRAC III	3.3.5			
600SC					
PowerVault™ systems					
100	DRAC 4	1.6.0	X	1.67 or later	1.5
500	DRAC 5	1.3.0	X	1.29 or later	2.0
600	DRAC 5	1.3.0	X	1.29 or later	2.0
64-bit systems					
7250					
7150	DRAC III	3.3.5			
3250					
PowerEdge SC systems					
SC1435			X	1.0 or later	2.0
SC1430					
SC1425			X	1.30 or later	1.5
SC1420					
SC440					
SC430					
SC420					
T105					

* DRAC 5 support on SUSE Linux Enterprise Server 10 is limited to the managed system and to the CLI only. DRAC 5 does not support the out-of-band GUI on the management station.

[Back to Contents Page](#)