

**Lifecycle Controller Operating System Driver  
Pack Version 15.04.06  
Reference Guide**



# Notes, cautions, and warnings

 **NOTE:** A NOTE indicates important information that helps you make better use of your computer.

 **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

**Copyright © 2015 Dell Inc. All rights reserved.** This product is protected by U.S. and international copyright and intellectual property laws. Dell™ and the Dell logo are trademarks of Dell Inc. in the United States and/or other jurisdictions. All other marks and names mentioned herein may be trademarks of their respective companies.

2015 - 05

Rev. A00

# Contents

<b>1 Overview.....</b>	<b>4</b>
Accessing Documents From Dell Support Site.....	4
Contacting Dell.....	5
<b>2 Dell PowerEdge R530XD.....</b>	<b>6</b>

# Overview


The *Lifecycle Controller OS Driver Pack Reference Guide* provides information about the operating systems (Windows and Linux) that are compatible with the driver pack for a specific 13th generation Dell PowerEdge server. The driver pack contains the drivers needed for OS deployment using Lifecycle Controller. For information on OS deployment, see the *Lifecycle Controller GUI v2.10.10.10 For 12<sup>th</sup> and 13<sup>th</sup> Generation PowerEdge Servers User's Guide* available at [dell.com/esmmanuals](http://dell.com/esmmanuals).

## Accessing Documents From Dell Support Site

You can access the required documents in one of the following ways:

- Using the following links:
  - For all Enterprise Systems Management documents — [dell.com/softwaresecuritymanuals](http://dell.com/softwaresecuritymanuals)
  - For OpenManage documents — [dell.com/openmanagemanuals](http://dell.com/openmanagemanuals)
  - For Remote Enterprise Systems Management documents — [dell.com/esmmanuals](http://dell.com/esmmanuals)
  - For OpenManage Connections Enterprise Systems Management documents — [dell.com/OMConnectionsEnterpriseSystemsManagement](http://dell.com/OMConnectionsEnterpriseSystemsManagement)
  - For Serviceability Tools documents — [dell.com/serviceabilitytools](http://dell.com/serviceabilitytools)
  - For OpenManage Connections Client Systems Management documents — [dell.com/dellclientcommandssuitemanuals](http://dell.com/dellclientcommandssuitemanuals)
- From the Dell Support site:
  - a. Go to [dell.com/support/home](http://dell.com/support/home).
  - b. Under **Select a product** section, click **Software & Security**.
  - c. In the **Software & Security** group box, click the required link from the following:
    - **Enterprise Systems Management**
    - **Remote Enterprise Systems Management**
    - **Serviceability Tools**
    - **Client Systems Management**
    - **Connections Client Systems Management**
  - d. To view a document, click the required product version.
- Using search engines:
  - Type the name and version of the document in the search box.

## Contacting Dell

 **NOTE:** If you do not have an active Internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.

Dell provides several online and telephone-based support and service options. Availability varies by country and product, and some services may not be available in your area. To contact Dell for sales, technical support, or customer service issues:

1. Go to **dell.com/support**.
2. Select your support category.
3. Verify your country or region in the **Choose a Country/Region** drop-down list at the bottom of the page.
4. Select the appropriate service or support link based on your need.

## Dell PowerEdge R530XD

Operating System	Component	Device Name	Vendor Revision
Windows Server 2012 R2 64-bit	Chipset	Intel C610 Series Chipset Drivers	9.4.2.1019
Windows Server 2012 R2 64-bit	Network	Intel NIC drivers	16.5.0
Red Hat Enterprise Linux 7.0 64-bit	Network	Intel NIC Linux KMP and KMOD RPMs for RedHat and Novell SLES	16.5.0
Windows Server 2012 R2 64-bit	SAS Non-RAID	Dell 12Gbps HBA	2.50.75.01
Windows Server 2012 R2 64-bit	SAS RAID	PERC H330/H730/H730P/H830/FD33xS/FD33xD Controllers	6.602.12.00
Windows Server 2012 R2 64-bit	SCSI non-RAID	Dell Backplane	NA
Red Hat Enterprise Linux 7.0 64-bit	System Utilities	RHEL 7.0 64 bit UPDATE	0