Dell EMC OpenManage Enterprise Version 3.7

Support Matrix



Notes, cautions, and warnings

(i) NOTE: A NOTE indicates important information that helps you make better use of your product.

CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

MARNING: A WARNING indicates a potential for property damage, personal injury, or death.

© 2017 - 2021 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

Introduction

OpenManage Enterprise is a systems management and monitoring web application delivered as a virtual appliance. It provides a comprehensive view of the Dell EMC servers, chassis, storage, and network switches on the enterprise network. With OpenManage Enterprise, a web-based one-to-many systems management application, users can:

- Discover devices in a data center environment.
- View hardware inventory and monitor health of devices.
- View and manage alerts received by the appliance and configure alert policies.
- Monitor firmware / driver versions and Manage firmware / driver updates on devices with firmware baselines.
- Manage remote tasks (such as power control) on devices.
- Manage configuration settings across devices using deployment templates.
- Manage virtual identity settings across devices using intelligent identity pools.
- Detect and remediate configuration deviations across devices using configuration baselines.
- Retrieve and monitor warranty information for devices.
- Group devices into static or dynamic groups.
- Create and manage OpenManage Enterprise users.

(i) NOTE:

 OpenManage Enterprise's system management and monitoring is best suited for enterprise LANs and is not recommended for usage over WANs.

Topics:

- Supported agents and interfaces
- Supported devices
- · Supported hypervisors on management stations
- Supported operating systems for in-band device management
- Supported browsers
- Supported plugins
- Minimum recommended hardware
- Contacting Dell

Supported agents and interfaces

NOTE: For more information about the agents and interfaces that are listed, see their respective product documentation available on the support site.

Table 1. Agents and interfaces supported by OpenManage Enterprise version 3.7

| Dell EMC system agents and interfaces | Supported version |
|--|---|
| Dell Chassis Management Controller (CMC) | For the PowerEdge M1000e chassis — 6.20 and later versions |
| | For the PowerEdge VRTX chassis — 3.21 and later versions |
| | For the PowerEdge FX2 and FX2s sleds — 2.21 and later versions |
| Dell EMC OpenManage Enterprise—Modular | For the PowerEdge MX7000 chassis—1.2 and later versions |
| iDRAC9 | All the YX4X (14G) and YX5X (15G) PowerEdge servers — • iDRAC 4.20.xx.xx • iDRAC 4.40.xx.xx • iDRAC 5.00.xx.xx |

Table 1. Agents and interfaces supported by OpenManage Enterprise version 3.7 (continued)

| Dell EMC system agents and interfaces | Supported version |
|---------------------------------------|---|
| iDRAC7 and iDRAC8 | All the YX3X (13G) and YX2X (12G) PowerEdge servers — • 2.70.xx.xx • 2.75.xx.xx • 2.80.xx.xx i) NOTE: Ensure that Express or Enterprise licenses are available to perform firmware updates. |
| iDRAC6 | All the YX1X (11G) PowerEdge servers: For the monolithic systems — 1.98 and later versions For the modular systems — 3.65 and later versions |
| Dell EMC Repository Manager | 3.0 and later versions |
| Networking OS | 9.13.0.0, 9.14.0.0, 10.5.0.0 and later versions, except for: • Dell Networking Z9000 — 9.7P19 and later versions • Networking OS switches MX5108N, MX9116N — minimum firmware version 10.5 (OS 10) (i) NOTE: For a complete list of supported networking devices, refer to the Supported Dell Networking devices—previously Dell Force10 devices on page 12. |

Supported devices

Supported Dell EMC PowerEdge servers

(i) NOTE: In the PowerEdge server name format YXXX; 'Y' denotes alphabets, for example M, MX, R, or T, and 'X' denotes numbers.

The following table lists the supported PowerEdge servers.

Table 2. Supported PowerEdge servers

| | Supported OpenManage Enterprise features | | | | |
|--|--|------------------------------|---------------------------------|---|--|
| PowerEdge servers | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment | |
| YX1X systems i NOTE: The appliance the limited capability | | tus for the monitored 11G | Servers with iDRAC6 as L | Inknown . This is due to | |
| PowerEdge R210 II | Yes | Yes | No | No | |
| PowerEdge R515 | Yes | Yes | No | No | |
| PowerEdge R815 | Yes | Yes | No | No | |
| PowerEdge R415 | Yes | Yes | No | No | |
| PowerEdge R715 | Yes | Yes | No | No | |
| PowerEdge T110 II | Yes | Yes | No | No | |
| PowerEdge M915 | Yes | Yes | No | No | |
| YX2X systems | | | | | |
| PowerEdge M420 | Yes | Yes | Yes | Yes | |

Table 2. Supported PowerEdge servers (continued)

| | Supported OpenManage Enterprise features | | | | |
|-------------------|--|------------------------------|-----------------------------|---|--|
| PowerEdge servers | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment | |
| PowerEdge M520 | Yes | Yes | Yes | Yes | |
| PowerEdge M620 | Yes | Yes | Yes | Yes | |
| PowerEdge M820 | Yes | Yes | Yes | Yes | |
| PowerEdge R220 | Yes | Yes | Yes | Yes | |
| PowerEdge R320 | Yes | Yes | Yes | Yes | |
| PowerEdge R420 | Yes | Yes | Yes | Yes | |
| PowerEdge R520 | Yes | Yes | Yes | Yes | |
| PowerEdge R620 | Yes | Yes | Yes | Yes | |
| PowerEdge R720 | Yes | Yes | Yes | Yes | |
| PowerEdge R720xd | Yes | Yes | Yes | Yes | |
| PowerEdge R820 | Yes | Yes | Yes | Yes | |
| PowerEdge R920 | Yes | Yes | Yes | Yes | |
| PowerEdge T320 | Yes | Yes | Yes | Yes | |
| PowerEdge T420 | Yes | Yes | Yes | Yes | |
| PowerEdge T620 | Yes | Yes | Yes | Yes | |
| PowerEdge FC420 | Yes | Yes | Yes | Yes | |
| PowerEdge FC620 | Yes | Yes | Yes | Yes | |
| PowerEdge FM120x4 | Yes | Yes | Yes | Yes | |
| YX3X systems | | | | | |
| PowerEdge M630 | Yes | Yes | Yes | Yes | |
| PowerEdge M830 | Yes | Yes | Yes | Yes | |
| PowerEdge T130 | Yes | Yes | Yes | Yes | |
| PowerEdge T330 | Yes | Yes | Yes | Yes | |
| PowerEdge T430 | Yes | Yes | Yes | Yes | |
| PowerEdge T630 | Yes | Yes | Yes | Yes | |
| PowerEdge R230 | Yes | Yes | Yes | Yes | |
| PowerEdge R330 | Yes | Yes | Yes | Yes | |
| PowerEdge R430 | Yes | Yes | Yes | Yes | |
| PowerEdge R530 | Yes | Yes | Yes | Yes | |
| PowerEdge R530xd | Yes | Yes | Yes | Yes | |
| PowerEdge R630 | Yes | Yes | Yes | Yes | |
| PowerEdge R730 | Yes | Yes | Yes | Yes | |
| PowerEdge R730xd | Yes | Yes | Yes | Yes | |
| PowerEdge R830 | Yes | Yes | Yes | Yes | |
| PowerEdge R930 | Yes | Yes | Yes | Yes | |

Table 2. Supported PowerEdge servers (continued)

| | Supported OpenManage Enterprise features | | | | | |
|-------------------|--|------------------------------|-----------------------------|---|--|--|
| PowerEdge servers | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment | | |
| PowerEdge FC430 | Yes | Yes | Yes | Yes | | |
| PowerEdge FC630 | Yes | Yes | Yes | Yes | | |
| PowerEdge FC830 | Yes | Yes | Yes | Yes | | |
| YX4X systems | | | | | | |
| PowerEdge M640 | Yes | Yes | Yes | Yes | | |
| PowerEdge R240 | Yes | Yes | Yes | Yes | | |
| PowerEdge R340 | Yes | Yes | Yes | Yes | | |
| PowerEdge R440 | Yes | Yes | Yes | Yes | | |
| PowerEdge R540 | Yes | Yes | Yes | Yes | | |
| PowerEdge R640 | Yes | Yes | Yes | Yes | | |
| PowerEdge R6415 | Yes | Yes | Yes | Yes | | |
| PowerEdge R740 | Yes | Yes | Yes | Yes | | |
| PowerEdge R740xd | Yes | Yes | Yes | Yes | | |
| PowerEdge R740xd2 | Yes | Yes | Yes | Yes | | |
| PowerEdge R7415 | Yes | Yes | Yes | Yes | | |
| PowerEdge R7425 | Yes | Yes | Yes | Yes | | |
| PowerEdge R840 | Yes | Yes | Yes | Yes | | |
| PowerEdge R940 | Yes | Yes | Yes | Yes | | |
| PowerEdge R940XA | Yes | Yes | Yes | Yes | | |
| PowerEdge T140 | Yes | Yes | Yes | Yes | | |
| PowerEdge T340 | Yes | Yes | Yes | Yes | | |
| PowerEdge T440 | Yes | Yes | Yes | Yes | | |
| PowerEdge T640 | Yes | Yes | Yes | Yes | | |
| PowerEdge FC640 | Yes | Yes | Yes | Yes | | |
| PowerEdge MX740c | Yes | Yes | Yes | Yes | | |
| PowerEdge MX840c | Yes | Yes | Yes | Yes | | |
| YX5X systems | | | | | | |
| PowerEdge R6515 | Yes | Yes | Yes | Yes | | |
| PowerEdge R6525 | Yes | Yes | Yes | Yes | | |
| PowerEdge R7515 | Yes | Yes | Yes | Yes | | |
| PowerEdge R7525 | Yes | Yes | Yes | Yes | | |
| PowerEdge R650 | Yes | Yes | Yes | Yes | | |
| PowerEdge R750 | Yes | Yes | Yes | Yes | | |
| PowerEdge R750xa | Yes | Yes | Yes | Yes | | |
| PowerEdge MX750c | Yes | Yes | Yes | Yes | | |

Table 2. Supported PowerEdge servers (continued)

| | Supported OpenManage Enterprise features | | | |
|--------------------|--|------------------------------|-----------------------------|---|
| PowerEdge servers | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment |
| PowerEdge R450 * | Yes | Yes | Yes | Yes |
| PowerEdge R550 * | Yes | Yes | Yes | Yes |
| PowerEdge R650xs * | Yes | Yes | Yes | Yes |
| PowerEdge R750xs * | Yes | Yes | Yes | Yes |

i NOTE: * indicates device added in this release.

The following table lists the supported PowerEdge C-Series servers.

Table 3. PowerEdge C-Series servers

| | Supported OpenManage Enterprise features | | | | |
|----------------------------|--|------------------------------|-----------------------------|---|--|
| PowerEdge C-Series servers | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment | |
| PowerEdge C4130 | Yes | Yes | Yes | Yes | |
| PowerEdge C4140 | Yes | Yes | Yes | Yes | |
| PowerEdge C6320 | Yes | Yes | Yes | Yes | |
| PowerEdge C6320p | Yes | Yes | Yes | Yes | |
| PowerEdge C6420 | Yes | Yes | Yes | Yes | |
| PowerEdge C6525 | Yes | Yes | Yes | Yes | |
| PowerEdge C6520 | Yes | Yes | Yes | Yes | |

i NOTE: * indicates device added in this release.

Supported Dell EMC XC Series Web-Scale converged appliances

The following table lists the supported XC Series Web-Scale converged appliances.

Table 4. Supported XC Series Web-Scale converged appliances

| VC Caulas Wak | Supported OpenManage Enterprise features | | | | | | |
|---|--|------------------------------|-----------------------------|---|--|--|--|
| XC Series Web- Scale converged appliances | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment | | | |
| XC6320-6 | Yes | Yes | No | No | | | |
| XC6320-6AF | Yes | Yes | No | No | | | |
| XC430 Xpress | Yes | Yes | No | No | | | |
| XC430-4 | Yes | Yes | No | No | | | |
| XC430-8 | Yes | Yes | No | No | | | |
| XC630-10 | Yes | Yes | No | No | | | |
| XC630-10AF | Yes | Yes | No | No | | | |
| XC630-10P | Yes | Yes | No | No | | | |
| | | | | | | | |

Table 4. Supported XC Series Web-Scale converged appliances (continued)

| VC Carias Wak | | Supported OpenMan | age Enterprise features | |
|---|-------------------------|------------------------------|-----------------------------|---|
| XC Series Web- Scale converged appliances | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment |
| XC640 | Yes | Yes | No | No |
| XC730-16G | Yes | Yes | No | No |
| XC730xd-12 | Yes | Yes | No | No |
| XC730xd-12C | Yes | Yes | No | No |
| XC730xd-12R | Yes | Yes | No | No |
| XC730xd-12R Xpress | Yes | Yes | No | No |
| XC730xd-12S | Yes | Yes | No | No |
| XC730xd-24 | Yes | Yes | No | No |
| XC730xd-24S | Yes | Yes | No | No |
| XC740xd | Yes | Yes | No | No |
| XC6420 | Yes | Yes | No | No |
| XC6400 | Yes | Yes | No | No |
| XC940 | Yes | Yes | No | No |
| XC640ENT XC Core | Yes | Yes | No | No |
| XC740xdENT XC Core | Yes | Yes | No | No |
| XC940ENT XC Core | Yes | Yes | No | No |
| XC6420ENT XC Core | Yes | Yes | No | No |
| XC6400 ENCLOSURE XC Core | Yes | Yes | No | No |
| XCXR2 Core | Yes | Yes | No | No |
| XC740xd2 Core | Yes | Yes | No | No |
| XC6515-8 | Yes | Yes | No | No |

NOTE: The SATADOM-specific information is not displayed in the device inventory of OpenManage Enterprise.

Supported Dell EMC XE Series

The following table lists the supported XE Series devices.

Table 5. Supported XE Series devices

| | Supported OpenManage Enterprise features | | | |
|-------------------|--|------------------------------|-----------------------------|---|
| XE Series Devices | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment |
| PowerEdge XE2420 | Yes | Yes | Yes | Yes |
| PowerEdge XE7420 | Yes | Yes | Yes | Yes |
| PowerEdge XE7440 | Yes | Yes | Yes | Yes |

Table 5. Supported XE Series devices (continued)

| | Supported OpenManage Enterprise features | | | | |
|--------------------|--|------------------------------|-----------------------------|---|--|
| XE Series Devices | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment | |
| PowerEdge XE8545 * | Yes | Yes | Yes | Yes | |

i NOTE: * indicates device added in this release.

Supported Dell EMC XR Series

The following table lists the supported XR Series devices.

Table 6. Supported XR Series devices

| | Supported OpenManage Enterprise features | | | |
|-------------------|--|------------------------------|-----------------------------|---|
| XR Series Devices | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment |
| PowerEdge XR2 | Yes | Yes | Yes | Yes |
| PowerEdge XR11 | Yes | Yes | Yes | Yes |
| PowerEdge XR12 | Yes | Yes | Yes | Yes |

Supported Dell EMC chassis devices

The following table lists the supported chassis devices.

Table 7. Supported Dell EMC chassis devices

| | Supported OpenManage Enterprise features | | | | | |
|---------------------------|--|------------------------------|-----------------------------|---|--|--|
| PowerEdge chassis devices | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment | | |
| PowerEdge MX7000 | Yes | Yes | Yes | Yes | | |
| PowerEdge M1000e | Yes | Yes | Yes | Yes | | |
| PowerEdge VRTX | Yes | Yes | Yes | Yes | | |
| PowerEdge FX2 | Yes | Yes | Yes | Yes | | |
| PowerEdge FX2s | Yes | Yes | Yes | Yes | | |

Supported Input/Output Aggregators (IOA)

The following table lists the chassis and the Input/Output Aggregators which support IOA template deployment.

Table 8. Supported Input/Output Aggregators (IOA)

| PowerEdge chassis Supported IOAs Managing device configurations and deployment | | Managing device configurations and deployment | Dell Networking OS version |
|--|---------|---|----------------------------|
| PowerEdge M1000e | MIOA | Yes | OS9 |
| PowerEdge FX2s | FN2210S | Yes | OS9 |
| PowerEdge FX2s | FN410S | Yes | OS9 |
| PowerEdge FX2s | FN410T | Yes | OS9 |

Supported Dell EMC VxRail Hyper-converged appliances

The following table lists the supported VxRail Hyper-converged appliances.

Table 9. Supported VxRail Hyper-converged appliances

| W. Dail H | | Supported OpenMana | age Enterprise features | 1 |
|--|-------------------------|------------------------------|-----------------------------|---|
| VxRail Hyper- converged appliances | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment |
| VxRail D560F | Yes | Yes | No | No |
| VxRail E460 | Yes | Yes | No | No |
| VxRail E460F | Yes | Yes | No | No |
| VxRail E560 | Yes | Yes | No | No |
| VxRail E560F | Yes | Yes | No | No |
| VxRail E665 | Yes | Yes | No | No |
| VxRail E665N | Yes | Yes | No | No |
| VxRail G560 | Yes | Yes | No | No |
| VxRail G560F | 560F Yes Yes | | No | No |
| VxRail P470 | Yes | Yes | No | No |
| VxRail P470F | Yes | Yes | No | No |
| VxRail P470N | Yes | Yes | No | No |
| VxRail P570 | Yes | Yes | No | No |
| VxRail P570F | Yes | Yes | No | No |
| VxRail P675F | Yes | Yes | No | No |
| VxRail P675N | Yes | Yes | No | No |
| VxRail S470 | Yes | Yes | No | No |
| VxRail S570 | Yes | Yes | No | No |
| VxRail V470 | Yes | Yes | No | No |
| VxRail V470F | Yes | Yes | No | No |
| VxRail V570 | il V570 Yes Yes | | No | No |
| VxRail V570F | Yes | Yes | No | No |

i) NOTE: * indicates device added in this release.

Supported Dell Storage modules

The following table lists the supported Dell Storage modules.

Table 10. Supported Dell Storage modules

| | Supported OpenManage Enterprise features | | | | |
|-----------------|--|-----|-----------------------------|---|--|
| Storage module | module Inventory Monitoring | | Managing device firmware | Managing device configurations and deployment | |
| PowerEdge FD332 | Yes | Yes | No | No | |

Table 10. Supported Dell Storage modules (continued)

| Storage module | Supported OpenManage Enterprise features | | | | |
|----------------------|--|-------------------|-----------------------------|---|--|
| | Inventory | Monitoring health | Managing device firmware | Managing device configurations and deployment | |
| PowerEdge MX5016S | Yes | Yes | Yes | No | |

Supported Dell Storage devices—previously Dell Compellent devices

The following table lists the supported Dell Storage devices—previously Dell Compellent devices.

Table 11. Supported Dell Storage devices

| | Supported OpenManage Enterprise features | | | | | | |
|----------------------|--|------------------------------|-----------------------------|---|--|--|--|
| Storage devices | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment | | | |
| FS8600 version 6 | Yes | Yes | No | No | | | |
| SC4020 | Yes | Yes | No | No | | | |
| SC7020 | Yes Yes | | No | No | | | |
| SC8000 | Yes | Yes | No | No | | | |
| SCv3000 | Yes | Yes | No | No | | | |
| SC9000 | Yes | Yes | No | No | | | |
| SC5020 | Yes | Yes | No | No | | | |
| SCv3020 | Yes | Yes | No | No | | | |
| SC3020 version 7.5.1 | Yes | Yes | No | No | | | |

(i) NOTE: * indicates device added in this release.

The following table lists the supported Dell storage devices grouped under the DELL PowerVault MD Series .

Table 12. Supported Dell Storage devices - PowerVault MD Series

| | Supported OpenManage Enterprise features | | | | | | |
|-----------------|--|------------------------------|-----------------------------|---|--|--|--|
| Storage devices | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment | | | |
| MD3220i | Yes | Yes | No | No | | | |
| MD3220 | Yes | Yes Yes | | No | | | |
| MD3200 | Yes Yes | | No | No | | | |
| MD3200i | Yes | Yes | No | No | | | |
| MD3800f | Yes | Yes | No | No | | | |
| MD3820f | Yes | Yes | No | No | | | |
| MD3860f | Yes | Yes | No | No | | | |
| MD3800i | Yes | Yes | No | No | | | |
| MD3820i | Yes | Yes | No | No | | | |
| MD3400 | Yes | Yes | No | No | | | |

Table 12. Supported Dell Storage devices - PowerVault MD Series (continued)

| | Supported OpenManage Enterprise features | | | | | |
|-----------------|--|------------------------------|-----------------------------|---|--|--|
| Storage devices | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment | | |
| MD3420 | Yes | Yes | No | No | | |
| MD3460 | Yes | Yes | No | No | | |
| MD3060e | Yes | Yes | No | No | | |

The following table lists the supported Dell Storage devices grouped under the DELL EMC PowerVault ME4 Series.

Table 13. Supported Dell Storage devices - DELL EMC PowerVault ME4 Series

| | Supported OpenManage Enterprise features | | | | | |
|------------------------------|--|------------------------------|-----------------------------|---|--|--|
| Storage devices | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment | | |
| ME4012 | Yes | Yes | No | No | | |
| ME4024 | Yes | Yes | No | No | | |
| ME4084 (not in JBOD mode) | Yes | Yes | No | No | | |

The following table lists the supported Dell Storage devices grouped under the DELL EMC PowerVault NX Series.

Table 14. Supported Dell Storage devices - DELL EMC PowerVault NX Series

| | Supported OpenManage Enterprise features | | | | | |
|-----------------|--|------------------------------|-----------------------------|---|--|--|
| Storage devices | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment | | |
| NX3340 | Yes | Yes | No | No | | |
| NX3240 | Yes | Yes | No | No | | |

Supported Dell Networking devices—previously Dell Force10 devices

The following table lists the supported Dell Networking devices.

Table 15. Supported Networking devices

| | Supported OpenManage Enterprise features | | | | | |
|-----------------------|--|------------------------------|-----------------------------|---|---|--|
| Networking devices | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment | Dell Networking OS version | |
| MX5108N | Yes | Yes | No | No | OS10 | |
| MX9116N | Yes | Yes | No | No | OS10 | |
| MXG610S | Yes | Yes | No | No | NOTE: These switches are managed via OME-M. | |
| MXL 10/40GbE | Yes | Yes | No | No | OS9 NOTE: These switches are | |

Table 15. Supported Networking devices (continued)

| | | Supported OpenManage Enterprise features | | | | | | |
|-----------------------|-------------------------------|--|-----------------------------|---|--------------------------------|--|--|--|
| Networking devices | Discovery and inventory | Monitoring and device alerts | Managing device firmware | Managing device configurations and deployment | Dell Networking OS version | | | |
| | | | | | managed via M1000e chassis. | | | |
| N3248TE | Yes | Yes | No | No | OS10.5.2.0 | | | |
| S3048-ON | Yes | Yes | No | No | OS9 | | | |
| S4048-ON | Yes | Yes | No | No | OS9 | | | |
| S4112F-ON | Yes | Yes | No | No | | | | |
| S4112T-ON | Yes | Yes | No | No | | | | |
| S4128F-ON | Yes | Yes | No | No | | | | |
| S4128T-ON | Yes | Yes | No | No | 0.040 | | | |
| S4148F-ON | Yes | Yes | No | No | OS10 | | | |
| S4148FE-ON | Yes | Yes | No | No | | | | |
| S4148T-ON | Yes | Yes | No | No | | | | |
| S4148U-ON | Yes | Yes | No | No | | | | |
| S4248FB | Yes | Yes | No | No | OS10.5.2.0 | | | |
| S4248FB-ON | Yes | Yes | No | No | OS10 | | | |
| S4248FBL-ON | Yes | Yes | No | No | | | | |
| S5148F-ON | Yes | Yes | No | No | OS10 | | | |
| S5212F-ON | Yes | Yes | No | No | OS10 | | | |
| S5224F-ON | Yes | Yes | No | No | | | | |
| S5232F | Yes | Yes | No | No | 0.040 | | | |
| S5248F-ON | Yes | Yes | No | No | OS10 | | | |
| S5296F-ON | Yes | Yes | No | No | | | | |
| S5296F | Yes | Yes | No | No | OS10.5.2.0 | | | |
| S6010 | Yes | Yes | No | No | OS10.5.2.0 | | | |
| S6010-ON | Yes | Yes | No | No | OS10 | | | |
| S6100-ON | Yes | Yes | No | No | OS9 | | | |
| Z9100 | Yes | Yes | No | No | OS10.5.2.0 | | | |
| Z9100-ON | Yes | Yes | No | No | OS9 | | | |
| Z9264F | Yes | Yes | No | No | OS10.5.2.0 | | | |
| Z9264F-ON | Yes | Yes | No | No | OS10 | | | |
| Z9332F | Yes | Yes | No | No | OS10 | | | |
| C9010 | Yes | Yes | No | No | OS9.14.2.8 | | | |
| C1048 | Yes | Yes | No | No | OS9.14.2.8 | | | |

i NOTE: * indicates device added in this release.

OEM devices

Dell EMC OEM devices (rebranded or debranded PowerEdge servers), when discovered, are classified under **SYSTEM GROUPS** > **All Devices** > **Servers** > **OEM Servers** on the **All Devices** page. If both the server and RAC of the OEM device are discovered, they are correlated and displayed as one device under the **OEM Devices** group. Most of the functionality available to the PowerEdge servers—such as tasks, reports, and filters—are also available to the PowerEdge OEM servers. However, system update may not be possible if it is not supported by the OEM device module.

Supported hypervisors on management stations

i NOTE: * indicates a newly-added item.

Supported VMware vSphere versions:

- vSphere ESXi 5.5
- vSphere ESXi 6.0
- vSphere ESXi 6.5
- vSphere ESXi 6.5 U3
- vSphere ESXi 6.7
- vSphere ESXi 6.7 U1
- vSphere ESXi 6.7 U3
- vSphere ESXi 7.0
- vSphere ESXi 7.0 U1
- vSphere ESXi 7.0 U2

Microsoft Hyper-V supported on:

- Windows Server 2012 R2
- Windows Server 2016
- Windows Server 2019

KVM supported on:

- Red Hat Enterprise Linux 6.5
- Red Hat Enterprise Linux 7.0
- Red Hat Enterprise Linux 7.2
- Red Hat Enterprise Linux 7.6
- Red Hat Enterprise Linux 7.7
- Red Hat Enterprise Linux 8.0
- Red Hat Enterprise Linux 8.1
- Red Hat Enterprise Linux 8.2
 Red Hat Enterprise Linux 8.3 *

Supported operating systems for in-band device management

Supported operating systems on managed nodes

The following table lists the supported operating systems on the managed devices.

Table 16. Supported operating systems on managed nodes

| | Supported OpenManage Enterprise features | | | | |
|-------------------|--|---------------|---|---------------|--|
| Operating systems | Discovery and Inventory | Device Alerts | Managing device configurations and deployment | Driver Update | |
| Windows 2016 | Yes | Yes | No | Yes | |

Table 16. Supported operating systems on managed nodes (continued)

| | Supported OpenManage Enterprise features | | | | |
|-------------------|--|---------------|---|---------------|--|
| Operating systems | Discovery and Inventory | Device Alerts | Managing device configurations and deployment | Driver Update | |
| Windows 2019 | Yes | Yes | No | Yes | |
| Azure Stack HCI | Yes | Yes | No | No | |
| ESXi 7.0 | Yes | Yes | No | No | |
| ESXi 7.0 U1 | Yes | Yes | No | No | |
| ESXi 7.0 U2 | Yes | Yes | No | No | |
| ESXi 6.7 U3 | Yes | Yes | No | No | |
| RHEL 7.8 | Yes | Yes | No | No | |
| RHEL 7.9 | Yes | Yes | No | No | |
| RHEL 8.1 | Yes | Yes | No | No | |
| RHEL 8.2 | Yes | Yes | No | No | |
| RHEL 8.3* | Yes | Yes | No | No | |
| Ubuntu 18.04.4 | Yes | Yes | No | No | |
| Ubuntu 20.04 | Yes | Yes | No | No | |
| SLES 15 SP2 | Yes | Yes | No | No | |

i NOTE: * indicates a newly-added item.

Supported browsers

- Microsoft Internet Explorer 11 and later (64-bit)
- Mozilla Firefox 52 and later
- Google Chrome 58 and later
- Microsoft Edge version 41.16299 and later

Supported plugins

The following table lists the supported plugins that can be enabled for additional OpenManage Enterprise monitoring and management capabilities.

Table 17. Supported Plugins

| Supported Plugin | Plugin Function |
|--|---|
| Dell EMC Power Manager | Enables PowerEdge servers' power management and allows administrators to view, measure, and control server power consumption. |
| Dell EMC OpenManage Enterprise Services (formerly Support Assist) | Enables proactive and predictive monitoring and management support for devices with ProSupport and ProSupport Plus entitlements. |
| Dell EMC Update Manager (UMP) | Enables administrators to create and manage repositories for PowerEdge devices with iDRAC or Windows that are managed in OpenManage Enterprise. |

Table 17. Supported Plugins (continued)

| Supported Plugin | Plugin Function | |
|------------------|---|--|
| | Enables administrators to register with the Dell EMC CloudIQ, select the device groups for data transfer to CloudIQ for proactive monitoring and measurement of overall health of the selected devices. | |

Minimum recommended hardware

This table describes the minimum recommended hardware for OpenManage Enterprise.

Table 18. Minimum recommended hardware

| Minimum recommended hardware | Large deployments | Small deployments |
|--|-------------------|-------------------|
| Number of devices that can be managed by the appliance | Up to 8000 | 1000 |
| RAM | 32 GB | 16 GB |
| Processors | 8 cores total | 4 cores total |
| Hard drive | 400 GB | 400 GB |

Contacting Dell

NOTE: If you do not have an active Internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.

Dell provides several online and telephone-based support and service options. Availability varies by country and product, and some services may not be available in your area. To contact Dell for sales, technical support, or customer service issues:

- 1. Go to Dell.com/support.
- 2. Select your support category.
- 3. Verify your country or region in the Choose a Country/Region drop-down list at the bottom of the page.
- 4. Select the appropriate service or support link based on your need.