# Inspiron 14 Gaming Setup and Specifications



## Notes, cautions, and warnings



NOTE: A NOTE indicates important information that helps you make better use of your product.



CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

**Copyright © 2016 Dell Inc. or its subsidiaries. All rights reserved.** Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

2016 - 10

Rev. A01

## **Contents**

٧/i	iews	٥
VI	Front	
	Left	
	Right	
	Base	
	Display	
	56pa,	
Sp	pecifications	13
	Dimensions and weight	13
	System information	13
	Memory	13
	Ports and connectors	14
	Communications	14
	Audio	14
	Storage	15
	Media-card reader	
	Keyboard	15
	Camera	16
	Touch pad	16
	Power adapter	17
	Battery	
	Display	
	Video	
	Computer environment	

Getting help and contacting Dell	22
Self-help resources	
Contacting Dell	23

## Set up your computer


1 Connect the power adapter and press the power button.



- **2** Follow the instructions on the screen to finish Windows setup:
  - a) Connect to a wireless network.



b) Sign in to your Microsoft account or create a new account.



### 3 Locate Dell apps.


### Table 1. Locate Dell apps



Register your computer

### Dell Help & Support








SupportAssist — Check and update your computer

## **Views**

## **Front**



#### 1 Power and battery-status light/hard-drive activity light

Indicates the battery-charge status or the hard-drive activity.



NOTE: Press Fn+H to toggle this light between power and batterystatus light and hard-drive activity light.

#### Hard-drive activity light

Turns on when the computer reads from or writes to the hard drive.

#### Power and battery-status light

Indicates the power and battery-charge status.


**Solid white** — Power adapter is connected and the battery has more than 5% charge.

**Amber** — Computer is running on battery and the battery has less than 5% charge.

#### Off

- Power adapter is connected and the battery is fully charged.
- Computer is running on battery and the battery has more than 5% charge.
- Computer is in sleep state, hibernation, or turned off.

## Left



#### 1 Security-cable slot

Connect a security cable to prevent unauthorized movement of your computer.

#### 2 Power-adapter port

Connect a power adapter to provide power to your computer and charge the battery.

#### 3 USB 3.0 port

Connect peripherals such as storage devices and printers. Provides data transfer speeds up to 5 Gbps.

#### Media-card reader 4

Reads from and writes to media cards.

## Right



#### 1 Headset port

Connect a headphone or a headset (headphone and microphone combo).

#### 2 USB 3.0 port

Connect peripherals such as storage devices and printers. Provides data transfer speeds up to 5 Gbps.

#### 3 USB 3.0 port with PowerShare

Connect peripherals such as storage devices and printers.

Provides data transfer speeds up to 5 Gbps. PowerShare enables you to charge your USB devices even when your computer is turned off.



NOTE: If your computer is turned off or in hibernate state, you must connect the power adapter to charge your devices using the PowerShare port. You must enable this feature in the BIOS setup program.



NOTE: Certain USB devices may not charge when the computer is turned off or in sleep state. In such cases, turn on the computer to charge the device.

#### 4 HDMI port

Connect a TV or another HDMI-in enabled device. Provides video and audio output.

#### 5 Network port

Connect an Ethernet (RJ45) cable from a router or a broadband modem for network or internet access.

### Base



#### Left-click area

Press to left-click.

#### 2 Touch pad

Move your finger on the touch pad to move the mouse pointer. Tap to left-click and two finger tap to right-click.

#### 3 Right-click area

Press to right-click.

#### 4 Power button

Press to turn on the computer if it is turned off, in sleep state, or in hibernate state.

Press to put the computer in sleep state if it is turned on.

Press and hold for 4 seconds to force shut-down the computer.



NOTE: You can customize the power-button behavior in Power Options. For more information, see *Me and My Dell* at <a href="https://www.dell.com/support/manuals">www.dell.com/support/manuals</a>.

## Display



#### 1 Left microphone

Provides digital sound input for audio recording and voice calls.

#### 2 Camera

Enables you to video chat, capture photos, and record videos.

#### 3 Camera-status light

Turns on when the camera is in use.

### 4 Right microphone

Provides digital sound input for audio recording and voice calls.

### 5 Service Tag label

The Service Tag is a unique alphanumeric identifier that enables Dell service technicians to identify the hardware components in your computer and access warranty information.

## **Specifications**

## Dimensions and weight

#### Table 2. Dimensions and weight

Height 25.10 mm (0.99 in) Width 348.90 mm (13.74 in) Depth 254.20 mm (10 in) 2.23 kg (4.92 lb) Weight (maximum)



NOTE: The weight of your computer varies depending on the configuration ordered and the manufacturing variability.

## System information

#### Table 3. System information

Inspiron 14-7466 Computer model

Processor 6<sup>th</sup> generation Intel Core i5/i7

Chipset Intel HM170

## Memory

#### Table 4. Memory specifications

Two SODIMM slots Slots

Type DDR4

2133 MHz Speed

Configurations supported 4 GB, 8 GB, 16 GB, and 32 GB

## Ports and connectors

Table 5. Ports and connectors specifications

External:	
Network	One RJ-45 port
USB	<ul><li>One USB 3.0 port with PowerShare</li><li>Two USB 3.0 ports</li></ul>
Audio/Video	<ul><li>One HDMI port</li><li>One headset (headphone and microphone combo) port</li></ul>

#### Table 6. Ports and connectors specifications

Internal:	
M.2 Card	<ul><li>One M.2 slot for SSD card</li><li>One M.2 slot for WiFi/Bluetooth</li></ul>

## Communications

#### Table 7. Communication specifications

Wireless

• Wi-Fi 802.11 ac

• Bluetooth 4.2

• Miracast

## **Audio**

### Table 8. Audio specifications

Controller Realtek ALC3246 with Waves
MaxxAudio Pro

Speakers Two

Speaker output . Average: 2 W

Peak: 2.5 W

Subwoofer One

Subwoofer output • Average: 3 W

Peak: 3.5 W

Microphone Digital-array microphones in camera

assembly

Volume controls Media-control shortcut keys

## Storage

#### Table 9. Storage specifications

Interface · SATA 6 Gbps

· PCle/NVMe

Hard drive One 2.5-inch drive (SATA)

Solid-state drive One M.2 drive (SATA or PCle/NVMe)

## Media-card reader

#### Table 10. Media-card reader specifications

Type One 2-in-1 slot

Cards supported . SD card

MultiMedia Card (MMC)

## Keyboard

#### Table 11. Keyboard specifications

Type · Chiclet backlit keyboard (red/white)



## NOTE: The red backlit keyboard is available only in specific regions.

Non-backlit keyboard

Shortcut keys

Some keys on your keyboard have two symbols on them. These keys can be used to type alternate characters or to perform secondary functions. To type the alternate character, press Shift and the desired key. To perform secondary functions, press Fn and the desired key.



NOTE: You can define the primary behavior of the function keys (F1-F12) by changing Function Key Behavior in BIOS setup program.

Keyboard shortcuts

## Camera

#### Table 12. Camera specifications

Resolution

Still image: 0.92 megapixel

Video: 1280 x 720 (HD) at 30 fps

(maximum)

Diagonal viewing angle

74 degrees

## Touch pad

#### Table 13. Touch pad

Resolution

Horizontal: 1228

· Vertical: 748

Dimensions

Height: 65 mm (2.56 in)Width: 105 mm (4.13 in)

## Power adapter

#### Table 14. Power adapter specifications

Type 90 W

Input voltage 100 VAC-240 VAC

Input frequency 50 Hz-60 Hz

Input current (maximum) 2.50 A

Output current (continuous) 4.62 A

Rated output voltage 19.50 VDC

Temperature range: Operating 0°C to 40°C (32°F to 104°F)

Temperature range: Storage -40°C to 70°C (-40°F to 158°F)

## **Battery**

#### Table 15. Battery specifications

Type 4-cell "smart" lithium ion (56 WHr)

 Width
 77.45 mm (3.05 in)

 Depth
 169.70 mm (6.68 in)

 Height
 11.30 mm (0.44 in)

 Weight (maximum)
 0.25 kg (0.55 lb)

Voltage 15.20 VDC

Charging time (approximate) 4 hours (when the computer is off)

Operating time Varies depending on operating conditions

and can significantly reduce under certain power-intensive conditions.

Life span (approximate) 300 discharge/charge cycles

Temperature range • Operating: 0°C to 35°C (32°F to

95°F)

• Storage: -20°C to 65°C (-4°F to 149°F)

Coin-cell battery CR-2032

## Display

#### Table 16. Display specifications

Туре	14-inch HD	14-inch FHD
Resolution (maximum)	1366 x 768	1920 x 1080
Viewing angle (Left/ Right/Up/Down)	40/40/10/30 degrees	40/40/10/30 degrees
Pixel pitch	0.2265 mm	0.161 mm
Height (excluding bezel)	173.95 mm (6.84 in)	
Width (excluding bezel)	309.4 mm (12.18 in)	
Diagonal (excluding bezel)	354.95 mm (13.97 in)	
Refresh rate	60 Hz	
Operating angle	140 degrees	
Controls	Brightness can be controlled using shortcut keys	

## Video

Table 17. Video specifications

	Integrated	Discrete
Controller	Intel HD Graphics 530	NVIDIA GeForce GTX950M
Memory	Shared system memory	4 GB GDDR5

## Computer environment

Airborne contaminant level: G1 as defined by ISA-S71.04-1985

Table 18. Computer environment

	Operating	Storage
Temperature range	0°C to 35°C (32°F to 95°F)	-40°C to 65°C (-40°F to 149°F)
Relative humidity (maximum)	10% to 90% (non- condensing)	0% to 95% (non- condensing)
Vibration (maximum)*	0.66 GRMS	1.30 GRMS
Shock (maximum)	110 G <sup>†</sup>	160 G <sup>‡</sup>
Altitude (maximum)	-15.2 m to 3048 m (-50 ft to 10,000 ft)	-15.2 m to 10,668 m (-50 ft to 35,000 ft)

<sup>\*</sup> Measured using a random vibration spectrum that simulates user environment.

<sup>†</sup> Measured using a 2 ms half-sine pulse when the hard drive is in use.

<sup>‡</sup> Measured using a 2 ms half-sine pulse when the hard-drive head is in parked position.

## **Keyboard shortcuts**

Table 19. List of keyboard shortcuts

Keys	Description
F1	Mute audio
F2 📦	Decrease volume
F3 🕬	Increase volume
F4 1€4	Play previous track/chapter
F5 ▶II	Play/Pause
F6 ▶₩	Play next track/chapter
F8	Switch to external display
F9 ρ	Search
F10	Toggle keyboard backlight (optional)
F11 泰	Decrease brightness
F12 ☀	Increase brightness
Fn + PrtScr	Turn off/on wireless
Fn + B	Pause/Break
Fn + Insert	Sleep
Fn + S	Toggle scroll lock

Keys	Description
Fn + H	Toggle between power and battery- status light/hard-drive activity light
Fn + R	System request
Fn + Ctrl	Open application menu
Fn + Esc	Toggle Fn-key lock
Fn + End →	End
Fn + ←Home	Home
Fn + PgDn	Page down
Fn + TPgUp	Page up

## Getting help and contacting Dell

## Self-help resources

You can get information and help on Dell products and services using these self-help resources:

#### Table 20. Self-help resources

Information about Dell products and services

Dell Help & Support app

Tips

Contact Support

Online help for operating system

Troubleshooting information, user manuals, setup instructions, product specifications, technical help blogs, drivers, software updates, and so on.

Dell knowledge base articles for a variety of computer concerns.

Learn and know the following information about your product:

- Product specifications
- Operating system

www.dell.com





In Windows search, type Help and Support, and press Enter.

www.dell.com/support/windows www.dell.com/support/linux www.dell.com/support

- 1 Go to www.dell.com/support.
- 2 Type the subject or keyword in the Search box.
- 3 Click **Search** to retrieve the related articles.

See Me and My Dell at www.dell.com/ support/manuals.

- · Setting up and using your product
- Data backup
- · Troubleshooting and diagnostics
- Factory and system restore
- BIOS information

To locate the *Me and My Dell* relevant to your product, identify your product through one of the following:

- Select Detect Product.
- Locate your product through the drop-down menu under View Products.
- Enter the **Service Tag number** or **Product ID** in the search bar.

## **Contacting Dell**

To contact Dell for sales, technical support, or customer service issues, see www.dell.com/contactdell.



NOTE: Availability varies by country and product, and some services may not be available in your country.



NOTE: If you do not have an active internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.