


Dell EMC OpenManage Ansible Modules

Version 2.0.1 Release Notes

Notes, cautions, and warnings

 **NOTE:** A NOTE indicates important information that helps you make better use of your product.

 **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

Dell EMC OpenManage Ansible Modules

Version 2.0.1

© Copyright 2018 - 2019 Dell Inc.

GNU General Public License v3.0+ (see COPYING or <https://www.gnu.org/licenses/gpl-3.0.txt>)

All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

Chapter 1:	4
Dell EMC OpenManage Ansible Modules Version 2.0.....	4
Dell EMC OpenManage Ansible Modules.....	4
Importance.....	4
Platform(s) Affected.....	4
What is Supported.....	4
What's new?.....	5
Fixes.....	5
Known Issues.....	5
Limitations.....	5
Installation Prerequisites.....	5
Software Requirements.....	6
Installation Procedure.....	6
Accessing documents from the Dell EMC support site.....	6
Contacting Dell.....	6

Topics:

- [Dell EMC OpenManage Ansible Modules Version 2.0](#)

Dell EMC OpenManage Ansible Modules Version 2.0

Dell EMC OpenManage Ansible Modules

Dell EMC OpenManage Ansible Modules allows data center and IT administrators to use RedHat Ansible to automate and orchestrate the configuration, deployment, and update of Dell EMC PowerEdge Servers (12th generation of PowerEdge servers and later) and modular infrastructure by leveraging the management automation capabilities in-built into the Integrated Dell Remote Access Controller (iDRAC) and OpenManage Enterprise (OME) respectively.

With the latest release of Dell EMC OpenManage Ansible Modules, the capabilities have improved with support for OpenManage Enterprise. OpenManage Ansible Modules simplifies and automates provisioning, deployment, and updates of PowerEdge servers and modular infrastructure. It allows system administrators and software developers to introduce the physical infrastructure provisioning into their software provisioning stack, integrate with existing DevOps pipelines and manage their infrastructure using version-controlled playbooks, server configuration profiles, and templates in line with the Infrastructure-as-Code (IaC) principles.

Version

2.0.1

Release Date

June 2019

Previous Version

2.0

Importance

OPTIONAL: Dell EMC recommends the customer review specifics about the update to determine if it applies to your system. The update contains changes that impact only certain configurations, or provides new features that may or may not apply to your environment.

Platform(s) Affected

For the list of supported platforms, see the section **Support Matrix** in the **Dell EMC OpenManage Ansible Modules version 2.0.1 Installation Guide**.

What is Supported

For information on the hardware and software requirements, see **Dell EMC OpenManage Ansible Modules version 2.0.1 Installation Guide**.

What's new?

The key features in OpenManage Ansible Modules version 2.0.1 include:

- **idrac_firmware** and **idrac_server_config_profile** modules are added.
- **dellemc_idrac_firmware** and **dellemc_idrac_server_config_profile** modules are deprecated.

For a complete list of supported features that you can leverage, see **Dell EMC OpenManage Ansible Modules Version 2.0.1 User's Guide**.

Fixes

Issue 1(134624)

Description: All iDRAC modules fail to run with Ansible v2.8.0 and OpenManage Ansible Modules v2.0.

Known Issues

Issue 1(86360)

Description: Creating iDRAC users using `dellemc_configure_idrac_users` module does not update the provided user properties for the created user on 14G servers.

Resolution: In case the user is not created with all the required user settings, change the user setting with action option modify in the `dellemc_configure_idrac_users` module.

Issue 2(93817)

Description: `dellemc_delete_lc_job_queue` may fail to clear all the jobs from iDRAC in case there are multiple jobs with same name and with different status present on iDRAC for server with iDRAC firmware version 2.50.50.50 and below.

Issue 3(126402)

Description: Creating template using **`dellemc_ome_template`** module may fail on OMEnt 3.1 in case no template is created on this OMEnt within the 24 hours (approximately) after the initial OMEnt installation and setup.

Resolution: A script is provided to fix the issue in OMEnt 3.1 through PSQN which will create a folder in CIFS share. See <https://kb.dell.com/infocenter/index?page=content&id=SLN316882> for more details.

Limitations

- **GracefulShutdown** choice of `change_power` option for **`dellemc_change_power_state`** module is supported only on iDRAC firmware versions 3.00.00.00 and above.
- `ipmiserialprivilege_users` option of **`dellemc_configure_idrac_users`** module is not supported for Modular servers.
- `secure_boot_mode` option of **`dellemc_configure_bios`** module is supported only on 14th generation of Dell EMC PowerEdge servers.

Installation Prerequisites

For installation prerequisites, see **Dell EMC OpenManage Ansible Modules Version 2.0.1 Installation Guide**.

Software Requirements

For information on the hardware and software requirements, see **Dell EMC OpenManage Ansible Modules Version 2.0.1 Installation Guide**.

Installation Procedure


For the installation instructions, see **Dell EMC OpenManage Ansible Modules Version 2.0.1 Installation Guide**.

Accessing documents from the Dell EMC support site

You can access the required documents using the following links:

- For Dell EMC Enterprise Systems Management documents — www.dell.com/esmmanuals
- For Dell EMC OpenManage documents — www.dell.com/openmanagemanuals
- For Dell EMC Remote Enterprise Systems Management documents — www.dell.com/esmmanuals
- For iDRAC and Dell Lifecycle Controller documents — www.dell.com/idracmanuals
- For Dell EMC OpenManage Connections Enterprise Systems Management documents — www.dell.com/esmmanuals
- For Dell EMC Serviceability Tools documents — www.dell.com/serviceabilitytools
- 1. Go to www.dell.com/support.
- 2. Click **Browse all products**.
- 3. From **All products** page, click **Software**, and then click the required link from the following:
 - **Analytics**
 - **Client Systems Management**
 - **Enterprise Applications**
 - **Enterprise Systems Management**
 - **Public Sector Solutions**
 - **Utilities**
 - **Mainframe**
 - **Serviceability Tools**
 - **Virtualization Solutions**
 - **Operating Systems**
 - **Support**
- 4. To view a document, click the required product and then click the required version.
- Using search engines:
 - Type the name and version of the document in the search box.

Contacting Dell

 **NOTE:** If you do not have an active Internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.

Dell provides several online and telephone-based support and service options. Availability varies by country and product, and some services may not be available in your area. To contact Dell for sales, technical support, or customer service issues:

1. Go to **Dell.com/support**.
2. Select your support category.
3. Verify your country or region in the **Choose a Country/Region** drop-down list at the bottom of the page.
4. Select the appropriate service or support link based on your need.